

.REM \*

IDENTIFICATION  
-----

PRODUCT CODE: MAINDEC-11-DZRKH-G-D  
PRODUCT NAME: RK11/RK05 PERFORMANCE EXERCISER  
DATE: APRIL, 1977  
MAINTAINER: DIAGNOSTIC GROUP  
AUTHOR: JIM KAPADIA  
REVISIONS: TOM SAWYER, GEORGE GALLANT, CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1974,1977 BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS  
\*\*\*\*\*

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESSES
4.0	PROGRAM CONTROL MODES
4.1	PAPER TAPE LOADING
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	SWITCH OPTIONS
7.0	PROGRAM STRUCTURE AND DESCRIPTION
7.1	NON-EXERCISER TESTS
7.2	EXERCISER PROGRAM
8.0	LOOPING CAPABILITIES
9.0	TRANSFER DATA LOGGING
10.0	ERROR LOGGING
11.0	ERROR REPORTING AND RECOVERY
12.0	SUBROUTINES AND HANDLERS

## 1.0 ABSTRACT

THE RK11/RK05 PERFORMANCE EXERCISER IS A HIGH LEVEL EXERCISER PROGRAM AIMED AT SIMULATING A RK11/RK05 SYSTEM ENVIRONMENT AND CHECKING FOR ERRORS THAT ARISE IN SUCH AN ENVIRONMENT (INTERACTION, POLLING, ETC). IT ALSO PROVIDES A MEANS OF EVALUATING A SYSTEM THROUGH ITS ERROR LOGGING AND DATA-TRANSFER LOGGING FACILITIES.

AT THE BEGINNING OF THE PROGRAM THERE IS A SERIES OF TESTS SPECIFICALLY AIMED AT DETECTING AND ANALYZING FAILURES ASSOCIATED WITH BOUNDARY CONDITION TRANSFERS.

THE LATTER PART (AND THE MORE SIGNIFICANT ONE) CONSISTS OF THE EXERCISER.

## 2.0 REQUIREMENTS

### 2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELTYPE
- B. 8K OF MEMORY - 12K FOR CHAIN MODE
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES (DRIVE TYPES MAY BE MIXED)

### 2.2 PRELIMINARY PROGRAMS

SINCE THIS IS A HIGH-LEVEL EXERCISER PROGRAM THE CONTROLLER AND THE DRIVE SHOULD BE FREE OF BASIC FAULTS. IT IS POSSIBLE TO HANG THE PROGRAM IF THE HEAD POSITIONING LOGIC IS FAULTY ON DUAL DENSITY DRIVES. THUS THE FOLLOWING PROGRAMS SHOULD BE RUN BEFORE ATTEMPTING TO USE THIS PROGRAM.

- A. RK11 BASIC LOGIC TESTS (I AND II)
- B. RK11/RK05 DYNAMIC TESTS
- C. RK05 UTILITY PACKAGE (IF NEEDED)

### 2.3 EXECUTION TIME

THIS VARIES FROM 30 TO 90 MINUTES FOR A PASS. IT SHOULD BE NOTED THAT THIS IS AN EXERCISER LEVEL PROGRAM AND SHOULD BE PREFERABLY RUN FOR A LONG PERIOD OF TIME.  
NOTE: THE FIRST PASS IS A SHORT (5-20 MINUTE) PASS TO SERVE AS A QUICK VERIFY OF THE RK SUBSYSTEM.

## 3.0 STARTING ADDRESS

200 - ALL SWITCHES DOWN. SEE SEC. 6.0 FOR SWITCHES.

210 - RESTART ADDRESS. THE RESTART ADDRESS PROVIDES THE USER WITH AN ABILITY TO GO STRAIGHT TO EXERCISER PART OF THE PROGRAM (SKIPPING TESTS 1-7). THERE IS A SWITCH OPTION (SW 4) WHICH ALLOWS THE USER TO INHIBIT THE REWRITE OF RANDOM PATTERNS ON ALL DRIVES, ON RESTART. SEE SEC- 6.9.

4.0 PROGRAM CONTROL MODES AND OPERATOR ACTION

PAPER TAPE LOADING  
RKDP DUMP MODE  
RKDP CHAIN MODE  
ACT11

4.1 PAPER TAPE LOADING

4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR ABSOLUTE TAPES.

4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.

4.1.3 LOAD ADDRESS 200

4.1.4 SET SWITCHES IF DESIRED (SEE SEC 6.0) AND PRESS START

4.1.5 THE PROGRAM IDENTIFIES ITSELF

MAINDEC-11-DZRKH-G  
RK11/RK05 PERFORMANCE EXERCISER  
THEN IT PROCEEDS TO TEST THE DRIVES.

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED BY THE RKDP MONITOR.

4.2.2 SET SA=200. SELECT ANY SWITCHES YOU WANT AND PRESS START.

4.2.3 THE PROGRAM IDENTIFIES ITSELF AND PRINTS OUT:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'

IN RESPONSE TO THIS MESSAGE, PERFORM THE ACTIONS REQUESTED IF THE DRIVE ON WHICH THE RKDP PACK IS MOUNTED IS TO BE TESTED.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN LOADED FROM RKDP PACK ON DRIVE 'N'. AFTER IDENTIFYING ITSELF, THE FOLLOWING MESSAGE APPEARS:

'DRIVE 'N' NOT TESTED'

DRIVE 'N' WILL NOT BE TESTED SINCE THE RKDP PACK IS ON THAT DRIVE.



4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. AFTER IDENTIFYING ITSELF, ASCERTAINS THE NUMBER OF DRIVES PRESENT AND PROCEEDS TO TEST EACH OF THEM AS BEFORE.

5.0 DRIVE SELECTION

PUT ALL THE DRIVES THAT ARE TO BE EXERCISED AND TESTED ON 'RUN', WRITE ENABLE THEM. MAKE SURE THAT THE 'WRT PROT' IS OFF. THE PROGRAM RECOGNIZES THAT THESE DRIVES ARE ON LINE AND PROCEEDS TO TEST THEM. RK05F DRIVES WILL HAVE THE LETTER F TYPED AFTER THE DRIVE NUMBER.

IF A FATAL ERROR OCCURS ON A DRIVE WHILE THE PROGRAM IS RUNNING THE DRIVE IS AUTOMATICALLY Deselected ('DSELCT') AND DROPPED FROM THE DRIVE SELECTION LIST.

6.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (9). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'PUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY. ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1	HALT ON ERROR
SW<13>=1	INHIBIT ERROR PRINTOUTS
SW<12>=1	TYPE OUT THE ERROR HISTORY
SW<11>=1	DUMP OUT ALL RK11 REGISTERS
SW<10>=1	RING BELL ON ERROR
SW<09>=1	LOOP ON SPECIFIC ERROR
SW<08>=1	DUMP OUT TRANSFER DATA AND ERROR STATISTICS
SW<06>=1	SELECT BUS ADDRESS LIMITS FOR DATA TRANSFERS
SW<05>=1	HALT BEFORE DOING THE NEXT SET OF COMMANDS
SW<04>=1	DO NOT REWRITE THE DISKS ON 210 RETSAPT
SW<03>=1	TYPE OUT ELAPSED TIME AT ERROR
SW<02>=1	DROP DRIVE AFTER MAXIMUM ERRORS

SW<01>=1 TYPE SERIAL NUMBER OF ERRORING DRIVE  
SW<00>=1 TYPE ONLY ELAPSED TIME IF SW<08> AND SW<03> = 1

6.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION, PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

6.2 SW<13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON ERROR (SW 9).

6.3 SW<12>

IF THIS SWITCH IS SET WHEN AN ERROR OCCURS, INFORMATION ABOUT THE HISTORY OF THAT ERROR IS TYPED OUT.

THE FUNCTION THAT WAS BEING PERFORMED ON THE RK11 IS TYPED OUT, THE FUNCTION COULD BE EITHER A READ, WRITE, WRITE CHECK, READ CHECK, BESIDES THESE NORMAL FUNCTIONS, IT COULD BE A CONTROL RESET, DRIVE RESET OR POSITIONING OF THE HEADS (SEEKING). FOR THE FOUR FUNCTIONS THE INITIAL DISK ADDRESS, BUS ADDRESS AND WORD COUNT (2'S COMPLEMENT) ARE ALSO GIVEN. FOR DRIVE RESET AND POSITIONING THE DRIVE NUMBER OR WHICH THE OPERATION WAS BEING PERFORMED IS GIVEN.

SIMILAR INFORMATION IS TYPED OUT ABOUT THE FUNCTION THAT WAS DONE JUST BEFORE THE ONE GIVING THE ERROR.

6.4 SW<11>

IF THIS SWITCH IS SET WHEN AN ERROR OCCURS, THE CONTENTS OF ALL RK11 REGISTERS ARE TYPED OUT.

6.5 SW<09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE LOOP. LOOPING IS DONE WHEN AN ERROR OCCURS. NOTE THAT THERE ARE TWO CLASSES OF ERRORS AND HENCE TWO CLASSES OF ERROR LOOPS, REFER TO SEC 8.0 FOR THE DIFFERENCE IN THE ERROR LOOPS PROVIDED BY SW 9.

6.6 SW<08>

WHEN THIS SWITCH IS SET, THE ERROR AND TRANSFER DATA STATISTICS WHICH HAVE BEEN COLLECTED UNTIL THAT TIME, ARE TYPED OUT.

THE TRANSFER DATA STATISTICS GIVE THE NUMBER OF WORDS WRITTEN AND READ ON EACH DRIVE THAT IS PRESENT. IT SHOULD BE NOTED THAT READ CHECK AND WRITE CHECK ARE CONSIDERED TO BE ESSENTIALLY READ OPERATIONS.

THE ERROR STATISTICS GIVE THE NUMBER OF ERRORS THAT HAVE OCCURRED

(IF ANY) IN THE FOLLOWING CATEGORIES, ON THE DRIVES THAT ARE PRESENT:

CHECK SUM ERROR  
WRITE CHECK ERROR  
DATA COMPARISON ERROR  
HARD ERROR  
SEEK ERROR  
SEEK INCOMPLETE

ABORTS - WHEN AN ERROR OCCURS THE FUNCTION IS RETRIED TWICE. IF STILL THE ERROR PERSISTS THE FUNCTION IS ABORTED AND THE ABORT COUNT IS INCREMENTED FOR THAT DRIVE.

6.7 SW<06>

THIS SWITCH ENABLES THE USER TO SELECT THE LIMITS OF THE MEMORY BUS ADDRESSES BETWEEN WHICH THE DATA TRANSFERS WILL BE DONE. NORMALLY THE TRANSFERS ARE DONE BETWEEN THE LOWER LIMIT (HASEBA) AND THE HIGHER LIMIT (MAXBA). THESE TWO LIMITS ARE NORMALLY SELECTED BY THE PROGRAM AND USE THE MAXIMUM AVAILABLE MEMORY. IF THE USER WANTS TO DO DATA TRANSFERS BETWEEN SELECTED MEMORY ADDRESSES (EX: BETWEEN 12K AND 16K) THEN THIS SWITCH SHOULD BE SET AT THE STARTING OF THE PROGRAM. THE FOLLOWING MESSAGE APPEARS:

TYPE OCTAL BUS ADDRESS FOR DATA XFER, BETWEEN XXXXXX AND YYYYYY

LO LIMIT?  
HI LIMIT?

IN RESPONSE THE USER SHOULD TYPE IN ANY TWO BUS ADDRESSES (OCTAL) BETWEEN XXXXXX AND YYYYYY. IF THE USER TYPES IN ANYTHING OUT OF THE X AND Y RANGE THE QUESTION IS ASKED AGAIN.

THIS SWITCH COULD BE QUITE USEFUL IN DETERMINING WHETHER THE PROBLEM IS WITHIN THE RK11 OR OUTSIDE (IN MEMORY). NORMALLY, IF THE PROBLEM IS WITHIN THE RK11, ERRORS WILL KEEP ON OCCURRING REGARDLESS OF WHERE IN THE MEMORY DATA TRANSFERS ARE TAKING PLACE. ON THE OTHER HAND IF THE PROBLEM IS MEMORY RELATED, THE ERRORS WILL TEND TO DISAPPEAR FOR DATA TRANSFERS TO CERTAIN MEMORY BLOCKS AND WOULD REAPPEAR FOR OTHER ONES.

6.8 SW<05>

THIS SWITCH PROVIDES THE USER A CAPABILITY TO HALT THE PROGRAM AT A KNOWN POINT. THE HALT IS DONE AFTER THE CURRENT SET OF EIGHT COMMANDS IN THE QUEUE HAVE BEEN EXECUTED. THE "HALT" IS LOCATED AT THE BEGINNING OF THE 'GENBRO' ROUTINE, JUST BEFORE A SET OF 8 NEW COMMANDS IS GENERATED. AFTER THE PROGRAM HALTS, THE EXECUTION CAN BE RESUMED BY PRESSING CONTINUE, OR THE PROGRAM CAN BE STARTED BACK AT 200 OR RESTARTED AT 210.

6.9 SW<04>

THIS SWITCH PROVIDES THE USER WITH AN ABILITY TO SKIP THE TIME CONSUMING REWRITE OF ALL THE DISKS WHEN THE PROGRAM IS RESTARTED AT 210. THIS SWITCH CAN BE USED ONLY WHEN RESTARTING THE PROGRAM AT 210 WITH SW 4 SET. ON RESTARTING THE PROGRAM AT 210, THE INITIAL BOUNDARY CONDITION TESTS (TST1-TST7) ARE SKIPPED. IF SWITCH 4 IS SET, THE REWRITE OF ALL THE DISKS (WHICH WOULD HAVE BEEN NORMALLY DONE) IS ALSO SKIPPED. THE USER IS CAUTIONED TO USE THIS SWITCH CAREFULLY. THE DISKS SHOULD HAVE BEEN WRITTEN WITH RANDOM PATTERNS AT LEAST ONCE BEFORE RESTARTING THE PROGRAM AT 210. IT SHOULD BE NOTED THAT TESTS 1-7 WRITE ON CYLINDERS 0,1. ON RESTART, THE STATISTICS COLLECTED SO FAR ARE SAVED.

6.10 SW<03>

THIS SWITCH ALLOWS THE TIMEOUT OF THE ELAPSED TIME AT WHICH ERROR OCCURRED. THE TIMING STARTS AT THE BEGINNING OF THE EXERCISER PROGRAM. THIS SWITCH SHOULD NOT BE SET IF KW11L LINE CLOCK IS NOT AVAILABLE ON THE SYSTEM.

6.11 SW<02>

THIS SWITCH CAUSES DRIVES WHICH EXCEED A MAXIMUM NUMBER OF ERRORS TO BE DEASSIGNED BY THE PROGRAM. THE PROGRAM CONTINUES TESTING OTHER DRIVES WHICH HAVE NOT ACCUMULATED THE REQUIRED NUMBER OF ERRORS.

6.12 SW<01>

IF THIS SWITCH IS SET, THE PROGRAM ALLOWS A SERIAL NUMBER TO BE SPECIFIED FOR EACH DRIVE TESTED. THE SERIAL NUMBER IS TYPED WITH EACH ERROR MESSAGE FOR THAT PARTICULAR DRIVE.

6.13 SW<00>

IF SW<08> AND SW<03> ARE SET, SETTING THIS SWITCH TYPES OUT THE ELAPSED TIME FROM THE START OF THE PROGRAM.

## 7.0 EXERCISER PROGRAM

THE EXERCISER PROGRAM ATTEMPTS TO SIMULATE A DISK OPERATING SYSTEM ENVIRONMENT BY DOING RANDOM EVENTS (FUNCTIONS) USING RANDOMLY SELECTED PARAMETERS (DISK ADDRESS, BUS ADDRESS, WORD COUNT, ETC). AN ATTEMPT IS MADE TO DETECT INTER-ACTION PROBLEMS, OVERLAPPING SEEK PROBLEMS, ETC. FOR EXAMPLE, OVER 500 MILLION BITS ARE TRANSFERRED PER HOUR ON A TYPICAL RK11/RK05 SYSTEM (BASED ON 2 DRIVES, PDP11/50, 28K SYSTEM).

EIGHT JOBS OR COMMANDS ARE GENERATED AT A TIME (GEN8RQ) AND PUT IN A QUEUE TO BE PROCESSED. THE ALGORITHM WORKS AS FOLLOWS. COMMANDS IN THE QUEUE ARE PREPOSITIONED (HEADS) BY PERFORMING OVERLAPPING SEEKS. WHILE SOME OF THE DRIVES ARE BEING POSITIONED, THE LAST AVAILABLE (AND EXECUTABLE) COMMAND IS PERFORMED. THUS WHILE SOME DRIVES ARE BUSY POSITIONING THEIR HEADS, SOME DRIVE IS PERFORMING A FUNCTION (DATA TRANSFER, ETC). AS SOON AS THE CONTROLLER IS FREE, A CHECK IS MADE TO SEE IF THERE IS ANY DRIVE WHICH HAS ALREADY POSITIONED ITS HEAD. IF ONE IS FOUND THE COMMAND IS EXECUTED ON THAT DRIVE AND THE CONTROLLER AGAIN BECOMES BUSY. IF NO POSITIONED COMMAND IS FOUND, A CHECK IS MADE TO SEE IF THERE IS A COMMAND THAT IS TO BE POSITIONED. IF YES, IT IS POSITIONED AND THE LAST AVAILABLE COMMAND IS EXECUTED. IF IT IS FOUND THAT NO DRIVE NEEDS TO BE POSITIONED (THIS COULD HAPPEN IF THERE IS ONLY ONE COMMAND LEFT IN THE QUEUE OR THE REMAINING COMMANDS IN THE QUEUE ARE TO BE PERFORMED ON THE SAME DRIVE), THEN THE COMMANDS IS/ ARE EXECUTED.

THE ABOVE ALGORITHM HELPS SIMULATE A REAL ENVIRONMENT, AT THE SAME TIME MAXIMISING THE RATE OF DATA TRANSFERS. THE EXERCISER PROGRAM GIVES AN ELABORATE ERROR DETECTION CAPABILITY. THE STATE OF THE PROGRAM IS CONTINUOUSLY TRACKED BY SOFTWARE KEYS, FLAGS, ETC. THESE FLAGS AND KEYS HAVE BEEN EXPLAINED IN DETAIL AT THE BEGINING OF THE LISTINGS, WHERE THEY ARE DEFINED. ON DUAL DENSITY DRIVES, ONLY ONE LOGICAL DRIVE IS SELECTED DURING EACH QUEUE BUILD. THIS INSURES THAT OVERLAPPED SEEKS WILL NOT INTERFERE WITH THE HEAD POSITIONING LOGIC.

THE PARAMETERS USED FOR DOING THE COMMANDS ARE SELECTED RANDOMLY USING A RANDOM GENERATOR. THE FUNCTION TO BE PERFORMED IS SELECTED RANDOMLY FROM ONE OF THE FOUR: WRITE, READ, WRITE CHECK, OR READ CHECK. THE DRIVE NUMBER IS SELECTED FROM THE AVAILABLE DRIVES. THE DISK ADDRESS IS SELECTED OVER THE ENTIRE RANGE AND THE WORD COUNT AND BUS ADDRESS ARE SELECTED RANDOMLY IN SUCH A WAY THAT A NON-EXISTENT MEMORY ERROR OR OVERPUN CONDITION DOES NOT OCCUR.

RANDOM DATA BLOCKS ARE WRITTEN ON THE DISK. THE FIRST WORD OF EACH SECTOR BLOCK IS A NUMBER (2'S COMPLEMENT) INDICATING THE TOTAL NUMBER OF WORDS WRITTEN IN THAT SECTOR. THE REST OF THE WORDS IN THE BLOCK ARE GENERATED USING THE DISK ADDRESS (OF THAT SECTOR) AS THE RANDOM SEED NUMBER.

8.0 LOOPING CAPABILITIES:

SWITCH 9 GIVES LOOPING CAPABILITIES, ON ERROR. THERE ARE TWO CLASSES OF ERRORS:

- A. ERRORS OCCURING IN THE NON-EXERCISER PART OF THE PROGRAM (ERROR NUMBERS UNDER 100 IN THE ERROR ITEMS TABLE)
- B. ERRORS OCCURING IN THE EXERCISER PART OF THE PROGRAM (ERROR NUMBERS STARTING FROM 100 AND UP IN THE ERROR ITEMS TABLE)
- C. NON-EXERCISER SCOPE LOOPS: IN THIS CASE, THE PROGRAM LOOPS ON A SPECIFIC ERROR GIVING A NARROW SCOPE LOOP. THIS SCOPE LOOP IS SIMILIAR TO THE ONE PROVIDED IN THE RK11 BASIC LOGIC TEST AND DYNAMIC TEST, WHICH THE USER MIGHT BE FAMILIAR WITH.
- D. EXERCISER SCOPE LOOPS: WHEN AN ERROR OCCURS (AFTER TYPING OUT THE ERROR MESSAGE) CONTROL IS TRANSFERRED TO THE BEGINNING OF THE COMMAND-QUEUF. THE COMMANDS FROM THE FIRST COMMAND ONWARDS, ARE EXECUTED AGAIN TILL THE POINT OF ERROR. THIS LOOPING PROVIDES THE USER WITH A CAPABILITY TO PECREATE A SET OF EVENTS THAT LED TO THE EPROR.

9.0 TPANSFER DATA LOGGING

IN THIS PROGRAM, WHENEVER A DATA TRANSFER TAKES PLACE IT IS LOGGED WHETHER IT IS READ, READ CHECK, WRITE OR WRITE CHECK. SEPERATE COUNTS ARE KEPT FOR DATA TRANSFERS TAKING PLACE ON EACH DRIVE IN THE SYSTEM. AT ANY GIVEN TIME THE USER CAN GET THESE TRANSFER STATISTICS BY SETTING SWITCH 8 TO 1 (SEE SEC.6.6). THIS IS HELPFUL FOR EVALUATING A SYSTEM.

10.0 EPROR LOGGING

THROUGHOUT THE EXERCISER PROGRAM, WHEN AN ERROR OCCURS IT IS LOGGED. THE FOLLOWING CLASSES OF ERRORS ARE LOGGED FOR EACH DRIVE IN THE SYSTEM;

CHECK SUM ERROR  
WRITE CHECK ERROR  
DATA COMPARISON ERROR  
HARD ERRORS

SEEK ERROR  
SPEK INCOMPLETE ERROR  
ABORTS

THE ERROR STATISTICS CAN BE OBTAINED BY PUTTING SWITCH 8 TO 1. THE ERROR STATISTICS CAN BE USED IN CONJUNCTION WITH DATA TRANSFER STATISTICS TO GIVE AN IDEA OF THE SYSTEM PERFORMANCE (NUMBER OF WORDS TRANSFERRED PER ERROR, CSE FREQUENCY, RECOVERABLE VERSUS NON-RECOVERABLE ERRORS ETC.).

#### 11.0. ERROR REPORTING AND RECOVERY

WHENEVER AN ERROR OCCURS IT IS REPORTED ALONG WITH RELEVANT INFORMATION. THE RK11 REGISTERS REPORTED IN THE ERROR MESSAGES REPRESENT THE CONTENTS AT THE TIME OF ERROR. EACH ERROR MESSAGE CONTAINS A 'PC' NUMBER, THIS IS THE PC LOCATION IN THE PROGRAM WHERE THE ERROR CALL IS LOCATED. THE USER IS ADVISED TO REFERENCE THIS LOCATION IN THE LISTINGS, IN CASE MORE INFORMATION ABOUT THE ERROR IS DESIRED.

SOME (SYSTEM) ERRORS REFER TO SOFTWARE FLAGS AND KEYS WHICH ARE USED TO MONITOR THE ONGOING ACTIVITIES ON THE SYSTEM. THESE FLAGS ARE EXPLAINED AT THE BEGINING OF THE LISTINGS AND SHOULD BE REFERRED TO, IF THE NEED ARISES.

IF A FATAL ERROR CONDITION IS DETECTED (LIKE DRIVE UNSAFE, WRITE PROTECT SET, DRIVE READY CLEAR, ETC.) THE DRIVE IS REMOVED FROM THE DRIVE SELECTION TABLE AND DROPPED FROM FURTHER TESTING. A MESSAGE IS GIVEN INDICATING DROPPING OF THAT DRIVE. FOR FURTHER INFORMATION, REFER TO THE 'CHKDRV' AND 'DSELCT' ROUTINES IN THE LISTINGS.

RECOVERABLE ERRORS ARE RETRIED THREE TIMES. IF THE ERROR CONDITION FAILS TO CORRECT OR A IF A DIFFERENT ERROR OCCURS THE FUNCTION IS ABORTED. MESSAGES ARE PRINTED ONLY ONCE FOR EACH ERROR. AFTER EIGHT ABORTS ARE RECORDED ON A DRIVE THE DRIVE IS DROPPED. DUAL DENSITY DRIVES ARE ALWAYS DROPPED IN PAIRS.

## 12.0 SUBROUTINES AND HANDLERS

THERE ARE TWO WAYS IN WHICH MOST OF THE SUBROUTINES USED IN THIS PROGRAM ARE CALLED:

### 1. THROUGH THE NORMAL JSR CALL

JSR REG, SUBROUTINE

2. THROUGH THE "TRAP" INSTRUCTION. THE TRAP INSTRUCTION WITH ITS LOWER BYTE ENCODED SERVES AS A CALL FOR SOME ROUTINES. WHEN THE "TRAP" IS EXECUTED A TRAP OCCURS TO THE TRAP VECTOR AND THE TRAP DECODER IS ENTERED. THE TRAP DECODER (\$TRAP) WILL PICK UP THE LOWER BYTE OF THE "TRAP" INSTRUCTION AND USE IT TO INDEX THROUGH THE TRAP TABLE (\$TRAPAD) FOR THE STARTING ADDRESS OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL GO TO THE DESIRED ROUTINE.

### 3. \$SCOPE - THE SCOPE HANDLER

THE SCOPE HANDLER IS ENTERED THROUGH THE EXECUTION OF THE "IOT" INSTRUCTION. IT KEEPS TRACK OF VARIOUS POINTERS, FLAGS AND DECIDES IF LOOPING IS TO BE DONE ON ERROR (SW 9). IT SHOULD BE NOTED THAT THIS HANDLER IS USED MOSTLY IN THE NON-EXERCISER PART OF THE PROGRAM.

### 4. \$ERROR - ERROR HANDLER ROUTINE

THE ERROR HANDLER IS ENTERED THROUGH THE EXECUTION OF THE "EMT" INSTRUCTION. THE LOWER BYTE OF THE EMT INSTRUCTION IS ENCODED TO GIVE AN IDENTIFIER TO THE ERROP CALL. THUS "ERROR 1" IS 104001, ETC. THE ERROR ROUTINE DECIDES IF ANY ACTION IS TO BE TAKEN DEPENDING ON THE SWITCH SETTING (LIKE, HALT ON ERROR, INHIBIT ERROR TYPEOUT, ETC.).

MOST OF THE SUBROUTINES RESIDE IN THE LATTER PART OF THE PROGRAM. THE USER CAN PREFER TO THEM TROUGH THE CROSS REFERENCE TABLE AT THE END OF THE LISTINGS OR TABLE OF CONTENTS AT THE BEGINING.



```

387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420

        .TITLE MD-11-DZPKHG, RK11-RK05 PERFORMANCE EXERCISER
        ;*COPYRIGHT (C) 1973,1977
        ;*DIGITAL EQUIPMENT CORP.
        ;*MAYNARD, MASS. 01784
        ;*
        ;*PROGRAM BY JIM KAPADIA
        ;*
        ;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
        ;*PACKAGE (MAINDEC-11-DEGAC-C3), JAN 19, 1977.
        ;*
        ;*REVISED BY GEORGE GALLANT,TOM SAWYER = MARCH 1976
        ;*REVISED BY CHUCK HESS = AUGUST 1976
        .SBTTL OPERATIONAL SWITCH SETTINGS
        ;*
        ;*      SWITCH      USE
        ;*      *****
        ;*      18          HALT ON ERROR
        ;*      14          LOOP ON TEST
        ;*      12          TYPE OUT ERROR HISTORY
        ;*      10          BELL ON ERROR
        ;*      9           LOOP ON ERROR
        ;*      8           TYPE OUT ERROR AND TRANSFER DATA STATISTICS
        ;*      6           SELECT BUS ADDRESS LIMITS FOR DISK DATA TRANSFERS
        ;*      5           HALT BEFORE DOING NEXT SET OF COMMANDS(GENSRQ)
        ;*      4           DO NOT REWRITE THE DISKS ON RESTART AT 210
        ;*      3           TYPE OUT ELAPSED TIME AT ERROR
        ;*      2           DROP DRIVE AFTER MAXM ERRORS ON THIS DRIVE
        ;*      1           TYPE SERIAL NUMBER OF ERRORING DRIVE
        ;*      0           IF SW8=1, ONLY TYPE ELAPSED TIME
        ;*      11          DUMP OUT ALL RK11 REGISTERS ON ERROR
        ;*
        ;*      YOU ARE ADVISED TO READ THE DOCUMENT FOR THIS PROGRAM.
    
```

```

621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676

        .SBTTL BASIC DEFINITIONS
        ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
        STACK= 1100
        .EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
        .EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
        ;*MISCELLANEOUS DEFINITIONS
        HT= 11                ;;CODE FOR HORIZONTAL TAB
        LF= 12                ;;CODE FOR LINE FEED
        CR= 13                ;;CODE FOR CARRIAGE RETURN
        CRLF= 200            ;;CODE FOR CARRIAGE RETURN=LINE FEED
        PS= 177776           ;;PROCESSOR STATUS WORD
        .EQUIV PS,PSW
        STKLM= 177774         ;;STACK LIMIT REGISTER
        PIRQ= 177772         ;;PROGRAM INTERRUPT REQUEST REGISTER
        DSW= 177570          ;;HARDWARE SWITCH REGISTER
        DDISP= 177570        ;;HARDWARE DISPLAY REGISTER
        ;*GENERAL PURPOSE REGISTER DEFINITIONS
        R0= %0                ;;GENERAL REGISTER
        R1= %1                ;;GENERAL REGISTER
        R2= %2                ;;GENERAL REGISTER
        R3= %3                ;;GENERAL REGISTER
        R4= %4                ;;GENERAL REGISTER
        R5= %5                ;;GENERAL REGISTER
        R6= %6                ;;GENERAL REGISTER
        R7= %7                ;;GENERAL REGISTER
        SP= %6                ;;STACK POINTER
        PC= %7                ;;PROGRAM COUNTER
        ;*PRIORITY LEVEL DEFINITIONS
        PR0= 0                ;;PRIORITY LEVEL 0
        PR1= 40               ;;PRIORITY LEVEL 1
        PR2= 100              ;;PRIORITY LEVEL 2
        PR3= 140              ;;PRIORITY LEVEL 3
        PR4= 200              ;;PRIORITY LEVEL 4
        PR5= 240              ;;PRIORITY LEVEL 5
        PR6= 300              ;;PRIORITY LEVEL 6
        PR7= 340              ;;PRIORITY LEVEL 7
        ;*"SWITCH REGISTER" SWITCH DEFINITIONS
        SW15= 100000          SW13= 20000
        SW14= 40000          SW12= 10000
        SW11= 4000          SW10= 2000
        SW09= 1000          SW08= 400
        SW07= 200           SW06= 100
        SW05= 40            SW04= 20
        001100
        000011
        000012
        000015
        000200
        177776
        177774
        177772
        177570
        000000
        000001
        000002
        000003
        000004
        000005
        000006
        000007
        000000
        000100
        000140
        000200
        000240
        000300
        000340
        100000
        040000
        020000
        010000
        004000
        002000
        001000
        000400
        000200
        000100
        000040
        000020
    
```

```

677      000010      SW03= 10
678      000004      SW02= 4
679      000002      SW01= 2
680      000001      SW00= 1
681      ,EQUIV SW09,SW9
682      ,EQUIV SW08,SW8
683      ,EQUIV SW07,SW7
684      ,EQUIV SW06,SW6
685      ,EQUIV SW05,SW5
686      ,EQUIV SW04,SW4
687      ,EQUIV SW03,SW3
688      ,EQUIV SW02,SW2
689      ,EQUIV SW01,SW1
690      ,EQUIV SW00,SW0
691
692      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
693      BIT15= 100000
694      BIT14= 40000
695      BIT13= 20000
696      BIT12= 10000
697      BIT11= 4000
698      BIT10= 2000
699      BIT09= 1000
700      BIT08= 400
701      BIT07= 200
702      BIT06= 100
703      BIT05= 40
704      BIT04= 20
705      BIT03= 10
706      BIT02= 4
707      BIT01= 2
708      BIT00= 1
709      ,EQUIV BIT09,BIT9
710      ,EQUIV BIT08,BIT8
711      ,EQUIV BIT07,BIT7
712      ,EQUIV BIT06,BIT6
713      ,EQUIV BIT05,BIT5
714      ,EQUIV BIT04,BIT4
715      ,EQUIV BIT03,BIT3
716      ,EQUIV BIT02,BIT2
717      ,EQUIV BIT01,BIT1
718      ,EQUIV BIT00,BIT0
719
720      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
721      ERRVEC= 4      ;TIME OUT AND OTHER ERRORS
722      RESVEC= 10     ;RESERVED AND ILLEGAL INSTRUCTIONS
723      TBITVEC=14    ;"T" BIT
724      TRIVEC= 14    ;TRACE TRAP
725      BPTVEC= 14    ;BREAKPOINT TRAP (BPT)
726      IOTVEC= 20    ;INPUT/OUTPUT TRAP (IOT) **SCOPE**
727      PWRVEC= 24    ;POWER FAIL
728      EMTRAP= 30    ;EMULATOR TRAP (EMT) **ERROR**
729      TRAPVEC=34    ;"TRAP" TRAP
730      TKVEC= 60     ;TTY KEYBOARD VECTOR
731      TPVEC= 64     ;TTY PRINTER VECTOR
732      PIRGVEC=240   ;PROGRAM INTERRUPT REQUEST VECTOR
    
```

```

733      000100      KMLVEC=100      ;KNILL CLOCK VECTOR
734
735      ,EQUIV BIT15,ERR
736      ,EQUIV BIT14,ME
737      ,EQUIV BIT13,SCP
738
739
740      ,EQUIV BIT12,DPL
741      ,EQUIV BIT10,DRU
742      ,EQUIV BIT09,SIN
743      ,EQUIV BIT07,DRY
744      ,EQUIV BIT06,RWS
745      ,EQUIV BIT05,WPS
746
747
748
749      ,EQUIV BIT12,SKE
750      ,EQUIV BIT01,CBE
751      ,EQUIV BIT00,WCE
752
753      ;SBTTL TRAP CATCHER
754
755      ;=0
756      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ",+2,HALT"
757      ;SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
758      ;LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
759      ;=174
760      000174 000000  DISPREG: ,WORD 0      ;SOFTWARE DISPLAY REGISTER
761      000176 000000  SWREG: ,WORD 0      ;SOFTWARE SWITCH REGISTER
762      ;SBTTL STARTING ADDRESS(ES)
763      000200 000137 003376  JMP @START ;JUMP TO STARTING ADDRESS OF PROGRAM
764
765      ;=210
766      000210 105237 001253  INCB PRSTRT ;RESTART ADDRESS, IF RESTART IS
767      000214 000137 003376  JMP @START ;DONE AT 210, THE BOUNDARY CONDITION
768      ;TESTS (TST1-7) ARE SKIPPED, IF SW 4
769      ;IS SET THEN THE DISKS ARE NOT REWRITTEN
770      ;(WRDSK) WITH RANDOM PATTERNS, NORMALLY
771      ;ALL THE DISKS PRESENT ARE COMPLETELY
772      ;WRITTEN WITH RANDOM PATTERNS, AT THE
773      ;BEGINNING OF THE
774      ;EXERCISER PART OF THE PROGRAM.
775
776      ;SBTTL ACT11 HOOKS
777
778      ;*****
779      ;HOOKS REQUIRED BY ACT11
780
781      000220      ;$VPC=, ;SAVE PC
782      00046      ;$46
783      00046 022780  SENDAD ;1)SET LOC,46 TO ADDRESS OF SENDAD IN ;$EOP
784      00052      ;$52
785      00052 000000  ,WORD 0 ;2)SET LOC,52 TO ZERO
786      000220      ;$VPC ;1 RESTORE PC
787
788      ;KT11 REGISTER DEFINITIONS
789      ;SBTTL MEMORY MANAGEMENT DEFINITIONS
    
```

```

789 ;*KT11 VECTOR ADDRESSES
790
791 000350 MMVEC= 250
792
793 ;*KT11 STATUS REGISTER ADDRESSES
794
795 177372 SR0= 177372
796 177374 SR1= 177374
797 177376 SR2= 177376
798 172516 SR3= 172516
799
800 ;*KERNEL "I" PAGE DESCRIPTOR REGISTERS
801
802 172300 KIPDR0= 172300
803 172302 KIPDR1= 172302
804 172304 KIPDR2= 172304
805 172306 KIPDR3= 172306
806 172310 KIPDR4= 172310
807 172312 KIPDR5= 172312
808 172314 KIPDR6= 172314
809 172316 KIPDR7= 172316
810
811 ;*KERNEL "D" PAGE DESCRIPTOR REGISTERS
812
813 172320 KDPDR0= 172320
814 172322 KDPDR1= 172322
815 172324 KDPDR2= 172324
816 172326 KDPDR3= 172326
817 172330 KDPDR4= 172330
818 172332 KDPDR5= 172332
819 172334 KDPDR6= 172334
820 172336 KDPDR7= 172336
821
822 ;*KERNEL "I" PAGE ADDRESS REGISTERS
823
824 172340 KIPAR0= 172340
825 172342 KIPAR1= 172342
826 172344 KIPAR2= 172344
827 172346 KIPAR3= 172346
828 172350 KIPAR4= 172350
829 172352 KIPAR5= 172352
830 172354 KIPAR6= 172354
831 172356 KIPAR7= 172356
832
833 ;*KERNEL "D" PAGE ADDRESS REGISTERS
834
835 172360 KDPAR0= 172360
836 172362 KDPAR1= 172362
837 172364 KDPAR2= 172364
838 172366 KDPAR3= 172366
839 172370 KDPAR4= 172370
840 172372 KDPAR5= 172372
841 172374 KDPAR6= 172374
842 172376 KDPAR7= 172376
843
844
    
```

```

845 ;SBTTL COMMON TAGS
846
847 ;*****
848 ;*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
849 ;*USED IN THE PROGRAM.
850
851 001100 .S=1100
852 001100 ;SCMTAG: ;START OF COMMON TAGS
853 001100 000000 ;$PASS: ,WORD 0 ;CONTAINS PASS COUNT
854 001102 000 ;$STNM: ,BYTE 0 ;CONTAINS THE TEST NUMBER
855 001103 000 ;$ERFLG: ,BYTE 0 ;CONTAINS ERROR FLAG
856 001104 000000 ;$ICNT: ,WORD 0 ;CONTAINS SUBTEST ITERATION COUNT
857 001106 000000 ;$LPADR: ,WORD 0 ;CONTAINS SCOPE LOOP ADDRESS
858 001110 000000 ;$LPERR: ,WORD 0 ;CONTAINS SCOPE RETURN FOR ERRORS
859 001112 000000 ;$ERTTL: ,WORD 0 ;CONTAINS TOTAL ERRORS DETECTED
860 001114 000 ;$ITEMB: ,BYTE 0 ;CONTAINS ITEM CONTROL BYTE
861 001115 001 ;$ERMAX: ,BYTE 1 ;CONTAINS MAX. ERRORS PER TEST
862 001116 000000 ;$ERRPC: ,WORD 0 ;CONTAINS PC OF LAST ERROR INSTRUCTION
863 001120 000000 ;$GADDR: ,WORD 0 ;CONTAINS ADDRESS OF 'GOOD' DATA
864 001122 000000 ;$BADDR: ,WORD 0 ;CONTAINS ADDRESS OF 'BAD' DATA
865 001124 000000 ;$GDDAT: ,WORD 0 ;CONTAINS 'GOOD' DATA
866 001126 000000 ;$BDDAT: ,WORD 0 ;CONTAINS 'BAD' DATA
867 001130 000000 ;$RESV: ,WORD 0 ;RESERVED--NOT TO BE USED
868 001132 000000 ;$RESV: ,WORD 0
869 001134 000 ;$AUTOB: ,BYTE 0 ;AUTOMATIC MODE INDICATOR
870 001135 000 ;$INTAG: ,BYTE 0 ;INTERRUPT MODE INDICATOR
871 001136 000000 ;$RESV: ,WORD 0
872 001140 177570 ;$SWR: ,WORD DSWR ;ADDRESS OF SWITCH REGISTER
873 001142 177570 ;$DISP: ,WORD DDISP ;ADDRESS OF DISPLAY REGISTER
874 001144 177560 ;$TKS: 177560 ;TTY KBD STATUS
875 001146 177562 ;$TKB: 177562 ;TTY KBD BUFFER
876 001150 177564 ;$TPS: 177564 ;TTY PRINTER STATUS REG. ADDRESS
877 001152 177566 ;$TPB: 177566 ;TTY PRINTER BUFFER REG. ADDRESS
878 001154 000 ;$NULL: ,BYTE 0 ;CONTAINS NULL CHARACTER FOR FILLS
879 001155 002 ;$FILLS: ,BYTE 2 ;CONTAINS # OF FILLER CHARACTERS REQUIRED
880 001156 012 ;$FILLC: ,BYTE 12 ;INSERT FILL CHARS. AFTER A "LINE FEED"
881 001157 000 ;$TPFLG: ,BYTE 0 ;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
882 001160 000000 ;$REGAD: ,WORD 0 ;CONTAINS THE ADDRESS FROM
883 ;WHICH ($REGO) WAS OBTAINED
884 001162 000000 ;$REG0: ,WORD 0 ;CONTAINS (($REGAD)+0)
885 001164 000000 ;$REG1: ,WORD 0 ;CONTAINS (($REGAD)+2)
886 001166 000000 ;$REG2: ,WORD 0 ;CONTAINS (($REGAD)+4)
887 001170 000000 ;$REG3: ,WORD 0 ;CONTAINS (($REGAD)+6)
888 001172 000000 ;$REG4: ,WORD 0 ;CONTAINS (($REGAD)+10)
889 001174 000000 ;$REG5: ,WORD 0 ;CONTAINS (($REGAD)+12)
890 001176 000000 ;$REG6: ,WORD 0 ;CONTAINS (($REGAD)+14)
891 001200 000000 ;$REG7: ,WORD 0 ;CONTAINS (($REGAD)+16)
892 001202 000000 ;$REG10: ,WORD 0 ;CONTAINS (($REGAD)+20)
893 001204 000000 ;$ESCAPE: ,WORD 0 ;ESCAPE ON ERROR ADDRESS
894 001206 177607 000377 ;$BELL: ,ASCIZ <207><377><377> ;CODE FOR BELL
895 001212 077 ;$QUES: ,ASCIZ ?/ ;QUESTION MARK
896 001213 015 ;$CRLF: ,ASCIZ <15> ;CARRIAGE RETURN
897 001214 000012 ;$LF: ,ASCIZ <12> ;LINE FEED
898 ;*****
899 001216 177400 ;$RDS: ,WORD 177400
900 001220 177402 ;$RKR: ,WORD 177402
    
```



```

984 00132b 000040 CMD:  ,BLKW  40      ;STORAGE TABLE
985
986 ;THESE ARE BUSY FLAGS FOR THE DRIVES, IF A DRIVE IS BUSY PERFORMING
987 ;ANY FUNCTION (INCLUDING POSITIONING) THEN BIT 7 OF THE FLAG FOR THAT
988 ;DRIVE IS SET. BITS 0-3 CONTAIN THE OFFSET TO KEY # WHICH MADE THE DRIVE
989 ;BUSY, EX: DRIVE #3 WAS MADE TO DO A WRITE BY COMMAND
990 ;KEYS, HENCE "BUSY3" WILL CONTAIN 210. NOTE THAT 10 IS THE
991 ;OFFSET FOR KEYS (TAKING KEY AS BASE). KEY # = OFFSET<0-3>/2 + 1
992
993 001426 000010 BUSY:  ,BLKB  10      ;BUSY FLAGS FOR DRIVES 0-7
994
995 ;THESE FLAGS WHEN SET INDICATE THAT A DRIVE IS BEING
996 ;POSITIONED OR HAS ALREADY BEEN POSITIONED.
997
998
999 001436 000010 POS:   ,BLKB  10      ;DRIVE 0 POSITIONED
1000
1001
1002
1003 ;RETRY COUNTS FOR A PARTICULAR FUNCTION ON A DRIVE THE FUNCTION IS ABORTED
1004 ;ON A DRIVE WHEN THE RETRY COUNT REACHES 3.
1005
1006 001446 000010 RETRY: ,BLKB  10      ;DRIVES 0-7 RERTY COUNTS
1007
1008 001456 000000 WCFLG: ,WORD  0      ;IF BIT 15 IS SET WRITE CHK IS TO BE DONE
1009 ;FOLLOWING THE WRITE, BITS 0-3 CONTAIN THE
1010 ;OFFSET TO KEY# (FROM BASE=KEY)
1011
1012 001460 000000 QSCNT: ,WORD  0      ;THIS IS A COUNT FOR KEEPING TRACK OF THE TIME
1013 ;TAKEN BY ALL THE 0 COMMANDS IN THE QUEUE.
1014 ;IF THIS COUNTS DOWN TO 0 AN ERROR IS REPORTED
1015
1016
1017 001462 000000 PRSFNC: ,WORD  0      ;CONTAINS INFO ABOUT THE PRESENT COMMAND
1018 ;BEING PERFORMED ON THE RK11
1019 001464 000000 PSTFNC: ,WORD  0      ;CONTAINS INFO ABOUT THE COMMAND PERFORMED
1020 ;BEFORE THE "PRSCMD"
1021
1022
1023 001466 000000 CICNT:  ,WORD  0      ;THIS IS A COUNT-TIMER USED FOR KEEPING TRACK
1024 001470 000000 CICNT1: ,WORD  0      ;OF THE TIME TAKEN BY ANY FUNCTION TO BE
1025 ;COMPLETED, IF THE COUNT GOES TO 0 AN ERROR IS REPORTED.
1026
1027 001472 000000 TIMER:  ,WORD  0
1028 001474 000000 ERCODE: ,WORD  0
1029 001476 000000 DRVPTR: ,WORD  0
1030 001500 000000 DRVCNT: ,WORD  0
1031
1032
1033 001502 000000 QDRV:   ,WORD  0      ;TEMPORARY REGISTERS USED BY "GENSR0"
1034 001504 000000 QCYL:   ,WORD  0      ;ROUTINE TO STORE VARIOUS PARAMETERS
1035 001506 000000 QSUR:   ,WORD  0      ;OF A COMMAND AS THEY ARE GENERATED.
1036 001510 000000 QSEC:   ,WORD  0
1037 001512 000000 QFNC:   ,WORD  0
1038 001514 000000 QBUSAD: ,WORD  0
1039 001516 000000 QWRCNT: ,WORD  0
  
```

```

1040
1041
1042 ;THIS TABLE CONTAINS VARIOUS MAPPING FACTORS TO BE USED
1043 ;FOR GENERATING RANDOM PARAMETERS FROM RANDOM NUMBERS
1044
1045 001520 000000 DRMAP:  ,WORD  0      ;MAPPING FACTOR FOR GENERATING RANDOM DRIVE NUMBER
1046 001522 000000 CYLMAP: ,WORD  0      ;MAPPING FACTOR FOR CYLINDER
1047 001524 000000 SECMAP: ,WORD  0      ;MAPPING FACTOR FOR SECTOR
1048 001526 000000 FNMMap: ,WORD  0      ;MAPPING FACTOR FOR FUNCTION
1049 001530 000000 BAMAP:  ,WORD  0      ;MAPPING FACTOR FOR BUS ADDRESS
1050 001532 000000 WCMAP:  ,WORD  0      ;MAPPING FACTOR FOR WORD COUNT
1051
1052
1053 ;THESE TWO FLAGS CORRESPOND TO THE 2 INTERRUPT HANDLERS (RK11) USED
1054 ;IN THIS PROGRAM. WHEN THE INTERRUPT HANDLER IS ENTERED THE FLAG IS
1055 ;CLEARED OR SET.
1056
1057 001534 000 INTFLG: ,BYTE  0      ;FOR "INTHND", CLEARED ON ENTERING HANDLER
1058 001535 000 INT1FL: ,BYTE  0      ;FOR "INT1SK", SET ON ENTERING HANDLER
1059
1060 001536 000000 SAVKEY: ,WORD  0
1061 001540 000000 ECOUNT: ,WORD  0
1062
1063 ;THIS TABLE CONTAINS COUNTS FOR THE NUMBER OF OF ERRORS OCCURING ON A
1064 ;DRIVE (NOTE: ONLY THOSE ERRORS WHICH ARE POSITIVELY ATTRIBUTABLE TO A
1065 ;SPECIFIC DRIVE). THE COUNT KEPT ONLY IF SWITCH 2 IS SET. WHEN THE COUNT
1066 ;REACHES THE MAXIMUM ALLOWABLE (USUALLY 3) THE DRIVE IS DROPPED FROM
1067 ;TESTING AND IS TAKEN OUT OF THE DRIVE SELECTION TABLE.
1068
1069 001542 000010 ERDRV:  ,BLKB  10      ;COUNT FOR DRIVES 0-7
1070
1071 001552 000000 KWHR:   ,WORD  0      ;COUNTS HOURS (2'S COMPLEMENT)
1072 001554 000000 KWMIN:  ,WORD  0      ;COUNTS MINUTES (2'S COMPLEMENT)
1073 001556 000000 KWSEC:  ,WORD  0      ;COUNTS SECONDS (2'S COMPLEMENT)
1074 001560 000000 KWCOUNT: ,WORD  0      ;COUNTS CPS FROM KW11L (2'S COMPLMNT)
1075
1076 ;THIS TABLE CONTAINS COUNTS FOR HARD ERRORS ON A PARTICULAR DRIVE.
1077 ;EX HECN2 WILL CONTAIN THE TOTAL NUMBER OF HARD ERRORS THAT OCCURED ON
1078 ;DRIVE 2
1079
1080 001562 000010 HECN:   ,BLKW  10      ;DRIVE 0-7 HARD ERROR COUNTS
1081
1082 ;THIS TABLE CONTAINS COUNTS FOR SEEK ERRORS
1083 ;ON A PARTICULAR DRIVE.
1084
1085 001602 000010 SKECN:  ,BLKW  10      ;DRIVE 0-7 SEEK ERROR COUNTS
1086
1087
1088 ;THIS TABLE CONTAINS COUNTS FOR SIN ERRORS ON A
1089 ;PARTICULAR DRIVE
1090
1091 001622 000010 SINCN:  ,BLKB  10      ;DRIVE 0-7 SIN COUNTS
1092
1093 ;THIS TABLE CONTAINS COUNTS FOR WRITE CHECK ERRORS
1094 ;THAT OCCURED ON A PARTICULAR DRIVE
1095
  
```

1096 001A32 000010 WCECN: .BLKW 10 ;WCE COUNT FOR DRIVES 0-7  
 1097  
 1098  
 1099 ;THIS TABLE CONTAINS COUNTS FOR CHECK SUM ERROR THAT  
 1100 ;OCCURRED ON A PARTICULAR DRIVE  
 1101  
 1102 001A52 000010 CSECN: .BLKW 10 ;CSE COUNT FOR DRIVES 0-7  
 1103  
 1104 ;THIS TABLE CONTAINS COUNT OF NUMBER OF FUNCTIONS  
 1105 ;THAT WERE ABORTED ON A PARTICULAR DRIVE, A  
 1106 ;FUNCTION IS ABORTED ONLY AFTER DOING RETRIES  
 1107  
 1108  
 1109 001A72 000010 ABORT: .BLKW 10 ;ABORT COUNT FOR DRIVES 0-7  
 1110  
 1111 ;COUNTS FOR NUMBER OF DATA ERRORS THAT OCCURED ON INDIVIDUAL DRIVES,  
 1112  
 1113 001712 000010 DATER: .BLKW 10 ;DRIVES 0-7

1114 001732 000000 NWRTL: .WORD 0 ;LO WORD: OF THE 2 WORD COUNT-GIVING TOTAL  
 1115 001734 000000 NNRTH: .WORD 0 ;HI WORD: OF WORDS WRITTEN ON DRIVE 0  
 1116 001736 000016 .BLKW 14 ;FOR REST OF DRIVES 1-7  
 1117  
 1118  
 1119 001772 000000 NRDL: .WORD 0 ;LO WORD: 2 WORD COUNT GIVING TOTAL  
 1120 001774 000000 NRDH: .WORD 0 ;HI WORD: OF WORDS READ ON DRIVE 0  
 1121 001776 000016 .BLKW 14 ;FOR DRIVES 1-7  
 1122  
 1123 002A32 001326 PCMND: .WORD CMND ;POINTERS TO PARAMETERS FOR COMMANDS IN QUEUE  
 1124 002A34 001336 .WORD CMND+10 ;POINTER TO SECOND COMMAND  
 1125 002A36 001346 .WORD CMND+20 ;POINTER TO THIRD COMMAND  
 1126 002A40 001356 .WORD CMND+30 ;POINTER TO FOURTH COMMAND  
 1127 002A42 001366 .WORD CMND+40 ;POINTER TO FIFTH COMMAND  
 1128 002A44 001376 .WORD CMND+50 ;POINTER TO SIXTH COMMAND  
 1129 002A46 001406 .WORD CMND+60 ;POINTER TO SEVENTH COMMAND  
 1130 002A50 001416 .WORD CMND+70 ;POINTER TO EIGHTH COMMAND  
 1131  
 1132  
 1133 002A52 000000 BASEBA: .WORD 0 ;CONTAINS THE LOWEST BUS ADDRESS STARTING WHICH DATA TRANSFERS  
 1134 ;CAN BE DONE  
 1135 002A54 000000 MAXBA: .WORD 0 ;CONTAINS THE HIGHEST BUS ADDRESS TO WHICH DATA TRANSFERS  
 1136 ;CAN BE DONE,  
 1137 002A56 000000 REPCNT: .WORD 0 ;CONTAINS THE REPETITION COUNT- THE NUMBER  
 1138 ;OF TIMES A REQUESTS WILL BE GENERATED, WHEN THIS  
 1139 ;COUNT GOES TO 0, IT MEANS AN END OF PASS, HOWEVER  
 1140 ;NOTE THAT THERE IS NO TRUE END OF PASS, IN THIS KIND  
 1141 ;OF EXERCISER PROGRAM, THE EXERCISER RESUMES FROM  
 1142 ;THE POINT IT LEFT OFF, AFTER TYPING OUT THE END IF  
 1143 ;PASS MESSAGE,  
 1144 002A60 000000 XXDPHD: .WORD 0 ;LOW BYTE CONTAINS ADDRESS OF RK08 DRIVE  
 1145 ;WHICH PROGRAM WAS LOADED FROM; HIGH BYTE  
 1146 ;CONTAINS THE RK08 'XXDP' CODE,  
 1147  
 1148 ;ASCII MESSAGES  
 1149  
 1150 002A62 005015 045523 000105 MSG1: .ASCII <15><12>/BKE/  
 1151 002A70 005015 041527 000105 MSG2: .ASCII<15><12>/WCE/  
 1152 002A76 005015 051503 000105 MSG3: .ASCII<15><12>/CSE/  
 1153 002104 005015 040510 042122 MSG4: .ASCII <15><12>/HARD ERROR/  
 1154 002112 042440 047522 000122  
 1155 002120 047440 020116 047504 MSG5: .ASCII/ ON DOING /  
 1156 002126 047111 020107 000  
 1157 002133 127 044522 042524 MSG6: .ASCII /WRITE/  
 1158 002140 000  
 1159 002141 122 040505 000104 MSG7: .ASCII /READ/  
 1160 002146 051127 020124 044103 MSG8: .ASCII /WRT CHK/  
 1161 002154 000113  
 1162 002156 042122 041440 045510 MSG9: .ASCII /RD CHK/  
 1163 002164 000  
 1164 002168 015 040412 047502 MSG10: .ASCII <15><12>/ABORTED/<15><12>  
 1165 002172 052122 042105 005015  
 1166 002200 000  
 1167 002201 123 042505 000113 MSG11: .ASCII /SEEK/  
 1168 002206 005015 041520 000075 MSG12: .ASCII <15><12>/PCM/  
 1169 002214 044120 051531 041040 MSG13: .ASCII2 /PHYS BAW/



```

1230 ,SBTTL ERROR POINTER TABLE
1231
1232 ,*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
1233 ,*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
1234 ,*LOCATION ITEM5, THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
1235 ,*NOTE1: IF ITEM5 IS 0 THE ONLY PERTINENT DATA IS (SERRPC).
1236 ,*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
1237
1238 ;* EM ;POINTS TO THE ERROR MESSAGE
1239 ;* DH ;POINTS TO THE DATA HEADER
1240 ;* DT ;POINTS TO THE DATA
1241 ;* DF ;POINTS TO THE DATA FORMAT
1242
1243
1244 002666 ,SERRTS:
1245 ,*THERE ARE TWO CLASSES OF ERRORS:
1246 ,*1. ERRORS IN EXERCISER PART OF THE PROGRAM = ERROR NUMBERS BELOW 100
1247 ,*2. ERRORS IN THE NON-EXERCISER PART OF THE PROGRAM = ERROR NUMBERS EQUAL
1248 ,*TO AND GREATER THAN 100.
1249 ,*THE DOCUMENT CONTAINS MORE INFORMATION ON THESE.
1250 ,*THE FOLLOWING ERRORS OCCUR IN THE EXERCISER PART OF THE PROGRAM.
1251
1252
1253 ;ITEM 1
1254
1255 EM1 ;ERROR ON WRITE
1256 DH1 ;PC RKCS RKER RKDS RKDA
1257 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1258 0
1259
1260 ;ITEM 2
1261
1262 EM2 ;ATTEMPT TO INITIATE FUNCTION ON 'BUSY' DRIVE
1263 DH2 ;PC DRIVE
1264 DT2 ;SERRPC SREG0
1265 0
1266
1267 ;ITEM 3
1268
1269 EM3 ;CONTROL READY NOT SET
1270 DH1 ;PC RKCS RKER RKDS RKDA
1271 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1272 0
1273
1274 ;ITEM 4
1275
1276 EM4 ;R/W/S READY NOT SET
1277 DH1 ;PC RKCS RKER RKDS RKDA
1278 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1279 0
1280
1281 ;ITEM 5
1282
1283 EM5 ;CONTROL READY NOT SET AFTER FIRST INTERRUPT ON ISSUING SEEK
1284 DH1 ;PC RKCS RKER RKDS RKDA
1285 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
  
```

```

1286 002734 000000 0
1287
1288
1289 ;ITEM 6
1290
1291 EM6 ;WRONG BITS IN RKCS, EXPECT SEEK
1292 DH1 ;PC RKCS RKER RKDS RKDA
1293 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1294 0
1295
1296 ;ITEM 7
1297
1298 EM7 ;'BUSY' FLAG CLEAR ON INTERRUPTING DRIVE
1299 DH2 ;PC DRIVE
1300 DT2 ;SERRPC SREG0
1301 0
1302
1303 ;ITEM 10
1304
1305 EM10 ;'POSITIONING' FLAG FOR INTERRUPTING DRIVE CLEAR
1306 DH2 ;PC DRIVE
1307 DT2 ;SERRPC SREG0
1308 0
1309
1310 ;ITEM 11
1311
1312 EM11 ;'ERROR SET AFTER FIRST INTERRUPT ON ISSUING SEEK
1313 DH1 ;PC RKCS RKER RKDS RKDA
1314 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1315 0
1316
1317 ;ITEM 12
1318
1319 EM12 ;SCP SET AFTER FIRST INTERRUPT ON ISSUING SEEK
1320 DH1 ;PC RKCS RKER RKDS RKDA
1321 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1322 0
1323
1324 ;ITEM 13
1325
1326 EM13 ;CONTROL READY NOT SET AFTER SEEK DONE INTERRUPT
1327 DH1 ;PC RKCS RKER RKDS RKDA
1328 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1329 0
1330
1331 ;ITEM 14
1332
1333 EM14 ;INTERRUPTING DRIVE (SEEK DONE) WAS NOT 'BUSY'
1334 DH1 ;PC RKCS RKER RKDS RKDA
1335 DT1 ;SERRPC SREG0 SREG1 SREG2 SREG3
1336 0
1337
1338 ;ITEM 15
1339
1340 EM15 ;R/W/S READY NOT SET FOR INTERRUPTING DRIVE (SEEK DONE)
1341 DH1 ;PC RKCS RKER RKDS RKDA
  
```





```

1454
1455
1456 003926 031451      EM35  ;DRIVE POWER LOW
1457 003730 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1458 003732 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1459 003734 000000      0
1460
1461
1462 ;ITEM 36
1463 003736 031467      EM36  ;DRIVE UNSAFE
1464 003740 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1465 003742 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1466 003744 000000      0
1467
1468 ;ITEM 37
1469
1470 003746 031503      EM37  ;NPS SET
1471 003750 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1472 003752 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1473 003754 000000      0
1474
1475 ;*
1476 ;*THE FOLLOWING ERRORS OCCUR IN THE NON-EXERCISER PART OF THE PROGRAM.
1477 ;*
1478
1479 ;ITEM 100
1480
1481 003756 030720      EM23  ;DATA (COMPARISON) ERROR
1482 003760 032110      DH23  ;PC      RKBA      EXPT      RECYD    RKDA
1483 003762 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1484 003764 000000      0
1485
1486 ;ITEM 101
1487
1488 003766 031513      EM101 ;INTERRUPT DID NOT OCCUR AFTER WRITE
1489 003770 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1490 003772 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1491 003774 000000      0
1492
1493 ;ITEM 102
1494
1495 003776 031553      EM102 ;'ERR'OR SET
1496 003780 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1497 003782 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1498 003784 000000      0
1499
1500 ;ITEM 103
1501
1502 003786 031567      EM103 ;RKDA INCREMENTED WRONGLY
1503 003790 032265      DH103 ;PC      EXPT      RECYD
1504 003792 032504      DT103 ;ERRPC  $REG0    $REG1
1505 003794 000000      0
1506
1507 ;ITEM 104
1508
1509 003796 031615      EM104 ;RKBA INCREMENTED WRONGLY
  
```

```

1510 003798 032265      DH103 ;PC      EXPT      RECYD
1511 003799 032504      DT103 ;ERRPC  $REG0    $REG1
1512 003800 000000      0
1513
1514 ;ITEM 105
1515
1516 003798 031643      EM105 ;RKC DID NOT OVERFLOW TO 0
1517 003799 032327      DH105 ;PC      RKDA      RKC
1518 003800 032504      DT103 ;ERRPC  $REG0    $REG1
1519 003801 000000      0
1520
1521 ;ITEM 106
1522
1523 003798 031673      EM106 ;MEX BITS INCORRECT
1524 003799 031730      DH1   ;PC      RKCS      RKER      RKDS      RKDA
1525 003800 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1526 003801 000000      0
1527
1528 ;ITEM 107
1529
1530 003798 030720      EM23  ;DATA (COMPARISON) ERROR ON READ
1531 003799 032265      DH103 ;PC      EXPT      RECYD
1532 003800 032504      DT103 ;ERRPC  $REG0    $REG1
1533 003801 000000      0
1534
1535 ;ITEM 110
1536
1537 003798 031712      EM110 ;WRITE CHECK ERROR
1538 003799 032354      DH110 ;PC      RKCS      RKER      RKBA      RKDA
1539 003800 032422      DT1   ;ERRPC  $REG0    $REG1    $REG2    $REG3
1540 003801 000000      0
  
```

```

1541 ;IF POWER FAILED, ON RETURN OF POWER ENTER HERE.
1542
1543 003166 004737 022630 PFSTRT: JSR PC,WATIME ;WAIT SOME TIME
1544 003172 105237 001253 INCB FRSTRT ;INDICATE THAT THE STATISTICS HAVE
1545 ;TO BE SAVED, ON RETRN FROM PWR FAIL,
1546
1547
1548
1549
1550 003176 000005 START: RESET ;CLEAR THE BUS
1551 ;GIVE DRIVES TIME TO LOAD IF PROGRAM WAS STARTED BY APT
1552 003400 023737 000042 000046 CMP #42,#46
1553 003406 001016 BNE STARTA
1554 003410 005077 175614 CLR #RKDA ;SELECT UNIT 0
1555 003414 012700 000250 MOV #250,R0 ;WAIT FOR..
1556 003420 032777 000200 175570 208: BIT #200,#RKDS ;DRIVE READY..
1557 003426 001006 BNE STARTA ;IN CASE..
1558 003430 005001 CLR R1 ;OF APT..
1559 003432 005301 DEC R1 ;START, BUT..
1560 003434 001376 BNE =-2 ;DON'T WAIT..
1561 003436 005300 DEC R0 ;FOREVER.
1562 003440 001367 BNE 208
1563 003442 000000 HALT ;RKDS BIT 7 (DRIVE READY) NEVER SET,
1564 003444
1565
1566 ;SBTTL INITIALIZE THE COMMON TAGS
1567 003444 012706 001100 ;CLEAR THE COMMON TAGS (#CMTAG) AREA
1568 003450 005026 MOV #CMTAG,R6 ;FIRST LOCATION TO BE CLEARED
1569 003452 022706 001140 CLR (R6)+ ;CLEAR MEMORY LOCATION
1570 003456 001374 CMP #SWR,R6 ;DONE?
1571 003460 012706 001100 BNE =6 ;LOOP BACK IF NO
1572 ;INITIALIZE A FEW VECTORS ;SETUP THE STACK POINTER
1573 003464 012737 027204 000020 MOV #SCOPE,#IOTVEC ;IOT VECTOR FOR SCOPE ROUTINE
1574 003472 012737 000340 000022 MOV #340,#IOTVEC+1 ;LEVEL 7
1575 003500 012737 027350 000034 MOV #TRAP,#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
1576 003506 012737 000340 000036 MOV #340,#TRAPVEC+2 ;LEVEL 7
1577 003514 012737 027450 000024 MOV #PNRDN,#PWRVEC ;POWER FAILURE VECTOR
1578 003522 012737 000340 000026 MOV #340,#PWRVEC+2 ;LEVEL 7
1579 003530 012737 003530 001106 MOV #,LPADR ;INITIALIZE THE LOOP ADDRESS FOR SCOPE
1580 003536 012737 003536 001110 MOV #,LPERR ;SETUP THE ERROR LOOP ADDRESS
1581 ;SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
1582 ;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1583 003544 013746 000004 MOV #ERRVEC,-(SP) ;SAVE ERROR VECTOR
1584 003550 012737 003604 000004 MOV #646,#ERRVEC ;SET UP ERROR VECTOR
1585 003556 012737 177570 001140 MOV #D8WR,SWR ;SETUP FOR A HARDWARE SWICH REGISTER
1586 003564 012737 177570 001142 MOV #DDIS,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
1587 003572 022777 177777 175340 CMP #1,SWR ;TRY TO REFERENCE HARDWARE SWR
1588 003600 001012 BNE 668 ;BRANCH IF NO TIMEOUT TRAP OCCURRED
1589 ;AND THE HARDWARE SWR IS NOT = -1
1590 003602 000403 BR 658 ;BRANCH IF NO TIMEOUT
1591 003604 012716 003612 648: MOV #658,(SP) ;SET UP FOR TRAP RETURN
1592 003610 000002 RTI
1593 003612 012737 000176 001140 658: MOV #SWREG,SWR ;POINT TO SOFTWARE SWR
1594 003620 012737 000174 001142 MOV #DISPREG,DISPLAY ;DISPREG,DISPLAY
1595 003626 012637 000004 668: MOV (SP)+,#ERRVEC ;RESTORE ERROR VECTOR
1596

```

```

1597 003632 023737 000042 000046 CMP #42,#46 ;ARE WE IN ACT11 AUTOMATIC MODE?
1598 003640 001416 BEQ 698 ;YES, SKIP TITLE PRINTOUT
1599 ;SBTTL TYPE PROGRAM NAME
1600 ;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
1601 003642 005227 177777 INC #1 ;FIRST TIME?
1602 003646 001052 BNE 678 ;BRANCH IF NO
1603 003650 104401 003706 TYPE ,698 ;TYPE ASCIZ STRING
1604 ;SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1605 003654 005737 000042 TST #42 ;ARE WE RUNNING UNDER XXDP/ACT?
1606 003660 001006 BNE 698 ;BRANCH IF YES
1607 003662 023727 001140 000176 CMP SWR,#SWREG ;SOFTWARE SWITCH REG SELECTED?
1608 003670 001005 BNE 708 ;BRANCH IF NO
1609 003672 104406 GTSWR ;GET SOFT-SWR SETTINGS
1610 003674 000403 BR 708
1611 003676 112737 000001 001134 698: MOV #1,AUTOB ;SET AUTO-MODE INDICATOR
1612 003704 708:
1613 003704 000433 BR 678 ;GET OVER THE ASCIZ
1614 ;688: .ASCIZ <CRLF>#RK11/RK05 PERFORMANCE EXERCISER#<15><12>#MAINDEC-11-DZRKH-G#<CRLF>
1615 003774 678:
1616 003774 012737 026206 000030 MOV #ERROR,#EMTVEC ;ENT VECTOR FOR ERROR ROUTINE
1617 004002 013737 001244 000032 MOV #PPLVL,#EMTVEC+2 ;LEVEL 8
1618 004010 012737 022552 000100 MOV #KNRVE,#KNLVEC ;KN111 CLOCK SERVICE
1619 004016 013737 001246 000102 MOV #KNPLVL,#KNLVEC+2 ;LEVEL 7
1620
1621 ;THE FOLLOWING CODE FINDS OUT THE PROGRAM CONTROL MODE:
1622 ;PAPER TAPE (MANUAL), ACT11, RKDP CHAIN OR DUMP
1623
1624
1625 004024 005037 002060 CLR XXDPMD ;CLEAR 'XXDP' LOAD DEVICE STORAGE
1626 004030 122737 000002 000041 CMPB #2,41 ;LOADED FROM AN RK05 ?
1627 004036 001160 BNE ST2 ;BR IF NOT
1628 004040 013737 000040 002060 MOV 40,XXDPMD ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1629 ;LOADING RK05
1630 004046 122737 000010 002060 CMPB #10,XXDPMD ;VALID DRIVE ADDRESS ?
1631 004054 101002 BHI 28 ;BR IF YES
1632 004056 105037 002060 CLRB XXDPMD ;CHANGE TO DRIVE ZERO
1633 004062 005737 000042 28: TST 42 ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1634 004066 001424 BEQ 38 ;BR IF NEITHER
1635 004070 104401 004076 TYPE ,728 ;TYPE ASCIZ STRING
1636 004074 000413 BR 718 ;GET OVER THE ASCIZ
1637 ;728: .ASCIZ <15><12>/NOT TESTING DRIVE /
1638 718:
1639 004124 CLR =(SP) ;CLEAR WORD ON STACK
1640 004126 113716 002060 MOVB XXDPMD,(SP) ;GET DRIVE ADDRESS
1641 004132 104403 TYPOS ;TYPE THE ADDRESS
1642 004134 001 .BYTE 1 ;ONLY 1 CHARACTER
1643 .BYTE 0 ;SUPPRESS LEADING ZEROS
1644 004136 000520 BR ST2 ;GET NUMBER OF DRIVES
1645 004140 005227 177777 38: INC #1 ;FIRST TIME THROUGH HERE ?
1646 004144 001115 BNE ST2 ;BR IF NOT
1647 004146 104401 004154 TYPE ,748 ;TYPE ASCIZ STRING
1648 004152 000411 BR 738 ;GET OVER THE ASCIZ
1649 ;748: .ASCIZ <15><12>/TO TEST DRIVE /
1650 738:
1651 004176 CLR =(SP) ;CLEAR WORD ON THE STACK
1652 004200 113716 002060 MOVB XXDPMD,(SP) ;GET DRIVE ADDRESS

```

```

1653 004704 104403          TYPOS          ;TYPE THE DRIVE ADDRESS
1654 004706          ,BYTE 1          ;ONLY 1 CHARACTER
1655 004707          ,BYTE 0          ;SUPPRESS LEADING ZEROS
1656 004710 104401 004216    TYPE ,768        ;TYPE ASCIZ STRING
1657 004714 000431          BR 758          ;GET OVER THE ASCIZ
1658          ;1768: ,ASCIZ / HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
1659          758:
1660 004700 104401 004306    TYPE ,788        ;TYPE ASCIZ STRING
1661 004704 000435          BR 778          ;GET OVER THE ASCIZ
1662          ;1788: ,ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
1663          778:
1664
1665
1666
1667 004400 104416          ST2: CON,RESET
1668 004402 005037 001264    CLR DRVPR8      ;FIND WHICH DRIVE #'S ARE PRESENT
1669 004406 005000          CLR R0
1670 004410 005002          CLR R2
1671 004412 005037 001254    CLR PDR        ;CLEAR DRIVES PRESENT TABLE
1672 004416 005037 001256    CLR PDR*2
1673 004422 005037 001260    CLR PDR*4
1674 004426 005037 001262    CLR PDR*6
1675 004432 012701 001254    MOV #PDR,R1
1676 004436 012703 001306    MOV #KEY,R3
1677 004442 010277 174562    MOV R2,SRKDA   ;SELECT A DRIVE
1678 004446 032777 000200 174842 BIT #200,SRKDB ;IS IT IN SYSTEM?
1679          BEQ 38
1680          MOV R2,ODRV ;LOAD DRIVE ADDRESS INTO ODRV
1681 004462 104420          DRV,RESET     ;RESET THE DRIVE
1682 004464 005737 002060    TST XXDPM      ;PROGRAM LOADED FROM AN RK05 ?
1683 004470 001403          BEQ 28        ;BR IF NOT
1684 004472 120037 002060    CMPB R0,XXDPM  ;LOADED FROM THIS RK05 ?
1685 004476 001404          BEQ 38        ;BR IF YES
1686          MOV# R0,(R1)+ ;STORE THE DRIVE NUMBER
1687 004502 010223          MOV R2,(R3)+ ;STORE ADDRESS IN KEY TABLE
1688 004504 005237 001264    INC DRVPR8     ;BUMP THE NUMBER OF DRIVES COUNTER
1689 004510 062702 020000 38:  ADD #20000,R2  ;NEXT DRIVE ADDRESS
1690 004514 005200          INC R0        ;NEXT DRIVE NUMBER
1691 004516 022700 000010    CMP #8,R0     ;DONE ALL DRIVES??
1692 004522 001347          BNE 18        ;LOOP TILL DONE
1693 004524 013703 001264    MOV DRVPR8,R3 ;FIND WHICH DRIVES ARE TYPE F
1694 004530 001510          BEQ ST4      ;BR IF NOT DRIVES PRESENT
1695 004532 012701 001254    MOV #PDR,R1
1696 004536 005000          CLR R0
1697 004540 005002          CLR R2
1698 004542 104401 002362    TYPE ,MSG20
1699 004546 111102 48:  MOV# (R1),R2   ;GET DRIVE NUMBER
1700 004550 010200          MOV R3,R0
1701 004552 002472          BLT 96
1702
1703 004554 104401 002372    TYPE ,MSG24
1704
1705 004560 010246          MOV R2,=(SP)  ;TYPE THE DRIVE NUMBER
1706 004562 104403          TYPOS
1707 004564          ,BYTE 1
1708 004566          ,BYTE 0
    
```

```

1709 004566 000241          CLC           ;MOVE DRIVE NUMBER TO BITS 15,14,13
1710 004570 006002          ROR R2       ;BIT0 TO CARRY
1711 004572 006002          ROR R2       ;BIT0 TO BIT15
1712 004574 006002          ROR R2       ;BIT0 TO BIT14
1713 004576 006002          ROR R2       ;BIT0 TO BIT13
1714 004600 042702 017777    BIC #17777,R2 ;CLEAR ANY EXTRANEIOUS BITS
1715
1716 004604 010237 001502    MOV R2,ODRV
1717 004610 104420          DRV,RESET     ;RESET THE DRIVE VIA ODRV
1718
1719 004612 032702 020000    BIT #20000,R2 ;EVEN DRIVE NUMBER???
1720 004616 001003          BNE 56       ;NO - CLEAR BIT
1721
1722 004420 052702 020000    BIS #20000,R2 ;MAKE IT AN ODD DRIVE
1723 004624 000402          BR 66
1724
1725 004626 042702 020000 58:  BIC #20000,R2 ;MAKE IT AN EVEN DRIVE
1726
1727 004632 010277 174372 68:  MOV R2,SRKDA   ;SELECT THE NEW DRIVE
1728 004636 032777 000200 174352 BIT #200,SRKDB ;MAKE SURE DRIVE IS IN SYSTEM
1729 004644 001420          BEQ 80       ;IF NOT, SKIP THIS TEST
1730
1731 004646 012777 000011 174346 MOV #11,SRKCB ;START A SEEK TO CYL 0
1732 004654 104417          CON,RDY     ;WAIT FOR CONTROLLER
1733 004656 032777 000100 174332 BIT #100,SRKDB ;IS IT IN MOTION???
1734 004664 001010          BNE 80       ;NO - J TYPE DRIVE
1735
1736 004666 152711 000200    BISB #200,(R1) ;YES - SET THE F TYPE BIT
1737 004672 104401 002375    TYPE ,MSG25
1738
1739 004676 032777 000100 174312 78:  BIT #100,SRKDB ;WAIT FOR HEADS TO STOP
1740 004704 001774          BEQ 78
1741
1742 004706 105737 001253 88:  TSTB FRSTRT
1743 004712 001012          BNE 90
1744
1745 004714 032777 000002 174216 BIT #8W1,#8W2 ;SERIAL NO. SW SET?
1746 004722 001406          BEQ 98
1747
1748 004724 104401 002326    TYPE ,MSG17   ;TYPE "SR NO"
1749 004730 104413          RDDEC      ;READ FROM TTY INPUT
1750 004732 006300          ABL R0      ;SAVE SERIAL NO FOR THE DRIVE
1751 004734 012660 001266    MOV (SP)+,SRNO(R0)
1752
1753 004740 005201 98:  INC R1
1754 004742 005303          DEC R3
1755 004744 003300          BOT 48
1756 004746 104401 001213    TYPE ,SCR1F
    
```

```

1757 ;'MAXBA' IS THE HIGHEST BUS ADDRESS (MEMORY) TO WHICH DATA TRANSFERS CAN
1758 ;BE DONE BY THE PROGRAM.
1759 ;'MAXBA' IS FIGURED USING THE FOLLOWING ALGORITHM:
1760
1761 ;1. IF KT11 IS NOT PRESENT,
1762 ;A. AND THE PROGRAM IS RUN UNDER XXDP, THEN THE TOP 1.5 K IS RESERVED
1763 ;AND THE 'MAXBA' IS COMPUTED ($LSTAD-6000).
1764 ;B. AND THE PROGRAM IS NOT RUNNING UNDER XXDP, THEN THE TOP 320 WORDS
1765 ;ARE RESERVED FOR 'MOM',LOADER,ETC. AND THE 'MAXBA' IS COMPUTED ($LSTAD-800).
1766
1767 ;2. IF KT11 IS PRESENT,
1768 ;A. AND MORE THAN 28K MEMORY IS PRESENT, THEN THE MAXIMUM BUS ADDRESS
1769 ;IS 147776 (OCTAL).
1770 ;B. AND LESS THAN 28K IS PRESENT, THEN THE TOP 2K IS RESERVED FOR RKDP
1771 ;MONITOR AND 'MAXBA' IS COMPUTED.
1772 ;FIGURE OUT THE AVAILABLE MEMORY AND 'MAXBA'
1773
1774 004752 004737 017466 ST4: JSR PC,$SIZE ;GO SIZE THE MEMORY
1775 004756 012702 002052 MOV $BASEBA,R2 ;INITIALIZE POINTERS
1776 004762 012703 002054 MOV $MAXBA,R3
1777 004766 005737 017524 TST $KT11 ;KT11 AVAILABLE?
1778 004772 100022 BPL 48 ;NO
1779 004774 013700 017772 MOV $LSTBK,R0 ;GET THE LAST BANK OF MEMORY
1780 005000 020027 001540 CMP R0,$1540 ;28K OR MORE?
1781 005004 002012 BGE 38 ;YES
1782
1783 005006 162700 000040 SUB $40,R0 ;BACK UP 2 K'S (RKDP MONITOR, ETC.)
1784 005012 012701 177772 MOV $=6,R1 ;AND FORM THE MAXIMUM BUS ADDRESS
1785 ;FOR DATA TRANSFER
1786 005016 006300 18: ASL R0
1787 005020 005201 INC R1
1788 005022 001375 BNE 18
1789 005024 162700 000002 SUB $2,R0
1790 005030 000415 28: BR 68
1791
1792 005032 012713 147776 38: MOV $147776,(R3) ;FOR 28K OR MORE, THIS IS THE 'MAXBA'
1793 005036 000413 BR 78
1794
1795 005040 013700 017770 48: MOV $LSTAD,R0 ;KT11 NOT PRESENT, GET THE LAST
1796 ;AVAILABLE ADDRESS
1797
1798 005044 005737 000040 58: TST $840 ;'XXDP' LOADED PROGRAM ?
1799 005050 001003 BNE 88 ;YES
1800 005052 162700 000800 SUB $800,R0 ;NO, SAVE THE LAST 320 WORDS
1801 005056 000402 BR 68
1802 005060 162700 006000 88: SUB $6000,R0 ;SAVE THE LAST 1.5K OF MEMORY (RKDP
1803 ;MONITOR, ETC.)
1804 005064 010013 88: MOV R0,(R3) ;SAVE THE MAXIMUM BUS ADDRESS(MAXBA) TO
1805 ;WHICH DATA TRANSFER CAN BE DONE SAFELY
1806 005066 012712 032514 78: MOV $DGENB,(R2) ;'BASEBA'
1807 005072 032777 000100 174040 BIT $806,$8MR
1808 005100 001510 BEQ 87
1809 005102 104401 005110 TYPE ,658 ;TYPE ASCII STRING
1810 005106 000432 BR 648 ;GET OVER THE ASCII
1811 ;;658: .ASCII <15><12>/TYPE OCTAL BUS ADDRESSES FOR DATA XFER, BETWEEN /
1812 005174 648:
    
```

```

1813 005174 011246 MOV (R2),-(SP) ;'BASEBA'
1814 005176 104402 TYPOC
1815 005200 104401 005206 TYPE ,678 ;TYPE ASCII STRING
1816 005204 000402 BR 668 ;GET OVER THE ASCII
1817 ;;678: .ASCII / & /
1818 005212 668:
1819 005212 011346 MOV (R3),-(SP) ;'MAXBA'
1820 005214 104402 TYPOC
1821 005216 98:
1822 005216 104401 005224 TYPE ,698 ;TYPE ASCII STRING
1823 005222 000407 BR 688 ;GET OVER THE ASCII
1824 ;;698: .ASCII <15><12>/LO LIMIT? /
1825 005242 688:
1826 005242 104412 RDOCT
1827 005244 012600 MOV (SP)+,R0
1828 005246 020012 CMP R0,(R2) ;CORRECT LO LIMIT?
1829 005250 103762 BLO 98
1830 005252 020013 CMP R0,(R3) ;CORRECT LO LIMIT?
1831 005254 103360 BHIS 98
1832 005256 010012 MOV R0,(R2) ;'BASEBA'
1833 005280 108:
1834 005280 104401 005266 TYPE ,718 ;TYPE ASCII STRING
1835 005284 000407 BR 708 ;GET OVER THE ASCII
1836 ;;718: .ASCII <15><12>/HI LIMIT? /
1837 708:
1838 005304 RDOCT
1839 005306 012600 MOV (SP)+,R0
1840 005310 020013 CMP R0,(R3) ;CORRECT HI LIMIT?
1841 005312 101362 BHI 108
1842 005314 020012 CMP R0,(R2) ;CORRECT LO LIMIT?
1843 005316 101760 BLOS 108
1844 005320 010013 MOV R0,(R3) ;'MAXBA'
1845
1846 005322 023727 002054 037476 ST3: CMP MAXBA,$37476 ;8K MEMORY = CLOBBER XXDP
1847 005330 002003 BGE 18 ;
1848 005332 012737 037476 002054 MOV $37476,MAXBA ;BUT SAVE LOADER
1849 005340 105737 001253 18: TSTB FRSTRT ;PROGRAM RESTARTED AT 210?
1850 005344 001402 BEQ 18 ;NO
1851 005346 000137 007772 JMP EXRCBR ;YES, SKIP TEST 1 TO 7
    
```

```

1852 ;THIS IS THE BEGINING OF THE CONSTRAINED TESTS AIMED AT CHECKING THE
1853 ;DIFFERENT BOUNDARY CONDITIONS OF RK11/RK05
1854
1855 ;FIND OUT THE DRIVE NUMBER TO BE TESTED,
1856 005152 012737 00110A 001476 BCTST1 MOV $KEY,DRVPTR ;INITIALIZE PTR TO DRV#
1857 005160 013737 001264 001500 MOV DRVPRS,DRVCNT ;NUMBER OF DRIVES PRESENT
1858 005166 017737 174104 001502 NATDRV: MOV $DRVPTR,QDRV ;SAVE DRIVE #(BITS 15-13)
1859 005174 062737 000002 001476 ADD $2,DRVPTR ;INCREMENT PTR TO NXT DRV#
1860 005402 063337 001500 DEC DRVCNT ;DONE ALL DRIVES?
1861 005406 100002 BPL TST1 ;NO, GO TEST THIS DRIVE
1862 005410 000137 007772 JMP EXCRSR ;ALL DONE, GO TO EXERCISER PART
    
```

```

1863 ;*****
1864 ;TEST 1 PERFORM WRITE OF 401 WORDS (1 SECTOR + 1 WORDS)
1865 ;THIS TEST PERFORMS A WRITE OF 401 WORDS (1 SECTOR + 1WORD) AND
1866 ;CHECKS IF RKDA,RKBA,RKWC INCREMENTED CORRECTLY,WRITING IS DONE
1867 ;ON CYLINDER 0, SURFACE 0, SECTORS 0,1 AND 10,11, IT SHOULD BE
1868 ;NOTED THAT THIS IS A BOUNDARY CONDITION TRANSFER, THE VALIDITY
1869 ;OF THE TRANSFER IS CHECKED IN THE NEXT TEST,
1870 ;DATA PATTERN WRITTEN IS 111111.
1871 ;*****
1872 005414 000004 TST11 SCOPE
1873
1874 005416 013701 001502 MOV QDRV,R1 ;GET RKDA
1875 005422 010102 MOV R1,R2 ;SAVE RKDA
1876 005424 062702 000002 ADD $2,R2 ;EXPCTD RKDA AFTER WRITE IS DONE
1877
1878 005430 012737 005436 001110 MOV $10,$LPERR ;RETURN ADDRESS FOR LUPING
1879
1880 005436 104416 18: CON,RESET
1881 005440 104420 DRV,RESET
1882 005442 104416 CON,RESET
1883 005444 012737 111111 032514 28: MOV $111111,DBUF ;CLEAR MASK BITS IN POLLING LOGIC
1884 005452 012703 000401 MOV $401,R3 ;PATTERN TO BE WRITTEN
1885 005456 004737 006304 JSR PC,DOWRITE ;WORD COUNT FOR WRITE
1886 ;GO DO WRITE
1887 005462 104101 ERROR 101 ;INTERRUPT DID NOT OCCUR AFTER WRITE
1888 005464 004737 020112 JSR PC,CHKCS ;CHECK ERROR BIT IN RKCS
1889 005470 104102 ERROR 102 ;ERROR BIT IN RKCS SET ON DOING WRITE
1890 005472 004737 020126 JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED RIGHT
1891 005476 104103 ERROR 103 ;RKDA DID NOT INCREMENT RIGHT AFTER
1892 ;A WRITE OF 401 WORDS,
1893 005500 004737 020230 JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0
1894 005504 104105 ERROR 105 ;RKWC DID NOT OVERFLOW TO 0 AFTER
1895 ;A WRITE OF 401 WORDS,
1896 005506 032701 000010 BIT $10,R1 ;SECTORS 10,11 WRITTEN?
1897 005512 001005 BNE TST2 ;YES
1898 005514 062701 000012 ADD $12,R1 ;RKDA TO BE USED NEXT (SEC 10)
1899 005520 062702 000016 ADD $16,R2 ;EXPCTD RKDA AFTER WRITE IS DONE
1900 005524 000747 BR 28 ;GO WRITE SECS 10,11
    
```

```
1901 ;*****
1902 ;TEST ? READ & CHECK THAT 401 WORD WRITE WAS DONE CORRECTLY
1903 ;THIS TEST PERFORMS A READ OF THE 401 WORDS WRITTEN IN THE
1904 ;PREVIOUS TEST AND CHECKS THAT THEY WERE CORRECTLY READ, MOREOVER
1905 ;IT CHECKS THAT ONLY ONE NON-ZERO WORD (401TH) WAS WRITTEN IN THE
1906 ;SECOND SECTOR AND THE REST OF THE WORDS ARE ALL ZEROS,
1907 ;*****
1908 TST2: SCUPE
1909
1910 005430 013701 001502 MOV QDPV,R1 ;GET DRIVE #
1911 005434 012737 005542 001110 MOV #10,SLPERR ;ADDRESS FOR LUPING ON ERROR
1912 005442 104416 100 CON,RESET
1913 005444 104420 DRV,RESET
1914 005446 104416 CON,RESET
1915
1916
1917 005450 004737 006436 JSR PC,CLEANBUF ;CLEAN UP THE DATA BUFFER
1918 ;INTO WHICH READ WILL
1919 ;BE DONE
1920 MOV #1000,R3 ;WORD COUNT
1921
1922 JSR PC,DOREAD ;GO DO A READ OF 2 SECTORS
1923 005464 104101 ERROR 101 ;FROM DISK ADDRESS GIVEN IN R1
1924 ;INTERRUPT DID NOT OCCUR AFTER
1925 ;READ OF 401 WORDS WAS DONE,
1926 005472 104102 JSR PC,CHKCS ;CHECK IF ERROR BIT IN RKCS SET?
1927 ERROR 102 ;ERROR BIT IN RKCS SET ON DOING A
1928 ;READ OF 401 WORDS,
1929 005474 012704 032514 MOV #DBUF,R4 ;STARTING BUS ADDRESS, INTO WHICH READ
1930 005600 010402 MOV R4,R2 ;WAS DONE
1931 005602 004737 020150 JSR PC,CHKBA ;CHECK IF RKBA INCREMENTED RIGHT
1932 005606 104104 ERROR 104 ;RKBA DID NOT INCREMENT RIGHT AFTER READ
1933 ;OF 401 WORDS,
1934 005610 012705 177764 MOV #14,R5 ;ALLOW 12 ERRORS, AT THE MOST
1935 005614 022712 111111 200 CMP #111111,(R2) ;CORRECT DATA READ?
1936 BEQ 38 ;YES
1937 005622 012737 111111 001164 MOV #111111,#REG1 ;GET EXPCTD DATA WORD
1938 JSR PC,ERINF1 ;GET ERROR INFORMATION
1939 ERROR 100 ;DATA ERROR OCCURRED WHEN A
1940 ;READ OF 401 WORDS WAS DONE
1941 ;THE DISK ADDRESS FROM WHERE
1942 ;THE DATA WAS READ INCORRECTLY
1943 ;IS GIVEN IN THE ERROR MESSAGE
1944
1945 005636 005205 INC R5 ;REPORT 12 ERRORS AT MOST
1946 005640 001421 BEQ 68
1947 005642 005722 300 TST (R2)+ ;INCREMENT POINTER
1948 005644 020227 033516 CMP R2,#DBUF+1002 ;CHECKED ALL 401 WORDS?
1949 BNE 28
1950
1951 005652 005712 400 TST (R2) ;CHECK THAT REST OF 377 WORDS
1952 005654 001407 BEQ 58 ;ARE ALL 0'S
1953 005656 005037 001164 CLR #REG1 ;GET EXPCTD DATA WORD (0)
1954 005662 004737 005720 JSR PC,ERINF1 ;GET ERROR INFO
1955 005666 104100 ERROR 100 ;DATA ERROR. IN A PREVIOUS
1956 ;TEST A WRITE OF 401 WORDS
1957 ;(1 SECTOR + 1 WORD) WAS DONE
```

```
1957 ;NOW THESE 2 SECTORS WERE
1958 ;READ IN THE SECOND SECTOR
1959 ;THE FIRST WORD IS A NON-ZERO
1960 ;WORD (WHICH WAS WRITTEN BEFORE)
1961 ;THE REST OF 377 WORD
1962 ;SHOULD BE ALL ZEROS, IF
1963 ;THE WRITE WAS DONE CORRECTLY
1964 ;(& READ IS DONE CORRECTLY)
1965
1966 005670 005205 INC R5 ;REPORT 12 ERRORS AT MOST
1967 005672 001404 BEQ 68
1968 005674 005722 500 TST (R2)+ ;ALL WORDS CHECKED?
1969 005676 020227 034514 CMP R2,#DBUF+2000
1970 005702 001363 BNE 40 ;IF NOT GO BAK
1971
1972 005704 032701 000010 600 BIT #10,R1 ;WERE SECTORS 10,11 READ
1973 005710 001030 BNE TST3 ;YES
1974 005712 062701 000012 ADD #12,R1 ;FROM NEW RKDA, SEC 10
1975 005716 000711 BR 18 ;GO BACK AND READ FROM SECS 10,11
1976
1977 ;ERINF1
1978 ;AT THE TIME OF ENTRY:
1979 ;R2 CONTAINS ERRORING BUS ADDRESS (WHERE DATA ERROR OCCURRED),
1980 ;(R2) CONTAINS BAD DATA THAT WAS READ BACK FROM DISK,
1981 ;R1 CONTAINS DISK ADDRESS WHERE READ BEGAN.
1982
1983 005720 010237 001162 ERINF1: MOV R2,#REG0 ;GET BUS ADDRESS OF DATA ERROR
1984 005724 011237 001166 MOV (R2),#REG2 ;GET BAD DATA WORD (READ)
1985 005730 010146 MOV R1,#(SP)
1986 005732 020227 033512 CMP R2,#DBUF+776 ;FIGURE OUT THE DISK ADDRESS
1987 005736 003001 BGT 18 ;WHERE DATA ERROR OCCURRED
1988 005740 005316 DEC (SP)
1989 005742 005216 100 INC (SP)
1990 005744 032716 BIT #10,(SP)
1991 005750 001405 BEQ 28
1992 005752 032716 BIT #4,(SP)
1993 005756 001402 BEQ 28
1994 005760 062716 ADD #4,(SP)
1995 005764 012637 001170 200 MOV (SP)+,#REG3
1996 005770 000207 RTS PC
```

```

1997 ;*****
1998 ;*TEST 3 PERFORM WRITE OF 12 SECTORS + 1 WORD
1999 ;THIS TEST CHECKS FOR ANOTHER BOUNDARY CONDITION, IT
2000 ;PERFORMS A WRITE OF 12 SECTORS + 1 WORD. RKDA,RKBA,
2001 ;RKWC ARE CHECKED TO SEE IF THEY ARE INCREMENTED CORRECTLY,
2002 ;VALIDITY OF THE DATA WRITTEN IS CHECKED IN THE NEXT
2003 ;TEST. DATA IS WRITTEN ON SECTORS 0-11, SURFACE 0
2004 ;CYLINDER 0 (6001TH WORD ON SECTOR 0, SURFACE 1, CYL 0),
2005 ;ALSO ON SECTORS 0-11, SURFACE 1 (6001TH WORD ON SECTOR
2006 ;0, CYL 1)
2007 ;*****
2008 TST3: SCOPE
2009 MOV QDRV,R1 ;GET DRIVE #
2010 MOV #18,SLPERR ;LUP ON ERROR TO '18'
2011 MOV R1,R2
2012 ADD #21,R2
2013 MOV #6001,R3
2014 CON,RESET
2015 DRV,RESET
2016 CON,RESET
2017
2018
2019 MOV #44444,DRUF ;PATTERN TO BE WRITTEN
2020
2021 JSR PC,DOWRITE ;GO DO WRITE
2022
2023 ERROR 101 ;INTERUPT DID NOT OCCUR ON
2024 ;COMPLETION OF WRITE
2025 JSR PC,CHKCS ;CHECK IF EROR BIT IN RKCS SET
2026 ERROR 102 ;EROR BIT IN RKCS SET ON DOING WRITE
2027 JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED RIGHT
2028 ERROR 103 ;RKDA DID NOT INCREMENT CORRECTLY
2029 ;AFTER A WRITE OF 6001 (OCTAL) WORDS,
2030 ;(12 SECTORS + 1)
2031 JSR PC,CHKWC ;CHECK IF RKWC OVERFLOWED TO 0
2032 ERROR 104 ;RKWC DID NOT OVERFLOW TO 0
2033 BIT #20,R1 ;WRITTEN ON SURFACE 1?
2034 BNE TBT4 ;YES
2035 MOV R2,R1
2036 ADD #20,R2 ;SURFACE 1
2037 MOV #5401,R3 ;WORD COUNT
2038 BR 16 ;GO WRITE SURFACE 1
    
```

```

2039 ;*****
2040 ;*TEST 4 READ & CHECK THAT 6001 WORD WRITE WAS DONE CORRECTLY
2041 ;THIS TEST CHECKS THAT THE 6001-WORD WRITE THAT WAS DONE IN THE
2042 ;PREVIOUS TEST WAS CORRECT, ESPECIALLY THE LAST 401 WORDS. THE
2043 ;FIRST WORD OF THE SECTOR( IN WHICH THE 6001TH WORD) IS WRITTEN
2044 ;IS THE ONLY NON-ZERO WORD IN THAT SECTOR, THE REST 377 WORDS ARE
2045 ;ALL ZEROS, IF THE WRITING WAS DONE CORRECTLY.
2046 ;*****
2047 TST4: SCOPE
2048 MOV QDRV,R1 ;GET DRIVE #
2049 ADD #13,R1 ;DISK ADDRESS FROM WHERE READ IS DONE
2050 MOV #18,SLPERR
2051 CON,RESET
2052 DRV,RESET
2053 CON,RESET
2054
2055 JSR PC,CLEANBUF ;CLEAN UP THE BUFFER INTO WHICH
2056 ;READ WILL BE DONE
2057 ;SET UP RKDA
2058 ;SECTOR 11, SURFACE 0
2059 MOV #1000,R3 ;WORD COUNT
2060
2061 JSR PC,DOREAD ;GO READ 1000 WORDS (2 SECS)
2062 ERROR 101 ;INTERUPT DID NOT OCCUR AFTER
2063 ;COMPLETION OF READ
2064 JSR PC,CHKCS ;CHECK IF EROR BIT IN RKCS SET
2065 ERROR 102 ;EROR (RKCS) SET ON DOING READ
2066 MOV #DBUF,R4 ;STARTING BA OF DATA BUFR
2067 MOV R4,R2
2068 JSR PC,CHKBA ;RKBA INCREMENTED CORRECTLY?
2069 ERROR 104 ;RKBA DID NOT INCREMENT CORRECTLY
2070 MOV #-14,R5
2071 CMP #44444,(R2) ;DATA WORD OK?
2072 BEQ 36
2073 MOV #44444,REG1 ;NO, GET EXPECTD DATA WORD
2074 JSR PC,ERINP1 ;GET, OTHER ERROR INFO
2075 ERROR 100 ;DATA ERROR. A WRITE OF 6001
2076 ;WORDS (12 SECS + 1 WORD) WAS DONE
2077 ;IN A PREVIOUS TEST. THE LAST TWO
2078 ;SECTORS (LAST 401 WORDS) WERE READ
2079 ;BACK. THIS ERROR INDICATES THAT
2080 ;SEC #11 (LAST BUT ONE SECTOR) GAVE
2081 ;BAD DATA WORDS
2082 ;REPORT 12 ERRORS AT MOST
2083 INC R5
2084 BEQ 66
2085 TBT (R2)+ ;INCREMENT POINTER TO BA
2086
2087 CMP R2,DBUF+1002 ;CHECKED 401 WORDS?
2088 BNE 26
2089 TBT (R2) ;CHECK THAT THE REMAINING 377
2090 BEQ 56 ;WORDS OF THE LAST SECTOR (SEC 0)
2091 CLR REG1 ;WERE READ BACK AS 0'S
2092 JSR PC,ERINP1
2093 ERROR 100 ;DATA ERROR. IF WRITE WAS DONE CORRECTLY
2094 ;IN THE PREVIOUS TEST, THE LAST SECTOR
2095 ;OF THE DATA BLOCK (12 SECS + 1 WORD)
2096 ;SHOULD CONTAIN ONLY 1 (FIRST) WORD
    
```



```

2095
2096
2097
2098
2099 006954 008205          INC      R8
2100 006956 001404          BEQ      R8
2101 006960 008722          TST     (R2)+
2102 006962 020227 034514  881     CMP     R2,#DBUF+2000
2103 006966 001363          BNE     R8
2104
2105 006970 032701 000020  881     BIT     #20,R1
2106 006974 001070          BNE     TSTB
2107 006976 062701 000020  881     ADD     #20,R1
2108 006102 000711          BR      16

```

;AS NON-ZERO, THE REST 377 SHOULD BE  
 ;ALL 0'S, THIS ERROR INDICATES THAT  
 ;THE SOME OF 377 WORDS  
 ;WERE NOT CORRECT  
 ;REPORT 12 ERRORS AT MOST  
  
 ;INCREMENT POINTER  
 ;CHECKED ALL WORDS?  
 ;NO  
  
 ;DONE CHECKING FOR SURFACE 1?  
 ;YES  
 ;SO SET UP FOR SURFACE 1  
 ;GO BACK & READ SURFACE 1

```

2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119 006304 012777 004002 172710  DOWRITE; MOV    #4002,#RKCS
2120 006312 010177 172712          DOXFER; MOV    R1,#RKDA
2121 006316 010377 172702          MOV     R3,#RKWC
2122 006322 005477 172676          NEG     #RKWC
2123 006326 012777 032514 172672  MOV     #DBUF,#RKBA
2124 006334 012777 006414 172676  MOV     #38,#RKVEC
2125 006342 005046          CLR    -(SP)
2126 006344 012746 006352          MOV    #18,-(SP)
2127 006350 000002          RTI
2128 006352 052777 000101 172642 18:    BIS    #101,#RKCS
2129 006360 005037 001466          CLR    C1CNT
2130 006364 012737 177760 001470  MOV    #-20,C1CNT1
2131 006372 005237 001466 28:    INC    C1CNT
2132 006376 001375          BNE    -4
2133
2134 006400 005237 001470          INC    C1CNT1
2135 006404 001372          BNE    28
2136
2137 006406 004737 022032          JSR    PC,@TARG
2138 006412 000207          RTS    PC
2139
2140 006414 022626          38:    CMP    (SP)+,(SP)+
2141 006416 062716 000002          ADD    #2,(SP)
2142 006422 000207          RTS    PC

```

;THIS ROUTINE PERFORMS A WRITE ON A DISK, AT THE TIME OF ENTRY, R1 CONTAINS  
 ;DISK ADDRESS (RKDA) WHERE WRITE IS TO BE DONE, R3 CONTAINS THE WORD COUNT  
 ;(RKWC), 'DBUF' CONTAINS THE DATA TO BE WRITTEN, NOTE ISA BIT IS SET,  
  
 ;WRITE IS DONE IN INTERRUPT MODE, IF THE INTERRUPT DOES NOT OCCUR WITHIN  
 ;A CERTAIN TIME, RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'  
 ;CALL, IF THE INTERRUPT OCCURS, RETURN ADDRESS IS ADJUSTED TO SKIP OVER  
 ;THE ERROR MESSAGE,  
  
 ;WRITE, ISA  
 ;ADDRESS THE DRIVE  
 ;XFER THIS # OF WORDS  
  
 ;USE THIS BUS ADDRESS  
 ;SET UP INTERRUPT VECTOR  
 ;NEW PSW  
 ;SET NEW PC TO STACK \*\*\*\*\*  
  
 ;SET IDE, GO (WRITE, IBA/ READ)  
  
 ;WAIT FOR INTERRUPT  
  
 ;TIMED OUT, INTERRUPT DID NOT OCCUR  
 ;RETURN TO THE ERROR MESSAGE  
  
 ;RESTORE STACK POINTER  
 ;ADJUST RETURN ADDRESS TO SKIP OVER  
 ;ERROR MESSAGE ON RETURN

```

2143 ;THIS ROUTINE PERFORMS A READ ON THE DISK, AT THE TIME OF ENTRY R1 CONTAINS
2144 ;THE DISK ADDRESS FROM WHERE THE READ IS TO BE DONE, R3 CONTAINS THE WORD
2145 ;COUNT (RKWC). READ WILL BE DONE INTO DATA BUFFER AT 'DBUF'.
2146
2147 ;READ IS DONE IN INTERRUPT MODE. IF THE INTERRUPT DOES NOT OCCUR WITHIN
2148 ;A CERTAIN TIME, RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
2149 ;CALL. IF THE INTERRUPT OCCURS AS EXPECTED, RETURN ADDRESS IS ADJUSTED
2150 ;TO SKIP OVER THE ERROR MESSAGE.
2151
2152 006424 012777 000004 172570 DOREAD: MOV #4, @RKCS ;READ
2153 006432 000727 BR DOXFER
2154
2155 ;CLEANBUF
2156 ;CLEANS OUT THE DATA BUFFER (ALL WORDS WRITTEN TO 177777) INTO WHICH THE
2157 ;READ FROM THE DISK WILL BE DONE. DATA BUFFER STARTS AT 'DBUF' AND IS
2158 ;1000 (OCTAL) WORDS LONG.
2159
2160
2161 006434 012702 177000 CLEANBUF: MOV #1000, R2 ;SET COUNT
2162 006440 012708 032514 MOV @DBUF, R5 ;INITIALIZE BA
2163 006444 012725 022222 10: MOV #22222, (R5)+
2164 006450 005202 INC R2 ;DONE ALL WORDS?
2165 ;BUFFER STARTING AT (PHYSICAL) BUS
2166 ;ADDRESS 177000 (177000-200776)
2167 006452 001374 BNE 10
2168 006454 000207 RTS PC ;YES RETURN
    
```

```

2169 ;*****
2170 ;TEST 5 CHECK DATA TRANSFER AROUND 32K BOUNDARY
2171 ;*THIS TEST PERFORMS A WRITE OF 2 SECTORS ON THE DISK FROM MEMORY
2172 ;*LOCATIONS AROUND THE 32K BOUNDARY. SECTORS 0,1, CYL 0, SURFACE
2173 ;*0 ARE WRITTEN. PHYSICAL BUS ADDRESSES FOR THE DATA BUFFER:
2174 ;* 177000 TO 200776 I.E. (32K-256) TO (32K+256)
2175
2176 ;*CHECKING IS DONE TO SEE IF MEX BITS, RKBA, RKDA, RKWC INCREMENTED
2177 ;*CORRECTLY. THEN DATA BUFFER IS CLEARED OUT AND A READ IS DONE
2178 ;*INTO IT. A CHECK IS MADE TO SEE IF THE CORRECT DATA WAS RECEIVED.
2179 ;*ONLY 12 DATA ERRORS ARE REPORTED.
2180 ;*****
2181 006456 000004 TSTS: SCOPE
2182 006460 023727 017772 002000 CMP @LSTBK, @2000 ;32K OR MORE OF MEMORY?
2183 006466 103002 BHS 10 ;YES
2184 006470 000137 007040 JMP TST6 ;IF NOT, DONT DO THIS TEST
2185 006474 012737 001600 172352 10: MOV #1600, @SKIPAR5 ;MAP 28-32K THRU PAR 5
2186 006502 012737 002000 172354 MOV #2000, @SKIPAR6 ;MAP 32-36K THRU PAR 6
2187 006510 012737 000001 172572 MOV #1, @SRO ;TURN ON MEMORY MANAGEMENT
2188
2189 ;SET UP DATA BUFFER (1000 OCTAL WORDS LONG) FOR WRITING TWO SECTORS
2190 ;ON THE DISK. THE TRANSFER IS DONE AROUND THE 32K BOUNDARY FROM
2191 ;BUS ADDRESS (PHYSICAL) 177000 TO 200776, (32K-256) TO (32+256)
2192
2193 ;DATA IN THE BUFFER IS A COUNT PATTERN STARTING FROM 1 FOR THE FIRST
2194 ;WORD TO 000 FOR THE LAST WORD.
2195 ;PHYSICAL BUFFER ADDRESS: 177000 TO 200776 (32K-256 TO 32K+256)
2196 006516 012737 006524 001110 20: MOV #20, @LVERR ;LUP TO 20 ON ERROR (BN 9)
2197 006524 104416 CON, RESET
2198 006526 104420 DRV, RESET
2199
2200 006530 012700 000001 MOV #1, R0 ;INITIALIZE DATA PATTERN TO BE
2201 ;WRITTEN
2202 006534 012701 137000 30: MOV #137000, R1 ;BA TO START PHYSICAL ADDRESS=177000
2203 006540 010021 MOV R0, (R1)+ ;WRITE COUNT PATTERN (1-1000)
2204 006542 005200 INC R0 ;INTO DATA BUFFER (PHYS ADDR)
2205 006544 020027 001001 CMP R0, #1001 ;177000 TO 200776)
2206 006550 013773 BNE 30
2207 006552 013777 001502 172450 MOV @DRV, @RKDA ;SUR 0, SEC 0, CYL 0
2208 006560 012777 177000 172438 MOV #1000, @RKWC ;WORD COUNT #2 SECS
2209 006566 012777 177000 172432 MOV #177000, @RKBA ;BUS ADDRESS.
2210 006574 012777 000003 172430 MOV #3, @RKCS ;WRITE, GO
2211 006602 104417 CON, RDY ;WAIT FOR CNTRL RDY
2212
2213 006604 004737 020112 JSR PC, CHKCS ;ANY ERROR IN RKCS?
2214 006610 104102 ERROR 102 ;'ERR' SET IN RKCS, ON DOING A
2215 ;WRITE OF SECTORS (0,1) FROM
2216 ;(PHYSICAL) BUS ADDRESSES 177000
2217 ;(177000 TO 200776)
2218 006612 004737 020204 JSR PC, CHNMEX
2219 ;CHECK THAT RKBA OVERFLOWED INTO
2220 ;EXTENDED MEM, BIT (0) OF RKCS (BIT 4)
2221 ;EX MEM BIT 0 SET?
2222 ;GET RKCS, ER, DB, DA
2223 006616 104106 ERROR 106 ;MEX BITS INCORRECT, BIT 4 OF RKCS
2224 ;(MEX BIT 0) SHOULD HAVE SET
    
```

```

2225
2226
2227
2228 006A20 012703 001000      MOV    #1000,R3
2229 006A24 012704 177000      MOV    #177000,R4
2230 006A30 004737 020150      JSR    PC,CHKBA
2231 006A34 104104      ERROR 104
2232
2233
2234
2235 006A36 013702 001502      MOV    QDRV,R2
2236 006A42 002702 000002      ADD    #2,R2
2237 006A46 004737 020126      JSR    PC,CHKDA
2238 006A52 104103      ERROR 103
2239
2240
2241
2242
2243 006A54 004737 020230      JSR    PC,CHKWC
2244 006A60 104105      ERROR 105
2245
2246
2247
2248
2249
2250
2251
2252 006662 012737 006670 001110      MOV    #48,LPERR
2253 006670 104416      48: CON,RESET
2254 006672 104420      DRV,RESET
2255
2256 006674 012701 137000      MOV    #137000,R1
2257 006700 005021      58: CLR    (R1)+
2258 006702 020127 141000      CMP    R1,#141000
2259 006706 001374      BNE   58
2260
2261
2262
2263
2264
2265 006710 013777 001502 172312      MOV    QDRV,0RKDA
2266 006716 012777 177000 172300      MOV    #-1000,0RKWC
2267 006724 012777 177000 172274      MOV    #177000,0RKBA
2268 006732 012777 000005 172262      MOV    #5,0RKCS
2269
2270 006740 104417      CON,RDY
2271
2272 006742 004737 020112      JSR    PC,CHKCS
2273 006746 104102      ERROR 102
2274
2275
2276
2277
2278
2279
2280

```

;AFTER RKBA OVERFLOWED ON DOING  
;A TRANSFER OF 2 SECTORS FROM BUS  
;ADDRESS (PHYSICAL) STARTING AT 177000  
;WORD COUNT  
;STARTING BUS ADDRESS  
;CHECK IF RKBA INCREMENTED CORRECTLY  
;RKBA DID NOT INCREMENT CORRECTLY  
;AFTER WRITE IF 2 SECTORS FROM A DATA  
;BUFFER STARTING AT (PHYSICAL) BUS  
;ADDRESS (177000=200776)  
;GET EXPECTED  
;DISK ADDRESS  
;CHECK IF RKDA INCREMENTED CORRECTLY  
;RKDA INCREMENTED WRONG AFTER  
;A WRITE OF 2 SECTOR (0,1) FROM  
;DATA BUFFER STARTING AT BUS  
;ADDRESS (PHYSICAL) 177000.  
;CHECK IF RKWC OVERFLOWED CORRECTLY  
;RKWC DID NOT OVERFLOW TO 0 ON  
;DOING A WRITE OF 2 SECTORS FROM  
;BA = 177000  
;NOW, READ IS DONE OF THE DATA  
;THAT WAS WRITTEN TO SEE IF IT  
;CAN BE READ CORRECTLY  
;LUP TO 48 ON EROR (8W 9)  
;CLEAR THE 1000-WORD DATA  
;BUFFER (PA 177000 TO 200776)  
;ALL DONE?  
;NOW, READ BACK INTO THE  
;SAME BUFFER 2 SECTORS  
;WRITTEN PREVIOUSLY  
;ADDRESS THE DRIVE CYL 0, SEC 0, 0  
;READ 2 SECTORS  
;INTO THIS BUS ADDRESS  
;READ, GO  
;WAIT FOR CONTROL RDY  
;ANY ERROR IN RKCS?  
;ERROR BIT SET IN RKCS ON DOING  
;A READ OF 2 SECTORS (0,1), CYL 0,  
;SUR 0, INTO DATA BUFFER STARTING  
;AT BUS ADDRESS 177000, NOTE AFTER  
;177776, RKBA WILL OVERFLOW (0)  
;INTO MEX BITS (BIT 4) OF RKCS,  
;IF THE ENTIRE TRANSFER (1000 WORD)  
;WAS DONE RKBA WILL CONTAIN 1000

```

2281
2282
2283 006750 012705 177764      68: MOV    #-14,R5
2284 006754 012702 137000      MOV    #137000,R2
2285
2286 006760 012701 000001      MOV    #1,R1
2287
2288 006764 020112      78: CMP    R1,(R2)
2289 006766 001414      BEQ   88
2290 006770 005705      TST   R5
2291 006772 001420      BEQ   98
2292 006774 005205      INC   R5
2293
2294 006776 010137 001162      MOV    R1,0REG0
2295
2296 007A02 011237 001164      MOV    (R2),0REG1
2297 007A06 104107      ERROR 107
2298
2299
2300
2301
2302 007A10 104421 002214      TYPMSG ,MSG13
2303 007A14 004737 017774      JSR    PC,TYPDBO
2304
2305
2306 007A20 062702 000002      88: ADD    #2,R2
2307 007A24 005201      INC   R1
2308 007A26 022701 001001      CMP    #1001,R1
2309 007A32 001354      BNE   78
2310
2311
2312 007A34 005037 177572      98: CLR    #0SRO

```

;AND BIT 4 OF RKCS (MEX) WILL BE SET.  
;REPORT ONLY 12 ERRORS.  
;STARTING ADDRESS OF BUFFER  
;(PA=177000)  
;INITIALIZE DATA PATTERN  
;CORRECT DATA WORD RECDV?  
;REPORT THIS ERROR?  
;COUNT ERRORS  
;GET EXPECTED DATA WORD  
;GET DATA WORD RECDV  
;DATA COMPARISON ERROR ON DOING A  
;READ OF 2 SECTORS (0,1), CYL 0, SURFACE 0)  
;INTO DATA BUFFER (PHYSICAL ADDRESS  
;177000 TO 200776)  
;TYPE 'PHYSICAL BUS ADDRESS'  
;TYPE THE 6 DIGIT PHYSICAL BUS ADDRESS  
;WHERE THE DATA ERROR OCCURRED.  
;INCREMENT POINTER TO BA  
;CHECKED THE ENTIRE BUFFER?  
;\*\*\*OFF  
;TURN OFF MEMORY MANAGEMENT

```

2313 ;*****
2314 ;TEST 6 CHECK DATA TRANSFER FROM 28K TO 32K
2315 ;THIS TEST DOES A WRITE OF 4K WORDS FROM A BUFFER LOCATED AT 28K
2316 ;THEN THE DATA IS READ BACK INTO THE SAME BUFFER(28K-32K) AND IS
2317 ;CHECKED TO SEE IF IT IS CORRECT, NOTE THAT THE BUFFER IS FILLED
2318 ;WITH ALL 1'S BEFORE DOING THE READ,
2319
2320 ;THE WRITE IS DONE STARTING AT CYLINDER 0, SECTOR 0, SURFACE 0,
2321 ;*****
2322 007A40 000004 TST6: SCOPE
2323
2324 007A42 023727 017772 001740 CMP 0LSTBK,01740 ;32K OR MORE OF MEMORY?
2325 007A50 103002 BHS 10 ;YES
2326 007A52 000137 007374 JMP TST7 ;IF NOT, DONT DO THIS TEST
2327 007A56 012737 001600 172352 10: MOV 01600,0SKIPARS ;MAP 28-32K THRU PAR 5
2328 007A64 012737 000001 177572 MOV 01,00BRO ;TURN ON MEM MANAGEMENT
2329
2330 ;WRITE A COUNT PATTERN (1=10000) INTO DATA BUFFER (PHYSICAL ADDRESS
2331 ;160000=177776). THIS DATA BUFFER WILL BE USED FOR WRITING ON THE DISK,
2332
2333 007A72 012737 007100 001110 MOV 028,0LPERR ;LUP TO 28 ON ERROR
2334 007100 104416 CON,RESET
2335 007102 104420 DRV,RESET
2336 007104 012700 000001 MOV 01,R0 ;INITIALIZE DATA PATTERN TO BE WRITTEN
2337 007110 012701 120000 MOV 0120000,R1 ;INITIALIZE BA (PAR160000) 28K
2338 007114 010021 30: RO,(R1)+ ;WRITE COUNT PATTERNS (1=10000)
2339 007116 005200 INC RO ;INTO DATA BUFFER (PA 160000 TO
2340 007120 020027 010001 CMP RO,010001 ;177776, 28K=32K)
2341 007124 001373 BNE 30
2342
2343 007126 013777 001502 172074 MOV 0DRV,0RKDA ;WRITE ON SEC 0, CYL 0, SUR1
2344 007134 012777 170000 172062 MOV 0=10000,0RKWC ;4K WORDS
2345 007142 012777 160000 172056 MOV 0160000,0RKBA ;FROM THIS BUS ADDRESS
2346 007150 012777 000003 172044 MOV 03,0RKCS ;WRITE, GO
2347
2348 007156 104417 CON,RDY ;WAIT FOR CONTROL READY
2349
2350 007160 004737 020112 JSR PC,CHKCS ;ANY ERROR IN RKCS?
2351 007164 104102 ERROR 102 ;'ERR' BIT SET IN RKCS ON DOING
2352 ;A WRITE OF 4K WORDS FROM 160000
2353 ;(28K-32K), DISK WRITE BEGAN ON
2354 ;SEC 0, CYL 0, SUR 0, IF ALL 4K
2355 ;WORDS WERE WRITTEN RKBA SHOULD OVERFLOW
2356 ;AND CONTAIN 0, BIT 4 OF RKCS
2357 ;(MEX BIT) SHOULD BE 1
2358
2359 007166 004737 020204 JSR PC,CHKMEX ;CHECK IF RKBA OVERFLOWED AND MEX
2360 ;BITS (4) IN RKCS WAS SET,
2361 007172 104106 ERROR 106 ;MEX BIT 4 NOT SET AFTER OVERFLOW OF
2362 ;RKBA. WRITE OF 4K WORDS (28K-32K) WAS DONE.
2363
2364 ;RETURN HERE IF NO ERROR
2365 007174 012703 010000 MOV 010000,R3 ;WORD COUNT
2366 007200 012704 160000 MOV 0160000,R4 ;STARTING BUS ADDRESS
2367 007204 004737 020150 JSR PC,CHKBA ;CHECK IF RKBA INCREMENTED CORRECTLY
2368 007210 104104 ERROR 104 ;RKBA DID NOT OVERFLOW TO AFTER A WRITE IF 4K

```

```

2369 ;WORDS (160000 TO 177776)
2370
2371 007212 004737 020230 JSR PC,CHKWC ;CHECK RKWC OVERFLOWED CORRECTLY
2372 007216 104109 ERROR 106 ;RKWC DID NOT OVEFLOW TO 0
2373 ;AFTER A WRITE OF 4K WORD (160000
2374 ;TO 177776)
2375
2376 ;RETURN ADDRESS FOR LUPING
2377 007220 012737 007226 001110 40: MOV 046,0LPERR
2378 007226 104416 CON,RESET
2379 007230 104420 DRV,RESET
2380
2381 007232 012701 120000 50: MOV 0120000,R1 ;CLEAR THE DATA BUFFER BEFORE
2382 007236 005021 CLR (R1)+ ;DOING A READ INTO IT
2383 007240 022701 140000 CMP 0140000,R1
2384 007244 001374 BNE 50
2385
2386 007246 013777 001502 171754 MOV 0DRV,0RKDA ;READ FROM SEC 0, SUR 0, CYL 0
2387 007254 012777 170000 171742 MOV 0=10000,0RKWC ;4K WORDS
2388 007262 012777 160000 171736 MOV 0160000,0RKBA ;INTO THIS BUS ADDRESS
2389
2390 007270 012777 000005 171724 MOV 05,0RKCS ;READ, GO
2391 007276 104417 CON,RDY ;WAIT FOR CTRL RDY
2392
2393 007300 004737 020112 JSR PC,CHKCS ;ANY ERROR IN RKCS?
2394 007304 104102 ERROR 102 ;ERROR BIT SET IN RKCS ON DOING
2395 ;A READ OF 4K WORDS INTO MEMORY
2396 ;(160000-177776)
2397 007306 012705 177764 MOV 0=14,R6 ;REPORT 12 ERRORS AT MOST
2398 007312 012702 120000 MOV 0120000,R2 ;STARTING ADDRESS OF BUFFER
2399 ;(PAR160000)
2400 007316 012701 000001 MOV 01,R1 ;INITIALIZE DATA PATTERN
2401
2402 007322 020112 60: CMP R1,(R2) ;CORRECT DATA WORD?
2403 007324 001413 BEQ 70
2404 007326 010137 001162 MOV R1,0REG0 ;GET EXPTD DATA WORD
2405 007332 011237 001164 MOV (R2),0REG1 ;GET DATA WORD RECD
2406 007336 104107 ERROR 107 ;DATA ERROR ON DOING A READ OF
2407 ;4K WORDS STARTING FROM SEC 0,
2408 ;CYL 0, SUR 0 INTO MEMORY (160000=
2409 ;177776)
2410 007340 104421 022214 TYPMSG ,MSG13 ;TYPE "PHYSICAL BUS ADDRESS"
2411 007344 004737 017774 JSR PC,TYPDSC ;TYPE OUT THE PHYSICAL BUS ADDRESS
2412 ;WHERE DATA
2413 007350 005205 INC R6 ;ERROR OCCURRED, R2 CONTAINS
2414 007352 001406 BEQ 60 ;THE VIRTUAL ADDRESS
2415
2416 007354 062702 000002 70: ADD 02,R2 ;POINTER TO NEXT BA
2417 007360 005201 INC R1 ;NEXT PATTERN
2418 007362 022701 001000 CMP 01000,R1 ;ALL DONE?
2419 007366 001355 BNE 60 ;NO
2420
2421 007370 005037 177572 80: CLR 00BRO ;TURN OFF MEM MANAGEMENT

```

```
2422 ;*****  
2423 ;*TEST 7 PFRFORM THE LARGEST POSSIBLE DATA TRANSFER  
2424 ;THIS TEST PERFORMS THE LARGEST DATA TRANSFER POSSIBLE  
2425 ;WITHIN AVAILABLE MEMORY.  
2426  
2427 ;1) IF KT11 IS PRESENT A WRITE OF 16K WORDS IS DONE ON  
2428 ;THE DISK (PROVIDED 28K OR MORE IS PRESENT).  
2429  
2430 ;2) IF KT11 IS NOT PRESENT THEN ALL BUT TOP 1.5K OF MEMORY WILL BE USED  
2431 ;FOR WRITING (RKDP MONITOR).  
2432  
2433 ;ALL DATA TRANSFERS ARE DONE STARTING AT BA 'PGEND'.  
2434 ;ALL WRITES ARE DONE BEGINNING AT SECTOR 0, CYLINDER 0,  
2435 ;SURFACE 0.  
2436  
2437 ;AFTER DOING THE 'WRITE' A 'WRITE CHECK' IS DONE  
2438 ;TO SEE IF THE WRITE WAS DONE CORRECTLY. ANY WRITE  
2439 ;CHECK ERROR IS REPORTED.  
2440 ;*****  
2441 TST7: SCOPE  
2442 TST 8KT11 ;MEMORY MANAGEMENT PRESENT?  
2443 BPL 16 ;NO  
2444 ;YES  
2445 007404 023727 017772 001840 CMP 8L8TBK,81540 ;28K OR MORE?  
2446 007412 020234 BGE XFR16K ;YES  
2447  
2448 007414 013703 002054 18: MOV MAXBA,R3 ;FIGURE OUT THE MAXIMUM  
2449 007420 162703 032514 SUB 8PGEND,R3 ;XFER THAT CAN BE DONE  
2450 007424 000241 CLC ;  
2451 007426 006003 ROR R3 ;FROM 'PGEND' TO THE  
2452 ;'MAXBA'  
2453 007430 005001 CLR R1 ;  
2454 007432 010346 MOV R3,=(8P) ;PUT DIVIDEND ON STACK (LO)  
2455 007434 005046 CLR 8(8P) ;(HIGH PART)  
2456 007436 012746 MOV 8400,8(8P) ;DIVISOR  
2457 007442 004737 025212 JSR PC,88DIY ;GO TO DIVIDE ROUTINE  
2458 007446 005726 TST 8(8P)+ ;POP OFF REMAINDER FROM STACK  
2459 007450 001401 BEQ 28 ;  
2460 007452 005201 INC R1 ;GET # OF SECTORS REQUIRED TO  
2461 ;DO WRITE OF # OF WORDS  
2462 007454 062601 28: ADD 8(8P)+,R1 ;(CONTAINED IN R0). R1 CONTAINS  
2463 ;# OF SECTORS  
2464 007456 005002 CLR R2 ;FORM THE EXPECTED DISK  
2465 007460 162701 000014 38: SUB 814,R1 ;ADDRESS = AFTER THE WRITE  
2466 007464 100403 BMI 46 ;IS DONE.  
2467 007466 062702 000020 ADD 820,R2  
2468 007472 000772 BR 38 ;  
2469 007474 062701 000014 48: ADD 814,R1 ;R2 CONTAINS EXPCD RKDA  
2470 007500 050102 BIS R1,R2 ;AFTER WRITE IS DONE  
2471 007502 000404 BR XFR16K ;  
2472  
2473 007504 012703 040000 XFR16K: MOV 840000,R3 ;# OF WORDS = 16K  
2474 007510 012702 000124 MOV 8124,R2 ;RKDA SHOULD INCREMENT TO  
2475 ;THIS AFTER A TRANSFER OF 16K  
2476 ;WORDS STARTING AT DISK  
2477 ;ADDRESS = 0 (CYL 2,SUR 1,SEC 4)
```

```
2478  
2479 007514 053702 001502 XFR: BIS QDRV,R2 ;ADD THE DRIVE # TO  
2480 ;EXPCD RKDA AFTER XFER  
2481 007520 012737 007526 001110 MOV #18,8LPERR ;LUP BAK TO '18' ON ERROR  
2482 ;(SW 9)  
2483 007526 104416 18: CON,RESET  
2484 007530 104420 DRV,RESET  
2485 007532 013777 001502 171470 MOV QDRV,8RKDA ;ADDRESS THE DRIVE, CYL 0,SUR 0,  
2486 ;SEC 0  
2487 007540 010377 171460 MOV R3,8RKWC ;  
2488 007544 005477 171454 NEG 8RKWC ;WORD COUNT (IF MORE THAN  
2489 ;28K IS AVAILABLE A TRANSFER  
2490 ;OF 20K WILL BE DONE, IF  
2491 ;LESS THAN 28K, THE  
2492 ;LARGEST TRANSFER WITHIN THE  
2493 ;AVAILABLE MEMORY WILL  
2494 ;BE DONE, IN BOTH  
2495 ;CASES, DATA TRANSFER  
2496 ;WILL BE DONE STARTING  
2497 ;AT 'PGEND'  
2498 007550 012777 032514 171450 MOV 8PGEND,8RKBA ;START WRITE FROM HERE  
2499 007556 012777 000003 171436 MOV 83,8RKCS ;WRITE, GO  
2500  
2501 007564 104417 CON,RDY ;WAIT FOR CONTROL READY  
2502  
2503 007566 004737 020112 JSR PC,CHKCS ;CHKCK RKCS FOR ERROR?  
2504 007572 104102 ERROR 102 ;ERROR BIT SET IN RKCS ON  
2505 ;DOING A LARGE 'WRITE'  
2506  
2507 007574 004737 020126 JSR PC,CHKDA ;CHECK IF RKDA INCREMENTED CORRECTLY?  
2508 007900 104103 ERROR 103 ;RKDA DID NOT INCREMENT  
2509 ;CORRECTLY  
2510  
2511 007602 012704 032514 MOV 8PGEND,R4 ;CHECK THAT RKBA INCREMENTED  
2512 007606 004737 020150 JSR PC,CHKBA ;CORRECTLY?  
2513 ;RKBA DID NOT INCREMENT  
2514 ;CORRECTLY  
2515  
2516 2517 007614 004737 020230 JSR PC,CHKWC ;CHECK THAT RKWC OVERFLOWED  
2518 007620 104105 ERROR 105 ;RKWC DID NOT OVERFLOW TO  
2519 ;ZERO AFTER A WRITE  
2520  
2521 007622 012737 007630 001110 28: MOV #28,8LPERR ;LUP BAK TO '28' ON EROR (SW 9)  
2522 007630 104416 CON,RESET  
2523 007632 104420 DRV,RESET  
2524 007634 013777 001502 171366 38: MOV QDRV,8RKDA ;ADDRESS THE DRIVE, CYL 0,SEC 0,SUR 0  
2525 007642 010377 171356 MOV R3,8RKWC ;  
2526 007646 005477 171382 NEG 8RKWC ;  
2527 007652 012777 032514 171346 MOV 8PGEND,8RKBA ;STARTING BA  
2528  
2529 007660 012777 000407 171334 48: MOV 8407,8RKCS ;WRITE CHECK, 88E, GO  
2530  
2531 007666 104417 CON,RDY ;WAIT FOR CONTROL RDY  
2532  
2533 007670 004737 020112 JSR PC,CHKCS ;ANY ERROR IN RKCS
```

```

2534 007674 104102          ERROR 102
2535
2536 007676 032777 040000 171316      BIT  #BIT14,0RKCS  ;SKIP CHECKING FOR WCE IF HE SET
2537 007704 001030          BNE  76
2538 007706 032777 000001 171304 58:  BIT  #WCE,0RKER  ;WRITE CHECK ERROR?
2539 007714 001406          BEQ  68             ;NO
2540
2541 007716 004737 022032          JSR  PC,GT4RG     ;GET RKCS,ER,DS,DA
2542 007722 017737 171300 001166      MOV  #RKBA,0REG2
2543 007730 106110          ERROR 110
2544
2545
2546
2547
2548
2549
2550
2551 007732 008777 171366          68:  TST  0RKWC
2552 007736 001413          BEQ  78             ;WAS THE ENTIRE DATA BUFFER
2553
2554 007740 017708 171360          MOV  0RKWC,R6
2555 007744 042708 177760          BIC  #177760,R6   ;FORM THE RKBA AND RKWC
2556 007750 006305          ASL  R6
2557 007752 160577 171250          SUB  R6,0RKBA
2558
2559 007756 042777 000017 171240      BIC  #17,0RKWC
2560
2561 007764 000738          BR   48             ;GO DO WRT=CHK FOR
2562
2563
2564
2565
2566 007766 000137 008366          78:  JMP  NXTDRV
    ;GO CHECK THE REST OF THE DRIVES,
    ;WRITE CHECKED?
    ;CHECKED IS NOT ON A SECTOR BOUNDARY
    ;(LIKE 256, 512 WORD ETC.), BUT IS SOME
    ;SECTORS & A FRACTION (LIKE 300 WORDS ETC.)
    ;WHERE WCE OCCURRED. (NOTE THE SECTOR IN
    ;ERROR IS OBTAINED BY BACKING OFF 1 SECTOR),
    ;NOTE THAT THE DATA BUFFER WHICH WAS WRITE
    ;TO BE USED FOR DOING
    ;WRITE-CHECK IF THE REST
    ;OF THE DATA BUFFER
    ;REST OF THE BUFFER
    
```

```

2567
2568
2569
2570
2571
2572
2573
2574 007772 104416          EXRCR: CON,RESET
2575 007774 012700 001306          MOV  #KEY,R0
2576 010000 005020          18:  CLR  (R0)+
2577 010002 020027 001552          CMP  R0,#KWHR
2578 010006 001374          BNE  18
2579 010010 105737 001253          TSTB FRSTRT
2580 010014 001045          BNE  38             ;RESTARTED AT 210?
2581
2582
2583 010016 005020          28:  CLR  (R0)+
2584 010020 020027 002032          CMP  R0,#PCMDND
2585 010024 001374          BNE  28             ;CLEAR LOCATIONS FROM 'HECH'
2586
2587 010026 012700 001554          MOV  #KWHIN,R0
2588 010032 012701 177704          MOV  #60,R1
2589 010036 010120          MOV  R1,(R0)+
2590 010040 010120          MOV  R1,(R0)+
2591 010042 010120          MOV  R1,(R0)+
2592
2593 010044 012700 025730          MOV  #RSDRYL,R0
2594 010050 012720 123456          MOV  #123456,(R0)+
2595 010054 012720 176543          MOV  #176543,(R0)+
2596 010060 012720 001201          MOV  #1201,(R0)+
2597 010064 012720 062465          MOV  #62465,(R0)+
2598 010070 012720 176105          MOV  #176105,(R0)+
2599 010074 012720 174532          MOV  #174532,(R0)+
2600 010100 012720 187650          MOV  #187650,(R0)+
2601 010104 012720 030783          MOV  #30783,(R0)+
2602 010110 012720 131547          MOV  #131547,(R0)+
2603 010114 012720 032070          MOV  #32070,(R0)+
2604 010120 012720 123456          MOV  #123456,(R0)+
2605 010124 012720 176543          MOV  #176543,(R0)+
2606
2607
2608 010130 003227 177777          38:  INC  #-1
2609 010134 001004          BNE  48
2610 010136 012737 000062 002056      MOV  #60,REPCNT
2611
2612 010144 000403          BR   58             ;FIRST PASS?
2613
2614
2615
2616
2617
2618 010154 004737 022656          58:  JSR  PC,CHOPRS
2619
2620
2621
2622
    ;BEGINNING OF THE EXERCISER PART OF THE PROGRAM.
    ;IF THE PROGRAM WAS RESTARTED AT 210, THEN THE STATISTICS COLLECTED
    ;SO FAR WILL NOT BE CLEARED.
    ;CLEAR UP THE LOCATIONS FROM
    ;'KEY' TO 'KWHR' (EXCLUDED)
    ;RESTARTED AT 210?
    ;YES, SAVE THE STATISTICS COLLECTED
    ;UNTILL NOW, DONT CLEAR THEM
    ;CLEAR LOCATIONS FROM 'HECH'
    ;TO 'PCMDND' (EXCLUDED)
    ;INITIALIZE COUNTS FOR MINS,
    ;SECS, KWII
    ;INITIALIZE PTR TO RANDOM NO, SEEDS
    ;USED BY THE RANDOM NUMBER GENERATOR
    ;SET UP RANDOM NUMBER SEEDS TO BE
    ;REPETITION COUNT, WHEN THIS COUNT GOES
    ;TO 0, IT'S CONSIDERED TO BE AN END OF PASS,
    ;THE NEXT PASS WILL START WILL START RIGHT
    ;FROM WHERE THE EXERCISER LEFT OFF,
    ;CHECK IF ANY DRIVES ARE PRESENT
    ;IF NONE, GO TO $EOP, END OF PASS
    
```

```

2623
2624 010160 012746 177777      MOV    $177777,=(BP)  ;PUT LOW DIVIDEND ON STACK
2625 010164 008046              CLR    =(BP)         ;CLEAR HIGH DIVIDEND AND PUSH
2626                                ;IT ON STACK
2627 010166 013746 001264      MOV    DRVPRS,=(BP)  ;PUSH DIVISOR ON STACK
2628 010172 004737 025212      JSR   PC,@@@DIV     ;GO TO THE 'DIVIDE' SUBROUTINE
2629 010176 008726              TBT   (BP)+         ;DISCARD THE REMAINDER, QUOTIENT IS
2630                                ;NOW ON TOP OF THE STACK
2631 010900 012637 001520      MOV    (BP)+,DRMAP   ;GET MAPPING FACTOR FOR DRIVES
2632 010904 012737 000804 001522  MOV    $804,CYLMAP   ;GET MAPPING FACTOR FOR CYLINDERS
2633 010912 012737 012527 001524  MOV    $8463,$ECMAP  ;GET MAPPING FACTOR FOR SECTORS
2634 010920 012737 031463 001526  MOV    $13107,$FNMAP ;GET MAPPING FACTOR FOR FUNCTION
2635
2636 010926 013700 002054      MOV    MAXBA,R0     ;COMPUTE THE MAXIMUM ALLOWABLE
2637 010932 163700 002052      SUB   BASEBA,R0     ;WORD COUNT FOR DATA TRANSFERS
2638 010936 000241              CLC
2639 010940 006000              ROR   R0             ;CONVERT TO WORDS
2640
2641 010942 012746 177777      MOV    $177777,=(BP) ;PUT LOW DIVIDEND ON STACK
2642 010946 008046              CLR    =(BP)         ;CLEAR HIGH DIVIDEND AND PUSH
2643                                ;IT ON STACK
2644 010950 010046              MOV    R0,=(BP)     ;PUSH DIVISOR ON STACK
2645 010952 004737 025212      JSR   PC,@@@DIV     ;GO TO THE 'DIVIDE' SUBROUTINE
2646 010956 008726              TBT   (BP)+         ;DISCARD THE REMAINDER, QUOTIENT IS
2647                                ;NOW ON TOP OF THE STACK
2648 010960 005216              INC   (BP)          ;SAVE THE MAPPING FACTOR FOR BUS ADDRESS
2649 010962 012637 001530      MOV    (BP)+,BAMAP
  
```

```

2650                                ;THE ENTIRE DISK (ALL DRIVES) IS WRITTEN WITH RANDOM PATTERNS. THE FIRST
2651                                ;WORD OF EACH SECTOR GIVES THE NUMBER OF WORDS (2'S COMPLEMENT) WRITTEN IN
2652                                ;THAT SECTORS. REST OF THE DATA WORDS FOR THE SECTOR ARE GENERATED USING
2653                                ;THE ABSOLUTE DISK ADDRESS AS THE RANDOM SEED.
2654                                ;IF THE PROGRAM WAS RESTARTED AT 210 THEN CHECK IF SW 4 IS SET. IF IT IS
2655                                ;THEN DO NOT REWRITE THE DISK WITH RANDOM PATTERNS, IF SW 4 IS NOT SET THEN
2656                                ;ALL THE DISKS (PRESENT) ARE WRITTEN WITH RANDOM PATTERNS.
2657
2658 010966 105737 001253      WRDSK: TSTB  FRSTRT   ;RESTARTED AT 210?
2659 010972 001407              BEQ   1$           ;NO
2660 010974 105037 001253      CLRB  FRSTRT   ;YES, CLEAR THE RESTART FLAG
2661 010980 032777 000020 170632  BIT   $SW4,$SWR   ;SW 4 SET?
2662 010986 001401              BEQ   1$           ;NO
2663 010990 000540              BR    BEGEX1     ;YES, DONT REWRITE ALL DISKS WITH
2664                                ;RANDOM PATTERNS
2665 010992 012737 010330 001110 18:  MOV   $28,$LPERR  ;LUP TO '28' ON EROR, SW 9 SET!
2666 010996 012702 001254      MOV   $PDR,R2     ;POINTER TO DRIVE #'S TABLE
2667 010998 013703 001264      MOV   DRVPRS,R3   ;# OF DRIVES PRESENT
2668 010999 012700 011410      MOV   $4872,,R0   ;NUMBER OF SECTORS PER DISK
2669 010999 012201 001502      MOVB  (R2)+,R1    ;GET THE FIRST AVAILABLE DRIVE
2670 010999 042701 177770      BIC   $177770,R1 ;POSITION THE BITS (15,14,13)
2671 010999 010137 001502      MOV   R1,GDRV
2672 010999 000241              CLC
2673 010999 006001              ROR   R1
2674 010999 006001              ROR   R1
2675 010999 006001              ROR   R1
2676 010999 006001              ROR   R1
2677 010999 010177 170644      MOV   R1,$RKDA   ;BASE DISK ADDRESS
2678
2679 010999 013704 002054      MOV   MAXBA,R4   ;CALCULATE MAXIMUM BUFFER
2680 010999 163704 002052      SUB   BASEBA,R4
2681 010999 006204              ASR   R4
2682 010999 042704 000377      BIC   $377,R4    ;CONVERT TO WORDS
2683 010999 000304              SWAB  R4         ;KEEP ONLY WHOLE BLOCKS
2684 010999 020427 000014      CMP   R4,$12    ;MAX OF 12 SECTORS
2685 010999 003402              BLE   3$
2686 010999 012704 000014      MOV   $12,,R4
2687
2688 010999 010401              38:  MOV   R4,R1
2689 010999 020400              CMP   R4,R0
2690 010999 003401              BLE   4$
2691 010999 010001              MOV   R0,R1
2692 010999 000301              40:  SWAB  R1
2693 010999 005401              NEG   R1
2694 010999 010137 010446      MOV   R1,$$
2695 010999 010177 170562      MOV   R1,$RKWC
2696
2696 010442 004537 016704      JSR   R5,GENBUF   ;GENERATE RANDOM DATA BUFR
2697 010446 000000              .WORD 0
2698 010450 032514              .WORD DBUF        ;STARTING ADDRESS OF DATA BUFR
2699
2700 010452 012777 032514 170546  MOV   $DBUF,$RKBA ;FROM THIS BUS ADDRESS
2701 010460 012777 000003 170534  MOV   $3,$RKCS   ;WRITE, GO
2702
2703 010466 104417              CON,RDY          ;WAIT FOR CONTROL RDY
2704 010470 004737 020112      JSR   PC,CHKCS   ;ANY ERROR?
2705 010474 104001              ERROR 1          ;AN ERROR OCCURED WHILE DOING WRITE
  
```

```

2706 ;ON THE DISK, YOU ARE ADVISED TO USE
2707 ;BASIC AND DYNAMIC TESTS.
2708
2709 010476 032777 000400 170434 BIT #BITS,#SWR ;TYPE CURRENT STATUS
2710 010404 001435 BEQ 66
2711 010406 032700 000377 BIT #377,RO
2712 010412 001032 BNE 66
2713 010414 104401 010922 TYPE ,650 ;;TYPE ASCII STRING
2714 010420 000421 BR 640 ;;GET OVER THE ASCII
;1650: ;ASCII <15><12>/WRITTING RANDOM PATTERN, DRIVE /
640:
2715 010464 MOV GDRV,=(SP)
2716 010470 104403 TYP08
2717 010472 001 ,BYTE 1
2718 010473 000 ,BYTE 0
2719
2720 010474 104401 001313 60: TYPE ,@CRLF
2721 010400 104407 CKSWR ;CHECK FOR SOFTWARE SWR CHANGE
2722 010402 160400 SUB R4,RO ;DECREMENT SECTOR COUNT
2723 010604 003304 BGT 36
2724
2725 010606 008303 DEC R3 ;MORE DRIVES TO DO?
2726 010610 001247 BNE 26
2727
2728 ;IF SW 3 IS SET, ENABLE THE LINE CLOCK AND INITIALIZE COUNTS.
2729
2730
2731 010412 032777 000010 170320 BEGNEX: BIT #SW3,#SWR ;KNILL CLOCK PRESENT?
2732 010420 001403 BEQ BEGNEX ;IF NOT, SKIP. NOTE:IF KNILL IS
;NOT PRESENT SW3 SHOULD NOT BE SET
;OTHERWISE, A TIMEOUT WILL OCCUR,
;ENABLE KNILL CLOCK
;SERVICED AT PRIORITY 7 (KNBRVE)
2733
2734
2735 010622 052777 000100 170404 BIS #BITS,@KWL6
2736
2737

```

```

2738 ;THE PROGRAM IS GOING TO LOOP BACK TO THIS POINT AT THE END OF A PASS.
2739
2740 010630 104416 BEGNEX: CON,RESET ;CLEAR EVERYTHING IN DRIVES
2741 010632 012706 001100 MOV #STACK,SP ;RESET STACK
2742 010636 005737 001264 TST DRVPRB ;ANY DRIVES LEFT IN SYSTEM?
2743 010642 001402 BEQ OMNGER
2744 010644 004737 014500 JBR PC,GENSRQ ;GO GENERATE @ COMMANDS FOR THE @
2745
2746
2747 ;CHECK IF THERE IS ANY UNFINISHED COMMAND IN THE @, WAITING TO BE EXECUTED.
2748 ;IF THERE IS NONE, GO TO THE 'GENSRQ' AND GENERATE @ REQUESTS (COMMANDS),
2749 ;AND PUT THEM IN THE @. IF THERE IS AN UNFINISHED COMMAND, FIND OUT IF
2750 ;THERE IS A PRIORITY COMMAND TO BE EXECUTED IMMEDIATELY.
2751
2752
2753 010650 013746 001244 OMNGER: MOV PPRVL,=(SP) ;NEW P@W , RAISE PRIORITY
2754 010654 012746 001062 MOV #16,=(SP) ;RETURN PC *****
2755 010660 000002 RTI
2756
2757 010662 005737 001264 10: TST DRVPRB ;ANY DRIVES IN SYSTEM?
2758 010666 001040 BNE 26
2759 010670 104401 010676 TYPE ,650 ;;TYPE ASCII STRING
2760 010674 000432 BR 640 ;;GET OVER THE ASCII
;1650: ;ASCII <15><12>/HALTING = PRESS CONTINUE TO RESTART AT '200'/'<15><12><12><12>
640:
2761
2762 010762 HALT
2763 010762 000000 JMP @START
2764 010764 000137 003376
2765
2766 010770 012700 001306 20: MOV #KEY,RO
2767 010774 005720 TST (RO)+ ;ANY UNFINISHED COMMAND
2768 010776 100006 BPL 48 ;IN @
2769 011000 020027 001326 CMP RO,#KEY+20
2770 011004 001373 BNE 36
2771 011006 004737 014500 JBR PC,GENSRQ ;IF NOT, GO GENERATE @ MORE COMMANDS
2772 011012 000450 BR CHFAFH
2773
2774
2775 011014 012700 001306 48: MOV #KEY,RO
2776 011020 032710 010000 50: BIT #BIT12,(RO) ;ANY HIGH PRIORITY COMMAND IN @
2777 011024 001404 BEQ 66
2778 011026 008710 TST (RO) ;FINISHED?
2779 011030 100402 BMI 66 ;YES
2780 011032 108710 TSTB (RO) ;IN EXECUTION?
2781 011034 100169 BPL PRICMND ;NO, GO PROCESS HIGH PRIORITY
2782
2783 011036 005720 60: TST (RO)+ ;CHECK THE ENTIRE @
2784
2785 011040 020027 001326 CMP RO,#KEY+20
2786 011044 001365 BNE 66
2787
2788 ;FIND OUT IF THERE IS A WRITE CHECK FUNCTION TO BE DONE IMMEDIATELY AFTER
2789 ;A WRITE, THAT WAS DONE PREVIOUSLY.
2790
2791 011046 005737 001456 TST WCFLG ;IS WRITE CHECK TO FOLLOW
2792 011052 100040 BPL CHFAFH ;WRITE? IF NOT, BRANCH
2793 ;YES

```



```

2794 011154 013700 001456      MOV      WCFLG,RO      ;GET WC FLAG
2795 011160 042700 177400      BIC      #177400,RO    ;LOWER BYTE CONTAINS KEY#X2 (OFFSET FROM
2796                                     ;KEY), OF THE WRITE FUNCTION
2797 011164 016001 002032      MOV      PCMND(RO),R1 ;GET POINTER
2798 011170 062700 001306      ADD      #KEY,RO      ;FROM ADDRESS OF THE KEY
2799                                     ;WHICH WAS USED FOR PREVIOUS
2800                                     ;WRITE
2801 011174 022761 000002 000002  CMP      #2,2(R1)     ;CHECK THAT THE FUNCTION
2802 011102 001413                                     BEQ      78           ;WAS A WRITE
2803 011104 011037 001162      MOV      (RO),#REG0   ;GET KEY CONTENTS
2804 011110 016137 000002 001164  MOV      2(R1),#REG1  ;GET THE FUNCTION INDICATED BY THIS KEY
2805 011116 104027                                     ERROR    27           ;IF NOT, ERROR
2806                                     ;BEFORE DOING A WRITE CHECK A WRITE IS
2807                                     ;ALWAYS DONE, OCCURANCE OF THIS ERROR
2808                                     ;INDICATES THAT SOMEHOW AN ATTEMPT IS BEING
2809                                     ;MADE TO DO WRITE CHECK BEFORE A WRITE IS
2810                                     ;PERFORMED, THE KEY IN ERROR MESSAGE WAS
2811                                     ;THE ONE WHICH GAVE RISE TO THIS ATTEMPT,
2812                                     ;THE FUNCTION CODE IS THE FUNCTION ASSOCIATED
2813                                     ;WITH THAT KEY
2814 011120 005037 001456      CLR      WCFLG        ;ABORT THIS WRITE CHECK
2815 011124 052710 100000      BIS      #BIT15,(RO)
2816 011130 000647                                     BR       QMNGER
2817 011132 012761 000006 000002 76:  MOV      #6,2(R1)    ;SET UP BITS FOR WRT CHK
2818                                     ;NOW
2819 011140 042710 174340      BIC      #174340,(RO) ;CLEAR OUT THE UNNECESSARY
2820                                     ;FLAGS FROM THE KEY
2821 011144 052710 000100      BIS      #BIT6,(RO)  ;SET FLAG FOR WRITE CHECK, FOR
2822                                     ;THIS KEY
2823 011150 000137 011612      JMP      EXECUT
2824
2825                                     ;NO HIGH PRIORITY COMMAND IN Q
    
```

```

2826                                     ;NO HIGH PRIORITY COMMAND WAS FOUND IN THE Q, FIND OUT THE FIRST AVAILABLE
2827                                     ;COMMAND IN THE Q, FOR EXECUTION,
2828 011154 005000      CHFAFN; CLR      RO      ;WAIT FOR ANY IMMEDIATE INTERRUPT
2829 011156 005046      CLR      -(SP)         ;NEW PSW
2830 011160 012746 011166      MOV      #16,=(SP)    ;RETURN FOR RTI
2831 011164 000002      RTI
2832
2833
2834 011166 105200      16:  INCB     RO
2835 011170 001376      BNE     #=2
2836 011172 013746 001244      MOV     PPRVL,=(SP)   ;NEW PSW, LOCK OUT CPU
2837 011176 012746 011204      MOV     #28,=(SP)    ;RETURN FOR RTI *****
2838 011202 000002      RTI
2839
2840
2841 011204 012700 001306      28:  MOV      #KEY,RO
2842 011210 005710      CH1:  TST      (RO)        ;UNFINISHED COMMAND?
2843 011212 100436      BMI     CH2
2844 011214 105710      TSTB   (RO)         ;IN PROGRESS?
2845 011216 100434      BMI     CH2
2846 011220 011001      MOV     (RO),R1
2847 011222 042701 177770      BIC     #177770,R1
2848 011226 105761 001426      TSTB   BUSY(R1)     ;IS THIS DRIVE BUSY?
2849 011232 100426      BMI     CH2
2850 011234 105761 001436      TSTB   POS(R1)     ;HAS THIS DRIVE BEEN POSITIONED
2851                                     ;FOR ANY OTHER COMMAND, IF YES,
2852                                     ;SKIP, IF NOT, PROCEED
2853 011240 001023      BNE     CH2
2854
2855
2856 011242 010002      MOV     RO,R2
2857                                     ;CHECK IF THERE IS AN OTHER COMMAND
2858 011244 000414      BR      28          ;ON A DRIVE THAT IS NOT THE SAME
2859                                     ;AS THE PREVIOUS DRIVE, THIS COMMAND
2860                                     ;SHOULD NOT BE IN PROGRESS
2861 011246 005712      16:  TST      (R2)
2862 011250 100412      BMI     28          ;AND SHOULD NOT HAVE BEEN COMPLETED
2863 011252 105712      TSTB   (R2)
2864 011254 100410      BMI     28          ;UNFINISHED COMMAND?
2865 011256 011203      MOV     (R2),R3
2866 011260 042703 177770      BIC     #177770,R3
2867 011264 105763 001426      TSTB   BUSY(R3)     ;IS THE DRIVE BUSY?
2868 011270 100402      BMI     28
2869 011272 020301      CMP     R3,R1
2870 011274 001447      BEQ     POSTION
2871                                     ;IS THIS COMMAND ON THE SAME DRIVE?
2872                                     ;IF YES, GO AND POSITION THE COMMAND
2873                                     ;POINTED TO BY RO, (BECAUSE THERE IS
2874                                     ;ONE MORE COMMAND THAT CAN BE PERFORMED
2875                                     ;ON THE SAME DRIVE)
2876                                     ;CHECK REST OF THE Q
2877 011276 005722      28:  TST      (R2)+
2878 011300 020227 001326      CMP     R2,#KEY+20
2879 011304 001360      BNE     18
2880                                     ;IF THERE WAS NO EXECUTABLE COMMAND
2881                                     ;ON ANY OTHER DRIVE, THEN EXECUTE
2882                                     ;COMMAND POINTED TO BY RO
2883 011306 000470      BR      EXN8K
2884
2885
2886 011310 005720      CH2:  TST      (RO)+
2887 011312 020027 001326      CMP     RO,#KEY+20
    
```

```

2882 011316 001334           BNE      CH1
2883
2884
2885           ;NO (UNPOSITIONED) EXECUTABLE COMMAND WAS FOUND IN THE Q, CHECK IF THERE
2886           ;IS ANY POSITIONED COMMAND IN THE Q, WAITING TO BE EXECUTED,
2887
2888 011320 105777 167676       TSTB   @RKCS           ;IF THE CONTROLLER IS BUSY GO TO
2889 011324 100402             BMI     18             ;STATUS AND WAIT FOR INTERRUPTS
2890 011326 000137 021436       JMP     STATUS         ;IF THE CONTROLLER IS NOT BUSY FIND
2891
2892 011332 012700 001306       18:    MOV     @KEY,R0           ;ANY POSITIONED COMMAND AND EXECUTE
2893 011336 032710 000020       28:    BIT     @BIT4,(R0)
2894 011342 001414             BEQ     38             ;IT
2895 011344 005710             TST    (R0)           ;MAKE SURE COMMAND IS POSITIONED
2896 011346 100412             BMI     38
2897 011350 105710             TSTB   (R0)           ;COMMAND IS UNFINISHED,
2898 011352 100410             BMI     38             ;IT IS NOT IN PROGRESS,
2899 011354 011001             MOV     (R0),R1        ;THE DRIVE IS NOT IN BUSY
2900 011356 042701 177770       BIC     @177770,R1
2901 011362 105761 001426       TSTB   BUSY(R1)
2902 011366 100402             BMI     38
2903 011370 000137 011612       JMP     EXECUT         ;GO EXECUTE THE COMMAND IF THE
2904
2905 011374 005720       38:    TST    (R0)+           ;ABOVE CONDITIONS ARE SATISFIED
2906 011376 020027 001326       CMP     R0,@KEY+20     ;CHECK ALL COMMANDS IN Q
2907 011402 001355             BNE     28
2908 011404 000137 021436       JMP     STATUS
2909
2910
2911           ;ENTER HERE IF THERE IS A PRIORITY COMMAND TO BE EXECUTED,
2912
2913
2914
2915 011410 000137 011612       PRICMN: JMP     EXECUT         ;GO EXECUTE NON-SEEK COMMAND,
2916
2917           ;ENTER THIS IF A COMMAND IS TO BE PREPOSITIONED (BEFORE EXECUTING A
2918           ;FUNCTION)
2919
2920 011414 032710 000020       POSITION: BIT    @BIT4,(R0) ;ALREADY POSITIONED?
2921 011420 001333             BNE     CH2           ;YES, GO BACK AND CHECK IF REST OF THE
2922                               ;COMMANDS IN THE Q ARE TO BE POSITIONED
2923
2924 011422 004737 012164       JSR     PC,POSK        ;GO CHECK, & SET UP FLAGS
2925 011426 004737 020350       JSR     PC,POSCMND     ;SAVE INFO ABOUT PRESENT & PAST COMAND
2926 011432 012777 000111 167562  MOV     @111,@RKCS     ;POSITION THE COMMAND
2927 011440 005046             CLR     -(SP)          ;NEW P&W, DROP PRIORITY
2928 011442 012746 011450       MOV     @18,-(SP)      ;RETURN FOR RTI
2929 011446 000002             RTI
2930
2931 011450 105737 001538       18:    TSTB   INTIFL         ;WAIT FOR INTERRUPT
2932 011454 001775             BEQ     =4             ;RE-ESTABLISH RK INTERRUPT VECTOR
2933 011456 012777 013256 167554  MOV     @INTHND,@RKVEC
2934 011464 000137 011154       JMP     CHPAFN         ;GO BACK AND CHECK IF ANY COMMANDS TO BE
2935                               ;POSITIONED OR EXECUTED
2936
2937
    
```

```

2938
2939           ;IS THERE ANY POSITIONED COMMAND IN
2940           ;THE Q, FIND OUT IF THERE IS
2941           ;ONE EXECUTE THE POSITIONED COMMAND,
2942           ;BUT FIRST POSITION THE COMMAND (KEY)
2943           ;POINTED TO BY R0
2944 011470 012701 001306       EXNRK: MOV     @KEY,R1
2945 011474 032711 000020       18:    BIT     @BIT4,(R1) ;HEADS POSITIONED?
2946 011480 001412             BEQ     28
2947 011482 005711             TST    (R1)           ;FUNCTION COMPLETED?
2948 011484 100410             BMI     28            ;YES, BRANCH
2949 011486 105711             TSTB   (R1)           ;FUNCTION IN PROGRESS?
2950 011490 100406             BMI     28
2951 011492 011102             MOV     (R1),R2
2952 011494 042702 177770       BIC     @177770,R2
2953 011496 105762 001426       TSTB   BUSY(R2)       ;DRIVE BUSY?
2954 011498 100005             BPL     38
2955
2956 011526 005721       28:    TST    (R1)+           ;CHECK ALL COMMANDS IN Q
2957 011530 020127 001326       CMP     R1,@KEY+20
2958 011534 001357             BNE     18
2959
2960 011536 000425             BR      EXECUT         ;NO POSITIONED COMMAND WAS
2961                               ;FOUND IN THE Q, SO EXECUTE
2962                               ;COMMAND POINTED TO BY R0
2963
2964
2965           ;AN ALREADY POSITIONED COMMAND HAS
2966           ;BEEN FOUND,
2967 011540 010137 001536       38:    MOV     R1,@KEY       ;SAVE POINTER TO THE COMMAND(KEY)
2968                               ;WHICH IS ALREADY POSITIONED
2969 011544 004737 012164       JSR     PC,POSK        ;GO AND POSITION THE COMMAND(KEY)
2970                               ;POINTED TO BY R0
2971 011550 004737 020350       JSR     PC,POSCMND     ;SAVE INFO ABOUT PAST & PRESENT COMAND
2972 011554 012777 000111 167440  MOV     @111,@RKCS     ;SEEK, IDE, GO
2973 011562 005046             CLR     -(SP)          ;ALLOW FIRST INTERRUPT
2974 011464 012746 011572       MOV     @48,-(SP)      ;RETURN FOR RTI *****
2975 011570 000002             RTI
2976
2977
2978 011472 105737 001538       48:    TSTB   INTIFL         ;DID INTERRUPT OCCUR?
2979 011476 001775             BEQ     48             ;IF NOT
2980 011480 012777 013256 167432  MOV     @INTHND,@RKVEC ;REESTABLISH INTERRUPT ADDRESS
2981 011486 013700 001536       MOV     @KEY,R0        ;RESTORE THE SAVED POINTER TO KEY
    
```

```

2982                                     ;EXECUTE THE COMMAND POINTED TO BY R0
2983                                     ;R0 CONTAINS THE POINTER TO THE
2984                                     ;COMMAND KEY
2985 011412 011001          EXECUT:  MOV   (R0),R1          ;GET DRIVE NO
2986 011514 042701 177770          BIC   $177770,R1
2987 011520 005710          TST   (R0)          ;THIS COMMAND UNFINISHED?
2988 011522 100004          BPL   18
2989 011524 011037 001162          MOV   (R0),$REGO
2990 011430 104030          ERROR  30          ;GET KEY
2991                                     ;IF NOT, ERROR
2992                                     ;AN ATTEMPT WAS MADE TO REEXECUTE A COMMAND
2993                                     ;THAT HAS ALREADY BEEN EXECUTED BEFORE,
2994                                     ;(ON DRIVE NO. GIVEN IN ERROR MESSAGE)
2994 011632 000512          BR    ABRT1
2995 011434 105710 101          TSTB  (R0)          ;IS IT IN PROGRESS?
2996 011636 100004          BPL   38
2997 011640 011037 001162          MOV   (R0),$REGO
2998 011644 104030          ERROR  30          ;GET KEY
2999                                     ;IF YES, ERROR
3000 011646 000504          BR    ABRT1          ;AN ATTEMPT WAS MADE TO REEXECUTE A COMMAND
3001                                     ;THAT IS IN PROGRESS (ON DRIVE NO. GIVEN
3002                                     ;IN EROR MESSAGE)
3003
3004 011680 105761 001426          38:   TSTB  BUSY(R1)          ;IS THE DRIVE BUSY?
3005 011684 100004          BPL   46
3006 011686 010137 001162          MOV   R1,$REGO
3007 011682 104002          ERROR  2          ;GET DRIVE #
3008 011664 000470          BR    ABRT          ;'BUSY' FLAG FOR THE DRIVE (CONTAINED
3009                                     ;IN R1) IS SET, INDICATING THAT THE DRIVE
3010                                     ;IS 'BUSY' AND ENGAGED IN AN ACTIVITY;
3011                                     ;STILL AN ATTEMPT WAS MADE TO INITIATE
3012                                     ;A FUNCTION ON THIS DRIVE. THIS IS AN
3013                                     ;UNEXCEPTED ERROR CONDITION.
3014 011666 105777 167330          46:   TSTB  $RKCS          ;CONTROL READY SET?
3015 011672 100404          BMI   58
3016 011674 004737 022032          JSR   PC,GT4RG
3017 011700 104003          ERROR  3          ;CONTROL READY IS NOT SET. THIS IS AN
3018 011702 000461          BR    ABRT          ;UNEXPECTED ERROR CONDITION AT THIS
3019                                     ;POINT OF EXECUTION, CONTROL SHOULD
3020                                     ;BE NORMALLY READY.
3021 011704 011002          58:   MOV   (R0),R2
3022 011706 000302          SWAB  R2
3023 011710 042702 177770          BIC   $177770,R2          ;FORM THE ADDRESS OF THE
3024 011714 006302          ASL   R2          ;PARAMETER LIST FOR THIS
3025 011716 010204          MOV   R2,R4          ;COMMAND
3026 011720 016205 002032          MOV   PC,MND(R2),R5
3027
3028 011724 011577 167300          MOV   (R5),$RKDA          ;GET THE FIRST ITEM FROM LIST
3029                                     ;DISK ADDRESS
3030 011730 032777 000100 167260          BIT   $RWS,$RKDS          ;R/W/S RDY SET?
3031 011736 001006          BNE   68
3032 011740 010137 001250          MOV   R1,$RDV
3033 011744 004737 022032          JSR   PC,GT4RG
3034 011750 104004          ERROR  4          ;GET DRIVE #, FOR TYPING SERIAL #
3035 011752 000435          BR    ABRT          ;$RKCS, ER, DS, DA
3036                                     ;R/W/S RDY IS NOT SET FOR THE DRIVE.
3037                                     ;A (NON-SEEK) FUNCTION WAS SUPPOSED
3038                                     ;TO BE EXECUTED ON THIS DRIVE. THIS IS
3039                                     ;AN UNEXPECTED ERROR CONDITIONS AT THIS
    
```

```

3038                                     ;POINT OF EXECUTION R/W/S RDY SHOULD
3039                                     ;BE NORMALLY SET.
3040 011754 016503 000002          68:   MOV   2(R5),R3          ;GET FUNCTION TO BE DONE
3041
3042 011760 122703 000002          CMPB  $2,R3          ;IS IT A WRITE FUNCTION?
3043 011764 001437          BEQ   WRFNC          ;YES, IT IS WRITE
3044                                     ;IT'S NOT A WRITE FUNCTION
3045
3046 011766 016503 000002          NWRFNC: MOV 2(R5),R3          ;GET FUNCTION TO BE DONE
3047 011772 052703 000501          BIS   $501,R3          ;SET SSE,IDE,GO BITS
3048 011776 016577 000004 167220          MOV   4(R5),$RKWC          ;GET WORD COUNT
3049 012004 016577 000006 167214          MOV   6(R5),$RKBA          ;GET BUS ADDRESS
3050
3051 012012 004737 020372          JSR   PC,FNCMND          ;SAVE INFO ABOUT PAST & PRESENT COMAND
3052
3053 012016 010377 167200          MOV   R3,$RKCS          ;SET SSE,IDE, FUNCTION, GO
3054
3055 012022 052710 000200          BIS   $BIT7,(R0)          ;SET FLAG INDICATING FUNCTION
3056 012026 052704 000200          BIS   $BIT7,R4          ;IN PROGRESS
3057                                     ;R4 CONTAINS OFFSET TO THE COMMAND KEY
3058                                     ;(FROM 'KEY') BITS 0-3, BIT 7 IS SET
3059 012032 110461 001426          MOVB  R4,BUSY(R1)          ;SET FLAG INDICATING DRIVE BUSY
3060 012036 110437 001534          MOVB  R4,INTFLG          ;SET FLAG FOR INTERRUPT USE
3061 012042 000137 021436          JMP   STATUS
3062
3063 012046 004737 014426          ABRT:  JSR   PC,DRVABT          ;ABORT THE FUNCTION
3064 012052 004737 016540          JSR   PC,CHKDRV          ;GO CHECK, DRIVE ERRORS
3065 012056 000240          NOP
3066 012060 000137 010650          ABRT1: JMP   QMNGER
    
```

```

3067
3068
3069 012064 016537 000004 012104 WRFNC: MOV 4(RB),18 ;THE FUNCTION TO BE EXECUTED IS A
;WRITE FUNCTION
3070 012072 016537 000006 012106 MOV 6(RB),28 ;GET # OF WORDS TO BE WRITTEN
;GET STARTING BA OF BUFFER
3071 012100 004837 016704 JBR RB,GENBUF ;GO GENERATE BUFFER
3072 012104 000000 18: ,WORD ;SAVE # OF WORDS
3073 012106 000000 28: ,WORD 0 ;SAVE STARTING BUS ADDRESS OF BUFFER
3074 012110 052703 000101 BIR #101,R3 ;SET IDE AND GO BIT
3075 012114 013777 012104 167102 MOV 18,0RKWC ;SET WORD COUNT
3076 012122 013777 012106 167076 MOV 28,0RKBA ;SET BUS ADDRESS
3077 012130 004737 020372 JBR PC,FNCMND ;SAVE INFO ABOUT PAST & PRESENT COMMAND
3078
3079 012134 010377 167062 MOV R3,0RKCS ;ISSUE WRITE,IDE,GO
3080 012140 082710 000200 BIR #BIT7,(R0) ;SET FLAG INDICATING FUNCTION IN
3081 012144 052704 000200 BIR #BIT7,R4 ;PROGRESS
3082
3083 012150 110461 001426 MOVBS R4,BUSY(R1) ;SET FLAG INDICATING DRIVE BUSY
3084 012154 110437 001534 MOVBS R4,INTFLG ;SET FLAG FOR INTERRUPT USE
3085
3086
3087 012160 000137 021436 JMP STATUS ;R4 CONTAINS OFFSET TO THE COMMAND KEY
;(FROM 'KEY') BITS 0-3, BIT 7 IS SET

```

```

3088 012164 011001 POSK: MOV (R0),R1 ;INITIAL CHECKING PRIOR TO DOING
3089 012166 042701 177770 BIC #177770,R1 ;POSITIONING COMMAND POINTED TO BY R0
3090 012172 105761 001426 TSTB BUSY(R1) ;DRIVE BUSY?
3091 012176 100004 BPL 18
3092 012200 010137 001162 MOV R1,REGO ;GET DRIVE # FOR WHICH 'BUSY' IS SET
3093 012204 104002 ERROR 2 ;'BUSY' FLAG FOR THE DRIVE (CONTAINED
3094 012206 000470 BR 78 ;IN R1) IS SET, INDICATING THAT THE DRIVE
;IS 'BUSY' AND ENGAGED IN AN ACTIVITY,
;STILL AN ATTEMPT WAS MADE TO INITIATE
;POSITIONING ON THIS DRIVE, THIS IS AN
;UNEXCEPTED ERROR CONDITION.
3095
3096
3097
3098
3099 012210 105777 167006 18: TSTB 0RKCS ;CONTROL READY SET?
3100 012214 100404 BMI 28 ;YES
3101 012216 004737 022032 JBR PC,GT4RG ;GET RKCS, ER, DS, DA
3102 012222 104003 ERROR 3 ;CONTROL READY IS NOT SET, THIS IS AN
3103 012224 000434 BR 68 ;UNEXPECTED ERROR CONDITION AT THIS
;POINT OF EXECUTION, CONTROL SHOULD
;BE NORMALLY READY.
3104
3105
3106 012226 011002 28: MOV (R0),R2
3107 012230 000302 SWAB R2
3108 012232 042702 177770 BIC #177770,R2
3109 012236 006302 ABL R2
3110 012240 016203 002032 MOV PCMND(R2),R3 ;STARTING WORD OF COMMAND TABLE
3111 012244 011377 166760 MOV (R3),0RKDA
3112 012250 032777 000100 166740 BIT #RWS,0RKDS ;R/W/S RDY SET?
3113 012256 001006 BNE 38 ;YES
3114 012260 010137 001250 MOV R1,SRDRV ;GET DRIVE #, FOR TYPING SERIAL #
3115 012264 004737 022032 JBR PC,GT4RG ;GET RKCS, ER, DS, DA
3116 012270 104004 ERROR 4 ;R/W/S RDY IS NOT SET FOR THE DRIVE, A
3117 012272 000431 BR 68 ;(POSITIONING) SEEK WAS SUPPOSED TO BE
;BE EXECUTED ON THIS DRIVE, THIS IS
;AN UNEXPECTED ERROR CONDITION, AT THIS
;POINT OF EXECUTION R/W/S RDY SHOULD
;BE NORMALLY SET.
3118
3119
3120
3121
3122 012274 110261 001426 38: MOVBS R2,BUSY(R1) ;SET FLAG INDICATING DRIVE BUSY
3123 012280 152761 000200 001426 BIRB #BIT7,BUSY(R1)
3124 012286 032710 000010 BIT #BIT3,(R0) ;IS THIS A SEEK COMMAND
3125 012212 001006 BNE 48
3126 012214 112761 000377 001436 MOVBS #377,POS(R1) ;SET FLAG INDICATING, THIS DRIVE POSITIONS
3127 012222 052710 000020 BIR #BIT4,(R0) ;SET FLAG INDICATING THIS COMMAND
3128 012226 000402 BR 58
3129 012230 082710 000200 48: BIR #BIT7,(R0) ;POSITIONED. SET FLAG INDICATING
;FUNCTION IN PROGRESS
3130
3131 012234 012777 012376 166676 58: MOV #INTLKB,0RKVEC ;SET UP RK11 VECTOR
3132 012242 013777 001244 166672 MOV #PRLVL,0RKSTAT ;PSW ON INTERRUPT
3133 012250 105037 001535 CLRB INT1FL ;CLEAR FLAG INDICATING - INTERRUPT
3134
3135 012254 000207 RTS PC ;OCCURRED
3136
3137 012256 004737 014426 68: JBR PC,DRVABT ;ABORT THE FUNCTION
3138 012262 004737 016840 JBR PC,CHKDRV ;GO CHECK, DRIVE ERRORS
3139 012266 000240 NOP
3140 012270 005726 78: TST (SP)+ ;POP THE RETURN ADDRESS
3141 012272 000137 010660 JMP QMNGER

```

```

3141 ;AFTER ISSUING A SEEK FOR POSITIONING, AN INTERRUPT IS ALLOWED TO TAKE
3142 ;*PLACE. THIS HANDLER SERVICES THE FIRST INTERRUPT, WHICH OCCURS AS A RESULT
3143 ;OF THE SEEK BEING ACCEPTED.
3144
3145 012476 105237 001533 INT18K1 INCB INT1FL ;INDICATE THAT INTERRUPT TOOK PLACE
3146 012402 053766 001244 000002 BIS PPRVLV,2(SP) ;CPU PRIORITY TO 5 ON RETURN FROM
3147 ;INTERRUPT
3148
3149 012410 004737 020272 JSR PC,CHKCRDY ;CONTROL READY SET?
3150 012414 104005 ERROR 5 ;CONTROL READY NOT SET AFTER THE FIRST
3151 ;INTERRUPT ON INITIATING SEEK
3152
3153 012416 032777 020000 166576 BIT #SCP,@RKCS ;SCP BIT SET?
3154 012424 001403 BEO 18
3155 012426 004737 022222 JSR PC,RG48DR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3156 ;TYPING SERIAL DRIVE #
3157 012432 104012 ERROR 12 ;SCP SET AFTER FIRST INTERRUPT ON
3158 ;ACCEPTING SEEK. A SEEK WAS INITIATED,
3159 ;AS A RESULT OF WHICH (THIS) FIRST
3160 ;INTERRUPT OCCURRED, BUT SCP SHOULD
3161 ;NOT BE SET AFTER THE FIRST INTERRUPT.
3162 ;(IT GETS SET ONLY AFTER THE SEEK
3163 ;IS DONE).
3164 ;THIS IS THE FIRST INTERRUPT
3165 ;AFTER ISSUING SEEK
3166 012434 017700 166562 181 MOV @RKCS,R0
3167 012440 042700 177760 BIC #177760,R0 ;CHECK THERE IS A SEEK FUNCTION
3168 012444 022700 000010 CMP #10,R0 ;IN RKCS
3169 012450 001403 BEQ 28
3170 012452 004737 022032 JSR PC,GT4RG ;GET RKCS,ER,DS,DA
3171 012456 104006 ERROR 6 ;RKCS DOES NOT CONTAIN 'SEEK' FUNCTION.
3172 ;A SEEK WAS INITIATED AS A RESULT OF WHICH
3173 ;(THIS) FIRST INTERRUPT OCCURRED. RKCS
3174 ;SHOULD CONTAIN THE SEEK FUNCTION BITS,
3175 ;BUT IT DID NOT
3176
3177 012460 017700 166544 281 MOV @RKDA,R0
3178 012464 042700 017777 BIC #17777,R0 ;GET THE DRIVE # FROM RKDA
3179 012470 000241 CLC
3180 012472 006100 ROL R0
3181 012474 006100 ROL R0
3182 012476 006100 ROL R0
3183 012480 006100 ROL R0
3184 012482 010001 MOV R0,R1
3185 012484 105761 001426 TSTB BUSY(R1) ;CHECK THIS DRIVE NO. WAS BUSY
3186 012410 100403 BMI 38 ;OK, IF IT WAS
3187 012512 010137 001162 MOV R1,@REGO ;GET DRIVE # (FROM RKDA)
3188 012416 104007 ERROR 7 ;'BUSY' FLAG FOR THE DRIVE WAS NOT SET,
3189 ;THE DRIVE # (IN RKDA) WHICH CAUSED (?)
3190 ;THIS (FIRST) INTERRUPT SHOULD HAVE BEEN
3191 ;'BUSY' (SOFTWARE FLAG). NOTE WHENEVER
3192 ;ANY OPERATION IS INITIATED ON ANY DRIVE
3193 ;'BUSY' FLAG FOR THAT DRIVE IS SET.
3194 012520 116100 001426 381 MOVB BUSY(R1),R0
3195 012524 042700 177600 BIC #177600,R0 ;FORM THE ADDRESS OF
3196 012430 062700 001306 ADD #KEY,R0 ;THIS KEY
    
```

```

3197
3198 012434 032710 000020 BIT #BIT4,(R0) ;IS THE KEY ACTIVE FOR 'POSITIONING'?
3199 012440 001003 BNE 48
3200 012442 010137 001162 MOV R1,@REGO ;GET DRIVE NUMBER
3201 012446 104010 ERROR 10 ;POSITIONING FLAG (IN THE KEY) IS NOT
3202 ;SET FOR THE INTERRUPTING DRIVE (GIVEN
3203 ;IN ERROR MESSAGE)
3204
3205 012450 105761 001436 481 TSTB POS(R1) ;IS THE 'POSITIONING' FLAG SET?
3206 012454 001003 BNE 58
3207 012456 010137 001162 MOV R1,@REGO ;GET DRIVE # FROM RKDA
3208 012462 104010 ERROR 10 ;THIS INTERRUPT IS SUPPOSED TO BE AS
3209 ;A RESULT OF INITIATING A (POSITIONING)
3210 ;SEEK. WHENEVER A SEEK IS INITIATED
3211 ;TO POSITION THE HEADS THE POSITIONING
3212 ;FLAG (POS#) IS SET. OCCURANCE OF THIS
3213 ;ERROR INDICATED THAT THE DRIVE #
3214 ;(FROM RKDA)GIVING THIS INTERRUPT DID
3215 ;NOT HAVE ITS POSITIONING FLAG SET.
3216
3217 012464 008777 166432 881 TST @RKCS ;ANY ERROR?
3218 012470 100044 BPL 88 ;NO - RETURN
3219
3220 012472 032737 000040 001474 BIT #BIT5,ERCODE ;SAME ERROR
3221 012600 001012 BNE 68
3222 012602 042737 000040 001474 BIC #BIT5,ERCODE
3223 012610 001026 BNE 78
3224 012612 052737 000040 001474 BIS #BIT5,ERCODE
3225
3226 012620 004737 022222 JSR PC,RG48DR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3227 ;TYPING SERIAL DRIVE #
3228 012624 104011 ERROR 11 ;BIT 15, 'ERR' SET IN RKCS AFTER FIRST
3229 ;INTERRUPT - WHICH OCCURRED AFTER A
3230 ;POSITIONING SEEK WAS INITIATED. RKER
3231 ;WILL CONTAIN ERROR BIT#
3232 012626 042710 000020 681 BIC #BIT4,(R0) ;CLEAR 'POSITIONING' BIT
3233 012632 105061 001426 CLRB BUSY(R1) ;CLEAR 'BUSY' FLAG
3234 012636 105061 001436 CLRB POS(R1) ;CLEAR 'POSITIONING' FLAG
3235
3236 012642 004737 016006 JSR PC,CLRERR ;CLEAR THE ERROR
3237 012646 052710 010000 BIS #BIT12,(R0) ;INDICATE HIGH PRIORITY ON
3238 012652 105261 001446 INCB RETRY(R1) ;INCREMENT RETRY COUNT
3239 012656 126127 001446 000003 CMPB RETRY(R1),#3 ;DONE RETRIES?
3240 012664 003406 BLE 88 ;NO
3241
3242 012666 004737 014426 781 JSR PC,DRVABT ;ABORT THE FUNCTION
3243 012672 005061 001446 CLR RETRY(R1)
3244 012676 005037 001474 CLR ERCODE
3245
3246 012702 000002 881 RTI
    
```

```

3247                                     ;THIS ROUTINE IS ENTERED UPON COMPLETION
3248                                     ;OF A SEEK OPERATION UNDER INTERRUPT MODE
3249
3250 012704 004737 020272          SKCMP; JSR      PC,CHKCRDY ;CONTROL READY SET?
3251 012710 104013                                     ERROR    13 ;CONTROL RDY NOT SET, AFTER A SEEK
3252                                     ;DONE INTERRUPT!
3253
3254 012712 017746 166300          18:  MOV      @RKDS,=(SP) ;GET DRIVE # THAT INTERRUPTED
3255 012716 004737 022170          JSR      PC,CROTLF ;ROTATE BITS 15,14,13 TO POSITION
3256                                     ;0,1,2
3257 012722 012601                                     MOV      (SP)+,R1 ;GET THE ROTATED BITS (DRIVE ID BITS)
3258 012724 105761                                     TSTB    BUSY(R1) ;CHECK THAT DRIVE WAS BUSY
3259 012730 100403                                     BMT     23
3260 012732 004737 022032          JSR      PC,G24RG
3261 012736 104014                                     ERROR    14
3262                                     ;'BUSY' FLAG FOR THE INTERRUPTING DRIVE
3263                                     ;(RKDS) WAS NOT SET. DRIVE # (15,14,13 = RKDS)
3264                                     ;INTERRUPTED AFTER SEEK WAS COMPLETE, BUT
3265                                     ;'BUSY' FLAG CORRESPONDING TO THAT DRIVE
3266                                     ;WAS CLEAR. IF THE CORRECT DRIVE WAS
3267                                     ;INTERRUPTING 'BUSY' FLAG SHOULD HAVE
3268                                     ;BEEN SET.
3269 012740 116100 001426          28:  MOVB    BUSY(R1),RO ;FORM THE ADDRESS OF THE
3270 012744 042700 177600          BIC     #177600,RO ;KEY
3271 012750 062700 001306          ADD     #KEY,RO
3272 012754 032710 000020          BIT     %BIT4,(RO) ;CHECK THAT POSITION BIT WAS SET
3273 012760 001003                                     BNE     38
3274 012762 010137 001162          MOV     R1,%REG0 ;GET DRIVE NUMBER
3275 012766 104010                                     ERROR    10 ;POSITIONING FLAG (IN KEY) IS NOT SET
3276                                     ;SET FOR INTERRUPTING DRIVE (GIVEN IN EROR
3277 012770 105761 001436          38:  TSTB    POS(R1) ;CHECK POSITIONING FLAG WAS SET
3278 012774 001003                                     BNE     48
3279 012776 010137 001162          MOV     R1,%REG0
3280 013002 104010                                     ERROR    10 ;'POSITIONING' FLAG WAS CLEAR. WHEN
3281                                     ;DOING A (POSITIONING) SEEK, THE FLAG
3282                                     ;'POS#' IS SET TO INDICATE THAT DRIVE
3283                                     ;IS POSITIONING HEADS (SEEKING). THIS
3284                                     ;ERROR INDICATES THAT FOR THE INTERRUPTING
3285                                     ;DRIVE (RKDS) POSITIONING FLAG WAS
3286                                     ;NOT SET.
3287 013004 004737 016540          48:  JSR      PC,CHKDRV ;GO, CHECK FOR DRV ERRORS (DPL,DRU,DRY,MPS)
3288 013010 000501          BR      PFTERR ;IF THERE IS A DRV ERROR, RETURN HERE
3289                                     ;THE DRIVE HAS BEEN DESELECTED, ALL
3290                                     ;FURTHER COMANDS ON THAT DRIVE ABORTED
3291                                     ;RETURN HERE IF NO DRIVE ERRORS
3292 013012 017777 166200 166210          MOV     @RKDS,@RKDA ;GET THE DRIVE # FROM DRIVE ID BITS
3293                                     ;IN RKDS AND ADDRESS THE DRIVE
3294 013020 032777 000100 166170          BIT     @RMS,@RKDS ;R/N/S RDY SET?
3295 013026 001005                                     BNE     58 ;YES
3296 013030 004737 022032          JSR      PC,G24RG ;GET RKCS,ER,DS,DA
3297 013034 010137 001250          MOV     R1,@RDRV ;GET DRIVE #, FOR TYPING SERIAL #
3298 013040 104013                                     ERROR    15 ;R/N/S RDY NOT SET FOR INTERRUPTING
3299                                     ;DRIVE (RKDS), AFTER SEEK WAS COMPLETED,
3300 013042 032777 001000 166146 58:  BIT     @SIN,@RKDS ;'SIN' ERROR?
3301 013050 001007          BNE     PSINER ;YES, BRANCH
3302

```

```

3303 013052 032777 040000 166142          BIT     @HE,@RKCS ;ANY HARD ERROR?
3304 013060 001060          BNE     FORKER ;YES
3305                                     ;NO ERRORS DETECTED ON POSITIONING
3306 013062 105061 001426          CLRB    BUSY(R1) ;CLEAR BUSY FLAG FOR THIS DRIVE
3307 013066 000207          RTS     PC

```

```

3308                                     ;THERE WAS A 'BIN' ERROR ON
3309                                     ;DOING POSITIONING (SEEK)
3310 013A70 004737 022032 PSINER: JSR   PC,GT4RG
3311 013074 010137 001230      MOV   R1,SRDRV
3312 013100 104016      ERROR 16
3313 013102 042710 000020      BIC   #R14,(R0)
3314 013106 103081 001436      CLRB  POS(R1)
3315 013112 106081 001426      CLRB  BUSY(R1)
3316 013116 004737 016192      JSR   PC,CLRBIN
3317
3318 013122 004737 016264      JSR   PC,SINCNT
3319
3320 013126 000432      BR    PFTERR
3321
3322                                     ;RETURN HERE IF COUNT LESS THAN MAX
3323 013130 105261 001446      PSRTY: INCB  RETRY(R1)
3324 013134 105061 001436      CLRB  POS(R1)
3325 013140 105061 001426      CLRB  BUSY(R1)
3326 013144 122761 000003      CMPB  #3,RETRY(R1)
3327 013152 001403      BEQ   18
3328 013154 052710 010000      BIS   #BIT12,(R0)
3329 013160 000207      RTS   PC
3330
3331 013162 052710 104000      18:  BIS   #104000,(R0)
3332 013166 105061 001446      CLRB  RETRY(R1)
3333 013172 010102      MOV   R1,R2
3334 013174 006302      ASL   R2
3335 013176 005262      INC   ABORT(R2)
3336 013180 042710 010000      BIC   #BIT12,(R0)
3337 013186 104421 002165      TYPMSG MSG10
3338 013192 000207      RTS   PC
3339
3340 013194 042710 010000      PFTERR: BIC   #BIT12,(R0)
3341 013198 000207      RTS   PC
3342
3343 013222 004737 022032      PORKER: JSR   PC,GT4RG
3344 013226 010137 001250      MOV   R1,SRDRV
3345 013232 104017      ERROR 17
3346
3347                                     ;IF ANY ERROR BIT IN RKCS SET
3348 013234 004737 015006      JSR   PC,CLRERR
3349 013240 042710 000020      BIC   #BIT4,(R0)
3350 013244 105061 001436      CLRB  POS(R1)
3351 013250 105061 001426      CLRB  BUSY(R1)
3352 013254 000725      BR    PSRTY
    
```

```

3353                                     ;ENTER THIS ROUTINE WHEN AN INTERRUPT
3354                                     ;OCCURS, NOTE THERE IS ONE OTHER
3355                                     ;INTERRUPT ROUTINE- 'INT18K'
3356 013256 105037 001534      INTHND: CLRB  INTFLG
3357
3358 013262 013766 001244 000002      MOV   PPRVL,2(SP)
3359 013270 004737 020272      JSR   PC,CHKCRDY
3360 013274 104024      ERROR 24
3361
3362 013276 032777 020000 165716 18:  BIT   #SCP,SRKCS
3363 013280 001403      BEQ   28
3364 013286 004737 012704      JSR   PC,SKCMP
3365 013292 000002      RTI
3366 013294 017746 165710 28:  MOV   SRKDA,-(BP)
3367
3368                                     ;GET THE DRIVE # TO WHICH
3369                                     ;THE COMMAND WAS ISSUED UNDER
3370                                     ;INTERRUPT MODE
3371 013298 004737 022170      JSR   PC,CROTFL
3372
3373                                     ;ROTATE BITS 15,14,13 TO POSITION
3374                                     ;0,1,2
3375 013304 012605      MOV   (BP)+,R5
3376 013308 105765 001426      TSTB  BUSY(R5)
3377 013312 100403      BMI   38
3378 013316 010537 001162      MOV   R5,REGO
3379 013320 104007      ERROR 7
3380
3381                                     ;'BUSY' FLAG FOR THE INTERRUPTING DRIVE
3382                                     ;WAS NOT SET. WHENEVER ANY ACTIVITY
3383                                     ;IS INITIATED ON A DRIVE, THE (SOFTWARE)
3384                                     ;'BUSY' FLAG IS SET TO INDICATE THAT
3385                                     ;DRIVE IS BUSY DOING SOMETHING.
3386                                     ;OCCURANCE OF THIS ERROR INDICATES
3387                                     ;THAT THE 'BUSY' FLAG FOR THE INTERRUPTING
3388                                     ;DRIVE (RKDA) IS CLEAR!
3389 013322 105065 001436      38:  CLRB  POS(R5)
3390 013326 116500 001426      MOVB  BUSY(R5),R0
3391 013330 042700 177760      BIC   #177760,R0
3392 013334 062700 001306      ADD   #KEY,R0
3393 013338 032710 000010      BIT   #BIT3,(R0)
3394 013342 001401      BEQ   48
3395 013346 104020      ERROR 20
3396
3397                                     ;(SOFTWARE) FLAG FOR THE INTERRUPTING
3398                                     ;DRIVE (RKDA) INDICATES THAT A SEEK
3399                                     ;FUNCTION WAS BEING EXECUTED ON THE
3400                                     ;DRIVE. IF THAT'S THE CASE, SCP BIT SHOULD
3401                                     ;HAVE SET ON SEEK DONE INTRUPT, BUT IT
3402                                     ;WAS NOT. NOTE, HERE THERE IS A CHANGE
3403                                     ;OF MULTIPLE ERRORS OR ERROR
3404                                     ;MISINTERPRETATION
3405 013348 105710 001162      48:  TSTB  (R0)
3406 013352 100403      BMI   56
3407
3408                                     ;CHECK THAT FUNCTION IN
3409                                     ;PROGRESS BIT WAS SET
3410 013354 010537 001162      MOV   R5,REGO
3411 013358 104031      ERROR 31
3412
3413                                     ;GET DRIVE NUMBER
3414                                     ;IF NOT, ERROR
3415                                     ;'FUNCTION IN PROGRESS' FLAG (IN THE KEY)
3416                                     ;WAS NOT SET FOR THE INTERRUPTING DRIVE.
3417                                     ;IF THIS DRIVE WAS BUSY DOING THE
3418                                     ;FUNCTION, THE ABOVE FLAG SHOULD BE SET.
3419 013360 011002      56:  MOV   (R0),R2
3420 013364 042702 177770      BIC   #177770,R2
3421 013368 020502      CMP   R5,R2
3422 013372 001405      BEQ   68
    
```

```

3409 013416 010837 001162      MOV      R6,REG0      ;GET EXPTD DRIVE NO.
3410 013422 010237 001164      MOV      R2,REG1      ;GET DRIVE NO, RECVD
3411 013426 104032      ERROR   32           ;UNEXPECTED DRIVE NO, INTERRUPTED
3412 013430 006302      ABL     R2           ;
3413 013432 011003      MOV      (R0),R3
3414 013434 010037 001836      MOV      R0,SAVKEY
3415 013440 000303      SHAB   R3
3416 013442 042703 177770      BIC     @177770,R3    ;GET POSITION OF THE PARAMETER
3417 013446 006303      ABL     R3           ;LIST FROM THE KEY
3418 013480 017704 188846      MOV      @RKB,R4
3419 013484 042704 177761      BIC     @177761,R4    ;CLEAR ALL BUT FUNCTION CODE
3420 013460 016308 002032      MOV      PC,PCR3,R6   ;CHECK THAT THE FUNCTION IN
                          ;RKB AND THE KEY ARE SAME,
3421
3422 013464 126804 000002      CNPB   2(R6),R4
3423
3424 013470 001406      BNG     76           ;IF NOT, ERROR
3425 013472 016837 000002 001162      MOV      2(R6),@REG0   ;GET EXPTD FUNCTION CODE IN RKB
3426 013900 010437 001164      MOV      R4,@REG1     ;GET CODE RECVD
3427 013504 104033      ERROR   33           ;FUNCTION CODE THAT IS IN RKB AFTER THIS
                          ;INTERRUPT OCCURED IS NOT THE EXPECTED ONE
3428
3429 013906 042710 000200 761      BIC     @BIT7,(R0)    ;CLEAR 'FUNCTION IN PROGRESS' BIT
3430 013912 142761 000200 001426      BIC     @BIT7,BUSY(R1) ;CLEAR BUSY FLAG FOR THIS DRIVE
3431 013920 004737 016840      JBR     PC,CHKDRV     ;CHECK FOR DRIVE ERRORS
3432 013924 000003      RTI
                          ;IF THERE WAS ANY DRIVE ERROR
                          ;Deselect the drive and exit
                          ;IF NO ERROR, RETURN HERE
3433
3434
3435 013926 022777 001000 165462      BIT     @SIN,@RKB     ;SIN ERROR?
3436 013934 001426      BEQ     108
3437 013936 004737 022222      JBR     PC,RC4DR      ;GET RKB, ER, DS, DA AND DRIVE # FOR
                          ;TYPING SERIAL DRIVE #
3438
3439
3440 013942 104016      ERROR   16
3441 013944 004737 016152      JBR     PC,CLRSEN     ;
3442 013950 004737 016264      JBR     PC,SINCF      ;HELP COUNT OF SIN'S, IF MORE
                          ;THAN MAX ALLOWABLE, DESELECT THE DRIVE
3443
3444
3445 013954 000002      RTI
                          ;RETURN HERE IF COUNT=MAX
                          ;RETURN HERE IF LESS THAN MAX
3446
3447 013956 105261 001446      INCB   RETRY(R1)
3448 013962 122761 000003 001446      CNPB   @3,RETRY(R1)
3449 013970 001405      BEQ     88
3450 013972 052710 010000      BIS     @BIT12,(R0)
3451 013976 042710 000020      BIC     @BIT4,(R0)
3452 013982 000002      RTI
3453
3454 013604 004737 014426      JBR     PC,DRVABF     ;ABORT THIS FUNCTION
3455 013610 000002      RTI
3456
3457 013612 032777 -040000 165402 106:      BIT     @NE,@RKB     ;HARD ERROR?
3458 013620 001076      BNE     HDRERR
3459 013622 032777 100000 165372      BIT     @ERR,@RKB    ;SOFT ERROR?
3460 013630 001002      BNE     @TERR
3461 013632 000137 014300      JMP     HDRERR        ;YES
                          ;NO

```

```

3460
3461
3462
3463 013636 032777 000001 165384 @TERR: BIT     @NCE,@RKB     ;NCE?
3464 013944 001417      BEQ     18
3465
3466 013646 032737 000001 001474      BIT     @BIT0,ERRCODE ;ALREADY WORKING ON A WC ERROR?
3467 013654 001084      BNE     38           ;YES - IGNORE THIS ONE
3468 013656 042737 000001 001474      BIC     @BIT0,ERRCODE ;ANY OTHER ERROR?
3469 013664 001082      BNE     48           ;YES - ABORT THIS FUNCTION
3470 013666 032737 000001 001474      BIS     @BIT0,ERRCODE ;SET THE WC ERROR BIT
3471
3472 013674 005262 001632      INC     @NCE,PC(R2)   ;INCREMENT NCE COUNT FOR
3473 013700 104421 002070      TYPNGB ,NGB2        ;THIS DRIVE
3474
3475 013704 032777 000002 165306 18:      BIT     @CSE,@RKB    ;CSE?
3476 013712 001417      BEQ     28
3477
3478 013714 032737 000002 001474      BIT     @BIT1,ERRCODE ;ALREADY WORKING ON A CS ERROR?
3479 013722 001031      BNE     36           ;YES - IGNORE THIS ONE
3480 013724 042737 000002 001474      BIC     @BIT1,ERRCODE ;ANY OTHER ERROR?
3481 013732 001027      BNE     46           ;YES - ABORT THIS FUNCTION
3482 013734 052737 000002 001474      BIS     @BIT1,ERRCODE ;SET THE CS ERROR BIT
3483
3484 013742 005262 001652      INC     @CSE,PCR2    ;INCREMENT CSE COUNT FOR THIS DRIVE
3485 013746 104421 002076      TYPNGB ,NGB3
3486 013752 104421 002120      TYPNGB ,NGB5
3487 013756 004737 021736      JBR     PC,TYPN      ;GO TYPE OUT THE FUNCTION THAT GAVE ERROR
3488 013762 004737 022064      JBR     PC,@TERR
3489 013766 004737 022226      JBR     PC,@SDRV
3490 013772 104021      ERROR   21
3491
3492
3493
3494 013774 022704 000004      CNPB   @4,R4
3495 014000 001002      BNE     36
3496 014002 004737 017110      JBR     PC,DATCRK     ;GO CHECK THE DATA READ
3497
3498 014006 000137 014160      JMP     @NERR
3499 014012 000137 014216      JMP     @MABT

```



```

3500 ;IF THERE WAS A HARD
3501 ;ERROR DURING THE DATA
3502 ;TRANSFER ENTER HERE
3503
3504 014A16 032777 010000 165174 HRDERR: BIT #SKE,SRKER ;SKE?
3505 014A24 001421 BEQ 18
3506
3507 014A26 032737 000004 001474 BIT #BIT2,ERCODE ;ALREADY WORKING ON A SK ERROR?
3508 014A34 001081 BNE CMNERR ;YES = IGNORE THIS ONE
3509 014A36 042737 000004 001474 BIC #BIT2,ERCODE ;ANY OTHER ERROR?
3510 014A44 001084 BNE CMNABT ;YES = ABORT THIS FUNCTION
3511 014A46 052737 000004 001474 BIS #BIT2,ERCODE ;SET THE SK ERROR BIT
3512
3513 014A54 005262 001602 INC SKECN(R2) ;INCREMENT COUNT FOR SKE
3514 014060 005262 001562 INC HECCN(R2) ;ON THIS DRIVE
3515
3516 014A64 104421 002062 TYPMSG ,MSG1
3517
3518 014A70 032777 167740 165122 18: BIT #167740,SRKER ;ANY HE BESIDES SKE?
3519 014A76 001417 BEQ 28
3520
3521 014100 032737 000010 001474 BIT #BIT3,ERCODE ;ALREADY WORKING ON A HE ERROR?
3522 014106 001024 BNE CMNERR ;YES = IGNORE THIS ONE
3523 014110 042737 000010 001474 BIC #BIT3,ERCODE ;ANY OTHER ERROR?
3524 014116 001037 BNE CMNABT ;YES = ABORT THIS FUNCTION
3525 014120 052737 000010 001474 BIS #BIT3,ERCODE ;SET THE HE ERROR BIT
3526
3527 014126 005262 001562 INC HECCN(R2) ;INCREMENT HE COUNT FOR
3528 014132 104421 002104 TYPMSG ,MSG4 ;THIS DRIVE
3529
3530 014136 104421 002120 28: TYPMSG ,MSG5 ;PRINT 'ON DOING'
3531 014142 004737 021736 JSR PC,TYPFN ;DO PRINT OUT THE FUNCTION
3532 ;WHICH GAVE THIS ERROR
3533
3534 014146 004737 022064 JSR PC,GETINF
3535 014152 004737 022226 JSR PC,GTSDRV ;SAVE DRIVE #, FOR TYPING SERIAL #
3536 014156 104022 ERROR 22 ;HARD ERROR ON DOING DATA XFER
3537
3538 014160 105261 001446 CMNERR: INCB RETRY(R1) ;INCREMENT RETRY COUNT
3539 014164 122761 000003 001446 CMPB #3,RETRY(R1) ;3 TRIES IN ALL?
3540 014172 001411 BEQ CMNABT ;YES, ABORT THIS FUNCTION
3541
3542 014174 052777 010000 165334 BIS #BIT12,SSAVKEY ;INDICATE HIGH PRIORITY ON RETRY
3543 014A02 042777 000020 165326 BIC #BIT4,SSAVKEY ;CLEAR 'POSITIONING HEADS', IF SET
3544 014A10 004737 016006 JSR PC,CLRERR ;CLEAR THIS ERROR
3545 014A14 000002 RTI
3546
3547 014A16 005037 001474 CMNABT: CLR ERCODE ;CLEAR ERROR CODE
3548 014A22 104421 002532 TYPMSG ,MSG27
3549 014A26 004737 014426 JSR PC,DRVABT ;ABORT THE FUNCTION
3550 014A32 032777 010000 164760 BIT #SKE,SRKER ;SEEK ERROR?
3551 014A40 001416 BEQ 38 ;NO
3552 014A42 104416 CON,RESET ;RESET THE CONTROLLER
3553 014A44 010137 001502 MOV R1,ODRV ;SET DRIVE NUMBER
3554 014A50 000241 CLC ;CLEAR THE 'C' BIT
3555 014A52 006037 001502 ROR ODRV ;LEFT JUSTIFY DRIVE NUMBER

```

```

3556 014A56 006037 001502 ROR ODRV ;LEFT JUSTIFY DRIVE NUMBER
3557 014A62 006037 001502 ROR ODRV ;LEFT JUSTIFY DRIVE NUMBER
3558 014A66 006037 001502 ROR ODRV ;LEFT JUSTIFY DRIVE NUMBER
3559 014272 104420 DRV,RESET ;RESET THE DRIVE
3560 014274 104416 CON,RESET ;RESET THE CONTROLLER
3561 014276 000002 38: RTI ;THIS DATA TRANSFER

```

```

3562                                     ;IF THERE WAS NO HARD OR
3563                                     ;SOFT ERROR ON DATA TRANSFER
3564                                     ;ENTER HERE
3565 014900 108761 001446      NOEROR: TSTB   RETRY(R1)
3566 014904 001406             BEQ     18
3567 014906 104421 002604     TYPMSG  ,MSG28
3568 014912 116146 001446     MOVB   RETRY(R1),-(SP)
3569 014916 104403             TYPOS  ,TYPE
3570 014920 002              ,BYTE  2
3571 014921 000              ,BYTE  0
3572
3573 014922 008037 001474     10:   CLR     ERCODE
3574 014926 108061 001446     CLRB  RETRY(R1)
3575 014932 042777 010000     BIC   %BIT12,%SAVKEY ;CLEAR PRIORITY BIT IF SET
3576 014940 004737 021006     JSR   PC,STATSTC    ;GO, COLLECT STATISTICS ON THIS
3577                                     ;DATA TRANSFER
3578
3579 014944 022704 000004     CMP   %4,R4         ;WAS IT A 'READ' FUNCTION?
3580 014980 001002             BNE   28
3581 014982 004737 017110     JSR   PC,DATCHK    ;IF IT WAS 'READ', CHECK THE DATA
3582
3583
3584
3585 014986 022704 000002     20:   CMP   %2,R4         ;WAS IT A 'WRITE' FUNCTION?
3586 014982 001011             BNE   38
3587 014984 032777 000040     BIT   %BIT8,%SAVKEY ;IS 'WRT CHK' TO FOLLOW THIS
3588 014972 001412             BEQ   48             ;'WRT' FUNCTION?
3589 014974 082703 100000     BIS   %BIT18,R3    ;SET FLAG BIT TO INDICATE
3590                                     ;THAT WRITE CHECK SHOULD
3591                                     ;FOLLOW THIS WRITE
3592 014400 010337 001486     MOV   R3,WCPLG     ;SET UP WC FLAG TO INDICATE
3593                                     ;THE ABOVE, THE LOWER BYTE
3594                                     ;CONTAINS THE POINTER TO THE
3595                                     ;COMMAND LIST, WHICH WILL
3596                                     ;BE USED, FOR DOING WRITE CHECK
3597 014404 000407             BR    58            ;IF WRITE CHECK IS TO BE DONE, DONT
3598                                     ;SET BIT 15 OF THE KEY TILL WRT CHK
3599                                     ;IS DONE
3600
3601 014406 022704 000006     30:   CMP   %6,R4         ;WRT CHK FUNCTION?
3602 014412 001002             BNE   48
3603 014414 005037 001456     CLR   WCPLG        ;CLEAR WR CNK FLAG
3604
3605 014420 052710 100000     40:   BIS   %BIT15,(R0) ;SET FLAG TO INDICATE THIS
3606 014424 000002             S0:   RTI           ;FUNCTION IS COMPLETED
    
```

```

3607                                     ;ABORT THE FUNCTION ON DRIVE POINTED TO BY R1
3608                                     ;CLEAR ASSOCIATED FLAGS
3609                                     ;DROP THE DRIVE IF MORE THAN 8, ABORTS
3610
3611 014426 010246             DRVABT: MOV   R2,-(SP)         ;SAVE R2
3612 014430 108061 001446     CLRB  RETRY(R1)
3613 014434 082710 104000     BIS   %104000,(R0) ;INDICATE THAT FUNCTION IS ABORTED
3614 014440 042710 010000     BIC   %BIT12,(R0) ;CLEAR HIGH PRIORITY BIT IF SET
3615 014444 010102             MOV   R1,R2
3616 014446 006302             ASL   R2
3617 014480 008262 001672     INC   ABORT(R2)
3618 014484 026227 001672     CMP   ABORT(R2),%10
3619 014462 003402             BLE   18
3620 014464 000137 016312     JMP   DBELCT        ;DROP THE DRIVE
3621 014470 012602             MOV   (SP)+,R2     ;RESTORE R2
3622 014472 104401 002165     TYPE ,MSG10        ;TYPE 'ABORTED'
3623 014476 000207             RTS   PC           ;RETURN
    
```

```

3624 ;THIS ROUTINE GENERATES THE 8 COMMAND REQUESTS AND PUT THEM IN THE QUEUE, THE
3625 ;FOLLOWING PARAMETERS ARE GENERATED RANDOMLY;
3626 ;1. DRIVE NUMBER ON WHICH THE COMMAND WILL BE PERFORMED.
3627 ;2. FUNCTION TO BE PERFORMED.
3628 ;3. DISK ADDRESS = CYLINDER, SURFACE, SECTOR.
3629 ;4. STARTING BUS ADDRESS.
3630 ;5. WORD COUNT FOR DATA TRANSFER.
3631
3632 ;THE QUEUE IS LOCATED AT 'CMND' (TO 'CMND8'),
3633
3634 014500 104407 GENBRQ: CKSWR
3635 014502 003337 002056 DEC REPCNT ;DECREMENT REPETITION COUNT
3636 014506 001025 BNE 18 ;CONTINUE IF NOT 0
3637 014510 013737 001236 002056 MOV PCNTR,REPCNT ;REESTABLISH REPETITION COUNT FOR EXERCISER
3638 014516 104401 014524 TYPE ,688 ;TYPE ASCIZ STRING
3639 014522 000407 BR 648 ;GET OVER THE ASCIZ
3640
3641 ;;65;: ,ASCIZ <18><12>/END OF PAGES/
3642 014542 013746 001100 ;;64;: MOV $PASS,=(8P)
3643 014546 005216 INC (8P)
3644 014550 104405 TYPDS
3645 014552 004737 021116 JBR PC,REPSTAT
3646 014556 000137 022704 JMP $EOP
3647
3648 014562 032777 000400 164350 18: BIT $SW8,$SWR
3649 014570 001422 BEQ 28
3650 014572 032777 000001 164340 BIT $SW0,$SWR ;SWITCH 0 SET ?
3651 014600 001410 BEQ 88 ;BR IF NOT
3652 014602 008727 TST (PC)+ ;CHECK INDICATOR
3653 014604 000000 ,WORD 0 ;TYPE TIME INDICATOR
3654 014606 001013 BNE 28 ;BR IF TIME ALREADY TYPED
3655 014610 008237 014604 INC 78 ;INCREMENT THE INDICATOR
3656 014614 004737 026660 JBR PC,TIMTYP ;TYPE THE TIME (IF SWR 03 SET)
3657 014620 000406 BR 28 ;CONTINUE
3658 014622 008037 014604 88: CLR 78 ;CLEAR THE INDICATOR
3659 014626 104401 001213 TYPE ,8CRLF
3660 014632 004737 021116 JBR PC,REPSTAT
3661 014636 032777 000040 164274 28: BIT $SW5,$SWR ;HALT?
3662 014644 001401 BEQ 38 ;NO
3663 014646 000000 HALT ;YES, PRESSING CONTINUE RESUMES PROG EXECUTION
3664
3665 014650 004737 022886 38: JBR PC,CNDPRS ;CHECK IF ANY DRIVES PRESENT
3666 014654 012700 001306 48: MOV $KEY,RO
3667 014660 010004 MOV RO,R4
3668 014662 008001 CLR R1
3669 014664 010120 58: MOV R1,(RO)+ ;CLEAR THE 8 COMMAND KEYS
3670 014666 062701 000400 ADD $400,R1 ;BITS 8,9,10 INDICATE THEIR
3671 014672 022701 004000 CMP $4000,R1 ;POSITION 0,1,2,3,4,5,6,7
3672 014676 001372 BNE 88
3673 014700 012700 001326 MOV $CMND,RO ;CLEAR THE PARAMETER TABLE
3674 014704 010005 MOV RO,R8
3675 014706 012701 177740 MOV $=40,R1 ;FOR THE 8 COMMANDS IN 8
3676 014712 005020 68: CLR (RO)+ ;(8X4) WORDS IN ALL
3677 014714 005201 INC R1
3678 014716 001375 BNE 68
3679

```

```

3680 014720 004737 015770 JBR PC,CLRFLGS ;CLEAR THE FLAGS PERTAINING TO THE 8
3681 ;COMMANDS IN THE Q
3682 ;R4 CONTAINS 'KEY'
3683 ;R5 CONTAINS 'CMND'
3684 014724 022737 000001 001264 GEN1: CMP $1,DRVPRS ;ONLY 1 DRV PRESENT?
3685 014732 001002 BNE 228 ;NO
3686 014734 005000 CLR RO ;YES
3687 014736 000420 BR 38
3688 014740 004737 025576 228: JBR PC,$RAND ;GENERATE A RANDOM NUMBER
3689 ;GET A RANDOM DRIVE NUMBER
3690 ;FROM THE AVAILABLE DRIVES
3691 014744 025730 R8DRVL
3692
3693 014746 013746 025732 MOV R8DRVH,=(8P) ;PUT LOW DIVIDEND ON STACK
3694 014752 005046 CLR =(8P) ;CLEAR HIGH DIVIDEND AND PUSH
3695 ;IT ON STACK
3696 014754 013746 001520 MOV DRMAP,=(8P) ;PUSH DIVISOR ON STACK
3697 014760 004737 025212 JBR PC,$$DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3698 014764 005726 TST (8P)+ ;DISCARD THE REMAINDER, QUOTIENT IS
3699 ;NOW ON TOP OF THE STACK
3700 014766 012600 MOV (8P)+,RO
3701 014770 020037 001264 CMP RO,DRVPRS ;MAKE SURE CORRECT MAPPING IS DONE
3702 014774 001001 BNE 38
3703 014776 005300 DEC RO ;'QDRVE' CONTAINS RANDOM DRIVE NO.
3704 015000 005037 001502 38: CLR QDRV
3705 015004 116037 001254 001502 MOVB PDR(RO),QDRV
3706 015012 105737 001502 TSTB QDRV ;TEST IF TYPE F DRIVE
3707 015016 100016 BPL 328 ;NOT IF POSITIVE
3708
3709 015020 142737 000200 001502 BICB $200,QDRV ;CLEAR THE FLAG BIT
3710 015026 132737 000001 001502 BITB $1,QDRV ;ODD OR EVEN DRIVE ADDRESS
3711 015034 001404 BEQ 318
3712
3713 015036 005737 015724 TST ODDEVN ;MUST HAVE BEEN AN ODD ONE
3714 015042 001730 BEQ GEN1 ;INSURE THAT ODDS WHAT WE WANT
3715 015044 000403 BR 328
3716
3717 015046 005737 015724 318: TST ODDEVN ;MUST HAVE BEEN AN EVEN ONE
3718 015052 001332 BNE 228 ;NO GOOD = TRY AGAIN
3719
3720 015054 004737 025576 328: JBR PC,$RAND ;GENERATE A RANDOM NUMBER
3721 015060 025734 R8FUNL
3722
3723 015062 013746 025736 MOV R8FUNH,=(8P) ;PUT LOW DIVIDEND ON STACK
3724 015066 005046 CLR =(8P) ;CLEAR HIGH DIVIDEND AND PUSH
3725 ;IT ON STACK
3726 015070 013746 001526 MOV FNMAP,=(8P) ;PUSH DIVISOR ON STACK
3727 015074 004737 025212 JBR PC,$$DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3728 015100 005726 TST (8P)+ ;DISCARD THE REMAINDER, QUOTIENT IS
3729 ;NOW ON TOP OF THE STACK
3730 015102 021627 000003 CMP (8P),#3 ;MAKE SURE CORRECT FUNCTION IS SELCTD
3731 015106 001001 BNE 208
3732 015110 005316 DEC (8P)
3733 015112 012637 001512 208: MOV (8P)+,QFNC ;THE FUNCTION THAT CAN BE PERFORMED
3734
3735 015116 004737 025576 JBR PC,$RAND ;GENERATE A RANDOM NUMBER

```

```

3736 01522 025740 RSCYLL
3737
3738 01524 013746 025742 MOV RSCYLH,=(SP) ;PUT LOW DIVIDEND ON STACK
3739 01530 005046 CLR =(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3740 ;IT ON STACK
3741 01532 013746 001522 MOV CYLMAP,=(SP) ;PUSH DIVISOR ON STACK
3742 01536 004737 025212 JBR PC,##DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3743 01542 005726 TBT ;DISCARD THE REMAINDER, QUOTIENT IS
3744 ;NOW ON TOP OF THE STACK
3745 01544 012637 001504 MOV (SP)+,QCYL ;(FROM 0-312)
3746 01540 022737 000313 001504 CMP #313,QCYL
3747 01556 001009 BNE 48
3748 015160 005337 001504 DEC QCYL ;'QCYL' CONTAINS RANDOM CYLINDER NO.
3749
3750 015164 481
3751
3752 015164 013746 025742 MOV RSCYLH,=(SP) ;PUT LOW DIVIDEND ON STACK
3753 015170 005046 CLR =(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3754 ;IT ON STACK
3755 01572 013746 001524 MOV SECMAP,=(SP) ;PUSH DIVISOR ON STACK
3756 01576 004737 025212 JBR PC,##DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3757 015902 005726 TBT ;DISCARD THE REMAINDER, QUOTIENT IS
3758 ;NOW ON TOP OF THE STACK
3759 015904 012637 001510 MOV (SP)+,QBEC ;(BETWEEN 0-13/8)
3760 015910 022737 000014 001510 CMP #14,QBEC
3761 015916 001002 BNE 58
3762 015920 005337 001510 DEC QBEC ;'QBEC' CONTAINS RANDOM SEC #
3763
3764 015924 022737 077777 025742 581 CMP #77777,RSCYLH ;SELECT SURFACE # RANDOMLY
3765 015932 101005 BHI 68
3766 015934 012737 000020 001506 MOV #BIT4,QBUR ;SURFACE 1
3767 ;R1 CONTAINS THE MAXM WORD COUNT BASED ON
3768 ;AVAILABLE DISK SPACE.
3769 ;R2 CONTAINS THE MAXM WORD COUNT BASED ON
3770 ;AVAILABLE MEMORY SPACE.
3771 015942 005001 CLR R1
3772 015944 000404 BR 78
3773
3774 015946 005037 001506 681 CLR QBUR ;SURFACE 0
3775 015952 012701 000014 MOV #14,R1 ;14 SECTORS ON BUR 0
3776
3777 ;ASSUMING THAT ENOUGH MEMORY IS AVAILABLE THE MAXIMUM TRANSFER THAT CAN
3778 ;TAKE PLACE IS 20K WORDS. IF THE RANDOM CYLINDER # > OR = TO 307 AND THE
3779 ;SURFACE IS 1, CHANCES ARE THAT THE NUMBER OF WORDS TO BE TRANSFERRED MAY
3780 ;BE GREATER THAN THE SPACE AVAILABLE ON THE DISK. IN THAT CASE, THE WORDS
3781 ;COUNT IS TO BE SELECTED IN SUCH A WAY THAT THIS OVERFLOW DOES NOT OCCUR,
3782
3783 015956 023727 001504 000306 781 CMP QCYL,#306 ;IS THE RANDOM CYL # GREATER THAN 306?
3784 015964 002003 BGE 98
3785 015966 012701 177777 881 MOV #177777,R1 ;IF YES, MAKE SURE THAT THE
3786 015972 000431 BR 318 ;WORD COUNT IS SELECTED PROPERLY
3787 ;COMPUTE MAXM WORD COUNT BASED ON
3788 ;AVAILABLE DISK SPACE
3789 015974 012700 000014 981 MOV #14,R0 ;COMPUTE # OF SECTORS AVAILABLE ON
3790 015900 163700 001510 SUB QBEC,R0 ;CYLINDERS SELECTED
3791 015904 060001 ADD R0,R1
    
```

```

3792 015906 012703 000312 MOV #312,R3 ;COMPUTE # OF SECTORS AVAILABLE
3793 015912 163703 001504 SUB QCYL,R3 ;BEYOND THE CYLINDER SELECTED
3794 015916 012746 000030 MOV #30,=(SP) ;PUT THE MULTIPLIER ON THE STACK
3795 015922 010346 MOV R3,=(SP) ;PUT THE MULTIPLICAND ON THE STACK
3796 015924 004737 025100 JBR PC,##MULT ;CALL THE MULTIPLY ROUTINE
3797 015930 012616 MOV (SP)+,(SP) ;DISREGARD THE MSB'S
3798 015932 012603 MOV #1,R3 ;GET THE LSB'S OF THE PRODUCT
3799 015934 060103 ADD R1,R3 ;COMPUTE TOTAL # OF SECTORS AVAILABLE
3800 015936 012746 000400 MOV #400,=(SP) ;PUT THE MULTIPLIER ON THE STACK
3801 015942 010346 MOV R3,=(SP) ;PUT THE MULTIPLICAND ON THE STACK
3802 015944 004737 025100 JBR PC,##MULT ;CALL THE MULTIPLY ROUTINE
3803 015950 012616 MOV (SP)+,(SP) ;DISREGARD THE MSB'S
3804 015952 012603 MOV #1,R3 ;GET THE LSB'S OF THE PRODUCT
3805 015954 010301 MOV R3,R1 ;COMPUTE TOTAL # OF WORDS=SPACE
3806 ;AVAILABLE ON DISK FROM THE SELECTED
3807 ;CYL #
3808 ;COMPUTE MAXM WORD COUNT BASED ON
3809 ;AVAILABLE MEMORY SPACE.
3810 015956 004737 025576 2181 JBR PC,#RAND ;GENERATE RANDOM NUMBER
3811 015962 025744 RBDAL
3812
3813 015964 013746 025746 MOV RBAN,=(SP) ;PUT LOW DIVIDEND ON STACK
3814 015970 005046 CLR =(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3815 ;IT ON STACK
3816 015972 013746 001530 MOV BANAP,=(SP) ;PUSH DIVISOR ON STACK
3817 015976 004737 025212 JBR PC,##DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3818 015402 005726 TBT ;DISCARD THE REMAINDER, QUOTIENT IS
3819 ;NOW ON TOP OF THE STACK
3820 015404 012637 001514 MOV (SP)+,QBUSAD ;BE USED
3821 015910 006337 001514 ABL QBUSAD
3822 015414 063737 002052 001514 ADD BASEBA,QBUSAD ;FORM THE RANDOM BUS=ADDRESS
3823 ;BY ADDING RANDOM OFFSET TO
3824 ;THE BASE BUS=ADDRESS
3825 015422 013703 002054 MOV MAXBA,R3 ;COMPUTE # OF WORDS THAT
3826 015426 163703 001514 SUB QBUSAD,R3 ;CAN BE TRANSFERRED, USING THE
3827 015432 000241 CLC ;ABOVE GENERATED BUS=ADDRESS WITHOUT
3828 015434 006003 ROR R3 ;CAUSING A NXM
3829 015436 010302 MOV R3,R2
3830
3831 015440 020201 1081 CMP R2,R1 ;SELECT SMALLER OF THE TWO
3832 015442 103401 SLO 118 ;WORD-COUNTS THAT WILL BE
3833 ;USED FOR GENERATING A RANDOM
3834 015444 010103 MOV R1,R3 ;WORD COUNT)
3835 ;R3 CONTAINS THE MAXM WORD COUNT
3836 ;POSSIBLE, COMPUTE THE WORD COUNT
3837 ;MAPPING FACTOR FROM THIS.
3838
3839 015446 1181
3840
3841 015446 012746 177777 MOV #177777,=(SP) ;PUT LOW DIVIDEND ON STACK
3842 015452 005046 CLR =(SP) ;CLEAR HIGH DIVIDEND AND PUSH
3843 ;IT ON STACK
3844 015454 010346 MOV R3,=(SP) ;PUSH DIVISOR ON STACK
3845 015456 004737 025212 JBR PC,##DIV ;GO TO THE 'DIVIDE' SUBROUTINE
3846 015462 005726 TBT ;DISCARD THE REMAINDER, QUOTIENT IS
3847 ;NOW ON TOP OF THE STACK
    
```

```

3848 015464 005216          INC      (8P)
3849 015466 012637 001532  MOV      (8P)+,WCMAP      ;WORD COUNT MAPPING FACTOR
3850                                     ;
3851 015472 004737 028576  JBR      PC,8RAND        ;GENERATE A RANDOM NUMBER
3852 015476 028780          R8WCL
3853                                     ;
3854 015400 013746 028752  MOV      R8WCH,-(8P)      ;PUT LOW DIVIDEND ON STACK
3855 015404 008046          CLR      -(8P)            ;CLEAR HIGH DIVIDEND AND PUSH
3856                                     ;IT ON STACK
3857 015406 013746 001532  MOV      WCMAP,-(8P)      ;PUSH DIVISOR ON STACK
3858 015412 004737 028212  JBR      PC,88DIV         ;GO TO THE 'DIVIDE' SUBROUTINE
3859 015416 008726          TST      (8P)+           ;DISCARD THE REMAINDER, QUOTIENT IS
3860                                     ;NOW ON TOP OF THE STACK
3861 015420 012637 001516  MOV      (8P)+,QWRCNT     ;'QWRCNT' CONTAINS THE RANDOM
3862                                     ;WORD COUNT THAT WILL BE USED
3863 015424 005737 001516  TST      QWRCNT          ;MAKE SURE THE WORD COUNT IS
3864 015430 003004          BGT      128             ;NOT 0
3865 015432 008437 001516  NEG      QWRCNT          ;TAKE CARE OF ZERO AND NEG NUMBS
3866 015436 005237 001516  INC      QWRCNT
3867 015442 113700 001502 128:  MOV8    QDRV,R0
3868 015446 000241          CLC
3869 015450 006000          ROR      R0
3870 015452 006000          ROR      R0              ;POSITION THE DRIVE NUMBER IN
3871 015454 006000          ROR      R0              ;BITS 15,14,13
3872 015456 006000          ROR      R0
3873 015460 013701 001504  MOV      QCYL,R1
3874 015464 000301          SWAB    R1
3875 015466 000241          CLC
3876 015470 006001          ROR      R1              ;POSITION THE CYLINDER NUMBER
3877 015472 006001          ROR      R1              ;IN BITS 12=5
3878 015474 006001          ROR      R1
3879 015476 050100          BIS     R1,R0
3880 015400 053700 001510  BIS     QSEC,R0          ;R0 CONTAINS THE COMPLETE DISK
3881 015404 053700 001506  BIS     QSUR,R0          ;ADDRESS
3882 015410 010025          MOV      R0,(R5)+       ;INSERT RKDA IN THE PARAMETER TABLE
3883                                     ; (FOR THE 8 COMMANDS)
3884                                     ; WHICH FUNCTION?
3885                                     ; 0-READ CHECK, 1-READ, 2-WRITE
3886 015412 022737 000001 001512  CMP      #1,QFNC
3887 015420 001412          BEQ     28              ;READ
3888 015422 003014          BGT     148            ;READ CHECK
3889 015424 012725 000002 16:  MOV      #2,(R5)+       ;WRITE FUNCTION CODE
3890 015430 023727 025752 077777  CMP      R8WCH,#77777    ;SHOULD WRITE CHECK BE DONE
3891 015436 101010          BHI     158            ;AFTER THE WRITE?
3892 015440 052714 000040          BIS     #BITS,(R4)      ;SET FLAG IN KEY TO INDICATE
3893                                     ; THAT WRITE CHECK SHOULD BE
3894                                     ; DONE FOLLOWING THE WRITE
3895 015444 000405          BR      158
3896                                     ;
3897 015446 012725 000004 28:  MOV      #4,(R5)+       ;READ FUNCTION CODE
3898 015452 000402          BR      158
3899                                     ;
3900 015454 012725 000012 148:  MOV      #12,(R5)+      ;READ CHECK FUNCTION CODE
3901                                     ;
3902 015460 013715 001516 158:  MOV      QWRCNT,(R5)    ;INSERT THE WORD COUNT (RKWC)
3903 015464 005425          NEG      (R5)+          ; (2'S COMPLEMENT)
    
```

```

3904 015466 013725 001514          MOV      QBUSAD,(R5)+    ;INSERT THE BUS ADDRESS (RKBA) FOR
3905                                     ; THIS COMMAND IN THE PARAMETER
3906                                     ; TABLE
3907 015472 053724 001502 168:  BIS     QDRV,(R4)+      ;SET THE DRIVE NUMBER INSIDE
3908                                     ; THE KEY FOR THIS COMMAND
3909 015476 020427 001326  CMP      R4,#KEY+20     ;GENERATED 8 COMMANDS IN
3910                                     ; THE QUEUE?
3911 015702 001402          BEQ     178
3912 015704 000137 014724          JMP     GEN1            ;IF NOT, GO BACK AND GENERATE
3913                                     ; THE NEXT COMMAND AND THE
3914                                     ; PARAMETERS (RKWC, BA, DA)
3915 015710 005237 015724 178:  INC      ODDEVN         ;CHANGE FROM ODD/EVEN TO EVEN/ODD
3916 015714 042737 177776 015724  BIC     #177776,ODDEVN ;KEEP ONLY ONE BIT
3917 015722 000207          RTS     PC              ;ALL 8 COMMANDS HAVE BEEN
3918                                     ; GENERATED IN THE TASK-QUEUE
3919 015724 000000          ODDEVN; 0
    
```

```

3920 ;ENTER THIS CODE IF SW 9 HAS BEEN SET AND LOOPING HAS TO BE DONE ON ERROR
3921 ;CONTROL IS TRANSFERRED TO THIS, ON RETURN FROM THE ERROR HANDLER '9ERROR'.
3922
3923
3924 015726 004737 016006 EXCLRUP: JSR PC,CLRERR ;WAIT FOR OTHER DRIVES TO GET DONE
3925 ;THEN ISSUE A CONTROL RESET
3926 015732 010146 MOV R1,=(SP)
3927 015734 012701 001306 MOV #KEY,R1 ;CLEAR OUT THE COMMAND-KEYS
3928 015740 043721 114220 18: BIC #1,4220,(R1)+
3929 015744 020127 001326 CMP R1,#KEY+20
3930 015750 001373 BNE 18
3931 015752 012601 MOV (SP)+,R1
3932 015754 004737 015770 JSR PC,CLRFLGS ;CLEAR OUT THE VARIOUS FLAGS PERTAINING
3933 ;TO THE 8 COMMANDS IN THE 8
3934 015760 012706 001100 MOV #STACK,SP ;REESTABLISH STACK POINTER
3935 015764 000137 010650 JMP QMNGER ;START OVER AGAIN, PROCESS THE COMMANDS
3936 ;IN THE 8 AGAIN, NOTE THAT ON LOOPING
3937 ;ON ERROR, WITH SW 9) AN ATTEMPT IS MADE
3938 ;TO RECREATE THE SET OF EVENTS WHICH LED TO
3939 ;ERROR.
3940
3941
3942
3943
3944 ;CLRFLGS
3945 ;THIS ROUTINE CLEARS OUT THE VARIOUS FLAGS USED FOR THE 8 COMMANDS IN THE QUEUE.
3946
3947 015770 012700 001426 CLRFLGS: MOV #BUSY,R0 ;CLEAR THE 8 BUSY FLAGS
3948 015774 005020 18: CLR (R0)+
3949 015776 020027 001462 CMP R0,#8CNT+2 ;ALL DONE?
3950 016002 001374 BNE 18 ;NO
3951 016004 000207 RTS PC
    
```

```

3952 ;CLRERR
3953 ;THIS ROUTINE IS ENTERED WHEN A HARD ERROR HAS OCCURRED AND IT HAS TO BE
3954 ;CLEARED. THE DRIVES THAT HAVE BEEN BUSY ARE CHECKED TO SEE IF THEIR R/W/S
3955 ;RDY BIT HAS SET. WHEN R/W/S IS SET, CHECKING IS DONE FOR ANY ERROR, IF A
3956 ;ERROR OCCURED IT IS REPORTED, IF NOT, APPROPRIATE FLAGS ARE SET AND
3957 ;CLEARED FOR THAT DRIVE. AFTER ABOVE IS DONE FOR ALL DRIVES THAT HAVE BEEN
3958 ;SEEKING, A CONTROL RESET IS ISSUED TO CLEAR THE HARD ERROR.
3959
3960 016006 010446 CLRERR: MOV R4,=(SP) ;SAVE R4, R4 ON THE STACK
3961 016010 010546 MOV R5,=(SP)
3962 016012 005005 CLR R5
3963 016014 005077 163210 CLR #RKDA
3964
3965 016020 105765 001426 18: TSTB BUBY(R5) ;WAS THIS DRIVE BUSY SEEKING?
3966 016024 100035 BPL 46 ;NO
3967 016026 005037 001472 CLR TIMER
3968 016032 032777 000100 163156 28: BIT #RWS,#RKDS ;R/W/S SET?
3969 016040 001018 BNE 38 ;YES
3970 016042 005237 001472 INC TIMER ;KEEP TIME
3971 016046 001371 BNE 28 ;WAIT FOR R/W/S RDY
3972 016050 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3973 ;TYPING SERIAL DRIVE #
3974 016054 104004 ERROR 4 ;R/W/S READY DID NOT SET
3975 ;FOR THIS DRIVE, WAITED LONG ENOUGH.
3976 016056 032777 001000 163132 BIT #SIN,#RKDS ;SIN ERROR ON THIS DRIVE?
3977 016064 001403 BEQ 38
3978 016066 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
3979 ;TYPING SERIAL DRIVE #
3980 016072 104016 ERROR 16 ;SIN OCCURED ON THIS DRIVE
3981
3982 016074 116504 001426 38: MOV# BUBY(R5),R4 ;FORM THE ADDRESS OF THE
3983 016100 042704 177760 BIC #17760,R4 ;KEY WHICH MADE THIS DRIVE
3984 016104 062704 001306 ADD #KEY,R4 ;BUSY
3985
3986 016110 042714 010000 BIC #1000,(R4) ;CLEAR HIGH PRIORITY BIT, IF SET
3987 016114 105065 001426 CLR# BUBY(R5) ;MAKE THIS DRIVE FREE, AVAILABLE
3988
3989
3990 016120 062777 020000 163102 48: ADD #20000,#RKDA ;ADDRESS THE NEXT POSSIBLE DRIVE
3991 016126 005205 INC R5 ;INCREMENT COUNT
3992 016130 022703 000010 CMP #10,R5 ;ALL DONE
3993 016134 001331 BNE 18 ;NO
3994
3995 016136 004737 020340 JSR PC,CRCMND ;SAVE INFO ABOUT THE PAST & PRESENT COMAND
3996 016142 104416 CON,RESET
3997 016144 012605 MOV (SP)+,R5 ;RESTORE R4,R5
3998
3999 016146 012604 MOV (SP)+,R4
4000 016150 000207 RTS PC ;RETURN
    
```

```

4000 ;CLRSIN
4001 ;THIS ROUTINE IS ENTERED WHEN THERE IS A 'SIN' ERROR. AT TIME OF ENTRY
4002 ;RKDA CONTAINS THE DRIVE # THAT GAVE 'SIN'. A DRIVE RESET IS DONE ON THAT
4003 ;DRIVE. AFTER IT IS DONE, ROUTINE 'CLRHE' IS ENTERED, TO WAIT FOR THE
4004 ;OTHER DRIVES THAT HAVE BEEN DOING SEEKS, WHEN ALL THE DRIVES GIVE
4005 ;'R/W/S RDY', A CONTROL RESET IS DONE, RETURN IS MADE BACK TO THIS
4006 ;ROUTINE='CLRSIN' AND FINALLY CONTROL IS TRANSFERRED BACK TO THE MAIN
4007 ;PROGRAM.
4008
4009 016152 017737 163052 001516 CLR SIN; MOV @RKDA,QWRCNT ;SAVE DISK ADDRESS
4010 016160 004737 016006 JSR PC,CLRERR ;GO, WAIT FOR OTHER DRIVES TO COMPLETE
4011 ;THEIR SEEKS(IF THEY ARE DOING ANY)
4012 ;THEN DO CON,RESET TO CLR THE ERROR.
4013 016164 013777 001516 163036 MOV QWRCNT,@RKDA ;ADDRESS THE DRIVE AGAIN
4014 016172 004737 020314 JSR PC,DRCHND ;SAVE INFO ABOUT THE PAST & PRESENT COMAND
4015 016176 012777 000015 163016 MOV $15,@RKCS ;DO DRIVE RESET ON THE
4016 ;DRIVE
4017 ;INDICATED IN RKDA
4018 016904 104417 CON,RDY
4019 016906 005037 001472 CLR TIMER
4020 016912 032777 000100 162776 18; BIT #RWS,@RKDS ;WAIT FOR R/W/S RDY TO SET
4021 016920 001015 BNE Z8
4022 016922 005237 001472 INC TIMER
4023 016926 001371 BNE Z8
4024 016930 004737 022222 JSR PC,RG48DR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
4025 ;TYPING SERIAL DRIVE #
4026 016934 104004 ERROR 4 ;R/W/S RDY DID NOT SET AFTER
4027 ;DOING DRIVE RESET, TIMED OUT
4028 016936 032777 001000 162752 BIT #SIN,@RKDS
4029 016944 001403 BEQ Z8
4030 016946 004737 022222 JSR PC,RG48DR ;GET RKCS, ER, DS, DA AND DRIVE # FOR
4031 ;TYPING SERIAL DRIVE #
4032 016952 104016 ERROR 16 ;A DRIVE RESET WAS DONE ON THIS DRIVE
4033 ;TO CLEAR 'SIN', BUT 'SIN' DID NOT GET
4034 ;CLEARED
4035
4036 016954 004737 020340 28; JSR PC,CRCHND ;SAVE INFO ABOUT THIS COMMAND
4037 016960 104416 CON,RESET ;DO IT TO CLEAR OUT MASK F/FS
4038 016962 000207 RTS PC ;EXIT FROM THIS ROUTINE
  
```

```

4039 ;SINCNT
4040 ;THIS ROUTINE IS ENTERED WHEN A 'SIN' ERROR OCCURS, THE 'SIN' COUNT FOR
4041 ;THE DRIVE GIVING 'SIN' IS INCREMENTED, IF MORE THAN 5 'SIN' ERRORS
4042 ;OCCURRED THE DRIVE IS DESELECTED, AT THE TIME OF ENTRY R1 CONTAINS THE
4043 ;DRIVE NUMBER THAT GAVE 'SIN' ERROR.
4044 ;CALL: JSR PC,SINCNT
4045 ; ----- RETURN HERE IF SIN COUNT (MAXIMUM ALLOWABLE)
4046 ; WAS EXCEEDED.
4047 ; ----- RETURN HERE IF TOTAL SIN COUNT LESS THAN MAXIMUM
4048 ; ALLOWABLE.
4049
4050
4051 016964 105261 001622 SINCNT; INCB @SINC(R1) ;INCREMENT 'SIN' COUNT FOR THIS DRIVE
4052 016970 122761 000005 001622 CMPB #5,@SINC(R1) ;5 ERRORS OCCURRED?
4053 016976 101403 BLOS Z8 ;YES
4054 016980 062716 000002 ADD #2,@P ;ADJUST PC FOR RETURN TO THE RIGHT POINT
4055 016984 000207 RTS PC ;RETURN
4056
4057 016986 000137 016312 18; JMP DSELECT ;5 ERRORS OCCURRED, GO DESELECT
  
```

```

4058 ;DSELECT
4059 ;THIS ROUTINE IS ENTERED WHEN A DRIVE IS TO BE DESELECTED (TAKEN
4060 ;OUT OF SELECTION LIST), BECAUSE THE FATAL ERRORS ON THAT DRIVE
4061 ;HAS REACHED A MAXIMUM COUNT, R1 CONTAINS THE DRIVE NUMBER THAT
4062 ;THAT IS TO BE DESELECTED, THE DRIVE IS DESELECTED IF 1. TOTAL SIN COUNT
4063 ;FOR THAT DRIVE REACHES THE MAXIMUM ALLOWABLE 2. IF A FATAL ERROR
4064 ;LIKE DRIVE UNSAFE, DRIVE POWER LOW OCCURS, 3. IF WPS GETS SET, OR DRY
4065 ;IS CLEAR.
4066
4067
4068
4069 016912 012705 001253 DSELECT: NOV $PDR=R1,R5 ;NUMBER OF DRIVES BEING TESTED
4070 016916 013702 001264 NOV DRVPR=R2 ;FOR END ADDRESS OF TABLE
4071 016922 062702 001253 ADD $PDR=R1,R2 ;LOCATE THE DRIVE (TO BE
4072 016926 005208 10: INC R5 ;DESELECTED) IN THE TABLE
4073 016930 111503 MOVB (R5),R3 ;DROP THE F FLAG
4074 016932 042703 177600 BIC $177600,R3 ;IS THIS THE ONE
4075 016936 020301 CMP R3,R1 ;CONTAINING AVAILABLE DRIVES
4076 016940 001403 BEQ Z5 ;FINISHED ?
4077 016942 020502 CMP R5,R2 ;BR IF NOT
4078 016944 103770 BLO Z5 ;DRIVE WAS NOT FOUND IN TABLE, EXIT
4079 016946 000472 BR 110 ;GET THE DRIVE NUMBER
4080 016950 111502 20: MOVB (R5),R2 ;IS THIS DRIVE $ THE LAST ENTRY IN TABLE?
4081 016952 020527 001264 50: CMP R5,$PDR+10 ;YES
4082 016956 001406 BEQ Z5
4083 016960 010904 MOV R5,R4 ;IF NOT, TAKE OUT THIS DRIVE $ FROM
4084 016962 005205 INC R5 ;THE MIDDLE AND PUSH UP THE
4085 016964 112524 30: MOVB (R5)+,(R4)+ ;REST OF THE ENTRIES
4086 016966 022704 001263 CMP $PDR+7,R4
4087 016972 001374 BNE Z5
4088 016976 105055 177777 40: CLRB =1(R5) ;CLEAR LAST ENTRY IN TABLE
4089
4090 ;THE DRIVE $ TYPED OUT WAS DESELECTED
4091 ;BECAUSE ERROR COUNT EXCEEDED THE
4092 ;MAXIMUM ALLOWABLE
4093 016400 104401 002336 TYPE ,NSG10 ;TYPE "DRIVE DROPPED"
4094 016404 010146 MOV R1,=(SP) ;PUSH DRIVE NUMBER ON STACK
4095 016406 104403 TYP05 ;TYPE IT ON THE TERMINAL
4096 016410 001 ,BYTE 1
4097 016411 000 ,BYTE 0
4098 016412 004737 026766 JSR PC,$NOTYP ;GO TYPE OUT SERIAL NO OF THE DRIVE,
4099 ;IF SW 1 IS SET.
4100 016416 005337 001264 DEC DRVPRS ;DECREMENT THE TOTAL NUMBER OF
4101 ;DRIVES PRESENT
4102 016422 004737 022686 JSR PC,$CHOPRS ;CHECK IF ANY DRIVES PRESENT
4103 ;IF NONE GOT TO END OF PASS, $EOP
4104
4105 016426 012746 177777 MOV $177777,=(SP) ;PUT LOW DIVIDEND ON STACK
4106 016432 005046 CLR =(SP) ;CLEAR HIGH DIVIDEND AND PUSH
4107 ;IT ON STACK
4108 016434 013746 001264 MOV DRVPRS,=(SP) ;PUSH DIVISOR ON STACK
4109 016440 004737 025212 JSR PC,$DIV ;GO TO THE "DIVIDE" SUBROUTINE
4110 016444 005726 TST (SP)+ ;DISCARD THE REMAINDER, QUOTIENT IS
4111 ;NOW ON TOP OF THE STACK
4112 016446 012637 001520 MOV (SP)+,DRMAP ;TO BE USED FOR GENERATING RANDOM
4113 ;DRIVE NUMBERS,

```

```

4114 016452 012704 001306 MOV $KEY,R4 ;DESELECT THE COMMANDS
4115 016456 011405 60: MOV (R4),R5 ;IN THE "COMMAND 0" CORRESPONDING
4116 016460 042705 177770 BIC $177770,R5 ;TO THE DESELECTED DRIVE
4117 016464 020105 CMP R1,R5
4118 016466 001002 BNE Z5
4119 016470 052714 104000 BIS $104000,(R6) ;INDICATE COMMAND DESELECTED
4120 016474 005724 70: TST (R4)+ ;(AND COMPLETED)
4121 016476 022704 001326 CMP $KEY+20,R4
4122 016502 001355 BNE $6
4123
4124 016506 105702 80: TSTB R2 ;"F" TYPE DRIVE ?
4125 016506 100012 SPL 110 ;NO = JUST EXIT
4126 016510 032701 000001 BIT $1,R1 ;ODD OR EVEN DRIVE NUMBER
4127 016514 001403 BEQ $6
4128 016516 042701 000001 BIC $1,R1
4129 016522 000402 BR 108
4130 016524 052701 000001 90: BIS $1,R1
4131 016530 000137 016312 100: JMP DSELECT ;DROP CORRESPONDING DRIVE
4132
4133
4134 016534 000137 010630 110: JMP $EGNEX ;GO RESTART EXERCISOR PART OF TEST

```



```

4135 ;CHKDRV
4136 ;THIS ROUTINE CHECKS FOR FATAL ERRORS OF THE DRIVE LIKE DPL, DRV
4137 ;WPS. IF ANY ONE OF THESE ERRORS OCCUR THE DRIVE IS Deselected
4138 ;AND NO MORE FUNCTIONS WILL BE PERFORMED ON THAT DRIVE. R1
4139 ;CONTAINS THE DRIVE NUMBER TO BE CHECKED.
4140
4141 ;*NOTE 1: IN THE ERROR MESSAGE WHERE RKDA IS PRINTED OUT, IT GIVES
4142 ;*ONLY THE DRIVE NUMBER (NOT CYLINDER, SURFACE AND SECTOR).
4143
4144 ;CALL: JSR PC,CHKDRV
4145 ; ----- RETURN HERE IF ANY FATAL ERROR OCCURED
4146 ; ----- RETURN HERE IF THERE WAS NO FATAL ERROR
4147
4148 016440 017746 162464 CHKDRV: MOV @RKDA,=@SP ;SAVE RKDA
4149 016344 010146 MOV R1,=@SP ;GET DRIVE #
4150 016446 000241 CLC
4151 016350 006016 ROR (SP)
4152 016452 006016 ROR (SP)
4153 016454 006016 ROR (SP)
4154 016456 006016 ROR (SP)
4155 016460 012677 162444 MOV (SP)+,@RKDA ;ADDRESS THE DRIVE TO BE CHECKED
4156 016464 032777 010000 162424 BIT @DPL,@RKDS ;DRIVE POWER LOW?
4157 016472 001403 BEQ 18
4158 016474 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE #
4159 ;FOR TYPING SERIAL NUMBER
4160 016400 104035 ERROR 35 ;DRIVE POWER LO, *NOTE 1 ABOVE
4161 016402 032777 002000 162406 18: BIT @DRU,@RKDS ;DRIVE
4162 016610 001403 BEQ 28
4163 016612 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE #
4164 ;FOR TYPING SERIAL NUMBER
4165 016616 104036 ERROR 36 ;DRIVE UNSAFE BIT IS SET
4166 ;*NOTE 1 ABOVE
4167 016620 032777 000040 162370 28: BIT @WPS,@RKDS ;WRITE PROTECT SET?
4168 016926 001403 BEQ 38
4169 016630 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE #
4170 ;FOR TYPING SERIAL NUMBER
4171 016634 104037 ERROR 37 ;WPS SET, CHECK WRITE PROTECT SWITCH ON DRIVE
4172 ;*NOTE 1 ABOVE
4173 016636 032777 000200 162352 38: BIT @DRY,@RKDS ;DRIVE READY CLEAR?
4174 016444 001004 BNE 48
4175 016646 004737 022222 JSR PC,RG4SDR ;GET RKCS, ER, DS, DA AND DRIVE #
4176 ;FOR TYPING SERIAL NUMBER
4177 016652 104034 ERROR 34 ;DRIVE READY CLEAR, SHOULD BE SET
4178 ;*NOTE 1 ABOVE
4179 016554 000411 BR 56
4180
4181 016656 032777 012040 162332 48: BIT #12040,@RKDS ;ANY ERROR?
4182 016664 001005 BNE 58
4183 016666 012677 162336 MOV (SP)+,@RKDA ;RESTORE RKDA
4184 016672 062716 000002 ADD #2,(SP) ;ADJUST RETURN ADDRESS
4185 016676 000207 RTS PC
4186
4187 016700 000137 016312 58: JMP DBELCT
    
```

```

4188 ;GENBUF
4189 ;THIS ROUTINE GENERATES A BUFFER FULL OF RANDOM DATA WORDS. THIS BUFFER
4190 ;IS THEN USED TO WRITE DATA ON THE DISK. AT THE TIME OF ENTRY, RKDA
4191 ;CONTAINS THE DISK ADDRESS WHERE WRITE WILL BE DONE. SEED WORDS USED FOR
4192 ;THE RANDOM NUMBERS ARE:
4193 ; 1) ABSOLUTE DISK ADDRESS (DRIVE #, CYL #, SEC #, SUR #) = @MINUM
4194 ; 2) COMPLEMENT OF THE ABOVE WORD
4195 ;CALL: JSR R5,GENBUF
4196 ; X ;X IS THE WORD COUNT (2'S COMPLEMENT)
4197 ; Y ;Y IS THE STARTING ADDRESS OF THE
4198 ; MEMORY BUFFER.
4199
4200 016704 104414 GENBUF: SAVREG ;SAVE REGISTERS
4201 016706 016504 000002 MOV 2(R5),R4 ;GET STARTING ADDRESS OF BUFFER
4202 016712 011503 MOV (R5),R3 ;GET WORD COUNT (# OF WORDS TO
4203 ;BE GENERATED)
4204
4205 016714 017702 162310 MOV @RKDA,R2 ;GET THIS RANDOM SEED
4206 016720 010237 025756 18: MOV R2,RSDTL
4207 016724 010237 025754 MOV R2,RSDTL
4208 016730 005137 025754 COM RSDTL ;GET LO RANDOM SEED
4209
4210 016734 022703 177400 CMP #-400,R3 ;IF THE BUFFER IS MORE THAN
4211 016740 003003 BGT 28 ;ONE SECTOR (400 WORDS) LONG,
4212 016742 010305 MOV R3,R5 ;GENERATE THE BUFFER IN SUCH
4213 016744 005003 CLR R3 ;A WAY THAT EACH SECTOR
4214 016746 000404 BR 38 ;BEGINS WITH RANDOM DATA
4215
4216 016750 062703 000400 28: ADD #400,R3 ;WORDS GENERATED USING THAT
4217 016754 012705 177400 MOV @-400,R5 ;SECTOR ADDRESS AS THE RANDOM
4218 ;SEED
4219 016760 010524 38: MOV R5,(R4)+ ;FIRST WORD OF EVERY SECTOR IS
4220 ;A WORD COUNT (2'S COMP) INDICATING #
4221 ;OF WORDS ACTUALLY WRITTEN IN THAT SECTOR
4222 016762 005205 INC R5 ;ALL DONE?
4223 016764 001427 BEQ 88
4224
4225 016766 004737 025576 48: JSR PC,@RAND ;GENERATE DATA WORDS
4226 016772 025754 RSDTL
4227 016774 012737 000002 017104 MOV #2,RCNT
4228 017A02 013737 025756 017106 MOV RSDTL,RNUM
4229 017A10 000406 BR 68
4230 017A12 005337 017104 58: DEC RCNT
4231 017A16 001763 BEQ 48
4232 017A20 013737 025754 017106 MOV RSDTL,RNUM
4233 017A26 005737 017106 68: TST RNUM
4234 017A32 001767 BEQ 56
4235 017A34 013724 017106 MOV RNUM,(R4)+ ;FILL THE BUFFER. DON'T USE
4236 017A40 005205 INC R5 ;ALL DONE?
4237 017A42 001351 BNE 48 ;NO
4238
4239 017A44 005703 88: TST R3 ;ANY MORE DATA WORDS (FOR
4240 017A46 001412 BEQ 108 ;REST OF THE SECTORS)?
4241 ;YES
4242 017A50 010246 MOV R2,=@SP
4243 017A52 042716 177760 BIC #177760,(SP) ;(ABSOLUTE DISK ADDRESS & ITS
    
```

```

4244 017A56 022726 000013      CMP      #13,(SP)+      ;COMPLEMENT) TO USE FOR
4245 017A62 011002              BNE      98             ;GENERATING DATA WORDS
4246 017A64 062702 000004      ADD      #4,R2         ;OF THE NEXT BLOCK
4247                                ;
4248 017A70 008202              98:     INC      R2     ;HI RANDOM SEED
4249 017A72 000712              BR       18
4250                                ;
4251 017A74 104418              108:    RESREG      ;RESTORE REGISTERS
4252 017A76 062705 000004      ADD      #4,R6         ;ADJUST RETURN ADDRESS
4253 017102 000305              RTS      R6            ;RETURN
4254                                ;
4255 017104 000000              RCNT:   0
4256 017106 000000              RNUM:   0
    
```

```

4257                                ;DATCHK
4258                                ;THIS ROUTINE IS ENTERED WHEN THE DATA THAT WAS READ FROM THE DISK IS TO
4259                                ;BE CHECKED. AT THE TIME OF ENTRY R3 CONTAINS THE OFFSET OF POINTER TO
4260                                ;THE ADDRESS OF THE PARAMETER LIST (RKCS,DA,NC,BA). DATA IS CHECKED IN
4261                                ;BLOCKS OF 1 SECTOR (400 WORDS). EACH BLOCK IS GENERATED USING THE SECTOR
4262                                ;ADDRESS (AND ITS COMPLEMENT) AS RANDOM SEEDS. WHEN A DATA MISCOMPARISON
4263                                ;OCCURS THE BUS ADDRESS, EXPECTED AND RECEIVED DATA ARE REPORTED,
4264                                ;
4265 017110 104414              DATCHK: SAVREG      ;SAVE R0-R5
4266 017112 016303 002032      MOV      PCNND(R3),R3 ;GET ADDRESS OF THE PARAMETER
4267                                ;TABLE
4268 017116 016304 000004      MOV      4(R3),R4     ;GET WORD COUNT (2'S COMP)
4269 017122 016305 000006      MOV      8(R3),R8     ;GET BUS ADDRESS
4270 017126 011301              MOV      (R3),R1      ;GET DISK ADDRESS
4271                                ;
4272 017130 010146              MOV      R1,*(SP)     ;
4273 017132 004737 022170      JSR      PC,CROTFL    ;ROTATE BITS 18,14,12 TO
4274                                ;0,1,2
4275 017136 012602              MOV      (SP)+,R2     ;POP OFF DRIVE # FROM THE STACK
4276 017140 006302              ASL      R2           ;
4277 017142 062702 001712      ADD      @DATER,R2   ;FORM THE ADDRESS OF DATA ERROR COUNT
4278                                ;FOR THIS DRIVE
4279 017146 012737 177764 001840      MOV      #14,RCOUNT   ;
4280 017154 011337 025756              MOV      (R3),RSDTN   ;CREATE RANDOM SEEDS TO
4281 017160 013737 025756 025754      MOV      RSDTN,RSDTL  ;BE USED FOR CHECKING DATA
4282 017166 005137 025754              COM      RSDTL
4283                                ;
4284 017172 022704 177400              18:     CMP      #400,R4    ;DATA IS CHECKED IN 1 SECTOR
4285 017176 003003              BGT      28           ;BLOCKS. EACH SECTOR IS GENERATED
4286 017200 010403              MOV      R4,R3       ;USING THAT SECTOR ADDRESS
4287 017202 005004              CLR      R4          ;AS THE RANDOM SEED
4288 017204 000404              BR       38
4289                                ;
4290 017206 062704 000400              28:     ADD      #400,R4
4291 017212 012703 177400              MOV      #400,R3
4292 017216 012500              38:     MOV      (R0)+,R0 ;SAVE THE FIRST WORD OF THE SECTOR.
4293                                ;FIRST WORD OF EVERY SECTOR IS A COUNT
4294                                ;(2'S COMP) INDICATING # OF WORDS ACTUALLY
4295                                ;WRITTEN IN THAT SECTOR
4296 017220 008200              INC      R0          ;INCREMENT COUNT OF # OF WORDS (WRITTEN)
4297                                ;IN THE SECTOR
4298 017222 008203              INC      R3          ;INCREMENT COUNT OF DATA WORDS TO BE CHECKED
4299 017224 001468              BEQ      148         ;BRANCH, IF DONE
4300                                ;
4301 017226 004737 025754              48:     JSR      PC,@RAND ;GENERATE RANDOM DATA WORD
4302 017232 025754              RSDTL
4303 017234 012737 000002 017104      MOV      #2,RCNT
4304 017242 013737 025756 017106      MOV      RSDTN,RNUM
4305 017250 000406              BR       108
4306 017252 005337 017104              98:     DEC      RCNT
4307 017256 001763              BEQ      48
4308 017260 013737 025754 017106      MOV      RSDTL,RNUM
4309 017266 008737 017106              108:    TST      RNUM
4310 017272 001767              BEQ      98
4311                                ;
4312 017274 005700              TST      R0
    
```

```

4313 017774 001401      BTW      88
4314 017700 005200      INC      RU
4315
4316 017702 023715 017106 58:  CMP      RNUM,(R5)      ;EXPCTD WORD = RECVN WORD?
4317 017706 001431      BEQ      88              ;YFS
4318
4319 017710 005700      TST      RO
4320 017712 001005      BNE      68
4321 017714 008715      TST      (R5)
4322 017716 001423      BEQ      88
4323 017720 005037 001164      CLR      $REG1
4324 017724 000403      BR       78
4325
4326 017726 013737 017106 001164 68:  MOV      RNUM,$REG1      ;SAVE EXPCTD DATA WORD
4327 017734 005212      INC      (R2)            ;INCRMNT DATA EROR COUNT FOR THIS DRIVE
4328 017736 008737 001540      TST      ECOUNT          ;STORE ONLY 12 (DEC) DATA ERRORS
4329 017742 001413      BEQ      88              ;IF MORE EXIT
4330 017744 010937 001162      MOV      R5,$REG0        ;SAVE ERROR SUB ADDRESS
4331 017750 011537 001166      MOV      (R5),$REG2      ;SAVE ERROR DATA WORD
4332 017754 010137 001170      MOV      R1,$REG3
4333 017760 004737 023226      JSR      PC,$TSDRV       ;SAVE DRIVE #, FOR TYPING SERIAL #
4334 017764 104023      ERROR    23              ;DATA (COMPARISON) ERROR ON DOING
4335                                     ;READ FROM DISK NORMALLY ONLY 12 DATA
4336                                     ;ERRORS WILL BE REPORTED, THROUGH
4337                                     ;CHECKING WILL BE DONE, ERRORS
4338                                     ;EXCEEDING 12 WON'T BE REPORTED, IF
4339                                     ;YOU WANT MORE, CHANGE 'ECOUNT', TO
4340                                     ;WHATEVER # OF ERRORS YOU WANT REPORTED
4341 017766 005237 001540      INC      ECOUNT
4342
4343 017772 005725 88:  TST      (R5)+
4344 017774 005203      INC      R3
4345 017776 001313      BNE      46              ;DONE CHECKING?
4346
4347 017700 005704 148:  TST      R4
4348 017702 001427      BEQ      178             ;ANY MORE SECTOR BLOCKS
4349                                     ;TO CHECK? IF NOT, EXIT
4350 017704 010146      MOV      R1,=(SP)
4351
4352 017706 042716 177760      BIC      $177760,(SP)    ;GET THE NEW RANDOM SEEDS
4353 017712 022726 000013      CMP      #13,(SP)+      ;(ABSOLUTE DISK ADDRESS & ITS COMPLEMENT)
4354 017716 001002      BNE      156             ;TO USE FOR GENERATING DATA WORDS
4355 017720 062701 000004      ADD      #4,R1           ;OF THE NEXT BLOCK
4356
4357 017724 005201 158:  INC      R1
4358 017726 032777 000002 161564  BIT      $CSE,$RKRER    ;IF THERE WAS A CSE THEN CHECK
4359 017734 001403      BEQ      168             ;ONLY THOSE SECTORS THAT WERE READ
4360 017736 020177 161566      CMP      R1,$RKDA
4361 017742 001407      BEQ      178
4362 017744 010137 025756 168:  MOV      R1,$RDTH
4363 017750 010137 025754      MOV      R1,$RDTL
4364 017754 005137 025754      COM      $RDTL
4365 017760 000644      BR       18
4366 017762 104415 178:  RESREG
4367 017764 000207      RTS      PC              ;RESTORE R0=R5
    
```

```

4368                                     ;SBTTL ROUTINE TO SIZE MEMORY
4369
4370                                     ;*****
4371                                     ;CALL:
4372                                     ;* JSR PC,$SIZE
4373                                     ;* RETURN
4374                                     ;* $LSTAD WILL CONTAIN:
4375                                     ;* WITH KT11 OPTION == LAST VIRTUAL ADDRESS OF THE LAST BANK
4376                                     ;* WITHOUT KT11 OPTION == LAST ABSOLUTE ADDRESS OF AVAILABLE MEMORY
4377                                     ;* $LSTBK WILL CONTAIN THE LAST BANK AS A SAF
4378                                     ;* $KT11 IS THE MEMORY MANAGEMENT KEY
4379                                     ;* $BIT07 = 0 DON'T USE MEMORY MANAGEMENT
4380                                     ;* MUST BE SETUP BEFORE THE CALL
4381                                     ;* $BIT15 = 0 DON'T HAVE MEMORY MANAGEMENT OPTION
4382                                     ;* DETERMINED BY ROUTINE
4383
4384 017766 010046 8:SIZE: MOV      R0,=(SP)      ;SAVE R0 ON THE STACK
4385 017770 010146      MOV      R1,=(SP)      ;SAVE R1 ON THE STACK
4386 017772 010246      MOV      R2,=(SP)      ;SAVE R2 ON THE STACK
4387 017774 010346      MOV      R3,=(SP)      ;SAVE R3 ON THE STACK
4388 017776 013746 000004      MOV      $ERRVEC,=(SP) ;SAVE PRESENT ERROR VECTOR P8 & PC
4389 017780 013746 000006      MOV      $ERRVEC+2,=(SP)
4390 017786 010600      MOV      $P,RO         ;SAVE THE STACK POINTER
4391                                     ;SET THE ERRVEC P8 TO THE PRESENT P8
4392 017710 104400      TRAP
4393 017712 012637 000006      MOV      (SP)+,$ERRVEC+2 ;PUSH OLD P8 AND PC ON STACK
4394 017716 012701 003776      MOV      $3776,R1      ;SAVE THE P8 IN $ERRVEC+2
4395 017722 105727      TSTB    (PC)+          ;SETUP ADDRESS
4396 017724 000200      $KT11: $WORD 200       ;USE MEMORY MANAGEMENT?
4397 017726 100062      BPL     $SCORE         ;SET TO USE MEMORY MANAGEMENT
4398 017730 012737 017666 000006  $KTINEX,$ERRVEC ;BR IF NO
4399 017736 005737 177572      MOV      $8RO          ;SET FOR TIMEOUT
4400 017742 082737 100900 017524  TST      $KT11         ;KT11 ARE YOU THERE?
4401 017750 005046      CLR      $KT11         ;YES--SET KT11 KEY
4402 017752 012702 172340      MOV      $KIPAR0,R2    ;INITIALIZE FOR "PAR" LOADING
4403 017756 012703 000010      MOV      $D8,R3        ;ADDRESS OF "FIRST" "PAR"
4404 017762 012762 077406 177740 18:  MOV      $77406,=40(R2) ;LOAD EIGHT "PAR,"S" AND EIGHT "PDR,"S"
4405 017770 011622      MOV      (SP),(R2)+    ;PDR = 4K, UP, READ/WRITE
4406 017772 062716 000200      ADD      $200,(SP)     ;LOAD "PAR"
4407 017776 077307      SOB     R3,18          ;UPDATE FOR NEXT "PAR"
4408 017800 012742 177600      MOV      $177600,=(R2) ;LOOP UNTIL ALL EIGHT ARE LOADED
4409 017804 005042      CLR      =(R2)         ;SETUP KIPAR7 FOR I/O
4410 017806 012737 017624 000004  $28,$ERRVEC ;SETUP KIPAR6 FOR TESTING
4411 017814 012737 000020 172516  $20,$8R3 ;CATCH TIMEOUT IF NO SR3
4412 017822 000401      BR      38             ;ENABLE 22 BIT MODE
4413 017824 022626 28:  CMP      (SP)+,(SP)+   ;THIS PDP-11 HAS A SR3 REGISTER
4414                                     ;CLEAN OFF THE STACK=NO SR3
4415
4414 017626 005237 177572 38:  INC      $8RO          ;TURN ON MEMORY MANAGEMENT
4415 017632 012737 017656 000004  MOV      $KTOUT,$ERRVEC ;SET FOR TIME OUT
4416 017640 005737 143776 48:  TST      $8143776     ;TRAP ON NON-EX-MEM
4417 017644 062712 000040      ADD      $40,(R2)      ;MAKE A 1K STEP
4418 017650 023712 172356      CMP      $KIPAR7,(R2)  ;LAST ONE?
4419 017654 101371      BHI     48             ;NO--TRY IT
4420 017656 011202 8KTOUT: MOV      (R2),R2        ;GET LAST BANK+1
4421 017660 005037 177572      CLR      $8RO          ;TURN OFF MEMORY MANAGEMENT
4422 017664 000421      BR      $8IZEX
4423 017666 042737 100000 017524 $KTINEX: BIC      $100000,$KT11 ;KT11 NON-EXISTENT
    
```

```

4424 017674 012737 017724 000004 SCORE: MOV #SCROUT, @ERRVEC ;SET FOR TIMEOUT
4425 017702 005002 CLN R2 ;SET UP BANK
4426 017704 062701 004000 181 ADD #4000,R1 ;INCREMENT BY 1K
4427 017710 062702 000040 ADD #40,R2 ;1K STEP
4428 017714 005711 TST (R1) ;TRAP ON TIME OUT
4429 017716 022701 177776 CMP #17776,R1 ;LAST ONE
4430 017722 001370 BNE 18 ;NO-TRY AGAIN
4431 017724 162701 004000 SCROUT: SUB #4000,R1
4432 017730 162702 000040 SSIZEX: SUB #40,R2 ;DROP BACK
4433 017734 010006 MOV R0,SP ;RESTORE THE STACK
4434 017736 012637 000006 MOV (SP)+, @ERRVEC+2 ;RESTORE ERROR VECTOR
4435 017742 012637 000004 MOV (SP)+, @ERRVEC
4436 017746 010137 017770 MOV R1, $LSTAD ;LAST ADDRESS
4437 017752 010237 017772 MOV R2, $LSTBK ;LAST BANK
4438 017756 012603 MOV (SP)+, R3 ;RESTORE R3
4439 017760 012602 MOV (SP)+, R2 ;RESTORE R2
4440 017762 012601 MOV (SP)+, R1 ;RESTORE R1
4441 017764 012600 MOV (SP)+, R0 ;RESTORE R0
4442 017766 000207 RTS PC
4443 017770 000000 $LSTAD: .WORD 0 ;CONTAINS THE LAST ADDRESS
4444 017772 000000 $LSTBK: .WORD 0 ;CONTAINS THE LAST BANK
    
```

```

4445 ;TYPD80
4446 ;THIS ROUTINE CONVERTS A VIRTUAL ADDRESS TO PHYSICAL ADDRESS AND TYPES
4447 ;OUT THE 6 DIGIT PHYSICAL ADDRESS. R2 CONTAINS VIRTUAL ADDRESS AT THE TIME
4448 ;OF ENTRY.
4449 ;TYPE OUT IS INHIBITED IF SW 13 IS SET.
4450
4451 017774 032777 020000 161136 TYPD80: BIT #SW13, @SWR ;INHIBIT TYPEOUT?
4452 020002 001042 BNE 28 ;YES
4453 020004 010346 MOV R3, -(SP)
4454 020006 010446 MOV R4, -(SP)
4455 020010 010846 MOV R5, -(SP)
4456
4457 020012 010246 MOV R2, -(SP) ;PUSH VA ON STACK
4458 020014 004737 022170 JSR PC, CROTLF ;ROTATE BITS 15,14,13 INTO 2,1,0
4459 020020 012603 MOV (SP)+, R3 ;FORM OFFSET TO BE USED
4460 020022 006303 ASL R3 ;FOR KIPAR
4461
4462 020024 016304 172340 MOV KIPAR(R3), R4 ;GET THE BASE PAGE ADDRESS FROM
4463 ;KIPAR
4464 020030 005003 CLR R3 ;ROTATE LEFT 6 TIMES (MULTIPLY
4465 020032 012708 177772 181 MOV #6, R5 ;BY 100 OCTAL) TO GET THE
4466 020036 006104 ROL R4 ;BASE SUB ADDRESS (PHYSICAL)
4467 020040 008208 INC R4 ;R3 CONTAINS HSB-2 BITS
4468 020042 001375 BNE 18
4469
4470
4471 020044 010246 MOV R2, -(SP) ;STRIP OFF TOP 3 BITS FROM VA &
4472
4473 020046 042716 160000 BIC #160000, (SP) ;GET THE OFFSET INSIDE THE PAGE
4474 020048 062604 ADD (SP)+, R4 ;FORM THE ENTIRE PHYSICAL
4475 020054 005503 ADC R3 ;ADDRESS, R4 CONTAINS LOWER 16 BITS
4476 ;R3 CONTAINS TOP 2 BITS
4477 020056 010437 001162 MOV R4, @REG0 ;SAVE LOWER 16 BITS OF PA
4478 020062 010337 001164 MOV R3, @REG1 ;SAVE TOP 2 BITS OF PA
4479 020066 012746 001162 MOV @REG0, -(SP) ;PUSH POINTER TO PA ON STACK
4480 020072 004737 024464 JSR PC, @SDB20 ;CONVERT THE 16 BIT BINARY
4481 ;ADDRESS TO OCTAL ASCII NUMBERS ON RETURN
4482 ;POINTER TO THE FIRST ASCII CHARACTERS
4483 ;IS ON STACK
4484 020076 004737 038014 JSR PC, @SUPR6 ;TYPE OUT THE OCTAL & DIGIT
4485 ;PHYSICAL ADDRESS.
4486
4487 020102 012608 MOV (SP)+, R6
4488 020104 012604 MOV (SP)+, R4
4489 020106 012603 MOV (SP)+, R3
4490
4491 020110 000207 281 RTS PC
    
```

```

4492 ;CHKCS
4493 ;THIS ROUTINE CHECKS IF BIT 15 OF RKCS WAS SET, IF IT WAS RETURN IS MADE TO
4494 ;THE ERROR MESSAGE FOLLOWING THE JSR CALL, IF NOT, THE ERROR MADE TO SKIP
4495 ;OVER THE ERROR MESSAGE.
4496
4497 020112 005777 161104 CHKCS: TST @RKCS ;BIT 15 SET?
4498 020116 100073 BPL COMRET ;NO
4499 020120 004737 022032 JSR PC,GT4RG ;YES, GET RKCS, ER, DS, DA
4500 020124 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4501
4502 ;CHKDA
4503 ;THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY, IF NOT, RETURN IS MADE
4504 ;TO THE ERROR MESSAGE FOLLOWING THE JSR CALL, IF YES, RETURN IS MADE TO
4505 ;SKIP OVER THE ERROR MESSAGE,
4506 ;AT THE TIME OF ENTRY, R2 CONTAINS THE EXPECTED RKDA.
4507
4508 020126 020277 161076 CHKDA: CMP R2,@RKDA ;DID RKDA INCREMENT CORRECTLY?
4509 020132 001485 BEQ COMRET ;YES
4510 020134 010237 001162 MOV R2,@REG0 ;GET EXPCTD RKDA
4511 020140 017737 161064 001164 MOV @RKDA,@REG1 ;GET RKDA RECVD
4512 020146 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4513
4514 ;CHKBA
4515 ;THIS ROUTINE CHECKS IF RKBA INCREMENTED CORRECTLY, IF NOT, RETURN IS MADE
4516 ;TO THE ERROR MESSAGE FOLLOWING THE JSR CALL, IF YES, RETURN IS MADE TO
4517 ;SKIP OVER THE ERROR MESSAGE.
4518 ;AT THE TIME OF ENTRY, R3 CONTAINS THE WORD COUNT (% OF WORDS TRANSFERRED)
4519 ;R4 CONTAINS THE BUS ADDRESS WHERE THE TRANSFER STARTED.
4520
4521 020150 000241 CHKBA: CLC
4522 020152 006103 ROL R3 ;FORM THE EXPCTD BUS ADDRESS
4523 020154 060304 ADD R3,R4
4524 020156 000241 CLC
4525 020160 006003 ROR R3
4526 020162 020477 161040 CMP R4,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4527 020166 001447 BEQ COMRET ;YES
4528 020170 010437 001162 MOV R4,@REG0 ;GET EXPCTD RKBA
4529 020174 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4530
4531 020176 017737 161024 001164 MOV @RKBA,@REG1 ;GET RKBA RECVD
4532
4533 ;CHKMEX
4534 ;THIS ROUTINE CHECKS THAT RKBA OVERFLOWED AND MEX BIT WAS SET IN RKCS (BIT 4)
4535 ;IF RKBA OVERFLOWED CORRECTLY, THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
4536 ;ERROR MESSAGE ON RETURN.
4537 020204 017746 161012 CHKMEX: MOV @RKCS,=(BP) ;GET RKCS
4538 020210 042716 177717 BIC #177717,(SP) ;GET MEX BITS 4,5
4539 020214 022726 000020 CMP #BIT4,(SP)+ ;CHECK BIT 4 SET?
4540 020220 001432 BEQ COMRET ;YES, OK
4541 020222 004737 022032 JSR PC,GT4RG ;SAVE RKCS,ER,DS,DA
4542 020226 000207 RTS PC ;RETURN
    
```

```

4543 ;CHKWC
4544 ;THIS ROUTINE CHECKS IF RWKC OVERFLOWED CORRECTLY AFTER A DATA TRANSFER
4545 ;IF IT DID NOT, RETURN IS MADE TO THE ERROR MESSAGE, IF IT DID, RETURN IS
4546 ;MADE TO SKIP OVER THE ERROR MESSAGE.
4547
4548 020230 005777 160770 CHKWC: TST @RWKC ;RWKC OVERFLOWED?
4549 020234 001424 BEQ COMRET ;YES
4550 020236 017737 160766 001162 MOV @RKDA,@REG0
4551 020244 017737 160754 001164 MOV @RWKC,@REG1
4552 020252 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4553
4554 ;CHKRWS
4555 ;THIS ROUTINE CHECKS IF R/W/S RDY BIT IN RKDS IS SET. IF IT IS NOT SET RETURN
4556 ;IS MADE TO THE ERROR MESSAGE FOLLOWING THE JSR CALL, IF IT IS, THE RETURN
4557 ;ADDRESS IS ADJUSTED TO SKIP OVER THE ERROR MESSAGE ON RETURN.
4558
4559 020254 032777 000100 160734 CHKRWS: BIT @RWS,@RKDS ;RWS RDY SET?
4560 020262 001011 BNE COMRET ;YES
4561 020264 004737 022032 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
4562 020270 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4563
4564 ;CHKCRDY
4565 ;THIS ROUTINE CHECKS IF CONTROL READY BIT IN RKCS IS SET, IF IT IS NOT,
4566 ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE JSR CALL, IF IT IS,
4567 ;RETURN ADDRESS IS ADJUSTED TO SKIP OVER THE ERROR MESSAGE.
4568
4569 020272 105777 160724 CHKCRDY: TSTB @RKCS ;CONTROL READY SET?
4570 020276 100403 BMI COMRET ;YES
4571 020280 004737 022032 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
4572 020284 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
4573
4574 COMRET: ADD #2,(BP) ;ADJUST RETURN ADDRESS TO SKIP OVER MESSAGE
4575 020312 000207 RTS PC
    
```

```

4579 ;THIS ROUTINE KEEPS A HISTORY OF THE COMMANDS THAT ARE BEING EXECUTED
4580 ;ON THE RK11. 'PRSFNC' CONTAINS INFORMATION ABOUT THE PRESENT COMMAND
4581 ;WHICH IS ABOUT TO BE INITIATED. 'PSTFNC' CONTAINS INFORMATION ABOUT THE
4582 ;COMMAND THAT WAS EXECUTED BEFORE THIS NEW ONE. THERE ARE MULTIPLE POINTS
4583 ;OF ENTRY DEPENDING ON THE TYPE OF COMMAND BEING PRESENTLY INITIATED:
4584
4585 ;DRCMND = ENTERED WHEN A DRIVE RESET IS BEING INITIATED. DRIVE # IS SAVED
4586 ;IN BITS 0-2 OF 'PRSCMND' AND BIT 8 IS SET.
4587
4588 ;CRCMND = ENTERED WHEN A CONTROL RESET IS BEING INITIATED. BIT 14 OF
4589 ;'PRSCMND' IS SET.
4590
4591 ;POSCMND = ENTERED WHEN A POSITIONING SEEK IS BEING INITIATED. BITS 0-2
4592 ;CONTAIN THE DRIVE NUMBER ON WHICH THE POSITIONING SEEK WAS DONE. ALSO
4593 ;BIT 7 IS SET.
4594
4595 ;IN ALL ABOVE CASES BIT 15 OF 'PRSCMND' IS SET.
4596
4597 ;FNCMND = ENTERED WHEN A COMMAND OTHER THAN ANY ONE OF THE ABOVE IS BEING
4598 ;INITIATED (EX: READ, WRITE, ETC).
4599 ;THE OFFSET TO THE COMMAND KEY (BASE=KEY) IS SAVED IN BITS 0-3 OF 'PRSCMND'.
4600
4601 ;IT SHOULD BE NOTED THAT CONTENTS OF 'PRSFNC' ARE PUSHED INTO 'PSTFNC'
4602 ;AND SAVED, BEFORE PUTTING INFO ABOUT THE PRESENT COMMAND IN 'PRSFNC'.
4603
4604 ;RO CONTAINS ADDRESS OF THE COMMAND KEY, AT THE TIME OF ENTRY.
4605
4606 020114 012737 100400 001512 DRCMND: MOV    $BITIS+BITS,QFNC
4607 020122 017746 160702          MOV    @RKA,=(SP)          ;SAVE DRIVE #
4608 020126 004737 022170          JBR   PC,CROTFL
4609 020132 052637 001812          BIS   (SP)+,QFNC
4610 020138 000424          BR    P2
4611
4612 020140 012737 140000 001512 CRCMND: MOV    $BITIS+BIT14,QFNC
4613 020146 000420          BR    P2
4614
4615 020150 011037 001512 POSCMND: MOV    (RO),QFNC
4616 020154 042737 177770 001512          BIC   $177770,QFNC          ;GET DRIVE NO.
4617 020162 052737 100200 001512          BIS   $BITIS+BIT7,QFNC
4618 020170 000407          BR    P2
4619
4620 020172 005037 001512 FNCMND: CLR   QFNC
4621 020176 010046 P1:  MOV    RO,=(SP)
4622 020400 162716          SUB   @KEY,(SP)
4623 020404 052637 001512          BIS   (SP)+,QFNC
4624
4625 020410 013737 001462 001464 P2:  MOV    PRSFNC,PSTFNC
4626 020416 013737 001512 001462          MOV   QFNC,PRSFNC
4627 020424 000207          RTS   PC
    
```

```

4628 ;HISTRY
4629 ;THIS ROUTINE TYPES OUT INFORMATION ABOUT THE FUNCTION THAT WAS
4630 ;BEING PERFORMED ON THE RK AT THE TIME OF ERROR AND THE FUNCTION
4631 ;THAT WAS PERFORMED JUST BEFORE THAT FUNCTION (WHICH LED TO
4632 ;THE ERROR). THIS ROUTINE IS CALLED WHEN AN ERROR OCCURS AND SW 12
4633 ;IS SET.
4634
4635 020426 010046 HISTRY: MOV    RO,=(SP)
4636 020430 010146          MOV    R1,=(SP)
4637
4638 020432 012700 001462          MOV    @PRSFNC,RO
4639 020436 104401 020746          TYPE   ,MH1
4640 020442 104401 020772          TYPE   ,MH3
4641 020446 104401 020762          TYPE   ,MH2
4642 020452 005710 68:  TBT   (RO)
4643 020454 100053          BPL   36                      ;READ, READ CHECK, WRITE, WRITE CHECK, SEEK
4644 020456 105710          TSTB  (RO)
4645 020460 100427          BMI   26                      ;POSITIONING (SEEK)
4646 020462 032710 040000          BIT   $BIT14,(RO)
4647 020466 001014          BNE   16                      ;CONTROL RESET
4648
4649 020470 104401 020476          TYPE   ,688                    ;TYPE ASCIZ STRING
4650 020474 000410          BR    648                    ;GET OVER THE ASCIZ
4651
4652 020416 688:  ,ASCIZ /DRESET ON DRV /
4653 020416 000425 688:  BR    78
4654
4655 020420 16:  TYPE   ,678                    ;TYPE ASCIZ STRING
4656 020420 104401 020926          BR    668                    ;GET OVER THE ASCIZ
4657 020424 000404 668:  ,ASCIZ /CRESET/
4658 020436 000463 668:  BR    48
4659
4660 020440 28:  TYPE   ,698                    ;TYPE ASCIZ STRING
4661 020440 104401 020946          BR    688                    ;GET OVER THE ASCIZ
4662 020444 000412 688:  ,ASCIZ /POSITIONING DRIVE /
4663
4664 020572 78:  MOV    (RO),=(SP)
4665 020572 011046          BIC   $177770,(SP)          ;TYPE DRIVE NO.
4666 020574 042716          TIPOC
4667 020600 104402          BR    48
4668 020602 000441
4669
4670 020404 011001 36:  MOV    (RO),R1
4671 020406 016101 002032          MOV   PCMND(R1),R1          ;GO TYPE OUT THE FUNCTION
4672
4673 020412 016104 000002          MOV   2(R1),R4              ;BEING PERFORMED
4674 020416 004737 021736          JBR   PC,TYPFN
4675 020622 104401 020630          TYPE   ,718                    ;TYPE ASCIZ STRING
4676 020426 000403          BR    708                    ;GET OVER THE ASCIZ
4677
4678 708:  ,ASCIZ <18><12>/DA=/
4679
4680 020436 708:  MOV    (R1),=(SP)          ;TYPE OUT DISK ADDRESS
4681 020440 104402          TIPOC
4682 020442 104401 020680          TYPE   ,738                    ;TYPE ASCIZ STRING
4683 020446 000403          BR    728                    ;GET OVER THE ASCIZ
    
```

```

4684 ;;738: ,ASCIZ / BA#/
4685 728:
4686 020456 MOV 6(R1),-(SP)
4687 020456 016146 000006 TST (R0)+
4688 020462 104402 TYPOC
4689 020464 104401 020672 TYPE ,758 ;;TYPE ASCIZ STRING
4690 020470 000403 BR 748 ;;GET OVER THE ASCIZ
4691 ;;759: ,ASCIZ / WC#/
4692 748:
4693 020700 MOV 4(R1),-(BP)
4694 020700 016146 000004 TYPOC
4695 020704 104402
4696 020706 020027 001464 48: CHP R0,#PSTFNC
4697 020712 001410 BEQ 58
4698 020714 005720 TST (R0)+
4699 020716 104401 020746 TYPE ,MH1
4700 020722 104401 020775 TYPE ,MH4
4701 020726 104401 020762 TYPE ,MH2
4702 020732 000647 BR 68
4703 020734 104401 001213 58: TYPE ,%CRLF
4704 020740 012601 MOV (SP)+,R1
4705 020742 012600 MOV (SP)+,R0
4706 020744 000207 RTS PC
4707 020746 005015 052506 041516 MH1: ,ASCIZ <15><12>/FUNCTION /
4708 020754 044524 047117 000040 MH2:
4709 020762 042440 051122 051117 MH2: ,ASCIZ / ERROR /
4710 020770 000040
4711 020772 052101 000 MH3: ,ASCIZ /AT/
4712 020775 120 044522 051117 MH4: ,ASCIZ /PRIOR TO/
4713 021002 052080 000117
, EVEN
    
```

```

4714 ;STATSTC
4715 ;AT THE TIME OF ENTRY R1 CONTAINS THE DRIVE NUMBER FOR WHICH THE STATISTIC
4716 ;IS TO BE OBTAINED. R5 CONTAINS THE POINTER TO THE PARAMETER TABLE, FOR
4717 ;THE COMMAND EXECUTED ON THE ABOVE DRIVE. R4 CONTAINS THE FUNCTION CODE
4718 ;(WRITE, READ, ETC) FOR WHICH STATISTICS ARE TO BE TAKEN.
4719
4720 021006 010046 STATSTC;MOV R0,-(SP) ;PUSH R0, R2, R3 ONTO THE
4721 021010 010246 MOV R2,-(SP) ;STACK
4722 021012 010346 MOV R3,-(SP)
4723
4724 021014 005002 CLR R2
4725 021016 005701 TST R1 ;DRIVE 0?
4726 021020 001404 BEQ 28 ;FORM THE OFFSET FOR THE
4727 021022 062702 000004 16: ADD #4,R2 ;"WORDS XFERRED COUNTS"-
4728 021026 005301 DEC R1 ;NWRTL, NRDL
4729 021030 001374 BNE 18
4730 021032 016500 000004 28: MOV 4(R5),R0 ;GET WORD COUNT (RKWC) FROM
4731 021036 005400 NEG R0 ;THE PARAMETER TABLE
4732
4733 021040 005777 160156 TST @RKCS ;ANY ERROR DURING THE XFER?
4734 021044 100004 BPL 38
4735
4736 021046 017703 160152 MOV @RKWC,R3 ;YES,
4737 021052 005403 NEG R3 ;GET THE # OF WORDS THAT
4738 021054 160300 SUB R3,R0 ;WERE ACTUALLY X-FERRED
4739
4740 021056 022704 000002 38: CMP #2,R4 ;WRITE FUNCTION?
4741 021062 001005 BNE 58
4742
4743 021064 060062 001732 48: ADD R0,NWRTL(R2) ;YES, ADD THE # OF WORDS
4744 021070 005562 001734 ADC NWRTH(R2) ;XFERRED (WRITE)
4745 021074 000404 BR 68 ;NOTE IT'S 2=WORD COUNT LO, HI
4746
4747 021076 060062 001772 58: ADD R0,NRDL(R2) ;ADD THE # OF WORDS READ
4748 ;NOTE THAT WRT CHK,
4749 ;READ CHK ARE ALSO CONSIDERED TO BE 'READ'
4750 ;CARRY OVER TO THE HI WORD
4751 021102 005562 001774 ADC NRDH(R2)
4752
4753 021106 012603 68: MOV (SP)+,R3 ;POP R3,R2,R0 FROM THE STACK
4754 021110 012602 MOV (SP)+,R2
4755 021112 012600 MOV (SP)+,R0
4756 021114 000207 RTS PC
    
```

```

4757 ;REPSTAT
4758 ;THIS ROUTINE REPORTS ERROR STATISTICS AND DATA-TRANSFER STATISTICS.
4759
4760 021116 104401 002377 REPSTA: TYPE ,MSG26
4761 021122 013700 001264 MOV DRVPRS,R0
4762 021126 012701 001254 MOV #PDR,R1
4763
4764 021132 104401 001213 18: TYPE ,%CRLF
4765 021136 112102 MOV# (R1)+,R2
4766 021140 042702 177770 BIC #177770,R2
4767 021144 010246 MOV R2,-(SP)
4768 021146 104403 TYPDS
4769 021150 003 ,BYTE 3
4770 021151 000 ,BYTE 0
4771 021152 104401 002662 TYPE ,BLNK#3
4772
4773 021156 005004 CLR R4
4774 021160 010203 MOV R2,R3
4775 021162 001404 BEQ 38
4776 021164 062704 000004 28: ADD #4,R4
4777 021170 005303 DEC R3
4778 021172 001374 BNE 28
4779
4780 021174 104401 002664 38: TYPE ,BLNK#1
4781 021200 010446 MOV R4,-(SP)
4782 021202 062716 001732 ADD #NHRTL,(SP)
4783 021206 004737 024604 JBR PC,%DB2D
4784 021212 004737 025014 JBR PC,%SUPRS
4785 021216 104401 002664 TYPE ,BLNK#1
4786 021222 010446 MOV R4,-(SP)
4787 021224 062716 001772 ADD #NRDL,(SP)
4788 021230 004737 024604 JBR PC,%DB2D
4789 021234 004737 025014 JBR PC,%SUPRS
4790
4791 021240 006302 ASL R2
4792
4793 021242 104401 002664 TYPE ,BLNK#1
4794 021246 016246 001652 MOV CSECN(R2),-(SP)
4795 021252 104405 TYPDS
4796
4797 021254 104401 002664 TYPE ,BLNK#1
4798 021260 016246 001632 MOV WSECN(R2),-(SP)
4799 021264 104405 TYPDS
4800
4801 021266 104401 002664 TYPE ,BLNK#1
4802 021272 016246 001712 MOV DATER(R2),-(SP)
4803 021276 042716 100000 BIC #100000,(SP) ;DONT TYPE A NEGATIVE NO.
4804 021282 104405 TYPDS
4805
4806 021284 104401 002664 TYPE ,BLNK#1
4807 021290 016246 001562 MOV HECN(R2),-(SP)
4808 021296 104405 TYPDS
4809
4810 021298 005300 DEC R0 ;FINISHED WITH THE DRIVES ?
4811 021300 001304 BNE 18 ;BR IF NOT
4812 021322 104401 002474 TYPE ,MSG26A ;REST OF SUMMARY MESSAGE
    
```

```

4813 021326 013700 001264 MOV DRVPRS,R0 ;NUMBER OF DRIVES
4814 021332 012701 001254 MOV #PDR,R1 ;'DRIVES PRESENT' TABLE ADDRESS
4815 021336 104401 001213 48: TYPE ,%CRLF ;CR-LF
4816 021342 112102 MOV# (R1)+,R2 ;DRIVE ADDRESS
4817 021346 042702 177770 BIC #177770,R2 ;LEAVE ONLY DRIVE NUMBER
4818 021350 010246 MOV R2,-(SP) ;PUT ON STACK FOR TYPEOUT
4819 021352 104403 TYPDS ;TYPE IT IN OCTAL
4820 021354 003 ,BYTE 3 ;TYPE 3 CHARACTERS
4821 021355 000 ,BYTE 0 ;SUPPRESS LEADING ZEROS
4822 021356 104401 002662 TYPE ,BLNK#3 ;3 BLANKS
4823 021362 006302 ASL R2 ;CONVERT TO A WORD TABLE INDEX
4824 021364 104401 002664 TYPE ,BLNK#1
4825 021370 016246 001602 MOV WSECN(R2),-(SP)
4826 021374 104405 TYPDS
4827
4828
4829 021376 104401 002664 TYPE ,BLNK#1
4830 021402 016246 001672 MOV ABORT(R2),-(SP)
4831 021406 104405 TYPDS
4832
4833 021410 006202 ASR R2
4834 021412 104401 002664 TYPE ,BLNK#1
4835 021416 116246 001622 MOV# SINCN(R2),-(SP)
4836 021422 104405 TYPDS
4837
4838 021424 005300 DEC R0
4839 021426 001343 BNE 48
4840 021430 004737 026660 JBR PC,TIMTYP ;TYPE THE TIME
4841 021434 000207 RTS PC
    
```



```

4842 ;STATUS
4843 ;THIS ROUTINE IS NORMALLY ENTERED WHEN THE PROGRAM IS WAITING FOR THE
4844 ;CONTROLLER TO FINISH WHAT IT IS DOING, THERE ARE TWO DOUBLE PRECISION
4845 ;COUNTS KEPT IN THIS ROUTINE,
4846 ;CICNT,CICNT1
4847 ;THIS COUNT KEEPS TRACK OF HOW LONG THE CONTROLLER HAS BEEN BUSY AFTER
4848 ;A COMMAND WAS INITIATED, THE CONTROLLER SHOULD FINISH WHATEVER IT IS DOING
4849 ;BEFORE THIS COUNT EXPIRES, IF IT DOES NOT, THERE IS AN ERROR CONDITION AND
4850 ;IT IS SO REPORTED.
4851
4852 ;QSCNT
4853 ;THIS COUNT IS INITIALIZED EVERY TIME 8 COMMANDS ARE GENERATED, THE COUNT
4854 ;IS INCREMENTED EVERY TIME THIS ROUTINE IS ENTERED. ALL THE 8 COMMANDS
4855 ;SHOULD BE DONE BEFORE THIS COUNT EXPIRES, IF THEY DO NOT AN ERROR CONDITION
4856 ;IS REPORTED, THIS COUNT HAS BEEN KEPT PRIMARILY TO INSURE THAT THE PROGRAM
4857 ;DOES NOT GET CAUGHT IN AN INDEFINITE LOOP, BECAUSE OF AN ERROR CONDITION.
4858
4859 021436 005046 STATUS: CLR =(SP) ;DROP PRIORITY AND WAIT FOR INT
4860 021440 012746 021446 MOV #18,-(SP) ;RETURN FOR RTI
4861 021444 000002 RTI
4862
4863 ;NOTE THAT THE INTERRUPTS ARE ALLOWED ONLY
4864 ;AT CERTAIN PLACES IN THE PROGRAM, BECAUSE
4865 ;IT MAKES TROUBLESHOOTING OF FAILURES EASY,
4866 ;OTHER PLACES WHERE INTERRUPTS ARE ALLOWED
4867 ;TO TAKE PLACE:
4868 ;'CHFAPN', FIRST INTERRUPT AFTER ISSUING
4869 ;A SEEK FUNCTION.
4870 021446 005237 001460 18: INC QSCNT
4871 021452 001456 BEQ QEROR
4872 021454 105777 157542 TSTB @RKCS
4873 021460 100514 BMI CNOBSY
4874
4875 021462 005037 001466 CLR CICNT
4876 021466 012737 177761 001470 MOV #=-17,CICNT1
4877
4878 021474 105737 001534 CBSY: TSTB INTFLG ;FOR A NON-SEEK COMAND;
4879 ;INTFLG- BIT 7 IS SET, BITS 0-3 CONTAIN
4880 ;OFFSET TO THE COMMAND KEY (FROM KEY),
4881 ;FOR WHICH THIS INTERRUPT IS EXPCTD,
4882 ;WHEN THE INTERRUPT OCCURS & 'INTHND' IS
4883 ;ENTERED 'INTFLG' IS CLEARED.
4884 021400 001507 BEQ SEXIT
4885 021402 005237 001466 INC CICNT
4886 021406 001372 CBSY BNE CBSY
4887 021410 005237 001470 INC CICNT1
4888 021414 001367 BNE CBSY
4889
4890 ;TIMED OUT WHILE WAITING FOR THE INTRUPT.
4891 ;ONE OF THE COMMANDS DID NOT INTERRUPT
4892 021416 113700 001534 NIEROR: MOVB INTFLG,R0
4893 021422 042700 177760 BIC #177760,R0
4894 021426 010003 MOV R0,R3
4895 021530 062700 001306 ADD #KEY,R0
4896 021534 011037 001172 MOV (R0),#REG4
4897 021540 042737 177770 001172 BIC #177770,#REG4
    
```

```

4898 021446 013737 001172 001250 MOV #REG4,#RDRV ;GET DRIVE #, FOR TYPING SERIAL #
4899
4900 021554 104421 002245 TYPNEG ,MSG15 ;PRINT 'DRIVE # DIDN'T INTERRUPT AFTER'
4901 021460 016305 002032 MOV PC,MND(R3),R5
4902 021564 016504 000002 MOV 2(R5),R4
4903 021470 004737 021736 JSR PC,TYPFN
4904 021574 004737 022032 JSR PC,GT4RG
4905 021600 104025 ERROR 25 ;COMMAND TYPED OUT IN EROR MESSAGE DID
4906 ;NOT INTERRUPT ON COMPLETION,
4907 021402 052710 104000 B16 #BIT15+BIT11,(R0) ;INDICATE THAT FUNCTION IS ABORTED
4908 021406 000444 BR SEXIT
4909
4910
4911 021410 005037 001460 QEROR: CLR QSCNT ;REESTABLISH COUNT
4912 021414 004737 022032 JSR PC,GT4RG
4913 021420 104026 ERROR 26 ;ALL 8 COMMANDS SHOULD BE DONE BY NOW, TIMED
4914 ;OUT, THE PROGRAM IS WAITING FOR ONE OF THE
4915 ;COMMANDS IN THE Q TO BE FINISHED AND THIS
4916 ;DID NOT HAPPEN OR FOR SOME OTHER REASON THE
4917 ;'FINISHED' FLAG (BIT 15) OF ONE OF THE 8
4918 ;COMMAND KEYS WAS NOT SET, VARIOUS FLAGS 'POS'(-7)
4919 ;'BUSY'(-7), 'KEY'(-8) CONTAIN INFORMATION
4920 ;ABOUT THE STATUS OF THE SYSTEM.
4921
4922 021422 032777 020000 157310 BIT #6W13,@SWR ;INHIBIT TYPEOUT?
4923 021630 001024 BNE 24 ;YES
4924 021432 104401 002305 TYPE, MSG16
4925 021436 012700 001306 MOV #KEY,R0
4926 021442 012701 001426 MOV #BUSY,R1
4927 021446 012702 177770 MOV #=-10,R2
4928 021452 104401 001213 18: TYPE ,@CRUF
4929 021456 012046 MOV (R0)+,-(SP) ;TYPE OUT CONTENTS OF ALL KEYS
4930 021460 104402 TYPCC ;KEY-KEYS
4931 021462 104401 002662 TYPE ,BLNKS3
4932 021466 005046 CLR -(SP)
4933 021470 112116 MOVB (R1)+,(SP) ;TYPE OUT CONTENTS OF ALL BUSY FLAGS
4934 021472 104403 TYPOS ;BUSY-BUSY?
4935 021474 003 ,BYTE 3
4936 021475 000 ,BYTE 0
4937 021476 005202 INC R2 ;DONE?
4938 021700 001364 BNE 18 ;NO
4939
4940 021702 004737 016006 -28: JSR PC,CLRERR ;MAKE SURE THERE IS NO HEAD MOVEMENT ON
4941 ;ANY DRIVE & THEN DO CONTROL RESET
4942 021706 000137 010630 JMP BEGNEX ;GO, BAK AND CONTINUE
4943
4944 021712 005004 CNOBSY: CLR R4
4945 021714 005204 INC R4
4946 021716 001376 BNE ,=-2
4947 021720 013746 001244 SEXIT: MOV #PRLVL,-(SP)
4948 021724 012746 021732 MOV #RTIPC7,-(SP) ;RETURN FOR RTI *****
4949 021730 000002 RTI
4950
4951 021732 000137 010650 RTIPC7: JMP QMNGER
    
```

```

4952 ;TYPFN
4953 ;ROUTINE TO TYPE OUT THE FUNCTION (READ,WRITE,ETC) ;R4 CONTAINS THE
4954 ;FUNCTION CODE AT THE TIME OF ENTRY.
4955 ;SW 13, IF SET INHIBITS TYPEOUT.
4956
4957 021736 032777 020000 187174 TYPFN: HIT SW13,SW13 ;INHIBIT TYPEOUT?
4958 021744 001031 BNE SW ;YES
4959 021746 020427 000002 CMP R4,SW ;WRITE?
4960 021752 001002 BNE SW
4961 021754 104401 002133 TYPE ,MAG6
4962 021760 022704 000004 18: CMP R4,R4 ;READ?
4963 021764 001002 BNE SW
4964 021766 104401 002141 TYPE ,MAG7
4965 021772 022704 000012 28: CMP R12,R4 ;READ CHECK?
4966 021776 001002 BNE SW
4967 022000 104401 002156 TYPE ,MAG9
4968 022004 022704 000006 38: CMP R6,R4 ;WRITE CHECK?
4969 022010 001002 BNE SW
4970 022012 104401 002146 TYPE ,MAG8
4971 022016 022704 000010 48: CMP R10,R4 ;SEEK?
4972 022022 001002 BNE SW
4973 022024 104401 002201 TYPE ,MAG11
4974 022030 000207 58: RTS PC
  
```

```

4975 ;GT4RG
4976 ;GET CONTENTS OF RKCS, RKER, RKDS, RKDAA
4977
4978 022032 017737 157172 001170 GT4RG: MOV BRKDA,REG3
4979 022040 017737 157156 001162 GT4RG: MOV BRCS,REG0
4980 022046 017737 157146 001164 MOV BRKER,REG1
4981 022054 017737 157136 001166 MOV BRKDS,REG2
4982 022062 000207 RTS PC
4983
4984
4985 ;GETINF
4986 ;THIS ROUTINE GETS CONTENTS OF RKCS, RKER, RKDS, THEN IT BREAKS DOWN THE
4987 ;CONTENTS OF RKDA INTO ITS COMPONENT; CYLINDER, SECTOR, SURFACE AND DRIVE
4988 ;NUMBER.
4989
4990 022064 004737 022040 GETINF: JBR PC,GT4RG
4991 022070 010046 MOV R0,=(SP)
4992 022072 010146 MOV R1,=(SP)
4993 022074 010246 MOV R2,=(SP)
4994 022076 012700 001200 MOV ,REG6+2,R0
4995 022082 017701 157122 MOV BRKDA,R1
4996 022106 010102 MOV R1,R2
4997 022110 042702 177760 BIC ,177760,R2
4998 022114 010240 MOV R2,=(R0)
4999 022116 006201 ABR R1
5000 022120 006201 ABR R1
5001 022122 006201 ABR R1
5002 022124 006201 ABR R1
5003 022126 010102 MOV R1,R2
5004 022130 042702 177776 BIC ,177776,R2
5005 022134 010240 MOV R2,=(R0)
5006 022136 006201 ABR R1
5007 022140 010102 MOV R1,R2
5008 022142 042702 177400 BIC ,177400,R2
5009 022146 010240 MOV R2,=(R0)
5010 022150 006201 ABR R1
5011 022152 042701 177770 BIC ,177770,R1
5012 022156 010140 MOV R1,=(R0)
5013 022160 012602 MOV (SP)+,R2
5014 022162 012601 MOV (SP)+,R1
5015 022164 012600 MOV (SP)+,R0
5016 022166 000207 RTS PC
  
```

```

5017 ;CROTLF
5018 ;CALL: MOV #NO,=(SP) ;PUSH NO, TO BE ROTATED ON STACK
5019 ; JSR PC,CROTLF
5020 ;THIS ROUTINE ROTATES BITS 15, 14, 13 OF A WORD INTO BITS 2, 1, 0. THE
5021 ;REST OF THE BITS OF THE ROTATED WORD ARE CLEARED.
5022
5023
5024 022170 042766 017777 000002 CROTLF: BIC #17777,2(SP)
5025 022176 000241 CLC
5026 022100 006166 000002 ROL 2(SP)
5027 022104 006166 000002 ROL 2(SP)
5028 022110 006166 000002 ROL 2(SP)
5029 022114 006166 000002 ROL 2(SP)
5030 022120 000207 RTS PC
5031
5032
5033 ;RG4SDRV
5034 ;CALL: JSR PC,RG4SDRV
5035 ;THIS ROUTINE GETS THE CONTENTS OF RKDS, RKER, RKCS, RKDA, THEN
5036 ;IT SAVES THE DRIVE NUMBER FROM RKDA IN 'SRDRV'.
5037 022122 004737 022032 RG4SDR: JSR PC,GT4RG ;GET RKCS, ER, DS, DA
5038
5039
5040 ;GTSDRV
5041 ;CALL: JSR PC,GTSDRV
5042 ;THIS ROUTINE EXTRACTS THE DRIVE # FROM RKDA (BITS 15,14,13) AND SAVES
5043 ;IT IN "SRDRV" (BITS 0,1,2)
5044
5045 022126 017746 156776 GTSDRV: MOV @RKDA,=(SP) ;GET BITS 15,14,13 FROM RKDA
5046 022132 004737 022170 JSR PC,CROTLF
5047 022136 012637 001250 MOV (SP)+,SRDRV ;SAVE THE DRIVE #
5048 022142 000207 RTS PC
    
```

```

5049 ;SBTTL DRV,RESET = DRIVE RESET ROUTINE
5050 ;DRV,RESET = DRIVE RESET ROUTINE
5051 ;IF R/W/S RDY DOES NOT SET WITHIN A CERTAIN TIME OF DOING DRIVE RESET
5052 ;AN ERROR IS REPORTED.
5053
5054 022144 005037 022354 DR,RST: CLR TIMEOUT
5055 022150 013777 001502 156752 MOV @DRV,@RKDA
5056 022156 012777 000015 156736 MOV #15,@RKCS
5057 022164 104417 CON,RDY
5058 022166 032777 000100 156722 18: BIT #100,@RKDS ;DID R/W/S RDY SET?
5059 022174 001026 BNE 26 ;YES
5060 022176 012746 177760 MOV #-20,=(SP) ;NO, WAIT FOR R/W/S
5061 022102 005216 INC (SP)
5062 022104 001376 BNE ,=2
5063 022106 005726 TST (SP)+
5064 022110 005237 022354 INC TIMEOUT
5065 022114 001364 BNE 18
5066 022116 032777 020000 156614 BIT #SW13,@SWR ;INHIBIT TYPEOUT?
5067 022124 001012 BNE 26 ;YES
5068 022126 104401 001213 TYPE ,@CRLF ;TIMED OUT, R/W/S RDY DID NOT SET
5069 022132 104401 027746 TYPE ,EM4 ;REPORT ERROR
5070 022136 104401 002206 TYPE ,MSG12
5071 022142 011646 MOV (SP),=(SP)
5072 022144 162716 000002 SUB #2,(SP)
5073 022150 104402 TYP0C
5074 022152 000002 28: RTI
5075 022154 000000 TIMEOUT: 0
    
```

```

5076          .SBTTL CON,RESET - CONTROL RESET ROUTINE
5077          ;CON,RESET
5078          ;CONTROL RESET ROUTINE
5079          ;CON,RDY
5080          ;CONTROL READY ROUTINE
5081
5082 022156 012777 000001 156636 CN,RST: MOV    #1,@RKCS
5083 022164 005037 001472 CN,RDY: CLR    TIMER
5084 022170 105777 156626 1$! 7$TB  @RKCS      ;DID CONTROL RDY SET?
5085 022174 100451          BMI    2$      ;YES
5086 022176 012746 177750          MOV    #=30,-(SP) ;WAIT FOR CNTRL RDY
5087 022402 005216          INC    (SP)
5088 022404 001376          BNE    =-2
5089 022406 005726          TST    (SP)+
5090 022410 005237 001472          INC    TIMER
5091 022414 001365          BNE    1$
5092 022416 032777 020000 156514 BIT    #SW13,@SWR ;INHIBIT TYPEOUT?
5093 022424 001035          BNE    2$      ;YES
5094 022426 104401 002206          TYPE  ,MSG12    ;CNTRL RDY DID NOT SET, REPORT ERROR
5095 022432 011646          MOV    (SP),-(SP)
5096 022434 162716 000002          SUB    #2,(SP)
5097 022440 104402          TYPDC
5098 022442 104401 022450          TYPE  ,65$      ;TYPE ASCIZ STRING
5099 022446 000421          BR     64$      ;GET OVER THE ASCIZ
5100          ;65$: ,ASCIZ <15><12>/CONTROLLER NOT READY = RKCS=/
5101          64$:
5102 022512 017746 156504          MOV    @RKCS,-(SP)
5103 022516 104402          TYPDC
5104 022520 000002          2$: RTI
  
```

```

5105          .SBTTL TYPMSG - TYPE MESSAGE ROUTINE (SW13)
5106          ;TYPMSG
5107          ;THIS ROUTINE IS USED FOR MESSAGE TYPEOUTS, IF SW 13 IS SET THE TYPEOUT
5108          ;IS SKIPPED.
5109          ;CALL: TYPMSG
5110          ;      POINTER          ;POINTER TO THE ASCII MESSAGE STRING
5111
5112 022522 032777 020000 156410 TY,MSG: BIT    #SW13,@SWR ;INHIBIT TYPEOUT?
5113 022530 001005          BNE    2$      ;YES
5114 022532 017637 000000 022542          MOV    @(SP),1$ ;GET POINTER TO ASCII STRING
5115 022540 104401          TYPE
5116 022542 000000          1$: ,WORD  0
5117
5118 022544 062716 000002          2$: ADD    #2,(SP) ;ADJUST RETURN ADDRESS TO SKIP OVER POINTER
5119 022550 000002          RTI
  
```

```

5120          ,SBTTL KWSRVE = KW11L CLOCK SERVICE ROUTINE
5121          ;THIS ROUTINE SERVICES THE INTERRUPT FROM THE KW11L LINE CLOCK
5122          ;AND KEEPS TRACK OF ELAPSED TIME.
5123          ;KWCOUNT= CONTAINS CYCLES (PER SECOND) (2'S COMPLEMENT)
5124          ;KWSEC= CONTAINS SECONDS (2'S COMPLEMENT)
5125          ;KWMIN= CONTAINS MINUTES (2'S COMPLEMENT)
5126          ;KWHR= CONTAINS HOURS (2'S COMPLEMENT)
5127
5128 022552 005237 001560      KWSRVE: INC      KWCOUNT      ;COUNT 60 CPS
5129 022556 001401              BEQ      16          ;OVERFLOWED?
5130 022560 000002              RTI
5131 022562 012737 177704 001560 18:  MOV      #-60;,KWCOUNT ;RESET 60 CPS COUNT
5132 022570 005237 001556      INC      KWSEC      ;COUNT SECONDS
5133 022574 001401              BEQ      26          ;OVERFLOWED?
5134 022576 000002              RTI          ;RETURN
5135 022600 012737 177704 001556 28:  MOV      #-60;,KWSEC ;RESET "SECONDS" COUNT
5136 022606 005237 001554      INC      KWMIN      ;COUNT MINUTES
5137 022612 001005              BNE      36          ;OVERFLOWED?
5138 022614 012737 177704 001554  MOV      #-60;,KWMIN ;RESET "MINUTES" COUNT
5139 022622 005237 001552      INC      KWHR      ;COUNT HOURS
5140
5141 022626 000002              38:  RTI          ;RETURN
5142
5143
5144          ;WATIME
5145          ;ROUTINE PROVIDES SOME WAITING TIME.
5146
5147 022630 013746 022652      WATIME: MOV      26, -(SP) ;COUNTER VALUE
5148 022634 005237 022654      18:  INC      36          ;COUNT
5149 022640 001375              BNE      18          ;HANG IN THERE UNTIL COUNT WRAPS AROUND
5150 022642 005216              INC      (SP)       ;COUNT AGAIN
5151 022644 001373              BNE      18          ;GO THROUGH MINOR LOOP AGAIN
5152 022646 005726              TST      (SP)+      ;RESTORE THE STACK POINTER
5153 022650 000207              RTS      PC          ;RETURN
5154 022652 177730              28:  ,WORD 177730    ;VALUE FOR APPROX 15 SEC DELAY
5155 022654 000000              38:  ,WORD 0          ;"MINOR" LOOP COUNTER
  
```

```

5156          ;CHDPRS
5157          ;THIS ROUTINE CHECKS IF THERE ANY DRIVES PRESENT (ON LINE), IF THERE
5158          ;ARE, A RETURN IS MADE. IF THERE ARE NONE PRESENT, A MESSAGE IS PRINTED OUT.
5159          ;THE STACK POINTER IS RE-INITIATED TO 1100 AND CONTROL IS TRANSFERRED
5160          ;TO THE END OF PASS ROUTINE, $EOP, BEFORE PASSING CONTROL TO $EOP, SOME
5161          ;TIME IS KILLED (WATIME), THIS IS DONE TO KEEP THE NUMBER OF MESSAGES
5162          ;(END OF PASS #X) TO A SMALL AMOUNT.
5163
5164 022656 005737 001264      CHDPRS: TST      DRVPRS ;ANY DRIVES PRESENT?
5165 022662 001401              BEQ      18          ;NO
5166 022664 000207              RTS      PC          ;YES, EXIT
5167 022666 104401 002225      18:  TYPE ,MSG14 ;NO, GIVE A MESSAGE
5168 022672 004737 022630      JSR      PC,WATIME ;KILL SOME TIME
5169 022676 012706 001100      MOV      $STACK,SP ;REINITIALIZE STACK
5170 022702 000400              BR      $EOP       ;GO TO END OF PASS ROUTINE
5171
  
```

```

5172 .SBTTL END OF PASS ROUTINE
5173
5174 ;*****
5175 ;*INCREMENT THE PASS NUMBER ($PASS)
5176 ;*INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
5177 ;*IF THERE'S A MONITOR GO TO IT
5178 ;*IF THERE ISN'T JUMP TO BEGNEX
5179
5180 022704 $EOP:
5181 022704 000004 SCOPE
5182 022706 005037 CLR $STSNM ;ZERO THE TEST NUMBER
5183 022712 005237 001102 INC $PASS ;INCREMENT THE PASS NUMBER
5184 022716 042737 100000 001100 BIC #100000,$PASS ;DON'T ALLOW A NEG. NUMBER
5185 022724 005327 DEC (PC)+ ;LOOP?
5186 022726 000001 $EOPCT: ,WORD 1
5187 022730 003013 BGT $DOAGN ;YES
5188 022732 012737 MOV (PC)+,@(PC)+ ;RESTORE COUNTER
5189 022734 000001 $ENDCT: ,WORD 1
5190 022736 022726 $EOPCT
5191 022740 013700 000042 $GET42: MOV #42,R0 ;GET MONITOR ADDRESS
5192 022744 001405 REQ $DOAGN ;BRANCH IF NO MONITOR
5193 022746 000005 RESET ;CLEAR THE WORLD
5194 022750 004710 $ENDAD: JSR PC,(R0) ;GO TO MONITOR
5195 022752 000240 NOP ;SAVE ROOM
5196 022754 000240 NOP ;FOR
5197 022756 000240 NOP ;ACT11
5198 022760 $DOAGN:
5199 022760 000137 JMP @(PC)+ ;RETURN
5200 022762 010630 $RTNAD: ,WORD BEGNEX
  
```

```

5201 .SBTTL TTY INPUT ROUTINE
5202
5203 ;*****
5204 .ENABL LSH
5205
5206 ;*****
5207 ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
5208 ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
5209 ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
5210 ;*WHEN OPERATING IN TTY FLAG MODE.
5211 022764 022737 000176 001140 $CKSWR: CMP #SWREG,SWR ;IS THE SOFT-SWR SELECTED?
5212 022772 001074 BNE 156 ;BRANCH IF NO
5213 022774 105777 156144 TSTB @&TKS ;CHAR THERE?
5214 023000 100071 BPL 156 ;IF NO, DON'T WAIT AROUND
5215 023002 117746 156140 MOVB @&TKB,@(SP) ;SAVE THE CHAR
5216 023006 042716 177600 RIC #'C177,(SP) ;STRIP-OFF THE ASCII
5217 023012 022726 000007 CMP #7,(SP)+ ;IS IT A CONTROL G?
5218 023016 001062 BNE 156 ;NO, RETURN TO USER
5219 023020 123727 001134 000001 CMPR $AUTOB,#1 ;ARE WE RUNNING IN AUTO-MODE?
5220 023026 001456 REQ 156 ;BRANCH IF YES
5221
5222 023030 104401 023511 TYPE ,&CNTLG ;ECHO THE CONTROL-G ("G")
5223 023034 104401 023516 $GTSWR: TYPE ,&MSWR ;TYPE CURRENT CONTENTS
5224 023040 013746 000176 MOV SWREG,@(SP) ;SAVE SWREG FOR TYPEOUT
5225 023044 104402 TYPCC ;GO TYPE=OCTAL ASCII(ALL DIGITS)
5226 023046 104401 023527 TYPE ,&MNEW ;PROMPT FOR NEW SWR
5227 023052 005046 198: CLR -(SP) ;CLEAR COUNTER
5228 023054 005046 CLR -(SP) ;THE NEW SWR
5229 023056 105777 156062 78: TSTB @&TKS ;CHAR THERE?
5230 023062 100375 HPL 78 ;IF NOT TRY AGAIN
5231
5232 023064 117746 156056 MOVB @&TKB,@(SP) ;PICK UP CHAR
5233 023070 042716 177600 BIC #'C177,(SP) ;MAKE IT 7-BIT ASCII
5234
5235
5236
5237 023074 021627 000025 98: CMP (SP),#25 ;IS IT A CONTROL-U?
5238 023100 001005 BNE 106 ;BRANCH IF NOT
5239 023102 104401 023504 TYPE ,&CNTLU ;YES, ECHO CONTROL-U ("U")
5240 023106 062706 000006 208: ADD #6,SP ;IGNORE PREVIOUS INPUT
5241 023112 000757 BR 198 ;LET'S TRY IT AGAIN
5242
5243
5244 023114 021627 000015 108: CMP (SP),#15 ;IS IT A <CR>?
5245 023120 001022 BNE 168 ;BRANCH IF NO
5246 023122 005766 000004 TST 4(SP) ;YES, IS IT THE FIRST CHAR?
5247 023126 001403 BEQ 118 ;BRANCH IF YES
5248 023130 016677 000002 156002 MOV 2(SP),@SWR ;SAVE NEW SWR
5249 023136 062706 000006 118: ADD #6,SP ;CLEAR UP STACK
5250 023142 104401 001213 148: TYPE ,&SCRLF ;ECHO <CR> AND <LF>
5251 023146 123727 001135 000001 CMPCB @INTAG,#1 ;RE-ENABLE TTY KBD INTERRUPTS?
5252 023154 001003 BNE 156 ;BRANCH IF NOT
5253 023156 012777 000100 155760 MOV #100,@&TKS ;RE-ENABLE TTY KBD INTERRUPTS
5254 023164 000002 158: RTI ;RETURN
5255 023166 004737 024414 168: JSR PC,&TYPEC ;ECHO CHAR
5256 023172 021627 000060 CMP (SP),#60 ;CHAR < 0?
  
```

```

5287 023174 02420          HLT      188          ;;BRANCH IF YES
5288 023100 021427 000067  CMP      (SP),#67      ;;CHAR > 7?
5289 023104 003015          BGT      188          ;;BRANCH IF YES
5290 023106 042726 000060  HIC      #60,(SP)+     ;;STRIP-OFF ASCII
5291 023112 005766 000002  TST      2(SP)         ;;IS THIS THE FIRST CHAR
5292 023116 001403          BEQ      174          ;;BRANCH IF YES
5293 023120 006316          ASL      (SP)         ;;NO, SHIFT PRESENT
5294 023122 006316          ASL      (SP)         ;; CHAR OVER TO MAKE
5295 023124 006316          ASL      (SP)         ;; ROOM FOR NEW ONE,
5296 023126 005266 000002  174: INC      2(SP)         ;;KEEP COUNT OF CHAR
5297 023132 056616 177776  BLS      -2(SP),(SP)   ;;SET IN NEW CHAR
5298 023136 000707          BR       78          ;;GET THE NEXT ONE
5299 023140 104401 001212  188: TYPE    ,#QUES     ;;TYPE ?<CR><LF>
5300 023144 000720          BR       208        ;;SIMULATE CONTROL-U
5301
5302
5303
5304
5305
5306
5307
5308
5309
5310 023146 011646          ;RDCHR: MOV    (SP),-(SP) ;;PUSH DOWN THE PC
5311 023150 016666 000004 000002  MOV    4(SP),2(SP) ;;SAVE THE PS
5312 023156 105777 155662  18: TSTB   #8TKS      ;;WAIT FOR
5313 023162 100375          BPL     18          ;;A CHARACTER
5314 023164 117766 155636 000004  MOVB   #8TKB,4(SP) ;;READ THE TTY
5315 023172 042766 177600 000004  BIC    #'C<177>,4(SP) ;;GET RID OF JUNK IF ANY
5316 023180 026627 000004 000023  CMP    4(SP),#23    ;;IS IT A CONTROL-Q?
5317 023186 001013          BNE     38          ;;BRANCH IF NO
5318 023190 105777 155630  28: TSTB   #8TKS      ;;WAIT FOR A CHARACTER
5319 023194 100375          BPL     28          ;;LOOP UNTIL ITS THERE
5320 023196 117746 155624  MOVB   #8TKB,-(SP) ;;GET CHARACTER
5321 023202 042716 177600          BIC    #'C<177>,2(SP) ;;MAKE IT 7-BIT ASCII
5322 023206 026627 000021  CMP    (SP),#21    ;;IS IT A CONTROL-Q?
5323 023212 001366          BNE     28          ;;IF NOT DISCARD IT
5324 023214 000750          BR      18          ;;YES, RESUME
5325 023216 026627 000004 000140  38: CMP    4(SP),#140  ;;IS IT UPPER CASE?
5326 023218 002407          BLT     48          ;;BRANCH IF YES
5327 023220 026627 000004 000175  CMP    4(SP),#175  ;;IS IT A SPECIAL CHART?
5328 023222 003003          BGT     48          ;;BRANCH IF YES
5329 023224 042766 000040 000004  BIC    #40,4(SP)   ;;MAKE IT UPPER CASE
5330 023226 000002          RTI     48          ;;GO BACK TO USER
5331
5332
5333
5334
5335
5336
5337
5338
5339
5340 023166 010346          ;RDLIN: MOV    R3,-(SP) ;;SAVE R3
5341 023170 012703 023474  18: MOV    #8TTYIN,R3 ;;GET ADDRESS
5342 023174 022703 023504  28: CMP    #8TTYIN+8,,R3 ;;BUFFER FULL?

```

```

5313 023100 101405          BLOS    48          ;;BR IF YES
5314 023102 104410          RDCHR   ;;GO READ ONE CHARACTER FROM THE TTY
5315 023104 112613          MOVB   (SP)+,(R3)   ;;GET CHARACTER
5316 023106 122713 000177  108: CMPB   #177,(R3)   ;;IS IT A RUBOUT
5317 023112 001003          BNE     38          ;;SKIP IF NOT
5318 023114 104401 001212  48: TYPE    ,#QUES     ;;TYPE A "?"
5319 023120 000763          BR      18          ;;CLEAR THE BUFFER AND LOOP
5320 023122 111337 023472  38: MOVB   (R3),98     ;;ECHO THE CHARACTER
5321 023126 104401 023472          TYPE    ,98
5322 023132 122723 000015  CMPB   #15,(R3)+    ;;CHECK FOR RETURN
5323 023136 001356          BNE     28          ;;LOOP IF NOT RETURN
5324 023140 105063 177777          CLRB   -1(R3)      ;;CLEAR RETURN (THE 15)
5325 023144 104401 001214          TYPE    ,8LF       ;;TYPE A LINE FEED
5326 023150 012603          MOV    (SP)+,R3    ;;RESTORE R3
5327 023152 011646          MOV    (SP),-(SP)  ;;ADJUST THE STACK AND PUT ADDRESS OF THE
5328 023154 016666 000004 000002  MOV    4(SP),2(SP)  ;; FIRST ASCII CHARACTER ON IT
5329 023162 012766 023474 000004  MOV    #8TTYIN,4(SP)
5330 023170 000002          RTI     ;;RETURN
5331 023172 000          .BYTE  0          ;;STORAGE FOR ASCII CHAR. TO TYPE
5332 023173 000          .BYTE  0          ;;TERMINATOR
5333 023174 000010          .BLKB  8          ;;RESERVE 8 BYTES FOR TTY INPUT
5334 023104 052536 005015 000          .CNTLU: .ASCII  /"U/<15><12>
5335 023111 136 006507 000012          .CNTLG: .ASCII  /"G/<15><12>
5336 023116 005015 053523 020122          .M&WR: .ASCII  <15><12>/&WR = /
5337 023124 020075 000          .MNEW: .ASCII  / NEW = /
5338 023127 040 047040 053505          .MNEW: .ASCII  / NEW = /
5339 023134 036440 000040

```

```
5340          ,SBTTL READ AN OCTAL NUMBER FROM THE TTY
5341
5342          ;;*****
5343          ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
5344          ;*CHANGE IT TO BINARY.
5345          ;*CALL:
5346          ;*   RD OCT          ;;READ AN OCTAL NUMBER
5347          ;*   RETURN HERE    ;;LOW ORDER BITS ARE ON TOP OF THE STACK
5348          ;*                   ;;HIGH ORDER BITS ARE IN SHIOCT
5349
5350 023440 011646          BRD OCT: MOV   (SP),=(SP)          ;;PROVIDE SPACE FOR THE
5351 023442 016666          MOV   4(SP),2(SP)          ;;INPUT NUMBER
5352 023450 010046          MOV   RO,=(SP)          ;;PUSH RO ON STACK
5353 023452 010146          MOV   R1,=(SP)          ;;PUSH R1 ON STACK
5354 023454 010246          MOV   R2,=(SP)          ;;PUSH R2 ON STACK
5355 023456 104411          18:  RD LIN          ;;READ AN ASCII LINE
5356 023460 012600          MOV   (SP)+,RO          ;;GET ADDRESS OF 1ST CHARACTER
5357 023462 005001          CLR   R1          ;;CLEAR DATA WORD
5358 023464 005002          CLR   R2
5359 023466 112046          28:  MOVBS (RO)+,=(SP)          ;;PICKUP THIS CHARACTER
5360 023470 001412          SEQ   36          ;;IF ZERO GET OUT
5361 023472 006301          ABL  R1          ;;*2
5362 023474 006102          ROL  R2          ;;*4
5363 023476 006301          ABL  R1          ;;*8
5364 023480 006102          ROL  R2          ;;*16
5365 023482 006301          ABL  R1          ;;*32
5366 023484 006102          ROL  R2
5367 023486 042716          BIC  #'C',(SP)          ;;STRIP THE ASCII JUNK
5368 023412 063601          ADD  (SP)+,R1          ;;ADD IN THIS DIGIT
5369 023414 000764          BR   28          ;;LOOP
5370 023416 005726          38:  TST  (SP)+          ;;CLEAN TERMINATOR FROM STACK
5371 023420 010166          MOV   R1,12(SP)          ;;SAVE THE RESULT
5372 023424 010237          MOV   R2,SHIOCT
5373 023430 012602          MOV   (SP)+,R2          ;;POP STACK INTO R2
5374 023432 012601          MOV   (SP)+,R1          ;;POP STACK INTO R1
5375 023434 012600          MOV   (SP)+,RO          ;;POP STACK INTO RO
5376 023436 000002          RTI
5377 023440 000000          SHIOCT: ,WORD 0          ;;HIGH ORDER BITS GO HERE
```

```
5379          ,SBTTL READ A DECIMAL NUMBER FROM THE TTY
5380
5381          ;;*****
5382          ;*THIS ROUTINE WILL READ A DECIMAL (ASCII) NUMBER FROM THE TTY AND
5383          ;*CHANGE IT TO BINARY, IF TOO MANY CHARACTERS OR ANY ILLEGAL CHARACTERS
5384          ;*ARE READ A "?" FOLLOWED BY A CARRIAGE RETURN=LINE FEED WILL BE TYPED.
5385          ;*THE COMPLETE NUMBER MUST BE RETYPED, THE INPUT IS TERMINATED BY THE
5386          ;*USER TYPING A CARRIAGE RETURN, THE RANGE OF THE INPUT NUMBER IS
5387          ;*POSITIVE 32767 TO NEGATIVE 32768.
5388          ;*CALL:
5389          ;*   RD DEC          ;;READ A DECIMAL NUMBER
5390          ;*   RETURN HERE    ;;NUMBER IS ON TOP OF THE STACK
5391
5392 023442 011646          BRD DEC: MOV   (SP),=(SP)          ;;PROVIDE SPACE FOR
5393 023444 016666          MOV   4(SP),2(SP)          ;;THE INPUT NUMBER
5394 023452 010046          MOV   RO,=(SP)          ;;PUSH RO ON STACK
5395 023454 010146          MOV   R1,=(SP)          ;;PUSH R1 ON STACK
5396 023456 010246          MOV   R2,=(SP)          ;;PUSH R2 ON STACK
5397 023460 104411          18:  RD LIN          ;;READ AN ASCII LINE
5398 023462 012600          MOV   (SP)+,RO          ;;ADDRESS OF 1ST CHAR.
5399 023464 010037          MOV   RO,66          ;;SAVE IN CASE OF BAD INPUT
5400 023470 005046          CLR   -(SP)          ;;CLEAR DATA WORD
5401 023472 005002          CLR   R2          ;;SIGN SET POSITIVE
5402 023474 122710          000085          CMPB  #'-',(RO)          ;;SEE IF A MINUS SIGN WAS TYPED
5403 023700 001001          28:  SNE  28          ;;BR IF NO MINUS SIGN
5404 023702 112002          MOVBS (RO)+,R2          ;;SAVE FOR LATER USE
5405 023704 112001          MOVBS (RO)+,R1          ;;PICKUP THIS CHARACTER
5406 023706 001424          SEQ   38          ;;GET OUT IF ZERO
5407 023710 122701          000060          CMPB  #'0',R1          ;;MAKE SURE THIS CHARACTER
5408 023714 003032          BGT  58          ;;IS A DIGIT BETWEEN 0 & 9
5409 023716 122701          000071          CMPB  #'9',R1
5410 023722 002427          BLT  58
5411 023724 032716          170000          BIT  #'C7777,(SP)          ;;DON'T LET NUMBER GET TO BIG
5412 023730 001024          SNE  58          ;;BR IF NUMBER WOULD OVERFLOW
5413 023732 006316          ABL  (SP)          ;;*2
5414 023734 011646          MOV   (SP),=(SP)          ;;SAVE FOR LATER
5415 023736 006316          ABL  (SP)          ;;*4
5416 023740 006316          ABL  (SP)          ;;*8
5417 023742 062616          ADD  (SP)+,(SP)          ;;*16
5418 023744 102416          SVS  58          ;;OVERFLOW ISN'T ALLOWED
5419 023746 162701          000060          SUB  #'0',R1          ;;STRIP AWAY THE ASCII JUNK
5420 023752 060116          ADD  R1,(SP)          ;;ADD IN THIS DIGIT
5421 023754 102412          SVS  56          ;;OVERFLOW ISN'T ALLOWED
5422 023756 000752          BR   28          ;;LOOP
5423 023760 005702          38:  TST  R2          ;;CHECK IF NUMBER IS NEG
5424 023762 001401          BEQ  48          ;;BR IF NO
5425 023764 005416          NEG  (SP)          ;;YES=-NEGATE THE NUMBER
5426 023766 012666          48:  MOV   (SP)+,12(SP)          ;;SAVE THE RESULT
5427 023772 012602          MOV   (SP)+,R2          ;;POP STACK INTO R2
5428 023774 012601          MOV   (SP)+,R1          ;;POP STACK INTO R1
5429 023776 012600          MOV   (SP)+,RO          ;;POP STACK INTO RO
5430 024000 000002          RTI
5431
5432 024002 005736          58:  TST  (SP)+          ;;CLEAN PARTIAL NUMBER FROM STACK
5433 024004 105010          CLRB (RO)          ;;SET A TERMINATOR
```



5434	024006	104401			TYPE		;;TYPE THE INPUT UP TO BAD CHAR,
5435	024010	000000		88:	,WORD	0	;;POINTER GOES HERE
5436	024012	104401	001212		TYPE	,SQUES	;;"?" "CR" &"LF"
5437	024016	000720			MM	18	;;TRY AGAIN

```

5438          ,SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE
5439
5440          ;*****
5441          ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
5442          ;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT, DEPENDING ON WHETHER THE
5443          ;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
5444          ;BEFORE THE FIRST DIGIT OF THE NUMBER, LEADING ZEROS WILL ALWAYS BE
5445          ;REPLACED WITH SPACES.
5446          ;CALL:
5447          ;*   MOV      NUM,=(SP)          ;;PUT THE BINARY NUMBER ON THE STACK
5448          ;*   TYPDS          ;;GO TO THE ROUTINE
5449
5450          $TYPDS:
5451          024020          MOV      R0,=(SP)          ;;PUSH R0 ON STACK
5452          024022          MOV      R1,=(SP)          ;;PUSH R1 ON STACK
5453          024024          MOV      R2,=(SP)          ;;PUSH R2 ON STACK
5454          024026          MOV      R3,=(SP)          ;;PUSH R3 ON STACK
5455          024030          MOV      R5,=(SP)          ;;PUSH R5 ON STACK
5456          024032          012746          020200          MOV      #20200,=(SP)          ;;SET BLANK SWITCH AND SIGN
5457          024036          016605          000020          MOV      20(SP),R5          ;;GET THE INPUT NUMBER
5458          024042          100004          BPL          18          ;;BR IF INPUT IS POS.
5459          024044          005405          NEG      R5          ;;MAKE THE BINARY NUMBER POS.
5460          024046          112766          000055          000001          MOVB    #'-,1(SP)          ;;MAKE THE ASCII NUMBER NEG.
5461          024054          005000          CLR      R0          ;;ZERO THE CONSTANTS INDEX
5462          024056          012703          024234          MOV      #DBLK,R3          ;;SETUP THE OUTPUT POINTER
5463          024062          112723          000040          MOVB    R2,(R3)+          ;;SET THE FIRST CHARACTER TO A BLANK
5464          024066          005002          28:      CLR      R2          ;;CLEAR THE BCD NUMBER
5465          024070          016001          024224          MOV      #DTBL(R0),R1          ;;GET THE CONSTANT
5466          024074          160105          38:      SUB      R1,R5          ;;FORM THIS BCD DIGIT
5467          024076          002402          BLT          46          ;;BR IF DONE
5468          024100          005202          INC      R2          ;;INCREASE THE BCD DIGIT BY 1
5469          024102          000774          BR          38
5470          024104          060105          48:      ADD      R1,R5          ;;ADD BACK THE CONSTANT
5471          024106          005702          TST      R2          ;;CHECK IF BCD DIGIT=0
5472          024110          001002          BNE          58          ;;FALL THROUGH IF 0
5473          024112          105716          TSTB    (SP)          ;;STILL DOING LEADING 0'S?
5474          024114          100407          BMI          78          ;;BR IF YES
5475          024116          106316          58:      ASLB    (SP)          ;;MSD?
5476          024120          103003          BCC          68          ;;BR IF NO
5477          024122          116663          000001          177777          MOVB    1(SP),-1(R3)          ;;YES--SET THE SIGN
5478          024130          052702          000060          68:      BIS      #'0,R2          ;;MAKE THE BCD DIGIT ASCII
5479          024134          052702          000040          78:      BIS      #' ,R2          ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
5480          024140          110223          MOVB    R2,(R3)+          ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
5481          024142          005720          TST      (R0)+          ;;JUST INCREMENTING
5482          024144          020027          000010          CMP      R0,#10          ;;CHECK THE TABLE INDEX
5483          024150          002746          BLT      28          ;;GO DO THE NEXT DIGIT
5484          024152          003002          BGT      88          ;;GO TO EXIT
5485          024154          010502          MOV      R5,R2          ;;GET THE L&D
5486          024156          000764          BR          68          ;;GO CHANGE TO ASCII
5487          024160          105726          88:      TSTB    (SP)+          ;;WAS THE L&D THE FIRST NON-ZERO?
5488          024162          100003          BPL          98          ;;BR IF NO
5489          024164          116663          177777          177776          MOVB    -1(SP),-2(R3)          ;;YES--SET THE SIGN FOR TYPING
5490          024172          105013          98:      CLR      (R3)          ;;SET THE TERMINATOR
5491          024174          012605          MOV      (SP)+,R5          ;;POP STACK INTO R5
5492          024176          012603          MOV      (SP)+,R3          ;;POP STACK INTO R3
5493          024180          012602          MOV      (SP)+,R2          ;;POP STACK INTO R2

```

```

5494 024502 012501      MOV      (SP)+,R1      ;;POP STACK INTO R1
5495 024504 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
5496 024506 104401 024234  TYPE      ,#DBLK      ;;NOW TYPE THE NUMBER
5497 024512 016666 000002 000004  MOV      2(SP),4(SP)   ;;ADJUST THE STACK
5498 024520 012616      MOV      (SP)+,(SP)
5499 024522 000002      RTI
5500 024524 024420      ;DBTL: 10000.        ;;RETURN TO USER
5501 024526 001750      1000.
5502 024530 000144      100.
5503 024532 000012      10.
5504 024534 000004      ;DBLK: ,BLKW 4
    
```

```

5505      ;SBTTL TYPE ROUTINE
5506
5507      ;*****
5508      ;ROUTINE TO TYPE ASCIZ MESSAGE, MESSAGE MUST TERMINATE WITH A 0 BYTE,
5509      ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED,
5510      ;*NOTE1:  #NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER,
5511      ;*NOTE2:  #FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED,
5512      ;*NOTE3:  #FILLC CONTAINS THE CHARACTER TO FILL AFTER.
5513      ;*
5514      ;*CALL:
5515      ;#1) USING A TRAP INSTRUCTION
5516      ;# TYPE      ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
5517      ;*OR
5518      ;# TYPE
5519      ;# MESADR
5520      ;*
5521
5522 024544 105737 001157      ;TYPE: TSTB  #TPFLG      ;;IS THERE A TERMINAL?
5523 024550 100002      BPL 10      ;;BR IF YES
5524 024552 000000      HALT      ;;HALT HERE IF NO TERMINAL
5525 024554 000407      BR 30      ;;LEAVE
5526 024556 010046      10: MOV      RO,-(SP)      ;;SAVE RO
5527 024560 017600 000002      MOV      @2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING
5528 024564 112046      20: MOVB   (RO)+,-(SP)   ;;PUSH CHARACTER TO BE TYPED ONTO STACK
5529 024566 001005      BNE 40      ;;BR IF IT ISN'T THE TERMINATOR
5530 024570 005726      TST      (SP)+
5531 024572 012600 60: MOV      (SP)+,RO      ;;IF TERMINATOR POP IT OFF THE STACK
5532 024574 062716 000002      30: ADD      #2,(SP)      ;;RESTORE RO
5533 024580 000002      RTI      ;;ADJUST RETURN PC
5534 024582 122716 000011      40: CNPB   #HT,(SP)      ;;RETURN
5535 024584 001430      SEQ 00      ;;BRANCH IF <HT>
5536 024586 122716 000200      50: CNPB   #CRLF,(SP)     ;;BRANCH IF NOT <CRLF>
5537 024588 001006      BNE 50
5538 024590 005726      TST      (SP)+
5539 024592 104401      TYPE      ;;POP <CR><LF> EQUIV
5540 024594 001213      #CRLF     ;;TYPE A CR AND LF
5541 024596 105037 024460      CLR      #CHARCNT     ;;CLEAR CHARACTER COUNT
5542 024598 000755      BR 20      ;;GET NEXT CHARACTER
5543 024600 004737 024414      50: JBR     PC,#TYPEPC    ;;GO TYPE THIS CHARACTER
5544 024602 132726 001156      60: CNPB   #FILLC,(SP)+   ;;IS IT TIME FOR FILLER CHARS.?
5545 024604 001350      BNE 20      ;;IF NO GO GET NEXT CHAR.
5546 024606 013746 001154      MOV      #NULL,-(SP)  ;;GET # OF FILLER CHARS, NEEDED
5547      AND     THE NULL CHAR.
5548 024608 105366 000001      70: DECB   1(SP)          ;;DOES A NULL NEED TO BE TYPED?
5549 024610 002770      BLT 60      ;;BR IF NO--GO POP THE NULL OFF OF STACK
5550 024612 004737 024414      JBR     PC,#TYPEPC    ;;GO TYPE A NULL
5551 024614 105337 024460      DECB   #CHARCNT     ;;DO NOT COUNT AS A COUNT
5552 024616 000770      BR 70      ;;LOOP
5553
5554      ;HORIZONTAL TAB PROCESSOR
5555
5556 024618 112716 000040      80: MOVB   #' ,(SP)      ;;REPLACE TAB WITH SPACE
5557 024620 004737 024414      90: JBR     PC,#TYPEPC    ;;TYPE A SPACE
5558 024622 132737 000007 024460      BITB   #7,#CHARCNT   ;;BRANCH IF NOT AT
5559 024624 001372      BNE 90      ;;BRANCH IF NOT AT
5560 024626 005726      TST      (SP)+
    
```

```

5561 024412 000724          BP      28          ;;GET NEXT CHARACTER
5562 024414 105777 154530  STYPEC: T&T  0&TFS  ;;WAIT UNTIL PRINTER IS READY
5563 024420 100175          MPL      STYPEC
5564 024422 114677 000002 154522  MOVB   2(SP),0&TPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
5565 024430 122766 000015 000002  CMFB   0CR,2(SP)  ;;IS CHARACTER A CARRIAGE RETURN?
5566 024436 001003          BNE    18          ;;BRANCH IF NO
5567 024440 105037 024460  CLRB   0CHARCNT  ;;YES==CLEAR CHARACTER COUNT
5568 024444 000406          BR     STYPEX     ;;EXIT
5569 024446 122766 000012 000002 181  CMFB   0LF,2(SP)  ;;IS CHARACTER A LINE FEED?
5570 024454 001402          BEQ    STYPEX     ;;BRANCH IF YES
5571 024456 105227          INCB   (PC)+     ;;COUNT THE CHARACTER
5572 024460 000000          0      ;;CHARCNT, WORD
5573 024462 000207          STYPEX: RTS     ;;CHARACTER COUNT STORAGE
5574
    
```

```

5575          ,SBTTL  DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
5576
5577          ;*****
5578          ;THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
5579          ;UNSIGNED OCTAL ASCII NUMBER.
5580          ;CALL
5581          ;*   MOV   0PNTR,=(0SP)  ;; POINTER TO LOW WORD OF BINARY NUMBER
5582          ;*   JSR   PC,000DB20   ;; CALL THE ROUTINE
5583          ;*   RETURN              ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
5584
5585          0DB20: SAVREG
5586 024464 104414          MOV   2(0SP),R1  ;; SAVE ALL REGISTERS
5587 024466 016601 000002  MOV   0OCTVL+13,R5 ;; PICKUP THE POINTER TO LOW WORD
5588 024472 012705 024603  MOV   012,R4      ;; POINTER TO DATA TABLE
5589 024476 012704 000014  MOV   0C7,R4      ;; DO ELEVEN CHARACTERS
5590 024502 012703 177770  MOV   0C7,R3      ;; MASK
5591 024506 012100  MOV   (R1)+,R0    ;; LOWER WORD
5592 024510 012101  MOV   (R1)+,R1    ;; HIGH WORD
5593 024512 005002  CLR   R2          ;; TERMINATOR
5594 024514 110245 181:  MOVB  R2,=(R5)    ;; PUT CHARACTER IN DATA TABLE
5595 024516 010002  MOV   R0,R2       ;; GET THIS DIGIT
5596 024520 005304  DEC   R4          ;; COUNT THIS CHARACTER
5597 024522 003007  BGT   38          ;; BR IF NOT THE LAST DIGIT
5598 024524 001405  BEQ   28          ;; BR IF IT IS THE LAST DIGIT
5599 024526 005205  INC   R5          ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
5600 024530 010566 000002  MOV   R5,2(0SP)  ;; ASCII CHAR. & PUT IT ON THE STACK
5601 024534 104415  RESREG           ;; RESTORE ALL REGISTERS
5602 024536 000207  RTS   PC         ;; RETURN TO USER
5603 024540 006203 28:  ASR   R3         ;; POSITION THE MASK FOR THE LAST DIGIT
5604 024542 006001 38:  ROR   R1         ;; POSITION THE BINARY NUMBER FOR
5605 024544 006000          ROR   R0         ;; THE NEXT OCTAL DIGIT
5606 024546 006001          ROR   R1
5607 024550 006000          ROR   R0
5608 024552 006001          ROR   R1
5609 024554 006000          ROR   R0
5610 024556 040302          BIC   R3,R2      ;; MASK OUT ALL JUNK
5611 024560 062702 000060  ADD   00,R2      ;; MAKE THIS CHAR, ASCII
5612 024564 000753          BR    18         ;; GO PUT IT IN THE DATA TABLE
5613 024566 000016          0OCTVL: ,BLKB  14, ;; RESERVE DATA TABLE
    
```

```

5614          ,SBTTL  DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
5615
5616          ;*****
5617          ;THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
5618          ;DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
5619          ;POSITIVE.
5620          ;CALL
5621          ;*      MOV      $PTR,=(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
5622          ;*      JBR     PC,$$DBD2D      ;;
5623          ;*      RETURN                    ;; THE FIRST ADDRESS OF ASCII
5624          ;; IS ON THE STACK
5625
5626
5627 024404 104414          SDBD2D: SAVREG                    ;; SAVE REGISTERS
5628 024406 016602 000002  MOV      2(SP),R2                    ;; PICKUP THE DATA POINTER
5629 024412 012700 024764  MOV      $$DECVL,R0                    ;; GET ADDRESS OF "$DECVL" STRING
5630 024416 010066 000002  MOV      R0,2(SP)                    ;; PUT ADDRESS OF ASCII STRING ON STACK
5631 024422 012201          MOV      (R2)+,R1                    ;; PICKUP THE BINARY NUMBER
5632 024424 012202          MOV      (R2)+,R2
5633 024426 012737 000012 024702  MOV      #10,,48                    ;; SET UP TO DO 10 CONVERSIONS
5634 024434 012704 024714  MOV      $$TNPWR,R4                    ;; ADDRESS OF TEN POWER
5635 024440 012705 024716  MOV      $$TNPWR+2,R5
5636 024444 008003          16:  CLN      R3                    ;; CLEAR PARTIAL
5637 024446 161401          20:  SUB      (R4),R1                    ;; SUBTRACT TEN POWER
5638 024450 008402          SUB      R2
5639 024452 161502          SUB      (R5),R2
5640 024454 002402          BLT      38
5641 024456 008203          INC      R3                    ;; BR IF TEN POWER TO LARGE
5642 024460 000772          BR      28                    ;; ADD 1 TO PARTIAL
5643 024462 062401          36:  ADD      (R4)+,R1                    ;; LOOP
5644 024464 005502          ADC      R2                    ;; RESTORE SUBTRACTED VALUE
5645 024466 062402          ADD      (R4)+,R2
5646 024470 022523          CMP      (R5)+,(R5)+            ;; MOVE TO NEXT TEN POWER
5647 024472 052703 000060  BIS      #0,R3                    ;; CHANGE PARTIAL TO ASCII
5648 024476 110320          MOVW    R3,(R0)+                ;; SAVE IT
5649 024700 005327          DEC      (PC)+                    ;; DONE?
5650 024702 000000          48:  ,WORD  0
5651 024704 001357          BNE     18                    ;; BR IF NO
5652 024706 105020          CLRB   (R0)+                    ;; TERMINATOR
5653 024710 104415          RESREG
5654 024712 000207          RTS      PC                    ;; RESTORE REGISTERS
5655 024714 148000          $TNPWR: 148000                    ;; RETURN
5656 024716 035632          35632
5657 024720 160400          ;; 1.0E00
5658 024722 002765          2765
5659 024724 113200          ;; 1.0E07
5660 024726 000230          230
5661 024730 041100          ;; 1.0E06
5662 024732 000017          17
5663 024734 103240          ;; 1.0E08
5664 024736 000001          1
5665 024740 023420          ;; 1.0E04
5666 024742 000000          0
5667 024744 001750          ;; 1.0E03
5668 024746 000000          0
5669 024750 000144          144          ;; 1.0E02
    
```

```

5670 024752 000000          0
5671 024754 000012          12          ;; 1.0E01
5672 024756 000000          0
5673 024760 000001          1          ;; 1.0E00
5674 024762 000000          0
5675 024764 000014          SDECVL: ,BLKB 12,          ;; RESERVE STORAGE FOR ASCII STRING
    
```

```

5676          ,SBTTL SUPRS = TYPE NUMERICAL ASCII STRING, REPLACE LEADING 0'S BY BLANKS
5677          ,SBTTL SUPRSL = TYPE NUMERICAL ASCII STRING, LEFT JUSTIFY
5678          ;NOT FROM SYBMAC
5679
5680 025A00 010046          SUPRSL: MOV    R0,=(SP)          ;SAVE R0
5681 025A02 005037 025070 CLR    SUP2
5682 025A06 016600 000004 MOV    4(SP),R0
5683 025A12 010405          BR     SUP1
5684
5685 025A14 010046          SUPRS: MOV    R0,=(SP)          ;SAVE R0
5686 025A18 016600 000004 MOV    4(SP),R0      ;PICKUP THE POINTER
5687 025A22 010037 025070 MOV    R0,SUP2      ;SAVE FOR TYPING
5688 025A26
5689 025A26 105710          SUP1: 18:  TSTB   (R0)          ;TERMINATOR?
5690 025A30 001406          BEQ    28           ;BR IF YES
5691 025A32 122710 000060 CMPB   #'0,(R0)     ;IS THIS AN ASCII "0"?
5692 025A36 001006          BNE    48           ;NO
5693 025A40 112720 000040 MOVB   #'0,(R0)+   ;REPLACE IT WITH "BLANK"
5694 025A44 000770          BR     18
5695 025A46 009300          28:  DEC    R0          ;BACKUP BY 1
5696 025A80 112710 000060 MOVB   #'0,(R0)     ;ASCII "0"
5697 025A54 005737 025070 48:  TST   SUP2        ;LEFT JUSTIFY?
5698 025A60 001002          BNE    58           ;NO
5699 025A62 010037 025070 MOV    R0,SUP2      ;YES
5700 025A66 104401          58:  TYPE   0          ;GO TYPE
5701 025A70 000000          SUP2: ,WORD  0
5702 025A72 012800          MOV    (SP)+,R0    ;RESTORE R0
5703 025A74 012816          MOV    (SP)+,(SP) ;RESTORE THE STACK
5704 025A76 000207          RTS    PC          ;RETURN
    
```

```

5705          ,SBTTL INTEGER MULTIPLY ROUTINE
5706
5707          ;*****
5708          ;CALL
5709          ;* MOV    MULTIPLIER,=(SP)
5710          ;* MOV    MULTIPLICAND,=(SP)
5711          ;* JSR    PC,##MULT
5712          ;* RETURN ;;PRODUCT IS ON THE STACK
5713          ;*
5714          ;* STACK PRODUCT
5715          ;* -----
5716          ;* TOP    LSB'S
5717          ;* +2    HSB'S
5718
5719 025100          #MULT:
5720 025100 010046          MOV    R0,=(SP)    ;;PUSH R0 ON STACK
5721 025102 010146          MOV    R1,=(SP)    ;;PUSH R1 ON STACK
5722 025104 010246          MOV    R2,=(SP)    ;;PUSH R2 ON STACK
5723 025106 005046          CLR    -(SP)       ;;CLEAR THE SIGN KEY
5724 025110 016601 000012 MOV    12(SP),R1    ;;GET THE MULTIPLICAND
5725 025114 100002          BPL    18           ;;BR IF PLUS
5726 025116 005216          INC    (SP)        ;;SET THE SIGN KEY
5727 025120 005401          NEG    R1          ;;MAKE THE MULTIPLICAND POSITIVE
5728 025122 016602 000014 18:  MOV    14(SP),R2    ;;GET THE MULTIPLIER
5729 025126 100002          BPL    28           ;;BR IF PLUS
5730 025130 005316          DEC    (SP)        ;;UPDATE THE SIGN KEY
5731 025132 005402          NEG    R2          ;;MAKE THE MULTIPLIER POSITIVE
5732 025134 012746 000021 28:  MOV    #'1,=(SP)   ;;SET THE LOOP COUNT
5733 025140 005000          CLR    R0          ;;SETUP FOR THE MULTIPLY LOOP
5734 025142 103001          BCC    48           ;;DON'T ADD IF MULTIPLICAND = 0
5735 025144 060200          ADD    R2,R0
5736 025146 006000          48:  ROR    R0          ;;POSITION THE PARTIAL PRODUCT AND
5737 025150 006001          ROR    R1          ;;THE MULTIPLICAND
5738 025152 005316          DEC    (SP)        ;;HAS ALL BITS OF THE MULTIPLICAND BEEN DONE?
5739 025154 001372          BNE    38           ;;BR IF NO
5740 025156 022616          CMP    (SP)+,(SP) ;;SHOULD PRODUCT BE NEGATIVE?
5741 025160 001403          BEQ    58           ;;GO TO EXIT IF NO
5742 025162 005400          NEG    R0          ;;YES--SO MAKE IT SO
5743 025164 005401          NEG    R1
5744 025166 005600          SBC    R0
5745 025170 005726          38:  TST   (SP)+       ;;CLEAR SIGN INFO, OFF OF STACK
5746 025172 010066 000012 MOV    R0,12(SP)    ;;PUT THE PRODUCT ON THE STACK (HSB'S)
5747 025176 010166 000010 MOV    R1,10(SP)    ;;LSB'S
5748 025202 012602          MOV    (SP)+,R2    ;;POP STACK INTO R2
5749 025204 012601          MOV    (SP)+,R1    ;;POP STACK INTO R1
5750 025206 012600          MOV    (SP)+,R0    ;;POP STACK INTO R0
5751 025210 000207          RTS    PC
    
```

```

,SBTTL INTEGER DIVIDE ROUTINE
3752
3753
3754 ;*CALL:
3755     MOV     LOW DIVIDEND,=(BP)      ;THE HIGH DIVIDEND MUST BE < 1/2
3756     MOV     HIGH DIVIDEND,=(BP)    ; AS LARGE AS THE DIVISOR
3757     MOV     DIVISOR,=(BP)
3758     JSR     PC,SDIV
3759     RETURN
3760     ;*      QUOTIENT & REMAINDER ARE ON THE STACK
3761     ;*      *V*=0
3762     ;*      *V*=1 IMPLIES NO ERROR
3763     ;*      *C*=0 DIVIDE OVERFLOW OCCURRED
3764     ;*      *C*=1 ATTEMPTED TO DIVIDE BY ZERO
3765
3766     ;*      STACK NO ERROR OVERFLOW DIVIDE BY ZERO
3767     ;*      -----
3768     ;*      TOP REMAINDER ALL ZEROS ALL ONES
3769     ;*      +2 QUOTIENT ALL ZEROS ALL ONES
3770
3771     025712 013748 000034 000034 8DIV: MOV     34,=(BP)      ;SAVE CURRENT TRAP VECTOR
3772     025716 012737 028226 000034  MOV     #18,34      ;SET UP TRAP VECTOR
3773     025724 104400  TRAP
3774     025726 012716 028280 18:  MOV     #28,(BP)    ;REPLACE NEW PC
3775     025732 018637 000004 000034  MOV     4(BP),34    ;RESTORE OLD TRAP VECT
3776     025740 016688 000002 000004  MOV     2(BP),4(BP) ;SAVE PSW
3777     025746 000002  RTI      ;RESTORE PSW
3778
3779     025750 042716 000017 28:  BIC     #17,(BP)    ;STRIP AWAY CONDITION CODES
3780     025754 010046  MOV     R0,=(BP)   ;PUSH R0 ON STACK
3781     025756 010146  MOV     R1,=(BP)   ;PUSH R1 ON STACK
3782     025760 010246  MOV     R2,=(BP)   ;PUSH R2 ON STACK
3783     025762 010346  MOV     R3,=(BP)   ;PUSH R3 ON STACK
3784     025764 008046  CLR     =(BP)      ;SAVE A PLACE FOR SIGN
3785     025766 012746 000021  MOV     #17,=(BP)  ;SETUP THE ITERATION COUNTER
3786     025772 018601 000024  MOV     24(BP),R1  ;PICKUP THE DIVIDEND
3787     025776 016600 000022  MOV     22(BP),R0
3788     025780 100005  SBL     38
3789     025784 105386 000003  DECB   3(BP)      ;CHECK THE SIGN
3790     025788 005400  NEG     R0         ;KEEP TRACK OF THE SIGN
3791     025792 005401  NEG     R1         ;AND NEGATE THE ORIGINAL
3792     025794 005600  SBC     R0         ;NUMBER
3793     025796 018602 000020 30:  MOV     20(BP),R2  ;PICKUP THE DIVISOR
3794     025798 022702 000001  CMP     #1,R2     ;IF THE DIVISOR IS 1 SKIP THE REST
3795     025800 001463  BEQ     138
3796     025802 008702  TST     R2
3797     025804 002407  BLT     48
3798     025806 003011  BGT     58
3799     025808 032766 000003 000014  BIS     #3,14(BP) ;CHECK THE SIGN
3800     025810 012700 177777  MOV     #-1,R0    ;DIVISOR OF 0 IS A NO-NO
3801     025812 000424  BR      98        ;SET *V* & *C*
3802     025814 005266 000002 48:  INC     2(BP)     ;SET REMAINDER TO ALL ONES
3803     025816 000401  BR      68
3804     025818 005402 58:  NEG     R2
3805     025820 000241 68:  CLC
3806     025822 000405  BR      98        ;NEGATE THE ORIGINAL NUMBER
3807     025824 006100 78:  ROL     R0
3808     ;*      ;CLEAR *C*
3809     ;*      ;START FORMING QUOTIENT
3810     ;*      ;POSITION MSB'S

```

```

3808     025770 010003  MOV     R0,R3     ;COPY
3809     025772 060203  ADD     R2,R3     ;COMPARE DIVIDEND & DIVISOR
3810     025774 103001  SBC     #6
3811     025776 010300  MOV     R3,R0
3812     025778 006101 88:  ROL     R1
3813     025780 005316  DEC     (BP)
3814     025782 001370  SNE     76
3815     025784 005701  TST     R1
3816     025786 100005  SBL     108
3817     025788 052766 000002 000014  BIS     #2,14(BP) ;BR IF NO
3818     025790 005000  CLR     R0
3819     025792 010001 98:  MOV     R0,R1
3820     025794 005726 108:  TST     (BP)+
3821     025796 005716  TST     (BP)
3822     025798 002004  BGE     118
3823     025800 005400  NEG     R0
3824     025802 105066 000001  CLRB   1(BP)     ;REMAINDER AFTER THIS LOOP
3825     025804 005316  DEC     (BP)     ;QUOTIENT BIT ENTERS HERE
3826     025806 005726 118:  TST     (BP)+
3827     025808 001401  BEQ     128
3828     025810 005401  NEG     R1
3829     025812 010166 000020 128:  MOV     R1,20(BP) ;DONE?
3830     025814 010066 000016  MOV     R0,16(BP) ;BR IF NO
3831     025816 012603  MOV     (BP)+,R3 ;OVERFLOW?
3832     025818 012602  MOV     (BP)+,R2 ;BR IF NO
3833     025820 012601  MOV     (BP)+,R1 ;RETURN QUOTIENT AND
3834     025822 012600  MOV     (BP)+,R0 ;REMAINDER TO USER
3835     025824 012666 000002  MOV     (BP)+,2(BP) ;POP STACK INTO R3
3836     025826 000002  RTI      ;POP STACK INTO R2
3837     025828 022626 138:  CMP     (BP)+,(BP)+ ;POP STACK INTO R1
3838     025830 000763  BR      128     ;POP STACK INTO R0
3839     ;*      ;SETUP TO RETURN CONDITION CODES
3840     ;*      ;RETURN
3841     ;*      ;POP THE STACK

```

```

5839          ,SBTTL SAVE AND RESTORE R0-R5 ROUTINES
5840
5841          ;*****
5842          ;SAVE R0-R5
5843          ;CALL:
5844          ;* SAVREG
5845          ;UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
5846          ;*
5847          ;TOP==(+16)
5848          ;* +2==(+10)
5849          ;* +4==R5
5850          ;* +6==R4
5851          ;* +8==R3
5852          ;* +10==R2
5853          ;* +12==R1
5854          ;* +14==R0
5855
5856          $SAVREG:
5857          MOV     R0,-(SP)      ;PUSH R0 ON STACK
5858          MOV     R1,-(SP)      ;PUSH R1 ON STACK
5859          MOV     R2,-(SP)      ;PUSH R2 ON STACK
5860          MOV     R3,-(SP)      ;PUSH R3 ON STACK
5861          MOV     R4,-(SP)      ;PUSH R4 ON STACK
5862          MOV     R5,-(SP)      ;PUSH R5 ON STACK
5863          MOV     22(SP),=(SP)  ;SAVE PS OF MAIN FLOW
5864          MOV     23(SP),=(SP)  ;SAVE PC OF MAIN FLOW
5865          MOV     24(SP),=(SP)  ;SAVE PS OF CALL
5866          MOV     25(SP),=(SP)  ;SAVE PC OF CALL
5867          RTI
5868
5869          ;RESTORE R0-R5
5870          ;CALL: RESREG
5871          ;*
5872          $RESREG:
5873          MOV     (SP)+,22(SP)   ;RESTORE PS OF CALL
5874          MOV     (SP)+,23(SP)   ;RESTORE PC OF CALL
5875          MOV     (SP)+,24(SP)   ;RESTORE PS OF MAIN FLOW
5876          MOV     (SP)+,25(SP)   ;RESTORE PC OF MAIN FLOW
5877          MOV     (SP)+,R5      ;POP STACK INTO R5
5878          MOV     (SP)+,R4      ;POP STACK INTO R4
5879          MOV     (SP)+,R3      ;POP STACK INTO R3
5880          MOV     (SP)+,R2      ;POP STACK INTO R2
5881          MOV     (SP)+,R1      ;POP STACK INTO R1
5882          MOV     (SP)+,R0      ;POP STACK INTO R0
5883          RTI
    
```

```

5884          ,SBTTL RANDOM NUMBER GENERATOR ROUTINE
5885          ;CALL:
5886          ;* JSR PC,$RAND      ;CALL THE ROUTINE
5887          ;* RETURN           ;RETURN HERE THE RANDOM
5888          ;*                  ;NUMBER WILL BE IN
5889          ;*                  ;$HINUM,$LONUM
5890          $RAND:
5891          MOV     R0,-(SP)      ;PUSH R0 ON STACK
5892          MOV     R1,-(SP)      ;PUSH R1 ON STACK
5893          MOV     R2,-(SP)      ;PUSH R2 ON STACK
5894          MOV     R3,-(SP)      ;PUSH R3 ON STACK
5895          MOV     R4,-(SP)      ;PUSH R4 ON STACK
5896          MOV     @12(SP),R4    ;GET POINTER TO THE SAVED SEEDS
5897          ;FOR GENERATING THIS RANDOM NUMBER
5898          MOV     (R4),R0      ;GET LO NUMBER SEED
5899          MOV     2(R4),R1     ;GET HIGH NUMBER SEED
5900          MOV     @-7,R3      ;SET SHIFT COUNT
5901          CLR     R2           ;ZERO R2
5902          ASL     R0           ;SHIFT R0 LEFT AND
5903          ROL     R1           ;ROTATE CARRY INTO R1 AND
5904          ROL     R2           ;ROTATE CARRY INTO R2
5905          INC     R3           ;CHECK FOR DONE
5906          BNE     1$         ;CONTINUE SHIFT LOOP
5907          ADD     (R4),R0      ;ADD NUMBER TO MAKE X 129
5908          ADC     R1           ;PROPAGATE CARRY
5909          ADD     2(R4),R1     ;ADD NUMBER TO MAKE X 129
5910          ADC     R2           ;PROPAGATE CARRY
5911          ADD     @1057,R0     ;ADD LOW CONSTANT
5912          ADC     R1           ;PROPAGATE CARRY
5913          ADC     R2           ;PROPAGATE CARRY
5914          ADD     @47401,R1    ;ADD HIGH CONSTANT
5915          ADC     R2           ;PROPAGATE CARRY
5916          ADD     @6,R2       ;ADD HIGHEST CONSTANT
5917          ADD     R2,R0       ;REPRIME R0 WITH HIGHEST DIGIT
5918          ADC     R1           ;PROPAGATE CARRY
5919          MOV     R0,(R4)     ;SAVE R0-$LONUM (FOR USE NXT TIME)
5920          MOV     R1,2(R4)    ;SAVE R1-$HINUM (FOR USE NXT TIME)
5921          MOV     (SP)+,R4    ;POP STACK INTO R4
5922          MOV     (SP)+,R3    ;POP STACK INTO R3
5923          MOV     (SP)+,R2    ;POP STACK INTO R2
5924          MOV     (SP)+,R1    ;POP STACK INTO R1
5925          MOV     (SP)+,R0    ;POP STACK INTO R0
5926          ADD     @2,(SP)    ;ADJUST SP FOR CORRECT RETURN
5927          RTS     PC         ;RETURN
5928          RSDRVL: 123456    ;RANDOM SEED FOR DRIVE SELECTION (LO)
5929          RSDRVH: 176543    ; " " (HI)
5930          $RFUNL: 1201      ;RANDOM SEED FOR FUNCTION
5931          $RFUNH: 62465     ; " " (HI)
5932          $RCYLL: 176105   ;RANDOM SEED FOR CYLINDER (LO)
5933          $RCYLH: 174532   ; " " (HI)
5934          $RBBAL: 157650   ;RANDOM SEED FOR BUS ADDRESS (LO)
5935          $RBBH: 30753     ; " " (HI)
5936          $RBNCL: 131547   ;RANDOM SEED FOR WORD COUNT (LO)
5937          $RBNCH: 32070    ; " " (HI)
5938          $RBDTL: 123456   ;RANDOM SEED FOR DATA (LO)
5939          $RBDTH: 176543   ; " " (HI)
    
```

```

5940          ,SBTTL BINARY TO OCTAL (ASCII) AND TYPE
5941
5942          ;*****
5943          ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
5944          ;OCTAL (ASCII) NUMBER AND TYPE IT.
5945          ;*TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
5946          ;*CALL:
5947          ;*   MOV     NUM,=(SP)      ;NUMBER TO BE TYPED
5948          ;*   TYP05      ;CALL FOR TYPEOUT
5949          ;*   ,BYTE  N          ;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
5950          ;*   ,BYTE  M          ;M=1 OR 0
5951          ;*                               ;1=TYPE LEADING ZEROS
5952          ;*                               ;0=SUPPRESS LEADING ZEROS
5953          ;*
5954          ;*TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
5955          ;*TYPOS OR STYPOC
5956          ;*CALL:
5957          ;*   MOV     NUM,=(SP)      ;NUMBER TO BE TYPED
5958          ;*   TYPON      ;CALL FOR TYPEOUT
5959          ;*
5960          ;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
5961          ;*CALL:
5962          ;*   MOV     NUM,=(SP)      ;NUMBER TO BE TYPED
5963          ;*   TYP0C      ;CALL FOR TYPEOUT
5964
5965          025760 017646 000000          STYPO5: MOV     6(SP),=(SP)      ;PICKUP THE MODE
5966          025764 116637 000001 026203 MOV5     1(SP),6OFILL      ;LOAD ZERO FILL SWITCH
5967          025772 112637 026205 MOV5     (SP)+,6OMODE+1 ;NUMBER OF DIGITS TO TYPE
5968          025774 062716 000002 ADD      62,(SP)      ;ADJUST RETURN ADDRESS
5969          026A02 000406 BR        STYPO5
5970          026A04 112737 000001 026203 STYPOC: MOV5     61,6OFILL      ;SET THE ZERO FILL SWITCH
5971          026A12 112737 000008 026205 MOV5     64,6OMODE+1 ;SET FOR SIX(6) DIGITS
5972          026A20 112737 000008 026202 STYPON: MOV5     65,6OCNT      ;SET THE ITERATION COUNT
5973          026A26 010346 MOV     R3,=(SP)      ;SAVE R3
5974          026A30 010446 MOV     R4,=(SP)      ;SAVE R4
5975          026A32 010546 MOV     R5,=(SP)      ;SAVE R5
5976          026A34 113704 026205 MOV5     6OMODE+1,R4 ;GET THE NUMBER OF DIGITS TO TYPE
5977          026A40 005404 NEG     R4
5978          026A42 062704 000006 ADD      66,R4      ;SUBTRACT IT FOR MAX. ALLOWED
5979          026A46 110437 026204 MOV5     R4,6OMODE ;SAVE IT FOR USE
5980          026A52 113704 026203 MOV5     6OFILL,R4 ;GET THE ZERO FILL SWITCH
5981          026A56 016608 000012 MOV     12(SP),R0 ;PICKUP THE INPUT NUMBER
5982          026A62 005003 CLR     R3          ;CLEAR THE OUTPUT WORD
5983          026A64 006105 10:  ROL     R0 ;ROTATE HBB INTO "C"
5984          026A66 000404 BR        20:
5985          026A70 006105 20:  ROL     R0 ;FORM THIS DIGIT
5986          026A72 006105 ROL     R0
5987          026A74 006105 ROL     R0
5988          026A76 010803 MOV     R0,R3
5989          026A80 006103 30:  ROL     R3 ;GET LSB OF THIS DIGIT
5990          026A82 105337 026204 DECB    6OMODE ;TYPE THIS DIGIT
5991          026A86 100016 BPL     70          ;BR IF NO
5992          026A90 042703 BIC     017770,R3 ;GET RID OF JUNK
5993          026A94 001002 SNE     40          ;TEST FOR 0
5994          026A96 005704 TST     R4          ;SUPPRESS THIS 0?
5995          026A98 001403 BEQ     50          ;BR IF YES
    
```

```

5996          026A22 005204 40:  INC     R4          ;DON'T SUPPRESS ANYMORE 0'S
5997          026A24 052703 000060 BIS     6'0,R3 ;MAKE THIS DIGIT ASCII
5998          026A30 052703 000040 50:  BIS     6',R3 ;MAKE ASCII IF NOT ALREADY
5999          026A34 110337 026200 MOV5     R3,R0 ;SAVE FOR TYPING
6000          026A40 104401 026200 TYPE    65 ;GO TYPE THIS DIGIT
6001          026A44 105337 026202 70:  DECB    6OCNT ;COUNT BY 1
6002          026A50 003347 BGT     20 ;BR IF MORE TO DO
6003          026A52 002402 BLT     60 ;BR IF DONE
6004          026A54 005204 INC     R4          ;INSURE LAST DIGIT ISN'T A BLANK
6005          026A56 000744 BR        28 ;GO DO THE LAST DIGIT
6006          026A60 012605 60:  MOV     (SP)+,R5 ;RESTORE R5
6007          026A62 012604 MOV     (SP)+,R4 ;RESTORE R4
6008          026A64 012603 MOV     (SP)+,R3 ;RESTORE R3
6009          026A66 016666 000002 000004 MOV     2(SP),4(SP) ;SET THE STACK FOR RETURNING
6010          026A74 012616 MOV     (SP)+,(SP)
6011          026A76 000002 RTI
6012          026A80 000      80:  ,BYTE  0 ;STORAGE FOR ASCII DIGIT
6013          026A82 000      ,BYTE  0 ;TERMINATOR FOR TYPE ROUTINE
6014          026A84 000      6OCNT: ,BYTE  0 ;OCTAL DIGIT COUNTER
6015          026A86 000      6OFILL: ,BYTE  0 ;ZERO FILL SWITCH
6016          026A88 000000 6OMODE: ,WORD  0 ;NUMBER OF DIGITS TO TYPE
6017
    
```



```

,ERRTL ERROR HANDLER ROUTINE
6014
6019
6020 ;*SW15=1 HALT ON ERROR
6021 ;*SW13=1 INHIBIT ERROR TYPEOUTS
6022 ;*SW12=1 TYPE OUT THE ERROR HISTORY, THE FUNCTION THAT
6023 ; WAS BEING PERFORMED ON RK AT THE TIME OF ERROR AND
6024 ; THE FUNCTION PERFORMED PRIOR TO THAT.
6025 ;*NOTE THIS SWITCH OPTION (12) IS MEANINGFUL ONLY FOR ERRORS OCCURRING IN THE
6026 ; EXERCISER PART OF THE PROGRAM.
6027 ;*SW11=1 DUMP OUT ALL RK REGISTERS
6028 ;*SW10=1 BELL ON ERROR
6029 ;*SW09=1 LOOP ON ERROR
6030 ;*SW03=1 TYPE OUT TIME AT WHICH ERROR OCCURED
6031 ;*SW02=1 DROP THE DRIVE AFTER MAXM ERRORS ON THIS DRIVE
6032 ;*SW01=1 TYPE OUT THE SERIAL NUMBER OF THE ERRERING DRIVE
6033 ;*GO TO $ERRTYP ON ERROR
6034
6035
6036 026906 104407          ,ERROR: CK$WR          ;LOOK FOR A 'CONTROL G'
6037 026910 108237 001103      INCB  $ERFLG          ;SET THE ERROR FLAG
6038 026914 001774          BEQ  $ERROR          ;DON'T LET THE FLAG GO TO ZERO
6039 026916 013777 001102 152716  MOV  $STNM,$DISPLAY ;DISPLAY TEST NUMBER AND ERROR FLAG
6040 026924 032777 002000 182706  BIT  $W10,$SWR       ;BELL ON ERROR?
6041 026932 001402          BEQ  18              ;NO = SKIP
6042 026934 104401 001206      TYPE  $BELL          ;RING BELL
6043 026940 005237 001112      18:  INC  $ERTTL       ;COUNT THE NUMBER OF ERRORS
6044
6045 026944 032777 000004 152666  BIT  $W2,$SWR       ;COUNT # OF ERRORS & DROP DRIVE?
6046 026952 001415          BEQ  38              ;NO
6047 ;YES
6048 026954 010146          MOV  R1, -(SP)       ;SAVE R1
6049 026956 013701 001250      MOV  $RDRV,R1        ;GET ERRERING DRIVE #
6050 026962 100410          BMI  20              ;IF ($RDRV)=-1, SKIP(BECAUSE THE
6051 ;ERROR WAS NOT ATTRIBUTABLE TO ANY
6052 ;SPECIFIC DRIVE)
6053 026964 105261 001542          INCB  ERDRV(R1)      ;COUNT # OF ERRORS ON THIS DRIVE
6054 026970 126127 001542 000003  CMPB ERDRV(R1),#3    ;# OF ERRORS GREATER THAN ALLOWABLE?
6055 026976 101402          BLOS 28              ;NO
6056 026980 000137 016312      JMP  D$ELECT        ;DROP THE DRIVE
6057
6058 026984 012601          28:  MOV  (SP)+,R1        ;RESTORE R1
6059
6060 026986 011637 001116      38:  MOV  (SP),$ERRPC    ;GET ADDRESS OF ERROR INSTRUCTION
6061 026992 162737 000002 001116  SUB  #2,$ERRPC
6062 026996 005046          CLR  -(SP)
6063 026998 117716 152570      MOVB $ERRPC,(SP)    ;STRIP AND SAVE THE ERROR ITEM CODE
6064 026998 121627 000100      CMPB (SP),#100     ;FORM THE CO$ECT ITEM# IF THIS IS AN
6065 026998 002402          BLT  48              ;ERROR MESSAGE EQUAL OR ABOVE 100,
6066 026998 162716 000040      SUB  #40,(SP)       ;NOTE THERE R 2 CLASSES OF ERRORS:
6067 ;1) $ITEMB'S BELOW 100
6068 ;2) $ITEMB'S ABOVE 100
6069 ;SUBTRACTION FACTOR HAS TOBE SUCH THAT
6070 ;THE CO$ECT OFFSET IS SELECTED, THIS
6071 ;FACTOR WILL CHANGE IF THE TOTAL # OF
6072 ;ERROR MESSAGES IN CLASS 1 CHANGES,
6073 ;#100 -LAST ITEM IN # CLASS 1 = 1
    
```

```

6074 026940 012637 001114      48:  MOV  (SP)+,$ITEMB    ;SKIP TYPEOUT IF SET
6075 026944 032777 020000 152566  BIT  $W13,$SWR       ;SKIP TYPEOUTS
6076 026952 001012          BNE  58              ;SKIP TYPEOUTS
6077 026954 004737 026472      JSR  PC,$$ERRTYP    ;GO TO USER ERROR ROUTINE
6078 026960 104401 001213      TYPE $CRLF
6079
6080 026964 032777 010000 152546  BIT  $W12,$SWR       ;TYPE ERROR HISTORY?
6081 026972 001402          BEQ  58              ;NO
6082 026974 004737 020426      JSR  PC,HISTRY      ;YES
6083
6084 026400 023737 000042 000046  58:  CMP  $42,$46        ;ACT11 AUTOMATIC MODE?
6085 026406 001403          BEQ  +10             ;YES, HALT ON ERROR
6086 026410 005777 152524      TST  $SWR           ;HALT ON ERROR
6087 026414 100002          BPL  68              ;SKIP IF CONTINUE
6088 026416 000000          HALT ON ERROR
6089 026420 104407          CK$WR
6090 026422 032777 001000 152510  68:  BIT  $W09,$SWR       ;LOOK FOR A 'CONTROL G'
6091 026430 001411          BEQ  78              ;LOOP ON ERROR SWITCH SET?
6092 026432 123727 001114 000040  CMPB $ITEMB,#40     ;BR IF NO
6093 026440 103011          BHIS 88              ;THERE R 37 ERROR MESSAGES IN CLASS 1
6094 026442 013746          MOV  PPRVLV, -(SP)  ;LOCK OUT ALL INTERRUPTS ON RETURN
6095 ;FROM THIS EROR HANDLER, IF THE EROR
6096 ;IS IN EXERCISER & LOOPING IS TO
6097 ;BE DONE
6098 026446 005726          TST  (SP)+
6099 026450 012716 015726      MOV  $EXCLUP,(SP)  ;IF THIS ERROR CALL WAS FROM EXERCISER
6100 ;PART OF THE PROGRAM, GO TO 'EXCLUP'
6101 ;OTHERWISE RETURN THRU '$LUPERR'
6102
6103 026454 012737 177777 001250  78:  MOV  #-1,$RDRV      ;RESET SERIAL NO FLAG
6104 ;IF ($RDRV)=-1, THEN THE SERIAL
6105 ;NO OF THE DRIVE WILL NOT BE
6106 ;TYPED OUT.
6107 ;OTHERWISE, SERIAL NO FOR THE DRIVE
6108 ;# IN '$RDRV' WILL BE TYPED.
6109 026462 000002          RTI
6110 026464 013716 001110      88:  MOV  $LPERR,(SP)    ;FUDGE RETURN FOR LOOPING
6111 026470 000771          BR   78              ;RETURN
    
```

```

        6112          ,SBTIL  ERROR MESSAGE TYPEOUT ROUTINE
        6113
        6114          ;*THIS ROUTINE USES THE *ITEM CONTROL BYTE* (*ITEMB) TO DETERMINE WHICH
        6115          ;*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE *ERROR TABLE* (*ERRTB),
        6116          ;*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR,
        6117
        6118
        6119          026472  104401  001213          $ERRTYP:TYPE          ,%CRLF          ;"CARRIAGE RETURN" & "LINE FEED"
        6120          026476  010046          MOV          RO,-(%SP)          ;SAVE RO
        6121          026400  005000          CLR          RO          ;PICKUP THE ITEM INDEX
        6122          026402  133700  001114          BSB          0,%ITEMB,RO
        6123          026404  001004          BNE          1%          ;IF ITEM NUMBER IS ZERO, JUST
        6124          026410  013746  001116          MOV          $ERRPC,-(%SP)          ;TYPE THE PC OF THE ERROR
        6125          026414  104402          TYPCC
        6126          026416  000425          BR          5%          ;GET OUT
        6127          026420  009300          1%:  DEC          RO          ;ADJUST THE INDEX SO THAT IT WILL
        6128          026422  006300          ASL          RO          ;WORK FOR THE ERROR TABLE
        6129          026424  006300          ASL          RO
        6130          026426  006300          ASL          RO
        6131          026430  062700  002666          ADD          $ERRTB,RO          ;FORM TABLE POINTER
        6132          026434  012037  026444          MOV          (RO)+,%ZB          ;PICKUP "ERROR MESSAGE" POINTER
        6133          026440  001404          BEQ          4%          ;SKIP TYPEOUT IF NO POINTER
        6134          026442  104401          TYPE          ;TYPE THE "ERROR MESSAGE"
        6135          026444  000000          ,WORD          0          ;"ERROR MESSAGE" POINTER GOES HERE
        6136          026446  104401  001213          2%:  TYPE          ,%CRLF          ;"CARRIAGE RETURN" & "LINE FEED"
        6137          026448  032777  004000  182360          3%:  BIT          %SW1,%SWR          ;DUMP OUT RK REGISTERS?
        6138          026450  001404          BEQ          5%
        6139          026452  004737  027032          JSR          PC,DMPREG          ;GO TYPE OUT RK REGISTERS
        6140          026454  104401  001213          TYPE          ,%CRLF
        6141
        6142          026472  012037  026802          5%:  MOV          (RO)+,%ZB          ;PICKUP "DATA HEADER" POINTER
        6143          026474  001404          BEQ          7%          ;SKIP TYPEOUT IF 0
        6144          026400  104401          TYPE          ;TYPE THE "DATA HEADER"
        6145          026402  000000          ,WORD          0          ;"DATA HEADER" POINTER GOES HERE
        6146          026404  104401  001213          6%:  TYPE          ,%CRLF          ;"CARRIAGE RETURN" & "LINE FEED"
        6147          026410  011000          MOV          (RO),RO          ;PICKUP "DATA TABLE" POINTER
        6148          026412  001406          BEQ          9%
        6149
        6150
        6151          026414  013046          8%:  MOV          0(RO)+,-(%SP)          ;TYPE AN OCTAL NUMBER
        6152          026416  104402          TYPCC          ;SAVE (RO)+ FOR TYPEOUT
        6153          026420  104401  002663          TYPE          ,BLNK%2          ;GO TYPE=OCTAL ASCII(ALL DIGITS)
        6154          026424  005710          TST          (RO)          ;TYPE TWO(2) SPACES
        6155          026426  001372          BNE          9%          ;IS THERE ANOTHER NUMBER?
        6156
        6157          026430  012600          9%:  MOV          (%SP)+,RO          ;RESTORE RO
        6158          026432  104401  001213          TYPE          ,%CRLF          ;"CARRIAGE RETURN" & "LINE FEED"
        6159          026436  123727  001114  000040          CMPB         %ITEMB,%40          ;SKIP TIME & SERIAL # FOR
        6160
        6161          026444  103004          BHS          10%          ;NON-EXERCISER ERRORS
        6162          026446  004737  026660          JSR          PC,TIMTYP          ;TYPE OUT TIME IF SW 3 IS SET
        6163          026452  004737  026766          JSR          PC,SHOTYP          ;GO TYPE OUT THE SERIAL # OF THE
        6164
        6165          026456  000207          10%:  RTS          PC          ;ERRORING DRIVE, IF SW 1 IS SET.
        ;RETURN
    
```

```

        6166          ;TIMTYP
        6167          ;THIS ROUTINE TYPES THE TIME IN HOURS:MIN:SECS IF SW 3 IS SET
        6168          ;SW 3 SHOULD NOT BE SET IF KW11 IS NOT PRESENT.
        6169
        6170          026450  032777  000010  152252          TIMTYP: BIT          %SW3,%SWR          ;IS SW 3 SET?
        6171          026456  001434          BEQ          4%          ;IF NOT SKIP TYPING TIME
        6172          026470  104401  002652          TYPE          ,M%G2%          ;"TIME"
        6173          026474  104401  002662          TYPE          ,BLNK%3
        6174          026700  104414          SAVREG
        6175          026702  012700  001552          MOV          %KNHR,RO          ;SAVE RO=R4
        6176          026706  012001          MOV          (RO)+,%R1          ;INITIALIZE POINTER
        6177          026710  000404          BR          2%
        6178          026712  012001          1%:  MOV          (RO)+,%R1          ;TYPE OUT
        6179          026714  001402          BEQ          2%
        6180          026716  062701  000074          ADD          %60,%R1
        6181          026722  010137  026762          2%:  MOV          R1,%S
        6182          026726  012746  026762          MOV          %S,-(%SP)          ;HOURS:MIN:SECS
        6183          026732  004737  024604          JSR          PC,%SDB2D          ;CONVERT TO ASCII STRING
        6184          026736  004737  025000          JSR          PC,%SUPR%L          ;GO TYPE
        6185          026742  020027  001560          CMP          RO,%KNSEC+2          ;ALL DONE?
        6186          026746  001403          BEQ          3%
        6187          026750  104401  002334          TYPE          ,M%G1%
        6188          026754  000756          BR          1%
        6189          026756  104415          3%:  REBREG          ;RESTORE RO=R4
        6190          026760  000207          4%:  RTS          PC          ;RETURN
        6191          026762  000000  000000          5%:  ,WORD          0,%0
    
```

```

6192 ;SNOTYP
6193 ;THIS ROUTINE TYPES OUT THE SERIAL NUMBER OF THE ERRORING DRIVE, IF SW 1
6194 ;IS SET. NOTE THAT THE SERIAL NUMBER IS TYPED OUT ONLY WHEN THE DRIVE
6195 ;CAN BE IDENTIFIED POSITIVELY, AS THE ONE WHICH GAVE THE ERROR, IF THE
6196 ;ERROR CANNOT BE ATTRIBUTED TO ANY SPECIFIC DRIVE (&SRDRV=&R1) THEN
6197 ;THE SERIAL NUMBER IS NOT TYPED OUT.
6198
6199 026766 032777 000002 152144 SNOTYP: BIT ;SW1,&SWR ;TYPE OUT SERIAL #?
6200 026774 001415 BEG 28 ;NO
6201 026776 010146 MOV R1,=&(SP) ;SAVE R1
6202 027000 013701 001250 MOV SRDRV,R1 ;GET ERRORING DRIVE #
6203 027004 006301 ASL R1 ;IF (&SRDRV)=-1, SKIP (BECAUSE
6204 027006 100407 BMI 18 ;THE ERROR WAS NOT ATTRIBUTABLE
6205 ;TO A SPECIFIC DRIVE)
6206 027010 104401 001213 TYPE ;&SR,NO
6207 027014 104401 002326 TYPE ;M&G17 ;TYPE "SR, NO:"
6208 027020 016146 001266 MOV SRNO(R1),-&(SP) ;GET THE SERIAL #
6209 027024 104405 TYPDS ;TYPE IT OUT (DECIMAL)
6210
6211 027026 012601 18: MOV (&R1),R1 ;RESTORE R1
6212 027030 000207 28: RTS PC ;RETURN
6213
6214
6215
6216 ;DMPREG
6217 ;THIS ROUTINE DUMPS OUT ALL RK11 REGISTERS WHEN SW 11 IS SET AND AN ERROR OCCURS.
6218
6219 027032 DMPREG:
6220 027032 104401 027040 TYPE ;650 ;TYPE ASCII STRING
6221 027036 000441 BR 648 ;GET OVER THE ASCII
6222 ;658: ;ASCII <15><12>/ PC RKDS RKER RKCS RKWC RKBA RKDA RKDB/<
6223 027142 648:
6224 027142 013746 001116 MOV ;ERRPC,=&(SP)
6225 027146 104402 TYPDC
6226 027150 104401 002663 TYPE ;BLNK&2
6227 027154 010046 MOV RO,=&(SP)
6228 027156 012700 001216 MOV ;RKDS,RO
6229 027162 013046 18: MOV ;(RO)+,=&(SP)
6230 027164 104402 TYPDC
6231 027166 104401 002663 TYPE ;BLNK&2
6232 027172 020027 001232 CMP RO,&RKDB
6233 027176 003771 BLE 18
6234 027000 012600 MOV (&R1),R1
6235 027002 000207 RTS PC
    
```

```

6236 ;SHTL SCOPE HANDLER ROUTINE
6237
6238 ;*****
6239 ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS, IT WILL INCREMENT
6240 ;*AND LOAD THE TEST NUMBER(&STNM) INTO THE DISPLAY REG.(DISPLAY<7;0>)
6241 ;*AND LOAD THE ERROR FLAG (&ERFLG) INTO DISPLAY<15;08>
6242 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
6243 ;*SW14=1 LOOP ON TEST
6244 ;*SW09=1 LOOP ON ERROR
6245 ;*CALL SCOPE ;SCOPE=IOT
6246
6247
6248 027004 ;SCOPE:
6249 027004 104400 BIT CK&SWR ;TEST FOR CHANGE IN SOFT-SWR
6250 027006 032777 040000 151724 18: BIT ;BIT14,&SWR ;LOOP ON PRESENT TEST?
6251 027014 001047 SNE &OVER ;YES IF SW14=1
6252 ;****START OF CODE FOR THE XOR TESTER****
6253 027016 000416 ;XTSTR: BR 68 ;IF RUNNING ON THE "XOR" TESTER CHANGE
6254 ;THIS INSTRUCTION TO A "NOP" (NOP=246)
6255 027220 013746 000004 MOV ;ERRVEC,=&(SP) ;HAVE THE CONTENTS OF THE ERROR VECTOR
6256 027224 012737 000004 000004 MOV ;&,&ERRVEC ;SET FOR TIMEOUT
6257 027232 005737 177060 TST ;177060 ;TIME OUT ON XOR?
6258 027236 012637 000004 MOV (&R1),=&ERRVEC ;RESTORE THE ERROR VECTOR
6259 027242 000431 BR ;&SVLAD ;GO TO THE NEXT TEST
6260 027244 022626 88: CMP (&R1),(&R1)+ ;CLEAR THE STACK AFTER A TIME OUT
6261 027246 012637 000004 MOV (&R1),=&ERRVEC ;RESTORE THE ERROR VECTOR
6262 027252 000407 BR 78 ;LOOP ON THE PRESENT TEST
6263 ;****END OF CODE FOR THE XOR TESTER****
6264 027254 105737 001103 28: TSTB ;ERFLG ;HAS AN ERROR OCCURRED?
6265 027260 001412 BEQ ;&SVLAD ;BR IF NO
6266 027262 032777 001000 151650 BIT ;BIT09,&SWR ;LOOP ON ERROR?
6267 027270 001404 BEQ 48 ;BR IF NO
6268 027272 013737 001110 001106 78: MOV ;&PERR,&LPADR ;SET LOOP ADDRESS TO LAST SCOPE
6269 027280 000415 BR ;&OVER
6270 027302 105037 001103 48: CLRB ;ERFLG ;ZERO THE ERROR FLAG
6271 027306 105237 001102 ;&SVLAD: INCB ;&STNM ;COUNT TEST NUMBERS
6272 027312 011637 001106 MOV (&R1),&LPADR ;SAVE SCOPE LOOP ADDRESS
6273 027316 011637 001110 MOV (&R1),&PERR ;SAVE ERROR LOOP ADDRESS
6274 027322 005037 001204 CLR ;ESCAPE ;CLEAR THE ESCAPE FROM ERROR ADDRESS
6275 027326 112737 000001 001115 MOVB #1,&ERMAX ;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6276 027334 013777 001102 151600 ;OVER: MOV ;&STNM,&DISPLAY ;DISPLAY TEST NUMBER
6277 027342 013716 001106 MOV ;&LPADR,&(SP) ;FUJGE RETURN ADDRESS
6278 027346 000002 RTI ;FIXES P5
    
```

```

6279          ,SBTTL TRAP DECODEH
6280
6281          ;*****
6282          ;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
6283          ;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
6284          ;OF THE DESIRED ROUTINE, THEN USING THE ADDRESS OBTAINED IT WILL
6285          ;GO TO THAT ROUTINE.
6286
6287 0277450 010046          $TRAP: MOV    RO, -(SP)          ;;SAVE RO
6288 0277452 016600          MOV    2(SP),RO          ;;GET TRAP ADDRESS
6289 0277456 005740          TST   =(RO)             ;;BACKUP BY 2
6290 0277460 111000          MOVB  (RO),RO           ;;GET RIGHT BYTE OF TRAP
6291 0277462 006300          ASL   RO                ;;POSITION FOR INDEXING
6292 0277464 016000          MOV   $TRPAD(RO),RO     ;;INDEX TO TABLE
6293 0277470 000200          RTS   RO                ;;GO TO ROUTINE
6294
6295
6296          ;THIS IS USE TO HANDLE THE "GETPRI" MACRO
6297
6298 0277472 011646          $TRAP2: MOV   (SP),-(SP)  ;;MOVE THE PC DOWN
6299 0277474 016666          MOV   4(SP),2(SP)      ;;MOVE THE PSW DOWN
6300 0277402 000002          RTI                   ;;RESTORE THE PSW
6301
6302          ,SBTTL TRAP TABLE
6303
6304          ;THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
6305          ;BY THE "TRAP" INSTRUCTION,
6306
6307          ;
6308          ; ROUTINE
6309          ;-----
6310 027404 027372          $TRPAD: ,WORD          $TRAP2
6311 027406 024244          TYPE          ;;CALLTYPE          TRAP+1(104401) TTY TYPEOUT ROUTINE
6312 027410 026004          $TYPOC          ;;CALLTYPOC         TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
6313 027412 025760          $TYPOS          ;;CALLTYPOS         TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
6314 027414 026020          $TYPON          ;;CALLTYPON         TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
6315 027416 024020          $TYPDS          ;;CALLTYPDS         TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
6316
6317
6318 027420 023034          $GTSWR          ;;CALLGTSWR          TRAP+6(104406) GET SOFT-SWR SETTING
6319
6320 027422 022764          $CKSWR          ;;CALLCKSWR          TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
6321 027424 023246          $RDCHR          ;;CALLRDCHR          TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
6322 027426 023366          $RDLIN          ;;CALLRDLIN          TRAP+11(104411) TTY TYPEIN STRING ROUTINE
6323 027430 023540          $RDOCT          ;;CALLRDOCT          TRAP+12(104412) READ AN OCTAL NUMBER FROM TTY
6324 027432 023642          $RDDEC          ;;CALLRDDEC          TRAP+13(104413) READ A DECIMAL NUMBER FROM TTY
6325 027434 025502          $SAVREG          ;;CALLSAVREG          TRAP+14(104414) SAVE RO-R5 ROUTINE
6326 027436 028540          $RESREG          ;;CALLRESREG          TRAP+15(104415) RESTORE RO-R5 ROUTINE
6327 027440 022366          CN,RST          ;;CALLCON,RESET          TRAP+16(104416) CONTROL RESET ROUTINE
6328 027442 023364          CN,RDY          ;;CALLCON,RDY          TRAP+17(104417) WAIT FOR CONTROL READY
6329 027444 022744          DR,RST          ;;CALLDRV,RESET          TRAP+20(104420) DRIVE RESET ROUTINE
6330 027446 022522          TY,M&G          ;;CALLTYPM&G          TRAP+21(104421) TYPE MESSAGE ROUTINE, SW13
6331
6332
6333
    
```

```

6330          ,SBTTL POWER DOWN AND UP ROUTINES
6331
6332          ;*****
6333          ;POWER DOWN ROUTINE
6334 027480 012737 027614 000024 $PWRDN: MOV    $ILLUP,$PWRVEC ;;SET FOR FAST UP
6335 027486 012737 000340 000026          MOV    340,$PWRVEC+2 ;;PRIO:7
6336 027464 010046          MOV    RO, -(SP)          ;;PUSH RO ON STACK
6337 027466 010166          MOV    R1, -(SP)          ;;PUSH R1 ON STACK
6338 027470 010266          MOV    R2, -(SP)          ;;PUSH R2 ON STACK
6339 027472 010366          MOV    R3, -(SP)          ;;PUSH R3 ON STACK
6340 027474 010466          MOV    R4, -(SP)          ;;PUSH R4 ON STACK
6341 027476 010566          MOV    R5, -(SP)          ;;PUSH R5 ON STACK
6342 027400 017746 151436          MOV    $SWR, -(SP)        ;;PUSH $SWR ON STACK
6343 027404 010637 027620          MOV    SP, $SAVR6        ;;SAVE SP
6344 027410 012737 027522 000024          MOV    $PWRUP,$PWRVEC   ;;SET UP VECTOR
6345 027416 000000          HALT
6346 027420 000776          BR     =2                ;;HANG UP
6347
6348          ;*****
6349          ;POWER UP ROUTINE
6350 027422 012737 027614 000024 $PWRUP: MOV    $ILLUP,$PWRVEC ;;SET FOR FAST DOWN
6351 027430 013706 027620          MOV    $SAVR6,SP        ;;GET SP
6352 027434 005037 027620          CLR   $SAVR6           ;;WAIT LOOP FOR THE TTY
6353 027440 005237 027620          IS:   INC   $SAVR6      ;;WAIT FOR THE INC
6354 027444 001375          SNE   IS               ;;OF WORD
6355 027446 012677 151366          MOV   (SP)+,$SWR       ;;POP STACK INTO $SWR
6356 027452 012605          MOV   (SP)+,R5         ;;POP STACK INTO R5
6357 027454 012604          MOV   (SP)+,R4         ;;POP STACK INTO R4
6358 027456 012603          MOV   (SP)+,R3         ;;POP STACK INTO R3
6359 027460 012602          MOV   (SP)+,R2         ;;POP STACK INTO R2
6360 027462 012601          MOV   (SP)+,R1         ;;POP STACK INTO R1
6361 027464 012600          MOV   (SP)+,RO         ;;POP STACK INTO RO
6362 027466 012737 027450 000024          MOV    $PWRDN,$PWRVEC   ;;SET UP THE POWER DOWN VECTOR
6363 027474 012737 000340 000026          MOV    340,$PWRVEC+2 ;;PRIO:7
6364 027802 104401          TYPE          ;;REPORT THE POWER FAILURE
6365 027404 027622          $PWRNG: ,WORD          $PWRNG          ;;POWER FAIL MESSAGE POINTER
6366 027406 012716          MOV   (PC)+,(SP)        ;;RESTART AT PFBTRT
6367 027410 003366          $PWRAD: ,WORD          PFBTRT          ;;RESTART ADDRESS
6368 027412 000002          RTI
6369 027414 000000          $ILLUP: HALT           ;;THE POWER UP SEQUENCE WAS STARTED
6370 027416 000776          BR     =2                ;; BEFORE THE POWER DOWN WAS COMPLETED
6371 027420 000000          $SAVR6: 0                ;;PUT THE SP HERE
6372 027422 005015          $PWRNG: ,ASCIZ <15><13>"POWER"
6373 027430 000122
6374          ,EVEN
    
```

ERROR MESSAGES

6375	027632	051105	051117	047440	EM11	.ASCIZ	/ERROR ON WRITE/
6376	027640	020116	051127	052111			
6377	027432	051105	051117	047440	EM11	.ASCIZ	/ERROR ON WRITE/
6378	027640	020116	051127	052111			
6379	027446	000105					
6380	027450	052101	046505	052120	EM21	.ASCIZ	/ATTEMPT TO INITIATE FUNCTION ON 'BUSY' DRIVE/
6381	027456	082040	020117	047111			
6382	027464	052111	040511	042524			
6383	027472	043040	047125	052103			
6384	027700	047511	020116	047117			
6385	027706	023440	052502	054523			
6386	027714	020047	051104	042526			
6387	027722	000					
6388	027723	103	052116	047522	EM31	.ASCIZ	/CONTROL RDY NOT SET/
6389	027730	020114	042122	020131			
6390	027736	047516	020124	042523			
6391	027744	000124					
6392	027746	051057	053457	051457	EM41	.ASCIZ	'R/W/S RDY NOT SET'
6393	027754	051040	084504	047040			
6394	027762	052117	051440	052105			
6395	027770	000					
6396	027771	103	052116	047522	EM51	.ASCIZ	/CONTROL RDY NOT SET AFTER 1ST INTERRUPT ON ISSUING SEEK/
6397	027776	020114	042122	020131			
6398	030704	047516	020124	042523			
6399	030712	020124	043101	042524			
6400	030720	020122	051461	020124			
6401	030726	047111	051124	050128			
6402	030734	020124	047117	044440			
6403	030742	051523	044525	043516			
6404	030750	051440	042505	000113			
6405	030756	051127	047117	020107	EM61	.ASCIZ	/WRONG BITS IN RKCS, EXPCT SEEK/
6406	030764	044502	051524	044440			
6407	030772	020116	045522	051503			
6408	030100	020054	054105	041520			
6409	030106	020124	042523	045505			
6410	030114	000					
6411	030115	047	052502	054523	EM71	.ASCIZ	'BUSY' FLAG CLEAR ON INTERRUPTING DRIVE/
6412	030122	020047	046106	043501			
6413	030130	041440	042514	051101			
6414	030136	047440	020116	047111			
6415	030144	051124	050125	044524			
6416	030152	043516	042040	053122			
6417	030160	000105					
6418	030162	050047	051517	052111	EM101	.ASCIZ	'POSITIONING' FLAG FOR INTERRUPTING DRIVE CLEAR/
6419	030170	047511	044516	043516			
6420	030176	020047	046106	043501			
6421	030204	043040	051117	044440			
6422	030212	052116	052522	052120			
6423	030220	047111	020107	051104			
6424	030226	042526	041440	042514			
6425	030234	051101	000				
6426	030237	047	051105	023522	EM111	.ASCIZ	'ERROR SET AFTER 1ST INTERRUPT ON ISSUING SEEK/
6427	030244	051117	051440	052105			
6428	030252	040440	052106	051105			
6429	030260	030440	052123	044440			
6430	030266	052116	051105	052522			

6431	030274	052120	047440	020116			
6432	030302	051511	052523	047111			
6433	030310	020107	042523	045505			
6434	030316	000					
6435	030317	123	050103	051440	EM121	.ASCIZ	/SCP SET AFTER 1ST INTERRUPT ON ISSUING SEEK/
6436	030324	052105	040440	052106			
6437	030332	051105	030440	052123			
6438	030340	044440	052116	052522			
6439	030346	052120	047440	020116			
6440	030354	051511	052523	047111			
6441	030362	020107	042523	045505			
6442	030370	000					
6443	030371	103	052116	047522	EM131	.ASCIZ	/CONTROL RDY NOT SET AFTER SEEK DONE INTERRUPT/
6444	030376	020114	042122	020131			
6445	030404	047516	020124	042523			
6446	030412	020124	043101	042524			
6447	030420	020122	042523	045505			
6448	030426	042040	047117	020105			
6449	030434	047111	051124	050128			
6450	030442	000124					
6451	030444	047111	051124	050128	EM141	.ASCIZ	/INTRUPTING DRIVE (SEEK DONE) WAS NOT 'BUSY'/
6452	030452	044524	043516	042040			
6453	030460	053122	020105	051450			
6454	030466	042505	020113	047504			
6455	030474	042516	020051	040527			
6456	030482	020123	047516	020124			
6457	030410	041047	051525	023531			
6458	030416	000					
6459	030417	122	053457	051457	EM151	.ASCIZ	'R/W/S READY NOT SET FOR INTERRUPTING DRIVE (SEEK DONE)'
6460	030424	051040	040505	054504			
6461	030432	047040	052117	051440			
6462	030440	052105	043040	051117			
6463	030446	044440	052116	052522			
6464	030454	052120	047111	020107			
6465	030462	051104	042526	024040			
6466	030470	042523	045505	042040			
6467	030476	047117	024505	000			
6468	030403	123	047111	042440	EM161	.ASCIZ	/SIN ERROR/
6469	030410	047522	000122				
6470	030414	042447	051122	047447	EM171	.ASCIZ	'ERROR ON DOING SEEK/
6471	030422	020122	047117	042040			
6472	030430	044517	043516	051440			
6473	030436	042505	000113				
6474	030442	041523	020120	044504	EM201	.ASCIZ	/SCP DID NOT SET AFTER SEEK WAS DONE/
6475	030450	020104	047516	020124			
6476	030456	042523	020124	043101			
6477	030464	042524	020122	042523			
6478	030472	045505	053440	051501			
6479	030700	042040	047117	000105			
6480	030706	047523	052106	042440	EM211	.ASCIZ	/SOFT ERROR/
6481	030714	047522	000122				
6482	030720	040504	040524	024040	EM231	.ASCIZ	/DATA (COMPARISON) ERROR/
6483	030726	047503	030115	051101			
6484	030734	051511	047117	020051			
6485	030742	051105	051117	000			
6486	030747	103	052116	047522	EM241	.ASCIZ	/CONTROL RDY CLR ON INTERRUPT AFTER RK FUNCTION/

6487	030754	020114	042122	020131				
6488	030762	046103	020122	047117				
6489	030770	044440	052116	052522				
6490	030776	057120	040440	052106				
6491	031004	051105	051040	020113				
6492	031012	052506	041516	044524				
6493	031020	047117	000					
6494	031023	123	052524	045503	EM26:	.ASCIZ	/STUCK IN LOOP,8 COMANDS SHLDBE DONE BY NOW/	
6495	031030	044440	020116	047514				
6496	031036	050117	034084	041440				
6497	031044	046517	047101	051504				
6498	031052	051440	046110	041104				
6499	031060	020105	047504	042516				
6500	031066	041040	020131	047516				
6501	031074	000127						
6502	031076	052101	050115	020124	EM27:	.ASCIZ	/ATMPT TO DO WRITE BEFORE WRT CHK/	
6503	031104	047524	042040	020117				
6504	031112	051127	052111	020105				
6505	031120	042502	047506	042522				
6506	031126	053440	052122	041440				
6507	031134	045510	000					
6508	031137	101	046524	052120	EM30:	.ASCIZ	/ATMPT TO REEXECUTE COMMAND=IN PROGRESS OR ALREADY FINISHED/	
6509	031144	052040	020117	042522				
6510	031152	054108	041505	052125				
6511	031160	020105	047503	046518				
6512	031166	047101	026504	047111				
6513	031174	030040	047522	031107				
6514	031182	051305	020123	031117				
6515	031190	040440	051114	040505				
6516	031196	054504	043040	047111				
6517	031198	051311	042510	000104				
6518	031202	043047	047125	052103	EM31:	.ASCIZ	/'FUNCTION IN PROGRES' FLG FOR INTRUPTING DRIVE ISN'T SET/	
6519	031240	047511	020116	047111				
6520	031246	050040	047522	051107				
6521	031254	051505	020047	046106				
6522	031262	020107	047506	020122				
6523	031270	047111	051124	050125				
6524	031276	044524	043516	042040				
6525	031284	044522	042526	044440				
6526	031312	047123	052047	051440				
6527	031320	052105	000					
6528	031323	125	042516	050130	EM32:	.ASCIZ	/UNEXPCED DRIVE INTRUPTED/	
6529	031330	052103	042105	042040				
6530	031336	044522	042526	044440				
6531	031344	052116	052522	052120				
6532	031352	042105	000					
6533	031355	125	042516	050130	EM33:	.ASCIZ	/UNEXPCED FUNCTION CODE IN RKCS AFTER INTRUPT/	
6534	031362	052103	020104	052506				
6535	031370	041516	044524	047117				
6536	031376	041440	042117	020105				
6537	031404	047111	051040	041513				
6538	031412	020123	043101	042524				
6539	031420	020127	047111	051124				
6540	031426	050125	000124					
6541	031432	051104	042526	051040	EM34:	.ASCIZ	/DRVE RDY CLEAR/	
6542	031440	054504	041440	042514				

6543	031446	051101	000					
6544	031451	104	053122	020105	EM35:	.ASCIZ	/DRVE POWER LO/	
6545	031456	047520	042527	020122				
6546	031464	047514	000					
6547	031467	104	053122	020105	EM36:	.ASCIZ	/DRVE UNSAFE/	
6548	031474	047125	040523	042506				
6549	031482	000						
6550	031483	127	051520	051440	EM37:	.ASCIZ	/WFS SET/	
6551	031490	052105	000					
6552	031493	111	052116	051105	EM101:	.ASCIZ	/INTERUPT DIDN'T OCUR AFTER WRT/	
6553	031498	050125	020124	044504				
6554	031426	047104	052047	047440				
6555	031434	052503	020122	043101				
6556	031442	042524	020122	051127				
6557	031450	042524	000					
6558	031453	047	051105	023522	EM102:	.ASCIZ	/'ERR'OR SET/	
6559	031460	051117	051440	052105				
6560	031466	000						
6561	031467	122	042113	020101	EM103:	.ASCIZ	/RKDA INCRMENTED WRONG/	
6562	031474	047111	051103	042515				
6563	031402	052116	042105	053440				
6564	031410	047522	043516	000				
6565	031415	122	041113	020101	EM104:	.ASCIZ	/RKBA INCRMENTED WRONG/	
6566	031422	047111	051103	042515				
6567	031430	052116	042105	053440				
6568	031436	047522	043516	000				
6569	031443	122	053513	020103	EM105:	.ASCIZ	/RKWC DIDN'T OVRFLD TO 0/	
6570	031450	044504	047104	052047				
6571	031456	047440	051126	046106				
6572	031464	020117	047524	030040				
6573	031472	000						
6574	031473	115	054105	041040	EM106:	.ASCIZ	/MEX BITS WRONG/	
6575	031700	052111	020123	051127				
6576	031706	047117	000107					
6577	031712	051127	042524	041440	EM110:	.ASCIZ	/WRTS CHK EROR/	
6578	031720	045510	042440	047522				
6579	031726	000122						

6580 ,DATA HEADERS  
6581 031730 020040 041520 020040 DH1: ,ASCIZ / PC RKCS RKER RKDS RKDA/  
6582 031736 020040 051040 041513  
6583 031744 020123 020040 051040  
6584 031752 042513 020122 020040  
6585 031760 051040 042113 020123  
6586 031766 020040 051040 042113  
6587 031774 000101  
6588  
6589 031776 020040 041520 020040 DH2: ,ASCIZ / PC DRV#/  
6590 032004 020040 051104 021526  
6591 032012 000  
6592  
6593 032013 040 050040 020103 DH21: ,ASCIZ / PC RKCS RKER RKDS DRIVE CYL SUR SEC/  
6594 032020 020040 020040 045522  
6595 032026 051503 020040 020040  
6596 032034 045522 051105 020040  
6597 032042 020040 045522 051304  
6598 032050 020040 042040 044322  
6599 032056 042526 020040 020040  
6600 032064 054503 020114 020040  
6601 032072 020040 052523 020122  
6602 032100 020040 020040 042523  
6603 032106 000103  
6604  
6605 032110 020040 041520 020040 DH23: ,ASCIZ / PC RKBA EXPCT RECVD RKDA/  
6606 032116 020040 045522 040502  
6607 032124 020040 020040 054105  
6608 032132 041520 020124 020040  
6609 032140 042522 053103 020104  
6610 032146 020040 045522 040504  
6611 032154 000  
6612 032155 040 050040 020103 DH25: ,ASCIZ / PC RKCS RKER RKDS RKDA DRV#/  
6613 032162 020040 020040 045522  
6614 032170 051503 020040 051040  
6615 032176 042513 020122 020040  
6616 032004 051040 042113 020123  
6617 032012 020040 051040 042113  
6618 032020 020101 020040 051104  
6619 032026 042526 000043  
6620  
6621 032032 020040 041520 020040 DH27: ,ASCIZ / PC KEY FNCTN CODE/  
6622 032040 020040 045440 054505  
6623 032046 020040 020040 047106  
6624 032054 052103 020116 047503  
6625 032062 042504 000  
6626 032065 040 050040 020103 DH103: ,ASCIZ / PC EXPCT RECVD/  
6627 032072 020040 042440 050130  
6628 032000 052103 020040 051040  
6629 032006 041505 042126 000  
6630  
6631 032113 040 050040 020103 DH30: ,ASCIZ / PC KEY/  
6632 032120 020040 045440 054505  
6633 032126 000  
6634 032127 040 050040 020103 DH105: ,ASCIZ / PC RKDA RKNC/  
6635 032134 020040 020040 045522

6636 032042 040504 020040 051040  
6637 032050 053513 000103  
6638 032054 020040 041520 020040 DH110: ,ASCIZ / PC RKCS RKER RKBA RKDA/  
6639 032062 020040 051040 041513  
6640 032070 020123 020040 051040  
6641 032076 042513 020122 020040  
6642 032004 051040 041113 020101  
6643 032012 020040 051040 042113  
6644 032020 000101  
6645  
6646  
6647 ,EVEN  
6648  
6649 032022 001116 001162 001164 DT1: ,WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,0  
6650 032030 001166 001170 000000  
6651  
6652 032036 001116 001162 000000 DT2: ,WORD \$ERRPC,\$REG0,0  
6653  
6654 032044 001116 001162 001164 DT21: ,WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,\$REG5,\$REG6,0  
6655 032052 001166 001170 001172  
6656 032060 001174 001176 000000  
6657 032066 001116 001162 001164 DT25: ,WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,0  
6658 032074 001166 001170 001172  
6659 032002 000000  
6660 032004 001116 001162 001164 DT103: ,WORD \$ERRPC,\$REG0,\$REG1,0  
6661 032012 000000  
6662  
6663 ,THIS IS THE DATA BUFFER USED TO WRITE THE RANDOM PATTERNS ON THE  
6664 ,DISK AT THE BEGINING, 400 (OCTAL) WORDS ARE WRITTEN AT A TIME, THUS  
6665 ,THIS BUFFER IS 400/8 WORDS LONG.  
6666  
6667 032014 DBUF: NOP  
6668 032014 PGEND: NOP  
6669 000001 ,END

Table with multiple columns listing symbols and their corresponding values. The first column contains symbols like ABORT, ABRT, ABRT1, etc., and the second column contains numerical values. The table continues with symbols like CIENT1, CKSWR, CLMAP, etc., and values up to 001470. The right side of the page has a similar structure with symbols like EXRCBH, FNCHND, FNMAR, etc., and values up to 007772.

Table with multiple columns listing symbols and their corresponding values. The first column contains symbols like QDDEVN, PCMHND, PCNTRP, etc., and the second column contains numerical values. The table continues with symbols like PDR, PFSTHT, PFTEAR, etc., and values up to 022222. The right side of the page has a similar structure with symbols like ST3, ST4, SUPRS, etc., and values up to 005322.



\$SAVR6 027A2J	\$SVPC = 000220	\$TPB 001152	\$STNM 001102	\$TYPON 026020
\$SCOPE 027204	\$SWR = 143000	\$TPFLG 001157	\$TYIN 023474	\$TYPOS 025760
\$SETUP= 000115	\$SWRMK= 000000	\$TPS 001150	\$TYPDS 024020	\$XTSTR 027216
\$SIZE 017466	\$TKB 001146	\$TRAP 027350	\$TYPE 024244	\$GET4= 000000
\$SIZEX 017730	\$TKS 001144	\$TRAP2 027372	\$TYPEC 024414	\$OFILL 026203
\$STUP = 177777	\$TN = 000010	\$TRP = 000022	\$TYPEX 024462	, = 032516
\$SVLAD 027A06	\$TNPWR 024714	\$TRPAD 027404	\$TYPC 026004	

. ABS. 032A16 000

ERRORS DETECTED: 0

,DSKZ:IDZPKHG/SDL=DSKZ:SYSMAC,SML,DSKM:IDZRRHG,P11  
RUN-TIME: 15 22 ,6 SECONDS  
RUN-TIME RATIO: 609/38=15.6  
CORE USED: 36K (71 PAGES)