

.REM -

IDENTIFICATION  
-----

PRODUCT CODE: AC-E911C-MC  
PRODUCT NAME: CXDZBCO DZV11 MODULE  
PRODUCT DATE: SEPTEMBER 1978  
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSIDERED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1976, 1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT:-----

DZB IS AN IOMOD THAT EXERCISES UP TO EIGHT (CONSECUTIVELY ADDRESSED) DZV11 ASYNCHRONOUS INTERFACES. IT USES MAINTENANCE MODE TO TRANSMIT AND RECEIVE A BINARY COUNT PATTERN OUTPUTTED AND RECEIVED IN 32 CHARACTER BURSTS. THE MAJOR PORTION OF THE ERROR CHECKING IS DEFERRED TO PRIORITY LEVEL 0. ALL DEVICES SELECTED FOR TEST ARE ACTIVATED AND RUN CONCURRENTLY. ALL FOUR LINES ARE RUN ON EACH SELECTED DEVICE.

2. REQUIREMENTS:-----

HARDWARE: AT LEAST ONE DZV11 INTERFACE; NO WRAPAROUND OR MAINTENANCE CABLE IS NEEDED

STORAGE: DZB REQUIRES:

- 1. DECIMAL WORDS: 1021
- 2. OCTAL WORDS: 01775
- 3. OCTAL BYTES: 3772

3. PASS DEFINITION:-----

ONE PASS OF THE DZB MODULE CONSISTS OF TRANSMITTING AND RECEIVING 8960. CHARACTERS FOR EACH LINE OF EACH DZV11 SELECTED

4. EXECUTION TIME:-----

EXECUTION TIME IS PROPORTIONAL TO THE BAUD RATE BUT SHOULD TAKE AN AVERAGE OF ONE MINUTE TO COMPLETE ONE PASS WHEN RUNNING ALONE ON A LSI-11 AT 9600. BAUD.

5. CONFIGURATION PARAMETERS:-----

DEFAULT PARAMETERS:

DVA: 1, VCT: 1, BR1: 4, BR2: 4, DVC: 1, SR1: 0

REQUIRED PARAMETERS:

AT CONFIGURATION TIME THE USER MUST SPECIFY:

DVA: ADDRESS OF FIRST DZV11 CSR REG.  
VCT: VECTOR ADDRESS OF FIRST DZV11 CSR REG.  
DVC: NO OF DZV11'S IF GREATER THAN 1

6. -----  
DEVICE OPTION SETUP:-----

NONE REQUIRED

7. -----  
MODULE OPERATION:-----

START: DETERMINE IF ANY DEVICES ARE SELECTED. DO NOT RUN THE MODULE IF NO DEVICES ARE SELECTED. IF THERE ARE SELECTED DEVICES INITIALIZE THE BINARY COUNT PATTERN AT 0. CONTINUE PROCESSING.

RESTR1: INITIALIZE THE ITERATION COUNTER TO 1120. DETERMINE VECTORS TO POINT TO THE JSR LINKING TABLE.

SETUP2: INITIALIZE THE QUEUE POINTERS. CLEAR ALL THE BUFFERS AND QUEUES. CLEAR THE BUFFER ACCESS FLAG (LCKOUT) IN CASE IT WAS STILL SET BY A CONTROL C INTERRUPT OF THE PROGRAM.

ACTVATE: THIS SEGMENT INITIALIZES EACH DZV11 SELECTED. EIGHT BITS PER CHARACTER IS SELECTED. IF A BAUD RATE IS SELECTED IT IS CALCULATED AND ASSIGNED. OTHERWISE THE DEFAULT RATE OF 9600 BAUD IS ASSUMED.

INITIAL: THE DATA PATTERN IS LOADED INTO THE TRANSMITTER BUFFER. IT IS A BINARY COUNT PATTERN WHICH ON SUCCESSIVE ITERATIONS BEGINS 0, 10, 20, 1777 60, 177770. THE NUMBER OF CHARACTERS TO BE TRANSMITTED IS CALCULATED. TRANSMITTER INTERRUPTS ARE ENABLED. ALL SELECTED TRANSMITTERS FOR EACH SELECTED DZV11 ARE ENABLED.

TMRSET: TMRCNT IS USED AS A MULTIPLYING FACTOR TO DETERMINE THE WAITING LENGTH FOR THE WATCHDOG TIMER. IT IS PRESENTLY SET AT 5 TO ALLOW SEVENTY-FIVE SECONDS TO ELAPSE BEFORE TAKING FURTHER ACTION.

TIMER: THIS IS THE WATCHDOG TIMER LOOP. IT IS CONTROLLED BY R4 AND TMRCNT. IF ALL DZV11'S SELECTED GENERATED BOTH TRANSMIT AND RECEIVE INTERRUPTS, THE APPROPRIATE BIT IN DONMFLC FOR THAT DZV11 WILL BE CLEARED. IF THIS DOES NOT OCCUR IN THE GIVEN TIME, THE DEVICE NUMBER OF THE OFFENDING DZV11 WILL BE CALCULATED AND THIS WILL BE REPORTED IN A MODULE MESSAGE. THE OFFENDING DEVICE IS DROPPED FROM THE EXERCISE. IF NO MORE DZV11'S ARE SELECTED THE MODULE ITSELF IS DROPPED FROM THE RUN. IF MORE REMAIN TO BE EXERCISED, HOWEVER, CONTROL IS TRANSFERRED TO "FINISH."

FINISH: CONTROL COMES HERE IF ALL SELECTED DZV11'S WERE SUCCESSFULLY EXERCISED OR IF MORE DZV11'S REMAIN AFTER ONE WAS HUNG. THE ITERATION COUNT IS DECREASED. IF THE COUNT DOES NOT REACH ZERO, CONTROL IS PASSED TO SETUP2 AND THE MODULE IS RUN AGAIN. WHEN THE COUNT REACHES ZERO, AN END OF PASS IS SIGNALLED.

XMTINT: THIS SEGMENT SAVES A POINTER TO THE CSR ADDRESS OF THE INTERRUPTING DZV11 IN A FIRST-IN, FIRST-OUT, WRAPAROUND BUFFER. THE TRANSMITTER QUEUE, NEXT ENTRY POINTER IS THEN UPDATED TO POINT TO THE NEXT ZERO IN THE QUEUE. SERVICE IS DEFERRED TO LEVEL ZERO PRIORITY.

XMTSRV: THIS BLOCK FETCHES A POINTER TO A CSR ADDRESS FROM THE TRANSMITTER QUEUE, AND THE QUEUE IS UPDATED TO THE NEXT ENTRY. THE CSR IS TESTED TO DETERMINE WHAT KIND OF INTERRUPT OCCURRED. FALSE INTERRUPT IS REPORTED. IF EVERYTHING IS CORRECT, THE ADDRESS OF THE BYTE ASSOCIATED WITH THIS LINE, (IN THE TRANSMITTER BUFFER) IS CALCULATED. A CHARACTER IS TRANSMITTED ON THIS LINE. TRANSMITTER INTERRUPTS ARE REENABLED FOR THIS DEVICE. MORE CHARACTERS ARE TO BE TRANSMITTED. IF NO MORE ARE TO BE SENT ON THIS LINE, A DATA POINTER IS BUILT AND THE TRANSMITTER IS DISABLED. IF ALL LINES ARE DISABLED, THE RECEIVER FOR THIS DZV11 IS ENABLED.

RCVINT: THIS SEGMENT SAVES A POINTER TO THE CSR ADDRESS OF THE INTERRUPTING DZV11 IN THE RECEIVER QUEUE. IT DISABLES FURTHER INTERRUPTS FOR THIS DEVICE. IT UPDATES THE QUEUE ENTRY AND RESTORES THE VALUE OF R5 WHICH WAS SAVED BY THE JSR INSTRUCTION FROM THE LINKAGE TABLE.

RCVSRV: THE FIRST TASK IS TO PREVENT VOLATILE REGISTER INFORMATION FROM BEING DESTROYED. THIS IS DONE BY TESTING A SEMAPHORE, "LCKOUT". IF IT IS DONE CONTROL IS RETURNED TO THE MONITOR TO WAIT FOR A FLAG. IF IT IS CLEAR, ACCESS IS PERMITTED. THE FLAG IS SET TO DENY OTHER ACCESS TO THIS DEFERRED ROUTINE. A CSR ADDRESS IS OBTAINED FROM THE QUEUE AND INTERRUPTS ARE CLEARED. THE RECEIVER INTERRUPT AND INTERRUPT ENABLER ARE QUICKLY ASSEMBLED FROM THE DZV11 SLO. EACH FEICH IS CHECKED TO SEE IF THE INFORMATION IS VALID. IF IT IS NOT, THE REGISTER ARE SAVED AND A BREAK LOOP IS USED TO ALLOW MORE TIME FOR THE VALID INFORMATION TO BECOME AVAILABLE. IF AFTER THE ALLOWED TIME ALL THE CHARACTERS ARE STILL NOT RECEIVED, AN ERROR MESSAGE IS REPORTED. IN THE MESSAGE, 16 NUMBERS ARE GIVEN. THE FIRST IS THE NUMBER OF CHARACTERS THAT WERE TRANSMITTED (IN OCTAL). THE NEXT IS THE NUMBER OF CHARACTERS THAT WERE NOT RECEIVED (ALSO IN OCTAL).

CKDATA: THIS SEGMENT INITIALIZES THE LINE CHECK BUFFER (UNCKBY) TO THE FIRST DATA THAT WAS TRANSMITTED. THE DEVICE NUMBER IS SAVED FOR LATER USAGE. THE RECEIVED INFORMATION IS CHECKED FOR VALIDITY AND TRANSMISSION ERRORS. ERRORS ARE HANDLED BY THE 'STATERR', (STATUS ERROR) AND 'DERRR' (DATA ERROR) ROUTINES.

RCVDONE: THIS BLOCK CLEARS THE ACCESS SEMAPHORE TO ALLOW OTHER DEVICES TO USE THE LINE CHECK BUFFER. IT ALSO DISEMBLES THE DEVICE WITH A DEVICE CLEAR. IT THEN BUILDS A ONE BIT MASK USING RO AND THE CARRY BIT TO DELETE THE APPROPRIATE BIT IN THE WATCHDOG TIMER FLAG (DOWFLG). WHEN THIS IS DONE, PROCESSING CONTROL IS RETURNED TO THE MONITOR.

SUBROUTINES

VCFLDAD: THIS ROUTINE IS CALLED IN 'SETUPI'. IT IS USED TO LOAD THE ADDRESS OF THE LINKING INSTRUCTION FOR INTERRUPT SERVICING INTO THE CORRESPONDING VECTOR SPACE. IT ALSO LOADS THE PRIORITY LEVEL AND THE DEVICE ADDRESS. THE LATTER IS LOADED INTO THE APPROPRIATE JSR TABLE ENTRY.

SAVREG: THIS ROUTINE SAVES THE FIVE VOLATILE INFORMATION REGISTERS IN A FIRST-IN, FIRST-OUT WRAPAROUND BUFFER, THE ERROR QUEUE.

GETREG: THIS ROUTINE RETRIEVES THOSE SAME REGISTERS.

GETLINE: THIS ROUTINE CALCULATES HOW MANY CHARACTERS WILL BE TRANSMITTED FOR EACH DEVICE DURING AN ITERATION OF THE PROGRAM. EIGHT CHARACTERS ARE SENT ON EACH SELECTED LINE IN ONE ITERATION. THE TOTAL COUNT IS STORED IN 'XMTCNT'.

BAUDRTE: THIS ROUTINE CALCULATES THE BAUD RATE, ASSIGNS IT, AND SELECTS 8 BITS/CHARACTER COMMUNICATION MODE. IF SRI=0, THE DEFAULT RATE OF 9600. BAUD IS ASSIGNED. THE BAUD RATE SELECTED IS DETERMINED BY THE LEAST SIGNIFICANT (RIGHTMOST) SET BIT IN SRI.

STATERR: THIS ROUTINE DETERMINES WHETHER AN ERROR INDICATED OVERHON ERROR, A FRAMING ERROR, OR A PARITY ERROR. THE DEVICE NUMBER OF THE ERRING DEVICE IS REPORTED AS STATIC. CSRA WILL BE CLEAR.

DERRR: THIS ROUTINE REPORTS A DATA ERROR.

8. OPERATOR OPTIONS  
-----

MODULE LOCATION DVID1 (APC=14) MAY BE MODIFIED (MOD. CMMD) TO EXERCISE ANY COMBINATION OF EIGHT DZV11'S.

MODULE LOCATION SR1 (APC=16) MAY BE MODIFIED TO SELECT A DIFFERENT BAUD RATE. THE FOLLOWING TABLE SHOULD BE USED:

FOR THE BAUD RATE	SR1=	LOC	276=
7200	1	2060	
4800	2	2000	
3600	4	1730	
2400	10	1460	
2200	20	1350	
1800	40	1200	
1200	100	630	
600	200	330	
300	400	150	
150	1000	144	
134.5	2000	120	
110	4000	170	
75	10000	45	
50	20000		

(USING THESE VALUES WILL YIELD AN END OF PASS CLOSE TO ONE MINUTE FO EACH BAUD RATE.)

THE DEFAULT RATE IS 9600 BAUD(SR1=0).

MODULE LOCATION SLCTLIN MAY BE MODIFIED TO RUN ANY COMBINATION OF FOUR LINES. THE COMBINATION IS THEN RUN ON ALL SELECTED DEVICES. THE DEFAULT SELECTION IS ALL FOUR LINES.

NOTE: SLCTLIN FALLS ON A BYTE BOUNDARY!! BE SURE TO RESTORE THE BITS SET IN THE OTHER BYTE !!!

MODULE LOCATION ICONT MAY BE MODIFIED TO VARY THE PERIOD BETWEEN END OF PASS REPORTS.

MODULE LOCATION TMRSET +2 MAY BE MODIFIED TO VARY THE PERIOD OF THE WATCHDOG TIMER. IT IS PRESENTLY SET TO EXPIRE AFTER SEVENTY-FIVE SECONDS WHEN DZB IS RUNNING ALONE.

9.

NON-STANDARD PRINTOUTS:

WHEN A STATUS ERROR IS DETECTED, DZB USES THE ERRORN CALL TO REPORT IT. THE FIRST NUMBER GIVEN IS THE NUMBER OF THE DEVICE (0 TO 7). THE SECOND IS THE CONTENTS OF THE READ BUFFER (DZRBDF = CSR + 2, E.G., 160042).

WHEN ALL CHARACTERS ARE NOT RECEIVED, AN ERRORN CALL IS REPORTED. THE FIRST NUMBER IS THE NUMBER OF CHARACTERS EXPECTED. THE SECOND IS THE NUMBER OF CHARACTERS THAT WERE NOT RECEIVED.

ALL OTHER PRINTOUT IS STANDARD.

10. MNEMONICS

THE FOLLOWING INFORMATION SHOULD BE USEFUL IN UNDERSTANDING  
NAMES GIVEN TO VARIABLES IN THIS PROGRAM.

XMT REFERS TO THE TRANSMITTER  
RCV REFERS TO THE RECEIVER  
ERR REFERS TO ANYTHING TO DO WITH ERROR HANDLING  
FLG REFERS TO A SOFTWARE FLAG USUALLY A BIT FLAG  
QUE REFERS TO A FIRST IN FIRST OUT BUFFER  
TMR REFERS TO SOFTWARE TIMING FUNCTIONS  
CNT REFERS TO A WORD USED AS A COUNTER  
QPT REFERS TO A POINTER ASSOCIATED WITH A QUEUE BUFFER  
LN REFERS TO AN INSERTION POINTER, O IS AN OUTPUT POINTER  
XM IS ANOTHER REFERENCE TO TRANSMITTER  
CT GENERALLY REFERS TO A COUNT

E.G: XMTQPO=TRANSMITTER QUEUE POINTER OUT

OTHERS ARE BASICALLY SELF EXPLANATORY.

```

;*****LIST BIN*****
;*****
000000" 055104 041502 040 BEGIN:
000005" 000000 MODNAM: .ASCII /DZBC / ;MODULE NAME.
000006" 000001 XFLAG: .BYTE OPEN ;USED TO KEEP TRACK OF WBUF USAGE
000010" 000001 ADDR: 1+0 ;1ST DEV
000012" 000001 VECTOR: 1+0 ;1ST DEVICE VECTOR.
000013" 200 BR1: .BYTE PRTY4+0 ;1ST BR LEVEL.
000014" 000001 BR2: .BYTE PRTY4+0 ;2ND BR LEVEL.
000016" 000000 SV1D1: +1 ;DEVICE INDICATOR 1.
000020" 000000 SR1: OPEN ;SWITCH REGISTER 1.
000022" 000000 SR2: OPEN ;SWITCH REGISTER 2.
000024" 000000 SR3: OPEN ;SWITCH REGISTER 3.
000024" 000000 SR4: OPEN ;SWITCH REGISTER 4.
;*****
000026" 140000 STAT: 140000 ;STATUS WORD.
000030" 000314 INIT: START ;MODULE START ADDR.
000032" 000224 SPOINT: MODSP ;MODULE STACK POINTER.
000034" 000000 PASCNT: 0 ;PASS COUNTER.
000036" 002140 ICOUNT: 2140 ;# OF ITERATIONS PER PASS=2140
000040" 000000 ICOUNT: 0 ;LOC TO COUNT ITERATIONS
000042" 000000 SPCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS
000044" 000000 HRCNT: 0 ;LOC TO SAVE TOTAL HARD ERRORS
000046" 000000 SOPPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS
000050" 000000 HRDPAS: 0 ;LOC TO SAVE HARD ERRORS PER PASS
000052" 000000 SYSCNT: 0 ;# OF SYS ERRORS ACCUMULATED
000054" 000000 RANUM: 0 ;HOLDS RANDOM # WHEN RAND MACRO IS CALLED
000056" 000000 CONFIG: 0 ;RESERVED FOR MONITOR USE
000056" 000000 RES1: 0 ;RESERVED FOR MONITOR USE
000060" 000000 RES2: 0 ;RESERVED FOR MONITOR USE
000062" 000000 SVR0: OPEN ;LOC TO SAVE R0.
000064" 000000 SVR1: OPEN ;LOC TO SAVE R1.
000066" 000000 SVR2: OPEN ;LOC TO SAVE R2.
000070" 000000 SVR3: OPEN ;LOC TO SAVE R3.
000072" 000000 SVR4: OPEN ;LOC TO SAVE R4.
000074" 000000 SVR5: OPEN ;LOC TO SAVE R5.
000076" 000000 SVR6: OPEN ;LOC TO SAVE R6.
00100" 000000 CSRA: OPEN ;ADDR OF CURRENT CSR.
00102" 000000 CSRB: OPEN ;ADDR OF GOOD DATA, OR
00102" 000000 ACSR: OPEN ;CONTENTS OF CSR.
00104" 000000 WASADR: OPEN ;ADDR OF BAD DATA, OR
00106" 000000 ASAT: OPEN ;STATUS REG CONTENTS.
00106" 000000 ERRTYP: 0 ;TYPE OF ERROR.
00106" 000000 ASB: OPEN ;EXPECTED DATA.
00110" 000000 AWAS: OPEN ;ACTUAL DATA.
00112" 000334 RSTRT: RSTRT ;RESTART ADDRESS AFTER END OF PASS
00114" 000000 WDR: OPEN ;WORDS TO MEMORY PER ITERATION
00116" 000000 WDRP: OPEN ;WORDS FROM MEMORY PER ITERATION
00120" 000000 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
00122" 000142 IDNUM: 142 ;MODULE IDENTIFICATION NUMBER=142
000224" 000000 MODSP:
;*****
390 000002 RBUF=2 ;DEFINITION OF MODE 6 OFFSET TO THE READ BUFFER
;*****
```

```

391 000002 LPR=2 ;MODE 6 OFFSET TO THE LINE PARAMETER REGISTER
392 000004 TCR=4 ;OFFSET TO THE TRANSMITTER CONTROL REGISTER
393 000006 MSR=6 ;OFFSET TO THE MODEM STATUS REGISTER
394 000006 TDR=6 ;OFFSET TO THE TRANSMITTER DATA REGISTER
395 000010 MAINT=BIT3 ;ENABLE MAINTENANCE MODE BIT
396 000020 DCLR=BIT4 ;DEVICE MASTER CLEAR
397 000040 MSENAB=BIT5 ;ENABLE THE MASTER SCANNER (DEVICE GO)
398 000100 RIE=BIT6 ;RECEIVER INTERRUPT ENABLE
399 010000 SILOEN=BIT12 ;SILO ALARM INTERRUPT ENABLE
400 040000 TIE=BIT14 ;TRANSMITTER INTERRUPT ENABLE
401 010000 RCVON=BIT12 ;TURN THE RECEIVER ON (RECEIVER GO)
402 000030 EIGHT=BIT4|BIT3 ;EIGHT BITS/CHARACTER SELECTION
```



```
403  
404  
405  
406 000224* 000000  
407 000226* 000000  
408 000230* 000000  
409 000232* 000000  
410 000234* 000000  
411 000236* 000040  
412 000276* 000000  
413 000300* 000000  
414 000302* 000000  
415 000304* 000  
416 000305* 000  
417 000306* 017  
418 000307* 000  
419 000310* 000  
420 000311* 000  
421 000312* 000000  
422
```

;THESE ARE THE PROGRAM PARAMETERS

```
LINPAR: OPEN ;SCRATCHWORD USED TO LOAD LINE PARAMETER REGISTERS  
TMRCT: OPEN ;COUNTER FOR WATCHDOG TIMER  
RCVTMR: OPEN ;RECEIVER BREAK LOOP TIMER  
DVCNMR: OPEN ;NUMBER OF DEVICE BEING PROCESSED  
XMTCT: OPEN ;COUNTER OF TOTAL NUMBER OF TRANSMISSIONS  
LNKCT: .BLKB 32. ;TRANSMISSION COUNTERS FOR EACH DEVICE  
BGNDATA: OPEN ;TWO COPIES OF THE FIRST CHARACTER IN TRANSMIT PATTERN  
RCVWORD: OPEN ;USED TO REPORT RECEIVER ERROR  
MISS: OPEN ;USED TO REPORT NUMBER OF CHARACTERS MISSING  
DATA: .BYTE ;CHARACTER BUILDING BYTE  
SELECT: .BYTE OPEN ;ACTIVE DEVICE SELECTION PARAMETER  
SLCTLIN: .BYTE 17 ;ACTIVE LINE SELECTION PARAMETER  
DNFLG: .BYTE OPEN ;WATCHDOG FLAG FOR BUSY DEVICES  
RCVDATA: .BYTE OPEN ;BUFFER FOR CHARACTER CHECKING  
LCKOUT: .BYTE OPEN ;BUFFER ACCESS FLAG  
TEMP1: .WORD 0 ;TEMPORARY STORAGE FOR ASCII CONVERSION  
.EVEN
```

```
423  
424  
425  
426 000314* 105067 177764  
427 000320* 116767 177470 177757  
428  
429 000326* 001002  
430 000330* 104410 000000*  
431  
432  
433  
434  
435  
436  
437 000334*  
438 000334* 116701 177745  
439 000340* 001773  
440  
441 000342* 016700 177442  
442 000346* 016702 177432  
443 000356* 012703 002324*  
444 000356* 000241  
445 000360* 106001  
446 000366* 103410  
447 000366* 001416  
448 000366* 062700 000010  
449  
450 000372* 062703 000020  
451 000376* 062702 000010  
452 000402* 000766  
453 000404* 004567 001344  
454 000410* 000013  
455  
456 000412* 004567 001336  
457 000416* 000012  
458 000420* 000766  
459  
460  
461  
462  
463  
464 000422* 012767 002524* 003262  
465 000430* 012767 002524* 003256  
466  
467 000436* 012767 002544* 003252  
468 000444* 012767 002544* 003246  
469 000452* 012767 002564* 003242  
470 000460* 012767 002564* 003236  
471 000466* 012703 002524*  
472 000472* 012704 000473  
473 000476* 005023  
474 000500* 005304  
475 000502* 001375  
476 000504* 105067  
477 000510* 012703 177601  
478 000510* 012703 000236*
```

;START ROUTINE. DETERMINE IF ANY DZV'S ARE SELECTED  
;IF SO, BEGIN MODULE PROCESSING... IF NOT, DROP THE MODULE FROM THE RUN

```
START: CLR B DATA ;INITIALIZE THE DATA PATTERN WORD  
MOV B DVID1,SELECT ;COPY THE DEVICE SELECTION PARAMETER. ARE  
;ANY DEVICES SELECTED?  
BNE RSTRT ;IF SO, BEGIN PROCESSING. IF NOT, DROP THE MODULE  
DROP: ENDS,BEGIN ;DROP THE MODULE
```

;INITIALIZE THE NUMBER OF PASSES TO BE MADE. SET UP THE DZV11 INTERRUPT  
;VECTORS TO INTERRUPT IN THE SUBROUTINE LINKING TABLE. CALL SUBROUTINE  
;VCTLOAD FOR THIS PURPOSE.

```
RSTRT: MOV B SELECT,R1 ;COPY THE DEVICE SELECTION PARAMETER INTO R1  
SETUP1: BEQ DROP ;IF NO DEVICES SELECTED (ALL FLAGS CLEAR) DROP THE  
;MODULE  
MOV VECTOR,R0 ;LOAD THE VECTOR ADDRESS IN R0  
MOV ADDR,R2 ;LOAD R2 WITH ADDRESS OF FIRST DZ11  
MOV #LNKTAB,R3 ;POINT R3 TO THE BEGINNING OF JSR LINKING TABLE  
CLC ;MAKE SURE CARRY BIT IS CLEAR BEFORE ROTATION  
RORB R1 ;ISOLATE A SELECTION FLAG IN THE CARRY BIT  
RCS ;IF THE FLAG IS SET, GO SET UP THE VECTORS  
REQ SETUP2 ;IF NO FLAGS ARE LEFT, GO SET UP THE BUFFERS  
ADD #10,R0 ;IF MORE FLAGS ARE SET, ADJUST POINTERS. THE  
;VECTOR POINTER IS POINTER...  
ADD #20,R3 ;AND THE ADDRESS POINTER...  
2$: ADD #10,R2 ;GO SET UP THE NEXT DZV11 ADDRESSES  
BR 1$ ;CALL THE VECTOR SETUP ROUTINE FOR RECEIVER  
3$: JSR R5,VCTLOAD ;VECTOR, PASSING THE RECEIVER BR LEVEL AS THE  
;ARGUMENT  
BR 2$ ;SET UP THE TRANSMITTER VECTOR PASSING THE  
;TRANSMITTER BR LEVEL AS THE ARGUMENT  
;GO SETUP THE NEXT DZV11
```

;THIS BLOCK RESETS ALL THE QUEUE POINTERS, CLEARS THE TRANSMITTER TEXT BUFFER, THE  
;RECEIVER BUFFERS, AND THE QUEUES. THIS IS THE BEGINNING OF THE ITERATIVE PART OF THE  
;PROGRAM.

```
SETUP2: MOV #XMTQUE,XMTQPI ;POINT THE TRANSMIT QUEUE ENTRY (IN) POINTER  
;TO THE BEGINNING OF THE QUEUE  
MOV #XMTQUE,XMTQPO ;POINT THE TRANSMIT QUEUE RETRIEVAL (OUT)  
;POINTER TO THE BEGINNING OF THE QUEUE  
MOV #RCVQUE,RCVQPI ;SET UP THE RECEIVER QUEUE POINTERS  
MOV #RCVQUE,RCVQPO ;SETUP THE ERROR QUEUE POINTERS  
MOV #ERRQUE,ERRQPI  
MOV #ERRQUE,ERRQPO ;POINT R3 TO THE BEGINNING OF THE QUEUE AREA  
1$: MOV #XMTQUE,R3 ;USING R4 AS A COUNTER CLEAR  
CLR #315,*R4 ;TRANSMITTER, RECEIVERS, AND ERROR QUEUES...  
DEC R4 ;TRANSMITTER TEXT BUFFER...  
BNE R5 ;RECEIVER SILO BUFFERS  
CLR B ;CLEAR THE BUFFER ACCESS FLAG  
MOV LNKMCT,R3 ;POINT TO THE CHARACTER COUNTER FOR EACH LINE
```

```

479 000514 012704 000040
480 000524 012704 000010
481 000524 005304
482 000526 001374
483
484
485
486
487 000530 116700 177551
488 000534 117273 177427
489 000540 016701 177242
490 000544 106000
491 000546 103404
492 000550 001426
493 000552 062701 000010
494 000556 000772 000020
495 000560 012711 000004
496 000564 012702 000004
497 000570 012767 010030 177426
498 000576 004767 001324
499 000602 052711 000010
500 000606 016701 177412 000002
501 000614 005302
502 000616 001755
503 000620 005257 177400
504 000624 000770
505
506
507
508
509 000626 012701 002646
510 000632 116700 177446
511 000636 110067 177434
512 000642 110067 177431
513
514 000646 012702 000040
515 000652 110021
516 000654 005302
517 000656 001375
518 000660 062700 000010
519 000664 110067 177414
520 000670 116700 177411
521 000674 016701 177106
522 000700 004767 001162
523 000704 106000
524 000706 106000
525 000710 103404
526 000712 001411
527 000714 062701 000010
528 000720 000772
529 000722 052711 040040
530 000726 116701 177354 000004
531 000734 000767
532

```

```

533
534
535
536
537
538
539 000736 012767 000005 177262
540 000744 005004
541 000746 005004
542 000746 104407 000000
543 000752 104407 000000
544 000756 105767 177325
545
546 000762 001437
547 000764 005304
548 000766 001367 177232
549 000770 005367
550 000774 001363
551
552 000776 116703 177305
553
554 001002 140367 177277
555 001006 006003
556
557 001010 103402
558
559 001012 005204
560
561 001014 000774
562 001016 010467 177270
563
564
565
566 001022 104420 000000 000312
567 001030 003756
568
569 001032 004767 000734
570 001036 104403 000000 003742
571 001044 004767 000760
572 001050 105767 177231
573 001054 001002
574
575 001056 104410 000000
576
577
578
579 001062 104413 000000
580 001062 104413 000000
581
582 001066 000167 177436
583
584
585
586
587
588

```

```
589  
590 001072 010577 002614 XMTINT: MOV R5,XMTQPI ;LOAD THE OFFSET TO THE CSR INTO TRANSMITTER QUEUE  
591 001076 022767 000002 ADD #2,XMTQPI ;UPDATE THE QUEUE ENTRY POINTER  
592 001112 103003 002542 CMP #XMTQVE+16,XMTQPI ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?  
593 001114 012767 002524 BHS IS ;IF NO, CONTINUE PROCESSING  
594 001122 012605 002570 1$: MOV #XMTQVE,XMTQPI ;IF YES, RESET THE POINTER TO QUEUE BEGINNING  
595 (SP)+,R5 ;RESTORE THE PREVIOUS R5 VALUE  
596  
597 001124 000004 000000 001132 *PIRQS,BEGIN,XMTRSV ; QUEUE UP TO CONTINUE AT XMTRSV AND RTI  
598  
599 XMTRSV: MOV #XMTQPO,R1 ;FETCH THE OFFSET FROM THE QUEUE  
600 ADD #2,XMTQPO ;UPDATE THE QUEUE RETRIEVAL POINTER  
601 001144 022767 002542 CMP #XMTQVE+16,XMTQPO ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?  
602 001152 103003 002524 BHS IS ;IF NO, CONTINUE PROCESSING  
603 001154 012767 002524 1$: MOV #XMTQVE,XMTQPO ;IF YES, RESET POINTER TO BEGINNING OF THE QUEUE  
604 001162 011100 000000 MOV (R1),R0 ;LOAD CSR ADDRESS INTO R0  
605 001164 005710 000000 TST (R0) ;IS THIS A VALID INTERRUPT?  
606 001166 100420 000000 BMI ZS ;IF YES, GO ENABLE RECEIVER INTERRUPT  
607 001170 010067 176704 MOV R0,CSRA ;IF NO, SET UP THE CSR ADDRESS FOR ERROR REPORTING  
608 001174 011067 176702 MOV (R0),ACSR ;SET UP THE CONTENTS  
609 001200 004767 000566 JSR PC,SAVREG ;SAVE THE REGISTERS BEFORE ERROR MESSAGE  
610 001204 012767 000011 MOV #11,ERRTYP ;SET THE ERROR TYPE  
611 *****  
612 001212 104405 000000 000000 *HDRER,BEGIN,NUIL ;RECEIVER INTERRUPT REQUEST FROM TRANSMITTER  
613 *****  
614 JSR PC,GETREG ;RESTORE THE REGISTERS  
615 EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.  
616 2$: MOV #R1,R2 ;GET THE LINE NUMBER FROM THE HIGH BYTE OF CSR  
617 001224 042702 177774 BIC #177774,R2 ;ISOLATE THE LINE NUMBER IN R2  
618 001240 016103 000002 MOV #1,R3 ;GET THE NUMBER OF THIS DEVICE  
619 001244 006303 000000 ASL R3 ;MULTIPLY THE DEVICE NUMBER BY FOUR  
620 001246 006203 000000 ADD R2,R3 ;CALCULATE THIS LINE'S TABLE OFFSET  
621 001252 042710 040000 BIC #TIE,(R0) ;DISABLE INTERRUPTS BEFORE AN OVERRUN OCCURS  
622 001256 105763 000236 *TS7B LNXMCT(R3) ;ALL CHARAC TRANSMITTED?  
623 001262 010197 000000 MOV #8,R3 ;IF SO, RESET THE COUNT OF CHARACTERS  
624 001264 112763 000010 MOV #1,R3 ;SET A BIT POINTER IN R3  
625 001272 012703 000001 DEC R2 ;USE R2 AS A COUNT OF ROTATIONS TO MAKE  
626 001276 100302 000000 BNE R3 ;IF POINTER NOW AT THE RIGHT LINE?  
627 001302 006303 000000 ASL R3 ;IF NOT, POINT IT TO THE NEXT LINE  
628 001304 000774 000000 BR ZS ;GO SEE IF THIS IS THE LINE  
629 001306 003600 000004 4$: BIC R3,TCR(R0) ;IF SO, DISABLE TRANSMITTERS ON THIS LINE  
630 001314 052710 000100 BR ZS ;OTHERWISE, TRANSMITTERS ARE ACTIVE, GO EXIT  
631 001320 000411 000000 BR ZS ;OTHERWISE, DISABLE THE RECEIVER  
632 001322 116360 002646 5$: MOV #XMTBUP(R3),TDR(R0) ;SKIP RESETTING THE INTERRUPT ENABLE  
633 001324 105363 000236 *LXNCT(R3) ;LOAD THE CHAR INTO TRANS BUFFER  
634 001334 105363 000236 *LXNCT(R3) ;CREATE ONE CHARACTER  
635 001340 052710 040000 BIC #TIE,(R0) ;COUNT A CHARAC FOR THIS LINE  
636 001344 104400 000000 6$: BIC #TIE,(R0) ;RESTART TRANS. INTERRUPTS  
637 7$: EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
```

```
641 ;RECEIVER INTERRUPT SERVICE ROUTINE  
642 ;THIS ROUTINE STORES A POINTER TO THE CSR ADDRESS OF THE INTERRUPTING DEVICE IN THE  
643 ;RECEIVER QUEUE. SERVICE IS DEFERRED TO PRIORITY LEVEL 0. AT DEFERRED SERVICE (RCVSRV),  
644 ;THE OFFSET IS FETCHED FROM THE QUEUE. THE INTERRUPT AND INTERRUPT ENABLE BITS ARE  
645 ;CLEARED AND THE SILO IS EMPTIED INTO THE SOFTWARE BUFFER. IF ALL CHARACTERS  
646 ;WERE NOT RECEIVED, THIS IS REPORTED. CHECK THE BUFFER AND REPORT DATA ERRORS. IF  
647 ;ANOTHER RECEIVER IS ALREADY USING THE LINE CHECK BUFFER (LNXMCT), SUBSEQUENT  
648 ;RECEIVERS WILL NOT BE PERMITTED ACCESS UNTIL THE FIRST IS COMPLETE. IF THERE  
649 ;ARE ANY CHARACTER ERRORS REPORT THEM. WHEN ALL DATA IS CHECKED, IT RELEASES  
650 ;THE LINE CHECK BUFFER AND CLEAR THE CORRESPONDING BIT IN DONFLG.  
651  
652 RCVINT: MOV R5,RCVQPI ;STORE THE OFFSET IN THE RETRIEVAL QUEUE  
653 001350 010577 002342 BIC #TIE,@(R5)+ ;DISABLE THIS RECEIVER'S INTERRUPTS BEFORE  
654 001354 042735 000100 ;OTHER LINES OVERRUN THE QUEUES  
655 ADD #2,RCVQPI ;UPDATE THE QUEUE ENTRY POINTER  
656 001360 062767 000002 002330 CMP #RCVQVE+16,RCVQPI ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?  
657 001366 022767 002562 002322 BHS IS ;IF NO, CONTINUE PROCESSING  
658 001374 103003 002544 002312 1$: MOV #RCVQVE,RCVQPI ;IF YES, RESET THE POINTER TO QUEUE BEGINNING  
659 (SP)+,R5 ;RESTORE THE PREVIOUS VALUE OF R5  
660 001404 012605 000000 *PIRQS,BEGIN,RCVSRV ; QUEUE UP TO CONTINUE AT RCVSRV AND RTI  
661  
662 RCVSRV: LCKOUT ;TEST THE BUFFER LOCK FLAG. IS ACCESS PERMITTED?  
663 001414 105767 176671 BEQ #11 ;IF YES, GO SET THE LOCK AND CHECK THE DATA  
664 001420 001405 000000 BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR  
665 001422 104407 000000 BREAKS,BEGIN ;THEN CONTINUE AT NEXT INSTRUCTION.  
666 001426 104407 000000 BR RCVSRV ;TRY TO ACCESS AGAIN  
667 001432 000770 000000 COMB ;DENY OTHER ACCESSES TO THE BUFFER  
668 001434 105167 176651 MOV #RCVQPO,R0 ;FETCH THE OFFSET FROM THE QUEUE  
669 001440 017700 002254 ADD #2,RCVQPO ;UPDATE THE QUEUE RETRIEVAL POINTER  
670 001444 062767 000002 002240 CMP #RCVQVE+16,RCVQPO ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?  
671 001452 022767 002562 002240 BHS IS ;IF NO, CONTINUE PROCESSING  
672 001460 103003 002544 002230 1$: MOV #RCVQVE,RCVQPO ;IF YES, RESET THE POINTER TO THE QUEUE BEGINNING  
673 001462 012767 (R0),R1 ;LOAD THE CSR ADDRESS INTO R1  
674 001470 012000 BIC #30300,(R1)+ ;DISABLE RECEIVER INTERRUPT AND INTERRUPT ENABLE  
675 001472 042721 030300 AND POINT R1 TO THE NEXT RECEIVED CHAR. REGISTER  
676  
677 MOV (R0),R2 ;LOAD THE SOFTWARE SILO BUFFER ADDRESS  
678 001476 011002 HSL #200,RCVTRM ;SET THE RECEIVER BREAK LOOP TIMER  
679 001500 016703 176522 MOV #XMTCNT,R3 ;SET THE COUNT FOR STORING THE DATA  
680 001506 016703 176522 MOV (R1),(R2)+ ;STORE A WORD IN THE SOFTWARE SILO  
681 001512 011122 BGE R3 ;IF THE DATA WASN'T VALID, GO ALLOW A LITTLE TIME FOR IT  
682 001514 002003 DEC R3 ;IF IT WAS VALID, REDUCE THE COUNT  
683 001516 005303 BNE ZS ;IF NOT ZERO, STORE THE NEXT WORD  
684 001520 001374 BR ZS ;IF ALL CHARACTERS RECEIVED, GO CHECK THEM  
685 001522 000434 TST -R2 ;RESET R2 TO THE PROPER BUFFER LOCATION  
686 001524 005744 JSR PC,SAVREG ;SAVE THE REGISTER VALUES  
687 001532 104407 000240 BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR  
688 001534 104407 000000 BREAKS,BEGIN ;THEN CONTINUE AT NEXT INSTRUCTION.  
689 001536 104407 000000 JSR PC,GETREG ;RESTORE THE REGISTER VALUES  
690 001542 004767 000262 DEC R3 ;HAS ENOUGH TIME BEEN PERMITTED FOR A CHARACTER?  
691 001544 005367 176456 BPL ZS ;IF NO, TRY TO GET ONE  
692 001552 100357 MOV -(R0),CSRA ;LOAD THE DEVICE ADDRESS  
693 001554 014067 176320 MOV @R0+,ACSR ;LOAD THE CSR CONTENTS  
694 001560 013067 176316 MOV #0,R3 ;REPORT THE NUMBER OF CHARACTERS MISSING  
695 001564 010367 176312 JSR PC,SAVREG ;SAVE THE REGISTERS  
696 001570 004767 000176
```

```

697 001574 012767 000014 176304      MOV      #14,ERRTYP
698 *****
699 001602 104405 000000 003726      HDRERS,BEGIN,TAB1 ;DID NOT RECEIVE ALL TRANSMITTED CHARACTERS
700 *****
701 001610 004767 000214              JSR      PC,GETREG
702
703 ;THIS ROUTINE PERMITS ONE DEVICE TO HAVE ITS DATA CHECKED.
704 ;THE DATA IS CHECKED
705 ;FOR EACH LINE OF THE DEVICE. DATA ERRORS ARE REPORTED.
706
707 001614 012705 003706      CKDATA: MOV      #LNCKBF,R5 ;POINT TO THE BEGINNING OF THE BUFFER
708 001620 016728 178452      MOV      @R5,R0 ;SET UP FOUR LINE CHECK BYTES
709 001624 016725 176446      MOV      @R5,R1
710 001630 011009 000010 176372      MOV      10(R0),DVCNMBR ;SAVE THE NUMBER OF THIS DEVICE
711 001632 016067 000010 176370      MOV      @R2,R0 ;LOAD THE SOFTWARE SILO ADDRESS IN R2
712 001640 016703 176370 3$: MOV      @R2,R0 ;LOAD COUNT TO COMPARE CHARACTERS
713 001644 012200 070000      MOV      @R2,R0 ;FETCH A WORD FROM THE SILO INTO R0
714 001646 002024      BGE      RCVDONE ;IF IT'S INVALID, GO CLEAN UP BUFFERS
715 001650 032700      BIT      #70000,R0 ;ARE THERE ANY TRANSMISSION ERRORS?
716 001654 001402      BRQ      4$ ;IF NO, GO DETERMINE THE LINE NUMBER
717 001656 004767 000322      JSR      PC,STATERR ;IF YES, GO DETERMINE THE ERROR TYPE
718 001662 001067 176422      MOV      R0,RCVDATA ;SAVE THE RECEIVED CHARACTER
719 001664 000300      SBC      R0,R0 ;PUT THE LINE NUMBER IN R0'S LOWER BYTE
720 001670 042700 177774      BIT      #177774,R0 ;ISOLATE THE LINE NUMBER IN R0
721 001674 126067 003706 176406      CMPB    LNCKBF(R0),RCVDATA ;IS THE DATA CORRECT?
722 001702 001409      BRQ      5$ ;IF YES, GO CHECK THE NEXT CHARACTER
723 001704 004767 000336      JSR      PC,ERRROR ;IF NO, GO REPORT A DATA ERROR
724 001710 105260 003706      JSR      PC,LNCKBF(R0) ;SET UP THE NEXT CHARACTER FOR THIS LINE
725 001714 005303      DEC      R3 ;REDUCE THE COUNT, ARE ALL CHARACTERS CHECKED?
726 001716 001352      BNE      3$ ;IF NO, GO CHECK THE NEXT CHARACTER.
727
728 ;THIS ROUTINE UNLOCKS THE LINE CHECK BUFFER TO PERMIT ACCESS BY OTHER DEVICES.
729 ;IT THEN COMPUTES THE LINE NUMBER AND CLEARS THE APPROPRIATE FLAG FROM THE WATCHDOG
730 ;TIMER BYTE.
731
732 001720 105067 176365      RCVDONE:CLRB   LCKOUT ;RESET THE BUFFER ACCESS SEMAPHORE
733 001724 012741 000020      MOV      #0,LCKOUT ;CLEAR THIS DEVICE AND DISABLE IT
734 001730 005000      CLR      R0 ;THE DELETION FLAG WILL PROPAGATE IN R0
735 001732 000261      SBC      R0,R0 ;USE THE CARRY BIT TO BUILD THE DELETION FLAG
736 001734 006100      ROL      R0 ;MOVE THE FLAG TO THE NEXT DEVICE
737 001736 005367 176270      DEC      DVCNMBR ;WHEN THIS NUMBER IS NEGATIVE, THE CORRECT
738 001742 002374      BGE      1$ ;DEVICE IS POINTED TO.
739 001744 004767 176337      BITB    1$,DOWNFLG ;CLEAR THIS FLAG
740 001750 104400 000000      EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
741

```

```

742 ;SUBROUTINES
743 -----
744
745 ;THE FIRST IS THE VECTOR LOADING SUBROUTINE. THE VECTOR ADDRESS IS PASSED IN R0,
746 ;THE DEVICE ADDRESS IS PASSED IN R2. THE LINKING TABLE ADDRESS IS PASSED IN R3.
747 ;THE BUS REQUEST PRIORITY LEVEL IS A PARAMETER TAKEN INDIRECTLY THROUGH R5.
748
749 001754 010320      VCTLOAD:MOV   R3,(R0)+ ;LOAD THE ADDRESS OF THE LINKING INSTRUCTION
750 001756 113520      MOV      @R3,(R0)+ ;AND THE PRIORITY LEVEL INTO THE VECTOR
751 001760 005200      INC      R0 ;POINT R0 TO THE NEXT VECTOR ADDRESS
752 001762 023323      CMP      (R3),(R3)+ ;POINT R3 TO THE CSR INSERT LOCATION
753 001764 010223      MOV      @R2,(R3)+ ;LOAD THE DEVICE ADDRESS IN THE LINK TABLE
754 001766 005723      TST      (R3)+ ;ALIGN R3 FOR THE NEXT DEVICE
755 001770 000205      RTS      R5 ;RETURN TO CALLING BLOCK
756
757 ;THIS ROUTINE SAVES THE REGISTER VALUES IN THE ERROR QUEUE, A FIRST-IN,
758 ;FIRST-OUT DISCIPLINE WRAPAROUND BUFFER.
759
760 001772 016705 001724      SAVREG: MOV   ERROPI,R5 ;USE R5 FOR INDEXING CAPABILITY
761 001776 010025      MOV      R0,(R5)+ ;SAVE R0...
762 002000 010125      MOV      R1,(R5)+ ;SAVE R1...
763 002002 010225      MOV      R2,(R5)+ ;SAVE R2...
764 002004 010325      MOV      R3,(R5)+ ;SAVE R3...
765 002006 010425      MOV      R4,(R5)+ ;AND R4
766 002010 022705 002644      CMP      #ERRQUE+60,R5 ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?
767 002014 103000      BHIS    1$ ;IF NO, GO RELOAD THE POINTER
768 002016 012705      MOV      #ERRQUE,R5 ;RESET R5 TO THE QUEUE BEGINNING
769 002022 010567 001674      MOV      PC,ERRQPI ;SET THE ENTRY POINTER TO NEXT ENTRY POINT
770 002026 000207      RTS      PC ;RETURN TO THE CALLING BLOCK
771
772 ;THIS ROUTINE RETRIEVES REGISTER VALUES FROM THE ERROR QUEUE
773
774 002030 016705 001670      GETREG: MOV   ERROPI,R5 ;USE R5 FOR INDEXING CAPABILITY
775 002034 012500      MOV      (R5),R0 ;RETRIEVE R0...
776 002036 012501      MOV      (R5),R1 ;R1...
777 002040 012502      MOV      (R5),R2 ;R2...
778 002042 012503      MOV      (R5),R3 ;R3...
779 002044 012504      MOV      (R5),R4 ;AND R4
780 002046 022705 002644      CMP      #ERRQUE+60,R5 ;HAS THE QUEUE BOUNDARY BEEN EXCEEDED?
781 002052 103002      BHIS    1$ ;IF NO, GO RELOAD THE POINTER
782 002054 012705      MOV      #ERRQUE,R5 ;RESET R5 TO THE QUEUE BEGINNING
783 002060 010567 001640      MOV      PC,ERRQPI ;SET THE RETRIEVAL POINTER TO THE NEXT FETCH POINT.
784 002064 000207      RTS      PC ;RETURN TO THE CALLING BLOCK
785
786 ;THIS ROUTINE CALCULATES HOW MANY CHARACTERS ARE BEING TRANSMITTED IN EACH PATTERN
787
788 002066 116702 176214      GETLINE:MOVB  SLCTLIN,R2 ;COPY THE LINES SELECTED PARAMETER
789 002072 005067 176136      CLR      XMTCNT ;RESET THE TOTAL TRANSMISSION COUNT
790 002076 106007      1$: ROBB   R2 ;GET A SELECTION BIT INTO THE CARRY BIT
791 002100 005567      ADC      XMTCNT ;ADD IT TO TOTAL NUMBER OF ACTIVE LINES
792 002104 105702      TSTB   R2 ;ARE ALL LINES CHECKED?
793 002106 001373      BNE      1$ ;IF NOT, GO CHECK THE REST
794 002110 006367 176120      ASL      XMTCNT ;NOW MULTIPLY BY 8
795 002114 006367 176114      ASL      XMTCNT ;DO THIS BY SHIFTING THREE TIMES
796 002120 006367 176110      ASL      XMTCNT ;WE NOW KNOW HOW MANY CHARACTERS ARE IN EACH BURST
797 002124 000207      RTS      PC ;RETURN TO THE CALLING SEGMENT

```

```

798
799
800 ;THIS ROUTINE CALCULATES THE BAUD RATE FROM THE SRI OPTION. IF SRI IS 0, THE DEFAULT
801 ;RATE OF 9600. IS ASSIGNED. THE LEAST SIGNIFICANT BIT IS THE ONLY ONE CONSIDERED.
802 ;THE BAUD RATE IS THEN LOADED INTO THE LINE PARAMETER WORD.
803 002126- 005767 175664 BAUDRATE:TSR SRI ;IS A SPECIFIC RATE SELECTED?
804 002134- 001418 ;IF NO, GO ASSIGN THE DEFAULT RATE
805 002140- 016704 175656 MOV SRI,R4 ;IF YES COPY SRI
806 002140- 012703 000015 MOV #15,R3 ;SET UP THE BIT CONFIGURATION FOR A BAUD RATE SELECTION
807 002144- 006000 1$: ROR R4 ;ISOLATE THE NEXT BIT IN THE CARRY BIT
808 002146- 003403 BCS 23 ;IF THIS IS THE BIT, PUT TOGETHER THE BAUD RATE
809 002150- 005303 DEC R3 ;IF NOT, CALCULATE THE NEXT BIT CONFIGURATION
810 002152- 000413 BMI 45 ;IF NONE OF THE BITS WERE SET, RETURN TO THE CALLING PRO
811 002154- 000773 BR 15 ;GO CHECK THE NEXT ALTERNATIVE
812 002156- 150367 176043 R3,LINPAR+1 ;PLACE THE BAUD RATE IN THE LINE PARAMETER REGISTER
813 002162- 000207 2$: RTS PC ;RETURN TO THE CALLING PROCEDURE
814 002164- 052767 007000 176032 3$: BIS #7000,LINPAR ;SET THE DEFAULT RATE(9600. BAUD)
815 002172- 104407 000000 BREAKS,BEGIN ;TEMPORARY RETURN TO MONITOR...
816 002176- 104407 000000 BREAKS,BEGIN ;THEN CONTINUE AT NEXT INSTRUCTION.
817 002202- 000207 4$: RTS PC ;RETURN TO CALLING PROCEDURE
818
819 ;THIS ROUTINE DETERMINES WHAT TYPE OF ERROR WAS INDICATED BY THE SILO AND REPORTS EACH
820
821 002204- 010067 176070 STATERR:MOV R0,RCVWORD ;COPY THE INFORMATION RECEIVED
822 002210- 011167 MOV (R1),CSRA ;GET THE CONTENTS OF THE CONTROL REGISTER
823 002214- 010167 MOV R1,ACSR ;REPORT THE CSR CONTENTS
824 002216- 014767 175646 JSR PC,SAVREG ;SAVE THE REGISTERS
825 002224- 012767 000011 175654 MOV #17,CRRTP
826 *****
827 002232- 104405 000000 003734- HDRS,BEGIN,TAB2 ;DEVICE RECEIVER ERROR
828 *****
829 002240- 004767 177564 JSR PC,GETREG ;RESTORE THE REGISTERS
830 002244- 000207 RTS PC ;RETURN TO CALLING PROCEDURE
831
832 ;THIS ROUTINE CALCULATES THE BUFFER ADDRESSES OF THE INCORRECT DATA AND REPORTS THE ERRO
833
834 002246- 004767 177520 DERROR:JSR PC,SAVREG ;SAVE THE PRESENT REGISTER VALUES
835 002254- 005741 TST -(R1) ;POINT TO THE CSR ADDRESS AGAIN
836 002254- 016704 175620 MOV R1,CSRA ;SHOW WHICH DEVICE IT WAS
837 002260- 116067 003706- 175620 MOVB LNKBF(R0),ASB ;LOAD THE CORRECT DATA VALUE
838 002266- 116767 176016 MOVB RCVDATA,AKAS ;LOAD THE ACTUAL DATA VALUE
839 002274- 005742 TST -(R2) ;GET THE SILO ADDRESS OF THE DATA
840 002276- 010267 175602 MOV R2,ASADR ;LOAD IT FOR REPORTING
841 002302- 062700 003706- ADD #LNKBF,R0 ;CALCULATE THE CORRECT VALUE ADDRESS
842 002306- 010067 175570 MOV R0,SBADR ;REPORT IT
843 *****
844 002312- 104404 000000- DATERS,BEGIN ;DATA ERROR!!!
845 *****
846 002316- 004767 177506 JSR PC,GETREG ;RESTORE THE REGISTERS
847 002322- 000207 RTS PC ;RETURN TO THE CALLING PROCEDURE
848
849 ;LINKAGE TABLE
850 ;EACH ENTRY CONSISTS OF A JSR INSTRUCTION FOLLOWED BY A LOCATION INTO WHICH THE CSR IS
851 ;LOADED, FOLLOWED BY THE SILO BUFFER ADDRESS, FOLLOWED BY A JSR INTO THE TRANSMITTER
852 ;INTERRUPT, THE CSR ADDRESS WORD, AND THE NUMBER OF THE INTERRUPTING DEVICE
853

```

```

854 002324- 004567 177020 LNKTAB:JSR R5,RCVINT ;LINK FOR RECEIVER 0
855 002330- 000000- 0 SILO0
856 002334- 002706- 175632 JSR R5,XMTINT ;LINK FOR TRANSMITTER 0
857 002334- 004567 0
858 002340- 000000- 0
859 002344- 000000- 0
860 002344- 004567 177000 JSR R5,RCVINT ;LINK FOR RECEIVER 1
861 002350- 000000- 0
862 002352- 003006- 176512 SILO1
863 002354- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 1
864 002362- 000001- 0
865 002364- 004567 176760 JSR R5,RCVINT ;LINK FOR RECEIVER 2
866 002370- 000000- 0
867 002374- 001306- 176472 SILO2
868 002374- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 2
869 002400- 000000- 0
870 002400- 000000- 0
871 002404- 000000- 2
872 002404- 004567 JSR R5,RCVINT ;LINK FOR RECEIVER 3
873 002410- 000000- 0
874 002412- 003206- 176452 SILO3
875 002414- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 3
876 002420- 000000- 0
877 002422- 000003- 3
878 002424- 004567 176720 JSR R5,RCVINT ;LINK FOR RECEIVER 4
879 002430- 000000- 0
880 002430- 003306- 176432 SILO4
881 002434- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 4
882 002440- 000000- 0
883 002442- 000004- 4
884 002444- 004567 JSR R5,RCVINT ;LINK FOR RECEIVER 5
885 002450- 000000- 0
886 002452- 003406- 176412 SILO5
887 002454- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 5
888 002460- 000000- 0
889 002462- 000005- 5
890 002464- 004567 JSR R5,RCVINT ;LINK FOR RECEIVER 6
891 002470- 000000- 0
892 002472- 003506- 176372 SILO6
893 002474- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 6
894 002500- 000000- 0
895 002504- 000009- 9
896 002504- 004567 JSR R5,RCVINT ;LINK FOR RECEIVER 7
897 002510- 000000- 0
898 002512- 003606- 176352 SILO7
899 002514- 004567 JSR R5,XMTINT ;LINK FOR TRANSMITTER 7
900 002520- 000000- 0
901 002522- 000007- 7
902
903 ;THESE ARE THE QUEUES.
904
905 002524- 000010 XMTQUE: .BLKW 8. ;TRANSMITTER SERVICE QUEUR
906 002544- 000010 RCVQUE: .BLKW 8. ;RECEIVER SERVICE QUEUR
907 002564- 000031 ERRRQUE: .BLKW 25. ;ERROR SERVICE QUEUR
908
909 ;THESE ARE THE BUFFERS

```

```

910
911 002646* 000040 XMTBUF: .BLKB 32. ;TRANSMITTER BUFFERS, ONE CHARACTER FOR EACH LINE
912 003706* 000040 SILO0: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 0
913 003006* 000040 SILO1: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 1
914 003106* 000040 SILO2: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 2
915 003206* 000040 SILO3: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 3
916 003306* 000040 SILO4: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 4
917 003406* 000040 SILO5: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 5
918 003506* 000040 SILO6: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 6
919 003606* 000040 SILO7: .BLKW 32. ;RECEIVER BUFFER FOR DEVICE 7
920 003706* 000040 LNCKBF: .BLKB 4. ;BUFFER FOR CHECKING INDIVIDUAL LINE DATA
921
922 ;THESE ARE THE QUEUE POINTERS
923
924 XMTQPI: OPEN ;TRANSMITTER QUEUE ENTRY (IN) POINTER
925 XMTQPO: OPEN ;TRANSMITTER QUEUE RETRIEVAL POINTER (OUT)
926 RCVQPI: OPEN ;RECEIVER QUEUE POINTERS
927 RCVQPO: OPEN
928 ERROPI: OPEN ;ERROR QUE POINTERS
929 ERROPO: OPEN
930
931 ;THESE ARE THE ASCII MESSAGES AND ERROR PRINTOUT TABLES
932
933 TAB1: XMTCNT ;TABLE 1 IS USED TO REPORT XMTCNTING CHAPACTERS
934 ;FIRST, THE NUMBER TRANSMITTED IS GIVEN
935 ;THEN THE NUMBER OF CHARACTERS NOT RECEIVED
936 ;TERMINATOR FOR TABLE 1
937 TAB2: DVCNMBR ;TABLE 2 IS USED TO REPORT RECEIVER ERRORS
938 ;WORD CONTAINING THE ERRORS
939 ;TERMINATOR FOR TABLE 2
940 HUNG: M1
941 177777
942
943 003746* 042504 044526 042503 M1: .ASCII "DEVICE "
944 003756* 026040 M2: .BLKB 6
945 003764* 044040 047125 000107 M3: .ASCII " HUNG"
946
947 .EVEN
948 .END

```

```

ACSR 000102R 377# 608* 694* 823*
ACTVAT 000530R 487# 582
ADDR 000106R 343# 442 489 521
ADDR22= 001006R 398#
ASB 000106R 381# 837*
ASTAT 000104R 379#
AWAS 000106R 393# 838#
BADDRT 002126R 492# 803#
BEGIN 000000R 340# 431 542 543 566 570 575 580 597 612 615 640 662
BCNDAT 000276R 666# 667 688 699 709
BIT0 = 000001 396#
BIT1 = 000002 390#
BIT10 = 002000 390#
BIT11 = 000100 390#
BIT12 = 010000 390# 399 401
BIT13 = 020000 390#
BIT14 = 040000 390# 400
BIT15 = 100000 390#
BIT2 = 000004 390#
BIT3 = 000010 390# 395 402
BIT4 = 000020 390# 402
BIT5 = 000040 390# 397
BIT6 = 000100 390# 398
BIT7 = 000200 390#
BIT8 = 000400 390#
BIT9 = 001000 390#
BREAKS= 104407 390# 542 543 666 667 688 689 815 816
BR1 000012R 345# 457
BR2 000013R 346# 454
BTODS = 104411 390#
CDATA = 104412 390#
CKDATA 001614R 685 707#
CONFIG 000056R 362#
CSRA 000100R 375# 607* 693* 822* 836*
DATA 000304R 415# 426* 510 519*
DATCK = 104411 390#
DATERS = 104402 390# 844
DCR 000020 396# 495 733
DERRDR 002246R 723# 834#
DONFLG 000307R 418# 544 552 739*
DRDP 000330R 430# 435
DVCNMB 002126R 409# 711* 737* 937
DVID1 = 000014R 347# 427
EIGHT = 000030 402# 497
ENDIT = 104413 390# 580
ENWS = 104419 390# 431
ERRQPI 003722R 470# 575 769* 928#
ERRQPO 003724R 471# 774 783* 929#
ERRQUE 002564R 470 471 766 768 780 782 907#
ERRYP 000106R 380# 610* 691* 825*
EXITS = 104400 390# 615 640 740
FINISH 001062R 546 573 579#
GETLIN 002066R 362# 788#
GETTAB = 104415 390#
GETREC 002030R 571 614 690 701 774# 829 846

```



TIMER	000744R	540#	550																
IMRCNT	000226R	407#	539*	549*															
IMRSET	000736R	526#	539#																
TRPDFD	000022	396#																	
VCTLOA	001754R	453#	456	749#															
VECTOR	000010R	344#	441																
WASADR	000104R	378#	840*																
WDFR	000116R	383#																	
WDTD	000114R	383#																	
XFLAG	000005R	342#																	
XMTBUF	002546R	506#	635	636*	911#														
XMTCNT	000234R	410#	680	712	789#														
XMTINT	001072R	590#	857	863	869	791*	794*	795*	796*	933									
XMTQPI	003712R	464#	590*	591*	592	594*	594*	594*	594*	881	887	893	899						
XMTQPD	003714R	464#	599	600*	601	603*	603*	603*	603*	924#									
XMTQUE	002524R	464	466	472	592	594	601	601	601	925#									
XMTSRV	001132R	597	599#							603	905#								
.	= 003772R	411#	905#	906#	907#	911#	912#	913#	914#	915#	916#	917#	918#	919#					
.		920#	945#																

. ABS. 000000 000  
 003772 001

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

XDZBC0, XDZBC0/SOL/CRF:SYH=DDXCOM, XDZBC0  
 RUN-TIME: 23.4 SECONDS  
 RUN-TIME RATIO: 19/5=3.7  
 CORE USED: 7K (13 PAGES)