

IDENTIFICATION

-----

PRODUCT CODE:           MAINDEC-11-DZRXA-E-D  
PRODUCT NAME:           RX11 SYSTEM RELIABILITY TEST  
DATE:                    APRIL 1976  
MAINTAINER:             DIAGNOSTIC ENGINEERING  
AUTHOR:                  DAVID L. ADAMS

COPYRIGHT (C) 1975,1976  
DIGITAL EQUIPMENT CORPORTION, MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO THESE LICENSE TERMS. TITLE TO AND OWNERSHIP OF THE SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.

THE INFOMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATIUN.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFRWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

## TABLE OF CONTENTS

-----

### 1.0 GENERAL PROGRAM INFORMATION

- 1.1 ABSTRACT
- 1.2 SYSTEM REQUIREMENTS
  - 1.2.1 HARDWARE
  - 1.2.2 SOFTWARE

### 2.0 OPERATING INSTRUCTIONS

- 2.0.1 OUTLINE OF OPERATING PROCEDURE
- 2.1 LOADING PROCEDURE
- 2.2 STARTING ADDRESSES
- 2.3 OPERATOR ACTION BEFORE STARTING PROGRAM
  - 2.3.1 DEVICE ADDRESS SELECTION
  - 2.3.2 NON-STANDARD DISKETTE ADDRESS SELECTION
  - 2.3.3 SOFTWARE SWITCH REGISTER (LOC. 176)
  - 2.3.4 TEST PARAMETER SELECTION ("DTESTP" LOC. 1212)
- 2.4 OPERATOR ACTION TO RUN THE PROGRAM
  - 2.4.1 STARTING THE PROGRAM
  - 2.4.2 OPERATING CONDITIONS
  - 2.4.3 ACT11 & XXOP HOOKS
- 2.5 PROGRAM OPTIONS
  - 2.5.1 PSEUDO SCOPE LOOP
  - 2.5.2 DISKETTE COMPATABILITY
  - 2.5.3 RX11 TO RX8 COMPATABILITY
- 2.6 RUN TIME

### 3.0 ERROR DETECTION

- 3.1 ERROR DEFINITIONS
- 3.2 DEFINITIVE ERROR CODES
- 3.3 UNEXPECTED OR MISSING ERROR CONDITIONS
- 3.4 POWER FAILURE
- 3.5 PROGRAM HUNG

### 4.0 ERROR REPORTING

### 5.0 HALTS

1,0 GENERAL PROGRAM INFORMATION

1,1 ABSTRACT

THE RX11 SYSTEM RELIABILITY PROGRAM CONSISTS OF SELECTABLE TESTS THAT CHECK THE OPERATION OF THE RX11 SYSTEM, BY WRITING, READING AND VERIFYING VARIOUS DATA PATTERNS, UNDER VARIOUS (SELECTABLE) HEAD MOVEMENTS. IT CAN TRANSFER DATA AND CHECK FOR ERRORS OVER THE ENTIRE DISKETTE, ALL TRACKS AND SECTORS, OR BETWEEN SEPARATELY SELECTABLE TRACK AND SECTOR ADDRESS LIMITS.

AS WELL AS TRANSFERRING DATA THE PROGRAM ACCUMULATES STATISTICAL DATA ON THE FOLLOWING:

- A. COMPLETED PASSES OF THE PROGRAM
- B. NUMBER OF RESTARTS
- C. NUMBER OF SECTORS WRITTEN/READ
- D. RECOVERABLE AND UNRECOVERABLE FAULTS AS FOLLOWS:

- 1. PARITY ERRORS
- 2. ERROR FLAG ERRORS
- 3. INTERRUPT ERRORS
- 4. SEEK ERRORS
- 5. DATA CRC ERRORS
- 6. CRC NO DATA ERRORS
- 7. DATA NO CRC ERRORS
- 8. DELETED DATA MARK ERRORS
- 9. WRITE ERRORS
- 10. READ ERRORS

- E. TOTAL OF EACH ERROR CODE DETECTED
- F. TOTAL OF TIMES EACH TRACK WAS ACCESSED
- G. TOTAL OF TIMES HEAD MOVED TO A TRACK.
- H. TOTAL OF ERRORS DETECTED PER TRACK PER DRIVE.

THE ABOVE INFORMATION IS REPORTED BY RUNNING THE ERROR DUMP PROGRAM.

1,2 SYSTEM REQUIREMENTS

1,2.1 HARDWARE REQUIREMENTS

THE FOLLOWING EQUIPMENT IS REQUIRED.

- A. PDP-11 SERIES OF COMPUTER WITH MIN 8K MEMORY
- B. RX11 FLOPPY DISK SYSTEM INCLUDING DUAL OR SINGLE DRIVE RX01 AND PDP-11 INTERFACE. (SEE SECTION 2.3 FOR SELECTION OF REGISTER ADDRESSES AND VECTOR ADDRESS)  
NOTE: A DISKETTE MUST BE INCLUDED WITH EACH DRIVE TESTED.
- C. CONSOLE TELEPRINTER

1,2.1 SOFTWARE REQUIREMENTS

THIS PROGRAM ASSUMES THAT THE RX11 INTERFACE DIAGNOSTIC ( MAINDEC = 11 - DZRXB-\* ) HAS BEEN SUCCESSFULLY RUN ON THIS SYSTEM.

## 2.0 OPERATING INSTRUCTIONS

### 2.0.1 OUTLINE OF OPERATING PROCEDURE

THE STANDARD OPERATING PROCEDURE FOR THE RX11 RELIABILITY TEST (TO RUN ALL TESTS ON BOTH DRIVES WITH NO OPERATOR INTERVENTION VIA THE SWITCH REGISTER) IS AS FOLLOWS:

- A. LOAD THE PROGRAM INTO MEMORY
  - 1. IF IT'S BEING LOADED FROM A DISKETTE, REPLACE THE "LIBRARY DISKETTE" WITH A "SCRATCH DISKETTE"
- B. START THE PROGRAM RUNNING AT LOCATION 200
- C. THE PROGRAM WILL TYPE OUT THE FOLLOWING:
  - 1. PROGRAM NAME AND REVISION
  - 2. RX11 REGISTER AND VECTOR ADDRESSES
  - 3. UNITS BEING TESTED
  - 4. "P"ATTERN, "T"EST, AND "S"EQUENCE

IT THEN STARTS RUNNING UNDER THOSE CONDITIONS
- D. IF THERE ARE NO ERRORS, AT THE END OF THE COMPLETED PASS A "D" AND "BELL" IS TYPED, AND THE PROGRAM WILL CONTINUE ON FOR ANOTHER PASS.
- E. HALT THE PROGRAM AS FOLLOWS:
  - 1. IF THERE IS A HARDWARE SWITCH REGISTER, PUT SW 14 UP TO HALT AT THE END OF PASS.
  - 2. IF THERE IS NO SWITCH REGISTER, OR TO HALT AT ANY TIME, HALT THE PROCESSOR.

### 2.1 LOADING PROCEDURE

LOAD THE PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR BINARY PAPER TAPES.

MAKE SURE THAT THE TOTAL SYSTEM IS READY FOR OPERATION, DISKETTE INSERTED CORRECTLY, DOORS CLOSED ON DRIVES TO BE TESTED, ETC.

### 2.2 STARTING ADDRESSES

THE PROGRAM HAS THREE (3) STARTING LOCATIONS.

#### 2.2.1 INITIAL START (LOC. 200)

THIS STARTING LOCATION INITIALIZES THE PROGRAM AS FOLLOWS:

- A. CLEARS ALL ERROR LOGS
- B. RESETS COUNTERS AND CONSTANTS
- C. TYPES OUT RX11 REGISTER AND VECTOR ADDRESSES BEING USED.
- D. TYPES THE DRIVE AND TEST SELECTION IN "DTESTP"
- E. INITIATES THE COLLECTION OF STATISTICAL DATA PERTAINING TO THE OPERATION OF THE RX11 SYSTEM.

2.2.2 RESTART (LOC. 202)

THIS STARTING LOCATION DIRECTS THE PROGRAM TO CONTINUE RUNNING USING DRIVE AND TEST SELECTIONS SPECIFIED IN THE PREVIOUS INITIAL START. IT ALSO CONTINUES TO ACCUMULATE STATISTICAL INFORMATION, AMENDING IT TO THE DATA ALREADY COLLECTED PRIOR TO THIS RESTART.

2.2.3 ERROR DUMP (LOC. 204)

THIS STARTING ADDRESS DIRECTS THE PROGRAM TO PRINT OUT ON THE CONSOLE TELEPRINTER ALL THE DATA ACCUMULATED FROM THE LAST "INITIAL START" TO THE TIME OF THE PRINTOUT. TYPING OUT THIS INFORMATION DOES NOT DESTROY IT, SO A RESTART CAN BE INITIATED AND INFORMATION WILL CONTINUE TO BE COLLECTED.

2.3 OPERATOR ACTION BEFORE STARTING PROGRAM

2.3.1 DEVICE ADDRESS SELECTION

LIKE MOST OPTIONS ON THE PDP11 THE RX11 INTERFACE CARD HAS JUMPERABLE REGISTER AND VECTOR ADDRESSES. THIS ALLOWS FOR DEVICES WITH THE SAME STANDARD ADDRESSES TO BE JUMPERED TO AN OTHER ADDRESS SO THEY WILL RUN WITHOUT CONFLICT.

THE PROGRAM MUST KNOW WHAT ADDRESSES ARE BEING USED, AS IT IS THROUGH THESE REGISTERS AND VECTOR THAT ALL COMMUNICATION BETWEEN THE PDP11 AND RX11 IS HANDLED.

IF THE RX11 SYSTEM UNDER TEST IS JUMPERED FOR REGISTER ADDRESS OTHER THAN STANDARD, WHICH IS RXCS=177170 AND RXDB=177172. PLACE IN THE MEMORY LOCATION CALLED "RXCS" (LOC. 1206) ITS NEW ADDRESS, AND IN LOCATION "RXDB" (LOC. 1210) ITS NEW ADDRESS. IF THERE AS A NONSTANDARD INTERRUPT VECTOR ADDRESS (STANDARD IS LOC 264) THEN PLACE IN MEMORY LOCATION CALLED "INTVEC" (LOC. 1204) ITS NEW ADDRESS.

IF THESE THREE MEMORY LOCATIONS DO NOT CONTAIN THE ADDRESSES THAT THE INTERFACE BOARD IS WIRED TO THE PROGRAM WILL REPORT "TEST HUNG" AND HALT, OR HALT AT THE VECTOR ADDRESS THAT IS JUMPERED IN. (NOTE: THE VECTOR ADDRESSES CAN NOT BE JUMPERED FOR LOCATIONS 200 THROUGH 220 AS THESE ARE USED BY THE PROGRAM)

2.3.2 NON-STANDARD DISKETTE ADDRESS SELECTION

IF IT IS DESIREABLE TO TEST THE DISKETTES BETWEEN TRACK AND SECTOR ADDRESS LIMITS OTHER THAN BETWEEN THE NORMAL OUTER DIAMETER (OD) AND INNER DIAMETER (ID) TRACK ADDRESSES, AND/OR MINIMUM (FIRST) AND MAXIMUM (LAST) SECTOR ADDRESS. THIS IS DONE BY THE OPERATOR MAKING CHANGES TO TWO (2) MEMORY LOCATIONS BEFORE THE PROGRAM IS STARTED. ONE LOCATION IS CALLED OD WHICH CONTAINS TWO BYTES ONE FOR OD AND THE OTHER ID TRACK ADDRESSES. THE OTHER LOCATION IS CALLED FIRST AND IT TOO CONTAINS TWO BYTES ONE FOR FIRST THE OTHER FOR LAST SECTOR ADDRESS. (IF THESE TWO LOCATIONS ARE LEFT CLEARED THE MAX AND MIN VALUES FOR THE ADDRESSES ARE ASSUMED.)

A. DEFINITIONS:

- OD = ADDRESS OF TRACK AT OUTER DIAMETER (MIN VALUE=0)
- ID = ADDRESS OF TRACK AT INNER DIAMETER (MAX VALUE=114 [OCTAL])
- FIRST = ADDRESS OF FIRST SECTOR OF TRACK (MIN VALUE=1)
- LAST = ADDRESS OF LAST SECTOR OF TRACK (MAX VALUE=32 [OCTAL])

B. LOCATIONS:

TRACKS LOC. 1200 BITS	14-----8	6-----0
	ID	OD
SECTORS LOC. 1202 BITS	12-----8	4-----0
	LAST	FIRST

C. RESTRICTIONS:

THE CONTENTS OF "OD" MUST BE LESS THAN OR EQUAL TO THE CONTENTS OF "ID"  
THE CONTENTS OF FIRST MUST BE LESS THAN OR EQUAL TO THE CONTENTS OF "LAST"

IF THESE LOCATIONS ARE CHANGED TO NEW LIMITS, THEN THE PROGRAM WILL ACCESS ONLY THOSE ADDRESSES INCLUSIVE OF AND BETWEEN THESE LIMITS.

### 2.3.3 SOFTWARE SWITCH REGISTER (LOC. 176)

FOR THE PDP 11 PROCESSORS THAT DO NOT HAVE A HARDWARE SWITCH REGISTER, OR IF THE OPERATOR WISHES TO SELECT THE SOFTWARE SWITCH REGISTER, BY PUTTING ALL THE SWITCHES UP TO A "1", (THIS MUST BE DONE EACH TIME THE PROGRAM IS STARTED AT LOCATION 200, OTHERWISE THE PROGRAM WILL USE THE HARDWARE SWR.) LOCATION 176 IS ASSIGNED AS THE SWITCH REGISTER. BITS SET TO A "1" IN THIS LOCATION HAVE THE SAME FUNCTION AS THE CORRESPONDING SWITCH IN THE HARDWARE SWITCH REGISTER. ALL REFERENCES TO THE SWR ARE INDIRECT AND THE PROGRAM ASSIGNS THE CORRECT ADDRESS OF THE SWR AT "INITIAL START". SEE SECTION 2.4.2 FOR THE SELECTION OF OPERATING CONDITIONS.

TO CHANGE THE SOFTWARE SWR, WHILE THE PROGRAM IS RUNNING, TYPE "CONTROL G". EACH TIME THE SWR IS TO BE TESTED THE PROGRAM WILL CHECK TO SEE IF THE SOFTWARE SWR IS SELECTED, AND THE PROGRAM IS NOT RUNNING IN AUTO MODE OF RXDP/ACT11. IF BOTH CONDITIONS EXIST THEN THE PROGRAM CHECKS FOR THE CTRL G IN THE KEYBOARD BUFFER. IF THE CTRL G IS THERE THE CONTENTS OF THE SOFTWARE SWR ARE PRINTED AND A "NEW =" IS ASKED FOR. THE OPERATOR MAY NOW TYPE IN THE NEW SWITCH REGISTER CONTENTS, TERMINATED BY A CARRIAGE RETURN (CR), OR IF HE DOESN'T WANT TO CHANGE THE SWR, JUST TERMINATE WITH THE (CR), NOTE SEE THE CHARACTER RESTRICTIONS BELOW.

WHEN THE PROGRAM DETECTS THE (CR) IT WILL REPLACE THE CONTENTS OF THE SOFTWARE SWR, IF A NEW ONE HAS BEEN TYPED IN, AND RETURN TO THE FLOW OF THE PROGRAM.

NOTE: CHARACTER RESTRICTIONS FOR CHANGING THE SOFTWARE SWR.

1. ONLY OCTAL NUMBERS 0 - 7 ARE ACCEPTED. ANY OTHER CHARACTER TYPED WILL BE PRINTED AS A ? AND THE WHOLE SWR MUST BE RETYPED.
2. TO WIPE OUT A "NEW" CONTENTS JUST TYPED IN, TYPE CTRL U. NOW A NEW CONTENTS CAN BE RETYPED.
3. ONLY 6 OCTAL CHARACTERS WILL BE PUT INTO THE SWR. IF MORE THAN 6 CHARACTERS ARE TYPED IN ONLY THE LAST 6 WILL BE PUT INTO THE SWR.

2.3.4 TEST PARAMETER SELECTION ("DTESTP" LOC. 1212)

THE DRIVE AND TEST SELECTION MUST BE DONE BEFORE THE PROGRAM STARTS. "DTESTP" (LOCATION 1212) IS WHERE THE BITS ARE SET TO TELL THE PROGRAM WHAT DRIVES ARE WANTED AND WHAT TEST TO RUN, AS INDICATED BELOW. WHEN THE PROGRAM STARTS IT WILL TYPE OUT THE TEST CONDITIONS IT IS RUNNING UNDER.

BIT 15 (1) SELECT DRIVE UNIT 1  
BIT 14 (1) SELECT DRIVE UNIT 0

THEN SET THE TEST CONDITIONS IN BITS 8 THROUGH 0 AS SHOWN BELOW.

"DTESTP" BITS 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0  
U1 U0 NOT USED U P P P T T T S S S

BIT 9 IF BIT 9 IS ON, ALL WRITE/READ FUNCTIONS WILL BE IN THE DELETED DATA MODE.  
BIT 8,7,6 SELECTS A DATA PATTERN TO BE USED.  
BIT 5,4,3 SELECTS A TEST TO BE PERFORMED.  
BIT 2,1,0 SELECTS A HEAD MOVEMENT SEQUENCE.

THE SELECTIONS ARE DEFINED AS FOLLOWS:

P = DATA PATTERN SELECTION

0 DEFAULT TO 7  
1 ZEROS  
2 ONES  
3 FLOATING ZERO  
4 FLOATING ONE  
5 125  
6 314  
7 RANDOM

T = FUNCTIONAL TESTS

0 DEFAULT TO 7  
1 WRITE ONLY  
2 WRITE/READ  
3 WRITE/READ CHECK  
4 READ CHECK ONLY  
5 READ ONLY (CRC CHECK)  
6 WRITE/READ CHECK UN ALTERNATING DRIVES \*  
7 WRITE/READ/READ CHECK \*\*

\* NOTE: TEST 6 WRITES THEN READ CHECKS ANY SELECTED DATA PATTERN USING ANY TRACK SEQUENCE, BUT ONE TRACK AT A TIME. FIRST ON UNIT 0 THEN UNIT 1. WHEN BOTH UNITS HAVE ACCESSED THAT TRACK, IT GOES BACK TO UNIT 0 FOR THE NEXT TRACK, ETC.



\*\* NOTE: THE FIRST HALF OF TEST 7 FORCES THE TRACK SEQUENCE TO INCREMENT UP THROUGH ALL TRACKS DOING WRITE/READ CHECK FUNCTIONS. THIS VERIFIES THAT ALL TRACKS ARE ACCESSABLE. THE SECOND HALF OF THE PASS WILL USE THE SEQUENCE SELECTED BY THE OPERATOR AS INDICATED BELOW, AND ONLY READ CHECK THE DATA JUST WRITTEN. THIS VERIFIES THAT THE DATA CAN BE READ FROM A TRACK AFTER THE HEAD HAS BEEN MOVED AWAY FROM AND BACK TO THAT TRACK. AT THE COMPLETION OF THE PASS THE DELETED DATA BIT IN TEST CONDITIONS IS COMPLEMENTED AND THE NEXT PASS WILL BE RUN UNDER THIS NEW CONDITION.

S = TRACK SEQUENCING

0	DEFAULT TO 7
1	INCREMENT
2	DECREMENT
3	INCREMENT/DECREMENT
4	BOUNCE
5	DECREASING BOUNCE
6	STROBE
7	RANDOM

IF NO BITS ARE SET (ZEROED "DTESTP:") THEN THE PROGRAM WILL SELECT ALL DRIVE UNITS THAT ARE READY AND DEFAULT TO TEST CONDITIONS AS INDICATED.

THE PROGRAM NEXT PRINTS THE REGISTER AND VECTOR ADDRESSES IT WILL USE IN COMMUNICATING WITH THE RX11 SYSTEM, AS EXPLAINED IN SECTION 2.3.1 THE OPERATOR MUST VERIFY THAT THESE ADDRESSES ARE THE ONES JUMPERED ON THE RX11 INTERFACE BOARD.

2.4 OPERATOR ACTION TO RUN THE PROGRAM

2.4.1 STARTING THE PROGRAM

SET THE DESIRED STARTING ADDRESS INTO THE SWITCH REGISTER, DEPENDING UPON THE TYPE OF CONSOLE AVAILABLE, LOAD ADDRESS, AND PRESS START.

THE PROGRAM WILL TYPE ITS "MAINDEC" NUMBER AND REVISION, AND DEPENDING UPON THE STARTING ADDRESS DO THE FOLLOWING:

SA200 - THE PROGRAM WILL TYPE DRIVE AND TEST PARAMETERS, THE TWO REGISTER ADDRESSES, AND VECTOR ADDRESS. IT WILL THEN BEGIN FUNCTIONAL TESTING, AND INFORMATION COLLECTION.

SA202 - THE PROGRAM WILL CONFIGURE TO CONDITIONS SET IN PREVIOUS "INITIAL START", PRINT OUT THESE CONDITIONS AND CONTINUE FUNCTIONAL TESTING AND DATA COLLECTING. THE ONLY OPERATOR ACTION REQUIRED IS THE DYNAMIC SELECTION OF OPERATING CONDITIONS IN THE SWITCH REGISTER AS REQUIRED.

SA204 - THIS PROGRAM WILL REPORT VIA THE TELEPRINTER ALL DATA COLLECTED. NO OTHER OPERATOR ACTION IS REQUIRED.

## 2.4.2 OPERATING CONDITIONS

THE PROGRAM CHECKS FOR OPERATING CONDITIONS AT VARIOUS POINTS WHILE RUNNING. IF THERE IS A HARDWARE SWR THESE CONDITIONS CAN BE CHANGED AND SET WHILE THE PROGRAM IS RUNNING. IF THE SOFTWARE SWR IS IN USE, THEN THESE CONDITIONS MUST BE SET IN LOCATION 176 BEFORE THE PROGRAM STARTS.

SW15 = HALT ON ERROR  
SW14 = HALT AT END OF PASS  
SW13 = DON'T PRINT ERROR MESSAGE  
SW12 = TYPE ONLY 10 DATA ERRORS  
SW11 = NO RETRY ON ERROR. LOG HARD ERROR  
SW08 = NO RECALIBRATION ON SEEK ERRORS  
SW15-SW0 (1) = SELECT SOFTWARE SWITCH REGISTER

NOTE: IF THERE IS A HARDWARE SWITCH REGISTER, AND THE OPERATOR WANTS THE SOFTWARE SWITCH REGISTER. PUT ALL SWITCHES UP (1) BEFORE STARTING THE PROGRAM AT THE INITIAL START ADDRESS.

THE PROGRAM WILL PRINT A "DRIVE(S)" SELECTED CONFIRMATION MESSAGE THAT IT WAS SUCCESSFUL IN FINDING AT LEAST ONE DRIVE READY (DRY) CONDITION ON AN OPERATOR SELECTED DRIVE OR EITHER OR BOTH IF NO SELECTION WAS MADE. THE DRIVES CONFIRMED AS BEING SELECTED BY THE PROGRAM MAY DIFFER FROM THAT SELECTED BY THE OPERATOR IF THE PROGRAM DETECTED A DRIVE TO BE NOT READY.

IF HOWEVER THERE ARE NO DRIVES IN THE DRIVE READY CONDITION THE PROGRAM WILL TYPE "NO DRIVES READY" AND HALT, AS IT CAN'T FUNCTION WITH NO DRIVES READY. WHEN THE REASON FOR ALL DRIVES TO BE NOT READY IS FOUND AND CORRECTED, THE OPERATOR MAY PRESS CONTINUE AND THE PROGRAM WILL GO BACK TO "INITIAL START" OR HE MAY RELOAD THE STARTING ADDRESS HIMSELF.

AS WELL AS "DRIVE(S)" SELECTED THE PROGRAM WILL TYPE OUT THE TEST PARAMETERS SELECTED OR DEFAULTED TO. IF NON-STANDARD TRACK AND/OR SECTOR ADDRESS LIMITS WERE SELECTED (SEE SECTION 2.3.2 OF THIS DOCUMENT) THESE LIMITS WILL ALSO BE PRINTED OUT FOR VERIFICATION BY THE OPERATOR.

## 2.4.3 ACT11 & XXDP HOOKS

THE PROGRAM HAS THE NECESSARY LOCATIONS SET UP FOR OPERATION UNDER ACT11 AND XXDP OPERATION. THE PROGRAM LOOKS AT THE LOADING MEDIA LOCATION AND IF IT CONTAINS THE NUMBER 10, INDICATING THE FLOPPY DISK LOADED THE PROGRAM, WILL TYPE THE FOLLOWING PROMPT MESSAGE & WAIT FOR A USER RESPONSE:

"CAUTION - IF YOU DESIRE TO TEST UNIT 0  
REPLACE LOAD MEDIUM WITH A SCRATCH DISKETTE  
THEN PRESS CONTINUE"

THUS, IF THE OPERATOR WISHES TO TEST DRIVE UNIT 0, AFTER LOADING THE PROGRAM, HE REMOVES THE LIBRARY DISKETTE FROM DRIVE 0, INSERTS A SCRATCH DISKETTE INTO DRIVE 0, AND PRESSES THE 'CONTINUE' SWITCH

## 2.5 PROGRAM OPTIONS

THERE ARE A COUPLE OF WAYS THE PROGRAM CAN BE SET UP TO RUN FOR OPTIONAL TESTING.

### 2.5.1 PSEUDO - SCOPE LOOP

BY SETTING THE ADDRESS LIMITS IN OD AND OR FIRST TO ONE OF TWO TRACKS AND OR SECTORS IT IS POSSIBLE TO PRODUCE A FAIRLY TIGHT PSEUDO - SCOPE LOOP. BY RUNNING ONLY A TEST THAT DOES WRITE ONLY OR READ ONLY ITS POSSIBLE TO SCOPE SPECIFIC FUNCTIONS, I.E. FILL BUFFER, WRITE, READ, EMPTY BUFFER.

### 2.5.2 DISKETTE COMPATABILITY

TO CHECK FOR DATA TRANSFER COMPATABILITY BETWEEN DRIVE UNITS USE THE FOLLOWING PROCEDURE. (IT IS ASSUMED THE SYSTEM HAS DUAL DRIVE RX01, IF NOT YOU MAY TEST COMPATABILITY BETWEEN DIFFERENT RX11 SYSTEMS BY RUNNING THE SAME TESTS ON BOTH.)

THIS TEST INSURES PROPER HEAD ALIGNMENT.

- A. HAVE DISKETTES IN BOTH DRIVES AND DRIVES READY.
- B. CLEAR THE OD/ID AND FIRST/LAST MEMORY LOCATION, FOR TOTAL DISKETTE TRANSFERS.
- C. LOAD THE INITIAL START ADDRESS (LOC 200) AND START THE PROGRAM RUNNING.
- D. SET LOCATION "DTESTP" FOR "DRIVE AND TEST CONDITIONS" ON BOTH DRIVES, ANY "P"ATTERN OF DATA, "S"EQUENCE #1 (INCRIMENT TRACKS, TO INSURE ALL HEAD POSITIONS ARE ALIGNED) AND "T"EST 3 (WRITE/READ CHECK). THIS WILL WRITE THEN READ AND VERIFY THE DATA ON BOTH DISKETTES.
- E. ALLOW THE PROGRAM TO RUN FOR AT LEAST 1 COMPLETE PASS.

NOTE: IF RANDOM PATTERN (0 OR 7) IS SELECTED YOU MUST HALT AT THE END OF THE FIRST PASS, AS ADDITIONAL PASSES CHANGES THE DATA AND YOU WILL GET DATA ERRORS WHEN YOU TRY TO REREAD.

TO HALT AT THE END OF PASS PUT SW14 UP (1) WHEN "OPERATING CONDITIONS" ARE REQUESTED BY THE PROGRAM.

- F. AFTER COMPLETION OF THE PASS, PROGRAM HALTED. SWAP DISKETTES, AND AS YOU ONLY WANT TO READ VERIFY THE DATA, START THE PROGRAM AGAIN AT LOC 200 (INITIAL START).
- G. WHEN REQUESTED SELECT THE SAME DRIVES, PATTERN, AND SEQUENCE, BUT SELECT TEST 4 (READ CHECK ONLY).
- H. ALLOW THE PROGRAM TO RUN AS LONG AS YOU WISH TO VERIFY THAT DATA WRITTEN AND CHECKED ON ONE DRIVE CAN BE READ AND VERIFIED ON THE OTHER DRIVE.

### 2.5.3 RX11 TO RX8 COMPATABILITY

TO WRITE A DISKETTE ON THE RX11 AND READ/VERIFY THE SAME DATA ON A RX8 REQUIRES THE FOLLOWING:

A. SET UP LOCATION "DTESTP" (1212) WITH ONE OF THE FOLLOWING DATA PATTERNS

P=1	(0'S)
P=2	(1'S)
P=5	(125) *
P=6	(314) *

\* NOTE: IF ONE OF THESE PATTERNS IS SELECTED A MODIFICATION TO THE PROGRAM MUST BE MADE TO ALLOW THIS DATA TO BE READ ON A RX8 SYSTEM. THE MODIFICATION IS IN THE "PAT125" ROUTEEN, THE TWO (2) LOCATIONS CONTAINING THE "COMB DATABYTE" INSTRUCTION MUST BE CHANGED TO TWO (2) NOP'S (OCTAL 000240)

B. SET IN "DTESTP" TEST 3 WHICH WILL WRITE AND READ CHECK THE DATA THEREBY VERIFYING THE QUALITY OF THE DATA PRIOR TO THE DISKETTE SWAP.

SET THE SEQUENCE TO 1 TO INSURE THAT ALL TRACKS HAVE BEEN WRITTEN ON.

C. HALT THE PROGRAM AT THE COMPLETION OF ONE PASS.

D. THE DISKETTE IS NOW READY TO BE READ ON THE RX8 SYSTEM. SEE MD-8-DIRX8-\* FOR THE PROCEDURE TO READ THIS DISKETTE.

TO READ A DISKETTE THAT WAS WRITTEN ON A RX8 SYSTEM SET UP AS FOLLOWS:

E. SET IN "DTESTP" THE DATA PATTERN THAT WAS USED BY THE RX8 SYSTEM. (SEE NOTE UNDER SECTION A.)

F. SET "DTESTP" FOR TEST 4 (READ CHECK ONLY) AND SEQUENCE 1 TO CHECK ALL TRACKS. START THE PROGRAM, IT SHOULD RUN WITHOUT DATA ERRORS.

## 2.6

### RUN TIME

RUN TIME PER PASS DEPENDS UPON NUMBER OF A FUNCTIONS IN THE TEST SELECTED AND THE TRACK SEQUENCE.

EXAMPLES OF RUN TIMES FOLLOW.

(THESE TIMES ARE FOR 1 DRIVE AND COMPLETE DISKETTE, MAXIMUM ID/OD, FIRST/LAST LIMITS, IF OPERATING ON 2 DRIVES DOUBLE THE TIME.) THESE TIMES ARE FOR A PDP 11/05 PROCESSOR AND MAY CHANGE SLIGHTLY FOR A FASTER PROCESSOR.

TEST SELECTION	P	T	S	TIME/PASS
	7	6	5	3 MIN.30 SEC.
	7	7	4	2 MIN.47 SEC.
	7	7	7	2 MIN.23 SEC.
	6	3	4	1 MIN.46 SEC.
	7	3	1	1 MIN.30 SEC.
	7	1	1	51 SEC.

NOTE: DUE TO THE SLOW SPEED OF THE LSI 11 PROCESSOR, THE RUN TIME IS ABOUT DOUBLE THAT LISTED ABOVE. TO SPEED UP THE RUNNING OF THIS PROGRAM IN THE LSI 11 YOU CAN CHANGE THE INTERLEAVE FACTOR, OF THE SECTORS, USED IN THE PROGRAM, TO DO THIS CHANGE THE CONTENTS OF LOCATION "THREE" FROM OCTAL 3 TO OCTAL 5.

## 3.0 ERROR DETECTION

### 3.1 PROGRAM DEFINITIONS

ON MOST ERRORS THE PROGRAM WILL TYPE OUT THE CONTENTS OF "STATUS A" AND "STATUS B".

STATUS A IS THE CONTENTS OF THE RXES (ERROR AND STATUS REGISTER) AT THE TIME THE ERROR IS DETECTED, IT SHOWS THE CRC, PAR, ETC. ERRORS.

STATUS B IS THE "DEFINITIVE ERROR CODES" THAT THE RX01 DETECTED, THAT MAY HAVE CAUSED THE ERROR CONDITION, THESE ERROR CODES ARE DEFINED IN SECTION 3.2.

THE PROGRAM HAS DEFINED THE FOLLOWING AS ERRORS.

#### 3.1.1 WRITE ERROR

A WRITE ERROR IS A RETRIED READ ERROR IF THE DATA BEING READ IS OF UNKNOWN QUALITY (THE DATA READ IS BEING READ FOR THE FIRST TIME AFTER A WRITE FUNCTION)

#### 3.1.2 READ (CRC) ERROR

A READ ERROR IS A RETRIED READ ERROR WHERE THE QUALITY OF THE DATA BEING READ IS KNOWN GOOD. (THE DATA HAS BEEN READ CORRECTLY SOME TIME PREVIOUSLY.)

3.1.3 CRC AND DATA ERROR

3.1.4 NO CRC ERROR BUT DATA ERROR

3.1.5 CRC ERROR BUT NO DATA ERROR

THE ABOVE THREE ERRORS ARE DETECTED WHEN THE PROGRAM IS VERIFYING THE DATA READ OFF THE DISKETTE AGAINST THE DATA THAT SHOULD HAVE BEEN READ.

UPON A NON-COMPARISON THE PROGRAM TYPES OUT THE "BYTE" NUMBER IN THE SECTOR, THE DATA READ FROM THE DISKETTE "BAD" AND THE EXPECTED DATA "GOOD".

BYTE#      BAD      GOOD  
(THE DATA PATTERNS ARE FORMATTED AS SHOWN)

0            (TRACK ADDRESS; BITS 6 - 0)  
1            (SECTOR ADDRESS; BITS 4 - 0)

BYTES 2 THROUGH 125 CONTAIN THE SELECTED "P"ATTERN.

126          (THE SUM OF ALL BYTES 0 - 125)  
127          (THE NEGATIVE OF 2 TIMES BYTE 126)

THE PROGRAM DETECTS A CHECKSUM ERROR BY SUMMING ALL THE DATA READ FROM THE DISKETTE AND COMPARING THAT SUM TO 0.

AT THE END OF THE DATA ERROR TYPEOUT THE PROGRAM TYPES OUT IF THE CHECK SUM ACCUMULATED IS "GOOD"OR HAD "ERRORS". IF BYTES 0 OR 1 HAVE DATA ERRORS THE OPERATOR MUST CHECK THE RESULTS OF THE CHECK SUM. IF IT IS ALSU BAD, THEN THERE WAS A TRUE DATA ERROR. IF THE CEHCK SUM IS GOOD, THEN IT MIGHT BE THAT THE HEAD IS NOT OVER THE TRACK EXPECTED, AND THERE IS A POSITIONING ERROR.

3.1.6 SEEK ERROR

A SEEK ERROR IS DEFINED AS NOT A CRC AND NOT A PARITY ERROR. A PROGRAMED RECALIBRATE IS ISSUED TO TRY TO CORRECT EACH SEEK ERROR.

3.1.7 PARITY ERROR

A PARITY ERROR RESULTS FROM AN INCORRECT TRANSFER OF A COMMAND WORD FROM THE RX11 INTERFACE TO THE RX01 MICRO-PROCESSOR CONTROLLER.

### 3.2 DEFINITIVE ERROR CODES

THE RX01 MICROCONTROLLER HAS DEFINED THE ERROR CODES AND MEANINGS WHICH ARE AVAILABLE TO THE PROGRAM BY ISSUING COMMAND #7 "READ THE B-CODE STATUS REGISTER".

A DEFINITIVE ERROR CODE REPRESENTS [WHERE] WITHIN A FUNCTION AN ERROR WAS DETECTED.

THE FOLLOWING ARE THE DEFINITIVE ERROR CODES AND MEANINGS:

- 00 - NO ERROR
- 10 - DRIVE 0 FAILED TO SEE HOME FROM INITIALIZE
- 20 - DRIVE 1 FAILED TO SEE HOME FROM INITIALIZE
- 30 - HOME FOUND WHEN STEPPING OUT 10 TRACKS FROM INIT
- 40 - TRIED TO ACCESS A TRACK GREATER THAN 7(DECIMAL)
- 50 - HOME WAS FOUND BEFORE DESIRED TRACK
- 60 - SELF DIAGNOSTIC ERROR
- 70 - DESIRED SECTOR NOT FOUND AFTER SAMPLING 52 HEADERS
- 100 - WRITE PROTECT ERROR
- 110 - MORE THAN 40US AND NO SEP CLOCK DETECTED
- 120 - A PREAMBLE COULD NOT BE FOUND
- 130 - PREAMBLE FOUND BUT NO ID MARO FOUND IN TIME
- 140 - CRC ERROR ON SUPPUSIPLY GOOD HEADER
- 150 - GOOD HEADER (NO CRC ERROR) BUT TRACK COMPARE ERROR
- 160 - IDAM NOT FOUND IN TOME
- 170 - DATA AM NOT FOUND IN TIME
- 200 - DATA CRC ERROR
- 210 - ALL PARITY ERRORS

### 3.3 UNEXPECTED OR MISSING ERROR CONDITIONS

#### 3.3.1 MISSING DD MARK

AN ERROR WHEN THE PROGRAM WROTE DELETED DATA INFORMATION BUT NO DELETED DATA MARK WAS DETECTED WHEN THE DATA WAS READ.

#### 3.3.2 UNEXPECTED DD MARK

AN ERROR WHEN A DELETED DATA MARK IS DETECTED BUT NO DELETED DATA WAS WRITTEN.

### 3.3.3 NO INTERRUPT ON DONE

THE INTERRUPT ENABLE BIT WAS SET AND THE DONE FLAG WAS SET BUT NO INTERRUPT OCCURRED.

### 3.3.4 UNKNOWN INTERRUPT

IF AN INTERRUPT OCCURS FROM ANY OTHER DEVICE WHILE THIS PROGRAM IS RUNNING IT WILL HALT AT THE INTERRUPT VECTOR LOCATION.

IF AN INTERRUPT OCCURS ON INTERRUPT VECTOR LOCATION 264 (RX11), AND THERE IS NO ERROR, DONE, OR ERROR STATUS CONDITION SET, THEN IT WILL BE TAGGED AS AN UNKNOWN INTERRUPT.

### 3.4 POWER FAILURE

THE PROGRAM TESTS FOR TWO TYPES OF POWER FAILURE, TOTAL SYSTEM POWER LOSS AND RX11 POWER LOSS RESULTING IN A RECALIBRATION OF THE DRIVES.

THE TOTAL SYSTEM POWER FAILURE IS DETECTED BY THE "SYSMAC" SUBROUTINE .SPOWER. WHEN THE POWER IS DETECTED TO BE GOING DOWN, THE REGISTERS ARE SANED. WHEN THE POWER COMES BACK UP THE REGISTERS ARE RESTORED AND THE MESSAGE "POWER" IS PRINTED. THE PROGRAM THEN AUTOMATICALLY DOES A RESTART.

LOSS OF POWER IN THE RX11 CAUSES A RECALIBRATION OF ALL DRIVES. WHEN THIS HAPPENS, THE "INIT DONE" BIT IS SET IN THE THE RXES REGISTER ALONG WITH THE NORMAL "DONE" FLAG. AT EACH INTERRUPT THE PROGRAM TESTS FOR INIT DONE. IF IT IS FOUND TRUE, THE FUNCTION WAS NOT COMPLETED AND A POWER LOSS MUST HAVE BEEN DETECTED. WHEN THIS HAPPENS THE PROGRAM TYPES OUT "RX11 POWER" AND DOES AN AUTOMATIC RESTART.

IF THERE ARE REPEATED, NOTHING ELSE HAPPENS BUT, RX11 POWER MESSAGES THE INIT DONE FLAG MIGHT BE STUCK ON.

### 3.5 PROGRAM HUNG

THERE ARE MANY PLACES WHERE THE PROGRAM MUST WAIT FOR AN OPERATION TO BE COMPLETED IN THE RX01. THESE ARE WAITING FOR THE "DONE" FLAG TO INDICATE A FUNCTION IS COMPLETED, OR WAITING FOR A TRANSFER REQUEST "TR" FLAG TO SEND OR RECEIVE THE NEXT BYTE OF INFORMATION. IF THE RX11 DOES NOT COME BACK WITH EITHER OR BOTH OF THESE FLAGS THE PROGRAM WOULD HANG UP.

TO INHIBIT THIS FROM HAPPENING THERE ARE TWO SUBROUTINES USED TO CHECK FOR THESE TWO FLAGS.

THE "DONECK" LOOKS FOR THE DONE FLAG AND IF IT IS NOT SEEN WITHIN A SPECIFIC TIME THE "TEST HUNG" MESSAGE IS PRINTED AND THE PROGRAM HALTS. IN REGISTER 3 (177703) IS THE RETURN ADDRESS OF THE TEST THAT IS WAITING FOR THE DONE FLAG.



"TRCK" LOOKS FOR THE "TR" FLAG. IF IT IS NOT SEEN WITHIN A SPECIFIC TIME IT ALSO PRINTS THE "TEST HUNG" MESSAGE AND HALTS. IN THE SP (177706) IS THE RETURN ADDRESS OF THE TEST WAITING FOR THE TR FLAG.

THE WAITING TIME FOR THE TWO FLAGS DEPENDS UPON THE HOST PROCESSOR AS INDICATED BELOW:

"DONE" WAIT	11/45 BIPOL 14 SEC. 11/05 CORE 62 SEC.
"TR" WAIT	11/45 BIPOL .44 SEC. 11/05 CORE 2 SEC.

4,0 ERROR REPORTING

ALL ERRORS DETECTED WILL BE REPORTED IF SW13 = 0 FOR OPERATING CONDITIONS. IF SW12 = 1 THEN ONLY 10 DATA ERRORS FOR 1 SECTOR WILL BE REPORTED, AND A TOTAL OF DATA ERRORS FOR THAT SECTOR WILL BE REPORTED AT THE END OF THE SECTOR.

THE END OF PASS INDICATOR TYPED, ALSO INDICATES WEITHER ANY ERRORS OCCURED DURING THAT PASS. IF THERE WERE NO ERRORS THEN A "\*" IS PRINTED. IF THERE WERE ERRORS THEN A "-" IS PRINTED. THE TOTAL ACCUMULATED ERRORS AND SYSTEMS OPERATION IS REPORTED BY THE "ERROR DUMP" PROGRAM.

5,0 HALTS

THERE ARE VARIOUS HALT LOCATIONS THROUGHOUT THE PROGRAM. SOME ARE THE RESULTS OF "HARD" ERRORS OTHERS ARE WAITING FOR INTERVENTION. THEY ARE LISTED BELOW:

HALT #	TYPE	DEFINITION
HLT1:	NO ERROR	!CAUTION - LOAD MEDIUM ON UNIT 0
HLT3:	ERROR	!ERRORS FOUND ON RECAL FUNCTIONS
HLT4:	ERROR	!HARD PARITY ERRORS
HLT5:	ERROR	!NO DRIVES READY
HLT6:	ERROR	!SW15 SET ON PARITY ERROR
HLT7:	ERROR	!SW15 SET ON SEEK ERROR
HLT10:	ERROR	!SW15 SET ON CRC GENERATOR ERROR (NO DATA ERROR)
HLT11:	ERROR	!HARD CRC GENERATOR ERROR (NO DATA ERRORS)
HLT12:	ERROR	!SW15 SET ON DATA CRC ERROR
HLT13:	ERROR	!SW15 SET ON MISSING DETECTED DATA ERROR
HLT14:	ERROR	!SW15 SET ON DATA NO CRC ERROR
HLT15:	ERROR	!SW15 SET ON MISSING INTERRUPT AT DONE
HLT16:	NO ERROR	!HALT AT END OF PASS
HLT17:	NO ERROR	!HALT AT END OF ERROR DUMP
HLT20:	ERROR	!PROGRAM HUNG WAITING FOR DONE
HLT21:	ERROR	!PROGRAM HUNG WAITING FOR TR FLAG

MAINDEC=11=DZRXA=E  
DZRXA,P11

- 1
- 2
- 3
- 4
- 5

.NLIST CND,MD,MC  
.LIST ME  
.ENABL ABS,AMA  
.MCALL .HEADER,.EQUAT, .SETUP, .STYPE, .STYPOCT, .\$READ

6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

```
.TITLE MAINDEC-11-UZRXA-E
;*COPYRIGHT (C) MARCH 21,1976
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY DAVID L ADAMS
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-UZGAC-C0),MAR 21, 1976.
;*
STN#1
SSWR=160000    ;;HALT ON ERROR, LOOP ON TEST, INHIBIT ERROR TYP0UT
```

```
;;COPYRIGHT (C) 1975,1976
;;THIS SOFTWARE IS FURNISHED UNDER A LICENSE FOR USE ONLY
;;ON A SINGLE COMPUTER SYSTEM AND MAY BE COPIED ONLY WITH
;;THE INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS
;;SOFTWARE, OR ANY OTHER COPIES THEREOF, MAY NOT BE PROVIDED
;;OR OTHERWISE MADE AVAILABLE TO ANY OTHER PERSON
;;EXCEPT FOR USE ON SUCH SYSTEM AND TO ONE WHO AGREES TO
;;THESE LICENSE TERMS. TITLE TO OWNERSHIP OF THE
;;SOFTWARE SHALL AT ALL TIMES REMAIN IN DEC.
;
;;THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE
;;WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT
;;BY DIGITAL EQUIPMENT CORPORATION.
;
;;DEC ASSUMES NU RESPONSIBILITY FOR THE USE OR RELIABILITY
;;OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY
;;DEC.
```

.SBTTL BASIC DEFINITIONS

```
;*INITIAL ADDRESS OF THE STACK POINTER *** 1200 ***
STACK# 1200
.EQUIV EMT,ERROR    ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE    ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
MT# 11    ;;CODE FOR HORIZONTAL TAB
LF# 12    ;;CODE FOR LINE FEED
CR# 15    ;;CODE FOR CARRIAGE RETURN
CHLF# 200  ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS# 17776  ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
```

```
57 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
58 177772 PIRQ# 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
59 177570 DSWR# 177570 ;;HARDWARE SWITCH REGISTER
60 177570 DDISP# 177570 ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
61
62
63 000000 R0# X0 ;;GENERAL REGISTER
64 000001 R1# X1 ;;GENERAL REGISTER
65 000002 R2# X2 ;;GENERAL REGISTER
66 000003 R3# X3 ;;GENERAL REGISTER
67 000004 R4# X4 ;;GENERAL REGISTER
68 000005 R5# X5 ;;GENERAL REGISTER
69 000006 R6# X6 ;;GENERAL REGISTER
70 000007 R7# X7 ;;GENERAL REGISTER
71 .EQUIV R0,SP ;;STACK POINTER
72 .EQUIV R7,PC ;;PROGRAM COUNTER

;*PRIORITY LEVEL DEFINITIONS
73
74
75 200000 PR0# 0 ;;PRIORITY LEVEL 0
76 000040 PR1# 40 ;;PRIORITY LEVEL 1
77 000100 PR2# 100 ;;PRIORITY LEVEL 2
78 000140 PR3# 140 ;;PRIORITY LEVEL 3
79 000200 PR4# 200 ;;PRIORITY LEVEL 4
80 000240 PR5# 240 ;;PRIORITY LEVEL 5
81 000300 PR6# 300 ;;PRIORITY LEVEL 6
82 000340 PR7# 340 ;;PRIORITY LEVEL 7

;*SWITCH REGISTER SWITCH DEFINITIONS
83
84
85 100000 SW15# 100000
86 040000 SW14# 40000
87 200000 SW13# 200000
88 010000 SW12# 100000
89 004000 SW11# 4000
90 002000 SW10# 2000
91 001000 SW09# 1000
92 000400 SW08# 400
93 000200 SW07# 200
94 000100 SW06# 100
95 000040 SW05# 40
96 000020 SW04# 20
97 000010 SW03# 10
98 000004 SW02# 4
99 000002 SW01# 2
100 000001 SW00# 1
101 .EQUIV SW09,SW9
102 .EQUIV SW08,SW8
103 .EQUIV SW07,SW7
104 .EQUIV SW06,SW6
105 .EQUIV SW05,SW5
106 .EQUIV SW04,SW4
107 .EQUIV SW03,SW3
108 .EQUIV SW02,SW2
109 .EQUIV SW01,SW1
110 .EQUIV SW00,SW0

;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
```

```

113      100000      BIT15= 100000
114      040000      BIT14= 400000
115      020000      BIT13= 200000
116      010000      BIT12= 100000
117      004000      BIT11= 40000
118      002000      BIT10= 20000
119      001000      BIT09= 10000
120      000400      BIT08= 4000
121      000200      BIT07= 2000
122      000100      BIT06= 1000
123      000040      BIT05= 400
124      000020      BIT04= 200
125      000010      BIT03= 100
126      000004      BIT02= 40
127      000002      BIT01= 20
128      000001      BIT00= 10
129      .EQUIV BIT09,BIT9
130      .EQUIV BIT08,BIT8
131      .EQUIV BIT07,BIT7
132      .EQUIV BIT06,BIT6
133      .EQUIV BIT05,BIT5
134      .EQUIV BIT04,BIT4
135      .EQUIV BIT03,BIT3
136      .EQUIV BIT02,BIT2
137      .EQUIV BIT01,BIT1
138      .EQUIV BIT00,BIT0
139
140      ;*BASIC "CPU" TRAP VECTOR ADDRESSES
141      ERVVEC= 4      ;TIME OUT AND OTHER ERRORS
142      RESVEC= 10     ;RESERVED AND ILLEGAL INSTRUCTIONS
143      TBITVEC=14     ;"T" BIT
144      TRTVEC= 14     ;TRACE TRAP
145      BPTVEC= 14     ;BREAKPOINT TRAP (BPT)
146      IOTVEC= 20     ;INPUT/OUTPUT TRAP (IOT) **SCOPE**
147      PWRVEC= 24     ;POWER FAIL
148      EMTVEC= 30     ;EMULATOR TRAP (EMT) **ERROR**
149      TRAPVEC=34     ;"TRAP" TRAP
150      TKVEC= 60      ;TTY KEYBOARD VECTOR
151      TPVEC= 64      ;TTY PRINTER VECTOR
152      PIQVEC=240     ;PROGRAM INTERRUPT REQUEST VECTOR
153
154
155      ;SPECIAL EQUATES
156
157
158      000013      RD0STAT =13
159      000033      RD1STAT =33
160      000017      RUER =17
161      000040      DONEBIT =40
162      000101      FBIE =101
163      000103      EBIE =103
164      000105      WRTIE =105
165      000107      RDIE =107
166      000115      WTD0IE =115
167      000001      RECAL =40001
168      000200      PR4 =200
  
```

```

169      000340      PR7 =340
170      000000      OPEN =0
171
172      000000      .#0
173      000000 000000 000000      .WORD 0,0
174
175      000024      .#24
176      000024 013764      SPWHDN
177      000026 000340      340
178
179      000034      .#34
180      000034 013716      STRAP          ;ADDRESS OF TRAP SERVICE
181      000036 000340      340
182
183      000046      .#46
184      000046 011130      LOGICAL          ;ACT11 EOP HOOK
185
186      000052      .#52
187      000052 000000      .WORD 0
188
189      000174      .#174
190      000174 000000      DISPREG: 0
191      000176 000000      SWREG: 0
192
193
194      ;*****
195
196      ;STARTING ADDRESSES
197      ;
198      ;INITIAL START =200 /CLEARS ALL ERROR LOGS,RESETS COUNTERS,AND ALLOWS FOR
199      ; /SELECTION OF DRIVES AND TEST CONDITIONS
200      ;
201      ;RESTART =202 /USES PREVIOUS INITIAL START DRIVES AND TEST
202      ; /SELECTION AND CONTINUES TO ACCUMULATE STATISTICAL DATA
203      ;
204      ;ERROR REPORT =204 /PRINTS OUT ALL RUN AND ERROR CONDITIONS
205      ; /ACUMULATED OVER THE RUN OF THE PROGRAM.
206      ;
207
208
209      .#200
210      000200 000402      BR 13
211      000202 000403      BR 25
212      000204 000404      BR 35
213      000206 000137 001220      151 JMP SA200          ;OPERATOR SELECTED CONDITIONS
214      000212 000137 002700      251 JMP RESTART      ;RESTART PROGRAM WITH PVIOUS CONDITIONS
215      000216 000137 021062      351 JMP ERDUMP       ;STATISTICAL ERROR PRINT OUT
216
217
218      ;*****
219
220      ;THE FOLLOWING LOCATIONS "OD","ID","FIRST",AND "LAST"
221      ;MAY BE CHANGED BY THE OPERATOR MANUALLY HOWEVER FOLLOWING THESE RESTRICTIONS.
222      ;(IF THESE LOCATIONS ARE LEFT CLEARED,MAX AND MIN VALUES ARE ASSUMED)
223      ;
224      ; 1. DEFINITIONS:
  
```

```

225 ; OU=ADDRESS OF TRACK AT OUTER DIAMETER (MIN VALUE=0)
226 ; IO=ADDRESS OF TRACK AT INNER DIAMETER (MAX VALUE=114 (OCTAL))
227 ; FIRST=ADDRESS OF FIRST SECTOR OF TRACK (MIN VALUE=1)
228 ; LAST=ADDRESS OF LAST SECTOR OF TRACK (MAX VALUE=32 (OCTAL))
229 ;
230 ;
231 ; 2. LOCATIONS:
232 ; TRACKS LOC, 1200 BITS 14-----8 6-----0
233 ; ID 00
234 ;
235 ; SECTORS LOC, 1202 BITS 12-----8 4-----0
236 ; LAST FIRST
237 ;
238 ; 3. RESTRICTIONS:
239 ; THE CONTENTS OF "00" MUST BE <= THE CONTENTS OF "ID"
240 ; THE CONTENTS OF FIRST MUST BE <= THE CONTENTS OF "LAST"
241 ;
242 ;
243 ;
244 ;
245 ;
246 ;
247 ;
248 ;
249 ;
250 ;
251 ;
252 ;
253 ;
254 ;
255 ;
256 ;
257 ;
258 ;
259 ;
260 ;
261 ;
262 ;
263 ;
264 ;
265 ;
266 ;
267 ;
268 ;
269 ;
270 ;
271 ;
272 ;
273 ;
274 ;
275 ;
276 ;
277 ;
278 ;
279 ;
280 ;

```

001200 001200                    =1200  
 001200 000000                    0  
 001202 001201                    IO=00+1  
           000000                    FIRST= 0  
           001203                    LAST=FIRST+1

```

;*****
;THE NEXT WORD IS THE LOCATION OF THE "INTERRUPT VECTOR" ADDRESS
;IF THE HARDWARE IS JUMPED FOR OTHER THAN STANDARD (264) VECTOR
;ADDRESS, THEN LOAD INTO THIS LOCATION THE NEW VECTOR ADDRESS.
;
;IF THIS ADDRESS IS INCORRECT (DOES NOT MATCH THE HARDWARE) THE
;PROGRAM WILL HALT AT THE VECTOR ADDRESS THE HARDWARE IS JUMPED
;TO, AS ALL OTHER VECTOR ADDRESSES WILL HAVE HALTS IN THEM.
;
;*****NOTE*****
;THE INTERRUPT VECTOR ADDRESS CAN NOT BE SET FOR ADDRESSES 200
;THRU 243, AS THESE ADDRESS ARE USED BY THE PROGRAM
;
;*****
INTVEC: 264
;*****
;THE FOLLOWING TWO WORDS CONTAIN THE DEVILE CODES FOR
;THE RX11 INTERFACE REGISTERS
;
; RXCS = COMMAND STATUS REGISTER (USED AT VARIOUS TIMES FOR:)
;   RXDB = DATA BUFFER REGISTER (USED AT VARIOUS TIMES FOR:)
;   (RXTA = TRACK ADDRESS)
;   (RXSA = SECTOR ADDRESS)
;   (RXES = ERROR STATUS)
;IF THE RX11 SYSTEM UNDER TEST IS JUMPED FOR REGISTER
;ADDRESSES OTHER THAN STANDARD: RXCS = 177170
;                                  RXDB = 177172

```

```

281 ;
282 ;
283 ;
284 ;
285 ;
286 ;
287 ;
288 ;
289 ;
290 ;
291 ;
292 ;
293 ;
294 ;
295 ;
296 ;
297 ;
298 ;
299 ;
300 ;
301 ;
302 ;
303 ;
304 ;
305 ;
306 ;
307 ;
308 ;
309 ;
310 ;
311 ;
312 ;
313 ;
314 ;
315 ;
316 ;
317 ;
318 ;
319 ;
320 ;
321 ;
322 ;
323 ;
324 ;
325 ;
326 ;
327 ;
328 ;
329 ;
330 ;
331 ;
332 ;
333 ;
334 ;
335 ;
336 ;

```

001206 177170                    RXCS: 177170  
 001210 177172                    RXDB: 177172

```

;BIT ASSIGNMENT IN THE RXCS REGISTER.
;
;KEY: R = READ ONLY BIT
;      W = WRITE ONLY BIT
;
;
; 15 = R - ERROR FLAG
; 14 = W - INITIALIZE (RECALIBRATE)
; 13 =
; 12 =
; 11 =
; 10 = NOT USED
; 9 =
; 8 =
; 7 = R - TRANSFER REQUEST (TR) FLAG
; 6 = R/W - INTERRUPT ENABLE
; 5 = R - DONE FLAG
; 4 = W - UNIT SELECT
; 3 = W - FUNCTION
; 2 = W - FUNCTION
; 1 = W - FUNCTION
; 0 = W - GO
;
;FUNCTION CODES:
;
; 0 + GO = FILL BUFFER
; 2 + GO = EMPTY BUFFER
; 4 + GO = WRITE SECTOR
; 6 + GO = READ SECTOR
; 10 (NOT USED)
; 12 + GO = READ STATUS "A"
; 14 + GO = WRITE DELETED DATA
; 16 + GO = READ STATUS "B" (CODES)
;
;
;THE FOLLOWING BIT ASSIGNMENTS REPRESENTS THE STATUS AT THE END OF A
;FUNCTION (EXCEPT FUNCTION "READ STATUS B") DISPLAYED IN THE
;RX DATA BUFFER (RXDB).
;
;
; 15 =
; 14 =
; 13 = NOT USED
; 12 =
; 11 =
; 10 =
; 9 =
; 8 =
; 7 = SELECTED DRIVE READY *
; 6 = DELETED DATA
; 5 =
; 4 =
; 3 = WRITE PROTECT ERROR (WHEN AVAILABLE)
; 2 = INITIALIZE DONE **

```

```

337          / 1 = PARITY ERROR
338          / 0 = CRC ERROR
339          /
340          /* VISIBLE ONLY IF THE FUNCTION WAS A #12 "READ STATUS A"
341          /
342          /** VISIBLE ONLY AFTER AN INITIALIZE [KEY] OR [PROGRAMMED] WAS ISSUED,
343          /
344          DTESTP:  .WORD 0          ;TEST SELECTION WORD
345          SWR:     .WORD USWR       ;ADDRESS OF SWITCH REGISTER
346          DISPLAY: .WORD DDISP     / ADDRESS OF DISPLAY REGISTER
347          /
348          /*******
349          /
350          ;START OF OPERATOR SELECTABLE TEST,DATA PATTERNS,AND DRIVE UNIT CONDITIONS
351          ;SET THE TEST CONDITIONS WANTED (OR LEAVE 0) IN LOCATION CALLED
352          ;"DTESTP" (LOC. 1212), BEFORE STARTING THE PROGRAM, WHEN THE PROGRAM
353          ;STARTS IT WILL TYPE OUT THE TEST CONDITIONS IT IS OPERATING UNDER,
354          /
355          /
356          ;SWITCH REGISTER BITS
357          /
358          / 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
359          / U1 U0 NOT USED D P P P T T T S S S
360          /
361          / U1 SELECT DRIVE UNIT 1
362          / U0 SELECT DRIVE UNIT 0
363          ;IF NEITHER DRIVE IS SPECIFIED,PROGRAM WILL SELECT ALL DRIVES
364          ;THAT ARE READY
365          /
366          / D = DELETED DATA FUNCTIONS
367          /
368          ;IF THIS SWITCH IS ON ALL READ AND WRITE FUNCTIONS WILL BE IN THE
369          ;DELETED DATA MODE
370          /
371          /
372          / P = DATA PATTERN SELECTION
373          / 0 DO PATTERN 7 (RANDOM)
374          / 1 ZEROS
375          / 2 ONES
376          / 3 FLOATING ZERO
377          / 4 FLOATING ONE
378          / 5 125
379          / 6 314
380          / 7 RANDOM
381          /
382          / T = FUNCTIONAL TESTS
383          / 0 DO TEST 7 (WRITE/READ/HEAD CHECK)
384          / 1 WRITE ONLY
385          / 2 WRITE/READ
386          / 3 WRITE/READ CHECK
387          / 4 READ CHECK ONLY
388          / 5 HEAD ONLY
389          / 6 WRITE/READ CHECK ON ALTERNATE DRIVES
390          / 7 WRITE/READ/READ CHECK *
391          /
392          ; * NOTE: THE FIRST HALF OF TEST 7 FORCES THE TRACK SEQUENCE
  
```

```

393          ;TO INCREMENT UP THROUGH ALL THE TRACKS DOING WRITE / READ CHECK FUNCTIONS.
394          ;THIS VERIFIES THAT ALL THE TRACKS ARE ACCESSABLE.
395          ;THE SECOND HALF OF THE PASS WILL USE THE SEQUENCE SELECTED BY THE
396          ;OPERATOR AS INDICATED BELOW,AND ONLY READ CHECK THE DATA JUST WRITTEN.
397          ;THIS VERIFIES THAT THE DATA CAN BE READ FROM A TRACK,AFTER THE HEAD HAS BEEN
398          ;MOVED AWAY FROM AND BACK TO THAT TRACK, AT THE COMPLETION OF THE PASS
399          ;THE DELETED DATA HIT IN TEST CONDITIONS IS COMPLEMENTED AND THE NEXT
400          ;PASS WILL BE RUN UNDER THIS NEW CONDITION.
401          /
402          /
403          / S = TRACK SEQUENCING
404          / 0 DO SEQUENCE 7 (RANDOM)
405          / 1 INCREMENT
406          / 2 DECREMENT
407          / 3 INCREMENT/DECREMENT
408          / 4 BOUNCE
409          / 5 DECREASING BOUNCE
410          / 6 STROBE
411          / 7 RANDOM
412          /
413          /
414          /*******
415          /
416          ;SET THE OPERATING CONDITIONS IN THE SWITCH REGISTER (HARDWARE).
417          ;FOR THE SOFTWARE SWITCH REGISTER (LOC. 176) BEFORE STARTING THE PROGRAM.
418          /
419          ;SWITCHES DO THE FOLLOWING WHEN SET TO "1".
420          /
421          / SW 15 =HALT ON ERROR
422          / SW 14 =HALT AT END OF TEST
423          / SW 13 =DON'T PRINT ERROR MESSAGE
424          / SW 12 =TYPE ONLY 10 DATA ERRORS
425          / SW 11 =NO RETRY ON ERROR, LOG HARD ERROR
426          /
427          / SW 8 =NO RECALIBRATION ON SEEK ERRORS
428          /
429          / SW15 = SW0 =SELECT SOFTWARE SWITCH REGISTER
430          /
431          /
432          /*******
433          /
434          /
435          001220 000005          SA200:      RESET          ;INITIALIZE THE RX01
436          001222 012737 177570 001214      MOV #177570,SWR      ;RESET TO HARDWARE SWR.
437          001230 012706 001200              MOV #STACK,SP
438          001234 012746 000340              MOV #PRT,-(SP)
439          001240 012746 001246              MOV #28,-(SP)
440          001244 000002              RTI
441          001246 104400 016554          25:      TYPE ,MREV          ;PRINT NAME AND REVISION
442          001252 012737 001272          MOV #3,4           ;SET TIME OUT VECTOR
443          001260 022777 177777 177726      CMP #177777,0SWR    ;IS SOFTWARE SWR SELECTED
444          001266 001402              BEQ 4$            ;YES, INSERT IT'S ADDRESS
445          001270 000423              BR 5$            ;BRANCH IF NO TIMEOUT TRAP OCCURS
446          001272 022626              CMP (SP)+,(SP)+    ;RESTORE STACK AFTER TRAP
447          001274 012737 000176 001214      MOV #SWREG,SWR     ;POINT TO SOFTWARE SWITCH REG.
448          001302 012737 000174 001216      MOV #DISPREG,DISP  ;POINT TO SOFTWARE DISP. REG.
  
```

```

449 .SHTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
450 001310 005737 000042 TST #42 ;ARE WE RUNNING UNDER XXDP/ACT?
451 001314 001006 BNE 64$ ;BRANCH IF YES
452 001316 023727 001214 000176 CMP SWR,#SWREG ;SOFTWARE SWITCH REG SELECTED?
453 001324 001005 BNE 65$ ;BRANCH IF NO
454 001326 104400 GTSWR ;GET SOFT-SWR SETTINGS
455 001330 000403 BR 65$
456 001332 112737 000001 013714 64$: MOV# #1,$AUTOB ;SET AUTO-MODE INDICATOR
457 001340 65$:
458 001340 012737 000006 000004 55: MOV #6,4 ;RESTORE ERROR VECTOR
459 001346 013703 001204 MOV INTVEC,R5 ;SET INTERRUPT VECTOR LOCATIONS
460 001352 012723 007250 MOV #INTSERV,(R3)+
461 001356 012713 000340 MOV #340,(R3)
462 001362 012737 001234 MOV #001234,RAN1 ;INITIALIZE CONSTANTS IN RANDOM NUMBER GENERATOR
463 001370 012737 000765 012212 MOV #000765,RAN2
464 001376 012705 017024 MOV #PARLOG,R5
465 001402 005025 1$: CLR (R5)+ ;SET UP TO CLEAR ALL COUNTERS
466 001404 022705 021044 CMP #PASCNTR+2,R5 ;OF ERRORS,ACCESSES,AND PASSES
467 001410 001374 HNE 1$ ;HAVE ALL COUNTERS BEEN CLEARED
468 001412 012705 017004 MOV #RURETRY,R5 ;SET ALL RETRY COUNTERS TO 10
469 001416 012725 000012 3$: MOV #10,(R5)+
470 001420 022705 017024 CMP #SHETRY+2,R5
471 001426 001374 HNE 3$
472 001430 104400 015167 TYPE ,#RXCS ;TYPE OUT DEVICE REGISTER ADDRESSES
473 001434 013746 001206 MOV #RXCS,-(SP) ;SAVE #RXCS FOR TYPEOUT
474 001440 104402 TYPDS ;GO TYPE--OCTAL ASCII
475 001442 006 .BYTE 6 ;TYPE 6 DIGITS
476 001443 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
477 001444 104400 015177 TYPE ,#RXDB
478 001450 013746 001210 MOV #RXDB,-(SP) ;SAVE #RXDB FOR TYPEOUT
479 001454 104402 TYPDS ;GO TYPE--OCTAL ASCII
480 001456 006 .BYTE 6 ;TYPE 6 DIGITS
481 001457 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
482 001460 104400 015150 TYPE ,#INTVEC ;AND VECTOR ADDRESS
483 001464 013746 001204 MOV #INTVEC,-(SP) ;SAVE INTVEC FOR TYPEOUT
484 001470 104402 TYPDS ;GO TYPE--OCTAL ASCII
485 001472 003 .BYTE 3 ;TYPE 3 DIGIT(S)
486 001473 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
487 001474 004737 007122 JSR PC,DONECK ;WAIT FOR DONE HIT AFTER RECAL
488 001500 032777 000004 177502 HIT #BIT2,#RXDB ;IS INIT DONE SET
489 001506 001002 HNE 1$ ;YES SKIP NEXT INSTRUCTION
490 001510 104400 015535 TYPE ,#INIT1 ;NO,PRINT NO INIT DONE ERROR
491 001514 005777 177466 1$: TST #RXCS ;WAS THERE AN ERROR ON START RECAL
492 001520 100002 HPL TESTDN ;IF NOT CONTINUE
493 001522 004737 002554 JSR PC,HOML ;YES,DO RECAL AGAIN
494 001526 012737 000012 017014 TESTDR: MOV #10,#PRETRY ;SET THE PARITY RETRY COUNTER
495 001534 005037 010704 CLR UNITSEL ;CLEAR UNIT SELECTION WORD
496 001540 105777 177444 TSTB #RXDB ;IS DRY BIT SET FOR UNIT 0 AFTER RECAL
497 001544 100003 HPL 2$ ;IF NOT SKIP NEXT INSTRUCTION
498 001546 052737 000200 010704 HIT #BIT7,UNITSEL ;YES,SET UNIT 0 READY BIT
499 001554 032737 140000 001212 2$: HIT #140000,UTESTP ;WERE ANY DRIVES SPECIFIED
500 001562 001445 BEQ NOSEL ;NO,SEE IF UNIT 1 IS READY
501 001564 005737 001212 TST UTESTP ;WAS UNIT 1 SELECTED
502 001570 100044 HPL OPCOND ;NO,IT MUST BE UNIT 0
503 001572 044737 001614 JSR PC,DRY1 ;SEE IF UNIT 1 IS READY
504 001576 032737 040000 001212 HIT #40000,DTESTP ;WAS UNIT 0 SELECTED

```

```

505 001604 001036 BNE OPCOND ;YES,CONTINUE
506 001606 135037 010704 CLRB UNITSEL ;NO,CLEAR UNIT 0 READY BIT
507 001612 000433 BR OPCOND
508
509 001614 012777 000033 177364 DRY1: MOV #RD1STAT,#RXCS ;HEAD STATUS OF UNIT 1
510 001622 004737 007122 JSR PC,DONECK ;WAIT FOR DONE HIT
511 001626 132777 000002 177354 HIT# #2,#RXDB ;IS PARITY ERROR BIT SET
512 001634 001411 BEQ 2$ ;NO,CONTINUE
513 001636 004737 002046 JSR PC,STATEN ;YES,GO HANDLE PARITY ERROR
514 001642 000764 HR UNY1 ;REISSUE FUNCTION
515 001644 032777 000004 177336 HIT #BIT2,#RXDB ;INIT DONE SHOULD NOT BE SET
516 001652 001402 BEQ 2$
517 001654 104400 015567 TYPE ,#INIT2 ;INIT DONE WAS SET PRINT ERROR
518 001660 105777 177324 2$: TSTB #RXDB ;IS UNIT 1 DRY BIT SET
519 001664 100003 HPL 3$ ;IF NOT SKIP NEXT INSTRUCTION
520 001666 052737 100000 010704 HIT #BIT15,UNITSEL ;YES,SET UNIT 1 READY BIT
521 001674 000207 3$: RTS PC
522
523 001676 004737 001614 NOSEL: JSR PC,DRY1 ;TEST UNIT 1 FOR DRY SET
524 001702 105737 010704 TSTB UNITSEL ;IS UNIT 0 SELECTED
525 001706 100016 HPL 1$ ;NO
526
527 ;TEST ACT11 LOAD MEDIA INDICATOR
528
529 001710 123727 000041 000010 CMPB #41,#10 ;DOES LOCATION 41 CONTAIN THE NUMBER 10?
530 001716 001012 HNE 1$ ;BRANCH IF NOT
531 001720 005737 000042 TST #42 ;CHECK FOR RXDP OPERATION
532 001724 001404 BEQ 2$
533 001726 042737 000200 010704 BIT #200,UNITSEL ;IN CHAIN MODE, DESELECT UNIT 0
534 001734 000403 BR 1$ ;AND DO NOT HALT
535 001736 104400 014643 2$: TYPE ,DLOAD ;INFORM USER TO REMOVE LOAD MEDIUM
536 ;FROM UNIT 0 AND REPLACE WITH
537 ;A "SCRATCH" DISKETTE IF HE
538 ;WISHES TO TEST UNIT 0
539 001744 000241 1$: CLC ;CLEAR C BIT FOR ROR'S THAT FOLLOW
540 001746 013737 001212 011370 MOV UTESTP,SEQUEN ;PUT INITIAL CONDITIONS IN SEQUENCE
541 001754 042737 177700 011370 BIT #17770,SEQUEN ;CLEAR ALL BUT SEQUENCE BITS
542 001762 013737 001212 002140 MOV UTESTP,TEST ;PUT INITIAL CONDITIONS IN TEST
543 001770 042737 177700 002140 BIT #17770,TEST ;CLEAR ALL BUT TEST BITS
544 001776 006037 002140 ROR TEST ;RIGHT JUSTIFY TEST BITS
545 002002 006037 002140 ROR TEST
546 002006 006037 002140 ROR TEST
547 002012 013737 001212 010420 MOV UTESTP,PAT ;PUT INITIAL CONDITIONS IN PATTERN
548 002020 006137 010420 ROL PAT ;RIGHT JUSTIFY PATTERN BITS
549 002024 006137 010420 ROL PAT
550 002030 000337 010420 SWAB PAT
551 002034 042737 177700 010420 BIT #17770,PAT ;CLEAR ALL BUT PATTERN BITS
552 002042 000137 002722 JMP XSTART
553
554 002046 005237 017024 STATER: INC PARLOG ;INC PARITY ERROR COUNTER
555 002052 104400 015167 TYPE ,#RXCS ;PRINT THE RXCS CONTENTS
556 002056 017746 177124 MOV #RXCS,-(SP) ;SAVE #RXCS FOR TYPEOUT
557 002062 104402 TYPDS ;GO TYPE--OCTAL ASCII
558 002064 003 .BYTE 3 ;TYPE 3 DIGIT(S)
559 002065 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
560 002066 005337 017014 DEC #PRETRY ;HAVE 10 ERRORS OCCURED

```



```

673 002656 104400 015713 TYPE ,MHALT3 ;YES,CAN'T CONTINUE AS RX11 WILL NOT RECAL
674 002662 000000 HALT ;
675 002664 000137 001220 HLT3: JMP SA200 ;IF CONT. SWITCH IS PRESSED GO TO START
676 002670 012737 000001 011362 XHOME: MOV #1,PRESTRK ;RESET THE PRESENT THACK TO TRACK 1
677 002676 000207 RTN: RTS PC ;RETURN
678
679 ;*****
680 ;DECODE TEST BITS OF INITIAL CONDITIONS
681 ;
682 ;BITS 5,4,AND 3 OF THE INITIAL SWR SELECTED THE TEST WHICH
683 ;IS TO BE PERFORMED, THEY ARE AS FOLLOWS:
684 ;
685 ; BITS TESTS
686 ; 5 4 3
687 ; 0 0 0 NO TEST SELECTED (DEFAULT TO TEST 7)
688 ; 0 0 1 WRITE ONLY
689 ; 0 1 0 WRITE FOLLOWED BY READ
690 ; 0 1 1 WRITE FOLLOWED BY READ AND VERIFY
691 ; 1 0 0 READ AND VERIFY ONLY
692 ; 1 0 1 READ ONLY (CRC CHECK)
693 ; 1 1 0 READ AND VERIFY DELETED DATA
694 ; 1 1 1 WRITE FOLLOWED BY READ FOLLOWED BY ANOTHER
695 ; READ AND VERIFY
696
697 ;*****
698
699
700 002700 012706 001200 RESTART: MOV #STACK,SP ;RESET THE STACK POINTER
701 002704 012746 000540 MOV #PN7,-(SP) ;AND INTERRUPT LEVEL
702 002710 012746 002716 MOV #18,-(SP)
703 002714 000002 RTI
704 002716 005237 021440 1S: INC HESTCNTN ;INC RESTART COUNTER
705 002722 004737 002452 XSTART: JSR PC,ICOND ;TYPE OUT INITIAL CONDITIONS
706 002726 005037 011142 TESTSEL: CLR CHARCT ;CLEAR EOP CHARACTER COUNTER
707 002732 012737 000012 017004 MOV #10,,R0RETRY ;SET UP READ AND WRITE RETRY COUNTERS
708 002740 012737 000012 017006 MOV #10,,W0RETRY
709 002746 005037 004124 CLR ERWRT ;CLEAR WRITE CAUSED BY ERROR FLAG
710 002752 005037 004122 CLR HDAFTWT ;CLEAR READ AFTER WRITE FLAG
711 002756 142737 000377 003014 BICB #377,##BRONTEST ;CLEAR OUT BRANCH OFFSET
712 002764 005737 002140 TST TEST ;IF NO TEST SPECIFIED FORCE TEST 7
713 002770 001003 BNE 1S
714 002772 012737 000007 002140 MOV #7,TEST
715 003000 013704 002140 1S: MOV TEST,R4
716 003004 005304 DEC R4 ;ADJUST TEST BITS FOR CORRECT
717 003006 006304 ASL R4 ;BRANCH OFFSET
718 003010 150437 003014 BISH R4,##BRONTEST ;INSERT OFFSET TO BRANCH INST.
719 003014 000777 BRONTEST: ;BRANCH BY TEST OFFSET
720 003016 000137 003052 JMP WRONLY ;WRITE ONLY FUNCTION
721 003022 000137 004130 JMP WRHD ;WRITE THEN READ FUNCTION
722 003026 000137 005456 JMP WRDCK ;WRITE THEN READ VERIFY
723 003032 000137 006504 JMP W0DVM ;READ VERIFY
724 003036 000137 006504 JMP W0UNLY ;READ ONLY FUNCTION
725 003042 000137 006544 JMP DRVSWP ;WRITE,AND READ VERIFY ON ALTERNATING DRIVES
726 003046 000137 006630 JMP TEST7 ;WRITE,READ,FOLLOWED BY READ VERIFY
727
728

```

```

729
730 ;*****
731 ;THIS IS A WRITE ONLY FUNCTION USING DATA PATTERN AND
732 ;TRACK SEQUENCE SPECIFIED BY INITIAL SWR SETTINGS
733 ; T = 1
734
735
736 003052 004737 010312 WRONLY: JSR PC,GETPATTERN ;SET UP SOFTWARE DATA BUFFER
737 003056 004737 011144 XWRONLY: JSR PC,INITTRACKS ;SET UP ID,OD,AND TRACK COUNTER
738 003062 004737 010614 JSR PC,GETUNIT ;SET UP DRIVE UNIT SELECTION
739 003066 004737 011254 1S: JSR PC,GETTRACK ;PICK UP NEXT TRACK
740 003072 004737 003112 JSR PC,WRITE ;DO THE WRITE FUNCTION
741 003076 005337 011356 DEC TRKCNTR ;TEST TRACK COUNTER
742 003102 001371 BNE 1S
743 003104 004737 010732 JSR PC,STOP ;CHECK FOR LAST DRIVE AND EOP
744 003110 000762 BR XWRONLY ;NEXT PASS
745
746 003112 004737 012216 WRITE: JSR PC,INITSECTOR ;SET UP FIRST, LAST, AND SECTOR COUNTER
747 003116 004737 012316 XWRITE: JSR PC,GETSECTOR ;PICK UP NEXT SECTOR
748 003122 012737 000012 017022 MOV #10,,SRETRY
749 003130 012737 000012 017016 ONEWRT: MOV #10,,PRETRY ;SET RETRY COUNTER
750 003136 004737 005656 FILLBUF: JSR PC,ADJSUM ;ADJUST DATA BUFFER AND CHECK SUM FOR ADDRESSES
751 003142 012746 005372 MOV #FILLDONE,-(SP) ;PUT GOOD RETURN ON STACK
752 003146 012746 005214 MOV #FILLER,-(SP) ;PUT ERROR RETURN ON STACK
753 003152 005037 006434 CLR BYTECNTR
754 003156 012746 000200 MOV #PR4,-(SP)
755 003162 012746 003170 MOV #13,-(SP)
756 003166 000002 RTI
757 003170 012777 000101 176010 1S: MOV #FNIE,0RXCS ;EXECUTE FILLBUFFER COMMAND
758 003176 004737 007014 FILLFLAG: JSR PC,TRCK ;TEST FOR TRANSFER REQUEST FLAG
759 003202 112077 176002 XFRBYTE: MOVB (#0)+,0RXDB ;TRANSFER DATA BYTE
760 003206 005237 006434 INC BYTECNTR
761 003212 000771 BR FILLFLAG ;WAIT FOR NEXT TR FLAG
762
763 003214 005726 FILLER: TST (SP)+ ;REMOVE THE DONE RETURN FROM THE STACK
764 003216 012737 015366 003264 MOV #MFIL,PTYP1+2 ;PUT ADDR OF FILLBUF MESSAGE IN PAR ERR TYP0UT 1
765 003224 012737 015366 003354 MOV #MFIL,PTYP2+2 ;PUT ADDR OF FILLBUF MESSAGE IN PAR ERR TYP0UT 2
766 003232 012737 003136 003334 MOV #FILLBUF,PCONT+2 ;IF NOT HARD ERR RETURN THROUGH PCONT TO FILLBUF
767 003240 000137 003244 JMP PARTEST ;PRINT OUT PAR ERR AND TEST CONDITIONS FOR RETRY
768
769
770 003244 005237 017024 PARTEST: INC PARLOG ;INCREMENT PARITY ERROR
771 003250 104405 CKSWR
772 003252 032777 020000 175734 BIT #SW13,0SWR ;TEST DON'T PRINT ERROR SWITCH
773 003260 001006 BNE CONT4
774 003262 104400 000000 PTPY1: TYPE ,OPEN ;PRINT THE PARITY ERROR MESSAGE
775 003266 104400 016017 TYPE ,MPAR
776 003272 104400 015052 TYPE ,MCRLF
777 003276 104405 CKSWR
778 003300 005777 175710 TST 0SWR ;TEST MALT ON ERROR SWITCH
779 003304 100001 HPL CONT13
780 003306 000000 HLT6: MALT ;HALT ON ERROR
781 003310 032777 004000 175676 CONT13: BIT #SW11,0SWR ;TEST NO RETRY SWITCH
782 003316 001007 BNE CNTS ;IF SET LOG HARD ERROR
783 003320 005337 017016 DEC PRETRY ;DECREMENT RETRY COUNTER
784 003324 005737 017016 TST PRETRY ;HAVE 10 ERRORS OCCURED

```



785	003330	001402			BEQ CONTS	IF CLEARED LOG HARD ERROR	
786	003332	000137	003136	PCONT:	JMP FILLBUF	RETURN TO RETRY TEST THROUGH HERE	
787	003336	005237	017026	CONTS:	INC HPARLOG	INC HARD PARITY ERROR COUNTER	
788	003342	104400	015240		TYPE ,UBLLF		
789	003346	104400	015755		TYPE ,MUNREC	ITYPE HARD PARITY ERROR	
790	003352	104400	000000	PTYP2:	TYPE ,UPEN		
791	003356	104400	016017		TYPE ,MPAR		
792	003362	104400	015052		TYPE ,MCLRF		
793	003366	000137	010074		JMP DELUNIT	GO DELETE THE UNIT,CAN NOT CONTINUE	
794							
795							
796							
797							
798							
799							
800	003372	012737	000012	017016	FILLDONE:	MOV #10,PRETRY	SET UP RETRY COUNTER
801	003400	012746	003462		REWRITE:	MOV #WRTDNE,-(SP)	SET GOOD RETURN ON STACK
802	003404	012746	003510			MOV #WRITER,-(SP)	SET ERROR RETURN ON STACK
803	003410	112737	000105	004120		MOV #WRTIE,FUNCTION	SET FUNCTION WORD TO WRITE
804	003416	032737	001000	001212		BIT #BIT9,DTSTP	TEST FOR WRITE DELETED DATA
805	003424	001403				BEQ 1\$	
806	003426	112737	000115	004120		MOV #WTDUIE,FUNCTION	
807	003434	062737	000001	021030	1\$:	ADD #1,WTCNTH	INC TOTAL WRITE FUNCTIONS COUNTER
808	003442	005537	021032			ADC WTCNTR+2	DOUBLE PRECISION COUNTER
809	003446	004737	004022			JSR PC,COMMWORD	TRANSFER COMMAND TO DRIVE
810	003452	004737	007122			JSR PC,DDNECK	TEST FOR DONE FLAG
811	003456	000137	007204			JMP DINTERR	NO INTERRUPT ERROR
812							
813	003462	005737	004124	WRTDNE:	TST ERWRT	IS THIS A REWRITE FROM A DATA ERROR	
814	003466	001004			BNE 1\$	YES GO REREAD THIS SECTOR	
815	003470	005337	012306		DEC SECCNTR	NO,TEST SECTOR COUNTER	
816	003474	001003			BNE Z\$	NOT LAST SECTOR GO TO NEXT ONE	
817	003476	000207			RTS PC		
818	003500	000137	004246	1\$:	JMP REREAD	REREAD THE SECTOR	
819	003504	000137	005110	Z\$:	JMP RWRITE		
820							
821	003510	005726		WRITER:	TST (SP)+	REMOVE THE DONE RETURN FROM THE STACK	
822	003512	032737	000002	010070	BIT #BIT1,ASTAT	IS THIS A PARITY ERROR	
823	003520	001413			BEQ WRTSEK	NO, IT MUST BE A SEEK ERROR	
824							
825	003522	012737	016010	003264		PARITY ERROR DURING A WRITE FUNCTION	
826	003530	012737	016010	003554	MOV #MWRITE,PTYP1+2	PUT ADDR OF WRITE MESSAGE IN PAR ER TYP0UT 1	
827	003536	012737	005400	003534	MOV #MWRITE,PTYP2+2	PUT ADDR OF WRITE MESSAGE IN PAR ER TYP0UT 2	
828	003544	000137	005244		MOV #REWRITE,PCONT+2	IF NOT HARD ERR RETURN THROUGH PCONT TO REWRITE	
829					JMP PARTST	GO INC LOG AND TEST FOR RETRY	
830							
831	003550	012737	005130	003674	WRTSEK:	SEEK ERROR DURING A WRITE FUNCTION	
832					MOV #ONEWRT,SEKRTY+2	SETUP FOR WRT RETRY ON SEEK ERROR	
833						(AFTER A RECAL. THE CONTENTS OF SECTOR 1,	
834						TRACK 1 ARE LOADED INTO THE SECTOR BUFFER.	
835						TO REWRITE THE CORRECT DATA THE PROGRAM	
836	003556	012737	016010	003630	MOV #MWRITE,STYP1+2	MUST REFILL THE SECTOR BUFFER.	
837	003564	012737	016010	003722	MOV #MWRITE,STYP2+2	PUT ADDR OF WRITE MESSAGE IN SEEK ER TYP0UT 1	
838	003572	004737	005576		JSR PC,SEEKER	PUT ADDR OF WRITE MESSAGE IN SEEK ER TYP0UT 2	
839						RECORD SEEK ERROR	
840	003576	012703	017036	SEEKER:	MOV #ZSEKLOG,R3	SETUP INC INSTRUCTION FOR UNIT 0 LOG	

841	003602	004737	021044		JSR PC,U1LOG	TEST FOR UNIT 1 LOG
842	003606	005213			INC (R5)	INCREMENT SEEK ERROR LOG
843	003610	004737	003770		JSR PC,TRKERR	INCREMENT ERROR PER TRACK COUNTERS
844	003614	104405			CXSR	
845	003616	032777	020000	175370	BIT #SW13,PSWR	CHECK DON'T PRINT ERROR SWITCH
846	003624	001004			BNE SWHLT1	
847	003626	104400	016010	STYP1:	TYPE ,MWRITE	PRINT WRITE (READ) SEEK ERROR
848	003632	004737	003736		JSR PC,SEKTYP	
849	003636	104405		SWHLT1:	CXSR	
850	003640	005777	175350		TST #SWR	TEST THE HALT ON ERROR SWITCH
851	003644	100001			HPL CONT14	
852	003646	000000			HALT	HALT ON THE ERROR
853	003650	032777	004000	175336	CONT14:	CHECK THE NO RETRY SWITCH
854	003656	001007			BNE HANDSK	IF SET LOG HARD SEEK ERROR
855	003660	005337	017022		DEC SRETRY	HAVE 10 ERRORS BEEN LOGED
856	003664	001404			BEQ HANDSK	YES LOG HARD ERROR
857	003666	004737	002550		JMP PC,HOME	RECALIBRATE DRIVES ON SEEK ERROR
858	003672	000137	005130		JMP ONEWRT	NO,RETRY WRITE COMMAND (READ COMAND)
859	003676	012703	017076	SEKRTY:	MOV #ZSEKLOG,R3	SET INC. INST.FOR UNIT 0 ERR LOG
860	003702	004737	021044	HANDSK:	JSR PC,U1LOG	TEST FOR UNIT 1 ERROR LOG
861	003706	005213			INC (R5)	HARD SEEK ERROR
862	003710	104400	015240		TYPE ,UBLLF	
863	003714	104400	015755		TYPE ,MUNREC	ITYPE UNRECOVERABLE SEEK ERROR
864	003720	104400	016010	STYP2:	TYPE ,MWRITE	ON WRITE (READ) COMMAND
865	003724	004737	003736		JSR PC,SEKTYP	
866	003730	062706	000002		ADD #2,SP	REMOVE SEEK ERROR FROM STACK POINTER
867	003734	000207			RTS PC	RETURN TO NEXT SECTOR BY DONE RETURN ON STACK
868						
869	003736	104400	015775	SEKTYP:	TYPE ,MSEEK	ITYPE SEEK ERROR
870	003742	104400	014567		TYPE ,MPRES	ITYPE ADDRESS OF TRACK MOVED FROM
871	003746	013737	011362	003760	MOV PRESTRK,15	
872	003754	004537	014446		JSR R5,SGLDEC	
873	003760	000000		1\$:	OPEN	
874	003762	104400	015052		TYPE ,MCLRF	
875	003766	000207			RTS PC	
876						
877	003770	013705	011360	TRKERR:	MOV TARGET,R5	SET UP TO INC ERROR PER TRACK COUNTER
878	003774	006305			ASL R5	ADJUST FOR EVEN ADDRESS
879	003776	062705	020344		ADD #U0TRK,R5	ADD IN ADDRESS OF UNIT 0 LOG
880	004002	032737	000020	010704	BIT #BIT4,UNITSEL	CHECK THE UNIT SELECTION BIT
881	004010	001402			BEQ 1\$	IF CLEARED UNIT 0 IS ACTIVE
882	004012	062705	020576		ADD #U1TRK,R5	ADJUST FOR UNIT 1 LOG
883	004016	005215		1\$:	INC (R5)	INC THE CORRECT COUNTER
884	004020	000207			RTS PC	
885						
886	004022	013705	011360	COMMWORD:	MOV TARGET,R5	GET TRACK NUMBER
887	004026	006305			ASL R5	MULTIPLY BY 4 TO DOUBLE PRECISION
888	004030	006305			ASL R5	INTERLEAVE COUNTER LOCATIONS
889	004032	062705	017174		ADD #TRACC,R5	ADD ON ADDRESS OF TRACK ACCESS COUNTER
890	004036	062715	000001		ADD #1,(R5)	INCREMENT THE COUNTER
891	004042	005565	000002		ADD 2(R5)	CARRY TO HIGH ORDER WORD
892	004046	153737	010704	004120	B1\$0 UNITSEL,FUNCTION	SET UNIT SELECTION BIT IN COMMAND WORD
893	004054	013777	007010	175124	MOV FUNCTION,0RXC5	SEND OUT COMMAND TO DRIVE
894	004052	004737	007014		JSR PC,TRCK	WAIT FOR TR FLAG
895	004056	113777	012310	175114	MOV B TSECTOR,0RXD0	SEND OUT TARGET SECTOR
896	004074	004737	007014		JSR PC,TRCK	WAIT FOR TR FLAG

```

897 004100 113777 011360 175102      MOVB TARGET,#RXDB      ;SEND OUT TARGET TEACK
898 004106 005046                    CLR -(SP)              ;LOWER INTERRUPT LEVEL TO ALLOW AN INTERRUPT
899 004110 012746 004116              MOV #15,-(SP)
900 004114 000002                    RTI
901 004116 000207                    IS:                   RTS PC
902
903 004120 000000                    FUNCTION:              0
904 004122 000000                    RDAFTWT:              0
905 004124 000000                    ERWRT:                0
906 004126 000000                    DATAK:               0
907
908
909
910
911
912
913
914 004130 005137 004122      WRTRD:                COM RDAFTWT      ;SET READ AFTER WRITE FLAG
915 004134 004737 010312      JSR PC,GETPATTERN
916 004140 004737 011144      XWRTRD:              JSR PC,INITTRACKS
917 004144 004737 010614      JSR PC,GETUNIT
918 004150 004737 011254      IS:                  JSR PC,GETTRACK
919 004154 004737 003112      JSR PC,WRITE
920 004160 004737 004200      JSR PC,READ
921 004164 005337 011356      DEC TRKCNTR
922 004170 001367                    BNE IS
923 004172 004737 010732      JSR PC,STOP
924 004176 000760                    BR XWRTRD
925
926
927
928
929
930
931 004200 004737 012216      READ:                JSR PC,INITSECTOR
932 004204 004737 012516      XHEAD:              JSR PC,GETSECTOR
933 004210 012737 000012 017010      MOV #10,,RDRETRY    ;SET UP RETRY COUNTERS FOR DELETED DATA
934 004216 012737 000012 017012      MOV #10,,DATARETRY ;DATA ERROR
935 004224 012737 000012 017016      MOV #10,,PRETRY     ;PARITY
936 004232 012737 000012 017022      MOV #10,,SRETRY     ;SEEK
937 004240 012737 000012 017020      MOV #10,,CRETRY     ;AND CRC ERRORS
938 004246 005037 004126      CLR UATACK          ;CLEAR CRC DATA CHECK FLAG
939 004252 012746 004316      MOV #RDONE,-(SP)    ;SET GOOD RETURN ON STACK
940 004256 012746 004460      MOV #RDERR,-(SP)    ;SET READ ERROR RETURN ON STACK
941 004262 112737 000107 004120      MOV #RDIE,FUNCTION
942 004270 062737 000001 021034      ADD #1,RDGNTR       ;INC TOTAL READ FUNCTIONS COUNTER
943 004276 005537 021036      ADC RDGNTR+2        ;DOUBLE PRECISION COUNTER
944 004302 004737 004022      JSR PC,COMMWORD
945 004306 004737 007122      JSR PC,DONECHK
946 004312 000137 007204      JMP NUNTER          ;TEST FOR DONE
947
948
949
950 004316 022737 000012 017004      RDONE:              CMP #10,,RDRETRY    ;IS READ RETRY EQUAL TO 10
951 004324 001420                    HGT CNT1            ;YES,NO ERRORS OCCURED
952 004326 012703 017052      MOV #RDLOG,R3      ;SET INC. INST. FOR UNIT 0 ERROR LOG

```

```

953 004332 004737 021044      JSR PC,U1LOG        ;TEST FOR UNIT 1 ERROR LOG
954 004336 005213                    INC (R3)            ;INC RECOVERABLE READ LOG
955 004340 012737 000012 017004      MOV #10,,RDRETRY    ;RESET READ RETRY COUNTER
956 004346 104400 015240      TYPE ,DUBLF         ;TYPE RECOVERABLE READ ERROR
957 004352 104400 015627      TYPE ,MREC          ;TYPE RECOVERABLE READ ERROR
958 004356 104400 015674      TYPE ,MREAD         ;TYPE RECOVERABLE READ ERROR
959 004362 104400 015052      TYPE ,MCRFL        ;TYPE RECOVERABLE READ ERROR
960 004366 022737 000012 017006      CONT1:             CMP #10,,WTRETRY    ;IS WRITE RETRY EQUAL TO 10
961 004374 001420                    BGT CNT2            ;YES,NO ERRORS OCCURED
962 004376 012703 017056      MOV #WRTRLOG,R3    ;SET INC. INST. FOR UNIT 0 ERROR LOG
963 004402 004737 021044      JSR PC,U1LOG        ;TEST FOR UNIT 1 LOG
964 004406 005213                    INC (R3)            ;INC RECOVERABLE WRITE LOG
965 004410 012737 000012 017006      MOV #10,,WTRETRY    ;RESET THE WRITE RETRY COUNTER
966 004416 104400 015240      TYPE ,USLF          ;TYPE RECOVERABLE WRITE ERROR
967 004422 104400 015627      TYPE ,MREC         ;TYPE RECOVERABLE WRITE ERROR
968 004426 104400 016010      TYPE ,MWRITE       ;TYPE RECOVERABLE WRITE ERROR
969 004432 104400 015052      TYPE ,MCRFL        ;TYPE RECOVERABLE WRITE ERROR
970 004436 004737 005204      CONT2:             JSR PC,ODCHK        ;CHECK FOR DELETED DATA INDICATOR
971 004442 005701      TST R1              ;BIT 15 OF R1 IS READ 1 SECTOR FLAG
972 004444 100001      RPL NEXTRD          ;IF SET,GO VERIFY DATA JUST READ
973 004446 000207      RTS PC
974 004450 005337 012306      NEXTRD:           DEC SECCNTR
975 004454 001253      BNE XREAD           ;IF SET,GO VERIFY DATA JUST READ
976 004456 000207      RTS PC              ;READ FUNCTION IS DONE
977
978 004460 005726      RDERR:            TST (SP)+           ;REMOVE THE DONE RETURN FROM THE STACK
979 004462 032737 000002 010070      BIT #BIT1,ASTAT    ;IS THIS A PARITY ERROR
980 004470 001413      BEQ IS              ;NO, SEE IF ITS A CRC ERROR
981
982 004472 012737 015674 003264      ;PARITY ERROR DURING A READ FUNCTION
983 004500 012737 015674 003354      MOV #NHEAD,PTYP1+2 ;PUT ADDR OF READ MESSAGE IN PAR ERR TYPEOUT 1
984 004506 012737 004246 003334      MOV #NHEAD,PTYP2+2 ;PUT ADDR OF READ MESSAGE IN PAR ER TYPEOUT 2
985 004514 000137 005244      MOV #RREAD,PCONT+2 ;IF HARD ERR RETURN THROUGH PCONT TO REREAD
986 004520 032737 000001 010070      JMP PARTEST        ;RECORD PARITY ERROR AND RETRY FUNCTION
987 004526 001014      BIT #BIT0,ASTAT    ;IS THIS A CRC ERROR
988
989 004530 012737 004246 003674      BNE CRER          ;YES GO TEST AND LOG IT
990 004536 012737 015674 003630      ;SEEK ERROR DURING A READ FUNCTION
991 004544 012737 015674 003722      MOV #RREAD,SEKRTY+2 ;SET SEEK CONTINUE FOR READ RETRY
992 004552 004737 003576      MOV #NHEAD,STYP1+2 ;SET ADDR OF READ MESSAGE IN SEEK ER TYPEOUT 1
993 004556 000734      MOV #NHEAD,STYP2+2 ;SET ADDR OF READ MESSAGE IN SEEK ER TYPEOUT 2
994
995 004560 004737 003770      JSR PC,SEEKER      ;RECORD SEEK ERROR
996 004564 005701      BR NEXTRD          ;GO TO NEXT SECTOR,CAN'T READ THIS ONE
997 004566 100061      ;CRC ERROR DETECTED WHILE READING
998 004570 005237 004126      JSR PC,TRKERR      ;INC ERROR PER TRACK COUNTER
999 004574 004737 005536      TST R3             ;IF READ ONLY, REPORT DATA CRC ERROR
1000 004600 005737      BPL DATACRC        ;SET DATA CHECK FLAG
1001 004604 001052      INC UATACK         ;CHECK FOR A DATA ERROR
1002 004606 012703 017046      JSR PC,EMPBUFF     ;WAS THERE A DATA ERROR
1003 004612 004737 021044      TST ERCONTR       ;YES,REREAD AND/OR REWRITE THE DATA
1004 004616 005213      BNE UATACRC        ;YES,REREAD AND/OR REWRITE THE DATA
1005 004620 104405      MOV #ZCRBAD,R3    ;SET INC. INST. FOR UNIT 0 ERROR LOG
1006 004622 032777 020000 174364      JSR PC,U1LOG      ;TEST FOR UNIT 1 ERROR LOGS
1007 004630 001004      INC (R3)           ;NO,INC BAD CRC GENERATOR ERROR
1008 004632 104400      CKSW              ;TEST DON'T SWITCH
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500

```

1009	004636	104400	015052			TYPE ,MCRLF	
1010	004642	104405				CXSWH	
1011	004644	005777	174344	25:		TST #SWR	
1012	004650	100001				BPL CONT15	IF TEST HALT ON ERROR SWITCH
1013	004652	000000				HALT	
1014	004654	032777	004000	174332	HLT10:	CONT15:	IF HALT ON ERROR
1015	004662	001005				BIT #SW11,#SWR	IF CHECK NO RETRY SWITCH
1016	004664	005337	017020			BNE 55	IF SET LOG HARD ERROR
1017	004670	001402				DEC CHETRY	IF HAVE 10 ERRORS BEEN LOGED
1018	004672	000137	004246			BEQ 55	IF YES, LOG HARD ERROR
1019	004676	012703	017106			JMP REREAD	IF NO, GO REREAD DATA
1020	004702	004737	021044		35:	MOV #ZHCRCBAD,R3	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1021	004706	005213				JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1022	004710	104400	015240			INC (R3)	
1023	004714	104400	015644			TYPE ,DBLLF	
1024	004720	104400	015052			TYPE ,MBADCRC	IF TYPE HARD CRC GENERATOR ERROR
1025	004724	104400	015724			TYPE ,MCRLF	
1026	004730	000000				TYPE ,MHALT11	IF AND HALT AS THE CRC GENERATOR DOESN'T WORK
1027						HALT	
1028	004732	012703	017042			DATA CRC ERROR REREAD AND/OR REWRITE TO GET GOOD DATA	
1029	004736	004737	021044			MOV #ZCRCLOG,R3	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1030	004742	005213				JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1031	004744	104405				INC (R3)	IF TRUE DATA CRC ERROR
1032	004746	032777	020000	174240		CXSWH	
1033	004754	001004				BIT #SW13,#SWR	IF TEST DON'T PRINT ERROR SWITCH
1034	004756	104400	015736			BNE 45	
1035	004762	104400	015052			TYPE ,MCRC	IF TYPE DATA CRC ERROR
1036	004766	104405				TYPE ,MCRLF	
1037	004770	005777	174220		45:	CXSWH	
1038	004774	100001				TST #SWR	IF TEST HALT ON ERROR SWITCH
1039	004776	000000				BPL CONT16	
1040	005000	032777	004000	174206	HLT12:	CONT16:	IF HALT ON ERROR
1041	005006	001005				BIT #SW11,#SWR	IF TEST NO RETRY SWITCH
1042	005010	005337	017004			BNE 55	IF SET LOG HARD ERROR
1043	005014	001402				DEC RDRETRY	IF HAVE 10 ERRORS OCCURED
1044	005016	000137	004246			BEQ 55	IF YES, LOG HARD ERROR OR REWRITE DATA
1045	005022	012703	017102			JMP REREAD	IF NO, GO REREAD THIS SECTOR
1046	005026	004737	021044		55:	MOV #ZMCRCLG,R3	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1047	005032	005213				JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1048	005034	012737	000012	017004		INC (R3)	IF INC HARD CRC ERROR LOG
1049	005042	005737	004122			MOV #10, RDRETRY	IF RESET READ RETRY COUNTER
1050	005046	001021				TST WDRAFT	IF IS THIS A HEAD AFTER WRITE FUNCTION
1051	005050	012703	017112			BNE CNT6	IF YES, GO REWRITE IT
1052	005054	004737	021044			MOV #ZHRDLOG,R3	IF NO, SET INC, INST, FOR UNIT 0 ERROR LOG
1053	005060	005213				JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1054	005062	104400	015240			INC (R3)	IF READ ONLY, HARD READ ERROR
1055	005066	104400	015755			TYPE ,DBLLF	
1056	005072	104400	015674			TYPE ,MUNREC	IF TYPE UNRECOVERABLE READ ERROR
1057	005076	104400	015052			TYPE ,MREAU	
1058	005102	062706	000002		CONT7:	TYPE ,MCRLF	
1059	005106	000137	004450			AUD #2,5P	IF REMOVE HEAD DONE ADDRESS FROM STACK
1060	005112	104405				JMP NEXTRD	IF READ NEXT SECTOR CAN'T READ THIS ONE
1061	005114	032777	004000	174072	CNT6:	CXSWH	
1062	005122	001011				BIT #SW11,#SWR	IF TEST NO RETRY SWITCH
1063	005124	005337	017006			BNE 75	IF SET LOG HARD ERROR
1064	005130	001406				DEC WTRETRY	IF HAVE 10 REWRITES BEEN DONE
						BEQ 75	IF YES, LOG HARD WRITE ERROR

1065	005132	005137	004124			COM ERWRT	IF NO, SET THE WRITE CAUSED BY ERROR FLAG
1066	005136	002706	000002			AUD #2,5P	IF REMOVE RDONE ADDRESS FROM STACK
1067	005142	000137	003130			JMP UNERWRT	IF REWRITE SECTOR THEN REREAD TO CHECK FOR ERROR
1068	005146	012703	017116		75:	MOV #ZHWRTLOG,R3	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1069	005152	004737	021044			JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1070	005156	005213				INC (R3)	IF HARD WRITE ERROR
1071	005160	012737	000012	017006		MOV #10, WTRRETRY	IF RESET WRITE RETRY COUNTER
1072	005166	104400	015240			TYPE ,DBLLF	
1073	005172	104400	015755			TYPE ,MUNREC	IF TYPE UNRECOVERABLE WRITE ERROR
1074	005176	104400	016010			TYPE ,MWRITE	
1075	005202	000735				BR CONT7	
1076							
1077							
1078							
1079	005204	032737	001000	001212	DDCHK1	HIT #BIT9,DTESTP	IF TEST BIT 9 AS TO DELETED DATA TRANSFER
1080	005212	001472				BEQ CONT10	
1081	005214	132737	000100	010070		HIT8 #BIT6,ASTAT	IF THIS IS A DELETED DATA FUNCTION
1082	005222	001114				BNE RETURN	IF DD BIT SHOULD BE SET
1083	005224	012703	017066			MOV #ZDDMIS,R3	IF SET INC INST FOR UNIT 0 ERROR LOG
1084	005230	004737	021044			JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1085	005234	005213				INC (R3)	IF INC MISSING DELETED DATA LOG
1086	005236	004737	003770			JSR PC,TRKERR	IF INC ERROR PER TRACK COUNTER
1087	005242	104405				CXSWH	
1088	005244	032777	020000	173742		BIT #SW13,#SWR	IF TEST DON'T PRINT ERROR SWITCH
1089	005252	001011				BNE CONT11	
1090	005254	104400	014506			TYPE ,MDDMIS	IF TYPE MISSING DELETED DATA BIT
1091	005260	052737	000400	010704	DDERR:	HIS #BIT8,UNITSEL	IF SET HAD ERROR FLAG
1092	005266	004737	007716			JSR PC,TYPADR	IF TYPE ADDRESS OF ERROR
1093	005272	104400	015052			TYPE ,MCRLF	
1094	005276	104405			CONT11:	CXSWH	
1095	005300	005777	173710			TST #SWR	IF TEST HALT ON ERROR SWITCH
1096	005304	100001				BPL CONT17	
1097	005306	000000				HALT	IF HALT ON DELETED DATA ERROR
1098	005310	032777	004000	173676	HLT13:	CONT17:	IF TEST NO RETRY SWITCH
1099	005316	001005				BIT #SW11,#SWR	IF SET LOG HARD ERROR
1100	005320	005337	017010			BNE 45	IF HAVE 10 ERRORS BEEN LOGED
1101	005324	001402				DEC UDRETRY	IF YES LOG HARD ERROR
1102	005326	000137	004246			BEQ 45	IF NO, REREAD SECTOR
1103	005332	012703	017126			JMP REREAD	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1104	005336	004737	021044		45:	JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1105	005342	005213				JSR PC,U1LOG	
1106	005344	104400	015240			INC (R3)	
1107	005350	104400	015755			TYPE ,DBLLF	
1108	005354	104400	015615			TYPE ,MUNREC	IF TYPE UNRECOVERABLE DELETED DATA ERROR
1109	005360	104400	015052			TYPE ,MODER	
1110	005364	004737	007716			TYPE ,MCRLF	
1111	005370	104400	015052			JSR PC,TYPADR	
1112	005374	000137	004450			TYPE ,MCRLF	
1113	005400	032737	000100	010070	CONT10:	JMP NEXTRD	IF READ NEXT SECTOR
1114	005406	001422				BIT #BIT6,ASTAT	IF THIS IS NOT A DELETED DATA TRANSFER
1115	005410	012703	017072			BEQ RETURN	
1116	005414	004737	021044			MOV #ZUNXDD,R3	IF SET INC, INST, FOR UNIT 0 ERROR LOG
1117	005420	005213				JSR PC,U1LOG	IF TEST FOR UNIT 1 ERROR LOGS
1118	005422	052737	000400	010704		INC (R3)	IF UNEXPECTED DD BIT SET
1119	005430	004737	003770			BIS #BIT8,UNITSEL	IF SET HAD ERROR FLAG
1120	005434	104405				JSR PC,TRKERR	IF INC ERROR PER TRACK COUNTER
						CXSWH	

```

1121 005436 032777 020000 173550          BIT #SW13,#SWR          !TEST DON'T PRINT ERROR SWITCH
1122 005444 001314                                BNE CONT11
1123 005446 104400 014462                                TYPE ,MUNXDD          !TYPE UNEXPECTED DELETED DATA HIT
1124 005452 000702                                BR UOERR
1125 005454 000207                                RETURN:              RTS PC
1126
1127
1128
1129
1130
1131
1132
1133
1134 005456 005137 004122          WTRDCK:          COM WDAFTWT          !SET READ AFTER WRITE FLAG
1135 005462 004737 010312          JSR PC,READ
1136 005466 004737 011144          XWTRDCK:        JSR PC,INITTRACKS
1137 005472 004737 010614          JSR PC,GETUNIT
1138 005476 004737 011254          1S:            JSR PC,GETTRACK
1139 005502 004737 003112          JSR PC,WRITE
1140 005506 004737 005526          JSR PC,READCHK
1141 005512 005337 011356          DEC TRKCNTR
1142 005516 001367                                MNE 1S
1143 005520 004737 010732          JSR PC,STOP
1144 005524 000760                                BR XWTRDCK
1145
1146
1147
1148
1149
1150
1151
1152 005526 052701 100000          READCHK:        BIS #BIT15,R1          !SET READ ONE SECTOR FLAG
1153 005532 004737 004200          JSR PC,READ          !GO READ ONE SECTOR
1154 005536 005737 012306          EMPBUFF:        TST SECCNTR          !IF CLEARED NO SECTOR WAS FOUND
1155 005542 001002                                MNE 2S
1156 005544 000137 006432          JMP EXIT          !GO TO NEXT TRACK CAN'T READ THIS ONE
1157 005550 005037 006434          2S:            CLR MYECNTR          !CLEAR THE BYTE AND ERROR COUNTERS
1158 005554 005037 006442          CLR ELCNTR
1159 005560 052701 000200          BIS #BIT7,R1          !R1 BIT 7 IS USED AS FIRST ERROR FLAG
1160 005564 004737 005656          JSR PC,ADJSUM          !ADJUST DATA AND CK SUM FOR ADDRESSES
1161 005570 005037 005746          CLR CKSUM          !SET UP FOR CHECK SUM ACCUMULATION
1162 005574 012746 006212          MOV #EMPDONE,-(SP)    !SET UP RETURN ADDRESSES
1163 005600 012746 005750          MOV #EMPER,-(SP)
1164 005604 005046                                CLR -(SP)          !LOWER INTERRUPT LEVEL
1165 005606 012746 005614          MOV #1S,-(SP)
1166 005612 000002                                RTI
1167 005614 012777 000103 173364 1S:          MOV #EMIE,#RXCS          !LOAD EMPTY BUFFER FUNCTION
1168 005622 004737 007014          EMPFLAG:        JSR PC,TRCK          !TEST FOR TR FLAG
1169
1170 005626 117737 173356 006436          CKBYTE:         MOV# #RX00,BAUBYTE    !SAVE BYTE FROM DISKETTE
1171 005634 063737 006436 005746          ADD BAUBYTE,CKSUM    !ACCUMULATE CHECK SUM
1172 005642 123720 006436          CMP# BAUBYTE,(R0)+   !COMPARE AGAINST GOOD BYTE
1173 005646 001054                                BNE DATAER          !IF NOT EQUAL GO TO DATAER
1174 005650 005237 006434          INC BYTECNTR
1175 005654 000762                                BR EMPFLAG          !GET NEXT BYTE
1176

```

```

1178 005664 113737 011360 016604          ADJSUM:         MOV# TARGET,BUFA0R    !SET FIRST AND SECOND BYTES WITH ADDRESSES
1179 005672 113737 012310 016605          MOV# TSECTOR,BUFA0R+1
1180 005700 063737 011360 005746          MOV SUM,CKSUM          !GET THE PATTERN SUM
1181 005706 063737 012310 005746          ADD TARGET,CKSUM      !ADD TRACK ADDRESS TO CHECK SUM
1182 005714 113737 005746 017002          ADD TSECTOR,CKSUM     !ADD SECTOR ADDRESS TO CHECK SUM
1183 005722 105337 005746 017002          MOV# CKSUM,BUFA0R+176 !INSERT CHECK SUM TO DATA BUFFER
1184 005726 105337 005746 017002          ASL# CKSUM            !GENERATE NEGATIVE CHECK SUM
1185 005732 113737 005746 017003          NEG# CKSUM
1186 005740 012700 016604          MOV# CKSUM,BUFA0R+177 !INSERT NEG,SUM INTO DATA BUFFER
1187 005744 000207                                MOV #BUFA0R,R0          !SET ADDRESS OF BYTE IN R0
1188                                RTS PC          !RETURN
1189
1190
1191 005750 005726                                CKSUM:          0
1192 005752 012737 015402 003264          EMPEP:          TST (SP)+          !REMOVE THE ODNE RETURN FROM THE STACK
1193 005760 012737 015402 003354          MOV #EMPTY,PTYP2+2   !PUT ADDR OF EMPTYBUF MESSAGE IN PAR ER TYP0UT 1
1194 005766 012737 005536 003334          MOV #EMPTY,PTYP2+2   !PUT ADDR OF EMPTYBUF MESSAGE IN PAR ER TYP0UT 2
1195 005774 000137 003244          MOV #EMPBUFF,PCONT+2 !NOT HARD ERR RETURN THROUGH PCONT TO EMPTYBUF
1196                                JMP PARTEST          !REPORT PARITY ERROR
1197
1198 006000 052737 000400 010704          DATAER:        BIS #BIT0,UNITSEL    !SET THE HARD ERROR FLAG
1199 006006 005237 006442                                INC ELCNTR          !INC THE BYTE ERROR COUNTER
1200 006014 032777 020000 173172          CKSWK:          BIT #SW13,#SWR          !TEST PRINT ERROR SW IN SWR
1201 006022 001062                                BNE NOERTYP          !DON'T PRINT THE ERROR
1202 006024 032777 010000 173162          BIT #SW12,#SWR          !TEST PRINT 10 ERRORS SWITCH
1203 006032 001404                                MEO 1S              !PRINT ALL ERRORS
1204 006034 023727 006442 000012          CMP ELCNTR,#10.      !HAVE 10 ERRORS BEEN TYPED
1205 006042 003052                                BGT NOERTYP          !YES,DON'T PRINT ANY MORE
1206 006044 005737 004126          1S:            TST DATAER          !WAS THIS A READ CHECK DUE TO CRC ERROR
1207 006050 001403                                REQ 2S              !NO,REPORT DATA ERRORS
1208 006052 105701                                TST# R1              !YES,TEST FIRST ERROR FLAG
1209 006054 100017                                BPL TYPERR          !TYPE THE DATA CRC ERROR
1210 006056 000412                                BR 3S
1211 006060 105701                                TST# R1              !TEST FIRST ERROR FLAG
1212 006062 100014                                BPL TYPERR
1213 006064 104400 015052                                TYPE ,MCRLF
1214 006070 104400 014527                                TYPE ,MDEH0R          !PRINT ERROR HEADER
1215 006074 104400 015052                                TYPE ,MCRLF
1216 006100 004737 007716          JSR PC,TYPADR          !PRINT TRACK AND SECTOR LOCATIONS
1217 006104 104400 014616          TYPE ,MCOLMUN          !SET UP COLMUN HEADINGS
1218 006110 042701 000200          BIC #BIT7,R1          !CLEAR FIRST ERROR FLAG
1219 006114 013737 006434 006126          TYPERR:         MOV #YTECNTR,1S      !PRINT BYTE NUMBER
1220 006122 004537 014446          JSR R5,SGLDEC
1221 006126 000000          1S:            OPEN
1222 006130 104400 015047                                TYPE ,DBLSP
1223 006134 013746 006436          MOV #BADBYTE,-(SP)    !PRINT BYTE READ FROM DISKETTE
1224 006140 104402                                TYP0S
1225 006142 000003                                ,WORD 3
1226 006144 104400 015047                                TYPE ,DBLSP
1227 006150 114037 006440          MOV# -(R0),GOODBYTE   !GET GOOD BYTE
1228 006154 005200                                INC R0              !RETURN R0 TO NEXT BYTE IN BUFFER
1229 006156 013746 006440          MOV GOODBYTE,-(SP)
1230 006162 104403                                TYP0N
1231 006164 104400 015052                                TYPE ,MCRLF          !PRINT GOOD DATA
1232 006170 104405          NOERTYP:        CKSWK

```

```

1233 006172 005777 173016          TST #SWR          ;TEST HALT ON ERROR SWITCH
1234 006176 100001          BPL CONT20
1235 006200 000000          HLT14:          MALT
1236 006202 005237 006434          CONT20:        INC BYTECNTR
1237 006206 000137 005622          JMP EMPFLAG
1238
1239 006212 005737 004126          EMPDNE:        TST DATABK      ;WAS THIS READCHECK CAUSED BY CRC ERROR
1240 006216 001401          BEQ 15         ;NO,CONTINUE
1241 006220 000207          RTS PC        ;YES,RETURN TO CRC ERROR HANDLER
1242 006222 005737 006442          1$:           TST ERCNTR     ;WAS THERE ERRORS
1243 006226 001471          BEQ CNT3      ;NO ERRORS
1244 006230 104405          CKS#W
1245 006232 032777 020000 172754          BIT #SW13,#SWR ;YES,TEST DON'T PRINT SWITCH
1246 006240 001024          BNE 25         ;DON'T PRINT THE ERROR
1247 006242 104400 015333          TYPE ,MERC     ;PRINT THE TOTAL DATA ERROR COUNT
1248 006246 013737 006442 006260          MOV ERCNTR,35
1249 006254 004537 014446          JSR #5,5GLDEC
1250 006260 000000          UPEN
1251 006262 104400 016327          TYPE ,MSUM     ;INDICATE IF CHECK SUM WAS GOOD OR HAD ERRORS
1252 006266 105737 005746          TST# CKSUM
1253 006272 001403          BEQ 45
1254 006274 104400 016067          TYPE ,MERS
1255 006300 000402          BR 59
1256 006302 104400 016322          TYPE,MGOOD
1257 006306 104400 015052          TYPE ,MCRFLF
1258 006312 012703 017062          4$:          ;SET INC,INST,FOR UNIT 0 ERROR LOG
1259 006316 004737 021044          5$:          ;TEST FOR UNIT 1 ERROR LOGS
1260 006322 005213          INC (W3)       ;INC DATA ERROR LOG
1261 006324 004737 003770          JSR PC,TRKERR ;INC ERROR PER TRACK COUNTER
1262 006330 104405          CKS#W
1263 006332 032777 004000 172654          BIT #SW11,#SWR ;TEST NO MTRY SWITCH
1264 006340 001007          BNE 65         ;IF SET LOG HARD ERROR
1265 006342 005337 017012          DEC DATARETRY ;HAVE 10 ERRORS BEEN LOGED
1266 006346 001404          BEQ 65
1267 006350 004737 004246          JSR PC,REREAD ;NO,GO REREAD THE DATA
1268 006354 000137 005536          JMP EMPBUFF    ;GO RECHECK THE DATA
1269 006360 012703 017122          MOV #ZMDATLOG,R3 ;YES,SET INC,INST,FOR UNIT 0 ERROR LOG
1270 006364 004737 021044          JSR PC,UILOG   ;TEST FOR UNIT 1 ERROR LOGS
1271 006370 005213          INC (K3)       ;INC HARD DATA NO STATUS ERROR
1272 006372 104400 015240          TYPE ,UBLLF
1273 006376 104400 015755          TYPE ,MUNREC   ;TYPE UNRECOVERABLE DATA NO
1274 006402 104400 014527          TYPE ,MODERHDR ;STATUS ERROR
1275 006406 104400 015052          TYPE ,MCRFLF
1276 006412 005337 012306          DEC SECCNTR
1277 006416 001405          BEQ EXIT
1278 006420 004737 004244          JSR PC,XREAD   ;READ THE NEXT SECTOR
1279 006424 000137 005536          JMP EMPBUFF
1280 006430 005001          CLR R1         ;CLEAR THE ONE READ FLAG
1281 006432 000207          EXIT:         RTS PC
1282
1283 006434 000000          BYTECNTR:     0
1284 006436 000000          BADBYTE:      0
1285 006440 000000          GOODBYTE:     0
1286 006442 000000          ERCNTR:       0
1287
1288 ;*****

```

```

1289
1290 ;READ AND VERIFY ALL SECTORS WRITTEN BY
1291 ;PREVIOUS WRITE FUNCTION
1292 ; T = 4
1293
1294
1295 006444 004737 010312          RDCHK:        JSR PC,GETPATTERN
1296 006450 004737 011144          XRDCHK:       JSR PC,INITTRACKS
1297 006454 004737 010614          JSR PC,GETUNIT
1298 006460 004737 011254          1$:          JSR PC,GETTRACK
1299 006464 004737 005526          JSR PC,READCHK
1300 006470 005337 011356          DEC TRKNTR
1301 006474 001371          HNE 15
1302 006476 004737 010732          JSR PC,STOP
1303 006502 000762          BR XRDCHK
1304
1305 ;*****
1306
1307 ;DO A READ ONLY FUNCTION ON ALL SECTORS
1308 ;THIS DOES NOT VERIFY THE DATA, ONLY TESTS FOR CRC ERRORS
1309 ; T = 5
1310
1311
1312 006504 004737 010312          RDONLY:       JSR PC,GETPATTERN
1313 006510 004737 011144          XRDONLY:     JSR PC,INITTRACKS
1314 006514 004737 010614          JSR PC,GETUNIT
1315 006520 004737 011254          1$:          JSR PC,GETTRACK
1316 006524 004737 004200          JSR PC,READ
1317 006530 005337 011356          DEC TRKNTR
1318 006534 001371          HNE 15
1319 006536 004737 010732          JSR PC,STOP
1320 006542 000762          BR XRDONLY
1321
1322 ;*****
1323
1324 ;WRITE AND READ CHECK ANY DATA PATTERN,AND ANY TRACK SEQUENCE
1325 ;BUT ALTERNATE BETWEEN DRIVE UNITS ON EACH TRACK SELECTED.
1326 ; T = 6
1327
1328
1329
1330 006544 005137 004122          DRVSWP:      COM WDAFTWT ;SET THE READ AFTER WRITE FLAG
1331 006550 004737 010312          JSR PC,GETPATTERN
1332 006554 004737 011144          2$:          JSR PC,INITTRACKS
1333 006560 004737 010614          1$:          JSR PC,GETUNIT ;SET UP FOR UNIT 0
1334 006564 004737 011254          JSR PC,GETTRACK ;GET THE TRACK TO BE ACCESSED
1335 006570 004737 003112          JSR PC,WRITE
1336 006574 004737 005526          JSR PC,READCHK
1337 006600 004737 010614          JSR PC,GETUNIT ;NOW GO TO UNIT 1 ON THE SAME TRACK
1338 006604 004737 003112          JSR PC,WRITE
1339 006610 004737 005526          JSR PC,READCHK
1340 006614 005337 011356          DEC TRKNTR
1341 006620 001357          BNE 15
1342 006622 004737 010732          JSR PC,STOP
1343 006626 000752          BR 25
1344

```

```

1345
1346 ;*****
1347 ;THE FIRST HALF OF TEST 7 FORCES THE TRACK SEQUENCE
1348 ;TO INCREMENT UP THROUGH ALL THE TRACKS DURING WRITE / READ CHECK FUNCTIONS.
1349 ;THIS VERIFIES THAT ALL THE TRACKS ARE ACCESSABLE.
1350 ;THE SECOND HALF OF THE PASS WILL USE THE SEQUENCE SELECTED BY THE
1351 ;OPERATION AS INDICATED BELOW, AND ONLY READ CHECK THE DATA JUST WRITTEN.
1352 ;THIS VERIFIES THAT THE DATA CAN BE READ FROM A TRACK, AFTER THE HEAD HAS BEEN
1353 ;MOVED AWAY FROM AND BACK TO THAT TRACK. AT THE COMPLETION OF THE PASS
1354 ;THE DELETED DATA BIT IN TEST CONDITIONS IS COMPLEMENTED AND THE NEXT
1355 ;PASS WILL BE RUN UNDER THIS NEW CONDITION.
1356 ; T = 0 OR 7
1357
1358 006630 004737 010312 TEST7: JSR PC,GETPATTERN
1359 006634 013737 011370 007012 MOV SEQUEN,SEQSAV ;SAVE THE SELECTED SEQUENCE
1360 006642 012737 000001 011370 TEST7X: MOV #1,SEQUEN ;FORCE INCREMENT SEQUENCE
1361 006650 005137 004122 COM WDAFTWT ;SET READ AFTER WRITE FLAG FOR ERROR TESTING
1362 006654 004737 011144 JSR PC,INITTRACKS
1363 006660 004737 010614 JSR PC,GETUNIT
1364 006664 004737 011254 1S: JSR PC,GETTRACK
1365 006670 004737 005112 JSR PC,WRITE
1366 006674 004737 005526 JSR PC,READCHK
1367 006700 005337 011356 DEC TRKCNTR ;IS THE FIRST HALF OF THE PASS DONE
1368 006704 001367 BNE 1S ;NO,CONTINUE WRITING AND READING
1369 006706 005037 004122 CLR WDAFTWT ;YES,NOW DO A READ ONLY
1370 006712 013737 007012 011370 MOV SEUSAV,SEQUEN ;USING SELECTED SEQUENCE
1371 006720 004737 011144 JSR PC,INITTRACKS
1372 006724 004737 011254 2S: JSR PC,GETTRACK
1373 006730 004737 005526 JSR PC,READCHK
1374 006734 005337 011356 DEC TRKCNTR ;IS THIS HALF OF THE PASS DONE
1375 006740 001371 BNE 2S ;NO,CONTINUE READ CHECKING
1376 006742 004737 010732 JSR PC,STUP ;YES,TEST FOR END OF PASS CONDITIONS
1377 006746 032737 040100 010704 BIT #40100,UNITSEL ;HAVE ALL SELECTED UNITS BEEN USED
1378 006754 001332 BNE TEST7X ;IF A USED BIT IS STILL SET GO TO NEXT DRIVE
1379 006756 012726 001200 MOV #1200,SP ;RESET STACK ADDRESS FOR ACT11 EOP
1380 006762 032737 001000 001212 HLT #BIT9,UTESTP ;NEXT PASS,COMPLEMENT D U BIT
1381 006770 001404 BEQ 3S
1382 006772 042737 001000 001212 HIC #BIT9,DTESTP ;IT WAS ON CLEAR IT
1383 007000 000720 MP TEST7X
1384 007002 052737 001000 001212 3S: HIS #BIT9,UTESTP ;IT WAS OFF SET IT
1385 007010 000714 HR TEST7X
1386
1387 007012 000000 SEUSAV: 0
1388 ;*****
1389 ;TEST FOR TRANSFER FLAG AND PROGRAM NOT HUNG
1390
1391
1392 007014 005037 007200 TRCK: CLR MCNTR1 ;CLEAR HUNG COUNTER
1393 007020 012746 000540 MOV #PK7,-(SP) ;RAISE INTERRUPT LEVEL TO INHIBIT INTERRUPTS
1394 007024 012746 007032 MOV #3S,-(SP)
1395 007030 000002 RTI
1396 007032 105777 172150 3S: TST #MXCS ;TEST FOR TR FLAG
1397 007036 100001 HPL 1S ;SKIP NEXT INST,IF NOT SET
1398 007040 000207 RTS PC ;RETURN TO TRANSFER DATA
1399 007042 023727 006434 000200 1S: CMP BYTECNTR,#128. ;HAVE 128 BYTES BEEN TRANSFERRED
1400 007050 001403 BEQ 2S ;ALLOW AN INTERRUPT IF EQUAL
  
```

```

1401 007052 005237 007200 INC MCNTR1 ;IF THE HUNG COUNTER OVERFLOWS EITHER
1402 ;THERE WAS NO TR FLAG OR NO INTERRUPT OCCURED
1403 ;AFTER 128 BYTES TRANSFERED
1404 007056 001365 BNE 1S ;NO OVERFLOW RETEST FOR TR FLAG
1405 007060 132777 000040 172120 2S: HLT #DUNEMIT,ORXCS ;TEST FOR A DONE FLAG WHICH WOULD INDICATE A
1406 ;POSSIBLE ERROR CONDITION EXISTS WHILE
1407 ;TRANSFERRING COMMANDS OK DATA
1408 007066 001407 BEQ 4S ;IF DONE NOT SET,TYPE HUNG
1409 007070 005037 006434 CLR BYTECNTR ;CLEAR BYTE COUNTER SO IT WON'T INTERFERE
1410 ;WITH TESTING FOR DONE.
1411 007074 005726 TST (SP)+ ;REMOVE THIS RETURN ADDRESS FROM STACK
1412 007076 005046 CLR -(SP) ;LOWER INTERRUPT LEVEL TO ACCEPT AN INTERRUPT
1413 007100 012746 007106 MOV #4S,-(SP) ;THE INTERRUPT WILL RETURN THROUGH PREVIOUSLY
1414 007104 000002 RTI ;SET ADDRESSES
1415 007106 005237 007200 4S: INC MCNTR1 ;ALLOW SOME TIME FOR FLAG TO SET
1416 007112 001362 BNE 2S
1417 007114 104400 015432 TYPE ,MHUNG
1418 007120 000000 HLT21: HALT ;PROGRAM HUNG, SP (177706) CONTAINS RETURN
1419 ;ADDRESS OF WAITING LOOP
1420
1421 ;TEST FOR DONE FLAG AND PROGRAM HUNG
1422 007122 012605 DUNECK1: MOV (SP)+,R3 ;TAKE THE RETURN ADDRESS OF THE STACK INCASE
1423 ;THE PROGRAM IS EXPECTING AN INTERRUPT AT DONE
1424 007124 005037 007200 CLR MCNTR1 ;CLEAR THE LOWER HUNG COUNTER
1425 007130 012737 177740 007202 MOV #177740,MCNTR2 ;SET UPPER COUNTER FOR 31 FULL LOOPS
1426 007136 032777 000040 172042 2S: BIT #DUNEMIT,ORXCS ;TEST FOR DONE FLAG
1427 007144 001402 BEQ 1S ;IF NOT SET SKIP RETURN
1428 007146 010346 MOV #3S,-(SP) ;PUT RETURN ADDRESS BACK ON THE STACK
1429 007150 000207 RTS PC ;RETURN
1430 007152 062737 000001 007200 1S: ADD #1,MCNTR1 ;WHEN THE DOUBLE WORD COUNTER OVERFLOWS
1431 007160 005537 007202 ADC MCNTR2 ;THE PROGRAM MUST BE HUNG
1432 007164 005737 007202 TST MCNTR2
1433 007170 001362 BNE 2S ;IF NO OVERFLOW RETEST FOR DONE
1434 007172 104400 015432 TYPE ,MHUNG
1435 007176 000000 HLT20: HALT ;PROGRAM HUNG,CONTENTS OF R3 (177703) HOLDES
1436 ;ADDRESS OF WAITING TEST.
1437
1438 007200 000000 MCNTR1: 0
1439 007202 177740 MCNTR2: 177740
1440
1441 ;AN INTERRUPT DID NOT OCCURE AT A FUNCTION DONE FLAG.
1442
1443 007204 005237 017034 NUNINTER: INC INTER ;INC INTERRUPT ERROR COUNTER
1444 007210 104405 CKSMH
1445 007212 032777 020000 171774 BIT #SW13,#SWR ;TEST DON'T PRINT ERROR SWITCH
1446 007220 001004 BNE 1S
1447 007222 104400 015200 TYPE ,MINTER ;TYPE NO INTERRUPT ON DONE ERROR
1448 007226 104400 015052 TYPE ,MCRLF
1449 007232 104405 1S: CKSMH
1450 007234 005777 171754 TST #SWR ;TEST HALT ON ERROR SWITCH
1451 007240 100001 RPL CONT21
1452 007242 000000 HLT15: HALT ;HALT ON ERROR
1453 007244 004737 007250 CONT21: JSR PC,INTSERV ;JSR TO INTSERV AS IF IT WAS AN INTERRUPT
1454
1455 ;*****
1456
  
```

```

1457                                     INTERRUPT SERVICE
1458
1459 007250 117737 171734 010070 INTSERVI  MOVБ #RХDВ,АСТАТ  ;SAVE THE ERROR AND STATUS WORD
1460 007256 005777 171724                ТST #RХСS          ;TEST THE ERROR FLAG
1461 007262 100450                BMI #RХROR        ;THERE WAS AN ERROR GO REPORT IT
1462 007264 032737 000004 010070        BIT #BIT2,АСТАТ  ;IS INIT DONE SET
1463 007272 001402                HPP              ;NO,CONTINUE
1464 007274 002137 007702                JMP #RXPWR       ;YES,REPORT POWER FAILED AND RESTART
1465 007300 032737 000003 010070 2S1    BIT #3,АСТАТ     ;ARE PAR DR CRC BITS SET.
1466 007306 001023                BNE 1S          ;YES GO LOG ERROR
1467 007310 132777 000040 171670        BITS #DОНЕBIT,#RХСS ;IS DONE SET
1468 007316 001014                BNE 3S          ;IF SET RETURN TO TEST
1469 007320 005237 017052                INC UKNINT      ;INC UNKNOWN INTERRUPT ERROR LOG
1470 007324 104405                HPP              ;NO,CONTINUE
1471 007326 032777 020000 171660        BIT #SW13,#SWR  ;TEST DON'T PRINT ERROR SWITCH
1472 007334 001004                BNE 4S          ;DON'T PRINT
1473 007336 104400 015312                TYPE ,MKNINT   ;TYPE UNKNOWN INTERRUPT
1474 007342 104400 015052                TYPE ,MCRLF    ;TYPE UNKNOWN INTERRUPT
1475 007346 000002                4S1            RTI              ;RETURN FROM THE INTERRUPT
1476 007350 062706 000006 3S1            ADD #6,SP       ;BYPASS INTERRUPT POINTERS ON STACK
1477 007354 000207                RTS PC          ;RETURN TO PROGRAM
1478 007356 005237 017030 1S1            INC NOERLOG    ;NO STATUS ERROR FLAG ERROR
1479 007362 104405                CКСWН          ;NO,CONTINUE
1480 007364 032777 020000 171622        BIT #SW13,#SWR  ;TEST DON'T PRINT ERROR SWITCH
1481 007372 001004                BNE #RХROR     ;TEST DON'T PRINT ERROR SWITCH
1482 007374 104400 016034                TYPE ,MNOFLAG  ;TYPE NO STATUS ERROR ERROR
1483 007400 104400 015052                TYPE ,MCRLF    ;TYPE NO STATUS ERROR ERROR
1484
1485 007404 052737 000000 010704 RХROR:    BIS #BIT0,UNITSEL ;SET HAD ERROR FLAG
1486 007412 012737 000012 017014        MOV #10,#P2RETRY ;SET RETRY COUNTER
1487 007420 012777 000017 171560 2S1    MOV #RDR,#RХСS  ;GET THE ERROR CODE
1488 007426 004737 007122                JSR PC,DONECK   ;TEST FOR DONE FLAG
1489 007432 032777 000002 171550        BIT #2,#RХDВ   ;WAS THERE A PARITY ERROR
1490 007440 001403                BEQ 1S         ;NO,CONTINUE
1491 007442 004737 002046                JSR PC,STATER   ;YES,GO REPORT THE PARITY ERROR
1492 007446 000764                BR 2S         ;ISSUE THE FUNCTION
1493 007450 117737 171534 010072 1S1    MOVБ #RХDВ,ВСТАТ ;SAVE THE ERROR CODE IN B STATUS
1494 007456 005737 010072                ТST #ВСТАТ     ;IS THERE A DEFINITE CODE
1495 007462 001407                BEQ NOPRNT     ;NO,CONTINUE
1496 007464 013705 010072                MOV #ВСТАТ,RS  ;ADJUST ERROR CODE TO PRODUCE AN EVEN ADDR
1497 007470 006005                RDR #5         ;OF THE CORRESPONDING COUNTER
1498 007472 006005                RDR #5         ;OF THE CORRESPONDING COUNTER
1499 007474 062705 017130        ADD #RСODE-2,RS ;ADD ON ADDR OF ERROR LOG -2,AS THERE IS NO 0
1500                                ;ERROR CODE, THE CONTENTS OF R5 WILL READJUST
1501                                ;ADDRESS TO CORRECT LOG.
1502 007500 005215                INC (R5)       ;INC THE CORRECT ERROR CODE COUNTER
1503 007502 104405                CКСWН          ;NO,CONTINUE
1504 007504 032777 020000 171502        BIT #SW13,#SWR  ;TEST PRINT ERROR SWITCH IN SWR
1505 007512 001032                BNE 2S         ;NO,CONTINUE
1506 007514 104400 015052                TYPE ,MCRLF    ;TYPE ERROR HEADER
1507 007520 104400 015063                TYPE ,MРHЕАDЕR ;TYPE PASSES COMPLETED AT ERROR
1508 007524 104400 016142                TYPE ,MPASS    ;TYPE PASSES COMPLETED AT ERROR
1509 007530 013737 021042 007542        MOV #PASCNTН,1S ;TYPE PASSES COMPLETED AT ERROR
1510 007536 004537 014446                JSR #5,SGLDEC  ;TYPE PASSES COMPLETED AT ERROR
1511 007542 000000                OPEN          ;TYPE PASSES COMPLETED AT ERROR
1512 007544 104400 015052                TYPE ,MCRLF    ;TYPE PASSES COMPLETED AT ERROR

```

```

1513 007550 104400 015167                TYPE ,MRХСS    ;TYPE COMMAND STATUS REGISTER
1514 007554 013746 004120                MOV FUNCTION,=(SP) ;SAVE FUNCTION FOR TYPEOUT
1515 007560 104402                TYPDS         ;GO TYPE--OCTAL ASCII
1516 007562 003                ,BYTE 3       ;TYPE 3 DIGIT(S)
1517 007563 000                ,BYTE 0       ;SUPPRESS LEADING ZEROS
1518 007564 004737 007716                JSR PC,TYPADR  ;TYPE ADDRESSES AND RUN CONDITIONS
1519 007570 104400 015052                TYPE ,MCRLF   ;TYPE ADDRESSES AND RUN CONDITIONS
1520 007574 004737 010250                JSR PC,TYPСODE ;PRINT THE STATUS REGISTERS
1521 007600 032737 000020 004120 2S1    BIT #BIT4,FUNCTION ;WHAT DRIVE IS BEING USED
1522 007606 001006                BNE 6S        ;WHAT DRIVE IS BEING USED
1523 007610 012777 000013 171370        MOV #RUBSTAT,#RХСS ;DRIVE 0 BEING USED
1524 007616 004737 007122 5S1            JSR PC,DONECK   ;TEST FOR DONE FLAG
1525 007622 000404                BR 1S        ;TEST FOR DONE FLAG
1526 007624 012777 000033 171354 6S1    MOV #RUISTAT,#RХСS ;DRIVE 1 BEING USED
1527 007632 000771                BR 5S        ;DRIVE 1 BEING USED
1528 007634 032777 000002 171346 7S1    BIT #2,#RХDВ   ;WAS THERE A PARITY ERROR
1529 007642 001403                BEQ 3S       ;NO,CONTINUE
1530 007644 004737 002046                JSR PC,STATER   ;YES,REPORT THE ERROR
1531 007650 000753                BR 2S       ;ISSUE THE COMMAND
1532 007652 105777 171332 3S1            TSTB #RХDВ     ;WAS DRIVE READY SET
1533 007656 100406                BMI 4S       ;YES RETURN
1534 007660 104400 015016                TYPE ,MNODRY  ;TYPE UNIT 0
1535 007664 104400 015052                TYPE ,MCRLF   ;TYPE UNIT 0
1536 007670 004737 010074                JSR PC,DELUNIT ;NO GO DELETE THAT UNIT
1537 007674 062706 000004 4S1            ADD #4,SP     ;MOVE ERROR RETURN TO TOP OF STACK
1538 007700 000207                RTS PC       ;MOVE ERROR RETURN TO TOP OF STACK
1539
1540 007702 104400 016344 RXPWR:    TYPE ,MRХ11    ;ONLY THE RX11 POWER HAS FAILED
1541 007706 104400 014136                TYPE ,SPOWER   ;PRINT POWER FAILED
1542 007712 000137 002700                JMP RESTART    ;GO TO RESTART
1543
1544
1545 007716 104400 014555                TYPE ,MTRK     ;TYPE TRACK ADDRESS
1546 007722 013737 011360 007734        MOV #TARGET,3S ;TYPE TRACK ADDRESS
1547 007730 004537 014446                JSR #5,SGLDEC  ;TYPE TRACK ADDRESS
1548 007734 000000                OPEN          ;TYPE TRACK ADDRESS
1549 007736 104400 014604                TYPE ,MSECT   ;TYPE SECTOR ADDRESS
1550 007742 013737 012310 007762        MOV #SECTOR,2S ;TYPE SECTOR ADDRESS
1551 007750 042737 177400 007762        HIC #177740,2S ;CLEAR ALL BUT SECTOR ADDRESS
1552 007756 004537 014446                JSR #5,SGLDEC  ;CLEAR ALL BUT SECTOR ADDRESS
1553 007762 000000                OPEN          ;CLEAR ALL BUT SECTOR ADDRESS
1554 007764 104400 015047                TYPE ,DBLSP   ;TYPE TEST CODE
1555 007770 032737 000020 010704        BIT #BIT4,UNITSEL ;WHICH DRIVE IS BEING USED
1556 007776 001003                BNE 1S       ;WHICH DRIVE IS BEING USED
1557 010000 104400 015106                TYPE ,MUNIT0  ;TYPE UNIT 0
1558 010004 000402                BR TYPSEL    ;TYPE UNIT 0
1559 010006 104400 015116 1S1            TYPE ,MUNIT1  ;TYPE UNIT 1
1560 010012 104400 015244                TYPE ,MPAT    ;TYPE PATTERN CODE
1561 010016 013746 010420                MOV #PAT,=(SP) ;SAVE PAT FOR TYPEOUT
1562 010022 104402                TYPDS         ;GO TYPE--OCTAL ASCII
1563 010024 001                ,BYTE 1       ;TYPE 1 DIGIT(S)
1564 010026 000                ,BYTE 0       ;SUPPRESS LEADING ZEROS
1565 010028 104400 015047                TYPE ,DBLSP   ;TYPE TEST CODE
1566 010032 104400 015250                TYPE ,MTEST   ;TYPE TEST CODE
1567 010036 013746 002140                MOV #TEST,=(SP) ;SAVE TEST FOR TYPEOUT
1568 010042 104402                TYPDS         ;GO TYPE--OCTAL ASCII

```

```

1569 010044 001 .BYTE 1 ;TYPE 1 DIGIT(S)
1570 010045 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1571 010046 104400 015047 TYPE ,OBLSP
1572 010052 104400 015254 TYPE ,MSEQ ;TYPE SEQUENCE CODE
1573 010056 013746 011370 MOV SEQUEN,-(SP) ;SAVE SEQUEN FOR TYPEOUT
1574 010062 104402 TYPOS ;GO TYPE--OCTAL ASCII
1575 010064 001 .BYTE 1 ;TYPE 1 DIGIT(S)
1576 010065 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1577 010066 000207 RTS PC
1578
1579 010070 000000 ASTAT: 0
1580 010072 000000 BSTAT: 0
1581
1582 010074 132737 000020 004120 DELUNIT: BITB #BIT4,FUNCTION ;TEST FOR PRESENTLY USED UNIT
1583 010102 001016 BNE JS ;
1584 010104 104400 015106 TYPE ,MUNIT0 ;UNIT 0 HAS BEEN DELETED FROM USE
1585 010110 104400 015126 TYPE ,MDELET
1586 010114 104400 015240 TYPE ,OBLLF
1587 010120 042737 000200 010700 MIC #BIT7,UNITSEL ;CLEAR UNIT 0 SELECTION BIT
1588 010126 005737 010704 TST UNITSEL ;WAS UNIT 1 SELECTED FOR USE
1589 010132 100020 RPL 15 ;UNIT 1 NOT SELECTED GO DUMP ERROR REPORT
1590 010134 000137 002726 2S: JMP TESTSEL ;CONTINUE ON OTHER UNIT AT BEGINING OF TEST
1591 010140 104400 015116 3S: TYPE ,MUNIT1 ;UNIT 1 HAS BEEN DELETED FROM USE
1592 010144 104400 015126 TYPE ,MDELET
1593 010150 104400 015240 TYPE ,OBLLF
1594 010154 042737 100000 010704 MIC #BIT15,UNITSEL ;CLEAR UNIT 1 SELECTION BIT
1595 010162 105737 010704 TSTB UNITSEL ;WAS UNIT 0 SELECTED FOR USE
1596 010166 100762 BMI 25 ;YES CONTINUE ON UNIT 0
1597 010170 005137 022514 CUM SHORTRPT ;SET SHORT REPORT FLAG
1598 010174 000137 021062 1S: JMP ERDUMP ;CAN'T CONTINUE TYPE OUT STATISTICAL REPORT
1599
1600
1601 010200 117737 171004 010070 HOCODE: MOVB #MXDH,ASTAT ;SAVE THE A STATUS
1602 010206 012777 000017 170772 2S: MOV #HDER,#RXCS ;READ THE B STATUS REGISTER
1603 010214 004737 007122 JSR PC,DONECK ;WAIT FOR DONE FLAG
1604 010220 032777 000002 170762 BIT #2,#RXDH ;WAS THERE A PARITY ERROR
1605 010226 001403 REQ 15 ;NO,CONTINUE
1606 010230 004737 002046 JSR PC,STATER ;YES,REPORT THE PARITY ERROR
1607 010234 000764 BR 25 ;RETRY READING STATUS B
1608 010236 117737 170746 010072 1S: MOVB #MXDH,BSTAT ;SAVE THE B STATUS CODES
1609 010244 104400 015052 TYPE ,MCLRF
1610 010250 104400 015210 TYPCODE: TYPE ,MASTAT ;TYPE THE CONTENTS OF THE TWO STATUS REGISTERS
1611 010254 013746 010070 MOV ASTAT,-(SP) ;SAVE ASTAT FOR TYPEOUT
1612 010260 104402 TYPOS ;GO TYPE--OCTAL ASCII
1613 010262 003 .BYTE 3 ;TYPE 3 DIGIT(S)
1614 010263 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1615 010264 104400 015040 TYPE ,TAB
1616 010270 104400 015224 TYPE ,M0STAT
1617 010274 013746 010072 MOV HSTAT,-(SP) ;SAVE BSTAT FOR TYPEOUT
1618 010300 104402 TYPOS ;GO TYPE--OCTAL ASCII
1619 010302 003 .BYTE 3 ;TYPE 3 DIGIT(S)
1620 010303 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
1621 010304 104400 015052 TYPE ,MCRLF
1622 010312 000207 RTS PC
1623
1624

```

```

1625 ;*****
1626
1627 ;DECODES THE DATA PATTERN SELECTED IN THE SWR
1628 ;
1629 ;BITS 6,7,AND 8 OF THE INITIAL SWR SELECTED THE DATA PATTERN
1630 ;TO BE USED AS FOLLOWS:
1631 ;
1632 ; BITS DATA PATTERN
1633 ; 0 7 6
1634 ; 0 0 0 NO PATTERN SPECIFIED (FORCE RANDOM DATA)
1635 ; 0 0 1 ALL ZEROS
1636 ; 0 1 0 ALL ONES
1637 ; 0 1 1 FLOATING ZERO
1638 ; 1 0 0 FLOATING ONE
1639 ; 1 0 1 ALTERNATING BITS
1640 ; 1 1 0 ALTERNATING PAIRS OF BITS
1641 ; 1 1 1 RANDOM
1642 ;
1643 ;NOTE: ALL DATA PATTERNS WILL BE MODIFIED SO THE FIRST BYTE WILL
1644 ;CONTAIN THE TRACK ADDRESS, THE SECOND BYTE WILL CONTAIN THE UNIT
1645 ;NUMBER AND SECTOR ADDRESS IN WHICH THE DATA IS WRITTEN, THE LAST
1646 ;TWO BYTES CONTAIN THE CHECK SUM NUMBERS.
1647 ;*****
1648
1649
1650
1651 010312 142737 000377 010360 GETPATTERN: MICB #377,#BRONPAT ;CLEAR BRANCH OFFSET
1652 010320 005037 010612 CLR SUM ;SET UP FOR ACCUMULATION OF CHECK SUM
1653 010324 005737 010420 TST PAT ;IF NO PATTERN SPECIFIED FORCE PATTERN 7
1654 010330 001003 BNE 15 ;
1655 010332 012737 000007 010420 1S: MOV #7,PAT ;GET PATTERN BITS
1656 010340 013704 010420 UEC #4 ;ADJUST FOR CORRECT OFFSET
1657 010344 005304 ASL #4 ;
1658 010346 006304 MOV #BUFADR+2,R4 ;INSERT OFFSET
1659 010350 150437 010360 ;SET UP ADDRESS OF FIRST BYTE
1660 010354 012704 016606 BR . ;BRANCH BY OFFSET SELECTED
1661 010360 000777 BR . ;
1662 010362 000137 010422 JMP DATA0 ;000 DATA BYTE
1663 010366 000137 010434 JMP DATA1 ;377 DATA BYTE
1664 010372 000137 010444 JMP FLOAT0 ;FLOAT A 0 THROUGH ALL 1'S
1665 010376 000137 010506 JMP FLOAT1 ;FLOAT A 1 THROUGH ALL 0'S
1666 010402 000137 010514 JMP PAT125 ;125/052 DATA WORD
1667 010406 000137 010534 JMP PAT314 ;314/063 DATA WORD
1668 010412 000137 010544 JMP RANDATA ;RANDOM DATA BYTE
1669
1670
1671 010416 000000 DATABYTE: 0
1672 010420 000000 PAT: 0
1673
1674
1675 ;*****
1676
1677 ;LOAD SOFTWARE BUFFER WITH ALL ZEROS
1678 ; P = 1
1679
1680 010422 005037 010416 DATA0: CLR DATABYTE

```



```

1681 010426 004737 010564 PATGEN: JSR PC,LOAD ;GO LOAD THE DATA BUFFER
1682 010432 000775 BR PATGEN
1683
1684 ;*****
1685 ;LOAD SOFTWARE BUFFER WITH ALL ONES
1686 ; P = 2
1687
1688
1689
1690 010434 112737 000377 010416 DATA1: MOVW #377,DATABYTE
1691 010442 000771 BR PATGEN
1692
1693 ;*****
1694 ;FLOAT A 0 THROUGH ONES IN SOFTWARE BUFFER
1695 ; P = 3
1696
1697
1698
1699 010444 112737 000376 010416 FLOAT0: MOVW #376,DATABYTE ;SET UP A ONES FIELD
1700 010452 000261 XPATGEN: SEC ;SET THE C BIT TO ROTATE THROUGH THE DATA
1701 010454 012702 000000 1S: MOV #0,R2 ;CLR R2 (CAN'T USE "CLR" AS IT CLEARS "C" BIT)
1702 010460 103001 BCC ZS ;BR IF THE "C" BIT IS CLEARED
1703 010462 005202 INC R2 ;SET R2 IF NOT
1704 010464 004737 010564 2S: JSR PC,LOAD ;GO LOAD THE DATA BUFFER
1705 010470 000241 CLC
1706 010472 005702 TST R2 ;IS R2 NONZERO
1707 010474 001401 BEQ 3S
1708 010476 000261 SEC ;YES, SET THE "C" BIT
1709 010500 106137 010416 3S: ROLW DATABYTE
1710 010504 000763 BR 1S
1711
1712 ;*****
1713 ;FLOAT A 1 THROUGH ALL ZEROS IN SOFTWARE BUFFER
1714 ; P = 4
1715
1716
1717 010506 005037 010416 FLOAT1: CLR DATABYTE
1718 010512 000757 BR XPATGEN
1719
1720 ;*****
1721 ;LOAD SOFTWARE BUFFER WITH ALTERNATING 1 AND 0 FOR
1722 ;ONE BYTE AND THE COMPLIMENT INTO THE NEXT
1723 ; P = 5
1724
1725
1726 010514 112737 000125 010416 PAT125: MOVW #125,DATABYTE
1727 010522 004737 010564 XXPATGEN: JSR PC,LOAD
1728 010526 105137 010416 CUMB DATABYTE ; * (SEE NOTE BELOW)
1729 010532 000773 BR XXPATGEN
1730
1731 ; * NOTE: TO MAKE PATTERN 5 AND 6 COMPATABLE WITH THE RX8 PATTERNS
1732 ;NDP THIS INSTRUCTION. (CHANGE THESE 2 LOCATIONS TO #00240)
1733 ;THIS CHANGE IS FOR INTERPROCESSOR RX** COMPATABILITY TESTING ONLY.
1734
1735 ;*****
1736
  
```

```

1737 ;LOAD SOFTWARE BUFFER WITH ALTERNATING PAIRS OF 1 AND 0 AND
1738 ;COMPLIMENT INTO THE NEXT
1739 ; P = 6
1740
1741 010534 112737 000314 010416 PAT314: MOVW #314,DATABYTE
1742 010542 000767 BR XXPATGEN
1743
1744 ;*****
1745 ;LOAD SOFTWARE BUFFER WITH RANDOM DATA PATTERN
1746 ; P = 0 OR 7
1747
1748
1749 010544 004737 012122 RANDATA: JSR PC,RANGEN ;GET RANDOM NUMBER
1750 010550 113724 012214 010416 MOVW RANUM,DATABYTE
1751 010556 004737 010564 JSR PC,LOAD
1752 010562 000770 BR RANDATA
1753
1754 010564 063737 010416 010612 LOAD: ADD DATABYTE,SUM ;ACCUMULATE THE PATTERN CHECK SUM
1755 010572 113724 010416 MOVW DATABYTE,(R4)+ ;LOAD THE DATA BUFFER
1756 010576 022704 017002 CMP #0FA0R+176,R4 ;HAVE 124 BYTES BEEN GENERATED
1757 010602 001401 BEQ 1S ;IF YES, RETURN TO TEST
1758 010604 000207 RTS PC ;IF NO, RETURN TO PATTERN GENERATOR
1759 010606 005726 1S: TST (SP)+ ;TAKE PATTERN RETURN ADDRESS OF STACK
1760 010610 000207 RTS PC ;RETURN TO TEST
1761
1762 010612 000000 SUM: 0
1763
1764 ;*****
1765 ;TEST FOR SELECTED UNITS, DRIVE READY, AND USED CONDITIONS
1766 ;ALSO CONTAINS A "MAD ERROR" FLAG TO BE TESTED AT EOP.
1767 ;THE BITS IN UNITSEL ARE USED AS FOLLOWS
1768 ;
1769 ;
1770 ;BIT15 =UNIT 1 SELECTED VIA SWR
1771 ;BIT14 =UNIT 1 USED BIT
1772 ;BIT8 =THIS PASS HAD AN ERROR
1773 ;BIT7 =UNIT 0 SELECTED VIA SWR
1774 ;BIT6 =UNIT 0 USED BIT
1775 ;BIT4 =UNIT SELECTION FOR FUNCTION WORD
1776
1777 ;*****
1778
1779 010614 032737 000100 010704 GETUNIT: BIT #BIT6,UNITSEL ;WAS UNIT 0 JUST USED
1780 010622 001012 BNE 1S ;UNIT 0 USED CHECK UNIT 1
1781 010624 103737 010704 TSTW UNITSEL ;WAS UNIT 0 SELECTED
1782 010630 100007 BPL 1S ;NO GO TO UNIT 1
1783 010632 042737 040020 010704 BIC #40020,UNITSEL ;CLEAR UNIT 1 USED BIT AND FUNCTION UNIT BIT
1784 010640 052737 000100 010704 BIS #BIT6,UNITSEL ;SET UNIT 0 USED BIT
1785 010646 000207 RTS PC
1786 010650 005737 010704 1S: TST UNITSEL ;WAS UNIT 1 SELECTED
1787 010654 100012 BPL 2S ;NO RETURN
1788 010656 032737 040000 010704 BIT #BIT14,UNITSEL ;WAS UNIT 1 BEEN USED
1789 010664 001006 BNE 2S ;YES RETURN
1790 010666 042737 000100 010704 BIC #BIT6,UNITSEL ;CLEAR UNIT 0 USED BIT
1791 010674 052737 040020 010704 BIS #40020,UNITSEL ;SET UNIT 1 USED BIT AND FUNCTION UNIT BIT
1792 010702 000207 RTS PC
  
```

```

1793
1794
1795
1796 010704 000000 UNITSEL: 0
1797
1798 ;TEST THAT ALL UNITS HAVE BEEN ACCESSED
1799
1800 010706 005737 010704 UONE: TST UNITSEL ;IS UNIT 1 SELECTED
1801 010712 100000 BPL 1$ ;NO RETURN
1802 010714 032737 000000 010704 BIT #BIT14,UNITSEL ;YES HAS IT BEEN USED
1803 010722 001002 HNE 1$ ;YES RETURN
1804 010724 062706 000002 ADD #2,SP ;BYPASS NOT DONE RETURN ON STACK
1805 010730 000207 1$: RTS PC
1806
1807
1808 010732 004737 010706 STOP: JSR PC,UONE ;HAVE ALL DRIVES BEEN USED
1809 010736 005737 007200 CLR HCNTN1
1810 010742 005237 021042 INC PASCNTR ;KEEP TOTAL NUMBER OF PASSES
1811 010746 005737 011142 TST CHARCT ;HAVE 72 EOP INDICATORS BEEN TYPED
1812 010752 001005 HNE 3$
1813 010754 104400 015052 TYPE ,MCRLF ;YES DO A CRLF
1814 010760 012737 177670 011142 MOV #-/2.,CHARCT ;RESET CHARACTER COUNTER
1815 010766 005237 011142 3$: INC CHARCT
1816 010772 032737 000400 010704 BIT #BIT8,UNITSEL ;TEST HAD ERROR FLAG
1817 011000 001403 BEQ 2$ ;NO ERROR PRINT D
1818 011002 104400 015057 TYPE ,MEREUP ;HAD ERROR PRINT ?
1819 011006 000404 BR 1$
1820 011010 104400 015055 2$: TYPE ,MEOP ;PRINT EOP INDICATOR
1821 011014 104400 015061 TYPE ,MAHELL
1822 011020 104405 1$: CKSWH
1823 011022 032777 040000 170164 HIT #SW14,#SWR ;TEST EOP HALT SWITCH
1824 011030 001417 BEQ CONT22
1825 011032 104400 015052 TYPE ,MCRLF
1826 011036 104400 016142 TYPE ,MPASS ;AT HALT UN PASS PRINT NUMBER OF PASSES COMPLETE
1827 011042 013737 021042 011054 MOV PASCNTR,65
1828 011050 004537 014446 JSR #5,SGLDEC
1829 011054 000000 6$: UPEN
1830 011056 104400 015052 TYPE ,MCRLF
1831 011062 000000 HLT16: HALT
1832 011064 005037 011142 CLR CHARCT ;THIS CAUSES A CRLF AFTER HALT AT E.O.P.
1833 011070 042737 040500 010704 CONT22: RIC #40500,UNITSEL ;CLEAR USED BITS, AND "HAD ERROR" BIT
1834 011076 022737 000007 010420 CMP #7,PAT ;IF RANDOM DATA GET NEW DATA FOR BUFFER
1835 011104 001002 BNE 2$
1836 011106 004737 010312 JSR PC,GETPATTERN
1837 011112 005237 007200 2$: INC HCNTN1 ;WAIT FOR THE EOP INDICATOR TO BE PRINTED
1838 011116 001375 BNE 2$
1839 011120 013725 000042 MOV #42,#5 ;ACT11 END OF PASS HOOKS
1840 011124 001405 BEQ HERE
1841 011126 000005 MASET
1842 011130 004715 LOGICAL: JSR PC,(R5)
1843 011132 000240 NOP
1844 011134 000240 NOP
1845 011136 000240 NOP
1846 011140 000207 HERE: RTS PC
1847
1848 011142 000000 CHARCT: 0

```

```

1849
1850 ;*****
1851
1852 ;INITIALIZE TRACK SEQUENCE
1853
1854
1855 011144 042737 100200 001200 INITTRACK: BIC #100200,0D ;CLEAR FIRST USED BITS
1856 011152 005737 001200 TST 0D ;TEST CONTENTS OF ID,OD FOR 0
1857 011156 001005 BNE 1$ ;ID,OD SPECIFIED USE THEM
1858 011160 112737 000114 001201 MOV# #114,ID ;NONE SPECIFIED SET ID TO MAXIMUM
1859 011166 105037 001200 CLRB 0D ;SET 0D TO MINIMUM
1860 011172 113737 001200 1$: MOV# 0D,TARGET ;INIT 0D AS PRESENT TRACK
1861 011200 005037 011366 CLR X1D ;INIT WORKING ID AND 0D LOCATIONS
1862 011204 113737 001201 011366 MOV# 0D,X1D
1863 011212 005037 011364 CLR X0D
1864 011216 113737 001200 011364 MOV# 0D,X0D
1865 011224 013737 011366 011356 MOV X1D,TRKCNTR ;SET UP NUMBER OF TRACK MOVEMENTS
1866 011232 163737 011364 011356 SUB X0D,TRKCNTR
1867 011240 005237 011356 INC TRKCNTR
1868 011244 052737 100200 001200 BIS #100200,0D ;SET FIRST TIME BITS IN ID,OD
1869 011252 000207 RTS PC
1870
1871
1872 ;*****
1873
1874 ;TEST FOR HEAD SEQUENCE SELECTED BY INITIAL SWR SETTING
1875 ;
1876 ;BITS 0,1,AND 2 OF THE INITIAL SWR SELECTED THE TRACK SEQUENCING
1877 ;TO BE FOLLOWED AS INITIATED BELOW
1878 ;
1879 ;
1880 ; BITS SEQUENCE
1881 ; 0 0 0 NO SEQUENCE SPECIFIED (DEFAULT TO SEQ 7)
1882 ; 0 0 1 INCREMENT FROM 0D TO ID
1883 ; 0 1 0 DECREMENT FROM ID TO 0D
1884 ; 0 1 1 DU PREVIOUS 2 SEQUENCES
1885 ; 1 0 0 BOUNCE BETWEEN ID AND 0D
1886 ; 1 0 1 DECREASING BOUNCE
1887 ; 1 1 0 STROBE BETWEEN 0D AND DECREMENTING ID
1888 ; 1 1 1 RANDOM TRACK SELECTION
1889
1890 ;*****
1891
1892 011254 113737 011360 011362 GETTRACK: MOV# TARGET,PRESTRK ;RESET TO PRESENT TRACK
1893 011262 142737 000377 011320 BIC# #377,#BRONTRK ;CLEAR OUT BRANCH OFFSET
1894 011270 005737 011370 TST SEQUEN ;IF NO SEQUENCE SPECIFIED FORCE SEQUENCE 7
1895 011274 001003 BNE 1$
1896 011276 012737 000007 011370 MOV #7,SEQUEN ;GET SEQUENCE BITS
1897 011304 013704 011370 1$: MOV SEQUEN,R4 ;ADJUST FOR CORRECT OFFSET
1898 011310 005304 DEC #4
1899 011312 006304 ASL #4
1900 011314 150437 011320 BIS #4,#BRONTRK ;THIS BR INST. IS MODIFIED BY THE TEST CONDITIONS
1901 ;SELECTED ,TO BRANCH TO ONE OF THE SEQ. BELOW
1902
1903 011320 000777 BRONTRK: BR ;BRANCH BY OFFSET SELECTED
1904 011322 000137 JMP SEQ1 ;INCREMENT

```

```

1905 011326 000137 011426 JMP SEQ2 ;DECREMENT
1906 011332 000137 011460 JMP SEQ3 ;INCREMENT/DECREMENT
1907 011336 000137 011524 JMP SEQ4 ;BOUNCE ID TO OD
1908 011342 000137 011610 JMP SEQ5 ;DECREASING BOUNCE
1909 011346 000137 011742 JMP SEQ6 ;STROBE
1910 011352 000137 012022 JMP SEQ7 ;RANDOM
1911
1912 011356 000000 TRKCNTR: 0
1913 011360 000000 TARGET: 0
1914 011362 000000 PRESTRK: 0
1915 011364 000000 X00: 0
1916 011366 000000 X10: 0
1917 011370 000000 SEQUEN: 0
1918
1919 ;*****
1920 ;INCREMENT FROM OD+1 TO ID AND RETURN TO OD
1921 ; S = 1
1922
1923
1924 011372 042737 100200 001200 SEQ1: BIC #100200,OD ;CLEAR FIRST TIME BITS
1925 011400 123737 011366 011362 CMPB X10,PRESTRK ;PRESENT TRACK EQUAL TO ID
1926 011406 001004 BNE IS ;NO GET NEW TRACK
1927 011410 113737 001200 011360 MOVB OD,TARGET ;YES RETURN TO OD
1928 011416 000461 BR NEWTRK ;NEWTRK INCREMENTS THE TRACK MOVED TO COUNTER
1929
1930 011420 005237 011360 IS: INC TARGET ;AND RETURNS TO NEXT TRACK
1931 011424 002456 BR NEWTRK ;ADD 1 TO TARGET TRACK
1932
1933 ;*****
1934 ;DECREMENT FROM ID TO OD
1935 ; S = 2
1936
1937
1938 011426 105737 001201 SEQ2: TSTB ID ;FIRST TIME BIT SET
1939 011432 100007 BPL IS ;NO GET NEXT TRACK
1940 011434 042737 100200 001200 BIC #100200,OD ;YES CLEAR FIRST TIME BITS
1941 011442 113737 011366 011360 MOVB X10,TARGET ;GO TO ID
1942 011450 000444 BR NEWTRK
1943 011452 005337 011360 IS: DEC TARGET ;MOVE TO NEXT TRACK
1944 011456 000441 BR NEWTRK
1945
1946 ;*****
1947 ;INCREMENT THEN DECREMENT TRACKS
1948 ; S = 3
1949
1950
1951 011460 105737 001200 SEQ3: TSTB OD ;CHECK FIRST TIME BIT
1952 011464 100007 BPL IS ;NOT FIRST TIME THROUGH
1953 011466 042737 100200 001200 BIC #100200,OD ;CLEAR FIRST TIME BITS
1954 011474 005337 011356 DEC TRKCNTR
1955 011500 006337 011356 ASL TRKCNTR ;RESET TRACK COUNTER TO DOUBLE THE COUNT
1956 011504 013700 011366 IS: MOV X10,R0
1957 011510 163700 011564 SUB X00,R0 ;GET DIFFERENCE BETWEEN ID AND OD
1958 011514 163700 011356 SUB TRKCNTR,R0 ;IS TRACK COUNTER HALF DONE
1959 011520 002342 HGF SEQ2 ;YES GO DECREMENT TRACKS
1960 011522 002723 BR SEQ1 ;NO CONTINUE INCREMENTING TRACKS

```

```

1961
1962 ;*****
1963 ;BOUNCE BETWEEN ID AND OD ONLY
1964 ; S = 4
1965
1966
1967
1968 011524 042737 100200 001200 SEQ4: BIC #100200,OD ;CLEAR THE FIRST TIME BITS
1969 011532 123737 011362 001200 CMPB PRESTRK,OD ;ID IT JUST DO OD
1970 011540 001404 BEQ IDNEXT ;YES
1971 011542 113737 001200 011360 MOVB OD,TARGET ;NO GO TO OD TRACK
1972 011550 000404 BR NEWTRK
1973 011552 113737 001201 011360 IDNEXT: MOVB ID,TARGET ;GO DO ID TRACK
1974 011560 000400 BR NEWTRK
1975
1976 ;*****
1977 ;INCREMENT THE "HEAD MOVED TO" COUNTERS AND RETURN
1978 ;THROUGH HERE FROM ALL TRACK SEQUENCES
1979
1980
1981 011562 013705 011360 NEWTRK: MOV TARGET,R5 ;GET TRACK ADDRESS
1982 011566 006305 ASL R5 ;MULTIPLY BY 4 TO DOUBLE PRECISION
1983 011570 006305 ASL R5 ;INTERLEAVE COUNTER ADDRESSES
1984 011572 062705 017660 ADD #HMOVE,R5 ;ADD ON ADDRESS OF HEAD MOVE COUNTER
1985 011576 062715 000001 ADD #1,(R5) ;INC COUNTER
1986 011602 005565 000002 ADC 2(R5) ;ADD CARRY TO HIGH ORDER WORD
1987 011606 000207 RTS PC ;RETURN TO ACCESS NEXT TRACK
1988
1989 ;*****
1990 ;BOUNCE BETWEEN DECREASING ID AND INCREASING OD
1991 ; S = 5
1992
1993
1994
1995 011610 105737 001201 SEQ5: TSTB ID ;TEST FIRST TIME BIT OF ID
1996 011614 100011 BPL IS
1997 011616 005237 011356 INC TRKCNTR ;ADJUST FOR ONE EXTRA MOVEMENT TO TRK 00
1998 011622 142737 000200 001201 BICB #200,ID ;CLEAR FIRST TIME BIT OF ID
1999 011630 113737 011366 011360 MOVB X10,TARGET ;MOVE TO ID
2000 011636 000751 BR NEWTRK
2001 011640 105737 001200 IS: TSTB OD ;TEST FIRST TIME BIT OF OD
2002 011644 100007 BPL 2S
2003 011646 142737 000200 001200 BICB #200,OD ;CLEAR FIRST TIME BIT OF OD
2004 011654 113737 011364 011360 MOVB X00,TARGET ;MOVE TO OD
2005 011662 000737 BR NEWTRK
2006 011664 132737 000001 011356 2S: BITB #1,TRKCNTR ;TEST COUNTER FOR ODD OR EVEN
2007 011672 001006 BNE 3S ;ODD MOVE TO NEW ID
2008 011674 005237 011364 INC X00 ;EVEN ADD 1 TO OD
2009 011700 113737 011364 011360 MOVB X00,TARGET
2010 011706 000405 BR LASTTRK ;SEE IF LAST TRACK IS BEING ACCESSED
2011 011710 005337 011366 3S: DEC X10 ;SUBTRACT 1 FROM ID
2012 011714 113737 011366 011360 MOVB X10,TARGET
2013 011722 123727 011356 000001 LASTTRK: CMPB TRKCNTR,#1
2014 011730 001003 BNE XRETURN
2015 011732 113737 001200 011360 MOVB OD,TARGET ;THIS IS LAST TRACK RETURN TO OD
2016 011740 000710 BR NEWTRK

```

```

2017
2018
2019
2020
2021
2022
2023 011742 105737 001200 SEQ6: TSTB OD ;CHECK FIRST TIME BIT
2024 011746 100007 MPL 15 ;NOT FIRST TIME
2025 011750 042737 100200 001200 BIC #100200,OD ;WAS FIRST TIME,CLEAR THE BITS
2026 011756 005337 011356 UEC TRKCNTR ;RESET COUNTER TO DOUBLE THE NUMBER OF TRACKS
2027 011762 006337 011356 ASL TRKCNTR
2028 011766 123737 011362 001200 15: CMPB PRESTRK,OD ;WAS OD JUST ACCESSED
2029 011774 001006 BNE ODNEXT ;NO GO TO OD
2030 011776 113737 011366 011366 MOVH XID,TARGET ;DECREASING ID IS NEXT TRACK
2031 012004 005337 011366 DEC XID
2032 012010 000664 BR NEWTRK
2033 012012 113737 001200 011366 ODNEXT: MOVH OD,TARGET ;OD IS NEXT TRACK
2034 012020 000664 BR NEWTRK
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044 012022 042737 100200 001200 SEQ7: BIC #100200,OD ;CLEAR THE FIRST TIME BITS
2045 012030 004737 012122 JSR PC,RANGEN ;GET A RANDOM NUMBER
2046 012034 042737 177600 012214 BIC #177600,RANUM ;CLEAR ALL BUT LOW 7 BITS
2047 012042 123737 012214 011366 IOCOMP: CMPB RANUM,XID ;IS RANUM LARGER THAN ID ADDRESS
2048 012050 003404 BLE UDCOMP ;NO,RANUM IS LESS OR EQUAL TO ID
2049 012052 163737 011366 012214 SUB XID,RANUM ;YES,SUBTRACT ID FROM IT
2050 012060 000776 BR IOCOMP ;SEE IF RANUM IS NOW OK
2051 012062 123737 012214 011364 UDCOMP: CMPB RANUM,XOD ;IS RANUM SMALLER THAN OD ADDRESS
2052 012070 002004 HGE PRESCHK ;NO,RANUM IS GREATER OR EQUAL TO OD
2053 012072 063737 011364 012214 ADD XOD,RANUM ;YES,ADD OD TO RANUM
2054 012100 000776 BR UDCOMP ;SEE IF RANUM IS NOW OK
2055 012102 123737 012214 011362 PRESCHK: CMPB RANUM,PRESCHK ;IF RANUM EQUALS PRESENT TRACK
2056 012110 001744 MEQ SEQ7 ;GET ANOTHER RANDOM NUMBER
2057 012112 013737 012214 011360 MOVH RANUM,TARGET ;RANUM OK PUT IT IN TARGET TRACK
2058 012120 000664 BR NEWTRK
2059
2060 012122 012700 000001 RANGEN: MOV #1,R0
2061 012126 063700 012210 ADD RAN1,R0
2062 012132 063700 012212 ADD RAN2,R0
2063 012136 042700 170000 BIC #170000,R0
2064 012142 000241 CLC
2065 012144 000100 ROL R0
2066 012146 000100 ROL R0
2067 012150 012037 012210 MOV R0,RAN1
2068 012154 005000 CLR R0
2069 012156 013700 012212 MOV RAN2,R0
2070 012162 000000 HLR R0
2071 012164 000000 RDR R0
2072 012166 063700 012210 ADD RAN1,R0

```

```

2073 012172 042700 170000 BIC #170000,R0
2074 012176 010037 012212 MOV R0,RAN2
2075 012202 010037 012214 MOV R0,RANUM
2076 012206 000207 RTS PC
2077
2078 012210 000000 RAN1: 0
2079 012212 000000 RAN2: 0
2080 012214 000000 RANUM: 0
2081
2082
2083
2084
2085
2086 012216 005737 001202 INITSECTOR: TST FIRST ;TEST FIRST AND LAST FOR 0
2087 012222 001095 BNE 15 ;SECTORS SPECIFIED USE THEM
2088 012224 005237 001202 INC FIRST ;NONE SPECIFIED SET FIRST TO 1
2089 012230 000032 001203 MOVB #52,LAST ;SET LAST TO MAXIMUM
2090 012236 113737 001203 012306 15: MOVB LAST,SECCNTR ;SET UP SECTOR COUNTER
2091 012244 163737 001202 012306 SUB FIRST,SECCNTR
2092 012252 005237 012306 INC SECCNTR
2093 012256 105037 012307 CLRB SECCNTR+1
2094 012262 113737 001202 012310 MOVB FIRST,TSECTOR ;PUT FIRST SECTOR IN TARGET SECTOR
2095 012270 163737 012314 012310 SUB THREE,TSECTOR ;SUB 3 FROM TSECTOR AS FIRST TIME THROUGH
2096 ;IT GETS ADDED BACK ON.
2097 012276 012737 000001 012312 MOV #1,INTLEAV ;SET INTERLEAVE OFFSET
2098 012304 000207 RTS PC
2099
2100 012306 000000 SECCNTR: 0
2101 012310 000000 TSECTOR: 0
2102 012312 000000 INTLEAV: 0
2103 012314 000003 THREE: 3
2104
2105 012316 063737 012314 012310 GETSECTOR: ADD THREE,TSECTOR ;ADD 3 FOR INTERLEAVING
2106 012324 123737 001203 012310 CMPB LAST,TSECTOR
2107 012332 000210 BGE 15 ;NEW SECTOR IS WITHIN LIMITS
2108 012334 113737 001202 012310 MOVB FIRST,SECTOR ;RESET TARGET SECTOR TO INTERLEAVE
2109 012342 063737 012312 012310 ADD INTLEAV,TSECTOR ;ADD ON INTERLEAVE OFFSET VALUE
2110 012350 005237 012312 INC INTLEAV ;UP DATE THE OFFSET VALUE
2111 012354 000207 15: RTS PC
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
;SBTTL TYPE ROUTINE
;*****
;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;
;CALL1
;1) USING A TMAP INSTRUCTION
;* TYPE ,MESADR ;MESADR IS FIRST ADDRESS OF AN ASCII STRING
;*OR
;* TYPE
;* MESADR

```

```

2129
2130
2131 012356 105737 012605 STYPE: TSTB STPFLG ;;IS THERE A TERMINAL?
2132 012362 100002 BPL 15 ;;BR IF YES
2133 012364 000000 HALT ;;HALT HERE IF NO TERMINAL
2134 012366 000407 BR ;;LEAVE
2135 012370 010046 15: MOV R0,=(SP) ;;SAVE R0
2136 012372 017600 000002 MOV R2(SP),R0 ;;GET ADDRESS OF ASCII STING
2137 012376 112046 25: MOVH (R0)+,=(SP) ;;PUSH CHARACTER TO BE TYPED ONTO STACK
2138 012400 001005 BNE 45 ;;BR IF IT ISN'T THE TERMINATOR
2139 012402 005726 TST (SP)+ ;;IF TERMINATOR POP IT OFF THE STACK
2140 012404 012600 60S: MOV (SP)+,R0 ;;RESTORE R0
2141 012406 062716 35: ADD #2,(SP) ;;ADJUST RETURN PC
2142 012412 000002 RTI ;;RETURN
2143 012414 122716 45: CMPB #HT,(SP) ;;BRANCH IF <HT>
2144 012420 001430 BEO 55
2145 012422 122716 000200 CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
2146 012426 001005 BNE 55
2147 012430 005726 TST (SP)+ ;;POP <CR><LF> EQUIV
2148 012432 104400 TYPE ;;TYPE A CR AND LF
2149 012434 012607 SCRLF CLRB ;;CLEAR CHARACTER COUNT
2150 012436 105037 012572 BR 25 ;;GET NEXT CHARACTER
2151 012442 000755 JSR PC,STYPEC ;;GO TYPE THIS CHARACTER
2152 012444 004737 012526 55: CMPB #FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
2153 012450 123726 012604 BNE 25 ;;IF NO GO GET NEXT CHAR.
2154 012454 001350 MOV #NULL,=(SP) ;;GET # OF FILLER CHARS. NEEDED
2155 012456 013746 ;;AND THE NULL CHAR.
2156
2157 012462 105366 000001 75: DECB 1(SP) ;;DOES A NULL NEED TO BE TYPED?
2158 012466 002770 BLT 65 ;;BR IF NO--GO POP THE NULL OFF OF STACK
2159 012470 004737 012526 JSR PC,STYPEC ;;GO TYPE A NULL
2160 012474 105337 012572 DECB #CHARCNT ;;DO NOT COUNT AS A COUNT
2161 012500 000770 BR 75 ;;LOOP
2162
2163 ;HORIZONTAL TAB PROCESSOR
2164
2165 012502 112716 000400 85: MOVH # ,(SP) ;;REPLACE TAB WITH SPACE
2166 012506 004737 012526 95: JSR PC,STYPEC ;;TYPE A SPACE
2167 012512 132737 000007 012572 RITH #7,#CHARCNT ;;BRANCH IF NOT AT
2168 012520 001372 BNE 95 ;;TAB STOP
2169 012522 005726 TST (SP)+ ;;POP SPACE OFF STACK
2170 012524 000724 BR 25 ;;GET NEXT CHARACTER
2171 012526 105777 000244 STYPEC: TSTB #STPB ;;WAIT UNTIL PRINTER IS READY
2172 012532 100375 BPL STYPEC
2173 012534 116677 000002 000036 MOVH 2(SP),#STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
2174 012542 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
2175 012550 001003 BNE 15 ;;BRANCH IF NO
2176 012552 105037 012572 CLRB #CHARCNT ;;YES--CLEAR CHARACTER COUNT
2177 012556 000406 BR #TYPEX ;;EXIT
2178 012560 122766 000012 000002 15: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
2179 012564 001402 BEO #TYPEX ;;BRANCH IF YES
2180 012570 105227 INCB (PC)+ ;;COUNT THE CHARACTER
2181 012572 000000 #CHARCNT:=WORD 0 ;;CHARACTER COUNT STORAGE
2182 012574 000207 STYPEX: RTS PC
2183
2184 012576 177564 STPB: .WORD 177564 ;;TTY PRINTER STATUS REG. ADDRESS

```

```

2185 012600 177564 STPB: .WORD 177564 ;;TTY PRINTER BUFFER REG. ADDRESS
2186 012602 000 #NULL:=.BYTE 0 ;;CONTAINS NULL CHARACTER FOR FILLS
2187 012603 002 #FILLC:=.BYTE 2 ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
2188 012604 012 #FILLC:=.BYTE 12 ;;INSERT FILL CHARS. AFTER A "LINE FEED"
2189 012605 000 STPFLG:=.BYTE 0 ;;"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
2190 012606 077 #QUES:=.ASCII "? " ;;QUESTION MARK
2191 012607 015 #CRLF:=.ASCII "<15>" ;;CARRIAGE RETURN
2192 012610 000012 #LF:=.ASCIIZ "<12>" ;;LINEFEED
2193
2194 .SBTTL BINARY TO OCTAL (ASCII) AND TYPE
2195
2196 ;*****
2197 ;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
2198 ;OCTAL (ASCII) NUMBER AND TYPE IT.
2199 ;*STYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
2200 ;*CALL:
2201 ;* MOV NUM,=(SP) ;;NUMBER TO BE TYPED
2202 ;* TYPOS ;;CALL FOR TYPEOUT
2203 ;* .BYTE N ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
2204 ;* .BYTE M ;;M=1 OR 0
2205 ;* ;;1=TYPE LEADING ZEROS
2206 ;* ;;0=SUPPRESS LEADING ZEROS
2207 ;*
2208 ;*STYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
2209 ;*STYPOS OR STYPOC
2210 ;*CALL:
2211 ;* MOV NUM,=(SP) ;;NUMBER TO BE TYPED
2212 ;* TYPON ;;CALL FOR TYPEOUT
2213 ;*
2214 ;*STYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
2215 ;*CALL:
2216 ;* MOV NUM,=(SP) ;;NUMBER TO BE TYPED
2217 ;* TYPOC ;;CALL FOR TYPEOUT
2218
2218 012612 017646 000000 STYPOS: MOV #,(SP),=(SP) ;;PICKUP THE MODE
2219 012616 116637 000001 013035 MOVH 1(SP),#0FILL ;;LOAD ZERO FILL SWITCH
2220 012624 112637 013037 MOVH (SP)+,#MODE+1 ;;NUMBER OF DIGITS TO TYPE
2221 012630 062716 000002 ADD #2,(SP) ;;ADJUST RETURN ADDRESS
2222 012634 000406 BR STYPON
2223 012636 112737 000001 013035 STYPOC: MOVH #1,#0FILL ;;SET THE ZERO FILL SWITCH
2224 012644 112737 000006 013037 MOVH #6,#MODE+1 ;;SET FOR SIX(6) DIGITS
2225 012652 112737 000005 013034 STYPON: MOVH #5,#CNT ;;SET THE ITERATION COUNT
2226 012660 010346 MOV R3,=(SP) ;;SAVE R3
2227 012662 010446 MOV R4,=(SP) ;;SAVE R4
2228 012664 010546 MOV R5,=(SP) ;;SAVE R5
2229 012666 113704 013037 MOVH #MODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
2230 012672 005404 NEG R4
2231 012674 062704 000006 ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
2232 012700 110437 013036 MOVH R4,#MODE ;;SAVE IT FOR USE
2233 012704 113704 013035 MOVH #0FILL,R4 ;;GET THE ZERO FILL SWITCH
2234 012710 016605 000012 MOV 12(SP),R5 ;;PICKUP THE INPUT NUMBER
2235 012714 005003 CLR R3 ;;CLEAR THE OUTPUT WORD
2236 012716 006105 15: ROL R5 ;;ROTATE MSB INTO "C"
2237 012720 000404 BR 35 ;;GO DO MSB
2238 012722 006105 25: ROL R5 ;;FORM THIS DIGIT
2239 012724 006105 ROL R5
2240 012726 006105 ROL R5

```

```

2241 012730 010503      MOV      R5,R3
2242 012732 006103      3S:    ROL      R3          ;;GET LSB OF THIS DIGIT
2243 012734 105337 015036  DECB     $DMODE          ;;TYPE THIS DIGIT?
2244 012740 100016      BPL      7$            ;;BR IF NO
2245 012742 042703 177770  BIC      #177770,R3     ;;GET RID OF JUNK
2246 012746 001002      BNE      4$            ;;TEST FOR 0
2247 012750 005704      TST      R4            ;;SUPPRESS THIS 0?
2248 012752 001403      BEQ      5$            ;;BR IF YES
2249 012754 005204      4S:    INC      R4            ;;DON'T SUPPRESS ANYMORE 0'S
2250 012756 052703 000060  BIS      #'0,R3         ;;MAKE THIS DIGIT ASCII
2251 012762 052703 000040  BIS      #' ,R3         ;;MAKE ASCII IF NOT ALREADY
2252 012766 110337 015032  MOVB     R3,R0          ;;SAVE FOR TYPING
2253 012772 104400 015032  TYPE     ,R5            ;;GO TYPE THIS DIGIT
2254 012776 105337 015034  7S:    DECB     $DCNT          ;;COUNT BY 1
2255 013002 003347      BGT      6$            ;;BR IF MORE TO DO
2256 013004 002402      BLT      6$            ;;BR IF DONE
2257 013006 005204      LMC      R4            ;;INSURE LAST DIGIT ISN'T A BLANK
2258 013010 000744      BR       2$            ;;GO DO THE LAST DIGIT
2259 013012 012605      6S:    MOV      (SP)+,R5     ;;RESTORE R5
2260 013014 012604      MOV      (SP)+,R4     ;;RESTORE R4
2261 013016 012603      MOV      (SP)+,R3     ;;RESTORE R3
2262 013020 016666 000002 000004  MOV      2(SP),4(SP)   ;;SET THE STACK FOR RETURNING
2263 013026 012616      MOV      (SP)+,(SP)
2264 013030 000002      RTI
2265 013032 000          8S:    .BYTE 0          ;;RETURN
2266 013033 000          .BYTE 0          ;;STORAGE FOR ASCII DIGIT
2267 013034 000          .BYTE 0          ;;TERMINATOR FOR TYPE ROUTINE
2268 013035 000          .BYTE 0          ;;OCTAL DIGIT COUNTER
2269 013036 000000      .WORD 0          ;;ZERO FILL SWITCH
2270 .SBTTL SAVE AND RESTORE R0-R5 ROUTINES
2271
2272 ;;*****
2273 ;*SAVE R0-R5
2274 ;*CALL:
2275 ;* SAVREG
2276 ;*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
2277 ;*
2278 ;*TOP---(+16)
2279 ;* +2---(+16)
2280 ;* +4---R5
2281 ;* +6---R4
2282 ;* +8---R3
2283 ;* +10---R2
2284 ;* +12---R1
2285 ;* +14---R0
2286
2287 $SAVREG:
2288 013040 01004b      MOV      R0,=(SP)     ;;PUSH R0 ON STACK
2289 013042 01014b      MOV      R1,=(SP)     ;;PUSH R1 ON STACK
2290 013044 01024b      MOV      R2,=(SP)     ;;PUSH R2 ON STACK
2291 013046 01034b      MOV      R3,=(SP)     ;;PUSH R3 ON STACK
2292 013050 01044b      MOV      R4,=(SP)     ;;PUSH R4 ON STACK
2293 013052 01054b      MOV      R5,=(SP)     ;;PUSH R5 ON STACK
2294 013054 01664b 000022  MOV      22(SP),-(SP) ;;SAVE PS OF MAIN FLOW
2295 013060 01664b 000022  MOV      22(SP),-(SP) ;;SAVE PC OF MAIN FLOW
2296 013064 01664b 000022  MOV      22(SP),-(SP) ;;SAVE PS OF CALL
  
```

```

2297 013070 01664b 000022  MOV      22(SP),-(SP) ;;SAVE PC OF CALL
2298 013074 200002      RTI
2299
2300 ;*RESTORE R0-R5
2301 ;*CALL:
2302 ;* RESREG
2303 $RESREG:
2304 013076 012666 000022  MOV      (SP)+,22(SP)  ;;RESTORE PC OF CALL
2305 013078 012666 000022  MOV      (SP)+,22(SP)  ;;RESTORE PS OF CALL
2306 013080 012666 000022  MOV      (SP)+,22(SP)  ;;RESTORE PC OF MAIN FLOW
2307 013082 012666 000022  MOV      (SP)+,22(SP)  ;;RESTORE PS OF MAIN FLOW
2308 013084 012605      MOV      (SP)+,R5     ;;POP STACK INTO R5
2309 013086 012604      MOV      (SP)+,R4     ;;POP STACK INTO R4
2310 013088 012603      MOV      (SP)+,R3     ;;POP STACK INTO R3
2311 013090 012602      MOV      (SP)+,R2     ;;POP STACK INTO R2
2312 013092 012601      MOV      (SP)+,R1     ;;POP STACK INTO R1
2313 013094 012600      MOV      (SP)+,R0     ;;POP STACK INTO R0
2314 013096 000002      RTI
2315 .SBTTL TTY INPUT ROUTINE
2316
2317 ;;*****
2318 013134 177560      STKB:   .WORD 177560    ;;TTY KBD STATUS
2319 013136 177562      STKB:   .WORD 177562    ;;TTY KBD BUFFER
2320 .ENABL  LSB
2321
2322 ;;*****
2323 ;*SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
2324 ;*ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
2325 ;*SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
2326 ;*WHEN OPERATING IN TTY-FLAG MODE.
2327 013140 022737 000176 001214  SCKSWR: CMP      #SWREG,SWR  ;;IS THE SOFT-SWR SELECTED?
2328 013142 001074      BNE      15$          ;;BRANCH IF NO
2329 013150 105777 177760  TSTB     #STKS         ;;CHAR THERE?
2330 013154 100071      RPL      15$          ;;IF NO, DON'T WAIT AROUND
2331 013156 117746 177754  MOVB     #STKB,=(SP)   ;;SAVE THE CHAR
2332 013162 042716 177600  BIC      #'C177,(SP)   ;;STRIP-OFF THE ASCII
2333 013166 022726 000007  CMP      #7,(SP)+      ;;IS IT A CONTROL G?
2334 013172 001062      BNE      15$          ;;NO, RETURN TO USER
2335 013174 123727 001314 000001  CMPB     SAUTOB,#1     ;;ARE WE RUNNING IN AUTO-MODE?
2336 013202 001456      BEQ      15$          ;;BRANCH IF YES
2337
2338 013204 104400 015665      TYPE     ,%CNTLG      ;;ECHO THE CONTROL-G (^G)
2339 013210 104400 015672  SGTSWR: TYPE     ,%MSWR  ;;TYPE CURRENT CONTENTS
2340 013214 013746 000176  MOV      SWREG,=(SP)   ;;SAVE SWREG FOR TYPEOUT
2341 013220 104401      TYPOC    ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
2342 013222 104400 015703      TYPE     ,%MNEW       ;;PROMPT FOR NEW SWR
2343 013226 005046      19S:    CLR      -(SP)     ;;CLEAR COUNTER
2344 013230 005046      CLR      -(SP)     ;;THE NEW SWR
2345 013232 105777 177676  7S:    TSTB     #STKS         ;;CHAR THERE?
2346 013236 100375      BPL      7$            ;;IF NOT TRY AGAIN
2347
2348 013240 117746 177672  MOVB     #STKB,=(SP)   ;;PICK UP CHAR
2349 013244 042716 177600  BIC      #'C177,(SP)   ;;MAKE IT 7-BIT ASCII
2350
2351
2352
  
```

```

2353 013250 021627 000025 95: CMP (SP),#25 ;IS IT A CONTROL-U?
2354 013254 001005 BNE 105 ;BRANCH IF NOT
2355 013256 104400 015660 TYPE ,SCNTLU ;YES, ECHO CONTROL-U (~U)
2356 013262 062706 000006 205: ADD #6,SP ;IGNORE PREVIOUS INPUT
2357 013266 000757 BR 195 ;LET'S TRY IT AGAIN
2358
2359
2360 013270 021627 000015 105: CMP (SP),#15 ;IS IT A <CR>?
2361 013274 001022 BNE 105 ;BRANCH IF NO
2362 013276 005766 000004 TST 4(SP) ;YES, IS IT THE FIRST CHAR?
2363 013302 001423 BEQ 115 ;BRANCH IF YES
2364 013304 016677 000002 165702 MOV 2(SP),#SWR ;SAVE NEW SWR
2365 013312 062706 000006 115: ADD #6,SP ;CLEAR UP STACK
2366 013316 104400 012607 145: TYPE ,SCRLF ;ECHO <CR> AND <LF>
2367 013322 123727 015715 000001 CMPB $INTAG,#1 ;RE-ENABLE TTY KBD INTERRUPTS?
2368 013330 001005 BNE 155 ;BRANCH IF NOT
2369 013332 012777 000100 177574 MOV #100,#STKS ;RE-ENABLE TTY KBD INTERRUPTS
2370 013340 000002 155: RTI ;RETURN
2371 013342 004737 012526 165: JSR PC,$TYPEC ;ECHO CHAR
2372 013346 021627 000060 CMP (SP),#0 ;CHAR < 0?
2373 013352 002420 BLT 105 ;BRANCH IF YES
2374 013354 021627 000067 CMP (SP),#07 ;CHAR > 7?
2375 013360 003015 BGT 105 ;BRANCH IF YES
2376 013362 042726 000060 BIC #60,(SP)+ ;STRIP-OFF ASCII
2377 013366 005766 000002 TST 2(SP) ;IS THIS THE FIRST CHAR
2378 013372 001403 BEQ 175 ;BRANCH IF YES
2379 013374 006316 ASL (SP) ;NO, SHIFT PRESENT
2380 013376 006316 ASL (SP) ; CHAR OVER TO MAKE
2381 013400 006316 ASL (SP) ; ROOM FOR NEW ONE.
2382 013402 005266 000002 175: INC 2(SP) ;KEEP COUNT OF CHAR
2383 013406 056616 177776 BIS -2(SP),(SP) ;SET IN NEW CHAR
2384 013412 000707 BR 75 ;GET THE NEXT ONE
2385 013414 104400 012606 165: TYPE ,SQUE$ ;TYPE ?<CR><LF>
2386 013420 000720 BR 205 ;SIMULATE CONTROL-U
2387
2388
2389
2390 ;*****
2391 ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
2392 ;*CALL:
2393 ;* R0CHR ;INPUT A SINGLE CHARACTER FROM THE TTY
2394 ;* RETURN HERE ;CHARACTER IS ON THE STACK
2395 ;* ;WITH PARITY BIT STRIPPED OFF
2396 ;
2397
2398 013422 011646 SR0CHR: MOV (SP),-(SP) ;PUSH DOWN THE PC
2399 013424 016666 000004 000002 MOV 4(SP),2(SP) ;SAVE THE PS
2400 013432 105777 177476 15: TSTB #STKS ;WAIT FOR
2401 013436 10375 BPL 15 ;A CHARACTER
2402 013440 117766 177472 000004 MOV8 #STKB,4(SP) ;READ THE TTY
2403 013446 042766 177600 000004 BIC #'C177',4(SP) ;GET RID OF JUNK IF ANY
2404 013454 026627 000004 000023 CMP #4,(SP),#23 ;IS IT A CONTROL-S?
2405 013462 001013 BNE 55 ;BRANCH IF NO
2406 013464 105777 177444 25: TSTB #STKB ;WAIT FOR A CHARACTER
2407 013470 100375 BPL 25 ;LOOP UNTIL ITS THERE
2408 013472 117766 177440 MOV8 #STKB,-(SP) ;GET CHARACTER

```

```

2409 013476 042716 177600 R1C #'C177,(SP) ;MAKE IT 7-BIT ASCII
2410 013502 022627 000021 CMP (SP)+,#21 ;IS IT A CONTROL-Q?
2411 013506 001366 BNE 25 ;IF NOT DISCARD IT
2412 013510 000750 BR 15 ;YES, RESUME
2413 013512 026627 000004 000140 35: CMP 4(SP),#140 ;IS IT UPPER CASE?
2414 013520 002407 BLT 45 ;BRANCH IF YES
2415 013522 026627 000004 000175 CMP 4(SP),#175 ;IS IT A SPECIAL CHAR?
2416 013530 003003 BGT 45 ;BRANCH IF YES
2417 013532 042766 000040 000004 45: BIC #40,4(SP) ;MAKE IT UPPER CASE
2418 013540 000002 RTI ;GO BACK TO USER
2419 ;*****
2420 ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2421 ;*CALL:
2422 ;* R0LIN ;INPUT A STRING FROM THE TTY
2423 ;* RETURN HERE ;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2424 ;* ;TERMINATOR WILL BE A BYTE OF ALL 0'S
2425
2426 013542 010346 SR0LIN: MOV R3,-(SP) ;SAVE R3
2427 013544 012703 013650 15: MOV #STTYIN,R3 ;GET ADDRESS
2428 013550 022703 013660 25: CMP #STTYIN+8,R3 ;BUFFER FULL?
2429 013554 101405 BLOS 45 ;BR IF YES
2430 013556 104406 R0CHR ;GO READ ONE CHARACTER FROM THE TTY
2431 013560 112613 MOV8 (SP)+,(R3) ;GET CHARACTER
2432 013562 122713 000177 105: CMPB #177,(R3) ;IS IT A RUBOUT
2433 013566 001003 BNE 35 ;SKIP IF NOT
2434 013570 104400 012606 45: TYPE ,SQUE$ ;TYPE A '?'
2435 013574 000763 BR 15 ;CLEAR THE BUFFER AND LOOP
2436 013576 111337 013646 35: MOV8 (R3),95 ;ECHO THE CHARACTER
2437 013602 104400 013646 TYPE ,95
2438 013606 122723 000015 CMPB #15,(R3)+ ;CHECK FOR RETURN
2439 013612 001356 BNE 25 ;LOOP IF NOT RETURN
2440 013614 105063 177777 CLR8 -1(R3) ;CLEAR RETURN (THE 15)
2441 013620 104400 012610 TYPE ,3LF ;TYPE A LINE FEED
2442 013624 012603 MOV (SP)+,R3 ;RESTORE R3
2443 013626 011646 MOV (SP),-(SP) ;ADJUST THE STACK AND PUT ADDRESS OF THE
2444 013630 016666 000004 000002 MOV 4(SP),2(SP) ; FIRST ASCII CHARACTER ON IT
2445 013636 012766 013650 000004 MOV #STTYIN,4(SP)
2446 013644 000002 RTI ;RETURN
2447 013646 000 95: .BYTE 0 ;STORAGE FOR ASCII CHAR. TO TYPE
2448 013647 000 .BYTE 0 ;TERMINATOR
2449 013650 000010 .BLKB 8 ;RESERVE 8 BYTES FOR TTY INPUT
2450 013660 052536 005015 000 SCNTLU: .ASCIZ /'U<15><12> ;CONTROL "U"
2451 013665 136 006507 000012 SCNTLG: .ASCIZ /'G<15><12> ;CONTROL "G"
2452 013672 005015 053523 020122 $MSWR: .ASCIZ <15><12>/$WR = /
2453 013700 020075 000 $MNEW: .ASCIZ / NEW = /
2454 013703 040 047040 053505 $AUTOB: .BYTE 0 ;AUTO MODE FLAG
2455 013710 036440 000040 $SINTAG: .BYTE 0 ;INTERRUPT MODE FLAG
2456 013714 000 .SBTTL TRAP DECODER
2457 013715 000
2458
2459
2460 ;*****
2461 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
2462 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
2463 ;*OF THE DESIRED ROUTINE, THEN USING THE ADDRESS OBTAINED IT WILL
2464 ;*GO TO THAT ROUTINE.

```

```

2465
2466 013716 010046          STRAP: MOV    R0,-(SP)          ;;SAVE R0
2467 013720 016600 000002    MOV    2(SP),R0              ;;GET TRAP ADDRESS
2468 013724 005740          TST    =(R0)                 ;;BACKUP BY 2
2469 013726 111000          MOVB   (R0),R0               ;;GET RIGHT BYTE OF TRAP
2470 013730 006300          ASL    R0                    ;;POSITION FOR INDEXING
2471 013732 016000 015740    MOV    STRPAD(R0),R0         ;;INDEX TO TABLE
2472 013736 000200          RTS    R0                    ;;GO TO ROUTINE
2473
2474
2475          .SBTTL TRAP TABLE
2476
2477          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
2478          ;*BY THE "TRAP" INSTRUCTION.
2479
2480          /
2481          / ROUTINE
2482          / -----
2483          STRPAD:
2484          STYPE  ;;CALL=STYPE TRAP+0(104400) TTY TYPEOUT ROUTINE
2485          STYPC  ;;CALL=STYPC TRAP+1(104401) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
2486          STYPO  ;;CALL=STYPO TRAP+2(104402) TYPE OCTAL NUMBER (NO LEADING ZEROS)
2487          STYFON ;;CALL=STYFON TRAP+3(104403) TYPE OCTAL NUMBER (AS PER LAST CALL)
2488
2489          SGTSWR ;;CALL=SGTSWR TRAP+4(104404) GET SOFT-SWR SETTING
2490
2491          SCKSWR ;;CALL=SCKSWR TRAP+5(104405) TEST FOR CHANGE IN SOFT-SWR
2492          SKDCHR ;;CALL=SKDCHR TRAP+6(104406) TTY TYPEIN CHARACTER ROUTINE
2493          SKDLIN ;;CALL=SKDLIN TRAP+7(104407) TTY TYPEIN STRING ROUTINE
2494          SSAVEG  ;;CALL=SSAVEG TRAP+10(104410) SAVE R0-R5 ROUTINE
2495          SRESREG ;;CALL=SRESREG TRAP+11(104411) RESTORE R0-R5 ROUTINE
2496
2497          .SBTTL POWER DOWN AND UP ROUTINES
2498
2499          ;******
2500          ;*POWER DOWN ROUTINE
2501          SPWRDN: MOV    #SILLUP,#PWRVEC ;;SET FOR FAST UP
2502          MOV    #340,#PWRVEC+2 ;;PRI0:7
2503          MOV    R0,-(SP) ;;PUSH R0 ON STACK
2504          MOV    R1,-(SP) ;;PUSH R1 ON STACK
2505          MOV    R2,-(SP) ;;PUSH R2 ON STACK
2506          MOV    R3,-(SP) ;;PUSH R3 ON STACK
2507          MOV    R4,-(SP) ;;PUSH R4 ON STACK
2508          MOV    R5,-(SP) ;;PUSH R5 ON STACK
2509          MOV    #SWR,-(SP) ;;PUSH #SWR ON STACK
2510          SP,SSAVK6 ;;SAVE SP
2511          MOV    #SPWRUP,#PWRVEC ;;SET UP VECTOR
2512          HALT
2513          BR     =-2 ;;HANG UP
2514
2515          ;******
2516          ;*POWER UP ROUTINE
2517          SPWRUP: MOV    #SILLUP,#PWRVEC ;;SET FOR FAST DOWN
2518          MOV    SSAVEK6,SP ;;GET SP
2519          CLR    SSAVEK6 ;;WAIT LOOP FOR THE TTY
2520          1$: INC    SSAVEK6 ;;WAIT FOR THE INC
2521          BNE   1$ ;;OF WORD
2522          MOV    (SP)+,#SWR ;;POP STACK INTO #SWR
2523          MOV    (SP)+,R5 ;;POP STACK INTO R5
    
```

```

2521 014070 012604          MOV    (SP)+,R4              ;;POP STACK INTO R4
2522 014072 012603          MOV    (SP)+,R3              ;;POP STACK INTO R3
2523 014074 012602          MOV    (SP)+,R2              ;;POP STACK INTO R2
2524 014076 012601          MOV    (SP)+,R1              ;;POP STACK INTO R1
2525 014100 012600          MOV    (SP)+,R0              ;;POP STACK INTO R0
2526 014102 012737 015764 000024    MOV    #SPWRDN,#PWRVEC ;;SET UP THE POWER DOWN VECTOR
2527 014110 012737 000340 000026    MOV    #340,#PWRVEC+2 ;;PRI0:7
2528 014116 104400          TYPE
2529 014120 014136          SPWRMG: ,WORD SPOWER ;;REPORT THE POWER FAILURE
2530 014122 012716          MOV    (PC)+,(SP) ;;POWER FAIL MESSAGE POINTER
2531 014124 002700          SPWRAD: ,WORD RESTART ;;RESTART AT RESTART
2532 014126 000002          RTI ;;RESTART ADDRESS
2533 014130 000000          SILLUP: HALT
2534 014132 000776          BR     =-2 ;;THE POWER UP SEQUENCE WAS STARTED
2535 014134 000000          SSAVEK6: 0 ;;BEFORE THE POWER DOWN WAS COMPLETE
2536 014136 005015 047520 042527    SPOWER: ,ASCIZ <15><12>"POWER" ;;PUT THE SP HERE
2537 014144 000122
2538
2539          .SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCIZ ROUTINE
2540
2541          ;******
2542          ;*THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
2543          ;*UNSIGNED DECIMAL ASCIZ NUMBER.
2544          ;*CALL
2545          ;* MOV    NUMBER,-(SP) ;;PUT BINARY NUMBER ON THE STACK
2546          ;* JSR    PC,#S0B2D ;;CALL
2547          ;* RETURN ;;ADDRESS OF THE 1ST ASCIZ CHAR,IS ON THE STACK
2548
2549
2550 014146 016637 000002 014176    S0B2D: MOV    2(SP),1$           ;;SAVE BINARY NUMBER
2551 014154 012746 014176          MOV    #1$,-(SP)           ;;SET POINTER
2552 014160 004737 014202          JSR    PC,#S0B2D           ;;CALL DOUBLE LENGTH CONVERT
2553 014164 026216 000005          ADD    #5,(SP)             ;;ONLY ALLOW FIVE CHARACTERS
2554 014170 012666 000002          MOV    (SP)+,2(SP)         ;;PICKUP POINTER
2555 014174 000207          RTS    PC                  ;;RETURN
2556 014176 000000          1$: ,WORD 0,0
2557          .SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
2558
2559          ;******
2600          ;*THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
2601          ;*DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
2602          ;*POSITIVE.
2603          ;*CALL
2604          ;* MOV    #PNTR,-(SP) ;;POINTER TO LOW WORD OF BINARY NUMBER
2605          ;* JSR    PC,#S0B2D ;;CALL
2606          ;* RETURN ;;THE FIRST ADDRESS OF ASCII
2607          ;* IS ON THE STACK
2608
2609
2610 014202 104410          S0B2D: SAVREG
2611 014204 016602 000002          MOV    2(SP),R2           ;;SAVE REGISTERS
2612 014210 012700 014362          MOV    #S0EVL,R0         ;;PICKUP THE DATA POINTER
2613 014214 010066 000002          MOV    R0,2(SP)          ;;GET ADDRESS OF "S0EVL" STRING
2614 014220 012201          MOV    (R2)+,R1          ;;PUT ADDRESS OF ASCII STRING ON STACK
2615 014222 012202          MOV    (R2)+,R1          ;;PICKUP THE BINARY NUMBER
2616 014224 012737 000012 014300          MOV    #10,,4$           ;;SET UP TO DO 10 CONVERSIONS
    
```



```

2577 014232 012704 014312      MOV    #STNPNR,R4      ;;ADDRESS OF TEN POWER
2578 014236 012705 014314      MOV    #STNPNR+2,R5
2579 014242 005003              15:   CLR    R3              ;;CLEAR PARTIAL
2580 014244 161401              25:   SUB    (R4),R1        ;;SUBTRACT TEN POWER
2581 014246 005002              SBC    R2
2582 014250 161502              SUB    (R5),R2
2583 014252 002402              BLT    J5              ;;BR IF TEN POWER TO LARGE
2584 014254 005203              INC    R3              ;;ADD 1 TO PARTIAL
2585 014256 000772              BR     Z5              ;;LOOP
2586 014260 062401              35:   ADD    (R4)+,R1        ;;RESTORE SUBTRACTED VALUE
2587 014262 005502              ADD    R2
2588 014264 062402              ADD    (R4)+,R2
2589 014266 022525              CMP    (R5)+,(R5)+    ;;MOVE TO NEXT TEN POWER
2590 014270 052703 000060      B1S    #'0,R3          ;;CHANGE PARTIAL TO ASCII
2591 014274 110320              MOVSB  R3,(R0)+        ;;SAVE IT
2592 014276 005327              DEC    (PC)+          ;;DONE?
2593 014300 000000              45:   .WORD 0
2594 014302 021357              RNE    J5              ;;BR IF NO
2595 014304 105020              CLRB  (R0)+            ;;TERMINATOR
2596 014306 104411              RESREG
2597 014310 000207              RTS    PC              ;;RETURN
2598 014312 145000              STNPNR: 145000         ;;1.0E09
2599 014314 035632              35632
2600 014316 160400              160400         ;;1.0E08
2601 014320 042765              2765
2602 014322 113200              113200         ;;1.0E07
2603 014324 000230              230
2604 014326 041100              041100         ;;1.0E06
2605 014330 000017              17
2606 014332 103240              103240         ;;1.0E05
2607 014334 000001              1
2608 014336 023420              23420          ;;1.0E04
2609 014340 000000              0
2610 014342 001750              1750           ;;1.0E03
2611 014344 000000              0
2612 014346 000144              144            ;;1.0E02
2613 014350 000000              0
2614 014352 000012              12            ;;1.0E01
2615 014354 000000              0
2616 014356 000001              1             ;;1.0E00
2617 014360 000000              0
2618 014362 000014      SUBCVL: .BLKB 12,      ;;RESERVE STORAGE FOR ASCII STRING
2619
2620      ;*****
2621      ;TYPE NUMERICAL ASCII STRING,RIGHT JUSTIFIED
2622      ;REPLACING LEADING ZEROS WITH SPACES.
2623      ;
2624      ;FIRST ADDRESS OF ASCII STRING MUST BE ON TOP OF THE STACK
2625
2626
2627 014376 010046      RTJUST:   MOV    R0,-(SP)      ;SAVE R0
2628 014400 016600 000004      MOV    4(SP),R0      ;PICK UP ADDRESS OF ASCII STRING
2629 014404 010037 014436      MOV    R0,J5         ;SAVE ADDRESS FOR TYPE OUT
2630 014410 105710      15:     TSTB (R0)          ;IS THIS THE TERMINATOR
2631 014412 001406      BEQ    Z5            ;IF YES TYPE IT OUT
2632 014414 122710 000060      CMPEB #'0,(R0)      ;IS IT A ZERO

```

```

2633 014420 001005              HNE    4$              ;IF NO GO PRINT IT
2634 014422 112720 000040      MOVSB  A' ,(R0)+      ;IF YES REPLACE IT WITH A SPACE
2635 014426 000770              BK     1$              ;TEST NEXT CHAR.
2636 014430 112740 000060      25:   MOVSB #'0,-(R0)     ;STRING OFF ALL ZEROS,PUT BACK THE LAST ONE
2637 014434 104400              45:   TYPE              ;TYPE THE STRING
2638 014436 000000              55:   OPEN
2639 014440 012600              MOV    (SP)+,R0       ;RESTORE R0
2640 014442 012610      MOV    (SP)+,(SP)     ;RESTORE THE STACK
2641 014444 000207              RTS    PC              ;RETURN
2642
2643      ;TYPES 16 BIT WORD IN DECIMAL
2644
2645 014446 012546              SGLDEC:  MOV    (R5)+,-(SP)      ;PUT NUMBER TO BE TYPED ON STACK
2646 014450 004737 014146      JSR    PC,#$S820      ;CONVERT NUMBER TO DECIMAL
2647 014454 004737 014376      JSR    PC,RTJUST      ;TYPE THE DECIMAL NUMBER
2648 014460 000205              RTS    R5
2649
2650
2651 014462 047125 054105 042520      MUNXDD:  .ASCII "UNEXPECTED D U MARK"
2652 014470 052103 042105 042040
2653 014476 042040 046440 051101
2654 014504 000113
2655
2656 014506 020104 020104 040515      MODMIS:  .ASCII "D U MARK MISSING"
2657 014514 045522 046440 051511
2658 014522 044523 043516 000
2659
2660
2661 014527 104 052101 026101      MDERHDR:  .ASCII "DATA, NO STATUS ERROR"
2662 014534 047040 020117 052123
2663 014542 052101 051525 042440
2664 014550 051122 051117 000
2665
2666 014555 040 047117 052040      MTRK:    .ASCII " ON TRACK"
2667 014562 040522 045503 000
2668
2669
2670 014567 040 043040 047522      MPRES:    .ASCII " FROM TRACK"
2671 014574 020115 051124 041501
2672 014602 000113
2673
2674 014604 027440 051440 041505      MSECT:    .ASCII " / SECTOR"
2675 014612 047524 000122
2676
2677 014616 005015 041040 052131      MCOLMUN:  .ASCII "<15><12>" BYTE BAD GOOD"<15><12>"
2678 014624 020105 041040 042101
2679 014632 020040 047507 042117
2680 014640 005015 000
2681
2682 014643 015 041412 052501      D0LOAD:  .ASCII "<15><12>"CAUTION - IF YOU DESIRE TO TEST UNIT 0"
2683 014650 044524 047117 026440
2684 014656 044440 020106 047531
2685 014664 020125 042504 044523
2686 014672 042522 052040 020117
2687 014700 042524 052123 052440
2688 014706 044516 020124 060

```

2689	014713	015	051012	050105		.ASCII <15><12>"REPLACE LOAD MEDIUM WITH A SCRATCH DISKETTE"
2690	014720	040514	042503	046040		
2691	014726	040517	020104	042515		
2692	014734	044504	046525	053440		
2693	014742	052111	020110	020101		
2694	014750	041523	040522	041524		
2695	014756	020110	044504	045523		
2696	014764	052105	042524			
2697	014770	005015	044124	047105		.ASCII <15><12>"THEN PRESS CONTINUE"
2698	014776	050040	042522	051523		
2699	015004	041440	047117	044524		
2700	015012	052516	000105			
2701						
2702	015016	047516	042040	044522	MNOORY:	.ASCIIZ "NO DRIVES READY"<15><12>
2703	015024	042526	020123	042522		
2704	015032	042101	006531	000012		
2705						
2706	015040	020040	020040	020040	TAB:	.ASCIIZ <40><40><40><40><40><40>
2707	015046	000				
2708						
2709	015047	040	000040		DBLSP:	.ASCIIZ <40><40>
2710						
2711	015052	005015	000		MCRLF:	.ASCIIZ <15><12>
2712						
2713	015055	104	000		MEOP:	.ASCIIZ "0"
2714						
2715	015057	055	000		MENEOP:	.ASCIIZ "="
2716						
2717	015061	007	000		MAHELL:	.ASCIIZ <07>
2718						
2719	015063	105	051122	051117	MERHEAULR:	.ASCIIZ "ERROR CONDITIONS "
2720	015070	041440	047117	044504		
2721	015076	044524	047117	020123		
2722	015104	000040				
2723						
2724	015106	047125	052111	030040	MUNIT0:	.ASCIIZ "UNIT 0 "
2725	015114	000040				
2726						
2727	015116	047125	052111	030440	MUNIT1:	.ASCIIZ "UNIT 1 "
2728	015124	000040				
2729						
2730	015126	040510	020123	042502	MDELET:	.ASCIIZ "HAS BEEN DELETED."
2731	015134	047105	042040	046105		
2732	015142	052105	042105	000056		
2733						
2734	015150	044440	052110	053040	MINTVLC:	.ASCIIZ "INT VECTOR = "
2735	015156	041505	047524	020122		
2736	015164	020075	000			
2737						
2738	015167	122	041530	020123	MRXCS:	.ASCIIZ "RXCS = "
2739	015174	020075	000			
2740						
2741	015177	040	054122	041104	MRXOR:	.ASCIIZ "RXOR = "
2742	015204	036440	000040			
2743						
2744	015210	052123	052101	051525	MASTAT:	.ASCIIZ "STATUS A = "

2745	015216	040440	036440	000040		
2746						
2747	015224	052123	052101	051525	MSTAT:	.ASCIIZ "STATUS B = "
2748	015232	041040	036440	000040		
2749						
2750	015240	005015	000012		DBLLF:	.ASCIIZ <15><12><12>
2751						
2752	015244	036520	000040		MPAT:	.ASCIIZ "P = "
2753						
2754	015250	036524	000040		MTEST:	.ASCIIZ "T = "
2755						
2756	015254	036523	000040		MSEQ:	.ASCIIZ "S = "
2757						
2758	015260	047516	044440	052116	MINTER:	.ASCIIZ "NO INTERRUPT AT DONE ERROR"
2759	015266	051105	050125	020124		
2760	015274	052101	042040	047117		
2761	015302	020105	051105	047522		
2762	015310	000122				
2763						
2764	015312	047125	047113	053517	MKNINT:	.ASCIIZ "UNKNOWN INTERRUPT"
2765	015320	020116	047111	042524		
2766	015326	052522	052120	000		
2767						
2768	015333	124	052117	046101	MERCT:	.ASCIIZ "TOTAL READ CHECK ERRORS = "
2769	015340	051040	040505	020104		
2770	015346	044103	041505	020113		
2771	015354	051105	047522	051522		
2772	015362	036440	000040			
2773						
2774	015366	044506	046114	052502	MFIL:	.ASCIIZ "FILLBUFFER "
2775	015374	043106	051105	000040		
2776						
2777	015402	046505	052120	041131	MEMPTY:	.ASCIIZ "EMPTYBUFFER "
2778	015410	043125	042506	020122		
2779	015416	000				
2780						
2781	015417	104	044522	042526	MICON:	.ASCIIZ "DRIVE(S) "
2782	015424	051450	020051	000040		
2783						
2784	015432	042524	052123	044040	MHUNG:	.ASCIIZ "TEST HUNG"<15><12>
2785	015440	047125	006507	000012		
2786						
2787	015446	047516	051516	040524	MNONSTD:	.ASCIIZ "NONSTANDARD TRACK / SECTOR LIMITS"
2788	015454	042116	051101	020104		
2789	015462	051124	041501	020113		
2790	015470	020057	042523	052103		
2791	015476	051117	046040	046511		
2792	015504	052111	000123			
2793						
2794	015510	042117	000075		MOD:	.ASCIIZ "00="
2795						
2796	015514	042111	000075		MID:	.ASCIIZ "ID="
2797						
2798	015520	044506	051522	036524	MFIRST:	.ASCIIZ "FIRST="
2799	015526	000				
2800						

2001	015527	114	051501	036524	MLAST:	.ASCIZ "LAST="
2002	015534	000				
2003						
2004	015535	111	044516	027124	MINIT1:	.ASCIZ "INIT,DONE NOT SET ERROR"<15><12>
2005	015542	047504	042516	047040		
2006	015550	052117	051440	052105		
2007	015556	042440	051122	051117		
2008	015564	005015	000			
2009						
2010	015567	111	044516	027124	MINIT2:	.ASCIZ "INIT,DONE SET ERROR" <15><12>
2011	015574	047504	042516	051440		
2012	015602	052105	042440	051122		
2013	015610	051117	005015	000		
2014						
2015	015615	104	042040	042440	MDDER:	.ASCIZ "D D ERROR"
2016	015622	051122	051117	000		
2017						
2018	015627	122	041505	053117	MREC:	.ASCIZ "RECOVERABLE "
2019	015634	051105	041101	042514		
2020	015642	000040				
2021						
2022	015644	051103	020103	051105	MBADCR:	.ASCIZ "CRC ERROR NO DATA ERROR"
2023	015652	047522	020122	047516		
2024	015660	042040	052101	020101		
2025	015666	051105	047522	000122		
2026						
2027	015674	042522	042101	000040	MREAD:	.ASCIZ "READ "
2028						
2029	015702	040510	052114	032040	MHALT4:	.ASCIZ "HALT 4" <15><12>
2030	015710	005015	000			
2031						
2032	015713	110	046101	020124	MHALT3:	.ASCIZ "HALT 3" <15><12>
2033	015720	006463	000012			
2034						
2035	015724	040510	052114	030440	MHALT11:	.ASCIZ "HALT 11" <15><12>
2036	015732	006461	000012			
2037						
2038	015736	040504	040524	041440	MCRC:	.ASCIZ "DATA CRC ERROR"
2039	015744	041522	042440	051122		
2040	015752	051117	000			
2041						
2042						
2043	015755	040	047125	042522	MUNREC:	.ASCIZ " UNRECOVERABLE "
2044	015762	047503	042526	040522		
2045	015770	046102	020105	000		
2046						
2047	015775	123	042505	020113	MSEEK:	.ASCIZ "SEEK ERROR"
2048	016002	051105	047522	000122		
2049						
2050	016010	051127	052111	020105	MWRITE:	.ASCIZ "WRITE "
2051	016016	000				
2052						
2053	016017	120	051101	052111	MPAR:	.ASCIZ "PARITY ERROR"
2054	016024	020131	051105	047522		
2055	016032	000122				
2056						

2057	016034	051105	047522	020122	MNUFLAG:	.ASCIZ "ERROR FLAG ERROR"
2058	016042	046106	043501	042440		
2059	016050	051122	051117	000		
2060						
2061	016055	122	030530	020061	MDUMP:	.ASCIZ "RX11 DUMP"
2062	016062	052504	050115	000		
2063						
2064	016067	105	051122	051117	MEHS:	.ASCIZ "ERRORS"
2065	016074	000123				
2066						
2067	016076	044123	051117	020124	MSHORT:	.ASCIZ "SHORT DUMP"
2068	016104	052504	050115	000		
2069						
2070	016111	122	051505	040524	MRESTART:	.ASCIZ "RESTARTS = "
2071	016116	052122	020123	020075		
2072	016124	000				
2073						
2074	016125	120	051501	020123	MNOPAS:	.ASCIZ "PASS ABORTED"
2075	016132	041101	051117	042524		
2076	016140	000104				
2077						
2078	016142	040520	051523	051505	MPASS:	.ASCIZ "PASSES = "
2079	016150	036440	000040			
2080						
2081	016154	051127	052111	042524	MWRTE:	.ASCIZ "WRITTEN "
2082	016162	020116	000			
2083						
2084	016165	057	000040		MSLASH:	.ASCIZ "/"
2085						
2086	016170	000040			SPACE:	.ASCIZ "<40>
2087						
2088	016172	051105	047522	051522	MCODES:	.ASCIZ "ERRORS PER ERROR CODES"<15><12>
2089	016200	050040	051105	042440		
2090	016206	051122	051117	041440		
2091	016214	042117	051505	005015		
2092	016222	000				
2093						
2094	016223	124	040522	045503	MTKLOG:	.ASCIZ "TRACK ACCESSED MOVED TO UNIT 0 UNIT 1 ERRORS"<15><12>
2095	016230	020040	041501	042503		
2096	016236	051523	042105	020040		
2097	016244	046440	053117	042105		
2098	016252	052040	020117	020040		
2099	016260	052440	044516	020124		
2000	016266	020060	052440	044516		
2001	016274	020124	020061	051105		
2002	016302	047522	051522	005015		
2003	016310	000				
2004						
2005	016311	050	047516	042516	MNONE:	.ASCIZ "(NONE)"<15><12>
2006	016316	006451	000012			
2007						
2008	016322	047507	042117	000	MGOOD:	.ASCIZ "GOOD"
2009						
2010	016327	040	041440	042510	MSUM:	.ASCIZ " CHECK SUM "
2011	016334	045503	051440	046525		
2012	016342	000040				

```

2913
2914 016344 005015 054122 030461 MRX11: .ASCIZ <15><12>"RX11 / RXV11"
2915 016352 027440 051040 053130
2916 016360 030461 000
2917
2918 016363 015 052012 040522 002BIG: .ASCII <15><12> "TRACK LIMITS SELECTED OUT OF RANGE,"
2919 016370 045503 046040 046511
2920 016376 052111 020123 042523
2921 016404 042514 052103 042105
2922 016412 047440 052125 047440
2923 016420 020106 040522 043516
2924 016426 026105
2925 016430 051525 047111 020107 .ASCIZ "USING OD=0, ID=114"<15><12>
2926 016436 042117 030475 020054
2927 016444 042111 030475 032061
2928 016452 005015 000
2929
2930 016455 015 051412 041505 S2BIG: .ASCII <15><12> "SECTOR LIMITS SELECTED OUT OF RANGE,"
2931 016462 047524 020122 044514
2932 016470 044515 051524 051440
2933 016476 046105 041505 042524
2934 016504 020104 052517 020124
2935 016512 043117 051040 047101
2936 016520 042507 054
2937 016523 125 044523 043516 .ASCIZ "USING FIRST=1, LAST=32"<15><12>
2938 016530 043040 051111 052123
2939 016536 030475 020054 040514
2940 016544 052123 031475 006462
2941 016552 000012
2942
2943 016554 005015 040515 047111 MREV: .ASCIZ <15><12> "MAINDEC-11-DZRXA-E" <15><12>
2944 016562 042504 026503 030461
2945 016570 042055 051132 040530
2946 016576 042455 005015 000
2947
2948 016604 .EVEN
2949
2950 ;*****
2951
2952 ;THE FOLLOWING LOCATIONS ARE USED FOR DATA STORAGE,RETRY COUNTERS
2953 ;ACCESS COUNTERS ETC.
2954
2955 016604 000200 HUFADR: .BLKW 200
2956
2957 ;RETRY COUNTERS
2958 017004 000012 HDRETRY: 10. ;FOR SETUP PURPOSE HDRETRY MUST BE FIRST ON RETRY LIST
2959 017006 000012 WTRETRY: 10.
2960 017010 000012 ODRETRY: 10.
2961 017012 000012 DATARETRY: 10.
2962 017014 000012 PDRETRY: 10.
2963 017016 000012 PRETRY: 10.
2964 017020 000012 CRETRY: 10.
2965 017022 000012 SRETRY: 10. ;FOR SETUP PURPOSE SRETRY MUST BE LAST ON RETRY LIST
2966
2967
2968 ;GENERAL ERROR COUNTERS
  
```

```

2969 017024 000000 PARLOG: 0. ;FOR SETUP PURPOSE PARLOG MUST BE FIRST ON COUNTERS LIST
2970 017026 000000 MPANLOG: 0.
2971 017030 000000 NOERLOG: 0.
2972 017032 000000 UKNINT: 0.
2973 017034 000000 INTER: 0.
2974
2975 017036 000000 ;DRIVE RELATED ERROR COUNTERS
2976 017040 000000 ZSEKLOG: 0. ;"Z" LOGS ARE FOR DRIVE UNIT "Z"ERO
2977 017042 000000 SEKLOG: 0. ;NON"Z" LOGS ARE FOR DRIVE UNIT 1
2978 017044 000000 ZCRCLG: 0.
2979 017046 000000 CRCLOG: 0. ; * * * NOTE: * * *
2980 017050 000000 ZCRBAD: 0. ;ERROR CODES MUST NOT BE CHANGED
2981 017052 000000 CMCBAD: 0. ;FROM THIS ORDER, ERROR DUMP
2982 017054 000000 ZHDLOG: 0. ;ASSUMES TAGS OF LOGS ARE IN ORDER SHOWN.
2983 017056 000000 HDLOG: 0.
2984 017060 000000 ZWRTLOG: 0.
2985 017062 000000 WRTLOG: 0.
2986 017064 000000 ZUATLOG: 0.
2987 017066 000000 DATALOG: 0.
2988 017070 000000 ZDDMIS: 0.
2989 017072 000000 DDMIS: 0.
2990 017074 000000 ZUNXDD: 0.
2991 017076 000000 UNXDD: 0.
2992 017100 000000 ZHSEKLOG: 0.
2993 017102 000000 HSEKLOG: 0.
2994 017104 000000 ZHCRCLG: 0.
2995 017106 000000 HCRCLG: 0.
2996 017110 000000 ZHCRBAD: 0.
2997 017112 000000 HCRBAD: 0.
2998 017114 000000 ZHRDLOG: 0.
2999 017116 000000 HRDLOG: 0.
3000 017120 000000 ZHWRTLOG: 0.
3001 017122 000000 HWRTLOG: 0.
3002 017124 000000 ZHDATALOG: 0.
3003 017126 000000 HDATALOG: 0.
3004 017130 000000 HDLOG: 0.
3005
3006 ;ERROR CODES
3007 017132 000021 ERCODE: .BLKW 17.
3008
3009 ;THE FOLLOWING 2 BLOCKS OF WORDS ARE TRACK ACCESS COUNTER AND
3010 ;HEAD MOVED TO TRACK COUNTERS, THEY ARE DOUBLE PRECISION
3011 ;COUNTERS IN THE FOLLOWING FORMATT:
3012 ;
3013 ;LOC.X LOW ORDER WORD TRACK 0
3014 ;LOC.X+2 HIGH ORDER WORD TRACK 0
3015 ;LOC.X+4 LOW ORDER WORD TRACK 1
3016 ;LOC.X+6 HIGH ORDER WORD TRACK 1
3017 ;ETC.
3018
3019 ;TOTAL ACCESS / TRACK
3020 017174 000232 TKACC: .BLKW 232
3021
3022 ;TOTAL HEAD MOVEMENT TO TRACK
3023 017660 000232 HMOVE: .BLKW 232
3024
  
```

```

3025 ;THE FOLLOWING 2 BLOCKS OF COUNTERS ARE SINGLE PRECISION
3026
3027 ;ERROR PER TRACK ON UNIT 0
3028 020344 000115 U0TRK: .BLKW 115
3029
3030 ;ERROR PER TRACK ON UNIT 1
3031 020576 000115 U1TRK: .BLKW 115
3032
3033 ;TOTAL WRITE AND READ FUNCTIONS DOUBLE PRECISION COUNTERS
3034 021030 000000 000000 WTCNTR: .WORD 0,0
3035 021034 000000 000000 RDCNTR: .WORD 0,0
3036
3037 ;RESTART AND PASSES COMPLETED COUNTERS
3038 021040 000000 RESTCNTR: 0
3039 021042 000000 PASCNTR: 0 ;FOR SETUP PURPOSE PASCNTR MUST BE PLACED LAST
3040
3041 021044 032737 000020 010704 U1LOG: BIT #BIT4,UNITSEL ;TEST FOR UNIT IN OPERATION
3042 021052 001402 REQ 1$ ;IF BIT 4 IS 0 RETURN AND INC. UNIT 0 COUNTERS
3043 021054 062703 000002 ADD #2,R3 ;ADJUST THE CONTENTS OF R3 FOR
3044 ;THE ADDRESS OF UNIT 1 ERROR LOG COUNTERS.
3045 021060 000207 1$: RTS PC
3046
3047 ;STATISTICAL ERROR REPORT ROUTEEN
3048 ;PRINTS ALL ERROR LOGS AND OPERATING CONDITIONS
3049
3050 ;*****
3051
3052 021062 012706 001200 ERDUMP: MOV #STACK,SP
3053 021066 104400 015240 TYPE ,DBLLF
3054 021072 025737 022514 TST SHURTRPT ;IS SHORT REPORT REQUESTED
3055 021076 001405 BEQ 1$ ;NO,PRINT LONG REPORT
3056 021100 104400 015040 TYPE ,TAB
3057 021104 104400 016076 TYPE ,MSHUNT ;YES,TYPE SHORT REPOR HEADER
3058 021110 000404 BR 2$
3059 021112 104400 015040 1$: TYPE ,TAB
3060 021116 104400 016055 TYPE ,MDUMP ;TYPE LONG REPORT HEADER
3061 021122 104400 016554 TYPE ,MREV ;PRINT NAME AND REVISION OF PROGRAM
3062 021126 004737 002452 JSR PC,ICOND ;TYPE OUT SELECTED DRIVES AND TESTS
3063 021132 005737 021040 TST WSTCNTR ;HAVE THERE BEEN ANY RESTARTS
3064 021136 001412 BEQ 3$ ;NO
3065 021140 104400 016111 TYPE ,MKESTART ;YES,PRINT OUT POW MANY
3066 021144 013737 021040 021156 MOV WSTCNTR,12$
3067 021152 004537 014446 JSR #5,SGLDEC
3068 021156 000000 12$: OPEN
3069 021160 104400 015240 TYPE ,DBLLF
3070 021164 005737 021042 TST PASCNTR ;HAVE ANY PASSES BEEN COMPLETED
3071 021170 001005 BNE 4$ ;YES,PRINT OUT HOW MANY
3072 021172 104400 016125 TYPE ,MNPAS ;NO,TYPE PASS ABORTED
3073 021176 104400 015240 TYPE ,DBLLF
3074 021202 000412 BR 5$
3075 021204 104400 016142 4$: TYPE ,MPASS ;TYPE OUT NUMBER OF PASSES
3076 021210 013737 021042 021222 MOV PASCNTR,7$
3077 021216 004537 014446 JSR #5,SGLDEC
3078 021222 000000 7$: OPEN
3079 021224 104400 015052 TYPE ,MCRLF
3080 021230 005737 022514 TST SHURTRPT ;IS THIS A SHORT REPORT

```

```

3081 021234 001030 BNE AERRS ;YES,DON'T PRINT WRITE/READ TOTALS
3082
3083 ;PRINTS TOTAL NUMBER OF SECTORS WRITTEN AND/OR
3084 ;READ FOR THE DURATION OF RUN TIME.
3085 021236 104400 016154 TYPE ,MWRTN ;PRINT WRT/RO MESSAGE
3086 021242 104400 016165 TYPE ,MSLASH
3087 021246 104400 015674 TYPE ,MREAD
3088 021252 104400 015047 TYPE ,DBLSP
3089 021256 012746 021030 MOV #WTCNTR,-(SP) ;ADDRESS OF TOTAL WRITES ON STACK
3090 021262 004737 014202 JSR PC,##$0B20 ;TYPE TOTAL WRITES
3091 021266 004737 014376 JSR PC,RTJUST
3092 021272 104400 016165 TYPE ,MSLASH
3093 021276 012746 021034 MOV #RDCNTR,-(SP) ;ADDRESS OF TOTAL READS ON STACK
3094 021302 004737 014202 JSR PC,##$0B20 ;TYPE TOTAL READS
3095 021306 004737 014376 JSR PC,RTJUST
3096 021312 104400 015240 TYPE ,DBLLF
3097
3098 ;TYPE OUT MICRO CPU RELATED ERRORS
3099 021316 104400 015052 AERRS: TYPE ,MCRLF
3100 021322 005737 017024 TST PARLOG ;WERE THERE ANY PARITY ERRORS
3101 021326 001435 BEQ 1$
3102 021330 013737 017024 021342 MOV PARLOG,20$ ;YES,TYPE OUT THE NUMBER
3103 021336 004537 014446 JSR #5,SGLDEC
3104 021342 000000 20$: OPEN
3105 021344 104400 015047 TYPE ,DBLSP
3106 021350 104400 016017 TYPE ,MPAN
3107 021354 104400 015052 TYPE ,MCRLF
3108 021360 005737 017026 TST MPARLOG ;WERE THERE ANY HARD PARITY ERRORS
3109 021364 001416 BEQ 1$
3110 021366 013737 017026 021400 MOV MPARLOG,21$ ;YES,TYPE OUT THE COUNT
3111 021374 004537 014446 JSR #5,SGLDEC
3112 021400 000000 21$: OPEN
3113 021402 104400 015047 TYPE ,DBLSP
3114 021406 104400 015755 TYPE ,MUNREC
3115 021412 104400 016017 TYPE ,MPAR
3116 021416 104400 015052 TYPE ,MCRLF
3117 021422 005737 017030 TST NDRLOG ;ANY STATUS ERROR FLAG ERRORS
3118 021426 001414 BEQ 3$ ;IF NONE CHECK NEXT ERROR
3119 021430 013737 017030 021442 MOV NDRLOG,24$ ;YES,TYPE OUT COUNT
3120 021436 004537 014446 JSR #5,SGLDEC
3121 021442 000000 24$: OPEN
3122 021444 104400 015047 TYPE ,DBLSP
3123 021450 104400 016034 TYPE ,MNOFLAG
3124 021454 104400 015052 TYPE ,MCRLF
3125 021460 005737 017034 TST INTER ;ANY NO INTERRUPT ON DONE ERRORS
3126 021464 001414 BEQ 4$ ;IF NONE CHECK NEXT ERROR GROUP
3127 021466 013737 017034 021500 MOV INTER,25$ ;YES,PRINT OUT NUMBER
3128 021474 004537 014446 JSR #5,SGLDEC
3129 021500 000000 25$: OPEN
3130 021502 104400 015047 TYPE ,DBLSP
3131 021506 104400 015260 TYPE ,MINTER
3132 021512 104400 015052 TYPE ,MCRLF
3133 ;TYPES DRIVE RELATED ERRORS
3134 021516 104400 015240 4$: TYPE ,DBLLF
3135 021522 104400 015106 TYPE ,MUNIT0 ;TYPE OUT COLUMN HEADINGS
3136 021526 104400 015116 TYPE ,MUNIT1

```

```

3137 021532 104400 016170      TYPE ,SPACE
3138 021536 104400 016067      TYPE ,MERS
3139 021542 104400 015052      TYPE ,MCRLF
3140 021546 005002
3141 021550 013746 022516      CLR R2
3142 021554 012746 014462      MOV ZK0,-(SP)
3143 021560 012746 014506      MOV #MUNXDU,-(SP)
3144 021564 012746 014527      MOV #MDDMIS,-(SP)
3145 021570 012746 016010      MOV #MDEHDR,-(SP)
3146 021574 012746 015674      MOV #MWRITE,-(SP)
3147 021600 012746 015644      MOV #MREAD,-(SP)
3148 021604 012746 015736      MOV #MADCMC,-(SP)
3149 021610 012746 015775      MOV #MCRC,-(SP)
3150 021614 012701 017036      MOV #MSEEK,-(SP)
3151 021620 005716      MOV #ZSEKLOG,R1
3152 021622 001436      TST (SP)
3153 021624 005721      TST (R1)+
3154 021626 001005      BNE B5
3155 021630 005711      TST (R1)
3156 021632 001003      BNE B5
3157 021634 005721      TST (R1)+
3158 021636 005726      TST (SP)+
3159 021640 000767      HR 75
3160 021642 005202      INC R2
3161 021644 014137 021654      MOV #(R1),S05
3162 021650 004537 014446      JSR R5,SGLDEC
3163 021654 000000      OPEN
3164 021656 104400 015047      TYPE ,DBLSP
3165 021662 005721      TST (R1)+
3166 021664 012137 021674      MOV (R1)+,S15
3167 021670 004537 014446      JSR R5,SGLDEC
3168 021674 000000      OPEN
3169 021676 104400 015047      TYPE ,DBLSP
3170 021702 012637 021710      MOV (SP)+,135
3171 021706 104400      TYPE
3172 021710 000000      OPEN
3173 021712 104400 015052      TYPE ,MCRLF
3174 021716 000743      BR 75
3175 021720 104400 015052      TYPE ,MCRLF
3176 021724 013746 022516      MOV ZK0,-(SP)
3177 021730 012746 015015      MOV #MDOHR,-(SP)
3178 021734 012746 014527      MOV #MDEHDR,-(SP)
3179 021740 012746 016010      MOV #MWRITE,-(SP)
3180 021744 012746 015674      MOV #MREAD,-(SP)
3181 021750 012746 015644      MOV #MADCMC,-(SP)
3182 021754 012746 015736      MOV #MCRC,-(SP)
3183 021760 012746 015775      MOV #MSEEK,-(SP)
3184 021764 012701 017076      MOV #ZSEKLOG,R1
3185 021770 005716      TST (SP)
3186 021772 001437      HR 125
3187 021774 005721      HR 125
3188 021776 001005      BNE 115
3189 022000 005711      TST (R1)
3190 022002 001003      BNE 115
3191 022004 005721      TST (R1)+
3192 022026 005726      TST (SP)+

```

```

3193 022010 000767      HR 125
3194 022012 014137 022022      MOV #(R1),S25
3195 022016 004537 014446      JSR R5,SGLDEC
3196 022022 000000      OPEN
3197 022024 104400 015047      TYPE ,DBLSP
3198 022030 005721      TST (R1)+
3199 022032 012137 022042      MOV (R1)+,S35
3200 022036 004537 014446      JSR R5,SGLDEC
3201 022042 000000      OPEN
3202 022044 104400 015047      TYPE ,DBLSP
3203 022050 104400 015755      TYPE ,MUNXLC
3204 022054 012637 022062      MOV (SP)+,145
3205 022060 104400      TYPE
3206 022062 000000      OPEN
3207 022064 104400 015052      TYPE ,MCRLF
3208 022070 000737      BR 125
3209      ;PRINTS ERRORS PER ERROR CODES
3210 022072 005702      TST R2
3211 022074 001004      BNE B5
3212 022076 104400 015040      TYPE ,TAB
3213 022102 104400 016311      TYPE ,MNONE
3214 022106 005002      CLR R2
3215 022110 104400 015240      TYPE ,DBLLF
3216 022114 104400 016172      TYPE ,MCOUES
3217 022120 012700 000001      MOV #1,R0
3218 022124 012701 017132      MOV #EKCODE,R1
3219 022130 020027 000022      CMP R0,#22
3220 022134 001001      BNE S5
3221 022136 000427      BR TPTRK
3222 022140 005721      TST (R1)+
3223 022142 001002      BNE 15
3224 022144 005200      INC R0
3225 022146 000770      BR 25
3226 022150 014137 022160      MOV #(R1),45
3227 022154 004537 014446      JSR R5,SGLDEC
3228 022160 000000      OPEN
3229 022162 104400 015040      TYPE ,TAB
3230
3231 022166 010002      MOV R0,R2
3232 022170 006302      ASL R2
3233 022172 006302      ASL R2
3234 022174 006302      ASL R2
3235 022176 010246      MOV R2,-(SP)
3236 022200 104402      ;SAVE R2 FOR TYPEOUT
3237 022202 004      ;GO TYPE=OCTAL ASCII
3238 022203 001      ;TYPE 4 DIGIT(S)
3239 022204 104400 015052      ;TYPE LEADING ZEROS
3240 022210 005200      TYPE ,MCRLF
3241 022212 005721      INC R0
3242 022214 000745      TST (R1)+
3243      BR 25
3244 022216 005702      ;PRINTS TRACK ACCESS,HEAD MOVEMENT,AND ERRORS PER TRACK
3245 022220 001004      TST R2
3246 022222 104400 015040      BNE B5
3247 022226 104400 016311      TYPE ,TAB
3248 022232 104400 015240      TYPE ,MNONE

```

3249	022236	005737	022514		TST SHORTRPT	IF SHORT REPORT DON'T TYPE TRACK ACCESS OR ERRO
3250	022242	001121			BNE 05	
3251	022244	104400	016223		TYPE ,MTKLOG	TYPE FORMAT OF ERROR PRINT OUT
3252	022250	005037	022330		CLR 25	TRACK ADDRESS COUNTER
3253	022254	012704	017170		MOV #TKACC-4,R4	SET UP ADDRESS OF TRACK ACCESSED
3254	022260	012703	017654		MOV #HMOVE-4,R3	ADDRESS OF HEAD MOVEMENT COUNTER
3255	022264	012702	020344		MOV #UOTR,R2	UNIT 0 ERROR PER TRACK COUNTER
3256	022270	012701	020576		MOV #UITR,R1	UNIT 1 ERROR PER TRACK COUNTER
3257	022274	062704	000004	15:	ADD #4,R4	ADJUST FOR ADDRESS OF NEXT COUNTER
3258	022300	005714			TST (R4)	HAS THIS TRACK BEEN ACCESSED
3259	022302	001010			BNE 105	YES,PRINT OUT THE COUNTERS
3260	022304	005764	000002		TST 2(W4)	TEST UPPER WORD OF ACCESS COUNTER
3261	022310	001005			BNE 105	
3262	022312	062703	000004		ADD #4,R3	THIS TRACK HAS NOT BEEN USED, ADJUST
3263	022316	005722			TST (R2)+	REGISTERS TO POINT TO NEXT TRACK COUNTERS
3264	022320	005721			TST (R1)+	
3265	022322	000463			BR 125	TEST FOR LAST TRACK
3266	022324	004537	014446	105:	JSR #5,SGLDEC	TYPE TRACK NUMBER
3267	022330	000000		25:	OPEN	THIS LOCATION USED AS TRACK ADDR COUNTER
3268	022332	104400	016170		TYPE ,SPACE	
3269	022336	010446			MOV #4,-(SP)	TYPE TRACK ACCESSED COUNT
3270	022340	004737	014202		JSR PC,##SDB2D	
3271	022344	004737	014376		JSR PC,RTJUST	
3272	022350	104400	016170		TYPE ,SPACE	
3273	022354	062703	000004		ADD #4,R5	TYPE HEAD MOVED TO COUNT
3274	022360	010306			MOV #3,-(SP)	
3275	022362	004737	014202		JSR PC,##SDB2D	
3276	022366	004737	014376		JSR PC,RTJUST	
3277	022372	104400	015047		TYPE ,DBLSP	
3278	022376	104400	016170		TYPE ,SPACE	
3279	022402	005712			TST (R2)	ARE THERE ANY UNIT 0 ERRORS
3280	022404	001421			BNE 205	NO,CHECK UNIT 1
3281	022406	012237	022416		MOV (R2)+,55	TYPE UNIT 0 ERRORS
3282	022412	004537	014446		JSR #5,SGLDEC	
3283	022416	000000		35:	OPEN	
3284	022420	005711			TST (R1)	ARE THERE ANY UNIT 1 ERRORS
3285	022422	001420			BNE 75	NO,GO ADJUST POINTERS
3286	022424	104400	016170		TYPE ,SPACE	
3287	022430	104400	015047	225:	TYPE ,DBLSP	
3288	022434	012137	022444		MOV (R1)+,45	TYPE UNIT 1 ERRORS
3289	022440	004537	014446		JSR #5,SGLDEC	
3290	022444	000000		45:	OPEN	
3291	022446	002407			BR 115	GO TO NEXT TRACK
3292						
3293	022450	005722		205:	TST (R2)+	NO ERRORS,ADJUST REG.FOR NEXT COUNTER
3294	022452	005711			TST (R1)	ARE THERE ANY UNIT 1 ERRORS
3295	022454	001403			BNE 75	NO,GO TO NEXT TRACK
3296	022456	104400	015040		TYPE ,TAB	YES,TYPE TAB FOR PLACEMENT
3297	022462	000762			BR 225	GO TYPE THE NUMBER
3298	022464	005721		75:	TST (R1)+	NO ERRORS,ADJUST REG. FOR NEXT COUNTER
3299	022466	104400	015052	115:	TYPE ,MCRLF	
3300	022472	005237	022330	125:	INC 25	
3301	022476	023727	022330	000115	CMP 25,#115	HAVE ALL TRACK ERRORS BEEN TYPED
3302	022504	001273			BNE 15	NO,TYPE THE NEXT ONE
3303	022506	005037	022514	65:	CLR SHORTRPT	SET UP FOR LONG REPORT
3304	022512	000000		HLT17:	HALT	YES DONE

3305						
3306	022514	000000		SHORTRPT:	0	
3307	022516	000000		ZERO:	0	
3308						
3309		000001		.END		







MSEEK	015775	869	2847#	3149	3183																	
MSEQ	015254	1572	2756#																			
MSHORT	016076	2867#	3057																			
MSLASH	016165	2884#	3086	3092																		
MSUM	016327	1251	2910#																			
MTEST	015250	1566	2754#																			
MTKLOG	016223	2094#	3251																			
MTRK	014555	1545	2666#																			
MUKNIN	015312	1473	2764#																			
MUNIT0	015106	639	1557	1584	2724#	3135																
MUNIT1	015116	642	1559	1591	2727#	3136																
MUNREC	015755	566	789	863	1055	1073	1107	1273	2843#	3114	3203											
MUNX00	010462	1123	2651#	3142																		
MWRITE	016010	825	826	836	837	847	864	968	1074	2850#	3145	3179										
MWRTEB	016154	2881#	3085																			
NEWTRK	011562	1928	1931	1942	1944	1972	1974	1981#	2000	2005	2016	2032	2034	2058								
NEXTRO	004450	972	974#	993	1059	1112																
NOERLO	017030	1478#	2971#	3117	3119																	
NOERTY	006170	1201	1205	1232#																		
NOINTE	007204	811	946	1443#																		
NOPRNT	007502	1495	1503#																			
NOSEL	001676	500	523#																			
OD	001200	244#	245	575	580	584	593	622#	1855#	1856	1859#	1860	1864	1868#								
		1924#	1927	1940#	1951	1953#	1968#	1969	1971	2001	2003#	2015	2023	2025#								
		2028	2033	2044#																		
ODCOMP	012062	2048	2051#	2054																		
ODNEXT	012012	2029	2033#																			
OD2BIG	016363	621	2918#																			
ONEWRT	003130	749#	831	858	1067																	
OPCOND	001702	502	505	507	524#																	
OPEN	000000	170#	586	591	609	614	774	790	873	1221	1250	1511	1548	1553								
		1829	2638	3068	3078	3104	3112	3121	3129	3163	3168	3172	3196	3201								
		3206	3228	3267	3283	3290																
PARLOG	017024	464	554#	770#	2969#	3140	3102															
PARTES	003244	767	770#	828	985	1195																
PASCTE	021042	406	1509	1810#	1827	3039#	3070	3076														
PAT	010420	547#	548#	549#	550#	551#	1561	1653	1655#	1656	1672#	1834										
PATGEN	010426	1681#	1682	1691																		
PAT125	010514	1666	1726#																			
PAT314	010534	1667	1741#																			
PC	0000007	72#	487#	493#	503#	510#	513#	521#	523#	564#	582#	624#	619#	633#								
		644#	651#	652#	660#	663#	667#	677#	705#	736#	737#	738#	739#	740#								
		743#	746#	747#	750#	758#	809#	810#	817#	836#	841#	843#	848#	857#								
		860#	865#	867#	875#	884#	894#	896#	901#	915#	916#	917#	918#	919#								
		920#	923#	931#	932#	944#	945#	953#	963#	970#	973#	976#	992#	995#								
		999#	1003#	1020#	1029#	1046#	1052#	1069#	1084#	1086#	1092#	1104#	1110#	1116#								
		1119#	1125#	1135#	1136#	1157#	1158#	1139#	1140#	1143#	1153#	1160#	1168#	1187#								
		1216#	1241#	1259#	1261#	1267#	1270#	1278#	1281#	1295#	1296#	1297#	1298#	1299#								
		1302#	1312#	1313#	1314#	1315#	1316#	1319#	1331#	1332#	1333#	1334#	1335#	1336#								
		1337#	1338#	1339#	1342#	1350#	1362#	1363#	1364#	1365#	1366#	1371#	1372#	1373#								
		1376#	1398#	1429#	1453#	1477#	1488#	1491#	1518#	1520#	1524#	1530#	1536#	1538#								
		1577#	1603#	1606#	1622#	1681#	1704#	1727#	1749#	1751#	1758#	1760#	1785#	1792#								
		1805#	1808#	1836#	1842#	1846#	1869#	1987#	2045#	2076#	2098#	2111#	2152#	2159#								
		2166#	2180#	2182#	2371#	2530#	2552#	2555#	2592#	2597#	2641#	2646#	2647#	3045#								
		3062#	3090#	3091#	3094#	3095#	3270#	3271#	3275#	3276#												
PCONT	003332	766#	786#	827#	984#	1144#																

PIRQ	017772	58#																			
PIRQVE	000240	152#																			
PRESCB	012102	2052	2055#																		
PRESTR	011362	676#	871	1892#	1914#	1925	1969	2028	2055												
PRETRY	017016	749#	783#	784	800#	935#	2963#														
PR0	000000	75#																			
PR1	000040	76#																			
PR2	000100	77#																			
PR3	000140	78#																			
PR4	000200	79#	168#	754																	
PR5	000240	80#																			
PR6	000300	81#																			
PR7	000340	82#	169#	438	701	1393															
PS	017776	55#	56																		
PSW	017776	56#																			
PTYP1	003262	764#	774#	825#	982#	1142#															
PTYP2	003352	765#	790#	826#	983#	1143#															
PWRVCC	000024	147#	2498#	2499#	2508#	2514#	2526#	2527#													
P2RETR	017014	494#	560#	657#	1486#	2962#															
RANDAT	010544	1666	1749#	1752																	
RANGEN	012122	1749	2045	2060#																	
RANUM	012214	1750	2046#	2047	2049#	2051	2053#	2055	2057	2075#	2080#										
RAN1	012210	462#	2061	2067#	2072	2078#															
RAN2	012212	463#	2062	2069	2074#	2079#															
RDAFTW	004122	710#	904#	914#	1049	1134#	1530#	1361#	1369#												
RDCBK	006444	723	1295#																		
RDCBR	010406	2430	2490#																		
RDCNTR	021034	942#	943#	3035#	3093																
RDCODE	010200	667	1601#																		
RDDONE	004316	939	950#																		
RDER	000017	160#	1487	1602																	
RDERH	004460	940	978#																		
RDI	000107	165#	941																		
RDLIN	0104407	2491#																			
RDL0G	017054	2982#																			
RDOONLY	006504	724	1312#																		
RDRTR	017004	468	707#	950	955#	1042#	1048#	2958#													







.SRAND 1#  
 .SRDUE 1#  
 .SRDOC 1#  
 .SREAC 1# 5# 2315  
 .SRAZ 1#  
 .SSAVE 1# 6# 2270  
 .SSR20 1# 6# 2539  
 .SSB20 1#  
 .SSCOP 1#  
 .SSIZE 1#  
 .SSUPR 1#  
 .STRAP 1# 6# 2458  
 .STYPB 1#  
 .STYFD 1#  
 .STYPE 1# 5# 2114  
 .STYFO 1# 5# 2193  
 .S40CA 1#  
 .1170 1#

ADC	808	891	943	1431	1986	2587										
ADD	807	866	879	882	889	890	942	1058	1066	1171	1180	1181	1430	1476	1499	
	1537	1754	1804	1904	1985	2053	2061	2062	2072	2105	2109	2141	2221	2231	2356	
	2365	2553	2586	2588	3043	3257	3262	3273								
ASL	717	878	867	888	1658	1899	1955	1982	1983	2027	2379	2380	2381	2470	3232	
	3233	3234														
ASLB	1183															
BCC	1702															
BEQ	444	503	512	516	532	561	576	579	596	599	601	662	785	805	823	
	856	881	951	961	980	1017	1043	1064	1080	1101	1114	1203	1207	1240	1243	
	1253	1266	1277	1381	1400	1408	1427	1463	1490	1495	1529	1605	1707	1757	1817	
	1824	1840	1970	2056	2144	2179	2248	2336	2363	2378	2631	3042	3055	3064	3101	
	3109	3118	3126	3152	3186	3280	3285	3295								
BGE	670	1959	2052	2107												
BGT	1205	2255	2375	2416												
BHI	578	581	598	603												
BIC	533	541	543	551	1218	1382	1551	1587	1594	1783	1790	1833	1855	1924	1940	
	1953	1968	2025	2044	2046	2063	2073	2245	2332	2349	2376	2403	2409	2417		
BICB	711	1651	1893	1998	2003											
BIS	498	520	1091	1118	1152	1159	1197	1384	1485	1784	1791	1868	2250	2251	2383	
	2590															
BISB	718	892	1659	1900												
BIT	488	499	504	515	655	661	772	781	804	822	845	853	880	979	986	
	1026	1014	1032	1040	1061	1079	1088	1098	1113	1121	1200	1202	1245	1263	1377	
	1380	1426	1445	1462	1465	1471	1480	1489	1504	1521	1528	1555	1604	1779	1788	
	1802	1816	1823	3041												
BITB	511	1081	1405	1467	1582	2006	2107									
BLE	2048															
BLOS	2429															
BLT	2158	2256	2373	2414	2583											
BMI	1461	1533	1596													
BNE	451	453	467	471	489	505	530	594	618	629	647	656	672	713	742	
	773	782	814	816	846	854	922	975	987	1001	1007	1015	1033	1041	1050	
	1062	1082	1089	1099	1122	1142	1155	1173	1201	1246	1264	1301	1318	1341	1368	
	1375	1378	1404	1416	1433	1446	1466	1468	1472	1481	1505	1522	1556	1583	1654	
	1780	1789	1803	1812	1835	1838	1857	1895	1926	2007	2014	2029	2087	2138	2146	
	2154	2160	2175	2246	2328	2334	2354	2361	2368	2405	2411	2433	2439	2518	2594	
	2633	3071	3081	3154	3188	3188	3190	3211	3220	3223	3223	3245	3259	3261	3302	
BPL	492	497	502	519	525	638	641	666	779	851	972	997	1012	1038	1096	
	1209	1212	1234	1397	1451	1589	1782	1787	1801	1939	1952	1996	2002	2024	2132	
	2172	2244	2330	2346	2401	2407										
BR	210	211	212	445	455	507	514	534	592	616	623	626	664	719	744	
	761	924	993	1075	1124	1144	1175	1210	1255	1303	1320	1343	1383	1385	1492	
	1525	1527	1531	1558	1607	1661	1682	1691	1710	1718	1729	1742	1752	1819	1903	
	1928	1931	1942	1944	1960	1972	1974	2000	2005	2010	2016	2032	2034	2050	2054	
	2058	2134	2151	2161	2170	2177	2222	2237	2258	2357	2384	2386	2412	2435	2510	
	2534	2585	2635	3058	3074	3159	3174	3193	3208	3221	3225	3242	3265	3291	3297	
CLC	539	1705	2064													
CLR	465	495	574	622	625	706	709	710	753	898	938	1157	1158	1161	1164	
	1280	1369	1592	1409	1412	1424	1652	1680	1717	1809	1832	1861	1863	2068	2235	
	2343	2344	2516	2579	3140	3214	3252	3303								
CLRB	506	1859	2093	2150	2176	2440	2595									
CMP	443	446	452	466	470	950	960	1204	1399	1756	1834	2327	2333	2353	2360	
CMPB	2372	2374	2404	2410	2413	2415	2428	2589	3219	3301						
	529	577	580	597	602	617	688	1172	1925	1969	2013	2028	2047	2051	2055	
	2106	2143	2145	2153	2174	2178	2335	2367	2432	2438	2632					

COM	914	1065	1134	1330	1361	1597									
COMB	1728														
DEC	560	671	716	741	783	815	855	921	974	1016	1042	1063	1100	1141	1265
DEC	1276	1300	1317	1340	1367	1374	1657	1898	1943	1954	2011	2026	2031	2592	
DEC	2157	2160	2243	2254											
EMT	47														
HALT	174	538	570	649	674	780	852	1013	1026	1039	1097	1235	1418	1435	1452
INC	1831	2133	2509	2533	3304										
INC	554	565	632	704	760	770	787	842	861	883	954	964	998	1004	1021
INC	1033	1047	1053	1070	1085	1105	1117	1174	1198	1228	1236	1260	1271	1401	1415
INC	1443	1469	1478	1502	1703	1810	1815	1837	1867	1930	1997	2008	2088	2092	2110
INC	2249	2257	2382	2517	2584	3160	3224	3240	3300						
INC	2180														
IOT	48														
JMP	213	214	215	552	571	650	675	720	721	722	723	724	725	726	767
JMP	786	793	811	818	819	828	858	946	985	1018	1044	1059	1067	1102	1112
JMP	1156	1195	1237	1268	1279	1464	1542	1590	1598	1662	1663	1664	1665	1666	1667
JSR	1668	1904	1905	1906	1907	1908	1909	1910							
JSR	487	493	503	510	513	523	582	585	590	604	608	613	644	651	660
JSR	663	667	705	736	737	738	739	740	743	746	747	750	758	809	810
JSR	838	841	843	848	857	860	865	872	894	896	915	916	917	918	919
JSR	920	923	931	932	944	945	955	963	970	992	995	999	1003	1020	1029
JSR	1046	1052	1069	1084	1086	1092	1104	1110	1116	1119	1135	1136	1137	1138	1139
JSR	1140	1143	1153	1160	1160	1216	1220	1249	1259	1261	1267	1270	1278	1295	1296
JSR	1297	1298	1299	1302	1312	1313	1314	1315	1316	1319	1331	1332	1333	1334	1335
JSR	1336	1337	1338	1339	1342	1358	1362	1365	1364	1365	1366	1371	1372	1373	1376
JSR	1453	1488	1491	1510	1518	1520	1524	1530	1536	1547	1552	1603	1606	1681	1704
JSR	1727	1749	1751	1808	1828	1836	1842	2045	2152	2159	2166	2371	2552	2646	2647
JSR	3062	3067	3077	3090	3091	3094	3095	3103	3111	3120	3128	3182	3187	3195	3200
MOV	3227	3266	3270	3271	3275	3276	3282	3289							
MOV	436	437	438	439	442	447	448	458	459	460	461	462	463	464	468
MOV	469	473	478	483	494	509	540	542	547	556	657	658	659	676	702
MOV	701	702	707	708	714	715	748	749	751	752	754	755	757	764	765
MOV	766	800	801	802	825	826	827	831	836	837	840	859	871	877	886
MOV	893	899	933	934	935	936	937	939	940	952	955	962	965	982	983
MOV	984	989	990	991	1002	1019	1028	1045	1048	1051	1068	1071	1083	1103	1115
MOV	1162	1163	1165	1167	1179	1186	1192	1193	1194	1219	1223	1229	1248	1258	1269
MOV	1359	1360	1370	1379	1393	1394	1415	1422	1425	1428	1486	1487	1496	1509	1514
MOV	1523	1526	1546	1550	1561	1567	1573	1602	1611	1617	1655	1656	1660	1701	1814
MOV	1827	1839	1865	1896	1897	1956	1941	2057	2060	2067	2074	2075	2076	2097	2135
MOV	2136	2140	2155	2218	2226	2227	2228	2234	2241	2259	2269	2274	2275	2282	2288
MOV	2289	2290	2291	2292	2293	2294	2295	2296	2297	2306	2307	2308	2309	2310	2311
MOV	2310	2311	2312	2313	2340	2364	2369	2398	2399	2426	2427	2442	2443	2444	2445
MOV	2466	2467	2471	2498	2499	2500	2501	2502	2503	2504	2505	2506	2507	2508	2514
MOV	2515	2519	2520	2521	2522	2523	2524	2525	2526	2527	2530	2550	2551	2554	2571
MOV	2572	2573	2574	2575	2576	2577	2578	2627	2628	2629	2639	2640	2645	3052	3066
MOV	3076	3089	3093	3102	3110	3119	3127	3141	3142	3143	3144	3145	3146	3147	3148
MOV	3149	3150	3161	3166	3170	3176	3177	3178	3179	3180	3181	3182	3183	3184	3194
MOV	3199	3204	3217	3218	3226	3231	3235	3253	3254	3185	3181	3182	3183	3184	3194
MOV	456	584	589	607	612	759	803	806	895	697	941	1170	1177	1178	1182
MOV	1185	1227	1459	1493	1601	1608	1690	1699	1726	1741	1750	1755	1858	1860	1862
MOV	1864	1892	1927	1941	1971	1973	1994	2004	2009	2012	2015	2030	2033	2089	2090
MOV	2094	2108	2137	2165	2173	2219	2220	2223	2224	2225	2229	2232	2233	2252	2331
MOV	2348	2402	2408	2431	2436	2469	2591	2634	2636						
NEG	2230														
NEGB	1184														

NOP	1843	1844	1845												
RESET	435	1841													
RDL	548	549													
RDLB	1709		2065	2066	2236	2238	2239	2240	2242						
RDR	544	545	546	1497	1498	2070	2071			2264	2298	2314	2370	2418	2446
RTI	440	703	756	900	1166	1395	1414	1475	2102	2264	2298	2314	2370	2418	2446
RTS	521	564	619	633	652	677	817	867	875	884	901	973	976	1125	1187
RTS	1241	1281	1398	1429	1477	1538	1577	1622	1758	1760	1785	1792	1805	1846	1869
RTS	1987	2076	2098	2111	2182	2472	2555	2597	2641	2648	3045				
SBC	2581														
SEC	1700	1708													
SUB	1866	1957	1958	2049	2091	2095	2500	2502							
SWAB	550														
TRAP	2474	2483	2484	2485	2487	2489	2490	2491	2492	2493					
TST	450	491	501	531	575	595	628	640	646	665	712	763	778	784	813
TST	821	850	971	978	996	1000	1011	1037	1049	1095	1154	1191	1206	1233	1239
TST	1242	1411	1432	1450	1460	1494	1588	1653	1706	1759	1800	1811	1856	1894	1894
TST	2086	2139	2147	2169	2247	2362	2377	2468	3054	3063	3076	3100	3100	3108	3117
TST	3125	3151	3153	3155	3157	3158	3165	3185	3187	3189	3191	3192	3198	3210	3222
TST	3241	3244	3249	3258	3260	3263	3264	3279	3284	3293	3294	3298	3298		
TST	496	518	524	593	600	637	1208	1211	1252	1346	1532	1595	1781	1938	1951
TST	1995	2001	2023	2131	2171	2329	2345	2400	2406	2630					
.ASCII	2190	2191	2682	2689	2918	2930									
.ASCII	2192	2450	2451	2452	2454	2536	2651	2656	2661	2666	2670	2678	2677	2697	2702
.ASCII	2706	2709	2711	2713	2715	2717	2719	2724	2727	2730	2738	2741	2742	2744	2748
.ASCII	2750	2752	2754	2756	2758	2764	2768	2774	2777	2781	2784	2787	2794	2796	2797
.ASCII	2801	2804	2810	2815	2818	2822	2827	2829	2832	2835	2838	2843	2847	2850	2853
.ASCII	2857	2861	2864	2867	2870	2874	2878	2881	2884	2886	2888	2894	2905	2908	2910
.ASCII	2914	2925	2937	2943											
.ASCII	2449	2618	2955												
.BLKB	3007	3020	3023	3028	3031										
.BLKW	475	476	480	481	485	486	598	559	1516	1517	1563	1564	1569	1570	1575
.BYTE	1576	1613	1614	1619	1620	2186	2187	2188	2189	2265	2266	2267	2268	2447	2448
.DSABL	2387														
.ENABL	1	4	2320												
.END	3309														
.ENDC	15														
.IF	476	477	139	153	195	208	214	251	271	289	349	414	432	452	458
.IF	1148	1209	1307	1325	1347	1389	1456	1517	1518	1564	1565	1570	1571	1576	1130
.IF	1614	1615	1620	1621	1626	1648	1676	1685	1694	1713	1721	1736	1745	1756	1577
.IF	1851	1874	1891	1920	1934	1947	1964	1977	1991	2019	2				

	2456	2460	2466	2470	2474	2483	2484	2485	2486	2487	2489	2490	2491	2492	2493
	2494	2496	2506	2507	2512	2519	2524	2528	2530	2532	2536	2541	2559	2620	2950
.IFF	3050	3237	3238												
	47	195	219	251	271	289	344	414	432	475	476	480	481	486	559
	680	699	731	749	909	927	1130	1148	1289	1307	1325	1347	1389	1456	1517
	1564	1570	1576	1614	1620	1626	1648	1676	1685	1694	1715	1721	1736	1745	1765
	1778	1851	1874	1891	1920	1934	1947	1964	1977	1991	2019	2039	2083	2117	2196
	2273	2318	2323	2391	2393	2398	2414	2420	2429	2433	2450	2461	2467	2497	2513
.IFT	2530	2542	2560	2621	2451	3051	3258								
.IFTF	2338	2398													
.IIF	2338	2391	2394												
	10	15	20	21	474	479	484	557	1515	1562	1568	1574	1612	1618	2184
	2185	2186	2187	2188	2189	2190	2191	2192	2193	2318	2319	2341	2442	2450	2456
.IRP	2457	2458	2482	2483	2484	2485	2487	2489	2490	2491	2492	2493	3256		
.LIST	208	2288	2308	2500	2506	2514	2520								
	1	3	153	174	208	2019	2474	2482	2483	2484	2485	2486	2467	2488	2489
.MACRO	2490	2491	2492	2493	2494										
.MCALL	1	2474													
.NLIST	5	6	153												
	1	2	153	174	208	2419	2474	2482	2483	2484	2485	2486	2487	2488	2489
.REPT	2490	2491	2492	2493	2494										
.SBTTL	174														
.TITLE	43	449	2114	2193	2270	2315	2458	2474	2494	2539	2557				
.WORD	10														
	173	187	344	345	346	1225	2181	2184	2185	2269	2318	2319	2529	2531	2556
	2593	3034	3035												

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

\*DZRKA,SEQ/SOL/CRF=SYSMAC,SML,DZRKA,P11  
 RUN-TIME: 42 44 6 SECONDS  
 RUN-TIME RATIO: 375/95=4.0  
 CORE USED: 34K (67 PAGES)