

IDENTIFICATION

Product Code: MAINDEC-08-D2PE-D
Product Name: Family-of-8 ASR 33/35
Teletype Tests Part 1 of 2
Date Created: February 21, 1969
Maintainer: Diagnostic Group

C

C

C

1. ABSTRACT

The Family-of-8 ASR33/35 Teletype Tests Part I is the first part of a two part package used to test the ASR33, ASR33TY, or ASR35 Teletype when attached to a Family-of-8 system.

Part I contains nine selectable programs numbered from 0 to 10 (octal). The programs are selected by means of the switch register (SR).

The programs available are:

PRG0	Basic Input Logic Tests
PRG1	Basic Output Logic Tests
PRG2	Reader Test
PRG3	Test Tape Generator. Punches tape with characters stored in locations 0021 and 0022.
PRG4	Test Tape Generator. Punches Binary Count Pattern test tape.
PRG5	Reader Exerciser. Reads Binary Count pattern tape in random length blocks, and with fixed stalls between characters. The stall is determined at random.
PRG6	Reader Exerciser. Reads Binary Count pattern tape. Fixed stall between characters. Stall count is taken from LOC 0023.
PRG7	Reader Exerciser. Reads tape punched with any 2 test characters. Random length blocks and fixed stall between characters. The stall is determined at random.
PRG10	Reader Exerciser. Reads tape punched with any 2 test characters. Fixed stall between characters. Stall count taken from LOC 0023.
PRG11	ASR33TY Automatic Reader option test. Checks for correct response to READER ON, and READER OFF commands.
PRG12	ASR33TY Automatic Punch option test. Checks for correct response to PUNCH ON and PUNCH OFF commands

2. REQUIREMENTS

2.1 Equipment

Standard PDP-8/S, PDP-8 or PDP-8/I with ASR33, ASR33TY, or ASR35 Teletype.

NOTE

Programs PRG0 through PRG10 are not written specifically for the ASR33TY Teletype. Whenever these programs are run, be sure to lock the punch and reader in their ON position. In the case of the reader, use a heavy rubber band to keep the reader switch in the ON position.

2.2 Storage

Locations 0000 through 2341 are used.

3. LOADING PROCEDURE

3.1 Method

The Binary Loader is used to load the program.

4. STARTING PROCEDURE (PRG0)

4.1 Control Switch Settings (PRG0)

SR0	Halt at end of routine. Routine number in AC.
SR1	Select routine whose number is set in SR6 through SR11.
SR2	Loop program.
SR6 through SR11	Routine number to be selected.

4.2 Starting Addresses (PRG0)

This program starts at LOC 0200.

4.3 Program and/or Operator Action (PRG0)

- a. Insure Teletype is on-line.
- b. Load binary count pattern test tape in reader.
- c. Turn on reader.
- d. Load address 0200.
- e. Set SR to 0000.
- f. Press START.
- g. Program halts at LOC 0232 to permit setting of options.
- h. Select desired options, if any, in SR. For normal run SR should be 0000. Press

CONTINUE.

- i. Program is executed and halts at LOC 0274, program end halt, if no loop options are selected and if no errors occur.

5. OPERATING PROCEDURE (PRG0)

5.1 Program and/or Operator Action (PRG0)

5.1.1 Normal Halts (PRG0)

LOC 0232	SR SET halt. Occurs to permit setting of desired options.
LOC 0274	Program end halt. Occurs if no "loop program" option is set. Set desired options and press CONTINUE. If no options are set, this halt reoccurs.
LOC 0320	Routine end halt. Occurs at end of routine if SR0 = 1. To proceed, press CONTINUE.

6. ERRORS (PRG0)

6.1 Error Halts and Description (PRG0)

LOC 0177	Incorrect program number selected. Set SR to 0000 and press CONTINUE.
LOC 0255	Nonexistent routine selected. Set correct routine number in SR6 through SR11 and press CONTINUE.
LOC 1221	PRG0, routine 0 error halt. KCC instruction failed to clear the AC. Pressing CONTINUE enters scope loop that sets AC to all 1s, issues KCC to clear AC, and repeats. Manual restart.
LOC 1244	PRG0, routine 1 error halt. 200 ms after KRB instruction the flag is not set, or KSF instruction failed to skip on flag = 1. Pressing CONTINUE repeats the test.
LOC 1267	PRG0, routine 2 error halt A. Same as PRG0, routine 1 error halt.
LOC 1271	PRG0, routine 2 error halt B. KSF instruction failed to skip with flag = 1. Pressing CONTINUE enters scope loop that skips on flag continuously. Manual Restart.
LOC 1320	PRG0, routine 3 error halt A. Same as PRG0, routine 1 error halt.
LOC 1322	PRG0, routine 3 error halt B. KCC failed to reset, or KSF instruction skipped with flag = 0. Pressing CONTINUE enters scope loop that clears the flag and skips on flag continuously. Manual restart.
LOC 1345	PRG0, routine 4, error halt A. Unexpected interrupt. Turn off any device that may be causing an interrupt (other than the Teletype). Pressing CONTINUE repeats the test.
LOC 1362	PRG0, routine 4, error halt B. With reader flag = 1 and interrupt enabled, no interrupt occurred. Pressing CONTINUE enters scope loop that turns on interrupt continuously. Manual restart.
LOC 1417	PRG0, routine 5, error halt. Timing error. Flag not = 1 110 ms after KRB command. Pressing CONTINUE enters scope loop that reads tape continuously to aid in timing adjustment. Manual restart.

- LOC 1457 PRG0, routine 6, error halt A. Reread error. A reread of the Teletype buffer did not match with the original read. New character is displayed in AC. Press CONTINUE.
- LOC 1462 PRG0, routine 6, error halt B. Follow up halt to PRG0, routine 6, error halt A. The "old" character is displayed in AC. Pressing CONTINUE enters scope loop that reads the teletype buffer continuously. Manual restart.

4A. STARTING PROCEDURES (PRG1)

4.1A Control Switch Settings (PRG1)

- SR0 Halt at end of routine. Routine number in AC.
- SR1 Select routine whose number is set in SR6 through SR11.
- SR2 Loop program.
- SR6 through SR11 Routine number to be selected.

4.2A Starting Addresses (PRG1)

This program starts at LOC 0200.

4.3A Program and/or Operator Action (PRG1)

- a. Insure Teletype is on-line.
- b. Insure reader is off.
- c. Insure that there is paper in teleprinter.
- d. Load address 0200.
- e. Set SR to 0001.
- f. Press START.
- g. Program halts at LOC 0232 to permit setting of options.
- h. Select desired options, if any, in SR. For normal run SR should be 0000. Press CONTINUE.
- i. Program is executed and halts at LOC 0274, program end halt, if no loop options are selected and if no errors occur.

5.A OPERATING PROCEDURE (PRG1)

5.1A Program and/or Operator Action (PRG1)

5.1.1A Normal Halts (PRG1)

- LOC 0232 SR SET halt. Occurs to permit setting of desired options. Press CONTINUE.
- LOC 0274 Program end halt. Occurs if no "loop program" option is set. Set desired options and press CONTINUE. If no options are set, the halt reoccurs.
- LOC 0320 Routine end halt. Occurs at end of routine if SRO = 1. To proceed, press CONTINUE.

6.A ERRORS (PRG1)

6.1A Error Halts and Description (PRG1)

- LOC 0177 Incorrect program number selected. Set SR to 0001 and press CONTINUE.
- LOC 0255 Nonexistent routine selected. Set correct routine number in SR6 through SR11 and press CONTINUE.
- LOC 1627 PRG1, routine 0, error halt A. 200 ms after TLS command the flag is not 1, or TSF command failed to skip. Pressing CONTINUE repeats the test.
- LOC 1631 PRG1, routine 0, error halt B. With flag = 1, TSF command failed to skip. Pressing CONTINUE enters scope loop that skips on flag continuously. Manual restart.
- LOC 1651 PRG1, routine 1 error halt. TCF command failed to clear flag, or TSF command skipped with flag = 0. Pressing CONTINUE enters scope loop that clears the flag and then skips on flag continuously. Manual restart.
- LOC 1676 PRG1, routine 2 error halt. TCF command failed to clear flag. Pressing CONTINUE enters scope loop that issues TCF command continuously. Manual restart.
- LOC 1717 PRG1, routine 3, error halt A. Unexpected interrupt. Turn off any device that may be causing an interrupt. (The teletype reader must be off). Press CONTINUE to repeat test.
- LOC 1734 PRG1, routine 3, error halt B. With flag = 1, and interrupt enabled, no interrupt occurred. Pressing CONTINUE enters scope loop that turns on interrupt continuously. Manual restart.
- LOC 1765 PRG1, routine 4 error halt. Timing error. Flag not 1 110 ms after TLS command. Pressing CONTINUE enters scope loop that runs the printer/punch continuously, to aid in timing adjustment. Manual restart.

4.B STARTING PROCEDURES (PRG2)

4.1B Control Switch Settings (PRG2)

SR0	Halt at end of routine. Routine number in AC.
SR1	Select routine whose number is set in SR6 through SR11.
SR2	Loop program.
SR6 through SR11	Routine number to be selected.

4.2B Starting Addresses (PRG2)

This program starts at LOC 0200.

4.3B Program and/or Operator Action (PRG2)

- a. Insure Teletype is on-line.
- b. Load binary count pattern test tape in reader.
- c. Turn on reader.
- d. Load address 0200.
- e. Set SR to 0002.
- f. Press START
- g. Program halts at LOC 0232 to permit setting of options.
- h. Set desired options, if any, in SR. For normal run, SR should be 0000. Press CONTINUE.
- i. Program is executed and halts at LOC 0274, program end halt, if no loop options are set, and if no errors occur.

5.B OPERATING PROCEDURE (PRG2)

5.1B Program and/or Operator Action (PRG2)

5.1.1B Normal Halts (PRG2)

LOC 0232	SR SET halt. Occurs to permit setting of desired options. Press CONTINUE.
LOC 0274	Program end halt. Occurs if no "loop program" option is set, set options and press CONTINUE. If no options are set, this halt reoccurs.
LOC 0320	Routine end halt. Occurs at end of routine if SR0 = 1. To proceed press CONTINUE.

6.B ERRORS (PRG2)

6.1B Error Halts and Description (PRG2)

LOC 0177	Incorrect program number selected. Set SR to 0002 and press CONTINUE.
LOC 0255	Nonexistent routine selected. Set correct routine number in SR6 through SR11 and press CONTINUE.
LOC 0564	Unable to sync. Sync subroutine has not found an all 1's character within 256 characters. Press CONTINUE to retry.
LOC 2030	PRG2, routine 0, error halt A. Read error. Bad character in AC. Press CONTINUE.
LOC 2033	PRG2, routine 0, error halt B. Follow up halt. Expected character in AC. Pressing CONTINUE resumes test.
LOC 2062	PRG2, routine 1, error halt A. Read error. Bad character in AC. Press CONTINUE.
LOC 2065	PRG2, routine 1, error halt B. Follow up halt. Expected character in AC. Pressing CONTINUE resumes test.
LOC 2120	PRG2, routine 2, error halt A. Read error. Bad character in AC. Press CONTINUE.
LOC 2123	PRG2, routine 2, error halt B. Follow up halt. Expected character AC. Pressing CONTINUE resumes test.

4.C STARTING PROCEDURES (PRG3)

4.1.C Control Switch Settings (PRG3)

None

4.2C Starting Addresses (PRG3)

This program starts at LOC 0200.

4.3C Program and/or Operator Action (PRG3)

- a. Insure Teletype is on-line.
- b. Turn off teletype reader.
- c. Load blank tape in punch.
- d. Turn on punch.
- e. Deposit in LOC 0021 and 0022 (8), the 8-bit code for characters to be punched.
- f. Load address 0200.
- g. Set SR to 0003.

- h. Press START.
- i. Program punches tape until stopped by user.

5.C OPERATING PROCEDURE (PRG3)

5.1C Program and/or Operator Action (PRG3)

5.1.1C Normal Halts (PRG3)

None

6.C ERRORS (PRG3)

6.1C Error Halts and Description (PRG3)

LOC 0177 Incorrect program number selected. Set SR to 0003 and press
CONTINUE.

4.D STARTING PROCEDURES (PRG4)

4.1D Control Switch Settings (PRG4)

None

4.2D Starting Addresses (PRG4)

This program starts at LOC 0200.

4.3D Program and/or Operator Action (PRG4)

- a. Insure Teletype is on-line.
- b. Turn off teletype reader.
- c. Load blank tape in punch.
- d. Turn on punch.
- e. Load address 0200.
- f. Set SR to 0004.
- g. Press START.
- h. Program punches binary count pattern test tape until stopped user.

5.D OPERATING PROCEDURE (PRG4)

5.1D Program and/or Operator Action (PRG4)

5.1.1D Normal Halts (PRG4)

None.

6.D ERRORS (PRG4)

6.1D Error Halts and Description (PRG4)

LOC 0177 Incorrect program number selected. Set SR to 0004 and press CONTINUE.

4.E STARTING PROCEDURES (PRG5)

4.1E Control Switch Settings (PRG5)

SR0 Halt. Program halts with accumulated error count in AC.

SR5 Halt on error. Program halts if read-error occurs.

4.2E Starting Addresses (PRG5)

This program starts at LOC 0200.

4.3E Program and/or Operator Action (PRG5)

a. Insure Teletype is on-line.

b. Load binary count pattern test tape in reader.

c. Turn on reader.

d. Load address 0200.

e. Set SR to 0005.

f. Press START.

g. Program runs continuously until stopped, unless a read error occurs with SR5 = 1, or SR0 is set to 1.

5.E OPERATING PROCEDURE (PRG5)

5.1E Program and/or Operator Action (PRG5)

5.1.1E Normal Halts

LOC 1115 Halt. Accumulated errors in AC. Occurs if SR0 = 1. Press CONTINUE to proceed.

6.E ERRORS (PRG5)

6.1E Error Halts and Description (PRG5)

LOC 0177 Incorrect program number selected. Set SR to 0005 and press CONTINUE.

LOC 1110 Read error halt. Occurs if SR5 = 1. Press CONTINUE to proceed.

4.F STARTING PROCEDURES (PRG6)

4.1F Control Switch Settings (PRG6)

SR0 Halt. Program halts with accumulated error count in AC.

SR5 Halt on error. Program halts if read error occurs.

4.2F Starting Addresses (PRG6)

This program starts at LOC 0200.

4.3F Program and/or Operator Action (PRG6)

- a. Insure Teletype is on-line.
- b. Load binary count pattern test tape in reader.
- c. Turn on reader.
- d. Deposit in LOC 0023 the desired stall count in 2's complement form. A count of -1 gives a 1ms stall, etc.
- e. Load address 0200.
- f. Set SR to 0006.
- g. Press START.
- h. Program runs continuously until stopped, unless a read error occurs with SR5 = 1, or SR0 is set to 1.

5.F OPERATING PROCEDURE (PRG6)

5.1F Program and/or Operator Action (PRG6)

5.1.1F Normal Halts (PRG6)

LOC 1115 Halt. Accumulated errors in AC. Occurs if SR0 = 1. Press CONTINUE to proceed.

6.F ERRORS (PRG6)

6.1F Error Halts and Description (PRG6)

LOC 0177 Incorrect program number selected. Set SR to 0006 and press CONTINUE.

LOC 1110 Read error halt. Occurs if SR5 = 1. Press CONTINUE to proceed.

4.G STARTING PROCEDURES (PRG7)

4.1G Control Switch Settings (PRG7)

SR0 Halt. Program halts with accumulated error count in AC.

SR5 Halt on error. Program halts if read error occurs.

4.2G Starting Addresses (PRG7)

This program starts at LOC 0200.

4.3G Program and/or Operator Action (PRG7)

- a. Insure Teletype is on-line.
- b. Load reader with 2-character test tape.
- c. Turn on reader.
- d. Deposit in location 0021 and 0022 the 8-bit codes for the character punched in the test tape.
- e. Load address 0200.
- f. Set SR to 0007.
- g. Press START
- h. Program runs continuously until stopped, unless a read error occurs with SR5 = 1, or SR0 is set to 1.

5.G OPERATING PROCEDURE (PRG7)

5.1G Program and/or Operator Action (PRG7)

5.1.1G Normal Halts (PRG7)

LOC 1115 Halt. Accumulated errors in AC. Occurs if SR0 = 1. Press CONTINUE to proceed.

6.G ERRORS (PRG7)

6.1G Error Halts and Description (PRG7)

LOC 0177 Incorrect program number selected. Set SR to 0007 and press CONTINUE.

LOC 1110 Read error halt. Occurs if SR5=1. Press CONTINUE to proceed.

LOC 1137 Align error halt. Insure that correct tape is used, and check Step 4.3Gd.

4.H STARTING PROCEDURES (PRG 10)

4.1H Control Switch Settings (PRG 10)

SR0 Halt. Program halts with accumulated error count in AC.

SR5 Halt on error. Program halts if read error occurs.

4.2H Starting Addresses (PRG 10)

This program starts at LOC 0200.

4.3H Program and/or Operator Action (PRG 10)

- a. Insure Teletype is on-line.
- b. Load reader with 2-character test tape.
- c. Turn on reader
- d. Deposit in LOC 0023 the desired stall count in 2's complement form. A count of -1 gives a 1 ms stall, etc.
- e. Load address 0200.
- f. Set SR to 0010.

- g. Press START.
- h. Program runs continuously until stopped, unless a read error occurs with SR5 = 1, or SR0 is set to 1.

5.H OPERATING PROCEDURE (PRG10)

5.1H Normal Halts (PRG 10)

LOC 1115 Halt. Accumulated errors in AC. Occurs is SR0 = 1. Press CONTINUE to proceed.

6.H ERRORS (PRG 10)

6.1H Error Halts and Description (PRG 10)

LOC 0177 Incorrect program number selected. Set SR to 0007 and press CONTINUE.

LOC 1110 Read error halt. Occurs if SR5 = 1. Press CONTINUE to proceed.

LOC 1137 Align error halt. Insure that correct tape is used, and check Step 4.3Hd.

4.I STARTING PROCEDURES (PRG 11)

4.1I Control Switch Settings (PRG 11)

None

4.2I Starting Addresses (PRG 11)

This program starts at LOC 0200.

4.3I Program and/or Operator Action (PRG 11)

- a. Insure that Teletype is on-line.
- b. Load reader with any test tape loop.
- c. Turn on reader by pushing the momentary contact switch to the START position.
- d. Make sure that teletype punch is not locked on.
- e. Load Address 0200.
- f. Set SR to 0011.
- g. Press START
- h. Program runs continuously until stopped, unless an error halt occurs.

5.I OPERATING PROCEDURE (PRG 11)

5.1I Normal Halts (PRG 11)

None

6.I ERRORS (PRG 11)

6.1I Error halts and Description (PRG 11)

- | | |
|----------|---|
| LOC 2212 | Reader flag not set after approximately 110 ms after KCC command issued after READER ON command. Probably the READER ON command failed to turn on the reader. Press CONTINUE to proceed. |
| LOC 2227 | Reader flag was set after approximately 110 ms after KCC command issued after READER OFF command. Probably the READER OFF command failed to turn off the reader. Press CONTINUE to proceed. |

4.J STARTING PROCEDURES (PRG 12)

4.1J Control Switch Settings (PRG 12)

None

4.2J Starting Addresses (PRG 12)

This program starts at LOC 0200.

4.3J Program and/or Operator Action (PRG 12)

a. With Teletype off-line, punch a section of blank leader about 6 inches long. Return Teletype to on-line position.

b. Load leader on reader, leaving very little slack between punch and reader.

c. Turn on reader by pushing the momentary contact switch to the START position.

d. Make sure that teletype punch is not locked on.

e. Load address 0200.

f. Set SR to 0012.

g. Press START

h. Program runs continuously until stopped, unless an error halt occurs.

5.J OPERATING PROCEDURE (PRG 12)

5.1J Normal Halts (PRG 12)

None

6.J ERRORS (PRG 12)

6.1J Error halts and Description (PRG 12)

LOC 2337	Reader failed to read a rubout. Reader failed to read correctly if character on tape is a rubout. If tape character is a rubout, the PUNCH FEED OFF command failed to stop the punch from feeding. Check for other similar failures. To be correct, the punched tape should contain all rubouts. Press CONTINUE to proceed.
----------	---

6.2J Other Errors (PRG 12)

Failure of the PUNCH FEED ON command will eventually be detected by the tightening of the slack between the reader and punch. The longer the program is run the better the chances are of detecting the problem, if present.

7. RESTRICTIONS

7.1 Starting Restrictions

All programs must be started at LOC 0200.

7.2 Operating Restrictions

PRG0 and PRG1 must be run prior to executing any other programs. Problems detected during execution of PRG0 and PRG1 should be corrected as they occur.

PRG11 must precede PRG12 execution.

8. MISCELLANEOUS

8.1 Execution Time

PRG0 execution time: 1 minute

PRG1 execution time: 20 seconds

PRG2 execution time: 18 minutes

PRG3 through PRG12 are continuous run programs.

8.2 Test Tapes

MAINDEC-08-D2G3-PT Binary Count Pattern test tape is provided with this program. For convenience in use, the tape should be spliced into a loop, making sure that the pattern is matched at the splice point.

9. PROGRAM DESCRIPTION

The Family-of-8 ASR33/35 Teletype Tests, Part 1, consists of 11 programs numbered from 0 to 12 (octal).

9.1 PRG0 - Basic Input Logic Tests

This program contains 7 routines numbered from 0 to 6 (octal).

RTN0 Checks that KCC command is able to clear the AC. Test is done 1000 times.

RTN1 Issues KCC, waits 200 ms and checks for flag = 1. A failure to skip on flag indicates that flag is not 1, or KSF command failure to skip.

- RTN2 Checks ability of KSF command to skip with flag = 1. Done 1000 times.
- RTN3 Checks that KSF command does not skip with flag = 0. Done 500 times.
- RTN4 Checks that no other device can cause an interrupt, and then checks that the reader is capable of interrupting.
- RTN5 Timing Test.
- RTN6 Reads a character from tape and saves it. It then rereads the TTI statically 1000 times to check for consistent reading from TTI. 256 characters are read in this manner.

9.2 PRG1 - Basic Output Logic Tests

This program contains five routines numbered from 0 to 4.

- RTN0 Issues TLS, waits 200 ms, and checks for flag = 1. A failure to skip indicates that flag is not 1, or KSF command failed. If this part is satisfied the routine skips on flag = 1, 1000 times. Failure to skip indicates TSF failure.
- RTN1 Checks that TSF command does not skip with flag = 0. Done 1000 times.
- RTN2 Checks that TCF command clears flag. Done 100 times.
- RTN3 Checks that no other device can cause an interrupt, and then checks that the printer/punch is able to interrupt.
- RTN4 Timing Test.

9.3 PRG2 - Reader Test

This program contains three routines numbered from 0 to 2.

- RTN0 Reads 4095 characters of binary count pattern, at full speed.
- RTN1 Reads 2000 characters of binary count patterns with random stalls between characters.
- RTN2 Reads 100 random-length character blocks. Fixed stall between characters in a block. Stall is changed for each block and is determined at random.

9.4 PRG3 - Test Tape Generator

This program punches test tape with characters whose code is stored in LOC 0021 and 0022.

9.5 PRG4 - Test Tape Generator

Punches binary count pattern test tape.

9.6 PRG5 - Reader Exerciser

This program reads binary count pattern test tape, in random length blocks, and with fixed stalls between characters. Stall is determined at random.

9.7 PRG6 - Reader Exerciser

Reads binary count pattern test tape. Fixed stall between characters. Stall count is taken from LOC 0023.

9.8 PRG7 - Reader Exerciser

Reads test tape punched with any two test characters, random length blocks, and fixed stall between characters. Stall is determined at random.

9.9 PRG10 - Reader Exerciser

Reads test tape punched with any two test characters. Fixed stall between characters. Stall count taken from LOC 0023.

9.10 PRG11 - ASR33TY Automatic Reader Option Test

Checks for correct response to READER ON, and READER OFF commands by checking for correct state of reader flag 110 ms after issuing KCC command which is preceded by one of the reader control commands.

The coder control commands used are:

READER ON - 221

READER OFF - 223

9.11 PRG12 - ASR33TY Automatic Punch Option Test

Checks for correct operation of PUNCH FEED ON and PUNCH FEED OFF commands by punching rubouts with the punch feed on, and all 0's characters with the punch feed off. The resulting tape should contain all rubouts. The tape is verified by running it through the reader at the same time.

The punch control commands used are:

PUNCH FEED ON - 222

PUNCH FEED OFF - 224

```
/FAMILY OF 8 ASR33/35 TELETYPE TESTS - PART 1
/
/COPYRIGHT 1969, DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASS.
/
/PRG0-BASIC INPUT CONTROL LOGIC TEST - (USES READER)
/PRG1-BASIC OUTPUT CONTROL LOGIC TEST - (USES PRINTER)
/PRG2-READER TEST
/PRG3-TEST TAPE GENERATOR, PUNCHES CONTENTS OF LOC 0021 AND 0022
/PRG4-TEST TAPE GENERATOR, PUNCHES BINARY COUNT PATTERN TEST TAPE
/PRG5-READER EXERCISER, READS BINARY COUNT PATTERN TEST TAPE IN RANDOM
/      LENGTH BLOCKS, STALLS WITH FIXED DELAY BETWEEN CHARACTERS, STALL
/      IS DIFFERENT FOR EACH BLOCK,
/PRG6-READER EXERCISER READS BINARY COUNT PATTERN, FIXED STALL BETWEEN CHARACTERS,
/PRG7-READER EXERCISER, READS TAPE PUNCHED BY PRG3, TEST DATA MUST BE STORED
/      IN LOC 0021 AND 0022, RANDOM LENGTH BLOCKS, FIXED STALL BETWEEN
/      CHARACTERS, STALL DIFFERENT FOR EACH BLOCK
/PRG10-SAME AS PRG7, BUT FIXED STALL BETWEEN CHARACTERS (NO RANDOM LENGTH BLOCKS)
/PRG11-ASR33TY AUTOMATIC READER OPTION TEST
/PRG12-ASR33TY AUTOMATIC PUNCH OPTION TEST
/
/SK OPTIONS
/
/SK0-HALT AT END OF ROUTINE, ROUTINE NUMBER IN AC
/SK1-SELECT ROUTINE WHOSE NUMBER IS SET IN SR6 TO SR11
/SK2-LOOP PROGRAM
/SK5-HALT ON ERROR
/SK6-SR11-ROUTINE NUMBER TO BE SELECTED,
```

/FAMILY-OF-8 ASRS3/35 TELETYPE TESTS-PART 1

0000	0000		
0001	5001	JMP 1	
0002	0002	2	
0003	0003	3	
	0005		*5
0005	5402	JMP 1 2	
0006	0000	2	
	0020		*20
0020	0000	KSTART, 0	/USER PROGRAM START,
0021	0000	PTEMP, 0	
0022	0000	PTEMP1, 0	
0023	0000	DELAYM, 0	
0024	0257	CHAIN, CHAINN	/CHAIN RTN ENTRY,
0025	0313	SHLT, SHALT	/HALT TEST ENTRY
0026	0322	SEICTR, SICTR	/SET COUNTER ENTRY
0027	0333	DLY1SC, DLYSC	/DELAY SECONDS ENTRY
0030	0345	DLY1MS, DLYMS	/DELAY MILLISECS ENTRY
0031	0232	SRST, SRSET	
0032	0400	RANDNO, RANGEN	
0033	0017	PRGMSK, 17	
0034	7766	PRGLIM, -12	
0035	0000	PRGNUM, 0	
0036	0037	PSW, PRGTAB	
0037	1200	PRGTAB, PRG0	
0040	1600	PRG1	
0041	2000	PRG2	
0042	1000	PRG3	
0043	1006	PRG4	
0044	1013	PRG5	
0045	1031	PRG6	
0046	1042	PRG7	
0047	1060	PRG10	
0050	2200	PRG11	
0051	2244	PRG12	

0052	0000	TEMP,	0	/WORK
0053	0000	TEMP1,	0	/LOCATIONS
0054	0077	ISIMSK,	77	/SR 6-11 ENABLE MASK
0055	0100	SR0MSK,	100	/SR5 MASK
0056	0000	CPID,	0	/IDENTIFIES CPU
0057	0000	CURTST,	0	/FOR CURRENT TEST ADDRESS
0060	0000	RTNNO,	0	/FOR CURRENT TEST NUMBER
0061	0000	NXTST,	0	/FOR NEXT TEST ADDRESS
0062	0000	SCCTR,	0	/SECONDS COUNTER
0063	0000	MSCTR,	0	/MILLISECONDS COUNTER
0064	0000	MILCTR,	0	
0065	0000	MIL1,	0	/FOR 1 MSEC CONSTANT
0066	7444	KP8,	-334	/PDP8 1 MSEC CONSTANT
0067	7764	KP8S,	-14	/PDP8S 1 MSEC CONSTANT
0070	0000	TEMQ,	0	/CONSTANTS
0071	0000	TEMR,	0	/FOR
0072	0000	FLAG,	0	/TYPE
0073	0077	K7/,	77	/CHARACTER
0074	7740	M40,	-40	/STRING
0075	0100	C100,	100	/SUBROUTINE
0076	0240	C240,	240	
0077	7500	SKIPMA,	SMA	
0100	7510	SKIPPA,	SPA	
0101	0000	CTRA,	0	/COUNTER A,
0102	0000	CTRB,	0	/COUNTER B,
0103	0000	SCNT,	0	
0104	7634	K100,	-144	
0105	2000	K2000,	2000	
		/		
0106	0546	SYNC,	SYNK	/ENTRY TO SYNC TAPE RTN,
0107	0444	INPATT,	INITPT	/ENTRY TO INITIATE PATTERN
0110	0453	GETPT,	GETPTT	/ENTRY TO GET PATTERN CHAR,
0111	0531	CHECK,	CHCK	
0112	0502	CRCNT,	CHRCNT	
0113	0520	DLYCNT,	DLCNT	
0114	0000	PFLAG,	0	
0115	0465	UPUNCH,	PUNCH	
0116	0600	UMOVE,	MOVE	
0117	7401	MRBOUT,	-377	

```

/CONTROL ROUTINE
* 177
0177 0177 HLT /INCORRECT PROGRAM NUMBER
0200 7604 START, LAS
0201 0033 AND PRGMSK
0202 1034 TAD PRGLIM
0203 7540 SVA SZA
0204 5177 JMP 177
0205 7604 LAS
0206 0033 AND PRGMSK
0207 3035 DCA PRGNUM
0210 1035 TAD PRGNUM
0211 1036 TAD PSW
0212 3052 DCA TEMP
0213 1452 TAD I TEMP
0214 3231 DCA PRGADR
0215 7350 ID, CLA CLL CMA RAR
0216 7710 SPA CLA
0217 5222 JMP ,+3
0220 1066 TAD KP8
0221 7410 SKP
0222 1067 TAD KP8S
0223 3065 DCA MIL1
0224 4516 JMS I UMOVE /INITIALIZE
0225 0005 5 /INTERRUPT,
0226 0001 1 /AREA,
0227 7776 =2
0230 5631 JMP I ,+1
0231 0000 PRGADR, 0
0232 7602 SRSET, HLT CLA

GETRDY, CLA
0233 7200 TAD KSTART /SET ADDRESS OF 1ST ROUTINE
0234 1020 DCA NXTST /STORE AT NXTST
0235 3061 JMS FORWD
0236 4276 LAS /READ SR
0237 7604 RAL
0240 7004 SMA /ROUTINE SELECT?
0241 7500 JMP I CURTST /NO, START WITH 1ST RTN
0242 5457 LAS /YES
0243 7604 AND TSTMSK
0244 0054 CIA
0245 7041 TAD RTNNO
0246 1060 SVA CLA /IS IT THIS RTN?
0247 7650 JMP I CURTST /YES, GO DO IT
0250 5457 TAD NXTST /NO
0251 1061 IAC /IS THIS LAST TRY?
0252 7001 SVA CLA /NO
0253 7640 JMP GETRDY+3
0254 5236 INCRTN, HLT
0255 7402 /YES, INCORRECT ROUTINE NO,
0256 5233 JMP GETRDY

```


0257	4313	CHAINN, JMS SHALT	/HALT? (SR0)
0258	7604	LAS	/READ SR
0259	7006	RTL	
0262	7630	SZL CLA	/SELECT ROUTINE? (SR1)
0263	5233	JMP GETRJY	/YES
0264	1061	TAD NXTST	
0265	7001	IAC	
0266	7640	SZA CLA	/LAST ROUTINE?
0267	5236	JMP GETRJY+3	/NO,
0270	7604	LAS	
0271	7006	RTL	
0272	7710	SPA CLA	/LOOP PROGRAM? (SR2)
0273	5233	JMP GETRJY	/YES
0274	7402	PRGEND, HLT	/END OF PROGRAM HALT
0275	5257	JMP CHAINN	
0276	0000	FORWD, 0	
0277	7300	CLA CLL	
0300	1461	TAD I NXTST	/GET NEXT RTN NO
0301	3060	DCA RTNNO	/STORE AT RTNNO
0302	2061	ISZ NXTST	
0303	1061	TAD NXTST	/SET CURRENT
0304	3052	DCA TEMP	/RTN NUMBER
0305	2061	ISZ NXTST	
0306	1061	TAD NXTST	/SET CURRENT
0307	3057	DCA CURTST	/RTN ADDR,
0310	1452	TAD I TEMP	/SET NEXT
0311	3061	DCA NXTST	/RTN ADDR,
0312	5676	JMP I FORWD	/EXIT

0313	0000	SHALT, 1	
0314	7604	LAS	/READ SR
0315	7700	SMA CLA	/HALT? (SR0)
0316	5713	JMP I SHALT	
0317	1060	TAD RTN0	
0320	7402	HLT	/UNCONDITIONAL HALT (SR0 = 1)
0321	5713	JMP I SHALT	/EXIT,S/-10L
0322	0000	STCTR, 0	
0323	7200	CLA	
0324	1722	TAD I STCTR	/GET CTR ADDR
0325	3052	DCA TEMP	/AND SAVE AT TEMP
0326	2322	ISZ STCTR	
0327	1722	TAD I STCTR	/GET COUNT AND
0330	3452	DCA I TEMP	/STORE PER C(TEMP)
0331	2322	ISZ STCTR	
0332	5722	JMP I STCTR	/EXIT
0333	0000	DLYSC, 0	
0334	7300	CLA CLL	
0335	1733	TAD I DLYSC	/GET SECONDS COUNT
0336	3062	DCA SCCTR	/STORE AT SCCTR
0337	4345	JMS DLYMS	/GO DELAY
0340	6030	-1750	/1 SECOND (1000 MSEC),
0341	2062	ISZ SCCTR	/DONE DELAYING?
0342	5337	JMP ,=3	
0343	2333	ISZ DLYSC	/YES
0344	5733	JMP I DLYSC	/EXIT
0345	0000	DLYMS, 0	
0346	7300	CLA CLL	
0347	1023	TAD DELAYM	/GET MS COUNT
0350	3063	DCA MSCTR	/STORE IN MSCTR
0351	1065	TAD MIL1	/GET 1 MS CONSTANT
0352	3064	DCA MILCTR	/STORE IN MILCTR
0353	2064	ISZ MILCTR	/DELAYED 1 MSEC?
0354	5353	JMP ,=1	
0355	2063	ISZ MSCTR	/DONE DELAYING?
0356	5351	JMP ,=5	
0357	5745	JMP I DLYMS	/EXIT

```

0400      0400      * 177+1
/RANDOM NUMBER GENERATOR SUBROUTINE
RANGEN: 1
0401      0000      CLA
0402      7200      TAD RANTVD
0403      1242      TAD RANDEX
0404      1227      SZA CLA
0405      7640      JMP RANTAD
0406      5215      TAD RANTBL
0407      1231      DCA RANDEX
0408      3227      TAD RANCON
0409      1230      CLL RAL
0410      7104      SEL
0411      7430      IAC
0412      7001      DCA RANCON
0413      3230      RANTAD: TAD RANCON
0414      1230      TAD I RANDEX
0415      1627      DCA I RANDEX
0416      3627      TAD RANSAV
0417      1243      RAR
0418      7010      TAD I RANDEX
0419      1627      ISZ RANDEX
0420      2227      DCA RANSAV
0421      3243      TAD RANSAV
0422      1243      JMP I RANGEN
0423      5600      RANDEX: RANTND
0424      0442      RANCON: 6543
0425      6543      RANTBL: ,+1
0426      6543      6543
0427      3210      3210
0428      0765      0765
0429      5432      5432
0430      2107      2107
0431      7654      7654
0432      4321      4321
0433      1076      1076
0434      7336      RANTND: -1
0435      0000      RANSAV: 0
0436      0000

```

```

/SUBROUTINE TO INITIALIZE BINARY COUNT PATTERN
0444 0000 INITPT, 0
0445 7200          CLA          /SET PT0 = 0
0446 3250          DCA PT0
0447 5644          JMP I INITPT /EXIT
0450 0000 PT0, 0
0451 0000 PT1, 0
0452 0377 PTMSK, 377

/SUBROUTINE TO PROVIDE NEXT BINARY COUNT PATTERN CHARACTER (IN AC)
0453 0000 GEIPTT, 0
0454 7200          CLA
0455 1250          TAD PT0          /GET PT0
0456 3251          DCA PT1          /STORE AT PT1
0457 1251          TAD PT1          /GET PT1
0458 7001          IAC          /INCREMENT ACCUMULATOR
0459 0252          AND PTMSK        /LIMIT TO 8 BITS
0460 3250          DCA PT0          /STORE AT PT0
0461 1251          TAD PT1          /GET PT1
0462 5653          JMP I GETPTT /EXIT

/PUNCH/PRINT ONE CHARACTER SUBROUTINE (CHAR IN AC).
0465 0000 PUNCH, 0
0466 2114          ISZ PFLAG        /SET PFLAG
0467 6046          TLS          /PUNCH PRINT
0470 7200          CLA
0471 1114          TAD PFLAG
0472 7640          SZA CLA          /FLAG RESET?
0473 7410          SKP          /NO
0474 5277          JMP ,+3          /YES,
0475 6041          TSF          /DONE PRINTING
0476 5271          JMP ,=5          /NO,
0477 6042          TCF          /YES, RESET PUNCH/PRINTER FLAG
0500 3114          DCA PFLAG        /RESET PFLAG,
0501 5665          JMP I PUNCH     /EXIT,

/SUBROUTINE TO GENERATE RANDOM CHARACTER COUNT, (NOT MORE THAN 77(8))
0502 0000 CHRCNT, 0
0503 4432          JMS I RANDNO     /GO GENERATE RANDOM NUMBER
0504 0317          AND CRMSK        /REMOVE HIGH ORDER 6 BITS
0505 7450          SVA
0506 5303          JMP CHRCNT+1
0507 7041          CIA          /2'S COMPLEMENT IT
0510 3103          DCA SCNT
0511 1702          TAD I CHRCNT
0512 3052          DCA TEMP
0513 1103          TAD SCNT
0514 3452          DCA I TEMP        /STORE AT SPECIFIED ADDRESS
0515 2302          ISZ CHRCNT       /SET UP EXIT
0516 5702          JMP I CHRCNT     /EXIT
0517 0077          CRMSK, 77

```

/SUBROUTINE TO GENERATE RANDOM DELAY COUNT (NOT MORE THAN 3777(8)).

```

/
DLCNT, 0
0520 0000
0521 4432      JMS I RANDNO      /GO GENERATE RANDOM NUMBER
0522 0330      AND DLYMSK      /MASK OUT UNDESIRED BITS,
0523 7400      SNA              /ZERO?
0524 5321      JMP DLCNT+1    /YES, GET ANOTHER NUMBER
0525 7041      CIA              /2'S COMPLMENT IT
0526 3023      DCA DELAYM
0527 5720      JMP I DLCNT    /EXIT
0530 0277      DLYMSK, 277

```

/SUBROUTINE TO COMPARE C(AC) TO CONTENTS STORED AT CALL+1

```

/
CHK, 0
0531 0000
0532 3345      DCA WCHK      /STORE AC AT WCHK
0533 1731      TAD I CHK      /GET COMPARE DATA
0534 7041      CIA              /2'S COMPLEMENT IT
0535 1345      TAD WCHK      /ADD C(WCHK)
0536 2331      ISZ CHK        /SET UP FOR UNEQUAL EXIT
0537 7640      SZA CLA        /EQUAL (AC = 0)
0540 5343      JMP ,+3        /NO
0541 2331      ISZ CHK        /YES, SET UP FOR EQUAL EXIT
0542 5731      JMP I CHK      /EQUAL EXIT
0543 1345      TAD WCHK      /RESTORE AC
0544 5731      JMP I CHK      /UNEQUAL EXIT
0545 0000      WCHK, 0

```

/SYNC ON TAPE SUBROUTINE

```

/
SYNK, 0
0546 0000
0547 4426      JMS I SETCTR    /SET COUNT OF
0550 0566      CTSK          /-256 (DEC) IN
0551 7400      -400          /CTSK
0552 6032      SYNKA, KCC     /CLEAR AC @ND FLAG
0553 6031      KSF           /READY?
0554 5353      JMP ,=1       /NO, TEST AGAIN
0555 6034      KRS           /YES, READ
0556 1117      TAD MRBOUT
0557 7640      SZA CLA        /377?
0560 7410      SKP
0561 5746      JMP I SYNK     /YES, EXIT

0562 2366      ISZ CTSK       /BUMP CHAR CTR +1
0563 5352      JMP SYNKA      /GO READ AGAIN
0564 7402      HLT           /256 CHARS READ, CAN'T SYNC
0565 5347      JMP SYNK+1    /GO TO SRST
0566 0000      CTSK, 0       /CHAR COUNTER

```

```

      0640      * 177+1
      /SUBROUTINE TO MOVE VARIABLE LENGTH DATA FIELDS
MOVE, 0620 0000
      0621 7200
      0622 1600
      0623 3223
      0624 2200
      0625 1600
      0626 3224
      0627 2200
      0610 1600
      0611 3225
      0612 2200
MOVEA, 0613 7200
      0614 1623
      0615 3624
      0616 2223
      0617 2224
      0620 2225
      0621 5213
      0622 5600
      0623 0000
      0624 0000
      0625 0000
      CLA
      TAD I MOVE      /GET "FROM ADDR" AND
      OCA FADDR      /STORE AT FADDR
      ISZ MOVE
      TAD I MOVE      /GET "TO ADDR" AND
      OCA TADDR      /STORE AT TADDR,
      ISZ MOVE
      TAD I MOVE      /GET "MOVE COUNT" AND
      OCA MCTR      /STORE AT MCTR,
      ISZ MOVE      /SET UP FOR EXIT.
      CLA
      TAD I FADDR      /GET "FROM" WORD
      OCA I TADDR      /STORE AT "TO" LOCATION
      ISZ FADDR      /+1 TO "FROM" ADDR
      ISZ TADDR      /+1 TO "TO" ADDR
      ISZ MCTR      /ALL WORDS MOVED?
      JMP MOVEA      /NO, GO MOVE AGAIN
      JMP I MOVE      /YES, EXIT
      FADDR, 0
      TADDR, 0
      MCTR, 0

```

```

1000      *. 177+1
          /PROGRAM NUMBER 3, PUNCHES TEST TAPE WITH 2 CHARACTERS
          /SPECIFIED IN SYMBOLIC LOCATIONS PTEMP, AND PTEMP1.
1000 7200 PRG3,  CLA
1001 1021      TAB PTEMP      /GET C(PTEMP)
1002 4515      JMS I UPUNCH   /PUNCH C(PTEMP)
1003 1022      TAB PTEMP1    /GET C(PTEMP1)
1004 4515      JMS I UPUNCH   /PUNCH C(PTEMP1)
1005 5200      JMP PRG3      /REPEAT,
/
/PROGRAM NUMBER 4, PUNCHES TEST TAPE WITH BINARY COUNT PATTERN.
1006 7200 PRG4,  CLA
1007 4507      JMS I INPATT   /INITIALIZE BINARY COUNT PATTERN
1010 4510      JMS I GETPT    /GET BINARY COUNT CHARACTER,
1011 4515      JMS I UPUNCH   /PUNCH CHARACTER
1012 5210      JMP , -2      /REPEAT,
/
/PROGRAM 5-READS COUNT PATTERN-RANDOM NUMBERED GROUPS,
/ FIXED RANDOM DELAY BETWEEN CHARACTERS IN A GROUP.
1013 4506 PRG5,  JMS I SYNC    /SYNC TAPE
1014 3317      DCA ERRCTR    /CLEAR ERROR COUNTER
1015 4507      JMS I INPATT   /INITIALIZE PATTERN,
1016 6032      KCC          /START READER
1017 4513      SRT0A, JMS I DLYCNT /GENERATE DELAY COUNT
1020 4512      JMS I CRONT    /GO GENERATE AND STORE
1021 0101      CTRA         /RANDOM CHAR, COUNT
1022 4510      SRT0B, JMS I GETPT /GET PATTERN CHAR,
1023 3276      DCA SBSP     /STORE AT SBSP,
1024 4430      JMS I DLY1MS  /GO DELAY
1025 4271      JMS READCK    /GO READ AND CHECK CHAR,
1026 2101      ISZ CTRA     /GROUP DONE?
1027 5222      JMP SRT0B    /NO,
1030 5217      JMP SRT0A    /YES, START AGAIN
/
/PROGRAM 6-READS COUNT PATTERN-FIXED DELAY BETWEEN CHARACTERS
1031 4506 PRG6,  JMS I SYNC    /SYNC TAPE
1032 3317      DCA ERRCTR    /CLEAR ERROR COUNTER
1033 4507      JMS I INPATT   /INITIALIZE PATTERN
1034 6032      KCC          /START READER
1035 4510      SRT1A, JMS I GETPT /GET PATTERN CHAR,
1036 3276      DCA SBSP     /STORE AT SBSP
1037 4430      JMS I DLY1MS  /GO DELAY
1040 4271      JMS READCK    /GO READ AND CHECK CHAR,
1041 5235      JMP SRT1A    /REPEAT

```

```

/PROGRAM 7 - READS CHARS FROM TAPE AND MATCHES AGAINST CHARS
/
/ IV TEMP AND TEMP1, RANDOM DELAY BETWEEN CHARS,
1042 7200 PRG7, CLA
1043 3317 DCA ERRCTR /CLEAR ERROR COUNTER
1044 4320 JMS ALIGN /
1045 6032 KCC /START READER
1046 4513 SRT2A, JMS I DLYCNT /GENERATE DELAY COUNT
1047 4512 JMS I CRCNT /GO GENERATE AND STORE
1050 2121 CTRA /RANDOM CHAR COUNT
1051 4350 SRT2B, JMS GIVE /GET CHARACTER
1052 3276 DCA SBSP /STORE AT SBSP
1053 4430 JMS I DLY1MS /GO DELAY
1054 4271 JMS READCK /GO READ AND CHECK CHAR
1055 2101 ISZ CTRA /GROUP DONE?
1056 5251 JMP SRT2B /NO,
1057 5246 JMP SRT2A /YES START AGAIN

```

```

/
/PROGRAM 10 - SAME AS SRT2, BUT FIXED DELAY BETWEEN
/ CHARS, DELAY IS SPECIFIED IN LOC - DELAYM,
1060 7200 PRG10, CLA
1061 3317 DCA ERRCTR /CLEAR ERROR COUNTER,
1062 4320 JMS ALIGN /
1063 6032 KCC /START READER
1064 4350 SRT3A, JMS GIVE /SET CHARACTER,
1065 3276 DCA SBSP /STORE AT SBSP
1066 4430 JMS I DLY1MS /GO DELAY
1067 4271 JMS READCK /GO READ AND CHECK CHAR,
1070 5264 JMP SRT3A /REPEAT,

/
READCK, 0
1071 0000 KSF /READY?
1072 6031 JMS ,-1 /TEST AGAIN,
1073 5272 KRR /READ CLEAR AC AND FLAG,
1074 6036 JMS I CHECK /GO CHECK CHARACTER WORD,
1075 4511 SBSP, 0 /
1076 0000 JMP ERRCNT /ERROR, NO MATCH, GO INC, ERRCNT
1077 5301 JMP HLTST
1100 5311 ERRCNT, ISZ ERRCTR /INCREMENT ERROR COUNTER
1121 2317 JMP ,+3
1102 5305 CLA CMA /OFLOW, RESET TO 7777,
1103 7240 DCA ERRCTR
1104 3317 LAS /READ SR,
1105 7604 AND SR5MSK
1106 0055 SZA CLA /HALT ON ERROR?
1107 7640 HLT /YES,
1110 7402 HLTST, LAS /READ SR
1111 7604 SMA CLA /HALT?
1112 7700 JMP I READCK /NO EXIT
1113 5671 TAD ERRCTR /GET ERROR COUNT
1114 1317 HLT /HALT, ERROR COUNT IN AC
1115 7402 JMP I READCK /EXIT,
1116 5671 ERRCTR, 0 /ERROR COUNTER
1117 0000

```



```

/
1120 3000      ALIGN,  '
1121 7200      CLA
1122 6031      KSF
1123 5322      JMP  ,-1      /READY?
1124 6034      KXS      /TEST AGAIN.
1125 7041      CIA      /READ CHARACTER,
1126 3347      DCA ATEMP /2'S COMPLEMENT IT,
1127 1347      TAD ATEMP /STORE AT A TEMP.
1130 1021      TAD PTEMP
1131 7650      SVA CLA      /IS IT CHAR IN PTEMP?
1132 5341      JMP AL1      /YES,
1133 1347      TAD ATEMP      /NO,
1134 1022      TAD PTEMP1
1135 7650      SVA CLA      /IS IT CHAR IN PTEMP1?
1136 5344      JMP AL2      /YES,
1137 7402      HLT      /NO, ERROR.
1140 5321      JMP ALIGN+1 /REPEAT,
1141 7040      AL1,      CMA
1142 3346      DCA IND      /SET IND TO -1
1143 5720      JMP I ALIGN
1144 3346      AL2,      DCA IND      /SET IND TO 0,
1145 5720      JMP I ALIGN
1146 0000      IND,      0
1147 0000      ATEMP, 0
1150 0000      GIVE,   0
1151 7200      CLA
1152 2346      ISZ IND      /IS IND = -1?
1153 5357      JMP ,+4      /NO,
1154 3346      DCA IND      /YES,
1155 1022      TAD PTEMP1 /GET CHAR FROM TEMP1
1156 5750      JMP I GIVE /EXIT,
1157 7040      CMA
1160 3346      DCA IND      /SET IND TO -1,
1161 1021      TAD PTEMP /GET CHAR FROM TEMP,
1162 5750      JMP I GIVE /EXIT,
/

```

```

1200      *, 177+1
          /PROGRAM 2, ASR 33/35 TELETYPE BASIC INPUT TESTS.
          /PROGRAM CHECKS INPUT IOT'S, INTERRUPT, AND READER TIMING
1200 4426 PRG0,   JMS I SETCTR   /SET KSTART TO INITIAL
1201 0020      KSTART       /ROUTINE ADDRESS,
1202 1205      POTS0
1203 5604      JMP I ,+1     /GO START TEST
1204 0232      SRSET
          /
1205 0040      POTS0, 0
1206 1225      POTS1
          /ISSUE KCC WITH AC=7777, AC SHOULD GO TO 2,
          /AC NOT 3 INDICATES KCC FAILURE, TEST IS DONE 1000 TIMES.
1207 4426      JMS I SETCTR   /SET COUNT OF
1210 0101      CTRA         /-1000 (DEC) IN
1211 6030      -1750        /CTRA
1212 7240      CLA CMA      /SET AC TO 7777
1213 6032      KCC         /CLEAR AC AND FLAG
1214 7440      SZA         /IS AC = 0?
1215 5221      JMP P0E0     /NO ERROR, GO TO P0E0
1216 2101      ISZ CTRA     /DONE?
1217 5212      JMP ,=5      /NO, REPEAT
1220 5424      JMP I CHAIN  /CHAIN
1221 7402      P0E0, HLT    /TST0 ERR HALT, KCC DID
          /NOT RESULT IN AC = 0
1222 7240      CLA CMA      /SET A TO 7777
1223 6032      KCC         /CLEAR AC AND FLAG
1224 5222      JMP ,=2      /RPEAT
1225 0001      POTS1, 1
1226 1246      POTS2
          /ISSUE KCC, WAIT 200 MSEC FOR FLAG TO SET,
          /SKIP ON FLAG, FAILURE TO SKIP INDICATES
          /THAT FLAG IS NOT SET, OR KSF FAILURE,
          /TEST IS DONE 100 TIMES,
1227 4426      JMS I SETCTR   /SET DELAYM
1230 0023      DELAYM      /TO -200
1231 7470      -310
1232 4426      POTS1A, JMS I SETCTR /GO SET COUNT OF
1233 0101      CTRA         /-100 (DEC) IN
1234 7634      -144        /CTRA
1235 6032      POTS1B, KCC   /CLEAR AC AND FLAG
1236 4430      JMS I DLY1MS /GO DELAY
1237 6031      KSF         /SKIP ON FLAG = 1
1240 5244      JMP P0E1     /ERROR, GO TO E1
1241 2101      ISZ CTRA     /ALL DONE?
1242 5235      JMP POTS1B  /NO, REPEAT
1243 5424      JMP I CHAIN  /CHAIN
1244 7402      P0E1, HLT    /TST1 ERROR HALT, FLAG IS NOT
          /SET, OR KSF FAILED
1245 5232      JMP POTS1A  /RESTARTING TEST.

```

```

1246 2002 P0TS2, 2
1247 1275 P0TS3
/ISSUE KCC, WAIT 200 MSEC FOR FLAG TO BE SET.
/SKIP ON FLAG 1000 TIMES TO VERIFY CONSISTENT SKIPPING.
/

1250 4426 JMS I SETCTR /SET DELAYM
1251 3023 DELAYM /TO -200
1252 7470 -310
1253 4426 JMS I SETCTR /GO SET COUNT OF 1000
1254 2101 CTRA /((DEC) IN
1255 6030 -1750 /CTRA
1256 6032 P0TS2A, KCC /CLEAR AC AND FLAG
1257 4430 JMS I DLY1MS /GO DELAY
1260 6031 KSF /SKIP ON FLAG = 1
1261 5267 JMP P0E2A /DID NOT SKIP, GO TO E2A
1262 6031 KSF /SKIP ON FLAG = 1
1263 5271 JMP P0E2B /DID NOT SKIP, GO TO E2B
1264 2101 ISZ CTRA /ALL DONE?
1265 5262 JMP ,-3 /NO, REPEAT
1266 5424 JMP I CHAIN /CHAIN
1267 7402 P0E2A, HLT /TST2 ERROR HALT, FLAG
/NOT SET OR KSF FAILURE,

1270 5256 JM P0TS2A
1271 7402 P0E2B, HLT /TST2 ERR HALT B,
/KSF FAILURE
/KSF FAILURE
1272 6031 KSF /SKIP ON FLAG = 1
1273 5272 JMP ,-1 /REPEAT
1274 5272 JMP ,-2 /REPEAT

```

```

1275 0003 POTS3, 3
1276 1327 POTS4
/
/ISSUE KCC, WAIT 200 MSECS FOR FLAG TO SET,
/VERIFY THAT FLAG IS SET, RESET FLAG (KCC) AND
/SKIP ON FLAG 500 TIMES TO VERIFY THAT NO
/SKIP OCCURS WITH FLAG = 0,
/
1277 4426 JMS I SETCTR /SET DELATM
1320 0023 DELAYM /TO -200,
1371 7470 -310
1372 4426 JMS I SETCTR /SET COUNT OF
1303 0101 CTRA /-500 (DEC) IN
1374 7014 -764 /CTRA
1375 6032 POTS3A, KCC /CLEAR FLAG
1376 4430 JMS I DLY1MS /GO DELAY
1377 6031 KSF /READY?
1310 5320 JMP P0E3A /NO, ERROR
1311 6032 KCC /YES, RESET FLAG
1312 6031 KSF /READY?
1313 5315 JMP ,+2 /NO, OK
1314 5322 JMP P0E3B /YES, ERROR
1315 2101 ISZ CTRA /ALL DONE TESTING?
1316 5312 JMP ,+4 /NO, REPEAT
1317 5424 JMP I CHAIN /YES, CHAIN
1320 7402 P0E3A, HLT /TST3 ERR HALT A, FLAG
/NOT SET OR KSF FAILURE
1321 5305 JMP POTS3A /TRY AGAIN
1322 7402 P0E3B, HLT /TST3 ERR HALT B, FLAG
/FAILED TO RESET, OR KSF
/SKIPPED ERRONEOUSLY,

/TURN OFF READER BEFORE ENTERING
/SCOPE LOOP,
1323 6032 KCC /CLEAR FLAG AND AC
1324 6031 KSF /SKIP ON FLAG = 1
1325 5323 JMP ,+2 /REPEAT
1326 5323 JMP ,+3 /REPEAT

```

```

1327 0004 POTS4, 4
1330 1400 POTS5
/THIS ROUTINE CHECKS THAT NO OTHER DEVICE CAN CAUSE AN INTERRUPT,
/AND THEN CHECKS THAT THE READER FLAG IS CAPABLE OF INTERRUPTING.
1331 4426 JMS I SETCTR /SET INTERRUPT RETURN
1332 0002 2 /TO P0E4A,
1333 1345 P0E4A
1334 6042 POTS4A, TCF /CLEAR PUNCH/PRINTER FLAG
1335 6032 KCC /CLEAR READER FLAG AFTER
1336 6031 KSF /IT COMES UP
1337 5336 JMP ,-1
1340 6032 KCC /CLEAR READER FLAG
1341 6001 ION /ENABLE INTERRUPT
1342 7000 NOP
1343 6002 IOF /TURN OFF INTERRUPT
1344 5347 JMP ,+3
1345 7402 P0E4A, HLT /UNEXPECTED INTERRUPT
1346 5334 JMP POTS4A /TRY AGAIN
1347 4426 JMS I SETCTR /SET CTRA TO
1350 0101 CTRA /-1300
1351 6030 -1750
1352 4426 JMS I SETCTR /SET INTERRUPT RETURN
1353 0002 2 /TO POTS4C,
1354 1371 POTS4C
1355 6032 KCC
1356 6031 KSF /WAIT FOR READER FLAG
1357 5356 JMP ,-1 /TO SET
1360 6001 POTS4B, ION /ENABLE INTERRUPT
1361 7000 NOP
1362 7402 P0E4B, HLT /READER FLAG FAILED TO INTERRUPT,
/QR INTERRUPT SYSTEM MALFUNCTION
1363 4426 JMS I SETCTR /SET INTERRUPT RETURN
1364 0002 2 /TO POTS4C-1,
1365 1370 POTS4C-1
/SCOPE LOOP
1366 6001 ION
1367 7000 NOP
1370 5366 JMP ,-2
/
1371 2101 POTS4C, ISX CTRA /DONE?
1372 5360 JMP POTS4B /NO, REPEAT
1373 5424 JMP I CHAIN

```

```

1400      1400      *, 177+1
1420      3005      POTS5, 5
1421      1424      POTS6
/READER TIMING TEST. CHECKS THAT READER FLAG IS =1 NO
/LATER THAN 110 MILLISECONDS AFTER KCC INSTRUCTION IS ISSUED.
/
1402      4426      JMS I SETCTR /SET DELAYM
1403      3023      DELAYM /TO=11
1404      7022      -156
1405      4426      JMS I SETCTR /SET COUNT OF
1406      3101      CTRA /-100 (DEC) IN
1407      7634      -144 /CTRA
1410      6032      POTS5A, KCC /START READER, CLEAR PC FLAG
1411      4430      JMS I DLY1MS /GO DELAY 110 MILLISECS
1412      6031      KSF
1413      5217      JMP P0E5
1414      2101      ISZ CTRA
1415      5210      JMP POTS5A
1416      5424      JMP I CHAIN
1417      7402      P0E5, HLT /TST5 ERR HALT, FLAG NOT=1
/110 MSECS AFTER KCC INSTRUCTION.
1420      6032      KCC /START READER, CLEAR FLAG, AC,
1421      6031      KSF /FLAG=1?
1422      5221      JMP ,-1 /NO, TEST AGAIN
1423      5220      JMP ,-3 /YES, REPEAT.

```

1424 0000
1425 7777

POTS6, 0

7777

/READ 256 DIFFERENT CHARACTERS, EACH CHARACTER IS READ 1000 TIMES
/TO VERIFY CONSISTENCY OF READING FROM TTI,
/

1426 4426

JMS I SETCTR

/SET COUNT OF

1427 0101

CTRA

/-256(DEC)

1430 7400

-400

/IN CTRA

1431 6032

POTS6A, KCC

/CLEAR AC, FLAG, START RDR

1432 6031

KSF

/READY?

1433 5232

JMP ,-1

/NO, TEST AGAIN,

1434 6034

KRS

/READ CHARACTER,

1435 3266

DCA WTS6A

/SAVE AT WTS6A,

1436 4426

JMS I SETCTR

/SET COUNT OF

1437 0102

CTRB

/CTRB

1440 6030

-1700

/-1000 (DEC) IN

1441 7200

POTS6B, CLA

1442 6034

KRS

/READ CHARACTER,

1443 3267

DCA WTS6B

/SAVE AT WTS6B

1444 1267

TAD WTS6B

/GET IT BACK,

1445 7041

CIA

/2'S COMPLEMENT IT

1446 1266

TAD WTS6A

/ADD EXPECTED CHAR,

1447 7640

SZA CLA

/RESULT 0?

1450 5256

JMP P0E6A

/NO, ERROR, GO TO E6A,

1451 2102

ISZ CTRB

/READ CHAR 1000 TIMES?

1452 5241

JMP POTS6B

/NO, GO READ IT AGAIN,

1453 2101

ISZ CTRA

/YES, READ 256 DIFF, CHARS?

1454 5231

JMP POTS6A

/NO,

1455 5424

JMP I CHAIN

/YES, CHAIN

1456 1267

P0E6A, TAD WTS6B

1457 7402

HLT

/TST6 ERR HALT A, AC DISPLAYS

/

/INCORRECTLY READ CHAR, DEPRESS

/

/KEY CONTINUE

1460 7200

CLA

1461 1266

TAD WTS6A

1462 7402

P0E6B, HLT

/TST6 ERR HALT B, AC DISPLAYS

/

/WHAT THE CORRECT CHAR SHOULD

/

/BE,

1463 7200

CLA

1464 6034

KRS

/READ CHARACTER

1465 5263

JMP ,-2

/L

1466 0000

WTS6A, 0

1467 0000

WTS6B, 0

```

1600      * . 17/+1
          /PROGRAM 1, ASR33/35 TELETYPE BASIC OUTPUT TESTS,
          /PROGRAM CHECKS OUTPUT IOT,S, INTERRUPT, AND TIMING,
1620  4426  PRG1,   JMS I SETCTR   /SET KSTART TO INITIAL
1621  3020      KSTART       /ROUTINE ADDRESS,
1622  1625      P1TS0
1623  5624      JMP I ,+1      /GO START TEST
1624  3232      SRSET

/
1625  3000  P1TS0, 0
1626  1635      P1TS1
          /1: TLS AND WAIT 200 MSEC'S FOR FLAG TO SET, SKIP ON FLAG=1 (TSF),
          /TSF SHOULD SKIP, OR ERROR HALT P1E0A OCCURS, FLAG NOT SET, OR TSF FAILURE,
          /2: WITH FLAG=1, SKIP ON FLAG 1000 TIMES TO TEST FOR CONSISTENT SKIPPING,
          /FAILURE TO SKIP CAUSES ERROR HALT P1E0B,
1627  4426      JMS I SETCTR   /-200 TO DELAYM
1610  3023      DELAYM
1611  7470      -310
1612  4426      JMS I SETCTR   /-1000 TO CTRA
1613  3101      CTRA
1614  6030      -1750
1615  7200  P1TS0A, CLA      /CLEAR AC
1616  6046      TLS          /START PRINTER/PUNCH
1617  4430      JMS I DLY1MS  /DELAY 200 MSEC'S,
1620  6041      TSF          /FLAG=1?
1621  5227      JMP P1E0A     /NO, ERROR
1622  6041  P1TS0B, TSF     /FLAG=1?
1623  5231      JMP P1E0B     /ERROR, FAILED TO SKIP,
1624  2101      ISZ CTRA     /DONE?
1625  5222      JMP P1TS0B   /NO, REPEAT,
1626  5424      JMP I CHAIN  /YES, CHAIN
1627  7602  P1E0A, HLT CLA  /ERR HALT A, FLAG NOT=1 AFTER
1630  5215      JMP P1TS0A   /200 MSEC'S, OR TSF FAILURE
1631  7602  P1E0B, HLT CLA  /ERR HALT B, TSF FAILED TO SKIP
1632  6041      TSF          /SCOPE LOOP, SKIPS ON
1633  5232      JMP , -1    /FLAG CONTINUOUSLY,
1634  5232      JMP , -2

```



```

1635 0001 P1TS1, 1
1636 1656 P1TS2
/ISSUE TCF TO CLEAR FLAG, SKIP ON FLAG 1000 TIMES TO VERIFY THAT NO
/SKIP OCCURS WITH FLAG=0
1637 4426 JMS I SETCTR /-1000 TO CTRA
1640 0101 CTRA
1641 6030 =1750
1642 6042 TCF /CLEAR FLAG
1643 6041 P1TS1A, TSF
1644 7410 SKP
1645 5251 JMP P1E1
1646 2101 ISZ CTRA
1647 5243 JMP P1TS1A
1650 5424 JMP I CHAIN
1651 7602 P1E1, HLT CLA /ERR HALT, AFTER CLEAR FLAG (TCF),
/TSF INSTRUCTION SKIPPED,
/SCOPE LOOP, CLEARS FLAG,
/ADN THEN SKIPS ON FLAG
1652 6042 TCF /CONTINUOUSLY,
1653 6041 TSF
1654 5253 JMP ,-1
1655 5253 JMP ,-2
/
1656 0002 P1TS2, 2
1657 1701 P1TS3
/ISSUE TCF, WAIT FOR FLAG TO SET, CLEAR FLAG (TCF), SKIP ON FLAG=1, NO SKIP
/SHOULD OCCUR, IF SKIP OCCURS, TCF INSTRUCTION (CLEAR FLAG), FAILED,
1660 4426 JMS I SETCTR /-100 TO CTRA
1661 0101 CTRA
1662 7634 =144
1663 7200 P1TS2A, CLA
1664 6046 TLS
1665 6041 TSF
1666 5265 JMP ,-1
1667 6042 TCF
1670 6041 TSF
1671 7410 SKP
1672 5276 JMP P1E2
1673 2101 ISZ CTRA
1674 5263 JMP P1TS2A
1675 5424 JMP I CHAIN
1676 7602 P1E2, HLT CLA /ERR HALT, TCF FAILED TO RESET
/FLAG,
/SCOPE LOOP, CLEARS FLAG
/CONTINUOUSLY,
1677 6042 TCF
1700 5277 JMP ,-1

```

```

1701 0003 P1TS3, 3
1702 1746 P1TS4
/THIS ROUTINE CHECKS THAT NO OTHER DEVICE CAN CAUSE AN INTERRUPT,
/AND THEN CHECKS THAT THE PUNCH/PRINTER FLAG CAN CAUSE AN INTERRUPT,
1703 4426 JMS I SETCTR /SET INTERRUPT RETURN TO
1704 0002 2 /P1E3A
1705 1717 P1E3A
1706 6032 P1TS3A, KCC /CLEAR READER FLAG IF UP,
1707 6046 TLS
1710 6041 TSF
1711 5310 JMP , -1
1712 6042 TCF /CLEAR PUNCH/PRINTER FLAG
1713 6001 ION /ENABLE INTERRUPTS,
1714 7000 NOP
1715 6002 IOF /DISABLE INTERRUPTS
1716 5321 JMP , +3
1717 7402 P1E3A, HLT /UNEXPECTED INTERRUPT,
1720 5306 JMP P1TS3A /TRY AGAIN,
1721 4426 JMS I SETCTR /-1000 TO CTRA,
1722 0101 CTRA
1723 6030 -1750
1724 4426 JMS I SETCTR /SET INTERRUPT RETURN
1725 0002 2 /TO P1TS3C
1726 1743 P1TS3C
1727 6046 TLS /START PUNCH/PRINTER
1730 6041 TSF /FLAG UP?
1731 5330 JMP , -1 /NO, TEST AGAIN
1732 6001 P1TS3B, ION /YES, ENABLE INTERRUPT
1733 7000 NOP
1734 7402 P1E3B, HLT /PRINTER FLAG FAILED TO INTERRUPT
/OR INTERRUPT MALFUNCTION,
1735 4426 JMS I SETCTR /SET INTERRUPT RETURN
1736 0002 2 /TO P1TS3C-1
1737 1742 P1TS3C-1
1740 6001 ION /SCOPE LOOP,
1741 7000 NOP
1742 5340 JMP , +2
1743 2101 P1TS3C, ISZ CTRA /DONE?
1744 5332 JMP P1TS3B /NO, REPEAT
1745 5424 JMP I CHAIN /YES, CHAIN

```

```

1746 2004 P1S4, 4
1747 7777      7777
/PUNCH/PRINTER TIMING TEST, CHECKS THAT FLAG IS=1 NO LATER THAN
/110 MILLISECONDS AFTER TLS INSTRUCTION
1750 4426      JMS I SETCTR /-110 TO DELAYM
1751 2023      DELAYM
1752 7622      -156
1753 4426      JMS I SETCTR /-100 TO CTRA
1754 0101      CTRA
1755 7634      -144
1756 6046 P1S4A, TLS /START PUNCH/PRINTER
1757 4430      JMS I DLY1MS /GO DELAY 110 MSECS,
1760 6041      TSF /FLAG=1?
1761 5365      JMP P1E4 /NO, ERROR.
1762 2101      ISZ CTRA /YES, DONE?
1763 5306      JMP P1S4A /NO, REPEAT.
1764 5424      JMP I CHAIN /YES, CHAIN
1765 7602 P1E4, HLT CLA /ERR HALT, FLAG NOT 1 110 MSECS
/AFTR TLS INSTRUCTION,
1766 6046      TLS /SCOPE LOOP, START PRINTER
1767 6041      TSF /FLAG=1?
1770 5367      JMP ,-1 /NO, CHECK AGAIN
1771 5366      JMP ,-3 /YES REPEAT.

```

```

2000      * , 177+1
          /PROGRAM 2, ASR33/35 TELETYPE READER TEST, CHECKS ABILITY OF READER
          /TO CORRECTLY READ AT FULL SPEED AND WITH RANDOM STALLS,
2000 4426  PRG2,   JMS I   SETCTR /SET KSTART TO INITIAL
2001 4020          KSTART   /ROUTINE ADDRESS.
2002 2025          P2TSP
2003 5624          JMP I ,+1   /GO START TEST
2004 2232          SRSET
/
2005 3000  P2TSP, /
2006 2035          P2TSP1   /NEXT RTN ADDR.
          /READ 4095 CHARACTERS, AT FULL SPEED, MATCHING EACH CHARACTER
          /READ AGAINST COUNT PATTERN
/
2007 4506          JMS I SYNC   /GO SYNC TAPE
2010 4426          JMS I SETCTR /SET COUNT OF
2011 2121          CTRA       /-4095(DEC) IN
2012 2001          =7777     /CTRA
2013 6032          KCC       /START READER
2014 4507          JMS I INPAT /GO INITIALIZE PATTERN
2015 4510  P2TSP,A, JMS I GETPT /GET PATTERN CHARACTER
2016 3223          DCA SB0    /STORE AT SB0
2017 6031          KSF       /READY?
2020 5217          JMP ,=1    /NO, TEST AGAIN
2021 6036          KRR       /YES, READ CHARACTER
2022 4511          JMS I CHECK /GO CHECK FOR CORRECT MATCH
2023 2000  SB0,   0          /CORRECT CHAR HERE
2024 5230          JMP P2E0   /ERROR, GO TO P2E0
2025 2101  P2T0B, ISZ CTRA   /OK, ALL DONE?
2026 5215          JMP P2TSP,A /NO, REPEAT
2027 5424          JMP I CHAIN /YES, CHAIN
2030 7402  P2E0,  HLT        /TST10 ERR HALT, AC CONTAINS
          /CHAR THAT DID NOT MATCH
          /AGAINST PATTERN, EPRESS
          /KEY CONTINUE
2031 7200          CLA
2032 1223          TAD SB0    /GET CORRECT CHARACTER
2033 7402          HLT
2034 5225          JMP P2T0B  /AC CONTAINS THE EXPECTED CHARACTER

```

```

2035 2001 P2IS1, 1
2036 2067 P2IS2
/READ 2000 CHARACTERS WITH RANDOM DELAY BETWEEN CHARACTERS,
/MATCH EACH CHARACTER READ AGAINST COUNT PATTERN
/
2037 4506 JMS I SYNC /TO SYNC TAPE
2040 4426 JMS I SETCTR /SET COUNT OF
2041 2101 CTRA /-2000 (DEC) IN
2042 4060 -5720 /CTRA
2043 6032 KCC /START READER
2044 4507 JMS I INPATT /INITIALIZE PATTERN
2045 4510 P2IS1A, JMS I GETPT /GET PATTERN CHARACTER
2046 3255 DCA SB1 /STORE AT SB1
2047 4513 JMS I DLYCNT /GENERATE RANDOM DELAY
2050 4430 JMS I DLY1MS /DELAY
2051 6031 KSF /READY?
2052 5251 JMP ,-1 /NO, TEST AGAIN
2053 6036 KRR /YES, READ CHARACTER
2054 4511 JMS I CHECK /GO CHECK FOR CORRECT MATCH

2055 2000 SB1, 0 /CORRECT CHAR HERE
2056 5262 JMP P2E1 /ERROR, GO TO P2E1
2057 2101 P2T1B, ISZ CTRA /OK, ALL DONE?
2060 5245 JMP P2TS1A /NO,
2061 5424 JMP I CHAIN /YES, CHAIN
2062 7402 P2E1, HLT /TST1 ERR HALT, AC CONTAINS
/CHARACTER THAT DID NOT MATCH
/AGAINST PATTERN, DEPRESS
/KEYCONTINUE

2063 7200 CLA
2064 1255 TAD SB1 /GET CORRECT CHARACTER
2065 7402 HLT /AC CONTAINS THE EXPECTED
/CHARACTER

2066 5207 JMP P2T1B

```

```

2067 2002 P2TS2, 2
2070 7777 7777
/READ WITH RANDOM STALL BETWEEN RANDOM CHARACTER GROUPS
/100 GROUPS READ.
/
2071 4506 JMS I SYNC /GO SYNC TAPE
2072 4426 JMS I SETCTR /SET COUNT OF
2073 2101 CTRA /-100 (DEC) IN
2074 7634 -144 /CTRA
2075 6032 KCC /START READER
2076 4527 JMS I INPATT /INITIALIZE PATTERN
2077 4513 P2TS2A, JMS I DLYCNT /SET RANDOM DELAY
2100 4512 JMS I CRCNT /SET RANDOM CHARACTER
2101 2102 CTRB /COUNT IN CTRB
2102 4510 P2TS2B, JMS I GETPT /GET PATTERN CHARACTER
2103 3311 DCA SB2 /AND STORE AT SB2
2104 4430 JMS I DLY1MS /GO DELAY NO OF
2105 6031 KSF /READY?
2106 5305 JMP , -1 /NO, TEST AGAIN
2107 6036 KRB /READ CHARACTER
2110 4511 JMS I CHECK /CHECK FOR CORRECT MATCH
2111 2000 SB2, 0 /AGAINST SB2 CONTENTS
2112 5320 JMP P2E2 /ERROR, GO TO P2E2
2113 2102 ISZ CTRB /OK, ALL CHARS FOR GROUP DONE?
2114 5302 JMP P2TS2B /NO
2115 2101 P2T2C, ISZ CTRA /YES, ALL GROUPS DONE?
2116 5277 JMP P2TS2A /NO
2117 5424 JMP I CHAIN /YES, CHAIN
2120 7402 P2E2, HLT /TST2 ERROR HALT, AC CONTAINS CHAR THAT
/DID NOT MATCH AGAINST PATTERN, DEPRESS KEY
/CONTINUE

2121 7200 CLA
2122 1311 TAD SB2 /GET CORRECT CHARACTER
2123 7402 HLT /AC CONTAINS THE EXPECTED CHARACTER
2124 5315 JMP P2T2C
/

```

2200

PAGE

/PRG11, ASR33TY, AUTOMATIC READER OPTION TEST,
 /CHECKS THAT READER FLAG RESPONDS TO KCC AFTER "READER ON" COMMAND,
 /AND THAT FLAG DOES NOT RESPOND TO KCC AFTER "READER OFF" COMMAND.
 /A TEST IS DONE BETWEEN 1 AND 7 CHARACTERS AFTER EACH READER CONTROL
 /COMMAND. TEST IS CONTINUOUS RUNNING, FAILURES ARE INDICATED BY HALTS.
 /

2200	3237	PRG11, DCA SPFLAG	/CLEAR SPFLAG,
2201	1236	TAD PCHOFF	/TURN OFF PUNCH FEED
2202	4311	JMS TTOUT	
2203	4273	JMS CRPIN	/INITIALIZE DELAY AND CHAR COUNT,
2204	1233	TAD RDRON	/TURN ON READER
2205	4311	JMS TTOUT	
2206	4430	JMS I DLY1MS	/WAIT AN ADDITIONAL 110 MSECS,
2207	6032	KCC	/ISSUE READER START,
2210	4430	JMS I DLY1MS	/DELAY 110 MSECS,
2211	6031	KSF	/FLAG UP?
2212	7602	HLT CLA	/NO, ERROR, FLAG SHOULD BE UP
2213	2102	ISZ CTRB	/DONE FOR N CHARACTER?
2214	5207	JMP ,-5	/NO, REPEAT,
2215	1101	TAD CTRA	/YES, RELOAD CHAR COUNT
2216	3102	DCA CTRB	/INTO CTRB,
2217	1234	TAD RDROFF	/TURN OFF READER
2220	4311	JMS TTOUT	
2221	6032	KCC	/CLEAR READER FLAG,
2222	4430	JMS I DLY1MS	/DELAY 110 MSECS
2223	6032	KCC	/ISSUE READER START
2224	4430	JMS I DLY1MS	/WAIT 110 MSECS,
2225	6031	KSF	/FLAG UP?
2226	7410	SKP	/NO, OK,
2227	7602	HLT CLA	/YES, HALT, FLAG SHOULD BE DOWN
2230	2102	ISZ CTRB	/DONE N TIMES
2231	5223	JMP ,=6	/NO, REPEAT
2232	5203	JMP PRG11+3	/YES, START OVER,
/			
2233	0221	RDRON, 221	
2234	0223	RDROFF, 223	
2235	0222	PCHON, 222	
2236	0224	PCHOFF, 224	
2237	0000	SPFLAG, 0	
2240	0007	K0007, 7	
2241	0377	K0377, 377	
2242	7650	K7650, 7650	
2243	7610	K7610, 7610	

/PRG12, ASR33TY AUTOMATIC PUNCH OPTION TEST
 /CHECKS OPERATION OF AUTOMATIC PUNCH BY PUNCHING RUBOUTS WITH
 /PCHON, AND ALL 0'S CHARACTERS WITH PCHOF, THE TAPE RESULTING
 /SHOULD HAVE ALL RUBOUTS, AS THE TAPE SHOULD NOT ADVANCE
 /WHEN PUNCHING WITH PCHOFF, THE READER IS USED TO CHECK THE
 /TAPE, REPEATED FAILURE OF THE PUNCH FEED TO TURN ON WILL
 /EVENTUALLY BE INDICATED BY TIGHTENING OF SLACK BETWEEN
 /READER AND PUNCH,
 /

2244	1242	PRG12, TAD K7650	/GET (SVA CLA) CODE AND
2245	3326	DCA TTOUTA	/SET AT TTOUTA.
2246	4273	JMS CRPIN	/INITIALIZE DELAY AND CHAR COUNT.
2247	1236	TAD PCHOFF	/TURN OFF PUNCH FEED
2250	4311	JMS TTOUT	
2251	1233	TAD RDRON	/TURN ON READER,
2252	4311	JMS TTOUT	
2253	4311	JMS TTOUT	/PUNCH ALL 0'S CHAR,
2254	2102	ISZ CTRB	/DONE FOR N 0 CHARS?
2255	5253	JMP , -2	/NO, REPEAT,
2256	1241	TAD K0377	/YES, PUNCH A RUBOUT
2257	4311	JMS TTOUT	
2260	1101	TAD CTRA	/RELOAD CHAR COUNT
2261	3102	DCA CTRB	/INTO CTRB
2262	1235	TAD PCHON	/SET SPFLAG
2263	3237	DCA SPFLAG	
2264	1235	TAD PCHON	/TURN ON PUNCH FEED,
2265	4311	JMS TTOUT	
2266	1241	TAD K0377	/PUNCH A RUBOUT
2267	4311	JMS TTOUT	
2270	2102	ISZ CTRB	/DONE FOR N RUBOUTS?
2271	5266	JMP , -3	/NO, REPEAT,
2272	5246	JMP PRG12+2	/YES, START OVER.

/SUB TO INITIALIZE DELAY CAUSED AND SET CHAR COUNT
 CRPIN, 0

2273	0000	JMS I SETCTR	/-110 TO DELAYM
2274	4426	DELAYM	
2275	0023	=156	
2276	7622	JMS I RANDNO	/GET RANDOM NUMBER
2277	4432	AND K0007	
2300	2240	SVA	/STILL NON=0?
2301	7450	JMP , -3	/NO,
2302	5277	CIA	
2303	7041	DCA CTRA	/SET IN CTRA
2304	3101	TAD CTRA	/AND CTRB
2305	1101	DCA CTRB	
2306	3102	DCA SPFLAG	/CLEAR SPFLAG
2307	3237	JMP I CRPIN	/EXIT
2310	5673		


```

/SUB TO OUTPUT DATA TO TELEPRINTER/PUNCH, IF SPFLAG
/IS SET, READ A CHARACTER FROM TAPE READER AND CHECK
/THAT IT IS A RUBOUT,
TTOUT, 1
2311 2000
2312 6046      TLS           /OUTPUT CHAR,
2313 6041      TSP           /DONE?
2314 5313      JMP , -1       /NO, WAIT
2315 6042      TCF           /YES, CLEAR FLAG,
2316 7200      CLA
2317 1237      TAD SPFLAG
2320 7650      SVA CLA       /PUNCH ON?
2321 5711      JMP I TTOUT   /NO, EXIT,
2322 6032      KCC           /YES, START READER,
2323 6031      KSF           /FLAG UP?
2324 5323      JMP , -1       /NO, WAIT
2325 6034      KRS           /YES, READ CHAR
2326 7650      TTOUTA, SVA CLA /OR (SKP CLA)
2327 5711      JMP I TTOUT   /CHAR IS 0, EXIT,
2330 1243      TAD K7610     /GET (SKP CLA) AND
2331 3326      DCA TTOUTA    /SET AT TTOUTA,
2332 6034      KRS           /REREAD CHAR,
2333 1117      TAD MRBOUT    /TAD (-37)
2334 7650      SVA CLA       /WAS IT A RUBOUT?
2335 5711      JMP I TTOUT   /YES, OK,
2336 6034      KRS           /NO, ERROR, REREAD CHAR,
2337 7402      HLT           /DISPLAY CHAR,
2340 7200      CLA
2341 5711      JMP I TTOUT   /EXIT,

```

4

C

C

O

AL1	1141	M4	1074	P1TS3A	1726	RANTAD	1442
AL2	1144	MCTR	1025	P1TS3B	1732	RJROFF	2234
ALIGN	1120	MIL1	1060	P1TS3C	1743	RJROM	2233
ATEMP	1147	MILCTR	1064	P1TS4	1746	READCK	1071
C100	1075	MOVE	1600	P1TS4A	1756	RTNVD	1062
C240	1076	MOVEA	1613	P2E0	2030	SB1	2023
CHAIN	1024	MHOUT	1117	P2F1	2062	SB1	2055
CHAINN	10257	MSCTR	1063	P2F2	2120	SB2	2111
CHCK	1031	NXTST	1061	P2T0R	2025	SBSP	1076
CHECK	1111	P2E0	1221	P2T1R	2057	SCCTR	1062
CHRCNT	1022	P2F1	1244	P2T2C	2115	SCNT	1103
CPIU	1056	P2E2A	1267	P2TS0	2005	SETCTR	1026
CRONT	1112	P2E2B	1271	P2TS0A	2015	SHALT	10313
CRMSK	10517	P0F3A	1320	P2TS1	2035	SHLT	1025
CRPIN	1273	P0F3B	1322	P2TS1A	2045	SKJPM	1077
CTRA	1011	P0F4A	1345	P2TS2	2067	SKIPPA	1100
CTRB	10102	P0F4B	1362	P2TS2A	2077	SPFLAG	2237
CTSK	10566	P2E5	1417	P2TS2B	2102	SR5MSK	1055
CURTST	10057	P2E6A	1456	PCHOFF	2236	SRSET	10232
DELAYM	10023	P2E6B	1462	PCHON	2235	SRST	10031
DLCNT	10520	P0TS0	1205	PFLAG	10114	SRT0A	1017
DLY1MS	10030	P0TS1	1225	PRG0	1200	SRT0R	1022
DLY1SC	10027	P0TS1A	1232	PRG1	1600	SRT1A	1035
DLYCNT	10113	P0TS1B	1235	PRG10	1060	SRT2A	1046
DLYMS	10345	P0TS2	1246	PRG11	2200	SRT2R	1051
DLYMSK	10530	P0TS2A	1256	PRG12	2244	SRT3A	1064
DLYSC	10333	P0TS3	1275	PRG2	2000	START	10200
ERRCNT	1101	P0TS3A	1305	PRG3	1000	STCTR	10322
ERRCTR	1117	P0TS4	1327	PRG4	1006	SYNC	10106
FADJR	10623	P0TS4A	1334	PRG5	1013	SYNK	10546
FLAG	10072	P0TS4B	1360	PRG6	1031	SYNKA	10552
FORWD	10276	P0TS4C	1371	PRG7	1042	TADDR	10624
GETPT	10110	P0TS5	1400	PRGADR	10231	TEMP	10052
GETPTT	10453	P0TS5A	1410	PRGEND	10274	TEMP1	10053
GETRJD	10233	P0TS6	1424	PRGLIM	10034	TEMQ	10070
GIVE	1150	P0TS6A	1431	PRGMSK	10033	TEMR	10071
H1TTST	1111	P0TS6B	1441	PRGNUM	10035	TSTMSK	10054
ID	10215	P1E0A	1627	PRGTAB	10037	TTOUT	2311
INCRTN	10255	P1E0B	1631	PSW	10036	TTOUTA	2326
IND	1146	P1E1	1651	PT0	10450	UMOVE	10116
INITPT	10444	P1E2	1676	PT1	10451	UPUNCH	10115
INPAT	10107	P1E3A	1717	PTEMP	10021	WCWK	10545
10007	2240	P1E3B	1734	PTFMP1	10022	WTS6A	1466
100377	2241	P1E4	1765	PTMSK	10452	WTS6R	1467
1100	2104	P1TS0	1605	PUNCH	10465		
12000	10105	P1TS0A	1615	RANCON	10430		
17617	2243	P1TS0B	1622	RANDEX	10427		
17650	2242	P1TS1	1635	RANDNO	10032		
177	10073	P1TS1A	1643	RANGEN	10400		
1PB	10066	P1TS2	1656	RANSAV	10443		
1PB5	10067	P1TS2A	1663	RANTAD	10415		
1START	10020	P1TS3	1701	RANTRL	10431		

ERRORS DETECTED: 0

RUN-TIME: 26 SECONDS

PK CORE USED