

94-003/109/24

**XVM/RSX  
SYSTEM MANUAL**

**DEC-XV-IRSMA-A-DN1**

First Printing, March 1976

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

Digital Equipment Corporation assumes no responsibility for the use or reliability of its software on equipment that is not supplied by DIGITAL.

Copyright © 1976 by Digital Equipment Corporation

The postage prepaid READER'S COMMENTS form on the last page of this document requests the user's critical evaluation to assist us in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DIGITAL	DECsystem-10	MASSBUS
DEC	DECTape	OMNIBUS
PDP	DIBOL	OS/8
DECUS	EDUSYSTEM	PHA
UNIBUS	FLIP CHIP	RSTS
COMPUTER LABS	FOCAL	RSX
COMTEX	INDAC	TYPESET-8
DDT	LAB-8	TYPESET-10
DECCOMM	DECsystem-20	TYPESET-11

## CONTENTS

		Page
PART I	PREFACE	
	LIST OF ALL XVM MANUALS	I-1-2
PART II	INTRODUCTION TO RSX	II-1-1
	1.1 THE XVM/RSX ENVIRONMENT	II-1-1
	1.1.1 Differences Between XVM/RSX and RSX PLUS II	II-1-2
	1.2 XVM/RSX HARDWARE	II-1-3
	1.3 XVM/RSX SOFTWARE	II-1-3
	1.4 XVM/RSX CONCEPTS	II-1-3
	1.4.1 Task Scheduling	II-1-3
	1.4.2 Partitioned Core	II-1-5
	1.4.3 Dynamic Reconfiguration	II-1-5
	1.4.4 Real-Time Multiprogramming	II-1-5
	1.4.5 Memory Protection and Relocation	II-1-7
CHAPTER 2	XVM/RSX HARDWARE CAPABILITIES	II-2-1
	2.1 MINIMUM HARDWARE CONFIGURATION	II-2-1
	2.2 EXPANDED HARDWARE FACILITIES	II-2-2
	2.3 EXTENDED MEMORY MANAGEMENT FACILITIES	II-2-3
	2.4 DISK SUPPORT	II-2-3
	2.5 SUPPORT OF UNICHANNEL	II-2-5
CHAPTER 3	XVM/RSX SYSTEM SOFTWARE	II-3-1
	3.1 INTRODUCTION TO SOFTWARE CAPABILITIES	II-3-1
	3.2 EXECUTIVE	II-3-2
	3.3 MONITOR CONSOLE ROUTINE	II-3-2
	3.4 TASK DEVELOPMENT FUNCTIONS	II-3-3
	3.5 BATCH PROCESSOR	II-3-3
	3.6 I/O DEVICE HANDLER TASKS	II-3-4
CHAPTER 4	GUIDE TO RSX DOCUMENTATION	II-4-1
	4.1 AN OVERVIEW OF THE XVM/RSX SYSTEM	II-4-1
	4.2 SYSTEM MANAGEMENT	II-4-1
	4.3 MONITOR CONSOLE ROUTINE (MCR)	II-4-1
	4.4 SYSTEM DIRECTIVES	II-4-1
	4.5 INPUT/OUTPUT OPERATIONS	II-4-2
	4.6 ON-LINE TASK DEVELOPMENT	II-4-2
	4.7 BATCH-PROCESSING	II-4-2
	4.8 SYSTEM LISTS AND ORGANIZATION	II-4-2
	4.9 GRAPHICS SYSTEM	II-4-2
	4.10 ADVANCED TASK DEVELOPMENT	II-4-2
	4.11 XVM/RSX V1B INSTALLATION GUIDE	II-4-2
INDEX		II-Index-1

CONTENTS (Cont'd)

		Page
PART III	SYSTEM MANAGEMENT	
CHAPTER 1	CORE MANAGEMENT	III-1-1
1.1	SYSTEM ORGANIZATION	III-1-1
1.2	PARTITION MANAGEMENT	III-1-1
1.2.1	Placement of the Executive	III-1-2
1.2.2	System COMMON Blocks	III-1-2
1.2.3	Monitor Console Routine	III-1-3
1.2.4	I/O Device Handler Tasks	III-1-3
1.2.5	MULTIACCESS Monitor and Task Development Functions	III-1-5
1.2.6	Unichannel Space	III-1-6
1.2.7	User Partitions	III-1-7
1.3	NODE ANALYSIS	III-1-8
1.3.1	Node Sizes	III-1-8
1.3.2	Estimating Number of Nodes	III-1-8
1.4	TYPES OF CORE SPACE	III-1-11
1.4.1	Permanent Core Space	III-1-11
1.4.2	Semipermanent Core Space	III-1-13
1.4.3	Exec-Mode Core Space	III-1-14
1.4.4	User-Mode Core Space	III-1-16
1.5	SAMPLE CORE ALLOCATIONS	III-1-16
1.5.1	Batch System Configuration	III-1-16
1.5.2	Real-Time Graphics Configuration	III-1-17
1.5.3	Real-Time TDV Configuration	III-1-19
1.5.4	Small MULTIACCESS Configuration	III-1-19
1.5.5	Large MULTIACCESS/Batch Configuration	III-1-20
APPENDIX A	CORE SIZES OF SYSTEM PROGRAMS	III-A-1
APPENDIX B	RSX ASSEMBLY AND TASK-BUILDING PARAMETERS	III-B-1
B.1	MONITOR CONSOLE ROUTINE FUNCTION SOURCES	III-B-1
B.1.1	ABO.6 SRC ABORT MCR Function	III-B-1
B.1.2	ACCESS 001 ACCESS MCR Function	III-B-1
B.1.3	ADV.02 SRC ADD-A-DEVICE MCR Function	III-B-2
B.1.4	ASP.05 SRC ASSIGN-A-PARTITION MCR Function	III-B-2
B.1.5	CAN.5 SRC CANCEL MCR Function	III-B-2
B.1.6	COM.10 COMMON BLOCK DEFINITIONS MCR Function	III-B-2
B.1.7	CON.12 SRC CONSTRUCT MCR Function	III-B-2
B.1.8	DAT.11 SRC DATE MCR Function	III-B-3
B.1.9	DEQ.07 SRC DEQUE LIST MCR Function	III-B-3
B.1.10	DEV.10 SRC DEVICES AND ASSIGNMENTS MCR Function	III-B-3
B.1.11	DIS.5 SRC DISABLE MCR Function	III-B-3
B.1.12	DOS.12 DOS BOOTSTRAP MCR Function	III-B-4
B.1.13	DSM.05 SRC DISMOUNT-USER-DISK MCR Function	III-B-4
B.1.14	DTC.7 SRC DEFINE TERMINAL MCR Function	III-B-4
B.1.15	ENA.5 SRC ENABLE MCR Function	III-B-4

CONTENTS (Cont'd)

		Page
B.1.16	ETI.11 SRC: ENTER TIME MCR Function	III-B-5
B.1.17	FIX.10 SRC FIX MCR Function	III-B-5
B.1.18	INS.25 SRC INSTALL MCR Function	III-B-5
B.1.19	MNT.09 SRC MOUNT-USER-DISK MCR Function	III-B-5
B.1.20	OPE.64 SRC OPEN MCR Function	III-B-6
B.1.21	PAR.11 SRC PARTITION DEFINITIONS MCR Function	III-B-6
B.1.22	RCF.25 SRC RECONFIGURE MCR Function	III-B-6
B.1.23	REA.35 SRC REASSIGN MCR Function	III-B-6
B.1.24	REM.34 SRC REMOVE MCR Function	III-B-7
B.1.25	REQ.11 SRC REQUEST MCR Function	III-B-7
B.1.26	RES.5 SRC RESUME MCR Function	III-B-7
B.1.27	RUN.10 SRC RUN MCR Function	III-B-7
B.1.28	SAV.47 SRC SAVE MCR Function	III-B-7
B.1.29	SCH.12 SRC SCHEDULE MCR Function	III-B-8
B.1.30	SLICE 009 TIME-SLICING MCR Function	III-B-8
B.1.31	STROBE 008 STROBE MCR Function	III-B-8
B.1.32	SYN.10 SRC SYNC MCR Function	III-B-8
B.1.33	TAS.61 SRC TASK LIST MCR Function	III-B-8
B.1.34	TIM.5 SRC TIME MCR Function	III-B-9
B.1.35	UFD 001 UFD MCR Function	III-B-9
B.1.36	UNF.7 SRC UNFIX MCR Function	III-B-9
B.1.37	XQT.7 SRC EXECUTE MCR Function	III-B-9
B.2	TASK DEVELOPMENT FUNCTION SOURCES	III-B-9
B.2.1	TPOLLR 021	III-B-9.1
B.2.2	PWAIT 000	III-B-9.1
B.2.3	ABORT 001	III-B-9.1
B.2.4	INIT 009	III-B-9.1
B.2.5	SYDISP 010	III-B-9.1
B.2.6	XQT1 001	III-B-9.1
B.2.7	XQT2 003	III-B-9.1
B.2.8	LOGON1 014	III-B-9.1
B.2.9	LOGON2 015	III-B-9.2
B.2.10	LOGOFF 008	III-B-9.2
B.2.11	STOPIT 002	III-B-9.2
B.2.12	EXIT 003	III-B-9.2
B.2.13	PARTS 000	III-B-9.2
B.2.14	DEV 013	III-B-9.2
B.2.15	ASSIGN 019	III-B-9.2
B.2.16	BCON 012: CONSTRUCT TDV Function	III-B-10
B.2.17	BIN.25 SRC: INSTALL TDV Function	III-B-10
B.2.18	BRM.34 SRC: REMOVE TDV Function	III-B-10
B.2.19	BRQ.14 SRC: REQUEST TDV Function	III-B-10
B.2.20	DEL.16 SRC: FILE DELETE TDV Function	III-B-11
B.2.21	DIR.70 SRC: DIRECTORY LISTING TDV Function	III-B-11
B.2.22	DSM.05 SRC: DISMOUNT-USER-DISK TDV Function	III-B-11
B.2.23	DTD.15 SRC: DECTAPE DIRECTORY TDV Function	III-B-11
B.2.24	FORTRAN IV Compiler	III-B-11
B.2.25	FIN.28 SRC: FILE INPUT, OUTPUT, and LIST TDV Functions	III-B-12
B.2.26	COPY 003: Copy From LUN to LUN With File Name	III-B-12

CONTENTS (Cont'd)

	Page	
B.2.27	STATUS SRC: Main Program for MULTIACCESS Status Display	III-B-12
B.2.28	TASKS SRC	III-B-12.1
B.2.29	USERS SRC	III-B-12.1
B.2.30	CORE SRC	III-B-12.1
B.2.31	EDIT15 142: Text Editor	III-B-12.1
B.2.32	MAC.9 SRC: Resident MACRO Assembler	III-B-12.1
B.2.33	MAC15 127: MACRO Assembler Overlay	III-B-12.1
B.2.34	CREF 126: MACRO Assembler Overlay	III-B-13
B.2.35	MNT.09 SRC: MOUNT-USER-DISK TDV Function	III-B-13
B.2.36	NEW.3 SRC: NEW DECTAPE DIRECTORY TDV Function	III-B-13
B.2.37	REN.15 SRC: FILE RENAME TDV Function	III-B-13
B.2.38	RSXODT 016: Octal Debugging Technique	III-B-13
B.2.39	TKB.101 SRC: Task Builder	III-B-14
B.3	BATCH PROCESSING SOURCES	III-B-15
B.3.1	BDRES 100: Batch Handler	III-B-15
B.3.2	ACD.03 SRC: ACCOUNT DISPLAY TDV Function	III-B-16
B.3.3	ACI.03 SRC: ACCOUNT INITIALIZATION TDV Function	III-B-16
B.3.4	END.01 SRC: BATCH Job Termination Processor	III-B-16
B.3.5	JOB.01 SRC: BATCH Job Startup Function	III-B-16
B.3.6	Miscellaneous Batch Functions	III-B-16
B.3.7	OPR 013: BATCH Operator Interface	III-B-17
B.3.8	QUEUE 100: QUEUE BATCH Function	III-B-17
B.3.9	Rename FIN.27 SRC to DEC.27 SRC	III-B-17
B.3.10	SCHED 006: SCHEDULE BATCH Function	III-B-17
B.4	I/O DEVICE HANDLERS SOURCES	III-B-18
B.4.1	AD.... 017 Analog-to-Digital Converter Handler	III-B-18
B.4.2	AF.10 SRC: Automatic Flying Capacitor Scanner Handler	III-B-18
B.4.3	CC.... 007: COMMON Communicator Handler	III-B-18
B.4.4	CD.... 022 Card Reader Handler	III-B-19
B.4.5	CP.... SRC: Card Punch Handler	III-B-19
B.4.6	CR.03B nnn: CR03B Card Reader Handler	III-B-20
B.4.7	DT.61 SRC: DEctape Handler	III-B-20
B.4.8	LP.33 SRC: Line Printer Handler	III-B-20
B.4.9	MT.25 SRC: Magtape Handler	III-B-21
B.4.10	MTMOV 019: Magtape Handler Overlay	III-B-21
B.4.11	MTPGET 008: Magtape Handler Overlay	III-B-21
B.4.12	MTWRA7 010: Magtape Handler Overlay	III-B-21
B.4.13	MTREA7 007: Magtape Handler Overlay	III-B-21
B.4.14	MTREA9 010: Magtape Handler Overlay	III-B-21
B.4.15	MTRWB 015: Magtape Handler Overlay	III-B-21
B.4.16	MTWRA9 008: Magtape Handler Overlay	III-B-21
B.4.17	PP.13 SRC: Paper Tape Punch Handler	III-B-22
B.4.18	PR.15 SRC: Paper Tape Reader Handler	III-B-22
B.4.19	RFRES 076: Fixed-Head Disk File Handler	III-B-22

CONTENTS (Cont'd)

	Page
B.4.20	RFCLOS 075: Disk File Handler Overlay III-B-22
B.4.21	RFCREA 075: Disk File Handler Overlay III-B-22
B.4.22	RFDLET 075: Disk File Handler Overlay III-B-22
B.4.23	RFOPEN 076: Disk File Handler Overlay III-B-22
B.4.24	RFREAD 075: Disk File Handler Overlay III-B-22
B.4.25	UD.13 SRC: Universal Digital Controller Handler III-B-22
B.4.26	VT.23 SRC: VT-15 Graphics Handler III-B-23
B.4.27	VW.04 SRC: Spark Tablet Handler III-B-23
B.4.28	XY.12 SRC: -- XY Plotter Handler III-B-23
B.5	MISCELLANEOUS SOURCES III-B-24
B.5.1	AUTORM 022: Autoremove Task III-B-24
B.5.2	FININS 029: Task for Finishing Exe- cutable Task Installation III-B-24
B.5.3	NODCNT 003: RSX Small Node Counter III-B-25
B.5.4	POLLER 006: Unichannel Poller III-B-25
B.5.5	RMC.13 SRC: MACRO Definition File III-B-25
B.5.6	RSX.BT 024: DOS-to-RSX Bootstrap III-B-25
B.5.7	TNTERM 005 Task Termination Notice Processor Task III-B-25
B.6	SYSTEM LIBRARY SOURCES III-B-25
B.7	EXECUTIVE SOURCES III-B-28
B.7.1	RSX.P1 207: Executive III-B-28
B.7.2	RSX.P2 206: Executive III-B-28
B.8	CHECKOUT PACKAGE SOURCES III-B-30
B.8.1	CANCOP SRC: Cancelling Checkout Package Execution III-B-30
B.8.2	COPHM SRC: Logging Hours of Checkout III-B-30
B.8.3	COPST 007: Synchronizing Checkout Task Execution III-B-30
B.8.4	DTRUN 004: Verifying DEctape Integrity III-B-30
B.8.5	DTASGN 004: DTRUN Subroutine III-B-30
B.8.6	DTCLOS 004: DTRUN Subroutine III-B-30
B.8.7	DTDUMMY SRC: DTRUN Subroutine III-B-30
B.8.8	DTENTR 004: DTRUN Subroutine III-B-31
B.8.9	DTWRIT 004: DTRUN Subroutine III-B-31
B.8.10	DTREAD 004: DTRUN Subroutine III-B-31
B.8.11	DTSEEK 004: DTRUN Subroutine III-B-31
B.8.12	LOG.3 SRC: LOG Subroutine III-B-31
B.8.13	RX.13 SRC: Checking Register Contents III-B-31
B.8.14	SATCHK 006: Verifying Disk Operation III-B-31
B.8.15	TTYIO 005: Checking Terminal Relia- bility III-B-31
B.9	SYSTEM LIBRARY BINARIES III-B-31
B.9.1	.LIBRX BIN Library III-B-32
B.9.2	.LIBFX BIN Library III-B-36
APPENDIX C	ASSEMBLY PARAMETERS FOR FORTRAN OTS COMPONENTS III-C-1
INDEX	III-Index-1
PART IV	MONITOR CONSOLE ROUTINE
CHAPTER 1	INTRODUCTION TO THE MONITOR CONSOLE ROUTINE IV-1-1
1.1	MCR FUNCTION TASKS IV-1-1

CONTENTS (Cont'd)

		Page
1.2	EXECUTION OF RESIDENT MCR	IV-1-1
1.3	MCR/SYSTEM COMMUNICATION	IV-1-1
1.4	MCR COMMAND CONVENTIONS	IV-1-3
CHAPTER 2 MCR FUNCTION TASKS		IV-2-1
2.1	ABORT: ABORTING TASK EXECUTION	IV-2-2
2.2	ACCESS: MODIFYING A MEMORY BLOCKS SHARED ACCESS PRIVILEGES	IV-2-4
2.3	ACD: REQUESTING AN ACCOUNT FILE DUMP	IV-2-5
2.4	ACI: INITIALIZING THE ACCOUNT FILE	IV-2-7
2.5	ADV: ADDING A NEW DEVICE	IV-2-9
2.6	ASP: ASSIGNING A PARTITION	IV-2-12
2.7	CANCEL: CANCELLING REQUESTS FOR A TASK	IV-2-13
2.8	COMMON BLOCK: PRINTING COMMON BLOCK DEFINITIONS	IV-2-14
2.9	CONSTRUCT: INSTALLING A TASK ON A USER DISK	IV-2-15
2.10	DATE: RETRIEVING TIME AND DATE	IV-2-16
2.11	DEQ: LISTING SYSTEM DEQUES	IV-2-17
2.12	DEVICES AND ASSIGNMENTS: PRINTING A CURRENT LIST	IV-2-23
2.13	DISABLE: DISABLING A TASK	IV-2-25
2.14	DOS: BOOTSTRAPPING THE DOS SYSTEM	IV-2-26
2.15	DSM: DISMOUNTING A DISK	IV-2-27
2.16	DTC: DEFINING TERMINAL CHARACTERISTICS	IV-2-29
2.17	ENABLE: REENABLING A TASK	IV-2-30
2.18	ETIME: ENTERING TIME AND DATE	IV-2-31
2.19	EXECUTE: REQUESTING TASK EXECUTION FROM A USER DISK	IV-2-32
2.20	FIX: FIXING A TASK IN CORE	IV-2-34
2.21	INSTALL: ADDING A TASK	IV-2-35
2.22	MNT: MOUNTING A DISK	IV-2-36
2.23	OPEN: EXAMINING CORE OR DISK REGISTERS	IV-2-37
2.24	OPERATOR: BATCH CONTROL FOR OPERATOR	IV-2-41
2.25	PARTITIONS: PRINTING PARTITION DEFINITIONS	IV-2-42
2.26	RCF: RECONFIGURING CORE LAYOUT	IV-2-45
2.27	RCP: RECONFIGURING PARTITIONS	IV-2-49
2.28	REASSIGN: CHANGING DEVICE ASSIGNMENTS	IV-2-51
2.29	REMOVE: DELETING A TASK	IV-2-54
2.30	REQUEST: REQUESTING TASK EXECUTION	IV-2-55
2.31	RESUME: RESUMING TASK EXECUTION	IV-2-56
2.32	RUN: ACTIVATING TASK EXECUTION	IV-2-57
2.33	SAVE: BACKING UP A SYSTEM	IV-2-59
2.34	SCHEDULE: SCHEDULING TASK EXECUTION	IV-2-61
2.34A	SHUT: SHUT DOWN MULTIACCESS	IV-2-62.1
2.35	SLICE: INITIATING TIME-SLICING WITHIN A PRIORITY RANGE	IV-2-63
2.36	STROBE: STROBE AND LIST SYSTEM DEQUES	IV-2-66
2.37	SYNC: SYNCHRONIZING TASK EXECUTION	IV-2-68
2.38	TASK LIST: PRINTING TASK DESCRIPTIONS	IV-2-70
2.39	TIME: RETRIEVING THE TIME	IV-2-71
2.40	UFD: PRINTING LUN-UFD RELATIONSHIPS	IV-2-72
2.41	UNFIX: FREEING A CORE PARTITION	IV-2-73



CONTENTS (Cont'd)

	Page
CHAPTER 3 MCR ERROR MESSAGES	IV-3-1
INDEX	IV-Index-1
PART V SYSTEM DIRECTIVES	
CHAPTER 1 INTRODUCTION TO SYSTEM DIRECTIVES	V-1-1
1.1 FUNCTION OF SYSTEM DIRECTIVES	V-1-1
1.2 DESCRIPTION OF DIRECTIVES	V-1-1
1.3 PROCESSING A DIRECTIVE	V-1-2
1.4 DIRECTIVE ERRORS	V-1-2
1.5 DIRECTIVE CONVENTIONS	V-1-3
CHAPTER 2 SYSTEM DIRECTIVES	V-2-1
2.1 CANCEL: CANCELLING REQUESTS FOR A TASK	V-2-2
2.2 CONNECT: CONNECTING TO AN INTERRUPT LINE	V-2-4
2.3 DATE: RETRIEVING TIME AND DATE	V-2-8
2.4 DISABLE: DISABLING A TASK	V-2-10
2.5 DISCONNECT: DISCONNECTING FROM AN IN- TERRUPT LINE	V-2-12
2.6 ENABLE: REENABLING A TASK	V-2-14
2.7 EXECUTE: REQUESTING TASK EXECUTION FROM A USER DISK	V-2-16
2.8 EXIT: TERMINATING EXECUTION OF A TASK	V-2-19
2.9 FIX: FIXING A TASK IN CORE	V-2-22
2.10 MARK: SETTING AN EVENT VARIABLE IN THE FUTURE	V-2-24
2.11 PARINF: RETURNING PARTITION ADDRESS AND SIZE	V-2-27
2.12 QJOB: QUEUING A BATCH JOB	V-2-29
2.13 QUEUE I/O: QUEUING REQUESTS FOR AN I/O DEVICE	V-2-34
2.14 RAISEB: RAISING THE MEMORY-PROTECT BOUND	V-2-36
2.15 REQUEST: REQUESTING TASK EXECUTION	V-2-37
2.15A REQUEST MAPPED: REQUESTING A TASK WITH MAPPED LUNS	V-2-39.1
2.16 RESUME: RESUMING TASK EXECUTION	V-2-40
2.17 RUN: ACTIVATING TASK EXECUTION	V-2-42
2.18 SCHEDULE: SCHEDULING TASK EXECUTION	V-2-47
2.19 SETJEA: INITIALIZING FLOATING-POINT EXIT REGISTER	V-2-52
2.20 SHARE: INVOKING CORE SHARING	V-2-53
2.21 SPY AND SPYREL: EXAMINING CORE LOCATIONS	V-2-55
2.22 SPYSET: MODIFYING CORE LOCATIONS	V-2-57
2.23 SUSPEND: SUSPENDING TASK EXECUTION	V-2-59
2.24 SYNC: SYNCHRONIZING TASK EXECUTION	V-2-60
2.25 TSKNAM: RETURNING THE NAME OF THE ISSUING TASK	V-2-65
2.26 UNFIX: FREEING A CORE PARTITION	V-2-67
2.27 UNMARK: CANCELLING MARK-TIME REQUESTS	V-2-69
2.28 WAIT: WAITING FOR THE NEXT SIGNIFICANT EVENT	V-2-70

CONTENTS (Cont'd)

		Page
	2.29 WAITFOR: WAITING FOR AN EVENT VARIABLE TO BE SET	V-2-71
	2.30 XFRCMD: TRANSFERRING TDV COMMAND LINE	V-2-73
CHAPTER 3	SYSTEM MACROS	V-3-1
	3.1 INTENTRY: ENTERING REGISTER SAVE ROUTINE	V-3-2
	3.2 INTEXT: ENTERING REGISTER RESTORE ROUTINE	V-3-3
CHAPTER 4	EVENT VARIABLES	V-4-1
APPENDIX A	THE MACRO DEFINITIONS FILE	V-A-1
	A.1 REQUEST: REQUESTING TASK EXECUTION	V-A-2
	A.2 SCHEDULE: SCHEDULING TASK EXECUTION	V-A-2
	A.3 RUN: ACTIVATING TASK EXECUTION	V-A-2
	A.4 SYNC: SYNCHRONIZING TASK EXECUTION	V-A-3
	A.5 CANCEL: CANCELLING REQUESTS FOR A TASK	V-A-3
	A.6 SUSPEND: SUSPENDING TASK EXECUTION	V-A-3
	A.7 RESUME: RESUMING TASK EXECUTION	V-A-3
	A.8 MARK: SETTING AN EVENT VARIABLE IN THE FUTURE	V-A-4
	A.9 WAITFOR: WAITING FOR AN EVENT VARIABLE TO BE SET	V-A-4
	A.10 WAIT: WAITING FOR THE NEXT SIGNIFICANT EVENT	V-A-4
	A.11 EXIT: TERMINATING EXECUTION OF A TASK	V-A-4
	A.12 CONNECT: CONNECTING TO AN INTERRUPT LINE	V-A-4
	A.13 DISCONNECT: DISCONNECTING FROM AN INTERRUPT LINE	V-A-5
	A.14 DISABLE: DISABLING A TASK	V-A-5
	A.15 ENABLE: REENABLING A TASK	V-A-5
	A.16 FIX: FIXING A TASK IN CORE	V-A-5
	A.17 UNFIX: FREEING A CORE PARTITION	V-A-5
	A.18 DATE: RETRIEVING TIME AND DATE	V-A-6
	A.19 INTENTRY: ENTERING REGISTER SAVE ROUTINE	V-A-6
	A.20 INTEXT: ENTERING REGISTER RESTORE ROUTINE	V-A-6
APPENDIX B	REGISTERS SAVED DURING SAVE AND RESTORE OPERATIONS	V-B-1
APPENDIX C	.SIXBT CHARACTER SET	V-C-1
INDEX		V-Index-1
PART VI	INPUT/OUTPUT OPERATIONS	
CHAPTER 1	RSX INPUT/OUTPUT	VI-1-1
	1.1 INTRODUCTION TO RSX I/O	VI-1-1
	1.2 I/O TABLES, LISTS, AND TASKS	VI-1-1
	1.2.1 Logical Unit Table	VI-1-1
	1.2.2 Attach Flag Table	VI-1-2
	1.2.3 Physical Device List	VI-1-2

## CONTENTS (Cont'd)

	Page
1.2.4 I/O Rundown Task and Queue	VI-1-3
1.3 I/O DEVICE HANDLER TASKS	VI-1-4
1.3.1 Handler Initialization	VI-1-6
1.3.2 I/O Request Queuing	VI-1-6
1.3.3 Event Variables	VI-1-7
1.3.4 I/O Request Processing	VI-1-7
1.3.5 Handler Exit	VI-1-7
1.3.6 I/O Data Modes	VI-1-8
 CHAPTER 2 STANDARD I/O FUNCTIONS	 VI-2-1
2.1 QUEUE I/O: QUEUING REQUESTS FOR A DEVICE	VI-2-3
2.2 ABORT: ABORTING I/O FOR A TASK	VI-2-5
2.3 ATTACH: ATTACHING AN I/O DEVICE	VI-2-6
2.4 CLOSE: CLOSING A FILE	VI-2-7
2.5 DELETE: DELETING A FILE	VI-2-9
2.6 DETACH: FREEING AN ATTACHED I/O DEVICE	VI-2-11
2.7 DISCONNECT & EXIT: CLEARING THE INTERRUPT LINE	VI-2-12
2.8 ENTER: OPENING A FILE FOR OUTPUT	VI-2-13
2.9 HINF: REQUESTING I/O HANDLER INFORMATION	VI-2-15
2.10 PREAL: PREALLOCATING I/O BUFFERS	VI-2-19
2.11 READ: READING FROM AN I/O DEVICE	VI-2-20
2.12 RENAME: RENAMING A FILE	VI-2-21
2.13 SEEK: OPENING A FILE FOR INPUT	VI-2-23
2.14 WRITE: WRITING TO AN I/O DEVICE	VI-2-25
 CHAPTER 3 DISK FILE I/O AND RF DISK I/O	 VI-3-1
3.1 RELATIONSHIP OF RF, RP, AND RK	VI-3-1
3.2 RF HANDLER TASK	VI-3-1
3.3 DESIGN DECISIONS	VI-3-1
3.4 SEQUENTIAL-ACCESS FILES	VI-3-2
3.4.1 Data Records Within a Sequential-Access File	VI-3-2
3.5 RANDOM-ACCESS FILES	VI-3-3
3.5.1 Data Records Within a Random-Access File	VI-3-4
3.6 USER FILE DIRECTORY (UFD)	VI-3-4
3.7 RF HANDLER STRUCTURE	VI-3-7
3.8 RF HANDLER REQUESTS	VI-3-8
3.8.1 HINF: Requesting Handler Task Information	VI-3-10
3.8.2 SEEK: Opening a File for Input	VI-3-10
3.8.3 ENTER: Opening a File for Output	VI-3-10
3.8.4 DELETE: Deleting a File Name from the Directory	VI-3-11
3.8.5 RENAME: Opening a File for Renaming	VI-3-11
3.8.6 PREAL: Preallocating I/O Buffer Space	VI-3-11
3.8.7 ABORT: Aborting I/O for a Task	VI-3-11
3.8.8 DISCONNECT & EXIT: Clearing the Interrupt Line	VI-3-11
3.9 CLOSE: CLOSING A FILE	VI-3-12
3.10 CREATE: CREATING A RANDOM-ACCESS FILE	VI-3-13
3.11 ERROR CLOSE: HANDLER'S INTERNAL CLOSING OF A FILE	VI-3-16

CONTENTS (Cont'd)

		Page
	3.12 READ: READING INPUT INTO A BUFFER	VI-3-17
	3.13 WRITE: WRITING OUTPUT FROM A BUFFER	VI-3-18
CHAPTER 4	RK DISK I/O	VI-4-1
	4.1 RK HANDLER TASK	VI-4-1
	4.2 DISK PLATTERS AND DISK ADDRESSES	VI-4-1
CHAPTER 5	RP DISK I/O	VI-5-1
	5.1 RP HANDLER TASK	VI-5-1
	5.2 DISK PLATTERS AND DISK ADDRESSES	VI-5-1
CHAPTER 6	DISK DRIVER I/O	VI-6-1
	6.1 DISK DRIVER TASKS	VI-6-1
	6.2 BIT MAPS	VI-6-2
	6.3 DISK ERRORS	VI-6-3
	6.4 DISK DRIVER REQUESTS	VI-6-3
	6.4.1 HINF: Requesting Driver Task Information	VI-6-4
	6.4.2 ABORT: Aborting I/O for a Task	VI-6-5
	6.5 ALLOCATE: RESERVING STORAGE	VI-6-6
	6.6 DEALLOCATE: FREEING STORAGE	VI-6-9
	6.7 GET: READING FROM DISK	VI-6-12
	6.8 PUT: WRITING TO DISK	VI-6-16
	6.9 UPKEV: UNPACKING AN EVENT VARIABLE	VI-6-20
CHAPTER 7	DECTAPE I/O	VI-7-1
	7.1 DT HANDLER TASK	VI-7-1
	7.2 DT HANDLER REQUESTS	VI-7-1
	7.2.1 HINF: Requesting Handler Task Information	VI-7-2
	7.2.2 ATTACH: Obtaining Exclusive Use of a Device	VI-7-3
	7.2.3 DETACH: Releasing an Attached Device	VI-7-3
	7.2.4 READ: Reading Input into a Buffer	VI-7-3
	7.2.5 WRITE: Writing Output from a Buffer	VI-7-3
	7.2.6 SEEK: Opening a File for Input	VI-7-3
	7.2.7 ENTER: Opening a File for Output	VI-7-3
	7.2.8 CLOSE: Closing a File	VI-7-3
	7.2.9 DISCONNECT & EXIT: Clearing the Interrupt Line	VI-7-4
	7.3 GET: READING FROM DECTAPE	VI-7-5
	7.4 PUT: WRITING TO DECTAPE	VI-7-6
CHAPTER 8	MAGTAPE I/O	VI-8-1
	8.1 MT HANDLER TASK	VI-8-1
	8.2 MT HANDLER REQUESTS	VI-8-1
	8.2.1 HINF: Requesting Handler Task Information	VI-8-3
	8.2.2 ABORT: Aborting I/O for a Task	VI-8-3
	8.3 BSPFIL: BACKSPACING ONE OR MORE FILES	VI-8-4
	8.4 BSPREC: BACKSPACING ONE OR MORE RECORDS	VI-8-5

CONTENTS (Cont'd)

	Page	
8.5	FORMAT: SPECIFYING TAPE FORMAT	VI-8--6
8.6	FSPEOT: SPACING FORWARD TO EOT	VI-8--8
8.7	FSPFIL: SPACING FORWARD ONE OR MORE FILES	VI-8--9
8.8	FSPREC: SPACING FORWARD ONE OR MORE RECORDS	VI-8--10
8.9	LABEL: READING OR WRITING A TAPE LABEL	VI-8--11
8.10	MOUNT: MOUNTING OR DISMOUNTING TAPE	VI-8--12
8.10.1	MOUNT a Labeled Tape	VI-8--12
8.10.2	MOUNT an Unlabeled Tape	VI-8--13
8.10.3	DISMOUNT a Tape	VI-8--13
8.11	MTGET: READING FROM TAPE INTO USER'S BUFFER	VI-8--14
8.12	MTPUT: WRITING TO TAPE FROM USER'S BUFFER	VI-8--16
8.13	ERROR RECOVERY	VI-8--17
8.13.1	Handler Recovery	VI-8--17
8.13.2	User Recovery	VI-8--17
8.14	RDCOMP: READING AND COMPARING A RECORD	VI-8--20
8.15	READ: READING INPUT INTO A BUFFER	VI-8--22
8.15.1	IOPS BINARY (Mode 0)	VI-8--22
8.15.2	IMAGE BINARY (Mode 1)	VI-8--22
8.15.3	IOPS ASCII (Mode 2)	VI-8--22
8.15.4	IMAGE ASCII (Mode 3)	VI-8--23
8.16	REWIND: REWINDING THE TAPE	VI-8--24
8.17	WREOF: WRITING AN END-OF-FILE MARK	VI-8--25
8.18	WRITE: WRITING OUTPUT FROM A BUFFER	VI-8--26
8.18.1	IOPS BINARY (Mode 0)	VI-8--26
8.18.2	IMAGE BINARY (Mode 1)	VI-8--26
8.18.3	IOPS ASCII (Mode 2)	VI-8--26
8.18.4	IMAGE ASCII (Mode 3)	VI-8--27
CHAPTER 9 TERMINAL I/O		VI-9-1
9.1	TTY HANDLER TASK	VI-9-1
9.2	TERMINAL CHARACTERISTICS	VI-9-1
9.3	LEGAL DATA MODES	VI-9-2
9.4	TYPE-IN	VI-9-3
9.4.1	CTRL/C from the MCR Terminal	VI-9-3
9.4.2	CTRL/T to Invoke MULTIACCESS	VI-9-3
9.4.3	CTRL/X for Remote Stimulus	VI-9-4
9.4.4	CTRL/Y To Abort a User Task Under MULTIACCESS	VI-9-4
9.4.5	CTRL/P to Resume the Task USR.nn	VI-9-4
9.5	TTY HANDLER REQUESTS	VI-9--4
9.5.1	HINF: Requesting Handler Task Information	VI-9--5
9.6	ABORT: ABORTING I/O FOR A TASK	VI-9--6
9.7	READ: READING INPUT INTO A BUFFER	VI-9--7
9.7.1	IOPS ASCII (Mode 2)	VI-9--7
9.7.2	IMAGE ASCII (Mode 3)	VI-9--8
9.8	WRITE: WRITING OUTPUT FROM A BUFFER	VI-9--9
9.8.1	IOPS ASCII (Mode 2)	VI-9--9
9.8.2	IMAGE ASCII (Mode 3)	VI-9--10

CONTENTS (Cont'd)

	Page
CHAPTER 10 CARD READER I/O	VI-10-1
10.1    CD HANDLER TASK	VI-10-1
10.2    CD HANDLER REQUESTS	VI-10-1
10.2.1    HINF: Requesting Handler Task Infor- mation	VI-10-2
10.3    READ: READING INPUT INTO A BUFFER	VI-10-3
10.4    CR15 ERROR MESSAGES	VI-10-3
10.5    UC15 OPERATION	VI-10-4
10.6    UC15 ERRORS	VI-10-5
10.7    OPERATION OF THE CR03B HANDLER	VI-10-8
CHAPTER 11 LINE PRINTER I/O	VI-11-1
11.1    LP HANDLER TASK	VI-11-1
11.2    LP HANDLER REQUESTS	VI-11-2
11.2.1    HINF: Requesting Handler Task Infor- mation	VI-11-2
11.3    WRITE: WRITING OUTPUT FROM A BUFFER	VI-11-3
11.4    UC15 OPERATION	VI-11-3
CHAPTER 12 PAPER TAPE READER I/O	VI-12-1
12.1    PR HANDLER TASK	VI-12-1
12.2    PR HANDLER REQUESTS	VI-12-1
12.2.1    HINF: Requesting Handler Task Infor- mation	VI-12-2
12.3    READ: READING INPUT INTO A BUFFER	VI-12-3
12.3.1    IOPS BINARY (Mode 0)	VI-12-3
12.3.2    IMAGE BINARY (Mode 1)	VI-12-4
12.3.3    IOPS ASCII (Mode 2)	VI-12-5
12.3.4    IMAGE ASCII (Mode 3)	VI-12-6
12.4    CLOSE: CLOSING A FILE AND UNLOADING TAPE	VI-12-7
12.5    ABORT: ABORTING I/O FOR A TASK	VI-12-8
CHAPTER 13 PAPER TAPE PUNCH I/O	VI-13-1
13.1    PP HANDLER TASK	VI-13-1
13.2    PP HANDLER REQUESTS	VI-13-1
13.2.1    HINF: Requesting Handler Task Infor- mation	VI-13-2
13.3    WRITE: WRITING OUTPUT FROM A BUFFER	VI-13-3
13.3.1    IOPS BINARY (Mode 0)	VI-13-3
13.3.2    IMAGE BINARY (Mode 1)	VI-13-4
13.3.3    IOPS ASCII (Mode 2)	VI-13-4
13.3.4    IMAGE ASCII (Mode 3)	VI-13-5
13.4    CLOSE: CLOSING A FILE	VI-13-6
13.4.1    IOPS BINARY (Mode 0)	VI-13-6
13.4.2    IOPS ASCII (Mode 2)	VI-13-6
13.4.3    IMAGE BINARY and IMAGE ASCII (Modes 1 and 3)	VI-13-7
13.5    ABORT: ABORTING I/O FOR A TASK	VI-13-8
CHAPTER 14 ANALOG-TO-DIGITAL CONVERTER I/O	VI-14-1
14.1    AD HANDLER TASK	VI-14-1

CONTENTS (Cont'd)

	Page
14.2 AD HANDLER REQUESTS	VI-14-1
14.2.1 HINF: Requesting Handler Task Information	VI-14-2
14.2.2 Significant Event Declaration	VI-14-3
14.3 ADCON: CONNECTING AD TO A TASK	VI-14-4
14.4 ADDIS: DISCONNECTING AD FROM A TASK	VI-14-5
14.5 ADSSET: ESTABLISHING SEQUENTIAL LINKS	VI-14-6
14.6 ADRSET: ESTABLISHING RANDOM LINKS	VI-14-9
14.7 ADSTRT: STARTING AD CONVERSION	VI-14-12
14.8 ADSTOP: STOPPING AD CONVERSION	VI-14-13
14.9 ADSMAP: MAPPING SEQUENTIAL INPUT PARAMETERS	VI-14-14
14.10 ADRMAP: MAPPING RANDOM INPUT PARAMETERS	VI-14-15
 CHAPTER 15 AUTOMATIC FLYING CAPACITOR SCANNER I/O	 VI-15-1
15.1 AF HANDLER TASK	VI-15-1
15.2 AF HANDLER REQUESTS	VI-15-1
15.2.1 HINF: Requesting Handler Task Information	VI-15-2
15.3 AI: READING A SEQUENCE OF ANALOG CHANNELS	VI-15-3
 CHAPTER 16 UNIVERSAL DIGITAL CONTROLLER I/O	 VI-16-1
16.1 UD HANDLER TASK	VI-16-1
16.2 UD HANDLER REQUESTS	VI-16-1
16.2.1 HINF: Requesting Handler Task Information	VI-16-2
16.2.2 FORTRAN Interface	VI-16-3
16.3 AO: ANALOG OUTPUT -- A633 MODULES	VI-16-4
16.4 DOS: DIGITAL OUTPUT, SINGLE SHOT -- M687 AND M807 MODULES	VI-16-5
16.5 DOL: DIGITAL OUTPUT LATCHING -- M685, M803, AND M805 MODULES	VI-16-6
16.6 DI (RBIN, RBCD, RDP): CONTACT SENSE/INTERRUPT DIGITAL INPUT -- W731 AND W733 MODULES	VI-16-7
16.6.1 RBIN: Read Binary	VI-16-7
16.6.2 RBCD: Read BCD	VI-16-7
16.6.3 RDP: Read Point	VI-16-8
16.7 CTDI, RDDI, AND DFDI: CONTACT INTERRUPT DIGITAL INPUT -- W733 MODULES	VI-16-9
16.7.1 CTDI: Connecting a Buffer	VI-16-10
16.7.2 RDDI: Reading a Buffer	VI-16-11
16.7.3 DFDI: Disconnecting a Buffer	VI-16-12
16.8 SAMPLE PROGRAM	VI-16-13
 CHAPTER 17 COMMON COMMUNICATOR I/O	 VI-17-1
17.1 CC HANDLER TASK	VI-17-1
17.2 CC HANDLER REQUESTS	VI-17-1
17.2.1 HINF: Requesting Handler Task Information	VI-17-2

CONTENTS (Cont'd)

	Page	
17.3	COMGET: TRANSFERRING DATA FROM A COMMON BLOCK TO A TASK	VI-17-3
17.4	COMPUT: TRANSFERRING DATA FROM A TASK TO A COMMON BLOCK	VI-17-5
CHAPTER 18	XY PLOTTER I/O	VI-18-1
18.1	XY HANDLER TASK	VI-18-1
18.2	XY HANDLER REQUESTS	VI-18-1
18.2.1	ABORT	VI-18-1
18.2.2	ATTACH	VI-18-2
18.2.3	CLOSE	VI-18-2
18.2.4	DETACH	VI-18-2
18.2.5	ENTER	VI-18-2
18.2.6	HINF	VI-18-2
18.2.7	READ	VI-18-2
18.2.8	WRITE	VI-18-3
18.3	UNICHANNEL OPERATION	VI-18-4
18.4	FORTRAN EXAMPLES	VI-18-4
18.4.1	Use of IOPS ASCII	VI-18-4
18.4.2	Characters From IOPS Binary	VI-18-4
18.4.3	Make Characters Double Sized and Vertical (XY11)	VI-18-5
18.4.4	Transfer an Array of 25 Lines	VI-18-5
18.4.5	Recommended Close-out for Plotter Job (LUN=7)	VI-18-5
CHAPTER 19	CARD PUNCH INPUT/OUTPUT	
19.1	CARD PUNCH HANDLER TASK	VI-19-1
19.2	CP HANDLER REQUESTS	VI-19-1
19.2.1	HINF: Requesting Handler Task Infor- mation	VI-19-1
19.3	WRITE: WRITING OUTPUT FROM A BUFFER	VI-19-2
19.4	CLOSE: CLOSING A FILE	VI-19-2
APPENDIX A	EVENT VARIABLES	VI-A-1
APPENDIX B	THE MACRO DEFINITIONS FILE	VI-B-1
B.1	READ: READING FROM AN I/O DEVICE	VI-B-1
B.2	WRITE: WRITING TO AN I/O DEVICE	VI-B-1
B.3	DSKAL: RESERVING STORAGE	VI-B-1
B.4	DSKDAL: FREEING STORAGE	VI-B-2
B.5	DSKPUT: WRITING TO DISK	VI-B-2
B.6	DSKGET: READING FROM DISK	VI-B-2
B.7	MDALLO: RESERVING STORAGE -- MULTIPLE DISKS	VI-B-2
B.8	MDDEAL: FREEING STORAGE -- MULTIPLE DISKS	VI-B-3
B.9	MDGET: READING FROM MULTIPLE DISKS	VI-B-3
B.10	MDPUT: WRITING TO MULTIPLE DISKS	VI-B-3
B.11	ATTACH: ATTACHING AN I/O DEVICE	VI-B-4
B.12	DETACH: FREEING AN ATTACHED I/O DEVICE	VI-B-4
B.13	SEEK: OPENING A FILE FOR INPUT	VI-B-4
B.14	ENTER: OPENING A FILE FOR OUTPUT	VI-B-4
B.15	DELETE: DELETING A FILE	VI-B-5



CONTENTS (Cont'd)

		Page
B.16	CLOSE: CLOSING A FILE	VI-B-5
B.17	RENAME: RENAMING A FILE	VI-B-5
B.18	HINF: REQUESTING I/O HANDLER INFORMATION	VI-B-5
INDEX		VI-Index-1
PART VII XVM/RSX ON-LINE TASK DEVELOPMENT		
CHAPTER 1	INTRODUCTION TO MULTIACCESS	VII-1-1
1.1	FUNCTION OF TASK DEVELOPMENT	VII-1-1
1.2	REQUESTING THE RESIDENT TDV DISPATCHER	VII-1-7
1.3	TDV/SYSTEM COMMUNICATION	VII-1-8
1.4	TDV COMMAND CONVENTIONS	VII-1-9
1.5	TDV FUNCTION TASKS	VII-1-9
CHAPTER 2	FORTRAN: COMPILING A FORTRAN PROGRAM	VII-2-1
2.1	INVOKING THE FORTRAN IV COMPILER	VII-2-1
2.2	INPUT/OUTPUT	VII-2-3
2.3	COMPARISON WITH OTHER VERSIONS OF FORTRAN	VII-2-3
2.3.1	Auxiliary Disk	VII-2-3
2.3.2	Input/Output	VII-2-4
2.3.3	STOP and PAUSE Statements	VII-2-4
2.3.4	Floating-Point Processor	VII-2-4
2.3.5	OTS Output	VII-2-4
2.3.6	Table Initialization	VII-2-4
2.4	ERROR MESSAGES	VII-2-5
CHAPTER 3	MACRO: ASSEMBLING A MACRO PROGRAM	VII-3-1
3.1	INVOKING THE MACRO ASSEMBLER	VII-3-2
3.2	INPUT/OUTPUT	VII-3-5
3.3	COMPARISON WITH OTHER VERSIONS OF MACRO	VII-3-6
3.3.1	Dump Mode	VII-3-6
3.3.2	Input/Output	VII-3-6
3.3.3	Parameter Input	VII-3-6
3.3.4	MACRO Definitions File	VII-3-6
3.4	ERROR MESSAGES	VII-3-7
CHAPTER 4	EDITOR: TEXT-EDITING SOURCE CODE	VII-4-1
4.1	INVOKING THE TEXT EDITOR	VII-4-1
4.2	INPUT/OUTPUT	VII-4-2
4.3	COMPARISON WITH OTHER VERSIONS OF THE TEXT EDITOR	VII-4-3
4.3.1	Disk-to-Disk Editing	VII-4-3
4.3.2	Buffer and Partition Size	VII-4-3
4.4	ERROR MESSAGES	VII-4-3
CHAPTER 5	SLIP: EDITING BATCH FILES	VII-5-1
5.1	INVOKING SLIP	VII-5-2
5.1.1	\$SLIP Options	VII-5-2
5.1.2	*FILE Specifications	VII-5-3

CONTENTS (Cont'd)

	Page	
5.1.3	SLIP Control Records and Insertion Records	VII-5-4
5.1.4	End-of-File	VII-5-5
5.2	CONTROL RECORDS	VII-5-5
5.2.1	INSERT	VII-5-6
5.2.2	INSERT FILE	VII-5-7
5.2.3	REPLACE	VII-5-8
5.2.4	REPLACE WITH FILE	VII-5-9
5.2.5	SEARCH AND INSERT	VII-5-10
5.2.6	SEARCH AND INSERT FILE	VII-5-11
5.2.7	SEARCH AND REPLACE	VII-5-12
5.2.8	SEARCH AND REPLACE WITH FILE	VII-5-13
5.2.9	END-OF-FILE	VII-5-14
5.3	INPUT/OUTPUT	VII-5-14
5.4	ERROR MESSAGES	VII-5-14
5.4.1	*FILE Errors	VII-5-14
5.4.2	\$SLIP Control Record Errors	VII-5-15
5.4.3	SLIP Command Syntax Errors	VII-5-16
5.4.4	SLIP Sequencing Errors	VII-5-16
5.5	DEMONSTRATION OF SLIP EDITING	VII-5-16
CHAPTER 6	TASK BUILDER AND BASIC TASK BUILDER: BUILDING A TASK FOR EXECUTION	VII-6-1
6.1	INVOKING THE TASK BUILDER	VII-6-2
6.2	INPUT/OUTPUT	VII-6-4
6.3	COMPARISON WITH CHAIN AND EXECUTE DIALOGUE	VII-6-4
6.3.1	List Options	VII-6-4
6.3.1.1	PAGE Mode	VII-6-7
6.3.1.2	BANK Mode	VII-6-7
6.3.1.3	EXEC Mode	VII-6-7
6.3.1.4	USER Mode	VII-6-7
6.3.2	Name Task	VII-6-8
6.3.3	Specify Default Priority	VII-6-8
6.3.4	Describe Partition	VII-6-9
6.3.5	Describe System or Shared COMMON Blocks	VII-6-10
6.3.5.1	Describe System COMMON Blocks	VII-6-10
6.3.5.2	Describe Shared COMMON Blocks	VII-6-11
6.3.6	Define Resident Code	VII-6-13
6.3.7	Describe Links and Structures	VII-6-13
6.3.7.1	LINK Definitions	VII-6-14
6.3.7.2	Overlay Structure Description	VII-6-15
6.3.8	Completion of Dialogue	VII-6-17
6.4	CONVERSION TO XVM/R SX	VII-6-18
6.5	BTK: BASIC TASK BUILDER	VII-6-18
6.6	ERROR MESSAGES	VII-6-19
CHAPTER 7	FILE INPUT, DECK, FILE OUTPUT, LIST AND TYPE	VII-7-1
7.1	INVOKING FIN, DEC, FOU, LIS AND TYPE	VII-7-2
7.2	INPUT/OUTPUT AND TASK BUILDING	VII-7-3
7.3	MAGTAPE OPERATION	VII-7-4
7.4	ERROR MESSAGES	VII-7-5

CONTENTS (Cont'd)

	Page
CHAPTER 8 DELETE: DELETING A FILE FROM DISK	VII-8-1
8.1 INVOKING DELETE FILE	VII-8-1
8.2 INPUT/OUTPUT AND TASK BUILDING	VII-8-1
8.3 ERROR MESSAGES	VII-8-1
CHAPTER 9 RENAME: RENAMING A FILE STORED ON DISK	VII-9-1
9.1 INVOKING RENAME FILE	VII-9-1
9.2 INPUT/OUTPUT AND TASK BUILDING	VII-9-2
9.3 ERROR MESSAGES	VII-9-2
CHAPTER 10 DIRECTORY LIST: LISTING FILES IN DISK DIRECTORY	VII-10-1
10.1 INVOKING DIRECTORY LIST	VII-10-1
10.2 INPUT/OUTPUT AND TASK-BUILDING	VII-10-2
10.3 ERROR MESSAGES	VII-10-2
CHAPTER 11 DECTAPE DIRECTORY: LISTING FILES IN DECTAPE DIRECTORY	VII-11-1
11.1 INVOKING DECTAPE DIRECTORY LIST	VII-11-1
11.2 INPUT/OUTPUT AND TASK BUILDING	VII-11-2
11.3 ERROR MESSAGES	VII-11-2
CHAPTER 12 NEW DECTAPE DIRECTORY: WRITING NEW DECTAPE DIRECTORY	VII-12-1
12.1 INVOKING NEW DECTAPE DIRECTORY	VII-12-1
12.2 INPUT/OUTPUT AND TASK-BUILDING	VII-12-1
12.3 ERROR MESSAGES	VII-12-1
CHAPTER 13 INSTALL: INSTALLING A TASK IN THE SYSTEM	VII-13-1
13.1 INVOKING INSTALL	VII-13-1
13.2 INPUT/OUTPUT AND TASK-BUILDING	VII-13-2
13.3 ERROR MESSAGES	VII-13-2
CHAPTER 14 REQUEST: REQUESTING TASK EXECUTION	VII-14-1
14.1 INVOKING REQUEST	VII-14-1
14.2 INPUT/OUTPUT AND TASK BUILDING	VII-14-1
14.3 ERROR MESSAGES	VII-14-2
CHAPTER 15 REMOVE: REMOVING A TASK FROM THE SYSTEM	VII-15-1
15.1 INVOKING REMOVE	VII-15-1
15.2 INPUT/OUTPUT AND TASK BUILDING	VII-15-1
15.3 ERROR MESSAGES	VII-15-1
CHAPTER 16 MOUNT: LOGICALLY MOUNTING A DISK	VII-16-1
16.1 INVOKING MOUNT	VII-16-1
16.2 INPUT/OUTPUT AND TASK BUILDING	VII-16-1
16.3 ERROR MESSAGES	VII-16-1

CONTENTS (Cont'd)

	Page
CHAPTER 17 DISMOUNT: LOGICALLY DISMOUNTING A DISK	VII-17-1
17.1 INVOKING DISMOUNT	VII-17-1
17.2 INPUT/OUTPUT AND TASK BUILDING	VII-17-1
17.3 ERROR MESSAGES	VII-17-1
CHAPTER 19 CONSTRUCT: STORING A TASK ON A USER DISK	VII-19-1
19.1 INVOKING CONSTRUCT	VII-19-1
19.2 INPUT/OUTPUT AND TASK BUILDING	VII-19-1
19.3 ERROR MESSAGES	VII-19-2
CHAPTER 21 QUEUE: QUEUING A BATCH JOB	VII-21-1
21.1 INVOKING QUEUE	VII-21-1
21.2 INPUT/OUTPUT AND TASK BUILDING	VII-21-3
21.3 ERROR MESSAGES	VII-21-3
CHAPTER 22 ODT: OCTAL DEBUGGING TECHNIQUE	VII-22-1
22.1 INVOKING ODT	VII-22-2
22.2 DEBUGGING WITH ODT	VII-22-2
22.2.1 OPEN	VII-22-3
22.2.2 START	VII-22-3
22.2.3 EXIT	VII-22-3
22.2.4 DEFINE	VII-22-4
22.2.5 SET	VII-22-4
22.2.6 REMOVE	VII-22-4
22.2.7 RESTART	VII-22-5
22.2.8 RELOAD	VII-22-5
22.2.9 CONTINUE	VII-22-5
22.2.10 REGISTERS	VII-22-5
22.2.11 DECODE	VII-22-5
22.2.12 DUMP	VII-22-6
22.3 MONITORING TASK PROGRESS	VII-22-6
22.4 AN EXAMPLE OF ODT USE	VII-22-6
22.5 ERROR MESSAGES	VII-22-9
CHAPTER 23 STATUS: MULTIACCESS STATUS REPORT	VII-23-1
23.1 INVOKING STATUS	VII-23-1
23.2 INPUT/OUTPUT AND TASK BUILDING	VII-23-1
CHAPTER 24 BATCH ACCOUNT FILE INITIALIZATION AND DISPLAY	VII-24-1
24.1 ACI: INITIALIZE BATCH ACCOUNT FILE	VII-24-1
24.2 ACD: DISPLAY BATCH ACCOUNT FILE	VII-24-1
INDEX	VII-Index-1
PART VII BATCH PROCESSING	
CHAPTER 1 INTRODUCTION TO BATCH-PROCESSING	VIII-1-1

CONTENTS (Cont'd)

		Page
1.1	INTRODUCTION	VIII-1-1
1.2	SAMPLE BATCH SEQUENCE	VIII-1-1
CHAPTER 2	INVOKING AND USING BATCH	VIII-2-1
2.1	JOB FILE SUBMISSION	VIII-2-1
2.2	INVOKING BATCH PROCESSING	VIII-2-1
2.3	CONTROL LINES	VIII-2-3
2.4	TERMINATING BATCH PROCESSING	VIII-2-3
CHAPTER 3	SPECIAL BATCH COMMANDS	VIII-3-1
3.1	\$JOB: BEGIN A JOB	VIII-3-1
3.2	\$MSG: SEND A MESSAGE	VIII-3-3
3.3	\$PAUSE: SUSPEND BATCH	VIII-3-5
3.4	\$LOG: LOG A COMMENT	VIII-3-5
3.5	\$EJECT: EJECT A PAGE	VIII-3-6
3.6	\$: PRINT A LINE	VIII-3-7
3.7	\$END: END A JOB FILE	VIII-3-8
3.8	\$QUIT: END BATCH INPUT	VIII-3-9
3.9	\$ERROR: PROCESSING AFTER JOB TERMINATION	VIII-3-10
CHAPTER 4	OPERATOR INTERACTION WITH BATCH	VIII-4-1
4.1	OPERATOR CONSOLE	VIII-4-1
4.2	OPR COMMANDS AND BATCH STATES	VIII-4-1
4.2.1	BATCH: Load BATCH	VIII-4-3
4.2.2	SCHEDULE: Set Job File Selection Parameters	VIII-4-4
4.2.3	JOB LIST: List Queued Job Files	VIII-4-5
4.2.4	ON: Indicate that the Operator is Available	VIII-4-5
4.2.5	OFF: Indicate that the Operator is Unavailable	VIII-4-5
4.2.6	WAIT: Cause BATCH to Wait Between Job Files	VIII-4-6
4.2.7	GO and PROCEED: Cause BATCH to Continue	VIII-4-6
4.2.8	HOLD: Prevent Processing of a Job File	VIII-4-6
4.2.9	RELEASE: Release a Job File after HOLD	VIII-4-6
4.2.10	EXIT: Cause BATCH to Exit	VIII-4-7
4.2.11	FORCE: Force a Job File Run Next	VIII-4-7
4.2.12	CANCEL and CANCEL ALL: Cancel Job File Requests	VIII-4-7
4.2.13	TLACT: Specify Action after Time Limit is Exceeded	VIII-4-8
4.2.14	STOP: Terminate The Current Job File	VIII-4-8
4.2.15	KILL: Terminate The Current Job File	VIII-4-8
4.2.16	MORE: Allow Extra Processing Time	VIII-4-9
4.2.17	ABORT: Terminate the Current Job File	VIII-4-9
4.3	ERROR MESSAGES	VIII-4-9

CONTENTS (Cont'd)

	Page
CHAPTER 5 SYSTEM MANAGEMENT	VIII-5-1
5.1 ORGANIZATION OF THE ACCOUNT FILE	VIII-5-1
5.2 ACI: INITIALIZE THE ACCOUNT FILE	VIII-5-2
5.3 ACD: DISPLAY THE ACCOUNT FILE	VIII-5-4
CHAPTER 6 BATCH OPERATIONS	VIII-6-1
6.1 BATCH SYSTEM ORGANIZATION	VIII-6-1
6.1.1 QUFUE TDV Function Task (QUE...)	VIII-6-1
6.1.2 Execute QJOB Directive	VIII-6-2
6.1.3 Batch Processor (BATCH)	VIII-6-2
6.1.4 Job Startup Processor (JOB...)	VIII-6-2
6.1.5 Job Termination Processor (END...)	VIII-6-2
6.1.6 MCR OPR Command (...OPP)	VIII-6-3
6.1.7 OPR SCHEDULE Command (SC.OPR)	VIII-6-3
6.1.8 ACI TDV Function Task (ACI...)	VIII-6-3
6.1.9 ACD TDV Function Task (ACD...)	VIII-6-3
6.2 I/O FUNCTIONS	VIII-6-3
6.2.1 HINF	VIII-6-3
6.2.2 READ	VIII-6-4
6.2.3 WRITE	VIII-6-4
6.2.4 ABORT	VIII-6-4
6.3 JOB SELECTION	VIII-6-5
6.3.1 Priority Calculation	VIII-6-5
6.3.2 Other Selection Factors	VIII-6-7
6.4 JOB FILES	VIII-6-7
6.4.1 Multiple Jobs	VIII-6-7
6.4.2 Printing Control Lines	VIII-6-7
APPENDIX A BATCH SYSTEM INSTALLATION CHECKLIST	VIII-A-1
APPENDIX B BATCH SYSTEM ERRORS	VIII-B-1
B.1 GENERAL	VIII-B-1
B.2 RECOVERABLE BATCH SYSTEM ERRORS	VIII-B-1
INDEX	VIII-Index-1
PART IX SYSTEM ORGANIZATION AND LISTS	
CHAPTER 1 INTRODUCTION TO SYSTEM ORGANIZATION	IX-1-1
1.1 THE DEQUE LIST APPROACH	IX-1-1
1.2 POOL: POOL OF EMPTY NODES	IX-1-2
1.3 LPOOL: POOL OF EMPTY LARGE NODES	IX-1-2
CHAPTER 2 SYSTEM LISTS	IX-2-1
2.1 ATL: ACTIVE TASK LIST	IX-2-3
2.2 CKQ: CLOCK QUEUE	IX-2-6
2.3 EXELH: EXECUTE LIST	IX-2-8
2.4 IORDQ: I/O RUNDOWN QUEUE	IX-2-9
2.5 JOB1: BATCH JOB LIST	IX-2-10
2.6 LNDL: LARGE NODE DESCRIPTION LIST	IX-2-12
2.7 PBDL: PARTITION BLOCK DESCRIPTION LIST	IX-2-13
2.8 PDVL: PHYSICAL DEVICE LIST	IX-2-17

CONTENTS (Cont'd)

	Page	
2.9	SCDL: SYSTEM COMMON BLOCKS DESCRIPTION LIST	IX-2-19
2.10	SNDL: SMALL NODE DESCRIPTION LIST	IX-2-20
2.11	STL: SYSTEM TASK LIST	IX-2-21
2.12	TNRL: TASK TERMINATION NOTICE REQUEST LIST	IX-2-24
2.13	TDV.EQ: MULTIACCESS EXIT QUEUE	IX-2-26
CHAPTER 3	SYSTEM COMMUNICATION REGISTERS	IX-3-1
INDEX		IX-Index-1
PART X GRAPHICS		
CHAPTER 1	INTRODUCTION	X-1-1
1.1	GENERAL DESCRIPTION	X-1-1
1.2	REFERENCE MANUALS	X-1-2
1.3	MINIMUM HARDWARE	X-1-2
CHAPTER 2	SUBPICTURE ROUTINES	X-2-1
2.1	GENERAL RESTRICTIONS	X-2-1
2.2	GENERAL FORMAT OF DISPLAY FILES	X-2-3
2.2.1	Storage Overhead	X-2-3
2.2.2	Space Allocation	X-2-3
2.3	LINE SUBROUTINE	X-2-4
2.4	TEXT SUBROUTINE	X-2-5
2.5	COPY SUBROUTINE	X-2-6
2.6	PRAMTR SUBROUTINE	X-2-7
2.7	GRAPH SUBROUTINE	X-2-11
2.8	BLANK SUBROUTINE	X-2-13
2.9	UNBLNK SUBROUTINE	X-2-14
2.10	POINT SUBROUTINE	X-2-14
2.11	ANY SUBROUTINE	X-2-15
2.12	CIRCLE SUBROUTINE	X-2-16
2.13	ROTATE SUBROUTINE	X-2-16
2.14	EXAMPLES	X-2-17
CHAPTER 3	MAIN DISPLAY FILE ROUTINES	X-3-1
3.1	SETPT SUBROUTINE	X-3-2
3.2	PLOT SUBROUTINE	X-3-2
3.2.1	Access Subroutine Copy	X-3-2
3.2.2	Access Subroutine LINE	X-3-3
3.2.3	Access Subroutine PRAMTR	X-3-4
3.2.4	Access Subroutine TEXT	X-3-4
3.2.5	Access Subroutine POINT	X-3-5
3.2.6	Access Subroutine GRAPH	X-3-5
3.2.7	Access Subroutine ANY	X-3-6
CHAPTER 4	CODE MODIFICATION ROUTINES	X-4-1
4.1	GENERAL	X-4-1
4.2	DELETE	X-4-2
4.3	REPLOT	X-4-2
4.4	RSETPT	X-4-3

CONTENTS (Cont'd)

	Page
CHAPTER 5 INPUT/OUTPUT	X-5-1
5.1 GENERAL	X-5-1
5.2 VTUNIT CALL	X-5-2
5.3 DINIT CALL	X-5-2
5.4 DCLOSE CALL	X-5-3
5.5 CINIT CALL	X-5-3
5.6 CCLOSE CALL	X-5-3
5.7 LTORPB CALL	X-5-3
5.8 GETPSH CALL	X-5-5
5.9 TRACK CALL	X-5-5
5.10 COMPREHENSIVE EXAMPLE	X-5-6
CHAPTER 6 RELOCATING ROUTINES	X-6-1
6.1 DYSET ROUTINE	X-6-1
6.2 DYLINK ROUTINE	X-6-2
6.3 NON-STANDARD DISPLAY FILES	X-6-3
6.4 PROGRAM EXAMPLE	X-6-3
CHAPTER 7 VT-15 HANDLER	X-7-1
7.1 DESCRIPTION OF PUT	X-7-1
7.2 DESCRIPTION OF GET	X-7-3
7.3 MACRO PROGRAMMING	X-7-5
CHAPTER 8 WRITING TABLET HANDLER	X-8-1
8.1 GETBLT ROUTINE	X-8-1
8.2 HANDLER INTERFACE	X-8-2
CHAPTER 9 GETTING ON THE AIR WITH XVM/RSX GRAPHICS SOFTWARE	X-9-1
9.1 CONSOLE DIALOGUE	X-9-1
9.2 FULL FORTRAN EXAMPLE	X-9-6
APPENDIX A ERROR MESSAGES	X-A-1
A.1 ERROR MESSAGE FORMAT	X-A-1
A.2 ERROR CODES	X-A-1
APPENDIX B SUMMARY OF CALLS	X-B-1
APPENDIX C MNEMONICS COMMONLY USED IN GRAPHICS CALLS	X-C-1
APPENDIX D ASSEMBLY PARAMETERS	X-D-1
INDEX	X-Index-1
PART XI CONSTRUCTION OF ADVANCED TASKS	
CHAPTER 1 CONSTRUCTION OF ADVANCED TASKS	XI-1-1
1.1 INTRODUCTION TO ADVANCED TASK CONSTRUCTION	XI-1-1
1.2 GUIDELINES FOR ADVANCED TASK CONSTRUCTION	XI-1-2



CONTENTS (Cont'd)

	Page
CHAPTER 2 CONSTRUCTION OF MCR FUNCTION TASKS	XI-2-1
2.1 CONVENTIONS FOR MCR TASK CONSTRUCTION	XI-2-1
2.2 SAMPLE MCR FUNCTION TASK	XI-2-2
CHAPTER 3 CONSTRUCTION OF TDV FUNCTION TASKS	XI-3-1
3.1 CONVENTIONS FOR TDV TASK CONSTRUCTION	XI-3-1
3.2 SAMPLE TDV FUNCTION TASK	XI-3-3
CHAPTER 4 CONSTRUCTION OF I/O DEVICE HANDLER TASKS	XI-4-1
4.1 CONVENTIONS FOR I/O HANDLER CONSTRUCTION	XI-4-1
4.2 SAMPLE I/O DEVICE HANDLER TASK	XI-4-4
CHAPTER 5 CONSTRUCTION OF FRONT-END INTERRUPT DRIVER TASKS	XI-5-1
CHAPTER 6 USE AND ALLOCATION OF I/O BUFFERS	XI-6-1
6.1 I/O BUFFERS	XI-6-1
6.2 PREALLOCATION OF I/O BUFFERS	XI-6-1
6.3 BUFFER ALLOCATION AND DEALLOCATION	XI-6-2
6.4 REENTRANT EXECUTIVE SUBROUTINES	XI-6-3
INDEX	XI-Index-1
PART XII V1B SYSTEM INSTALLATION GUIDE	
CHAPTER 1 INTRODUCTION	XII-1-1
CHAPTER 2 BUILDING AN XVM/DOS SYSTEM	XII-2-1
CHAPTER 3 GENERATING A DOS BATCH JOB FILE	XII-3-1
3.1 PREPARING TO RUN BUILD	XII-3-1
3.2 RUNNING BUILD	XII-3-1
3.3 RUNNING THE BATCH JOB	XII-3-4
3.4 BUILDING XVM/RSX V1B	XII-3-4
3.5 RUNNING THE BATCH JOB	XII-3-7
3.6 SAVING THE PRECONFIGURED SYSTEM	XII-3-8
CHAPTER 4 RSX CONFIGURATION PROCEDURES	XII-4-1
4.1 RSX: BOOTSTRAPPING THE RSX SYSTEM	XII-4-1
4.2 RSX SYSTEM CONFIGURATION	XII-4-1
4.3 SYSTEM CONFIGURATION ERROR MESSAGES	XII-4-3
4.4 SETTING UP AN RSX ENVIRONMENT	XII-4-3
CHAPTER 5 ADDING TASKS TO THE SYSTEM	XII-5-1
CHAPTER 6 XVM/RSX SYSTEM BUILD PROCEDURES	XII-6-1
APPENDIX A REPLACING THE RSX EXECUTIVE	XII-A-1
APPENDIX B BUILDING A CROSS DISK SYSTEM	XII-B-1
INDEX	XII-Index-1

## FIGURES

Figure Number		Page
PART II		
1-1	Task Scheduling	II-1-6
2-1	Disk Configuration	II-2-4
2-2	UNICHANNEL Configuration	II-2-5
3-1	RSX On-Line Task Development	II-3-2
PART VII		
6-1	Task Builder Session	VII-6-3
6-2	Messages Produced by Recoverable TKB Errors	VII-6-20.1
6-3	Messages Produced by Unrecoverable TKB Errors	VII-6-21
20-1	Relationship of a Spawned Job to Other Batch Jobs	VII-20-1
PART VIII		
1-1	Batch-Processing Example	VIII-1-2
PART IX		
1-1	A Three-Node Deque	IX-1-2
1-2	An Empty Deque	IX-1-2
PART X		
2-1	Four Square Display Example	X-2-18
2-2	CIRCLE Subroutine Example	X-2-19
2-3	DOS Sine Wave Program Example	X-2-20
2-4	DOS Sine Wave Program Converted to RSX	X-2-21
2-5	RSX Sine Wave Program Eliminating Chapter 3 Calls	X-2-22
2-6	Sine Wave Program Written for Single Display File	X-2-23
2-7	Demonstration of PRAMTR Settings	X-2-25
2-8A	ROTATE Subroutine Example (FORTRAN Listing)	X-2-26
2-8B	ROTATE Subroutine Example (Random Num- ber Generator Coding)	X-2-29
5-1	Comprehensive Example	X-5-7
6-1	DYSET-DYLINK Example	X-6-4
7-1	MACRO Programming Example	X-7-6
8-1	Tracking with Writing Tablet	X-8-3
8-2	Inputting with Writing Tablet	X-8-5
9-1	Simulated Console Listing	X-9-2
PART XI		
6-1	I/O Buffers Within a Partition	XI-6-4
PART XII		
6-1	Guide to Building XVM/RSX	XII-6-2

TABLES

Table Number		Page
PART IV		
2-1	RSX Devices	IV-2-10
2-2	DEQ List Symbols	IV-2-17
2-3	DEQ Listing Abbreviations	IV-2-18
2-4	RSX Devices	IV-2-24
2-5	OPEN Line Terminators	IV-2-38
2-6	RSX Devices	IV-2-51
2-7	Interval Ranges	IV-2-57
2-8	Interval Ranges	IV-2-61
2-9	Interval Ranges	IV-2-68
3-1	MCR Error Messages	IV-3-1
PART V		
1-1	System Directives	V-1-4
2-1	API Lines	V-2-5
2-2	Reschedule Interval Ranges	V-2-24
2-3	Reschedule Interval Ranges	V-2-42
2-4	Reschedule Interval Ranges	V-2-47
2-5	Reschedule Interval Ranges	V-2-60
4-1	System Directive Abbreviations	V-4-2
4-2	Returned Event Variables	V-4-3
PART VI		
1-1	RSX Devices	VI-1-5
1-2	I/O Data Modes	VI-1-8
1-3	I/O Data Modes by Device	VI-1-9
2-1	Standard I/O Functions	VI-2-2
2-2	I/O Devices and Codes	VI-2-17
3-1	RF Disk I/O Functions	VI-3-9
6-1	Disk Driver I/O Functions	VI-6-4
7-1	DECTape I/O Functions	VI-7-2
8-1	Magtape I/O Functions	VI-8-2
8-2	ASCII to BCD Conversion	VI-8-18
8-3	ASCII to EBCDIC Conversion	VI-8-19
9-1	Terminal I/O Functions	VI-9-4
10-1	Card Reader I/O Functions	VI-10-1
10-2	DEC029 Character Set Hollerith Card Code - Type 29 Punch	VI-10-6
10-3	DEC026 Character Set Hollerith Card Code - Type 26 Punch	VI-10-7
11-1	Line Printer I/O Functions	VI-11-2
12-1	Paper Tape Reader I/O Functions	VI-12-1
13-1	Paper Tape Punch I/O Functions	VI-13-1
14-1	AD Converter I/O Functions	VI-14-2
15-1	AFC I/O Functions	VI-15-2
16-1	UDC I/O Functions	VI-16-2
17-1	COMMON Communicator I/O Functions	VI-17-1
18-1	XY Plotter I/O Functions	VI-18-1
18-2	Format of Information Returned by READ	VI-18-2
18-3	IOPS Binary Modes	VI-18-3
19-1	Card Punch I/O Functions	VI-19-1
A-1	Returned Event Variables	VI-A-2
A-2	Special Meanings of Event Variables	VI-A-5

TABLES (Cont'd)

Table Number		Page
PART VII		
1-1	TDV Function Tasks	VII-1-2
1-2	MULTIACCESS Monitor Commands	VII-1-2.1
1-3	MULTIACCESS Control-Character Facilities	VII-1-2.1
1-4	TDV Virtual LUN Assignments	VII-1-4
1-5	I/O Devices	VII-2-2
2-1	FORTRAN IV Compiler Options	VII-2-2
2-2	FORTRAN Error Messages	VII-2-5
2-3	OTS Error Messages	VII-2-15
2-4	OTS Error Messages in FPP Systems	VII-2-17
3-1	Assembler Options	VII-3-2
3-2	MACRO Assembler Error Flags	VII-3-7
3-3	MACRO Assembler Error Messages	VII-3-9
4-1	Editor Error Messages	VII-4-4
5-1	SLIP Options	VII-5-3
5-2	Error Codes for *FILE Routine	VII-5-15
6-1	Task Builder List, Execution Mode, and Library Options	VII-6-5
6-2	Messages Produced by Recoverable TKB Errors	VII-6-20
6-3	Messages Produced by Unrecoverable TKB Errors	VII-6-21
7-1	FILE INPUT, OUTPUT, and LIST Error Messages	VII-7-5
8-1	DELETE FILE Error Messages	VII-8-2
9-1	RENAME FILE Error Messages	VII-9-2
10-1	DIRECTORY LIST Error Messages	VII-10-3
11-1	DECTAPE DIRECTORY LIST Error Messages	VII-11-3
12-1	NEW DIRECTORY Error Messages	VII-12-2
13-1	INSTALL Error Messages	VII-13-3
14-1	REQUEST Error Messages	VII-14-2
15-1	REMOVE Error Messages	VII-15-2
16-1	MOUNT Error Messages	VII-16-2
17-1	DISMOUNT Error Messages	VII-17-2
18-1	EXECUTE Error Messages	VII-18-2
19-1	CONSTRUCT Error Messages	VII-19-2
20-1	SPAWN Error Messages	VII-20-4
21-1	QUEUE Error Messages	VII-21-4
22-1	ODT Error Messages	VII-22-10
PART VIII		
2-1	Special BATCH Commands	VIII-2-2
4-1	BATCH States	VIII-4-2
4-2	OPR Commands	VIII-4-3
4-3	OPR Error Messages	VIII-4-11

TABLES (Cont'd)

Table Number		Page
PART IX		
2-1	RSX System Lists	IX-2-2
PART X		
2-1	Display Parameter Settings	X-2-10
PART XI		
4-1	RSX Devices	XI-4-3



**Update Notice**  
**XVM/RSX System Manual**  
**DEC-XV-IRSMA-A-DN1**

September 1976

Insert this Update Notice page in the manual as a means of maintaining an up-to-date record of changes to the manual.

NEW AND CHANGED INFORMATION

The change pages contained in this update package reflect the addition of the MULTIACCESS facility to XVM/RSX. MULTIACCESS is a multiuser monitor based on the XVM/RSX real-time operating system. Under MULTIACCESS, several users can perform program development concurrently with batch operations and real-time processes supervised by XVM/RSX.

The addition of MULTIACCESS has caused significant changes throughout the software and the manual. Areas that have changed the most are:

Batch Processing	Part VIII
On-Line Task Development	Part VII
System Management	Part III
System Installation	Part XII

Many small technical changes have been made throughout the manual.

In the insert pages, the most current writing conventions and style have been used. The best possible presentation has been used even though the reader may notice some discrepancies between the base manual and update pages.

Copyright © 1976 Digital Equipment Corporation

Additional copies of this Update Notice to the XVM/RSX System Manual may be ordered from the Software Distribution Center, DIGITAL, Whitney Street, Northboro, MA 01532. Order Code: DEC-XV-IRSMA-A-DN1. The order code for the base manual is DEC-XV-IRSMA-A-D.

# INSTRUCTIONS

## DEC-XV-IRSMA-A-DN1

The following list of page numbers specifies which pages are to be placed in the XVM/RSX System Manual as replacements for or additions to current pages.

[ title page	[ I-1-1	[ III-1-15	[ III-B-13	[ IV-2-19
[ copyright page	[ I-1-2	[ III-1-16	[ III-B-14	[ IV-2-20
[ iii	[ II-1-1	[ III-1-17	[ III-B-15	[ IV-2-31
[ iv	[ II-1-2	[ III-1-18	[ III-B-16	[ IV-2-32
[ v	[ II-1-3	[ III-1-19	[ III-B-17	[ IV-2-35
[ vi	[ blank	[ III-1-20	[ III-B-18	[ IV-2-36
[ vii	[ II-1-3.1	[ III-1-21	[ III-B-19	[ IV-2-41
[ viii	[ II-1-4	[ blank	[ III-B-20	[ IV-2-42
[ ix	[ II-2-1	[ III-A-1	[ III-B-21	[ IV-2-43
[ x	[ II-2-2	[ III-A-2	[ III-B-22	[ IV-2-44
[ xi	[ II-3-1	[ III-A-3	[ III-B-23	[ IV-2-53
[ xii	[ II-3-2	[ blank	[ III-B-24	[ IV-2-54
[ xiii	[ II-3-3	[ III-B-1	[ III-B-27	[ IV-2-59
[ xiv	[ II-3-4	[ III-B-2	[ III-B-28	[ IV-2-60
[ xv	[ II-4-1	[ III-B-3	[ III-B-29	[ IV-2-62.1
[ xvi	[ II-4-2	[ III-B-4	[ III-B-30	[ blank
[ xvii	[ II-Index-1	[ III-B-5	[ III-Index-1	[ IV-2-63
[ xviii	[ II-Index-2	[ III-B-6	[ III-Index-2	[ IV-2-64
[ xix	[ III-1-1	[ III-B-7	[ IV-1-1	[ IV-2-65
[ xx	[ III-1-2	[ III-B-8	[ IV-1-2	[ IV-2-66
[ xxi	[ III-1-3	[ III-B-9	[ IV-1-3	[ IV-3-1
[ xxii	[ III-1-4	[ blank	[ blank	[ IV-3-2
[ xxiii	[ III-1-5	[ III-B-9.1	[ IV-2-1	[ IV-3-5
[ xxiv	[ III-1-6	[ III-B-9.2	[ IV-2-2	[ IV-3-6
[ xxv	[ III-1-9	[ blank	[ IV-2-5	[ IV-3-9
[ xxvi	[ III-1-10	[ III-B-10	[ IV-2-6	[ IV-3-10
[ xxvii	[ III-1-11	[ III-B-11	[ IV-2-7	[ IV-3-11
[ xxviii	[ III-1-12	[ III-B-12	[ IV-2-8	[ IV-3-12
[ xxix	[ III-1-13	[ III-B-12.1	[ IV-2-15	[ IV-Index-1
[ blank	[ III-1-14	[ blank	[ IV-2-16	[ IV-Index-2



[ IV-Index-3 blank	[ VI-2-3 VI-2-4	[ VII-5-7 VII-5-8	[ VII-22-1 VII-22-2	[ VIII-4-5 VIII-4-6
[ V-1-1 V-1-2	[ VI-2-5 VI-2-6	[ VII-6-1 VII-6-2	[ VII-22-3 VII-22-4	[ VIII-4-7 VIII-4-8
[ V-1-3 V-1-4	[ VI-8-5 VI-8-6	[ VII-6-3 VII-6-4	[ VII-22-5 VII-22-6	[ VIII-4-9 VIII-4-10
[ V-2-15 V-2-16	[ VI-9-1 VI-9-2	[ VII-6-7 VII-6-8	[ VII-22-7 VII-22-8	[ VIII-5-1 VIII-5-2
[ V-2-17 V-2-18	[ VI-9-3 VI-9-4	[ VII-6-9 VII-6-10	[ VII-22-9 VII-22-10	[ VIII-5-3 VIII-5-4
[ V-2-18.1 blank	[ VI-9-5 VI-9-6	[ VII-6-17 VII-6-18	[ VII-22-11 blank	[ VIII-6-1 VIII-6-2
[ V-2-19 V-2-20	[ VI-9-7 VI-9-8	[ VII-6-20.1 blank	[ VII-23-1 VII-23-2	[ VIII-6-3 VIII-6-4
[ V-2-29 V-2-30	[ VI-11-1 VI-11-2	[ VII-6-21 VII-6-22	[ VII-24-1 blank	[ VIII-6-5 VIII-6-6
[ V-2-31 V-2-32	[ VI-Index-1 VI-Index-2	[ VII-7-1 VII-7-2	[ VII-Index-1 VII-Index-2	[ VIII-6-7 blank
[ V-2-33 V-2-34	[ VI-Index-3 VI-Index-4	[ VII-7-3 VII-7-4	[ VII-Index-3 VII-Index-4	[ VIII-A-1 VIII-A-2
[ V-2-35 V-2-36	[ VII-1-1 VII-1-2	[ VII-13-1 VII-13-2	[ VIII-1-1 VIII-1-2	[ VIII-B-1 VIII-B-2
[ V-2-39 blank	[ VII-1-2.1 blank	[ VII-14-1 VII-14-2	[ VIII-1-3 blank	[ VIII-B-3 blank
[ V-2-39.1 V-2-40	[ VII-1-3 VII-1-4	[ VII-15-1 VII-15-2	[ VIII-2-1 VIII-2-2	[ VIII-Index-1 VIII-Index-2
[ V-2-73 blank	[ VII-1-5 VII-1-6	[ VII-16-1 VII-16-2	[ VIII-2-3 blank	[ IX-2-1 IX-2-2
[ V-4-1 V-4-2	[ VII-1-7 VII-1-8	[ VII-17-1 VII-17-2	[ VIII-3-1 VIII-3-2	[ IX-2-5 IX-2-6
[ V-4-3 V-4-4	[ VII-1-9 VII-1-10	[ VII-18-1 VII-18-2	[ VIII-3-3 VIII-3-4	[ IX-2-7 IX-2-8
[ V-B-1 blank	[ VII-2-3 VII-2-4	[ VII-19-1 VII-19-2	[ VIII-3-5 VIII-3-6	[ IX-2-8.1 blank
[ V-Index-1 V-Index-2	[ VII-2-15 VII-2-16	[ VII-20-1 VII-20-2	[ VIII-3-7 VIII-3-8	[ IX-2-9 IX-2-10
[ VI-1-1 VI-1-2	[ VII-3-5 VII-3-6	[ VII-20-3 VII-20-4	[ VIII-3-9 VIII-3-10	[ IX-2-11 IX-2-12
[ VI-1-3 VI-1-4	[ VII-4-1 VII-4-2	[ VII-21-1 VII-21-2	[ VIII-4-1 VIII-4-2	[ IX-2-15 blank
[ VI-1-5 VI-1-6	[ VII-4-3 VII-4-4	[ VII-21-3 VII-21-4	[ VIII-4-3 VIII-4-4	[ IX-2-15.1 IX-2-16

[ IX-2-23 IX-2-24	[ X-2-3 X-2-4	[ X-9-3 X-9-4	[ XII divider blank	[ Index-1 Index-2
[ IX-2-25 IX-2-26	[ X-2-15 X-2-16	[ X-9-5 X-9-6	[ XII-1-1 blank	[ Index-3 Index-4
[ IX-3-1 IX-3-2	[ X-2-21 X-2-22	[ X-A-1 X-A-2	[ XII-2-1 blank	[ Index-5 Index-6
[ IX-3-3 IX-3-4	[ X-3-5 X-3-6	[ X-D-1 blank	[ XII-3-3 XII-3-4	[ Index-7 Index-8
[ IX-3-5 blank	[ X-4-1 X-4-2	[ X-Index-1 X-Index-2	[ XII-3-5 XII-3-6	[ Index-9 Index-10
[ IX-3-5.1 IX-3-6	[ X-4-3 blank	[ XI-1-1 XI-1-2	[ XII-3-7 XII-3-8	[ Index-11 Index-12
[ IX-3-7 IX-3-8	[ X-5-1 X-5-2	[ XI-3-1 XI-3-2	[ XII-6-1 XII-6-2	[ Index-13 Index-14
[ IX-3-9 IX-3-10	[ X-5-3 X-5-4	[ XI-3-3 XI-3-4	[ XII-6-7 XII-6-8	[ Index-15 blank
[ IX-Index-1 blank	[ X-7-3 X-7-4	[ XI-4-3 XI-4-4	[ XII-6-9 XII-6-10	
[ X-1-1 X-1-2	[ X-9-1 X-9-2	[ XI-Index-1 XI-Index-2	[ XII-Index-1 blank	

XVM/RSX PART I  
PREFACE

## PREFACE

This manual describes the operation and use of the XVM/RSX V1B software operating system. The manual contains twelve parts numbered I through XII. Each of these parts is divided into chapters and sections. There is a Master Table of Contents and a Master Index for the entire manual.

The new reader should become familiar with RSX (Resource Sharing Executive) by studying this manual in the following suggested order:

- Part II Introduction
- Part XII System Installation Guide
- Part IV Monitor Console Routine
- Part VII On-Line Task Development
- Part VI I/O Operations
- Part V System Directives

This study can be followed by reading the remaining topics of interest.

## LIST OF ALL XVM MANUALS

The following is a list of all XVM manuals and their DEC numbers, including the latest version available. Within this manual, other XVM manuals are referenced by title only. Refer to this list for the DEC numbers of these referenced manuals.

BOSS XVM USER'S MANUAL	DEC-XV-OBUAA-A-D
CHAIN XVM/EXECUTE XVM UTILITY MANUAL	DEC-XV-UCHNA-A-D
DDT XVM UTILITY MANUAL	DEC-XV-UDDTA-A-D
EDIT/EDITVP/EDITVT XVM UTILITY MANUAL	DEC-XV-UETUA-A-D
STRAN XVM UTILITY MANUAL	DEC-XV-UTRNA-A-D
FOCAL XVM LANGUAGE MANUAL	DEC-XV-LFLGA-A-D
FORTRAN IV XVM LANGUAGE MANUAL	DEC-XV-LF4MA-A-D
FORTRAN IV XVM OPERATING ENVIRONMENT MANUAL	DEC-XV-LF4EA-A-D
LINKING LOADER XVM UTILITY MANUAL	DEC-XV-ULLUA-A-D
MAC11 XVM ASSEMBLER LANGUAGE MANUAL	DEC-XV-LMLAA-A-D
MACRO XVM ASSEMBLER LANGUAGE MANUAL	DEC-XV-LMALA-A-D
MTDUMP XVM UTILITY MANUAL	DEC-XV-UMTUA-A-D
PATCH XVM UTILITY MANUAL	DEC-XV-UPUMA-A-D
PIP XVM UTILITY MANUAL	DEC-XV-UPPUA-A-D
SGEN XVM UTILITY MANUAL	DEC-XV-USUTA-A-D
SRCCOM XVM UTILITY MANUAL	DEC-XV-USRCA-A-D
UPDATE XVM UTILITY MANUAL	DEC-XV-UUPDA-A-D
VP15A XVM GRAPHICS SOFTWARE MANUAL	DEC-XV-GVPAA-A-D
VT15 XVM GRAPHICS SOFTWARE MANUAL	DEC-XV-GVTAA-A-D
■ XVM QUICKSCAN USER'S MANUAL	DEC-XV-GVSDA-A-D
XVM/DOS KEYBOARD COMMAND GUIDE	DEC-XV-ODKBA-A-D
XVM/DOS READER'S GUIDE AND MASTER INDEX	DEC-XV-ODGIA-A-D
XVM/DOS SYSTEM MANUAL	DEC-XV-ODSAA-A-D
XVM/DOS USERS MANUAL	DEC-XV-ODMAA-A-D
XVM/DOS V1A INSTALLATION GUIDE	DEC-XV-ODSIA-A-D
■ XVM/RSX SYSTEM MANUAL	DEC-XV-IRSMA-B-D
XVM UNICHANNEL SOFTWARE MANUAL	DEC-XV-XUSMA-A-D
XVM MUMPS LANGUAGE REFERENCE MANUAL	DEC-XV-MLMAA-A-D
■ XVM MUMPS VERSION 1 USER'S GUIDE	DEC-XV-MGMAA-A-D
XVM TENLINK USER'S MANUAL	DEC-XV-CTLSA-A-D
■ XVM/RSX MULTIACCESS USER TIPS	DEC-XV-IRUTA-A-D