



iSeries<sup>™</sup>

RouteD

Version 5 Release 3





iSeries<sup>™</sup>

RouteD

Version 5 Release 3

#### Note

Before using this information and the product it supports, be sure to read the information in notices.

#### Fourth Edition (August 2005)

| | | This edition applies to version 5, release 3, modification 0 of IBM Operating System/400<sup>®</sup> (product number 5722–SS1) and to all subsequent releases and modifications until otherwise indicated in new editions. This version does not run on all reduced instruction set computer (RISC) models nor does it run on CISC models.

© Copyright International Business Machines Corporation 2000, 2005. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

# RouteD

The Route Daemon, or RouteD, provides support for the Routing Information Protocol, or RIP, on the system. RIP is the most widely used routing protocol today. It is an Interior Gateway Protocol, or IGP, that assists TCP/IP in the routing of IP data packets within an autonomous domain. Dynamic routing protocols allow you to handle networks with multiple routers or to switch automatically to redundant routes.

• **RouteD configuration commands** This topic describes the RouteD configuration commands and how to access them. You can use these commands to configure RouteD.

- **RouteD attribute commands** This topic describes the Change RouteD Attributes (CHGRTDA) command and how to access this command. You can use this command to change RouteD attributes.
- **RouteD work with configuration command** This topic describes the Work with RouteD Configuration (WRKRTDCFG) command and how to access this command. You can use this command to work with the RouteD configuration.
- **RouteD configuration scenario** This topic describes a configuration scenario that shows how RouteD configuration entries work in a sample network. You can use this scenario as an example for your own RouteD configuration
- RIP\_INTERFACE statement

This topic describes RIP\_INTERFACE statement. It allows you to specify all of the routing options that you configure on a per-interface basis.

# Print this topic

To view or download the PDF version, select RouteD (about 11 KB).

### Saving PDF files

To save a PDF on your workstation for viewing or printing:

- 1. Open the PDF in your browser (click the link above).
- 2. In the menu of your browser, click File.
- 3. Click Save As...
- 4. Navigate to the directory in which you would like to save the PDF.
- 5. Click Save.

### Downloading Adobe Acrobat Reader

If you need Adobe Acrobat Reader to view or print these PDFs, you can download a copy from the

Adobe Web site (www.adobe.com/prodindex/acrobat/readstep.html)

# **RouteD configuration commands**

Use the Configure TCP/IP RouteD (CFGTCPRTD) command to configure the RouteD server. The following are two different ways to access this command prompt:

- Specify CFGTCPRTD (Configure TCP/IP RouteD) command from the command line.
- Specify CFGTCPAPP (Configure TCP/IP Applications) command from the command line. Select option 2 (Configure RouteD).

After you specify the command, you see the following display:

```
Configure TCP/IP RouteD
System: SYSNAM01
Select one of the following:
1. Change RouteD attributes
2. Work with RouteD configuration
```

Figure 1. Configure TCP/IP RouteD

The following two commands control the RouteD server:

- The Change RouteD Attributes (CHGRTDA) command allows an administrator to set the configurable attributes for the RouteD server.
- The Work with RouteD Configuration (WRKRTDCFG) command allows an administrator to work with the RouteD configuration.

# **RouteD attribute commands**

Use the Change RouteD Attributes (CHGRTDA) command to change the RouteD server attributes. The following are two different ways to access this command prompt:

- Specify the CHGRTDA (Change RouteD Attributes) command from the command line.
- Select option 1 on the Configure TCP/IP RouteD (CFGTCPRTD) display.
- **Note:** You must have \*IOSYSCFG special authority to make changes to the RouteD attributes with the CHGRTDA command.

```
Change RouteD Attributes (CHGRTDA)
Type choices, press type.
Autostart . . . . . . . . . *No *SAME, *YES, *NO
Supply . . . . . . . . . . . *No *SAME, *YES, *NO
```

Figure 2. Change RouteD Attributes (CHGRTDA)

# RouteD work with configuration command

Use the Work with RouteD Configuration (WRKRTDCFG) command to change the RouteD configuration. The following are two different ways to access this command prompt:

- Specify WRKRTDCFG (Work with RouteD Configuration) from the command line.
- Select option 2 on the Configure TCP/IP RouteD (CFGTCPRTD) display.
- **Note:** You must have \*IOSYSCFG special authority to make changes to the RouteD configuration with the WRKRTDCFG command.

(			Work with RouteD Configuration	Suctor: SVSNAMO1
	Type opt	tions, pro	ess Enter.	System: SYSNAMUI
	1=Add	2=Chang	je 3=Copy 4=Remove 5=Display I3=Ins	sert
	Se	equence		
	Opt N	Number	Entry	
		00010	# * * * * * * * * * * * * * * * * * * *	* * * * * * * >
		00020	# RTD DEFAULT CONFIGURATION	>
		00030	# * * * * * * * * * * * * * * * * * * *	* * * * * * * >
		00040	#	>
		00050	<pre># RouteD Interface Definitions</pre>	
		00060	#	
		00070	<pre># TCP/IP will learn about a route to netwo</pre>	ork 9.0.0.0 th >
		00080	<pre># means external to RouteD, therefore do r</pre>	not allow Rout >
		00090	# route to this network.	
		00100	#	
		00110	<pre># RIP INTERFACE * SUPPLY RIP1 METRIC 1 BL(</pre>	DCK 9.0.0.0 MA >
		00120	#	
		00130	#	
				More
	F3=Exit	F5=Ref	resh F6=Print List F12=Cancel F17=Top	o F18=Bottom

Figure 3. Work with RouteD Configuration

# Scenario: RouteD configuration

The preceding figure hows how the RouteD configuration entries work in a sample network. The routers know that every route within every network, including networks X, Y, Z, A, and W.



Figure 4. RouteD configuration scenario

- **Case 1** If router AY has an interface of 192.10.2.1, a metric of 1, and a NOFORWARD parameter of 192.50.21.0, then none of the hosts in the networks reach network A.
- **Case 2** If router WZ has an interface of 192.10.3.1, a metric of 1, and a NOFORWARD parameter of 192.10.4.0, then none of the IP packets go through router WZ to get to network W. IP packets can still reach network W, however, because router WY provides a route to that network.
  - **Note:** If you set the parameter option of any interface to Passive, then no routing takes place across the interface.

# **RIP\_INTERFACE** statement

Use the RIP\_INTERFACE statement to specify all of the routing options that you configure on a per-interface basis. The RIP\_INTERFACE statement now contains the functionality for defining routes and creating static routes. Prior to Version 4 Release 2, this functionality existed in the NET statement and HOST statement.

You can specify multiple interface options on a single entry in the configuration file. You can accomplish this only if one of those options that requires a destination address appears on a given statement. Options include the following:

- BLOCK
- FORWARD
- FORWARD.COND
- NOFORWARD

For example, a statement can use the forward and metric options on a single line. However, the forward and noforward options cannot appear on the same line. Use only one option on a given line and use multiple lines to specify multiple options for a given interface.

You can specify interfaces on the system in the following methods:

#### Network

Specified as an IP address and either a mask or an IP address and bit number. The bit number n indicates which bit in the 0 - n bits of the IP address (counting left to right) is the last bit of the IP address' network portion. If the MASK and bit number are missing, the system calculates a network by using the subnet mask of the interface specified through the ADDTCPIFC command.

#### Interface name

Logical Interface name that identifies a PPP interface with an IP address that is assigned dynamically when the PPP connection becomes active.

### Hostname

The Host name of the system, which is resolvable through DNS.

\* Refers to all of the interfaces on the system and is useful for setting default values that apply to all interfaces. You can override these defaults by providing a RIP\_INTERFACE statement for a specific interface with different values for selected parameters.

# Supply values

The following is a list of possible values for a RIP\_INTERFACE supply value:

### PASSIVE

The system does not receive or generate any RIP traffic on the specified interface.

### SUPPLY RIP1

Indicates which version of the RIP protocol the system uses to send and receive routing information to and from neighboring routers. For SUPPLY RIP1, the system processes only RIPv1 packets.

### SUPPLY RIP2

Indicates which version of the RIP protocol the system uses to send and receive routing information to and from neighboring routers. For SUPPLY RIP2, the system uses the multicast address 224.0.0.9 to process only RIPv2 packets, as specified in the RFC1723 sect.3.5.

#### **SUPPLY OFF**

Indicates that the system receives both RIPv1 and RIPv2 on the specified interface. However, the system does not send RIP packets.

**Note:** The default supply value for interfaces that you do not specify is SUPPLY RIP1. The system does not support RIP Version 1 Compatibility mode.

# DIST\_ROUTES\_IN

DIST\_ROUTES\_IN controls how RouteD redistributes routes that it receives from this RIP\_INTERFACE network to Wide Area Networks, or WANs. This parameter does not affect redistribution of routes to Local Area Networks, or LANs. The following is a list of values and their definitions:

### \*CALC

RouteD determines a value of FULL or LIMITED by whether the RIP\_INTERFACE network is a LAN or a WAN. If the specified interface is broadcast-capable, it is assumed local, and a value of FULL is given. Otherwise, the system uses a value of LIMITED.

### FULL

Indicates that RouteD redistributes routes that it receives from the specified interface to all of the other interfaces that use normal RIP algorithm. Specify this value only for local networks.

### LIMITED

Indicates that the server is not to redistribute routes that it receives from the RIP\_INTERFACE network to other LIMITED interfaces. Specify this value only for some type of WAN. You cannot set this value for a LAN.

## **Metric**

This parameter specifies the metric that the system adds to routes that it receives through the specified interface. Possible values are 1 through 15.

# Community

This parameter specifies the community name used by this interface for authentication purposes as specified in RFC 1723 section 3.1. It is valid for interfaces with a SUPPLY value of RIP2. The rip\_community\_name is a character string of 1 to 16 characters in length.

If you specify the community option, then the system indicates that this interface needs authentication. The community name that is specified with the community option must match the community name sent in all RIP2 message blocks for this interface. If you do not specify the community option, then the system does not indicate any authentication for this interface.

# **Additional parameters**

You can also encounter the following RIP\_INTERFACE parameters:

- BLOCK
- FORWARD
- FORWARD.COND
- NOFORWARD

## BLOCK

The BLOCK parameter prevents the network route received on the specified interface from being included in the RouteD routes table. Consequently, the network is unknown and not forwarded to any other routers. Specify networks that you want to block by one of the following methods:

### Network

A network that is specified as an IP address and a mask or as an IP address and a bit number. The bit number n indicates which bit in the 0 - n bits of the IP address (counting left to right) is the last bit of the network portion of the IP address. If the MASK and bit number are missing, the system calculates a network by using the subnet mask of the interface specified through the ADDTCPIFC CL command.

### PRIVATE

The PRIVATE keyword refers to the sets of IP addresses that are designated for use by the Internet Assigned Number Authority (IANA) only within private internets. For more information, see RFC 1918, section 3.

- 10.0.0.0 to 10.255.255.255 (10/8 prefix) 1 class A network.
- 172.16.0.0 to 172.31.255.255 (172.16/12 prefix) 16 class B networks.
- 192.168.0.0 to 192.168.255.255 (192.168/16 prefix) 256 class C networks.

When the RouteD server tries to send a route, it processes multiple forward parameters in the supplied order. The first forward parameter that allows the system to send the route over the specified interface ends the processing. The default is not to forward.

### FORWARD

Use of the FORWARD keyword forwards the specified network route exclusively over the specified interface. If the specified interface is inactive, RouteD takes no special action to forward this network.

Specify a network as both an IP address and a mask or as both an IP address and a bit number. The bit number n indicates which bit in the 0 - n bits of the IP address (counting left to right) is the last bit of the network portion of the IP address. If the MASK and bit number are missing, the system calculates a network by using the subnet mask of the interface specified through the ADDTCPIFC CL command.

### FORWARD.COND

Use of the FORWARD.COND keyword forwards the specified network route exclusively over the specified interface. If the specified interface is inactive, RouteD forwards the network over all of the other interfaces.

Specify a network as both an IP address and a mask or as both an IP address and a bit number. The bit number n indicates which bit in the 0 - n bits of the IP address (counting left to right) is the last bit of the network portion of the IP address. If the MASK and bit number are missing, the system calculates a network by using the subnet mask of the interface specified through the ADDTCPIFC CL command.

### **NOFORWARD**

When you use the NOFORWARD parameter, the system does not send out RIP information about the specified network to the specified interface. Specify networks in one of the following two methods:

### Network

Specify a network as both an IP address and a mask or as both an IP address and a bit number. The bit number n indicates which bit in the 0 - n bits of the IP address (counting left to right) is the last bit of the network portion of the IP address. If the MASK and bit number are missing, the system calculates a network by using the subnet mask of the interface specified through the ADDTCPIFC CL command.

### PRIVATE

The PRIVATE keyword refers to the sets of IP addresses that are designated for use by the IANA within private internets. For more information, see RFC 1918, section 3.

- 10.0.0.0 to 10.255.255.255 (10/8 prefix) 1 class A network.
- 172.16.0.0 to 172.31.255.255 (172.16/12 prefix) 16 class B networks.
- 192.168.0.0 to 192.168.255.255 (192.168/16 prefix) 256 class C networks.

# **Appendix. Notices**

This information was developed for products and services offered in the U.S.A.

IBM<sup>®</sup> may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

- | IBM Director of Licensing
- I IBM Corporation
- North Castle Drive
- | Armonk, NY 10504-1785
- U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

- I IBM World Trade Asia Corporation
- | Licensing
- | 2-31 Roppongi 3-chome, Minato-ku
- | Tokyo 106-0032, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate withoutincurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

| IBM Corporation

Software Interoperability Coordinator, Department 49XA
3605 Highway 52 N
Rochester, MN 55901
U.S.A.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this information and all licensed material available for it are provided
by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement,
IBM License Agreement for Machine Code, or any equivalent agreement between us.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

### COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. You may copy, modify, and distribute these sample programs in any form without payment to IBM for the purposes of developing, using, marketing, or distributing application programs conforming to IBM's application programming interfaces.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

## **Trademarks**

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

Application System/400 AS/400 e(logo)server IBM iSeries Operating System/400 OS/400 400

Other company, product, and service names may be trademarks or service marks of others.



Printed in USA