

RLV11, RL01,
RL02

RLV11, RL01 DISKLESS
CVRLACO

AH-B108C MC
FICHE 1 OF 1

MAY 1983
COPYRIGHT © 78-83
MADE IN USA



Microfiche grid containing multiple frames of data, including text and tables. The content is too small to read accurately but appears to be organized in a structured format.



.REM 8

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47

IDENTIFICATION

PRODUCT CODE: AC-B107C-MC
PRODUCT NAME: CVRLACO RLV11 RL01 DSKLS
PRODUCT DATE: SEPTEMBER 1982
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: W. HEAVEY

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPOSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1978,1983 DIGITAL EQUIPMENT CORPORATION

48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT FOR THE RLV11 RLO1 DISKLESS TEST

1.1.1 STRUCTURE OF PROGRAM

THE DIAGNOSTIC SUPERVISOR > REV C HAS BEEN RELEASED SEPARATED FROM THIS PROGRAM. ONE SHOULD REFER TO THE XXDP+/SUPR USERS MANUAL (AC-F348_-MC) FOR SUPERVISOR LOADING AND OPERATING INSTRUCTIONS.

THIS DIAGNOSTIC WITH THE SUPERVISOR OCCUPIES UP TO 14.5K WORDS OF MEMORY AND IS COMPATIBLE WITH BOTH XXDP+ AND ACT. IT CAN BE RUN IN STANDALONE UNDER XXDP+ AND CAN BE CHAINED UNDER XXDP+,ACT AND RUN ON APT AND ACT ON APT.

WHEN THIS DIAGNOSTIC IS STARTED AT ADDRESS 200, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER. AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN THE XXDP+/SUPR USERS MANUAL (AC-F348_-MC).

1.1.2 DIAGNOSTIC INFORMATION

THE RLV11 RLO1 DISKLESS TEST IS A LSI-11(PDP-11) BASED PROGRAM THAT WILL TEST THE CONTROLLER.

RLV11 CONTROLLER

THE PROGRAM TESTS THE BASIC INTERFACE LOGIC, REGISTER MANIPULATION AND FUNCTIONALITY. THE RLV11 MAINTENANCE FUNCTION IS PERFORMED TO TEST THE CONTROLLER WRITE/READ DATA PATHS WITHOUT A DRIVE PRESENT. THIS TEST WILL RUN WITH OR WITHOUT A DRIVE PRESENT.

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF CORE
CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
RLV11 CONTROLLER(S) (1-8)
KW11P, KW11L (OPTIONAL)
LINEPRINTER(OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159

1.3 RELATED DOCUMENTS AND STANDARDS

RL01 USERS MANUAL (EK-RL01-UG-PRE)
CHQUSB XXDP+/SUPR USER MAN (AC-F348 -MC)
FOR DIAGNOSTIC SUPERVISOR COMMAND INSTRUCTIONS.

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01 SUBSYSTEM IS ASSUMED TO WORK
PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC.,
DO NOT FUNCTION PROPERLY.

2.0 OPERATING INSTRUCTIONS

2.1 LOADING AND STARTING PROCEDURES

2.1.1 LOADING PROCEDURES

FOR LOADING AND OPERATING INSTRUCTIONS, PLEASE REFER TO
CHQUSB XXDP+/SUPR USER MAN (AC-F348 -MC).
ISSUE THE COMMAND 'R CVRLAC'. THE XXDP+ MONITOR WILL LOAD
THE DIAGNOSTIC AND THE SUPERVISOR FILE HSAA??.SYS AND THEN
GIVE CONTROL TO THE SUPERVISOR.

2.1.2 STARTING PROCEDURES

THE PROGRAM STARTS AT LOCATION 200. USE STANDARD DEC PROCEDURES
TO START THE PROGRAM.
PLEASE REFER TO CHQUSB XXDP+/SUPR MAN (AC-F348 -MC) FOR
SUPERVISOR STARTUP COMMANDS.

2.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION

THE DIAGNOSTIC CAN BE EXECUTED STANDALONE WITHOUT READING THE REMAINDER OF THIS
DOCUMENT AS FOLLOWS:

- A) LOAD THE DIAGNOSTIC
- B) START AT ADDRESS 200
- C) ANSWER THE HARDWARE QUESTIONS
- D) RECEIVE PROMPT

160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215

- E) ENTER STA<CR>
- F) ANSWER HARDWARE AND SOFTWARE QUESTIONS
- G) GET END OF PASS MESSAGES OR ERROR MESSAGES
- H) TO END EXECUTION, ENTER CONTROL/C

2.2 SPECIAL ENVIRONMENTS

THE ENVIRONMENTS THIS PROGRAM WILL RUN IN ARE XXDP+, XXDF+ CHAIN, ACT, SLIDE AND APT.

2.3 PROGRAM OPTIONS

2.3.1 START COMMAND

STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:<FLAG-LIST>/EOP:<INCR>

2.3.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) SEPARATED BY COLONS, SPECIFYING WHICH TESTS IT IS DESIRED BE EXECUTED. THE TEST NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE OPERATOR. SEE EXAMPLE AT END OF 2.3.1.

2.3.1.2 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING EXECUTION: IE, EXIT IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR BY A HALT ON ERROR BEING ENCOUNTERED, IN WHICH CASE WE RETURN TO COMMAND MODE. SEE EXAMPLE AT END OF 2.3.1.

2.3.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

- HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED
- LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR
- IER INHIBIT ERROR REPORTING

216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271

IBE INHIBIT BASIC ERROR REPORTS
IXE INHIBIT EXTENDED ERROR REPORTS
PRI DIRECT ALL MESSAGES TO A LINE PRINTER
PNT PRINT NUMBER OF TEST BEING EXECUTED
BOE BELL ON ERROR
UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
ISR INHIBIT STATISTICAL REPORTS
IDR INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

2.3.1.4 END OF PASS SWITCH (/EOP:<INCR>)

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

2.3.2 CONTROL CHARACTERS

A CONTROL C (^C) ENTERED VIA THE CONSOLE DEVICE DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO THE DIAGNOSTIC SUPERVISOR COMMAND MODE.

A CONTROL Z (^Z) ENTERED WITHIN ONE OF THE THREE OPERATOR DIALOGS (HARDCORE, HARDWARE, OR SOFTWARE QUESTIONS) CAUSES TO DEFAULT VALUES TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.

A CONTROL O (^O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL CONSOLE OUTPUT TO BE SUPPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER CONTROL O IS TYPED.

2.3.4 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

11/23 PROCESSOR (L) Y?

ANSWER YES(Y) IF YOU HAVE AN 11/23 LSI-11 BUS PROCESSOR,
ANSWER NO (N) IF YOU HAVE AN LSI-11(11/03L ETC.) PROCESSOR.

BUS ADDRESS (O) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (O) 330?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327

DRIVE (0) 0?

SINCE THIS PROGRAM RUNS WITHOUT A DRIVE, THIS QUESTION DOES NOT APPLY. THE HARDWARE QUESTION ON DRIVE NUMBER IS ASKED TO MAINTAIN COMPATIBILITY WITH THE RL11 PROGRAMS FOR CHAIN MODE.

WHEN TESTING MULTIPLE CONTROLLERS(0 TO 7), THE OPERATOR CAN RESPOND TO DRIVE NUMBER BY TYPING A NUMBER(0-7) FOR EACH CONTROLLER. THEN WHEN AN ERROR IS PRINTED, THE DRIVE NUMBER IN THE ERROR PRINTOUT WILL REFER TO THE NUMBER ASSIGNED THE CONTROLLER.

BR LEVEL(0) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

2.3.5 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED ON A START, RESTART OR CONTINUE IF THE QUESTION:

CHANGE SW?

IS ANSWERED YES(Y). THE QUESTIONS ARE:

DROP ON ERROR LIMIT (L) Y?

TO ALLOW THE UNIT TO BE DROPPED ONCE A PREDETERMINED NUMBER OF ERRORS ARE ENCOUNTERED.

ANSWER Y OR N

ERROR LIMIT (D) 10?

NUMBER OF ERRORS ALLOWED BEFORE DROPPING UNIT.

ANSWER 1 TO 65K

AUTOSIZE (L) N?

TO CHECK TO SEE IF UNIT SPECIFIED ACTUALLY EXISTS BEFORE TESTING IT (VIA DRIVE READY), IF NOT UNIT WILL NOT BE TESTED.

ANSWER Y OR N

2.3.6 EXTENDED DISCUSSION OF P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N, SAY) SPACE IN CORE IS ALLOCATED FOR N P-TABLES. ALL OF THE P-TABLES

328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383

ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

ON THE FIRST TRIP THRU THE QUESTIONS, ALL OF THE SLOTS IN ALL OF THE P-TABLES ARE FILLED. IF THE OPERATOR TYPES IN LESS THAN N EXPLICIT VALUES IN RESPONSE TO A PARTICULAR QUESTION, THESE VALUES ARE PLACED IN THE P-TABLES (ONE VALUE GOING INTO THE PROPER SLOT OF EACH P-TABLE BEGINNING WITH THE FIRST P-TABLE) UNTIL THE STRING OF VALUES IS EXHAUSTED. THE LAST VALUE IN THE STRING BECOMES THE NEW DEFAULT AND IS USED THEN AND THERE TO FILL THAT SLOT IN THE REMAINING P-TABLES.

ON SUBSEQUENT TRIPS THRU THE QUESTIONS, THE SAME PROCESS IS CARRIED OUT, EXCEPT THAT THE EARLIEST P-TABLE NOT TO HAVE RECEIVED AN EXPLICIT VALUE IN ANY OF ITS SLOTS NOW ASSUMES THE ROLE THAT TABLE NUMBER ONE PLAYED IN THE FIRST TRIP.

THE SERIES OF QUESTIONS IS REISSUED UNTIL AT LEAST ONE QUESTION HAS RECEIVED N EXPLICIT VALUES FROM THE OPERATOR.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 64 UNITS, AND THAT THERE ARE THREE HARDWARE PARAMETERS FOR EACH (THREE SLOTS IN THE P-TABLE, THREE HARDWARE QUESTIONS IN THE DIALOGUE). LET THE DESIRED VALUE FOR THE FIRST PARAMETER BE THE NUMBER 75 FOR ALL 64 TABLES. LET THE DESIRED VALUE FOR THE SECOND PARAMETER BE EQUAL TO THE UNIT NUMBER (1,2,3,...,64) EXCEPT FOR UNIT 50, WHICH SHOULD RECEIVE THE VALUE 49. LET THE DESIRED VALUE FOR THE THIRD PARAMETER BE THE NUMBER 76 FOR THE FIRST 20 UNITS AND THE NUMBER 77 FOR THE LAST 44 UNITS.

THE FOLLOWING DIALOGUE WOULD ACCOMPLISH THIS GOAL:

UNITS (D) ? 64

UNIT 1
<QUESTION 1> ? 75
<QUESTION 2> ? 1-20
<QUESTION 3> ? 76

UNIT 21
<QUESTION 1> ?
<QUESTION 2> ? 21-49,,51-64
<QUESTION 3> ? 77

THE FIRST TIME THE SERIES IS ASKED, SLOT ONE RECEIVES A 75 IN ALL 64 TABLES. SLOT TWO RECEIVES THE VALUES 1,2,3,...,20 IN TABLES 1 THRU 20 AND A CONSTANT 20 IN TABLES 21 THRU 64. SLOT THREE RECEIVES A CONSTANT 76 IN ALL 64 TABLES.

384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439

THE SECOND TIME THRU THE SERIES, TABLES 21 THRU THE END ARE GOING TO BE AFFECTED (NOTE THAT THIS PIECE OF INFORMATION IS PRINTED OUT FOR THE OPERATOR IN THE FORM 'UNIT XX' AT THE BEGINNING OF EACH SERIES). QUESTION 1 IS RESPONDED TO BY A <CR>, SO SLOT ONE STAYS AT CONSTANT 75 IN TABLES 21 THRU 64, SINCE NO NEW EXPLICIT VALUES ARE TYPED IN. SLOT TWO GETS THE VALUES 21,22,23,...,49 IN TABLES 21 THRU 49, AND GETS A 49 IN SLOT 50, AND GETS THE VALUES 51,52,53,...,64 IN TABLES 51 THRU 64. SLOT THREE GETS THE VALUE 77 IN TABLES 21 THRU 64.

THE DIALOGUE IS TERMINATED WHEN THE SOFTWARE RECOGNIZES THAT 64 EXPLICIT VALUES HAVE BEEN GIVEN FOR AT LEAST ONE QUESTION (NAMELY QUESTION 2).

2.4 EXECUTION TIMES

ONE PASS OF THE PROGRAM TAKES APPROXIMATELY < 30 SECONDS.

3.0 ERROR INFORMATION

3.1 ERROR REPORTING

ALL ERROR INFORMATION IS PRINTED ON THE CONSOLE DECIVE. ERROR REPORTS ARE AIMED AT BEING SELF EXPLANATORY. THE GENERAL FORMAT IS:

CVRL? XXX ERR YYYYY TST ZZZ SUB PPP PC: RRRRRR

WHERE:

? IS PROGRAM LETTER
XXX IS SFT - SOFT ERROR
HRD - HARD ERROR
DV FAT - DEVICE FATAL ERROR
SYS FAT - SYSTEM FATAL ERROR
YYYYY IS THE ERROR NUMBER
ZZZ IS THE TEST NUMBER
PPP IS THE SUBTEST NUMBER
RRRRRR IS THE PROGRAM LISTING LOCATION

ERRORS GIVE THE REGISTER CONTENTS BEFORE AND AFTER THE ERROR ALONG WITH A ONE LINE DESCRIPTION AND RELEVANT DATA.

EXAMPLE:

ONE LINE DESCRIPTION
(OPTIONAL SECOND LINE)
(OPTIONAL THIRD LINE)
BEFORE COMMAND: CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX
TIME OF ERROR: CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX XXXXXX

REGISTER DESCRIPTIONS CAN BE FOUND IN SECTION 5.0.
CS:CONTROL AND STATUS REGISTER

440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495

BA:BUS ADDRESS REGISTER
DA:DISK ADDRESS REGISTER
MP:MULTIPURPOSE REGISTER

NOTE: TO PREVENT EXTENSIVE PRINTOUTS ON BUFFER FAILURES
USE THE "FLAG:IXE" (INHIBIT EXTENDED ERROR REPORTS)
SUPERVISOR COMMAND.

EXAMPLE: DR>STA/FLAG:IXE OR DR>RES/FLAG:IXE

USE OF THIS FLAG WILL PRINT ONLY THE FIRST FAILURE
ENCOUNTERED IN THE BUFFER.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION
WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4)
REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

- BIT 15 - COMPOSITE ERROR
- BIT 14 - DRIVE ERROR
- BIT 13 - NON EXISTENT MEMORY ERROR
- BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
- DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)
- DATA CRC (WITH BIT 10 CLEAR)
- BIT 10 - OPERATION INCOMPLETE
- BIT 9/8 - DRIVE SELECT (0-3)
- BIT 7 - CONTROLLER READY
- BIT 6 - INTERRUPT ENABLE

496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551

BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
BIT 3-1 - FUNCTION CODE
0 - NOP (PDP-11) MAINT (LSI-11)
1 - WRITE CHECK
2 - GET DRIVE STATUS
3 - SEEK
4 - READ HEADER
5 - WRITE DATA
6 - READ DATA
7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15 - MUST BE ZERO(0)
BIT 14-7 - CYLINDER ADDRESS FOR TRANSFER
BIT 6 - SURFACE FOR TRANSFER
BIT 5-0 - SECTOR FOR TRANSFER (0-47)

FOR SEEK FUNCTION

BIT 15 - MUST BE ZERO(0)
BIT 14-7 - DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO(0)
BIT 4 - SURFACE
BIT 3 - MUST BE ZERO
BIT 2 - SEEK DIRECTION(1 - IN / 0 - OUT)
BIT 1 - MUST BE ZERO
BIT 0 - MUST BE ONE(1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO
BIT 1 - MUST BE ONE
BIT 0 - MUST BE ONE

RLMP - MULTIPURPOSE REGISTER

552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT(TWO'S COMPLEMENT)

FOR READ AFTER MAINTENANCE FUNCTION

BIT 15-0

FIRST RLMP: CRC OF STARTING DISK ADDRESS VALUE+3

SECOND RLMP: CRC OF CRC OF STARTING DISK ADDRESS VALUE+4

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

- BIT 15 - WRITE DATA ERROR
- BIT 14 - CURRENT HEAD ERROR(CHE)
- BIT 13 - WRITE LOCK STATUS(WL)
- BIT 12 - SEEK TIME OUT(SKTO)
- BIT 11 - SPIN ERROR(SPE)
- BIT 10 - WRITE GATE ERROR(WGE)
- BIT 9 - VOLUME CHECK(VC)
- BIT 8 - DRIVE SELECT ERROR(DSE)
- BIT 7 - RESERVED(O)
- BIT 6 - SURFACE
- BIT 5 - COVER OPEN
- BIT 4 - HEADS HOME
- BIT 3 - BRUSHES HOME
- BIT 2-0 - STATE BITS
 - 0 - LOAD STATE
 - 1 - SPIN UP
 - 2 - BRUSH CYCLE
 - 3 - LOAD HEADS
 - 4 - SEEK - TRACK COUNTING
 - 5 - SEEK - LINEAR MODE
 - 6 - UNLOAD HEADS
 - 7 - SPIN DOWN

6.0 TEST SUMMARIES

TEST 1 - RLCS WRITE ADDRESSABILITY

THIS TEST WILL CHECK THAT THE CONTROL AND STATUS REGISTER CAN BE ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 2 - RLBA WRITE ADDRESSABILITY

608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663

THIS TEST WILL CHECK THAT THE BUS ADDRESS REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 3 - RLDA WRITE ADDRESSABILITY

THIS TEST WILL CHECK THAT THE DISK ADDRESS REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 4 - RLMP WRITE ADDRESSABILITY

THIS TEST WILL CHECK THAT THE MULTIPURPOSE REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 5 - RLCS READ ADDRESSABILITY

THIS TEST WILL CHECK THAT THE CONTROL AND STATUS REGISTER
CAN BE ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE
PROCESSOR WILL TRAP TO LOCATION 4, WHICH IS SET UP TO
HANDLE THE TRAP.

TEST 6 - RLBA READ ADDRESSABILITY

THIS TEST WILL CHECK THAT THE BUS ADDRESS REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 7 - RLDA READ ADDRESSABILITY

THIS TEST WILL CHECK THAT THE DISK ADDRESS REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 8 - RLMP READ ADDRESSABILITY

THIS TEST WILL CHECK THAT THE MULTIPURPOSE REGISTER CAN BE
ACCESSED. IF THE REGISTER CANNOT BE ACCESSED THE PROCESSOR
WILL TRAP TO LOCATION 4, WHICH IS SET UP TO HANDLE THE TRAP.

TEST 9 - BUS RESET OF RLCS

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL
CLEAR ALL BITS OF THE RLCS WITH THE EXCEPTION OF BIT 7 (CON-
TROLLER READY), BIT 0 (DRIVE READY) AND BIT 15 (COMPOSITE ERROR)
WHICH WILL BE SET IF BIT 14 (DRIVE ERROR) IS SET.

TEST 10 - BUS RESET OF RLBA

664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL CLEAR ALL BITS OF THE RLBA.

TEST 11 - BUS RESET OF RLDA

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL CLEAR ALL BITS OF THE RLDA.

TEST 12 - READ WRITE OF RLCS

THIS TEST WILL ATTEMPT TO WRITE RLCS BITS 9-1 AND READ THEM BACK. WALKING AND GROWING 0'S AND 1'S ARE USED. BIT 7 (CONTROLLER READY) IS ALWAYS WRITTEN AS A 1 SO NOT TO INITIATE A FUNCTION. BITS 15, 14 AND 0 ARE TREATED AS DON'T CARE FOR THIS TEST.

TEST 13 - READ WRITE OF RLBA

THIS TEST WILL ATTEMPT TO WRITE RLBA BITS 15-0 AND READ THEM BACK. WALKING AND GROWING 0'S AND 1'S ARE USED. BIT 0 ON A RL11 SHOULD ALWAYS COME BACK AS A 0, WHILE ON AN RLV11 IT IS LOADABLE.

TEST 14 - READ WRITE OF RLDA

THIS TEST WILL ATTEMPT TO WRITE RLDA BITS 15-0 AND READ THEM BACK. WALKING AND GROWING 0'S AND 1'S ARE USED.

TEST 15 - BIS OF RLCS

THIS TEST WILL USE THE 11 INSTRUCTION 'BIS' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLCS WORKS. BITS 9-1 ARE USED, BIT SETTING IN WALKING AND GROWING 0'S AND 1'S. BIT 7 (CONTROLLER READY) IS ALWAYS SET. BITS 15, 14 AND 0 ARE DON'T CARES.

TEST 16 - BIC OF RLCS

THIS TEST WILL USE THE 11 INSTRUCTION 'BIC' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLCS WORKS. BITS 9-1 ARE USED, BIT CLEARING IN WALKING AND GROWING 0'S AND 1'S. BIT 7 (CONTROLLER READY) IS ALWAYS SET. BITS 15, 14 AND 0 ARE DON'T CARES.

TEST 17 - BIS OF RLBA

THIS TEST WILL USE THE 11 INSTRUCTION 'BIS' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLBA WORKS. BITS 15-0 ARE BIT SET USING GROWING AND WALKING 0'S AND 1'S. BIT 0 CAN SET ON A RLV11.

720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775

TEST 18 - BIC OF RLBA

THIS TEST WILL USE THE 11 INSTRUCTION 'BIC' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLBA WORKS. BITS 15-0 ARE BIT CLEARED USING GROWING AND WALKING 0'S AND 1'S.

TEST 19 - BIS OF RLDA

THIS TEST WILL USE THE 11 INSTRUCTION 'BIS' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLDA WORKS. BITS 15-0 ARE BIT SET USING GROWING AND WALKING 0'S AND 1'S.

TEST 20 - BIC OF RLDA

THIS TEST WILL USE THE 11 INSTRUCTION 'BIC' TO SHOW THAT A READ-MODIFY-WRITE SEQUENCE OF THE RLDA WORKS. BITS 15-0 ARE BIT CLEARED USING GROWING AND WALKING 0'S AND 1'S.

TEST 21 - BUS RESET OF RLCS

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL CLEAR ALL BITS OF THE RLCS WITH THE EXCEPTION OF BIT 7 (CONTROLLER READY), BIT 0 (DRIVE READY) AND BIT 15 (COMPOSITE ERROR) WHICH WILL BE SET IF BIT 14 (DRIVE ERROR) IS SET.

TEST 22 - BUS RESET OF RLBA

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL CLEAR ALL BITS OF THE RLBA.

TEST 23 - BUS RESET OF RLDA

THIS TEST WILL VERIFY THAT THE BUS RESET OF THE PROCESSOR WILL CLEAR ALL BITS OF THE RLDA.

TEST 24 - UNIQUENESS OF RLCS

THIS TEST WILL VERIFY THAT WHEN THE RLCS (XXXXX0) IS ADDRESSED ONLY THAT REGISTER IS EFFECTED. BOTH THE RLBA AND THE RLDA ARE SET UP WITH KNOWN DATA, THE RLDA IS WRITTEN, THEN THE RLBA AND RLDA ARE VERIFIED THAT THEY DID NOT CHANGE.

TEST 25 - UNIQUENESS OF RLBA

THIS TEST WILL VERIFY THAT WHEN THE RLBA (XXXXX2) IS ADDRESSED ONLY THAT REGISTER IS EFFECTED. BOTH THE RLCS AND RLDA ARE WRITTEN WITH KNOWN DATA, THE RLBA IS WRITTEN, THEN THE RLCS

776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831

AND RLDA ARE VERIFIED THAT THEY DID NOT CHANGE.

TEST 26 - UNIQUENESS OF RLDA

THIS TEST WILL VERIFY THAT WHEN THE RLDA (XXXXX4) IS ADDRESSED ONLY THAT REGISTER IS EFFECTED. BOTH THE RLCS AND RLBA ARE WRITTEN WITH KNOWN DATA, THE RLDA IS WRITTEN, THEN THE RLCS AND RLBA ARE VERIFIED THAT THEY DID NOT CHANGE.

TEST 27 - UNIQUENESS OF RLMP

THIS TEST WILL VERIFY THAT WHEN THE RLMP (XXXXX6) IS ADDRESSED ONLY THAT REGISTER IS EFFECTED. THE RLCS, RLBA AND RLDA ARE WRITTEN WITH KNOWN DATA, THE RLMP IS WRITTEN, THEN THE RLCS, RLBA AND RLDA ARE VERIFIED THAT THEY DID NOT CHANGE.

TEST 28 - RLV11 MAINT. FORCED OPI TEST, LESS THAN 510 WORDS

PERFORM RLV11 MAINTENANCE FUNCTION 0 WITH LESS THAN 510 WORDS TO FORCE OPI ERROR. THE TEST SHOULD FORCE COMPOSITE ERROR (BIT 15), HEADER NOT FOUND (BIT 12) AND OPI (BIT 10). DRIVE ERROR IS IGNORED.

TEST 29 - RLV11 MAINT. FORCED OPI TEST, MORE THAN 511 WORDS

PERFORM RLV11 MAINTENANCE FUNCTION 0 WITH MORE THAN 511 WORDS TO FORCE OPI ERROR. THE TEST SHOULD FORCE COMPOSITE ERROR (BIT 15), HEADER NOT FOUND (BIT 12) AND OPI (BIT 10). DRIVE ERROR IS IGNORED.

TEST 30 - RLV11 MAINT. FORCED OPI TEST - INTERRUPT MODE

PERFORM TEST OF INTERRUPT BY ISSUING RLV11 MAINTENANCE FUNCTION 0 WITH MORE THAN 511 WORDS TO FORCE OPI ERROR. CHECK INTERRUPT OPERATION AND REPORT IF ERROR FOUND.

TEST 31 - RLV11 OPI TIMEOUT TEST

PERFORM RLV11 MAINTENANCE FUNCTION 0 WITH INTERRUPT MODE. FORCE OPI TIMEOUT BY SETTING WORD COUNT TO -512 WORDS. MEASURE OPI TIMEOUT AND COMPARE TO MIN. AND MAX. LIMITS.

TEST 32 - TEST RLV11 MAINT. FUNCTION -FLAG MODE

PERFORM RLV11 MAINTENANCE FUNCTION 0 (FLAG MODE) AND CHECK DA AND BA REGISTERS FOR PROPER INCREMENT. CHECK THE SERIAL WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER THE CRC OF THE DA+3 AND THE CRC OF THE DA+4 AND COMPARING TO EXPECTED RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE FIFO INTO BUF2 MEMORY FOR PROPER DATA. CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR A VALUE=123456 TO INSURE THAT THE DATA TRANSFER IN MAINTENANCE MODE WAS

832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887

NOT MORE THAN 255 WORDS.

TEST 33 - TEST RLV11 MAINT. FUNCTION -INTERRUPT MODE

PERFORM RLV11 MAINTENANCE FUNCTION 0 (INT. MODE) AND CHECK DA AND BA REGISTERS FOR PROPER INCREMENT. CHECK THE SERIAL WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER THE CRC OF THE DA+3 AND THE CRC OF THE CRC OF THE DA+4 AND COMPARING TO EXPECTED RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE FIFO INTO BUF2 MEMORY FOR PROPER DATA. CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR A VALUE=123456 TO INSURE THAT THE DATA TRANSFER IN MAINTENANCE MODE WAS NOT MORE THAN 255 WORDS.

TEST 34 - RLV11 FIFO ADDRESS TEST

TEST THAT FIFO OPERATES CORRECTLY. STORE ADDRESS PATTERN IN BUF1 (0-255) WHICH CONTAINS A UNIQUE PATTERN IN EACH LOCATION. PERFORM MAINTENANCE FUNCTION AND TEST BUF2 FOR PROPER FIFO ADDRESSING.

TEST 35 - RLV11 FIFO ADDRESS COMPLEMENT TEST

TEST THAT FIFO ADDRESSES CORRECTLY. STORE THE ADDRESS COMPLEMENT OF 0-255 INTO BUF1. PERFORM MAINTENANCE FUNCTION AND CHECK BUF2 FOR PROPER FIFO ADDRESSING.

TEST 36 - TEST RLV11 MAINT. WITH COMPLEMENT DATA -INTERRUPT MODE

PERFORM RLV11 MAINT. FUNCTION WITH COMPLEMENT DATA IN BUF1. CHECK DA AND BA REGISTERS FOR PROPER INCREMENT. CHECK THE SERIAL WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER THE CRC OF THE DA+3 AND THE CRC OF THE CRC OF THE DA+4 AND COMPARING TO EXPECTED RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE FIFO INTO BUF2 MEMORY FOR PROPER DATA. CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR A VALUE=123456 TO INSURE THAT THE DATA TRANSFER IN MAINTENANCE MODE WAS NOT MORE THAN 255 WORDS.

TEST 37 - TEST RLV11 MAINT. WITH RANDOM DATA -INTERRUPT MODE

PERFORM RLV11 MAINT. FUNCTION WITH A RANDOM DATA PATTERN IN BUF1 THE RANDOM PATTERN IS THE SAME FOR EACH CONTROLLER UNDER TEST. THE RANDOM PATTERN WILL CHANGE AT END OF PASS. THE RANDOM PATTERN WILL INIT AT START OR RESTART. CHECK DA AND BA REGISTERS FOR PROPER INCREMENT. CHECK THE SERIAL WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER THE CRC OF THE DA+3 AND THE CRC OF THE CRC OF THE DA+4 AND COMPARING TO EXPECTED RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE FIFO INTO BUF2 MEMORY FOR PROPER DATA. CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR A VALUE=123456 TO INSURE THAT THE DATA TRANSFER IN MAINTENANCE MODE WAS NOT MORE THAN 255 WORDS.

888
889
890
891
892
893
894
895
896
897 000000
898 000000
899 000000
900 002000
901
902
903 002000
904
905
906 002000
907
908 002000
909 002000 103
910 002001 126
911 002002 122
912 002003 114
913 002004 101
914 002005 000
915 002006 000
916 002007 000
917 002010 103
918 002011 060
919 002012 000000
920 002014 000036
921 002016 027436
922 002020 027574
923 002022 013574
924 002024 013610
925 002026 030520
926 002030 000000
927 002032 000000
928 002034 000000
929 002036 000000
930 002040 013620
931 002042 000340
932 002044 000000
933 002046 000000
934 002050 003
935 002051 003
936 002052 000000
937 002054 000000
938 002056 000000
939 002060 002122
940 002062 000000
941 002064 000000
942 002066 000000
943 002070 014510

7.0 PROGRAM LISTING

&
.ENABLE AMA
.ENABLE ABS
.NLIST ME,CND,MD

SVC
SVCINS=0
SVCTAG=0
.=2000

POINTER BGNSFT,BGNSW,BGNDU,BGNAU

BGNMOD MDHEDR

HEADER CVRLA,C,0,30.,0,340
.ASCII /C/
.ASCII /V/
.ASCII /R/
.ASCII /L/
.ASCII /A/
.BYTE 0
.BYTE 0
.BYTE 0
.ASCII /C/
.ASCII /O/
.WORD 0
.WORD 30.
.WORD L\$HARD
.WORD L\$SOFT
.WORD L\$HW
.WORD L\$SW
.WORD L\$LAST
.WORD 0
.WORD 0
.WORD 0
.WORD 0
.WORD L\$DISPATCH
.WORD 340
.WORD 0
.WORD 0
.BYTE C\$REVISION
.BYTE C\$EDIT
.WORD 0
.WORD 0
.WORD 0
.WORD L\$DVTYP
.WORD 0
.WORD 0
.WORD 0
.WORD L\$AU

```
944 002072 014504 .WORD LSDU
945 002074 000000 .WORD 0
946 002076 002130 .WORD L$DESC
947 002100 104035 EMT E$LOAD
948 002102 000000 .WORD 0
949 002104 013732 .WORD L$INIT
950 002106 014442 .WORD L$CLEAN
951 002110 014440 .WORD L$AUTO
952 002112 014432 .WORD L$PROT
953 002114 000000 .WORD 0
954 002116 000000 .WORD 0
955 002120 000000 .WORD 0
956
957 002122 ENDMOD
958
959
960
961
962 002122 DEVTYP <RLV11>
963 002122 046122 030526 000061 .ASCIZ /RLV11/
964 .EVEN
965 002130 DESCRIPT <CVRLACRLV11 RL01 DSKLESS DIAGNOSTIC>
966 002130 053103 046122 041501 .ASCIZ /CVRLACRLV11 RL01 DSKLESS DIAGNOSTIC/
967 002136 046122 030526 020061
968 002144 046122 030460 042040
969 002152 045523 042514 051523
970 002160 042040 040511 047107
971 002166 051517 044524 000103
972 .EVEN
973
974 .SBTTL GLOBAL EQUATES
975 002174 BGNMOD GLBEQAT
976
977 002174 EQUALS
978
979 : BIT DIFINITIONS
980 :
981 100000 BIT15== 100000
982 040000 BIT14== 40000
983 020000 BIT13== 20000
984 010000 BIT12== 10000
985 004000 BIT11== 4000
986 002000 BIT10== 2000
987 001000 BIT09== 1000
988 000400 BIT08== 400
989 000200 BIT07== 200
990 000100 BIT06== 100
991 000040 BIT05== 40
992 000020 BIT04== 20
993 000010 BIT03== 10
994 000004 BIT02== 4
995 000002 BIT01== 2
996 000001 BIT00== 1
997 :
998 001000 BIT9== BIT09
999 000400 BIT8== BIT08
```

```

1000      000200      BIT7== BIT07
1001      000100      BIT6== BIT06
1002      000040      BIT5== BIT05
1003      000020      BIT4== BIT04
1004      000010      BIT3== BIT03
1005      000004      BIT2== BIT02
1006      000002      BIT1== BIT01
1007      000001      BIT0== BIT00
1008
1009      :
1010      : EVENT FLAG DEFINITIONS
1011      : EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
1012      :
1012      000040      EF.START==      32.      ; START COMMAND WAS ISSUED
1013      000037      EF.RESTART==     31.      ; RESTART COMMAND WAS ISSUED
1014      000035      EF.CONTINUE==    30.      ; CONTINUE COMMAND WAS ISSUED
1015      000035      EF.NEW==        29.      ; A NEW PASS HAS BEEN STARTED
1016      000034      EF.PWR==        28.      ; A POWER-FAIL/POWER-UP OCCURRED
1017
1018      :
1019      : PRIORITY LEVEL DEFINITIONS
1020      :
1021      000340      PRI07== 340
1022      000300      PRI06== 300
1023      000240      PRI05== 240
1024      000200      PRI04== 200
1025      000140      PRI03== 140
1026      000100      PRI02== 100
1027      000040      PRI01== 40
1028      000000      PRI00== 0
1029
1030      :
1031      : OPERATOR FLAG BITS
1032      :
1032      000004      EVL==          4
1033      000010      LOT==         10
1034      000020      ADR==         20
1035      000040      IDU==         40
1036      000100      ISR==        100
1037      000200      UAM==        200
1038      000400      BOE==        400
1039      001000      PNT==       1000
1040      002000      PRI==       2000
1041      004000      IXE==       4000
1042      010000      IBE==      10000
1043      020000      IER==      20000
1044      040000      LOE==      40000
1045      100000      HOE==     100000
1046      000001      DRDY=BIT0
1047      000100      INTEN=BIT6
1048      100000      ERR=BIT15
1049      040000      DERR=BIT14
1050      002000      OPI=BIT10
1051      000200      CRDY=BIT7
1052      000040      BA17=BIT5
1053      000020      BA16=BIT4
1054      020000      NXM=BIT13
1055      000000      DSO=0
:DRIVE READY (RLCS)
:INTERRUPT ENABLE (RLCS)
:RL11 ERROR (RLCS)
:RLO1 DRIVE ERROR (RLCS)
:OPERATION INCOMPLETE (RLCS)
:CONTROLLER READY (RLCS)
:EXTENDED ADDRESS BIT 17 (RLCS)
:EXTENDED ADDRESS BIT 16 (RLCS)
:NON-EXISTANT MEMORY (RLCS)
:DRIVE SELECT 0 (RLCS)

```

```
1056      000400      DS1=BIT8      ;DRIVE SELECT 1 (RLCS)
1057      001000      DS2=BIT9      ;DRIVE SELECT 2 (RLCS)
1058      001400      DS3=BIT8!BIT9 ;DRIVE SELECT 3 (RLCS)
1059      000000      MAINT=0      ;MAINTENANCE FUNCTION-RLV11
1060      000002      WRCHK=BIT1   ;WRITE CHECK FUNCTION
1061      000004      GSTAT=BIT2   ;GET STATUS FUNCTION
1062      000006      SEEK=BIT2!BIT1 ;SEEK FUNCTION
1063      000010      RDHDR=BIT3   ;READ HEADER FUNCTION
1064      000012      WRITE=BIT3!BIT1 ;WRITE DATA FUNCTION
1065      000014      READ=BIT3!BIT2 ;READ DATA FUNCTION
1066      000202      GODRVR=BIT1!BIT7 ;CRDY AND DRDY
1067      000010      DRST=BIT3   ;DRIVE RESET (RLDA)
1068      000002      GSBIT=BIT1  ;GET STATUS BIT (RLDA)
1069      000001      MK=BIT0    ;MARKER BIT (RLDA)
1070      000004      SIGN=BIT2   ;SIGN BIT (RLDA)
1071      000100      RHHS=BIT6   ;HEAD SELECT IN READ HEADER
1072      000100      STHS=BIT6   ;HEAD SELECT IN STATUS BACK
1073      000020      DAHS=BIT4   ;HEAD SELECT IN SEEK
1074
1075      ;OFFSET FOR HARDWARE P-TABLE
1076
1077      000000      CSR=0
1078      000002      VECT=2
1079      000004      PRIOR=4
1080      000006      DRBT=6
1081      000010      CNT=10
1082      000012      LTYPE=12
1083
1084      ;OFFSET FOR SOFTWARE P-TABLE
1085
1086      000000      DLT=0
1087      000002      ELT=2
1088      000004      SIZE=4
1089
1090      002174      ENDMOD
1091
1092      .SBTTL GLOBAL DATA
1093
1094      002174      BGNMOD GLBDAT
1095
1096      .SBTTL GLOBAL DATA
1097
1098      002174      000000      UUT:      .WORD      0
1099      002176      000000      UNITST: .WORD      0
1100      002200      000000      RLCS:   .WORD      0
1101      002202      000000      RLBA:   .WORD      0
1102      002204      000000      RLDA:   .WORD      0
1103      002206      000100      RLMP:   .WORD      0
1104      002210      000000      BCSR:   .WORD      0
1105      002212      000000      BPRIOR: .WORD      0
1106      002214      000000      BVEC:   .WORD      0
1107      002216      000000      DRIVE:  .WORD      0      ;DRIVE UNDER TEST
1108      002220      000000      B.CS:   .WORD      0
1109      002222      000000      B.BA:   .WORD      0
1110      002224      000000      B.DA:   .WORD      0
1111      002226      000000      B.MP:   .WORD      0
```

1112	002230	000000	DERFLG: .WORD		
1113	002232	000000	E.CS: .WORD	0	
1114	002234	000000	E.BA: .WORD	0	
1115	002236	000000	E.DA: .WORD	0	
1116	002240	000000	E.MP: .WORD	0	
1117	002242	000000	E.MP1: .WORD	0	
1118	002244	000000	PFLG: .WORD	0	:PROCESSOR TYPE 0=UNIBUS 1=Q-BUS
1119	002246	000000	TRPFLG: .WORD	0	
1120	002250	000000	INTFLG: .WORD	0	: INTERRUPT OCCURANCE FLAG
1121	002252	000000	LDCSR: .WORD	0	: LOCATION TO FORM RLCS
1122	002254	120001	XPOLY: .WORD	120001	
1123	002256	000004	ERRVEC: .WORD	4	
1124	002260	000000	BCCFBK: .WORD	0	: LOCATION USED BY "SIMBCC"
1125	002262	000000	CALBCC: .WORD	0	: LOCATION USED BY "SIMBCC"
1126	002264	000000	TEMP2: .WORD	0	: LOCATION USED BY "SIMBCC"
1127	002266	000000	TEMP3: .WORD	0	: LOCATION USED BY "SIMBCC"
1128	002270	000000	TEMP4: .WORD	0	: LOCATION USED BY "SIMBCC"
1129	002272	000000	TEMP5: .WORD	0	
1130	002274	000000	TEMP1: .WORD	0	
1131	002276	000000	TMP0: .WORD	0	
1132	002300	000000	TMP1: .WORD	0	
1133	002302	000000	TMP2: .WORD	0	
1134	002304	000000	CHECK: .WORD	0	
1135	002306	000000	GDDAT: .WORD	0	
1136	002310	000000	BDDAT: .WORD	0	
1137	002312	000000	GCRCP: .WORD	0	
1138	002314	000000	GDCRCA: .WORD	0	
1139	002316	000000	GDCRCB: .WORD	0	
1140	002320	000000	GDDATP: .WORD	0	
1141	002322	000000	GDATMP: .WORD	0	
1142	002324	000000	MATFLG: .WORD	0	
1143	002326	000000	ERRLMT: .WORD	0	
1144	002330	000000	WHY: .WORD	0	: REASON FOR DROP IN AUTOSIZE
1145	002332	000000	T.CNTRLR: .WORD	0	
1146	002334	000000	TMPFNC: .WORD	0	
1147	002336	000233	OPIMN: .WORD	155.	
1148	002340	001212	OPIMX: .WORD	650.	
1149	002342	176543	HINUM: .WORD	176543	
1150	002344	123456	LONUM: .WORD	123456	
1151	002346	000000	TEMLO: .WORD	0	
1152	002350	000000	TEMHI: .WORD	0	
1153	002352	000000	PATSAV: .WORD	0	
1154	002354	000000	DELCNT: .WORD	0	
1155	002356	000000	LFLG: .WORD	0	
1156	002360	000000	SAVCNT: .WORD	0	
1157	002362	000000	ERPOINT: .WORD	0	
1158	002364	000100	ERCOUNT: .BLKW	64.	: ERROR COUNTER FOR ALL UNITS
1159					
1160			.SBTTL PATTERNS FOR REGISTER R/W		
1161			:		
1162			: PATTERNS USED FOR LOADING/READING REGISTERS		
1163					
1164	002564	000000	BEGPAT: 0		: GROWING 1
1165	002566	000001	1		
1166	002570	000003	3		
1167	002572	000007	7		

1168	002574	000017	17
1169	002576	000037	37
1170	002600	000077	77
1171	002602	000177	177
1172	002604	000377	377
1173	002606	000777	777
1174	002610	001777	1777
1175	002612	003777	3777
1176	002614	007777	7777
1177	002616	017777	17777
1178	002620	037777	37777
1179	002622	077777	77777
1180	002624	177777	177777
1181	002626	177776	177776
1182	002630	177774	177774
1183	002632	177770	177770
1184	002634	177760	177760
1185	002636	177740	177740
1186	002640	177700	177700
1187	002642	177600	177600
1188	002644	177400	177400
1189	002646	177000	177000
1190	002650	176000	176000
1191	002652	174000	174000
1192	002654	170000	170000
1193	002656	160000	160000
1194	002660	140000	140000
1195	002662	100000	100000
1196			
1197	002664	000000	000000
1198	002666	000001	1
1199	002670	000002	2
1200	002672	000004	4
1201	002674	000010	10
1202	002676	000020	20
1203	002700	000040	40
1204	002702	000100	100
1205	002704	000200	200
1206	002706	000400	400
1207	002710	001000	1000
1208	002712	002000	2000
1209	002714	004000	4000
1210	002716	010000	10000
1211	002720	020000	20000
1212	002722	040000	40000
1213	002724	100000	100000
1214	002726	177777	177777
1215	002730	177776	177776
1216	002732	177775	177775
1217	002734	177773	177773
1218	002736	177767	177767
1219	002740	177757	177757
1220	002742	177737	177737
1221	002744	177677	177677
1222	002746	177577	177577
1223	002750	177377	177377

:GROWING 0

:WALKING 1

:WALKING 0

1224	002752	176777	176777
1225	002754	175777	175777
1226	002756	173777	173777
1227	002760	167777	167777
1228	002762	157777	157777
1229	002764	137777	137777
1230	002766	077777	077777
1231	002770	177777	177777
1232	002772	000000	ENDPAT: 000000

1233			
1234			
1235			
1236	002774	155552	.SBTTL PATTERNS FOR MAINT. CRC TEST OF SERIAL DATA PATH
1237	002776	133330	PATCRC: 155552
1238	003000	066663	133330
1239	003002	125247	066663
1240	003004	052522	125247
1241	003006	177774	052522
1242	003010	000374	177774
1243	003012	022217	000374
1244	003014	044441	022217
1245	003016	166663	044441
1246	003020	144441	166663
1247	003022	033330	144441
1248	003024	011106	033330
1249	003026	070704	011106
1250	003030	107065	070704
1251	003032	111106	107065
1252	003034	167353	111106
1253	003036	156732	167353
1254	003040	146311	156732
1255	003042	135670	146311
1256	003044	114626	135670
1257	003046	104205	114626
1258	003050	073564	104205
1259	003052	063143	073564
1260	003054	042101	063143
1261	003056	031460	042101
1262	003060	021037	031460
1263	003062	010416	021037
1264	003064	000000	010416
1265			CRCEND: 000000

1266			:DATA PATTERNS FOR MAINTENANCE TEST
1267	003066	155555	PATDAT: 155555
1268	003070	133333	133333
1269	003072	066666	066666
1270	003074	125252	125252
1271	003076	052525	052525
1272	003100	177777	177777
1273	003102	000000	000000
1274	003104	107070	107070
1275	003106	070707	070707
1276	003110	144444	144444
1277	003112	033333	033333
1278	003114	011111	011111
1279	003116	022222	022222

1280 003120 044444
 1281 003122 111111
 1282 003124 166666
 1283 003126 010421
 1284 003130 021042
 1285 003132 031463
 1286 003134 042104
 1287 003136 063146
 1288 003140 073567
 1289 003142 104210
 1290 003144 114631
 1291 003146 135673
 1292 003150 146314
 1293 003152 156735
 1294 003154 167356
 1295 003156 000000

044444
 111111
 166666
 010421
 021042
 031463
 042104
 063146
 073567
 104210
 114631
 135673
 146314
 156735
 167356
 ENDDAT: 000000

:PATTERNS FOR TEST OF RLCS

1296
 1297
 1298
 1299
 1300 003160 000000
 1301 003162 000002
 1302 003164 000004
 1303 003166 000010
 1304 003170 000020
 1305 003172 000040
 1306 003174 000100
 1307 003176 000400
 1308 003200 001000
 1309 003202 001576
 1310 003204 001574
 1311 003206 001570
 1312 003210 001560
 1313 003212 001540
 1314 003214 001500
 1315 003216 001400
 1316 003220 001576
 1317 003222 001574
 1318 003224 001566
 1319 003226 001556
 1320 003230 001536
 1321 003232 001436
 1322 003234 001136
 1323 003236 000076
 1324 003240 000006
 1325 003242 000016
 1326 003244 000036
 1327 003246 000076
 1328 003250 000176
 1329 003252 000576
 1330 003254 001576
 1331 003256 000000
 1332 003260 000240
 1333
 1334
 1335 003760 000400

CSPAT: .WORD 0 ;SHIFTING 1
 .WORD BIT1
 .WORD BIT2
 .WORD BIT3
 .WORD BIT4
 .WORD BIT5
 .WORD BIT6
 .WORD BIT8
 .WORD BIT9
 .WORD 1576 ;GROWING 0
 .WORD 1574
 .WORD 1570
 .WORD 1560
 .WORD 1540
 .WORD 1500
 .WORD 1400
 .WORD 1576 ;SHIFT 0
 .WORD 1574
 .WORD 1566
 .WORD 1556
 .WORD 1536
 .WORD 1436
 .WORD 1136
 .WORD 76
 .WORD 6 ;GROWING 1
 .WORD 16
 .WORD 36
 .WORD 76
 .WORD 176
 .WORD 576
 .WORD 1576
 CSEND: .WORD 0
 HDRBUF: .BLKW 160.
 .SBTTL BUFFERS FOR RLV11 MAINTENANCE FUNCTION
 BUF1: .BLKW 256.

1336	004760	000400			BUF2:	.BLKW	256.
1337	005760				ENDMOD		
1338							
1339	005760				BGNMOD	GLBTXT	
1340					.SBTTL	GLOBAL	TEXT
1341							
1342	005760	047516	041440	047117	NORES:	.ASCIZ	/NO CONTROLLER/
	005776	047516	042040	044522	NODRY:	.ASCIZ	/NO DRIVE CONNECTED/
	006021	040	051104	000126	DEMES:	.ASCIZ	/ DRV/
	006026	047040	046530	000	NXMMES:	.ASCIZ	/ NXM/
	006033	040	050117	000111	OPIMES:	.ASCIZ	/ OPI/
	006040	044040	051103	000103	HCRCMES:	.ASCIZ	/ HCRC/
	006046	044040	043116	000	HNFMES:	.ASCIZ	/ HNF/
	006053	040	041504	000113	DCKMES:	.ASCIZ	/ DCK/
	006060	042040	052114	000	DLTMES:	.ASCIZ	/ DLT/
	006065	105	050130	042047	EXPMES:	.ASCIZ	/EXP'D: COMP HNF OPI REC'D: /
	006122	047516	042440	050130	NONMES:	.ASCIZ	/NO EXPECTED ERRORS FOUND/
	006153	015	000012		MSCRLF:	.ASCIZ	<15><12>
	006156	000015			LF:	.ASCIZ	<15>
	006160	041440	046517	000120	COMP:	.ASCIZ	/ COMP/
	006166	047506	041522	042105	OPIERR:	.ASCIZ	/FORCED OPI(GET STATUS) CAUSED OTHER ERRORS/
	006241	116	047517	020120	NOPMES:	.ASCIZ	/NOOP OPERATION-FLAG MODE/
	006272	047516	050117	047440	NOPINT:	.ASCIZ	/NOOP OPERATION-INTR. MODE/
	006324	040515	047111	042524	MATMES:	.ASCIZ	/MAINTENANCE OPERATION-FLAG MODE/
	006364	040515	047111	042524	MATINT:	.ASCIZ	/MAINTENANCE OPERATION-INTERRUPT MODE/
	006431	103	035123	000040	ARLCS:	.ASCIZ	/CS: /
	006436	041040	035101	000040	ARLBA:	.ASCIZ	/ BA: /
	006444	042040	035101	000040	ARLDA:	.ASCIZ	/ DA: /
	006452	046440	035120	000040	ARLMP:	.ASCIZ	/ MP: /
	006460	042502	047506	042522	BEREG:	.ASCIZ	/BEFORE COMMAND: /
	006501	124	046511	020105	AFREG:	.ASCIZ	/TIME OF ERROR: /
	006522	047503	052116	047522	CRTIM:	.ASCIZ	/CONTROLLER TIMED OUT/
	006547	104	044522	042526	DRTIM:	.ASCIZ	/DRIVE READY TIMED OUT/
	006575	103	047101	047040	EM1:	.ASCIZ	/CAN NOT ADDRESS RLCS/
	006622	040503	020116	047516	EM2:	.ASCIZ	/CAN NOT ADDRESS RLBA/
	006647	103	047101	047040	EM3:	.ASCIZ	/CAN NOT ADDRESS RLDA/
	006674	040503	020116	047516	EM4:	.ASCIZ	/CAN NOT ADDRESS RLMP/
	006721	122	041514	020123	EM5:	.ASCIZ	%RLCS READ/WRITE ERROR (BIT 0 DON'T CARE)%
	006772	046122	040502	051040	EM6:	.ASCIZ	%RLBA READ/WRITE ERROR%
	007020	046122	040504	051040	EM7:	.ASCIZ	%RLDA READ/WRITE ERROR%
	007046	046122	040502	042440	EM10:	.ASCIZ	/RLBA ERROR AFTER MAINT. FUNCTION/
	007107	117	044520	053440	EM11:	.ASCIZ	/OPI WOULD NOT GENERATE INTERRUPT/
	007150	046122	040504	042440	EM12:	.ASCIZ	/RLDA ERROR AFTER MAINT. FUNCTION/
	007211	116	020117	047111	EM13:	.ASCIZ	/NO INTERRUPT FROM NOOP(0)/
	007243	116	047517	024120	EM14:	.ASCIZ	/NOOP(0) MODIFIED RLMP/
	007271	116	047517	024120	EM15:	.ASCIZ	/NOOP(0) MODIFIED RLBA/
	007317	116	047517	024120	EM16:	.ASCIZ	/NOOP(0) MODIFIED RLDA/
	007345	111	052116	051105	EM17:	.ASCIZ	/INTERRUPT PRIORITY FAILURE/
	007400	046122	050115	020072	EM20:	.ASCIZ	/RLMP: CRC OF DA+3 ERROR (SERIAL DATA PATH)/
	007453	122	046514	035120	EM21:	.ASCIZ	/RLMP: CRC OF CRC OF DA+4 ERROR (SERIAL DATA PATH)/
	007535	115	044501	052116	EM22:	.ASCIZ	%MAINT. FILL/EMPTY FIFO DMA DATA TRANSFER COMPARE ERROR%
	007624	040515	047111	042524	EM23:	.ASCIZ	/MAINTENANCE LAST WORD+1 FAILURE/
	007664	047516	044440	052116	EM24:	.ASCIZ	/NO INTERRUPT FROM MAINT. FUNCTION/
	007726	040515	047111	042524	EM25:	.ASCIZ	/MAINTENANCE FIFO ADDRESS ERROR/
	007765	115	044501	052116	EM26:	.ASCIZ	/MAINTENANCE FIFO ADDRESS COMPLEMENT ERROR/
	010037	115	044501	052116	EM27:	.ASCIZ	/MAINT. FORCED OPI ERROR, LESS THAN 510 WORDS/

010113	115	044501	052116	EM30:	.ASCIZ	/MAINT. FORCED OPI ERROR,MORE THAN 511 WORDS/
010167	117	044520	052040	EM31:	.ASCIZ	/OPI TIMING ERROR/
010210	051127	052111	047111	EM44:	.ASCIZ	/WRITING RLMP MODIFIED RLCS/
010243	127	044522	044524	EM45:	.ASCIZ	/WRITING RLMP MODIFIED RLBA/
010276	051127	052111	047111	EM46:	.ASCIZ	/WRITING RLMP MODIFIED RLDA/
010331	102	052111	051440	EM61:	.ASCIZ	/BIT SET INSTRUCTION ON RLCS YIELDED WRONG RESULT/
010412	044502	020124	046103	EM62:	.ASCIZ	/BIT CLEAR INSTRUCTION ON RLCS YIELDED WRONG RESULT/
010475	102	052111	051440	EM63:	.ASCIZ	/BIT SET INSTRUCTION ON RLBA YIELDED WRONG RESULT/
010556	044502	020124	046103	EM64:	.ASCIZ	/BIT CLEAR INSTRUCTION ON RLBA YIELDED WRONG RESULT/
010641	102	052111	051440	EM65:	.ASCIZ	/BIT SET INSTRUCTION ON RLDA YIELDED WRONG RESULT/
010722	044502	020124	046103	EM66:	.ASCIZ	/BIT CLEAR INSTRUCTION ON RLDA YIELDED WRONG RESULT/
011005	102	051525	051040	EM67:	.ASCIZ	/BUS RESET DID NOT CLEAR RLCS/
011042	052502	020123	042522	EM70:	.ASCIZ	/BUS RESET DID NOT CLEAR RLBA/
011077	102	051525	051040	EM71:	.ASCIZ	/BUS RESET DID NOT CLEAR RLDA/
011134	051127	052111	047111	EM72:	.ASCIZ	/WRITING RLCS MODIFIED RLBA/
011167	127	044522	044524	EM73:	.ASCIZ	/WRITING RLCS MODIFIED RLDA/
011222	051127	052111	047111	EM74:	.ASCIZ	/WRITING RLBA MODIFIED RLCS/
011254	051127	052111	047111	EM75:	.ASCIZ	/WRITING RLBA MODIFIED RLDA/
011306	051127	052111	047111	EM76:	.ASCIZ	/WRITING RLDA MODIFIED RLCS/
011341	127	044522	044524	EM77:	.ASCIZ	/WRITING RLDA MODIFIED RLBA/
011374	046122	051503	041440	EM101:	.ASCIZ	/RLCS CONTAINED FOLLOWING ERROR(S): /
011441	000170			EM102:	.BLKB	120.

011632 .EVEN

(0) 011632
1343
1344
1345
1346 011632
1347
1348 011632
1349
1350 011632 004737 012322
1351 011636 004737 012356
1352
1353 011642 004537 014514
1354 011646
1355 011646
1356 011646 104423
1357
1358 011650
1359
1360 011650 004737 012322
1361
1362 011654 004537 014514
1363 011660
1364 011660
1365 011660 104423
1366 011662
1367
1368 011662 004737 012322
1369 011666
1370 011666 013746 002310
1371 011672 013746 002306
1372 011676 012746 013014

ENDMOD
.SBTTL GLOBAL ERRORS
BGNMOD GLBERR
BGNMSG ERRO
JSR PC,LINE1
JSR PC,LINE2
JSR R5,CKERLT ;CHECK ERROR LIMIT
ENDMSG
L10000: TRAP C\$MSG
BGNMSG ERR1
JSR PC,LINE1
JSR R5,CKERLT ;CHECK ERROR LIMIT
ENDMSG
L10001: TRAP C\$MSG
BGNMSG ERR2
JSR PC,LINE1
PRINTB #FRMT4,GDDAT,BDDAT
MOV BDDAT,-(SP)
MOV GDDAT,-(SP)
MOV #FRMT4,-(SP)

1373	011702	012746	000003	MOV	#3,-(SP)	
1374	011706	010600		MOV	SP,R0	
1375	011710	104414		TRAP	C\$PNTB	
1376	011712	062706	000010	ADC	#10,SP	
1377	011716	004537	014514	JSR	R5,CKERLT	
1378	011722			ENDMSG		
1379	011722					
1380	011722	104423		L10002: TRAP	C\$MSG	
1381						
1382						
1383	011724			BGNMSG ERR3		
1384	011724	004737	012322	JSR	PC,LINE1	
1385	011730	004737	012356	JSR	PC,LINE2	
1386	011734			PRINTB	#FRMT99	
1387	011734	012746	013135	MOV	#FRMT99,-(SP)	
1388	011740	012746	000001	MOV	#1,-(SP)	
1389	011744	010600		MOV	SP,R0	
1390	011746	104414		TRAP	C\$PNTB	
1391	011750	062706	000004	ADD	#4,SP	
1392	011754			PRINTB	#FRMT14,E.BA,E.DA,TMPO,GDDAT,BDDAT	
1393	011754	013746	002310	MOV	BDDAT,-(SP)	
1394	011760	013746	002306	MOV	GDDAT,-(SP)	
1395	011764	013746	002276	MOV	TMPO,-(SP)	
1396	011770	013746	002236	MOV	E.DA,-(SP)	
1397	011774	013746	002234	MOV	E.BA,-(SP)	
1398	012000	012746	013477	MOV	#FRMT14,-(SP)	
1399	012004	012746	000006	MOV	#6,-(SP)	
1400	012010	010600		MOV	SP,R0	
1401	012012	104414		TRAP	C\$PNTB	
1402	012014	062706	000016	ADD	#16,SP	
1403	012020	004537	014514	JSR	R5,CKERLT	
1404	012024			ENDMSG		
1405	012024					
1406	012024	104423		L10003: TRAP	C\$MSG	
1407						
1408						
1409						
1410	012026			BGNMSG ERR4		
1411						
1412	012026	004737	012322	JSR	PC,LINE1	
1413	012032	004737	012356	JSR	PC,LINE2	
1414	012036			PRINTB	#FRMT4,GDDAT,BDDAT	
1415	012036	013746	002310	MOV	BDDAT,-(SP)	
1416	012042	013746	002306	MOV	GDDAT,-(SP)	
1417	012046	012746	013014	MOV	#FRMT4,-(SP)	
1418	012052	012746	000003	MOV	#3,-(SP)	
1419	012056	010600		MOV	SP,R0	
1420	012060	104414		TRAP	C\$PNTB	
1421	012062	062706	000010	ADD	#10,SP	
1422						
1423	012066	004537	014514	JSR	R5,CKERLT	;CHECK ERROR LIMIT
1424	012072			ENDMSG		
1425	012072					
1426	012072	104423		L10004: TRAP	C\$MSG	
1427						
1428	012074			BGNMSG ERR5		

1429					
1430	012074	004737	012322	JSR	PC,LINE1
1431					
1432	012100	004537	014514	JSR	R5,CKERLT ;CHECK ERROR LIMIT
1433	012104			ENDMSG	
1434	012104			L10005:	
1435	012104	104423		TRAP	C\$MSG
1436					
1437	012106			BGNMSG	ERR6
1438					
1439	012106	004737	012322	JSR	PC,LINE1
1440	012112	004737	012574	JSR	PC,LINE3
1441	012116	004737	012356	JSR	PC,LINE2
1442					
1443					
1444	012122			1\$:	PRINTB #FRMT99
1445	012122	012746	013135	MOV	#FRMT99,-(SP)
1446	012126	012746	000001	MOV	#1,-(SP)
1447	012132	010600		MOV	SP,RO
1448	012134	104414		TRAP	C\$PNTB
1449	012136	062706	000004	ADD	#4,SP
1450	012142	004537	014514	JSR	R5,CKERLT ;CHECK ERROR LIMIT
1451	012146			ENDMSG	
1452	012146			L10006:	
1453	012146	104423		TRAP	C\$MSG
1454					
1455	012150			BGNMSG	ERR7
1456					
1457	012150	004737	012322	JSR	PC,LINE1
1458	012154			PRINTB	#FRMT6,BDDAT
1459	012154	013746	002310	MOV	BDDAT,-(SP)
1460	012160	012746	013211	MOV	#FRMT6,-(SP)
1461	012164	012746	000002	MOV	#2,-(SP)
1462	012170	010600		MOV	SP,RO
1463	012172	104414		TRAP	C\$PNTB
1464	012174	062706	000006	ADD	#6,SP
1465					
1466	012200	004537	014514	JSR	R5,CKERLT
1467					
1468	012204			ENDMSG	
1469	012204			L10007:	
1470	012204	104423		TRAP	C\$MSG
1471					
1472	012206			BGNMSG	ERR10
1473	012206	004737	012322	JSR	PC,LINE1
1474	012212	004737	012356	JSR	PC,LINE2
1475	012216	004737	012646	JSR	PC,LINE4
1476	012222			PRINTB	#FRMT99
1477	012222	012746	013135	MOV	#FRMT99,-(SP)
1478	012226	012746	000001	MOV	#1,-(SP)
1479	012232	010600		MOV	SP,RO
1480	012234	104414		TRAP	C\$PNTB
1481	012236	062706	000004	ADD	#4,SP
1482	012242	004537	014514	JSR	R5,CKERLT
1483	012246			ENDMSG	
1484	012246			L10010:	

Line	Address	Code	Label	Instruction	Comments
1485	012246	104423		TRAP	C\$MSG
1486					
1487	012250		BGNMSG	ERR11	
1488	012250	004737		JSR	PC,LINE1
1489	012254	004737		JSR	PC,LINE2
1490	012260			PRINTB	#FRMT10,OPIMN,OPIMX,BDDAT
1491	012260	013746	002310	MOV	BDDAT,-(SP)
1492	012264	013746	002340	MOV	OPIMX,-(SP)
1493	012270	013746	002336	MOV	OPIMN,-(SP)
1494	012274	012746	013246	MOV	#FRMT10,-(SP)
1495	012300	012746	000004	MOV	#4,-(SP)
1496	012304	010600		MOV	SP,R0
1497	012306	104414		TRAP	C\$PNTB
1498	012310	062706	000012	ADD	#12,SP
1499	012314	004537	014514	JSR	R5,CKERLT
1500	012320			ENDMSG	
1501	012320		L10011:		
1502	012320	104423		TRAP	C\$MSG
1503					
1504					
1505	012322		LINE1:	PRINTB	#FRMT1,RLCS,<B,DRIVE+1>
1506	012322	005046		CLR	-(SP)
1507	012324	153716	002217	BISB	DRIVE+1,(SP)
1508	012330	013746	002200	MOV	RLCS,-(SP)
1509	012334	012746	012674	MOV	#FRMT1,-(SP)
1510	012340	012746	000003	MOV	#3,-(SP)
1511	012344	010600		MOV	SP,R0
1512	012346	104414		TRAP	C\$PNTB
1513	012350	062706	000010	ADD	#10,SP
1514	012354	000207		RTS	PC
1515					
1516	012356		LINE2:	PRINTB	#FRMT2,#BEREG,#ARLCS,B.CS,#ARLBA,B.BA
1517	012356	013746	002222	MOV	B.BA,-(SP)
1518	012362	012746	006436	MOV	#ARLBA,-(SP)
1519	012366	013746	002220	MOV	B.CS,-(SP)
1520	012372	012746	006431	MOV	#ARLCS,-(SP)
1521	012376	012746	006460	MOV	#BEREG,-(SP)
1522	012402	012746	012734	MOV	#FRMT2,-(SP)
1523	012406	012746	000006	MOV	#6,-(SP)
1524	012412	010600		MOV	SP,R0
1525	012414	104414		TRAP	C\$PNTB
1526	012416	062706	000016	ADD	#16,SP
1527	012422			PRINTB	#FRMT2A,#ARLDA,B.DA,#ARLMP,B.MP
1528	012422	013746	002226	MOV	B.MP,-(SP)
1529	012426	012746	006452	MOV	#ARLMP,-(SP)
1530	012432	013746	002224	MOV	B.DA,-(SP)
1531	012436	012746	006444	MOV	#ARLDA,-(SP)
1532	012442	012746	012753	MOV	#FRMT2A,-(SP)
1533	012446	012746	000005	MOV	#5,-(SP)
1534	012452	010600		MOV	SP,R0
1535	012454	104414		TRAP	C\$PNTB
1536	012456	062706	000014	ADD	#14,SP
1537	012462			PRINTB	#FRMT2,#AFREG,#ARLCS,E.CS,#ARLBA,E.BA
1538	012462	013746	002234	MOV	E.BA,-(SP)
1539	012466	012746	006436	MOV	#ARLBA,-(SP)
1540	012472	013746	002232	MOV	E.CS,-(SP)

```

1541 012476 012746 006431 MOV #ARLCS,-(SP)
1542 012502 012746 006501 MOV #AFREG,-(SP)
1543 012506 012746 012734 MOV #FRMT2,-(SP)
1544 012512 012746 000006 MOV #6,-(SP)
1545 012516 010600 MOV SP,R0
1546 012520 104414 TRAP C$PNTB
1547 012522 062706 000016 ADD #16,SP
1548 012526 PRINTB #FRMT2B,#ARLDA,E.DA,#ARLMP,E.MP,E.MP1
1549 012526 013746 002242 MOV E.MP1,-(SP)
1550 012532 013746 002240 MOV E.MP,-(SP)
1551 012536 012746 006452 MOV #ARLMP,-(SP)
1552 012542 013746 002236 MOV E.DA,-(SP)
1553 012546 012746 006444 MOV #ARLDA,-(SP)
1554 012552 012746 012766 MOV #FRMT2B,-(SP)
1555 012556 012746 000006 MOV #6,-(SP)
1556 012562 010600 MOV SP,R0
1557 012564 104414 TRAP C$PNTB
1558 012566 062706 000016 ADD #16,SP
1559 012572 000207 RTS PC
    
```

```

LINE3: PRINTB #FRMT3,#EM101
MOV #EM101,-(SP)
MOV #FRMT3,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
PRINTB #FRMT3,#EM102
MOV #EM102,-(SP)
MOV #FRMT3,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
RTS PC
    
```

```

LINE4: PRINTB #FRMT3,#EM102
MOV #EM102,-(SP)
MOV #FRMT3,-(SP)
MOV #2,-(SP)
MOV SP,R0
TRAP C$PNTB
ADD #6,SP
RTS PC
    
```

```

1576 012646 LINE4: PRINTB #FRMT3,#EM102
1577 012646 MOV #EM102,-(SP)
1578 012646 012746 011441 MOV #FRMT3,-(SP)
1579 012652 012746 013007 MOV #2,-(SP)
1580 012656 012746 000002 MOV SP,R0
1581 012662 010600 TRAP C$PNTB
1582 012664 104414 ADD #6,SP
1583 012666 062706 000006 RTS PC
1584 012672 000207
1585
1586
012674 040445 047503 052116 FRMT1: .ASCIZ /%ACONTROLLER: %06% DRIVE: %01/
012734 047045 052045 052045 FRMT2: .ASCIZ /%N%T%T%06%T%06/
012753 045 022524 033117 FRMT2A: .ASCIZ /%T%06%T%06/
012766 052045 047445 022466 FRMT2B: .ASCIZ /%T%06%T%06% %06/
013007 045 022516 000124 FRMT3: .ASCIZ /%N%T/
013014 047045 040445 054105 FRMT4: .ASCIZ /%N%AE%P'D: %06% REC'D: %06%/
013052 047045 042045 022463 FRMT98: .ASCIZ /%N%D3% WORDS BAD OUT OF 255 WORDS TRANSFERRED%N%/
013135 045 000116 FRMT99: .ASCIZ /%N/
013140 047045 040445 040514 FRMT5: .ASCIZ /%N%ALAST: %06% PRES: %06% EXP'D: %06%/
013211 045 022516 040501 FRMT6: .ASCIZ /%N%AAT PROCESSOR LEVEL %06%/
    
```

```
013246 047045 040445 040522 FRMT10: .ASCIZ /%N%ARANGE %D3% - %D3% MILLISECONDS WAS %D6%/
013326 040445 051105 047522 FRMT11: .ASCIZ /%AERROR LIMIT EXCEEDED-DROPPED%/
013367 045 022516 042101 FRMT12: .ASCIZ /%N%ADRIE DID NOT RECOVER FROM POWER FAILURE%/
013446 047045 052045 040445 FRMT13: .ASCIZ /%N%T% - WILL NOT TEST%/
013477 045 041101 035101 FRMT14: .ASCIZ /%ABA: %06% DA: %06% ADDR: %06% EXP'D: %06% REC'D %06%/
```

.EVEN

```
1587
1588
1589 013572 ENDMOD
1590
1591 013572 BGNMOD HPTCODE
1592
1593 013572 BGNHW
1594 013572 000005 .WORD L10012-L$HW/2
1595 013574 174400 .WORD 174400 ;CSR
1596 013576 000160 .WORD 160 ;VECTOR
1597 013600 000240 .WORD 240 ;PRIORITY
1598 013602 000000 .WORD 0 ;DRIVE (BITS 8,9,10)
1599 013604 000001 .WORD 1 ;11/23 = 1, 1103L = 0
1600
1601 013606 ENDMOD
1602 013606 L10012:
1603
1604 013606 ENDMOD
1605
1606 013606 BGNMOD SPTCODE
1607
1608 013606 BGNHW
1609 013606 000003 .WORD L10013-L$SW/2
1610
1611 013610 000000 DROP: .WORD 0
1612 013612 000012 MERLMT: .WORD 10.
1613 013614 000000 T.SIZE: .WORD 0
1614
1615 013616 ENDSW
1616 013616 L10013:
1617
1618 013616 ENDMOD
1619
1620 013616 BGNMOD DSPCODE
1621
1622 013616 DISPATCH 37
1623 013616 000045 .WORD 37
1624 013620 017002 .WORD T1
1625 013622 017100 .WORD T2
1626 013624 017176 .WORD T3
1627 013626 017274 .WORD T4
1628 013630 017372 .WORD T5
1629 013632 017466 .WORD T6
1630 013634 017562 .WORD T7
1631 013636 017656 .WORD T8
1632 013640 017752 .WORD T9
```


1633	013642	020062		.WORD	T10	
1634	013644	020134		.WORD	T11	
1635	013646	020172		.WORD	T12	
1636	013650	020312		.WORD	T13	
1637	013652	020414		.WORD	T14	
1638	013654	020502		.WORD	T15	
1639	013656	020626		.WORD	T16	
1640	013660	020752		.WORD	T17	
1641	013662	021056		.WORD	T18	
1642	013664	021156		.WORD	T19	
1643	013666	021246		.WORD	T20	
1644	013670	021346		.WORD	T21	
1645	013672	021456		.WORD	T22	
1646	013674	021530		.WORD	T23	
1647	013676	021566		.WORD	T24	
1648	013700	021712		.WORD	T25	
1649	013702	022052		.WORD	T26	
1650	013704	022212		.WORD	T27	
1651	013706	022416		.WORD	T28	
1652	013710	022526		.WORD	T29	
1653	013712	022636		.WORD	T30	
1654	013714	022772		.WORD	T31	
1655	013716	023324		.WORD	T32	
1656	013720	024136		.WORD	T33	
1657	013722	025014		.WORD	T34	
1658	013724	025362		.WORD	T35	
1659	013726	025734		.WORD	T36	
1660	013730	026612		.WORD	T37	
1661						
1662	013732			ENDMOD		
1663						
1664				.SBTTL	INITIALIZATION CODE	
1665	013732			BGNMOD	INITCODE	
1666						
1667	013732			BGNINIT		
1668						
1669	013732			BRESET		
1670	013732	104433		TRAP	C\$RESET	
1671	013734			READEF	#EF.PWR	:POWER UP?????
1672	013734	012700	000034	MOV	#EF.PWR,RO	
1673	013740	104447		TRAP	C\$REFG	
1674	013742			BCOMPLETE	CONT	:BRANCH
1675	013742	103510		BCS	CONT	
1676	013744			READEF	#EF.RESTART	:RESTART?
1677	013744	012700	000037	MOV	#EF.RESTART,RO	
1678	013750	104447		TRAP	C\$REFG	
1679	013752			BCOMPLETE	START	
1680	013752	103411		BCS	START	
1681	013754			READEF	#EF.START	:START?
1682	013754	012700	000040	MOV	#EF.START,RO	
1683	013760	104447		TRAP	C\$REFG	
1684	013762			BCOMPLETE	START	
1685	013762	103405		BCS	START	
1686	013764			READEF	#EF.NEW	:NEW PASS????
1687	013764	012700	000035	MOV	#EF.NEW,RO	
1688	013770	104447		TRAP	C\$REFG	

```

1689 013772          BCOMPLETE START1          ;YES,THEN RE INIT
1690 013772 103416   BCS          START1
1691 013774 000424   BR          CONTINUE
1692 013776 012737 176543 002342 START: MOV #176543,HINUM ;RANDOM GEN. PRIME
1693 014004 012737 123456 002344 MOV #123456,LONUM ;RANDOM GEN. PRIME
1694 014012 012700 002364 MOV #ERCOUNT,RO ;SETUP TO CLEAR ERROR COUNTERS
1695 014016 012701 000100 MOV #64.,R1 ;GET A COUNT
1696 014022 005020 1$: CLR (RO)+ ;CLEAR A COUNTER
1697 014024 005301 DEC R1
1698 014026 001375 BNE 1$ ;LOOP TILL COUNTERS CLEARED
1699 014030 013737 002344 002346 START1: MOV LONUM,TEMLO
1700 014036 013737 002342 002350 MOV HINUM,TEMHI ;NEW PRIMES AT END OF PASS
1701 014044 000407 BR START2
1702
1703 014046          CONTINUE: REDEF #EF,CONTINUE ;CONTINUE????
1704 014046 012700 000036 MOV #EF,CONTINUE,RO
1705 014052 104447 TRAP C$REFG
1706 014054          BCOMPLETE CONT
1707 014054 103443 BCS CONT
1708
1709 014056 005737 002174 NXT: TST UUT ;DONE ALL UUT'S
1710 014062 001011 BNE START3 ;NO
1711 014064 012737 177777 002176 START2: MOV #-1,UNITST
1712 014072 013737 002012 002174 MOV L$UNIT,UUT
1713 014100 012737 002362 002362 MOV #ERCOUNT-2,ERPOINT ;INIT THE UNIT ERROR COUNTER
1714
1715 014106 005237 002176 002362 START3: INC UNITST
1716 014112 062737 000002 ADD #2,ERPOINT ;POINT TO PROPER ERROR COUNTER LOCATION
1717 014120 005337 002174 DEC UUT
1718 014124          REST: GPHARD UNITST,RO
1719 014124 013700 002176 MOV UNITST,RO
1720 014130 104442 TRAP C$GPHRD
1721 014132          BNCOMPLETE NXT
1722 014132 103351 BCC NXT
1723 014134 012037 002210 1$: MOV (RO)+,BCSR
1724 014140 012037 002214 MOV (RO)+,BVEC
1725 014144 012037 002212 MOV (RO)+,BPRIOR
1726 014150 012037 002216 MOV (RO)+,DRIVE
1727 014154 012037 002332 MOV (RO)+,T.CNTRL ;GET CONTROLLER TYPE
1728 014160 012037 002356 MOV (RO)+,L.FLG ;GET PROCESSOR
1729 ;LFLG=1,11/23
1730 ;LFLG=0,1103L ETC.
1731
1732 014164 013737 002346 002344 CONT: MOV TEMLO,LONUM ;RESTORE RANDOM FOR NEXT UUT
1733 014172 013737 002350 002342 MOV TEMHI,HINUM ;RESTORE PRIME FOR NEXT UUT
1734 014200 013700 002210 MOV BCSR,RO
1735 014204 010037 002200 MOV RO,RLCS
1736 014210 062700 000002 ADD #2,RO
1737 014214 010037 002202 MOV RO,RLBA
1738 014220 062700 000002 ADD #2,RO
1739 014224 010037 002204 MOV RO,RLDA
1740 014230 062700 000002 ADD #2,RO
1741 014234 010037 002206 MOV RO,RLMP
1742 014240 005737 013614 TST T.SIZE ;DO WE WANT TO CHECK UNITS??
1743 014244 001450 BEQ END ;NO
1744
    
```

```
1745 014246 005037 002246 CLR TRPFLG ;CLR OUT TRAP FLAG
1746 014252 SETVEC ERRVEC,#TRPHAN,#340 ;SETUP VECTOR TO CATCH NON-EXIST
1747 014252 012746 000340 MOV #340,-(SP)
1748 014256 012746 016636 MOV #TRPHAN,-(SP)
1749 014262 013746 002256 MOV ERRVEC,-(SP)
1750 014266 012746 000003 MOV #3,-(SP)
1751 014272 104437 TRAP C$SVEC
1752 014274 062706 000010 ADD #10,SP
1753 014300 005777 165674 TST @RLCS ;ACCESS CONTROLLER
1754 014304 CLRVEC ERRVEC ;RELEASE VECTOR
1755 014304 013700 002256 MOV ERRVEC,R0
1756 014310 104436 TRAP C$CVEC
1757 014312 005737 002246 TST TRPFLG ;DID IT TRAP
1758 014316 001423 BEQ END
1759 014320 012737 005760 002330 MOV #NORES,WHY ;SETUP ERR MESS
1760 014326 8$: PRINTB #FRMT13,WHY
1761 014326 013746 002330 MOV WHY,-(SP)
1762 014332 012746 013446 MOV #FRMT13,-(SP)
1763 014336 012746 000002 MOV #2,-(SP)
1764 014342 010600 MOV SP,R0
1765 014344 104414 TRAP C$PNTB
1766 014346 062706 000006 ADD #6,SP
1767 014352 004737 012322 6$: JSR PC,LINE1 ;GIVE DRIVE INFO
1768 014356 DODU UNITST ;TELL SUPERVISOR TO DROP IT
1769 014356 013700 002176 MOV UNITST,R0
1770 014362 104451 TRAP C$DODU
1771 014364 000634 BR NXT ;TRY NEXT
1772 014366 END: SETVEC BVEC,#INTSRV,#340
1773 014366 012746 000340 MOV #340,-(SP)
1774 014372 012746 016644 MOV #INTSRV,-(SP)
1775 014376 013746 002214 MOV BVEC,-(SP)
1776 014402 012746 000003 MOV #3,-(SP)
1777 014406 104437 TRAP C$SVEC
1778 014410 062706 000010 ADD #10,SP
1779 014414 005037 002244 CLR PFLG ;CLR PROCESSOR FLAG
1780 014420 READBUS ;Q-BUS
1781 014420 104407 TRAP C$RDBU
1782 014422 BNCOMPLETE 1$
1783 014422 103002 BCC 1$
1784 014424 005237 002244 1$: INC PFLG ;NO, Q-BUS THEN
1785 014430 ENDINIT
1786 014430 L10014:
1787 014430 TRAP C$...IT
1788 014430 104411
1789 014432 ENDMOD
1790 014432 BGNPROT
1791 014432 177777 .WORD -1 ;CSR OFFSET MAKE NOP
1792 014432 177777 .WORD -1 ;MASS BUS OFFSET MAKE NOP
1793 014434 177777 .WORD -1 ;DRIVE OFFSET MAKE NOP
1794 014436 177777 ENDPROT
1795 014440 BGNAUTO
1796 014440 ENDAUTO
1797 014440 L10016:
1798 014440 TRAP C$AUTO
1799 014440 104461
```

```

1801
1802
1803 014442          BGNMOD  CLNCODE
1804
1805 014442          BGNCLN
1806
1807 014442          SETPRI  #PRI00
1808 014442 012700 000000  MOV      #PRI00,RO
1809 014446 104441    TRAP     C$SPRI
1810
1811 014450 032777 000200 165522 1$:  BIT      #CRDY,@RLCS
1812 014456 001774    BEQ      1$
1813
1814 014460          SETPRI  #PRI07
1815 014460 012700 000340  MOV      #PRI07,RO
1816 014464 104441    TRAP     C$SPRI
1817 014466 042777 000100 165504  BIC      #INTEN,@RLCS
1818
1819 014474          CLRVEC  BVEC
1820 014474 013700 002214  MOV      BVEC,RO
1821 014500 104436    TRAP     C$VEC
1822 014502          2$:
1823 014502          ENDCLN
1824 014502          L10017:
1825 014502 104412    TRAP     C$CLEAN
1826
1827 014504          ENDMOD
1828
1829
1830
1831 014504          BGNMOD  DRPCODE
1832
1833 014504          BGNDU
1834
1835 014504 000240    NOP
1836
1837 014506          ENDDU
1838 014506          L10020:
1839 014506 104453    TRAP     C$DU
1840
1841 014510          ENDMOD
1842
1843 014510          BGNMOD  ADDCODE
1844
1845 014510          BGNAU
1846
1847 014510 000240    NOP
1848
1849 014512          ENDAU
1850 014512          L10021:
1851 014512 104452    TRAP     C$AU
1852
1853 014514          ENDMOD
1854
1855
1856          .SBTTL  GLOBAL SUBROUTINES
  
```

```

1857
1858 014514          BGNMOD  GLBSUB
1859
1860 014514          CKERLT: INLOOP
1861 014514 104420   TRAP      C$INLP
1862 014516          BCOMPLETE 99$
1863 014516 103427   BCS      99$
1864 014520 005737 013610 TST      DROP      ;DROP ON ERROR LIMIT?
1865 014524 001424          BEQ      99$      ;NO
1866 014526 005277 165630 INC      @ERPOINT  ;COUNT THE UNIT ERROR DETECTED
1867 014532 027737 165624 013612 CMP      @ERPOINT, MERLMT ;REACHED THE ERROR LIMIT?
1868 014540 002416          BLT      99$      ;NO
1869
1870 014542          PRINTF  #FRMT11
1871 014542 012746 013326 MOV      #FRMT11, -(SP)
1872 014546 012746 000001 MOV      #1, -(SP)
1873 014552 010600          MOV      SP, R0
1874 014554 104417          TRAP    C$PNTF
1875 014556 062706 000004 ADD      #4, SP
1876 014562 004737 012322 JSR      PC, LINE1
1877 014566          DODU    UNITST      ;DROP THE UNIT
1878 014566 013700 00217c MOV      UNITST, R0
1879 014572 104451          TRAP    C$DODU
1880 014574          DOCLN
1881 014574 104444          TRAP    C$DCLN
1882 014576          99$:
1883 014576 000205          RTS      R5
1884
1885
1886
1887          .SBTTL  ROUTINE TO CHECK FOR CONTROLLER ERRORS
1888
1889          ;*****
1890          ;THIS ROUTINE WILL CHECK RLCS FOR ERRORS AND PRINT THEM
1891          ;ACCORDINGLY. IT WILL MERGE THE ERROR PRINTOUT WITH THE TEST
1892          ;ERROR MESSAGE.
1893          ;
1894          ;EXAMPLE:  RLCS CONTAINED FOLLOWING ERROR(S):
1895          ;              DRV  OPI  HCRC  HNF
1896          ;              MAINTENANCE OPERATION-INTERRUPT MODE
1897          ;
1898          ;
1899          ;
1900          ;ROUTINE USES R0,R1 AND PICKS HEADER FROM R3
1901          ;
1902          ;      CALL  JSR      R5,CHERR
1903          ;
1904          ;
1905          ;
1906
1907 014600 005037 002230 CHERR: CLR      DERFLG      ;CLEAR OUT DRIVE ERROR FLAG
1908 014604 032737 176000 002232 BIT      #176000,E.CS  ;ANY ERRORS SET
1909 014612 001001          BNE      199$      ;IF YES, INVESTIGATE
1910 014614 000205          RTS      R5      ;NO, EXIT
1911 014616 023727 002334 000004 199$: CMP      TMPFNC, #GSTAT ;FUNCTION-NOP, RESET, GETSTATUS
1912 014624 002401          BLT      98$      ;YES, GO CHECK IF ONLY DRIVE ERROR
    
```


1969 015076 000205

RTS R5 ;EXIT ROUTINE

1970

1971

1972

1973

1974

1975

1976

1977

1978

1979

1980

1981

1982

1983

1984

1985

1986

1987

1988

1989

1990

1991

1992

1993

1994

1995

1996

1997

1998

1999

2000

2001

2002

2003

2004

2005

2006

2007

2008

2009

2010

2011

2012

2013

2014

2015

2016

2017

2018

2019

2020

2021

2022

2023

2024

```
*****
* ROUTINE TO LOAD RLCS WITH FUNCTION TO BE PERFORMED FOR RL11
* CALL: JSR R5,LDFUNC
* .WORD ;BITS TO BE LOADED, FUNCTION
* ;AND INTR ENABLE ONLY
*****
```

```
LDFUNC: MOV (R5)+,LDCSR ;GET BITS TO LOAD
TST DERFLG
BEQ 98$
MOV B.CS,-(SP)
MOV #13,@RLDA
MOV #GSTAT,B.CS
BIS DRIVE,B.CS
MOV B.CS,@RLCS
MOV (SP)+,B.CS
99$: BIT #200,@RLCS
BEQ 99$
98$: MOV R3,-(SP) ;SAVE R3
BIC #177661,LDCSR ;CLEAR ALL BUT FUNC & INTR EN
MOV LDCSR,FNDFNC ;SAVE FUNCTION
BIC #INTEN,FNDFNC ;ONLY FUNCTION
MOV FNDFNC,TMPFNC
MOV #HDRLST,R3 ;GET HEADER LIST
ASR FNDFNC ;ALIGN TO RIGHT
BEQ 2$
1$: CMP (R3)+,(R3)+ ;BUMP R3 BY 4
DEC FNDFNC ;FOUND IT
BNE 1$ ;NO,KEEP LOOKING
2$: BIT #INTEN,LDCSR ;YES,DO WE WANT FLAG OR INTR
BEQ 3$ ;FLAG BRANCH
TST (R3)+ ;INTR POINT TO THAT ONE
3$: MOV (R3),R3 ;SET HEADER
MOV R3,RESTMS ;SET UP HEADER
BIS DRIVE,LDCSR ;SELECT DRIVE
4$: BIS #200,LDCSR ;CONTROLLER READY
MOV LDCSR,@RLCS
JSR R5,BEFORE
5$: BIC #200,@RLCS
MOV (SP)+,R3 ;RESTORE R3
RTS R5 ;EXIT
```

FNDFNC: .WORD 0

HDRLST: NOPMES
NOPINT

```
*****
: THIS ROUTINE WILL CHECK RLV11 CSR FOR COMP,HNF AND OPI ERRORS
: IN THE MAINTENANCE FORCED OPI TESTS. IT WILL MERGE THE ERROR PRINTOUT
: WITH THE TEST ERROR MESSAGE. DRIVE ERRORS WILL BE IGNORED.
*****
```

```
2025      :      CALL      JSR      R5,CHKOPI
2026      :
2027      :      CHKOPI:  MOV      R1,-(SP)
2028      015324 010146      112000      MOV      #112000,R1      :EXPECTED RESULTS
2029      015332 005037      002324      CLR      MATFLG      :CLEAR ERROR FOUND FLAG
2030      015336 043701      002232      BIC      E.CS,R1      :CHECK COMP,HNF,OPI
2031      015342 005701
2032      015344 001001
2033      015346 000453
2034      015350 012701      011441      1$:      MOV      #EM102,R1      :EXPECTED ERRORS NOT SET
2035      015354 004537      015502      JSR      R5,FIX      :ALL EXPECTED ERRORS SET,EXIT
2036      015360 006065      EXPMES      :GET START OF TEXT STRING
2037      015362 032737      100000      002232      BIT      #BIT15,E.CS      :STORE MESSAGE
2038      015370 001405      BEQ      2$      :EXPECTED
2039      015372 005237      002324      INC      MATFLG      :IS COMP SET?
2040      015376 004537      015502      JSR      R5,FIX      :NO,CONTINUE ERROR SEARCH
2041      015402 006160      COMP      :YES,SET ERROR FOUND
2042      015404 032737      010000      002232      2$:      BIT      #BIT12,E.CS      :STORE COMP MESSAGE
2043      015412 001405      BEQ      3$      :IS HNF SET?
2044      015414 005237      002324      INC      MATFLG      :NO,CONTINUE ERROR SEARCH
2045      015420 004537      015502      JSR      R5,FIX      :YES,SET ERROR FOUND
2046      015424 006046      HNFMES      :STORE HNF MESSAGE
2047      015426 032737      002000      002232      3$:      BIT      #BIT10,E.CS      :IS OPI SET?
2048      015434 001405      BEQ      4$      :NO,COMPLETE MESSAGE
2049      015436 005237      002324      INC      MATFLG      :YES,SET ERROR FOUND
2050      015442 004537      015502      JSR      R5,FIX      :STORE OPI MESSAGE
2051      015446 006033      OPIMES
2052      015450 005737      002324      4$:      TST      MATFLG      :CHECK IF EXPECTED ERRORS FOUND
2053      015454 001003      BNE      5$
2054      015456 004537      015502      JSR      R5,FIX      :STORE MESSAGE
2055      015462 006122      NONMES      :NO EXPECTED ERRORS FOUND
2056      015464 004537      015502      5$:      JSR      R5,FIX
2057      015470 006153      MSCRLF
2058      015472 105011      CLRB      (R1)      :STORE MESSAGE TERMINATOR
2059      015474 005725      TST      (R5)+      :RETURN TO PRINT ERROR
2060      015476 012601      6$:      MOV      (SP)+,R1
2061      015500 000205      RTS      R5
2062      :*****
2063      :*ROUTINE TO MOVE ASCII STRINGS
2064      :*USES REGISTERS R1 - WHERE STRING IS BEING BUILT
2065      :*
2066      :*      CALL      JSR      R5,FIX
2067      :*      .WORD      :ADDRESS OF STRING TO MOVE
2068      :*
2069      015502 012500      FIX:      MOV      (R5)+,R0      :GET ADDRESS AND MOVE RETURN
2070      015504 112021      1$:      MOV      (R0)+,(R1)+      :GET BYTE AND UPDATE
2071      015506 001376      BNE      1$      :WATCH 0 BYTE TERMINATOR
2072      015510 105741      TST      -(R1)      :BACK UP OVER ZERO BYTE
2073      015512 000205      RTS      R5      :EXIT
2074
2075
2076      :*****
2077      :*RLV11 MAINTENANCE SUBROUTINE FOR CRC CALCULATIONS
2078      :*ROUTINE TO RETRIEVE PATTERN AND CALCULATE CRC OF PATTERN+3
2079      :*AND CRC OF CRC OF PATTERN+4.
2080      :*CRC OF PATTERN+3 WILL BE STORED IN 'GDCRCA'.
```



```

2081 ;CRC OF CRC OF PATTERN+4 WILL BE STORED IN "GDCRCB".
2082 ;PATTERN WILL BE STORED IN "GDDATA".
2083 :
2084 : CALL JSR R5,CALCRC
2085 : .WORD ;PATTERN IN DA
2086 :
2087 015514 012537 002312 CALCRC: MOV (R5)+,GCRCP ;STORE PATTERN
2088 015520 013737 002312 002274 MOV GCRCP,TEMP1
2089 015526 113737 002274 002272 MOV#B TEMP1,TEMP5
2090 015534 062737 000003 002272 ADD #3,TEMP5 ;ADD 3 TO PATTERN
2091 015542 113737 002272 002274 MOV#B TEMP5,TEMP1
2092 015550 013737 002274 015564 MOV TEMP1,1$
2093 015556 004537 016464 JSR R5,SIMBCC ;CALCULATE EXPECTED CRC
2094 015562 000020 16. ;DATA BITS
2095 015564 000000 1$: .WORD 0 ;INITIAL PATTERN+3
2096 015566 000000 .WORD 0
2097 015570 013737 002262 002314 MOV CALBCC,GDCRCA ;SAVE CRC OF PATTERN+3
2098 015576 005237 002272 INC TEMP5 ;VALUE=PATTERN+4
2099 015602 113737 002272 002274 MOV#B TEMP5,TEMP1
2100 015610 013737 002274 015624 MOV TEMP1,2$
2101 015616 004537 016464 JSR R5,SIMBCC ;CALCULATE EXPECTED CRC
2102 015622 000020 16. ;DATA BITS
2103 015624 000000 2$: .WORD 0 ;INITIAL PATTERN+4
2104 015626 000000 .WORD 0 ;STARTING CRC=0
2105 015630 013737 002262 015644 MOV CALBCC,3$ ;STORE CRC FOR NEXT CALL
2106 015636 004537 016464 JSR R5,SIMBCC ;CAL. CRC OF CRC OF DA+4
2107 015642 000020 16. ;DATA BITS
2108 015644 000000 3$: .WORD 0 ;CRC OF DA+4
2109 015646 000000 .WORD 0 ;STARTING CRC=0
2110 015650 013737 002262 002316 MOV CALBCC,GDCRCB ;SAVE CRC OF CRC OF DA+4
2111 015656 000205 RTS R5
2112 :
2113 ;LOAD REGISTERS BEFORE FUNCTION
2114 ;CALL: JSR R5,BEFORE
2115 :
2116 015660 017737 164314 002220 BEFORE: MOV @RLCS,B.CS ;READ CS
2117 015666 017737 164310 002222 MOV @RLBA,B.BA ;READ BA
2118 015674 017737 164304 002224 MOV @RLDA,B.DA ;READ DA
2119 015702 017737 164300 002226 MOV @RLMP,B.MP ;READ MP
2120 015710 000205 RTS R5
2121 :
2122 :
2123 ;LOAD REGISTERS AT ERROR
2124 ;CALL: JSR R5,AFTER
2125 :
2126 015712 017737 164262 002232 AFTER: MOV @RLCS,E.CS ;READ CS
2127 015720 017737 164256 002234 MOV @RLBA,E.BA ;READ BA
2128 015726 017737 164252 002236 MOV @RLDA,E.DA ;READ DA
2129 015734 017737 164246 002240 MOV @RLMP,E.MP ;READ MP
2130 015742 017737 164240 002242 MOV @RLMP,E.MP1 ;READ MP
2131 015750 000205 RTS R5
2132 :
2133 ;ROUTINE TO SETUP BUFFERS FOR RLV11 MAINTENANCE FUNCTION
2134 ;BUF1 IS SET WITH 256 WORDS OF PATTERN
2135 ;BUF2 IS CLEARED BEFORE MAINTENANCE FUNCTION
2136 : CALL JSR R5,SETPAT

```

ROUTINE TO CHECK FOR CONTROLLER ERRORS

```
2137      ; .WORD      :PATTERN FOR BUFFER
2138      ;
2139      SETPAT: MOV     R1,-(SP)
2140      MOV     R2,-(SP)
2141      MOV     (R5)+,GDDATP
2142      MOV     #BUF1,R1      :FIRST BUFFER START
2143      MOV     #256,R2
2144      1$: MOV     GDDATP,(R1)+
2145      DEC     R2
2146      BNE     1$      :STORE PATTERN IN 256 WORDS
2147      MOV     #BUF2,R1      :START OF SECOND BUFFER
2148      MOV     #255,R2
2149      2$: CLR     (R1)+
2150      DEC     R2
2151      BNE     2$      :CLEAR 255 WORDS OF SECOND BUFFER
2152      MOV     #123456,(R1)+ :STORE IN LAST BUFFER WORD
2153      MOV     (SP)+,R2
2154      MOV     (SP)+,R1
2155      RTS     R5
2156
2157      ;ROUTINE TO DELAY IN MSECS
2158      ;LFLG = 1      DELAY MSECS FOR 11/23
2159      ;LFLG = 0      DELAY MSECS FOR 1103L ETC.
2160
2161      ;CALL
2162      JSR     R5,WDELAY
2163      ;40 MSECS
2164
2165      WDELAY: MOV     R1,-(SP)
2166      MOV     R2,-(SP)
2167      MOV     (R5)+,R2      :APPROX MSEC DELAY
2168      TST     LFLG      :CHECK PROCESSOR FLAG
2169      BNE     1$      :BRANCH IF 11/23
2170      MOV     #120,DELCNT :LSI-11 APPROX 1 MSEC LOOP
2171      BR     2$
2172      1$: MOV     #300,DELCNT :11/23 APPROX 1 MSEC LOOP
2173      2$: MOV     DELCNT,R1
2174      3$: DEC     R1      :START LOOP
2175      BNE     3$
2176      DEC     R2      :CHECK ON MSECS REQUESTED
2177      BNE     2$      :BRANCH AND DO ANOTHER LOOP
2178      MOV     (SP)+,R2      :SETUP FOR RETURN AFTER DELAY
2179      MOV     (SP)+,R1
2180      RTS     R5
2181
2182      ;ROUTINE TO LOAD RLCS WITH RLV11 MAINT. FUNCTION
2183      ;EITHER FLAG DRIVEN OR INTERRUPT MODE.
2184      ;CALL JSR R5,LDFUN
2185      ; .WORD      :MAINT!INTEN
2186      ; .WORD      :WORD COUNT COMP.
2187      ; .WORD      :MAINTENANCE MESSAGE
2188
2189      LDFUN: MOV     (R5)+,LDCSR :GET FUNCTION
2190      MOV     (R5)+,@RLMP :LOAD WORD COUNT
2191      MOV     (R5)+,RESTMS :GET MESSAGE
2192      CLR     TMPFNC      :CLEAR FUNCTION STORAGE
```

```

2193 016134 012777 003760 164040      MOV      #BUF1,@RLBA      ;SET BA REGISTER
2194 016142 013777 002312 164034      MOV      GCRCPT,@RLDA     ;LOAD DA REGISTER
2195 016150 042737 177661 002252      BIC      #177661,LDCSR    ;CLEAR ALL BUT FUNC.+INT.
2196 016155 053737 002216 002252      BIS      DRIVE,LDCSR     ;SELECT DRIVE
2197 016164 052737 000200 002252      BIS      #200,LDCSR      ;CONTROLLER READY
2198 016172 013777 002252 164000      MOV      LDCSR,@RLCS     ;LOAD CS REGISTER
2199 016200 004537 015660          JSR      R5,BEFORE        ;STORE REGISTERS BEFORE OPERATION
2200 016204 042777 000200 163766      BIC      #200,@RLCS      ;CLEAR CONTROLLER READY
2201 016212 000205          RTS      R5               ;RETURN

```

```

2202
2203
2204
2205
2206
2207
2208
2209

```

;ROUTINE TO SETUP COMPLEMENT BUFFERS FOR RLV11 MAINTENANCE FUNCTION

;BUF1 IS SET WITH PATTERN

;BUF1+1 IS SET WITH COMPLEMENT OF PATTERN

```

:      CALL      JSR      R5,SETCMP
:      .WORD      ;PATTERN FOR BUFFER

```

```

2210 016214 010146      SETCMP: MOV      R1,-(SP)
2211 016216 010246      MOV      R2,-(SP)
2212 016220 012537 002320      MOV      (R5)+,GDDATP
2213 016224 012701 003760      MOV      #BUF1,R1        ;FIRST BUFFER START
2214 016230 012702 000400      MOV      #256.,R2        ;BUFFER COUNT
2215 016234 013737 002320 002322      MOV      GDDATP,GDATMP   ;STORE DATA PATTERN FOR BUF FILL
2216 016242 013721 002322 1$:      MOV      GDATMP,(R1)+
2217 016246 005137 002322      COM      GDATMP          ;STORE COMP. IN NEXT BUF LOCATION
2218 016252 005302      DEC      R2
2219 016254 001372      BNE      1$             ;CHECK FOR BUFFER END
2220 016256 012701 004760      MOV      #BUF2,R1        ;SETUP TO CLEAR BUF2
2221 016262 012702 000377      MOV      #255.,R2
2222 016266 005021 2$:      CLR      (R1)+
2223 016270 005302      DEC      R2
2224 016272 001375      BNE      2$             ;CHECK FOR BUF2 END
2225 016274 012721 123456      MOV      #123456,(R1)+  ;STORE IN LAST BUFFER WORD
2226 016300 012602      MOV      (SP)+,R2
2227 016302 012601      MOV      (SP)+,R1
2228 016304 000205      RTS      R5

```

```

2229
2230
2231
2232
2233
2234
2235

```

;ROUTINE TO SETUP BUFFER WITH RANDOM NUMBERS FOR RLV11 MAINT. FUNCTION

;SAME PATTERN IS USED FOR EACH CONTROLLER

;END OF PASS WILL CHANGE RANDOM PATTERN PRIMES

```

:      CALL      JSR      R5,SETRAN

```

```

2236 016306 010146      SETRAN: MOV      R1,-(SP)
2237 016310 010246      MOV      R2,-(SP)
2238 016312 012701 003760      MOV      #BUF1,R1        ;FIRST BUFFER START
2239 016316 012702 000400      MOV      #256.,R2        ;BUFFER COUNT
2240 016322 004537 016366 1$:      JSR      R5,RAND         ;GET RANDOM NUMBER
2241 016326 013721 002344      MOV      LONUM,(R1)+    ;STORE IN BUFFER
2242 016332 005302      DEC      R2             ;CHECK FOR BUFFER END
2243 016334 001372      BNE      1$
2244 016336 012701 004760      MOV      #BUF2,R1        ;SETUP TO CLEAR BUF2
2245 016342 012702 000377      MOV      #255.,R2
2246 016346 005021 2$:      CLR      (R1)+
2247 016350 005302      DEC      R2
2248 016352 001375      BNE      2$             ;CHECK FOR BUFFER END

```

2249 016354 012721 123456 MOV #123456,(R1)+ ;STORE IN LAST BUFFER WORD
2250 016360 012602 MOV (SP)+,R2
2251 016362 012601 MOV (SP)+,R1
2252 016364 000205 RTS R5

2253
2254
2255 ;THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
2256 ;WITH A RANGE OF 0 TO 2(+33)-1.

2257 ;CALL:
2258 ;CALL THE ROUTINE
2259 ;RETURN HERE THE RANDOM NUMBER
2260 ;WILL BE IN HINUM,LONUM
2261 016366 010146 RAND: MOV R1,-(SP) ;PUSH R1 ON STACK
2262 016370 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
2263 016372 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
2264 016374 013703 002344 MOV LONUM,R3 ;SET R3 WITH LOW
2265 016400 013701 002342 MOV HINUM,R1 ;SET R1 WITH HIGH
2266 016404 012702 177771 MOV #-7,R2 ;SET SHIFT COUNTER
2267 016410 006303 1\$: ASL R3 ;SHIFT R3 LEFT AND
2268 016412 006101 ROL R1 ;ROTATE CARRY INTO R1 AND
2269 016414 005202 INC R2 ;CHECK FOR DONE
2270 016416 001374 BNE 1\$;CONTINUE SHIFT LOOP
2271 016420 063703 002344 ADD LONUM,R3 ;ADD NUMBER TO MAKE X 129
2272 016424 005501 ADC R1 ;PROPOGATE CARRY
2273 016426 063701 002342 ADD HINUM,R1 ;ADD NUMBER TO MAKE X 129
2274 016432 062703 001057 ADD #1057,R3 ;ADD LOW CONSTANT
2275 016436 005501 ADC R1 ;PROPOGATE CARRY
2276 016440 062701 047401 ADD #47401,R1 ;ADD HIGH CONSTANT
2277 016444 010337 002344 MOV R3,LONUM ;SAVE R3
2278 016450 010137 002342 MOV R1,HINUM ;SAVE R1
2279 016454 012603 MOV (SP)+,R3 ;POP STACK INTO R3
2280 016456 012602 MOV (SP)+,R2 ;POP STACK INTO R2
2281 016460 012601 MOV (SP)+,R1 ;POP STACK INTO R1
2282 016462 000205 RTS R5 ;RETURN

2283
2284
2285 .SBTTL ROUTINE TO CALCULATE CRC
2286
2287 ;ROUTINE WILL CALCULATE A CRC-16 CRC ON A WORD OF
2288 ;1-16 BITS IN LENGTH, RESULT IS RETURNED IN "CALBCC"
2289 ;
2290 ;CALL: JSR R5,SIMBCC
2291 ;NUMBER OF BITS (1-16)
2292 ;DATA FOR CRC CALCULATION
2293 ;PREVIOUS OR STARTING CRC
2294 ;(SHOULD BE ZEROED FOR START)
2295 ;
2296 ;ROUTINE USES R0,R1,R2

2297 016464 010046 SIMBCC: MOV R0,-(SP) ;SAVE R0
2298 016466 010146 MOV R1,-(SP) ;SAVE R1
2299 016470 010246 MOV R2,-(SP) ;SAVE R2
2300 016472 012537 002264 MOV (R5)+,TEMP2 ;GET NUMBER OF BITS
2301 016476 012537 002266 MOV (R5)+,TEMP3 ;GET DATA FOR CRC CALCULATION
2302 016502 012537 002270 MOV (R5)+,TEMP4 ;GET STARTING CRC
2303 016506 005037 002260 1\$: CLR BCCFBK ;
2304 016512 013700 002270 MOV TEMP4,R0 ;GET PRESENT CRC

```
2305 016516 006037 002266 ROR TEMP3 :ROTATE NEW DATA
2306 016522 005500 ADC R0 :MERGE NEW WITH OLD
2307 016524 032700 000001 BIT #1,R0 :BIT 0 SET
2308 016530 001402 BEQ 2$ :IF NOT CONTINUE
2309 016532 005137 002260 COM BCCFBK :
2310 016536 013700 002254 2$: MOV XPOLY,R0 :GET CRC POLYNOMIAL (CRC-16)
2311 016542 005100 COM R0 :COMPLIMENT POLYNOMIAL
2312 016544 040037 002260 BIC R0,BCCFBK :
2313 016550 000241 CLC :CLEAR CARRY
2314 016552 006037 002270 ROR TEMP4 :
2315 016556 013700 002260 MOV BCCFBK,R0 :
2316 016562 013701 002270 MOV TEMP4,R1 :
2317 016566 010102 MOV R1,R2 :
2318 016570 040100 BIC R1,R0 :
2319 016572 043702 002260 BIC BCCFBK,R2 :
2320 016576 050200 BIS R2,R0 :
2321 016600 043737 002254 002270 BIC XPOLY,TEMP4 :
2322 016606 050037 002270 BIS R0,TEMP4 :
2323 016612 005337 002264 DEC TEMP2 :
2324 016616 001333 BNE 1$ :
2325 016620 013737 002270 002262 MOV TEMP4,CALBCC :
2326 016626 012602 MOV (SP)+,R2 :
2327 016630 012601 MOV (SP)+,R1 :
2328 016632 012600 MOV (SP)+,R0 :
2329 016634 000205 RTS R5 :RETURN
2330
2331
2332
2333 :ROUTINE TO SET FLAG IF TRAP OCCURRED
2334 :"TRPHAN" IS IN LOCATION 4.
2335
2336
2337 016636 005237 002246 TRPHAN: INC TRPFLG :INDICATE TRAP
2338 016642 000002 RTI :RETURN
2339
2340 016644 BGNSRV
2341
2342 016644 005237 002250 INTSRV: INC INTFLG :INDICATE INTERRUPT
2343
2344 016650 ENDSRV
2345 016650 L10022:
2346 016650 000002 RTI
2347
2348 :ROUTINE USED IN TIMING OPI
2349 016652 005237 002250 TIMSRV: INC INTFLG
2350 016656 000002 RTI
2351
2352
2353 :ROUTINE TO WAIT FOR DRIVE READY
2354 016660 010146 WTDRDY: MOV R1,-(SP) :SAVE R1
2355 016662 012701 000310 MOV #200.,R1 :TIME OUT OF 200 MILLISECONDS
2356 016666 032777 000001 163304 1$: BIT #DRDY,@RLCS :DRIVE READY?
2357 016674 001011 BNE 2$ :YES, EXIT
2358
2359 016676 004537 016032 JSR R5,WDELAY :WAIT A WHILE
2360 016702 000001 1 :APPROX. A MILLISECOND
```

```
2361 016704 005301      DEC      R1      :CHECK IF TIME UP
2362 016706 001367      BNE      1$      :NO, GO CHECK DRIVE READY
2363
2364 016710              ERRDF    200.,DRTIM,ERR5 ;DRIVE READY DID NOT SET
2365 016710 104455      TRAP    C$ERDF
2366 016712 000310      .WORD   200
2367 016714 006547      .WORD   DRTIM
2368 016716 012074      .WORD   ERR5
2369
2370 016720 012601      2$:     MOV     (SP)+,R1      :RESTORE
2371 016722 000205      RTS     R5              :EXIT
2372
2373              ;ROUTINE TO WAIT FOR CONTROLLER READY
2374 016724 010146      WTCRDY: MOV     R1,-(SP)      :SAVE R1
2375 016726 012701 001440      MOV     #800.,R1      :WAIT 800 MILLISECONDS
2376 016732 032777 000200 163240 1$:     BIT     #CRDY,@RLCS    :CONTROLLER READY
2377 016740 001014      BNE     2$            :YES, EXIT
2378 016742 004537 016032      JSR     R5,WDELAY     :WAIT A WHILE
2379 016746 000001      1
2380 016750 005301      DEC     R1            :APPROX A MILLISECOND
2381 016752 001367      BNE     1$            :CHECK IF TIME UP
2382
2383 016754 004537 015712      JSR     R5,AFTER      :GET REGISTERS
2384
2385 016760              ERRDF    100.,CRTIM,ERR6 ;CONTROLLER TIMED OUT
2386 016760 104455      TRAP    C$ERDF
2387 016762 000144      .WORD   100
2388 016764 006522      .WORD   CRTIM
2389 016766 012106      .WORD   ERR6
2390
2391 016770 000402      BR      3$            :EXIT
2392
2393 016772 004537 015712      2$:     JSR     R5,AFTER      :GET REGISTERS
2394 016776 012601      3$:     MOV     (SP)+,R1
2395 017000 000205      RTS     R5              :EXIT
2396
2397
2398
2399 017002              ENDMOD
2400
2401
2402
2403              .SBTTL  **TEST 1** - RLCS WRITE ADDRESSABILITY
2404
2405 017002      BGNTST              ;****START OF TEST****
2406 017002      STARS
2407      ;*****
2408      ;TEST TO SEE IF WE CAN ADDRESS THE CONTROL
2409      ;AND STATUS REGISTER. IF WE TRAP WE WILL REPORT
2410      ;THE ERROR AND ABORT. AFTER THIS TEST WE ONLY KNOW
2411      ;THAT WE CAN ADDRESS THE REGISTER.
2412 017002      STARS
2413      ;*****
2414
2415
2416 017002 005037 002246      1$:     CLR     TRPFLG      ;CLEAR TRAP OCCURANCE
```

```
2417 017006          2$: SETVEC  ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2418 017006 012746 000340      MOV      #340,-(SP)
2419 017012 012746 016636      MOV      #TRPHAN,-(SP)
2420 017016 013746 002256      MOV      ERRVEC,-(SP)
2421 017022 012746 000003      MOV      #3,-(SP)
2422 017026 104437          TRAP     C$SVEC
2423 017030 062706 000010      ADD      #10,SP
2424
2425 017034 012777 177777 163136  MOV      #177777,@RLCS ;ADDRESS RLCS
2426 017042          CLRVEC  ERRVEC ;RELEASE TRAP VECTOR
2427 017042 013700 002256      MOV      ERRVEC,R0
2428 017046 104436          TRAP     C$CVEC
2429 017050 005737 002246      TST     TRPFLG ;TRAP OCCURRED???
2430 017054 001407          BEQ     3$ ;NO, OKAY PROCEED
2431 017056 013737 002200 002306  MOV      RLCS,GDDAT ;SET UP ERROR DATA
2432
2433 017064          ERRSF  0,EM1,ERR1 ;BUS TIMEOUT IN ADDRESSING RLCS
2434 017064 104454          TRAP     C$ERSF
2435 017066 000000          .WORD   0
2436 017070 006575          .WORD   EM1
2437 017072 011650          .WORD   ERR1
2438 017074          3$:  CKLOOP          ;CHECK IF /FL:LOE IS SET
2439 017074 104406          TRAP     C$CLP1
2440 017076          ENDTST          ;****END OF TEST****
2441 017076          L10023:
2442 017076 104401          TRAP     C$ETST
2443
2444
2445          .SBTTL  **TEST 2** - RLBA WRITE ADDRESSABILITY
2446
2447 017100          BGNTST          ;****START OF TEST****
2448
2449
2450 017100          STARS
2451          ;*****
2452          ;TEST TO SEE IF WE CAN ADDRESS THE BUS ADDRESS
2453          ;REGISTER. IF WE TRAP WE WILL REPORT THE ERROR
2454          ;AND ABORT. AFTER THIS TEST WE ONLY KNOW THAT
2455          ;WE CAN ADDRESS THE REGISTER.
2456 017100          STARS
2457          ;*****
2458
2459 017100 005037 002246          1$:  CLR      TRPFLG ;CLEAR TRAP OCCURANCE
2460 017104          2$:  SETVEC  ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2461 017104 012746 000340      MOV      #340,-(SP)
2462 017110 012746 016636      MOV      #TRPHAN,-(SP)
2463 017114 013746 002256      MOV      ERRVEC,-(SP)
2464 017120 012746 000003      MOV      #3,-(SP)
2465 017124 104437          TRAP     C$SVEC
2466 017126 062706 000010      ADD      #10,SP
2467
2468 017132 012777 177777 163042  MOV      #177777,@RLBA ;ADDRESS RLBA
2469 017140          CLRVEC  ERRVEC ;RELEASE TRAP VECTOR
2470 017140 013700 002256      MOV      ERRVEC,R0
2471 017144 104436          TRAP     C$CVEC
2472 017146 005737 002246      TST     TRPFLG ;TRAP OCCURRED???
```

TEST 2 - RLBA WRITE ADDRESSABILITY

```
2473 017152 001407          BEQ      3$          :NO, CONTINUE
2474 017154 013737 002202 002306  MOV     RLBA,GDDAT  :SETUP ERROR DATA
2475
2476 017162          ERRSF   1,EM2,ERR1  :BUS TIMEOUT IN ADDRESSING RLBA
2477 017162 104454          TRAP   C$ERSF
2478 017164 000001          .WORD  1
2479 017166 006622          .WORD  EM2
2480 017170 011650          .WORD  ERR1
2481 017172          3$: CKLOOP
2482 017172 104406          TRAP   C$CLP1      :CHECK IF /FL:LOE IS SET
2483 017174          ENDTST
2484 017174          L10024:           :*****END OF TEST****
2485 017174 104401          1RAP   C$ETST
```

.SBTTL **TEST 3** - RLDA WRITE ADDRESSABILITY

```
2486
2487
2488
2489
2490 017176          BGNTST           :*****START OF TEST****
2491 017176          STARS
2492
2493          :*****
2494          :TEST TO SEE IF WE CAN ADDRESS THE DISK ADDRESS
2495          :REGISTER IF WE TRAP WE WILL REPORT THE ERROR
2496          :AND ABORT. AFTER THIS TEST WE ONLY KNOW THAT
2497          :WE CAN ADDRESS THE REGISTER.
2498          STARS
2499          :*****
```

```
2500
2501 017176 005037 002246          1$: CLR     TRPFLG          :CLEAR TRAP OCCURANCE
2502 017202          2$: SETVEC  ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2503 017202 012746 000340          MOV     #340,-(SP)
2504 017206 012746 016636          MOV     #TRPHAN,-(SP)
2505 017212 013746 002256          MOV     ERRVEC,-(SP)
2506 017216 012746 000003          MOV     #3,-(SP)
2507 017222 104437          TRAP   C$SVEC
2508 017224 062706 000010          ADD     #10,SP
2509
2510 017230 012777 177777 162746          MOV     #177777,@RLDA  :ADDRESS RLDA
2511 017236          CLRVEC  ERRVEC          :RELEASE TRAP VECTOR
2512 017236 013700 002256          MOV     ERRVEC,R0
2513 017242 104436          TRAP   C$CVEC
2514 017244 005737 002246          TST    TRPFLG          :TRAP OCCURRED??
2515 017250 001407          BEQ     3$          :NO, CONTINUE
2516
2517 017252 013737 002204 002306          MOV     RLDA,GDDAT  :SETUP ERROR INFO
2518 017260          ERRSF   2,EM3,ERR1  :BUS TIMEOUT IN ADDRESSING RLDA
2519 017260 104454          TRAP   C$ERSF
2520 017262 000002          .WORD  2
2521 017264 006647          .WORD  EM3
2522 017266 011650          .WORD  ERR1
2523 017270          3$: CKLOOP
2524 017270 104406          TRAP   C$CLP1      :CHECK IF /FL:LOE IS SET
2525 017272          ENDTST
2526 017272          L10025:           :*****END OF TEST****
2527 017272 104401          TRAP   C$ETST
```


2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584

017274
017274

017274

017274 005037 002246

017300

017300 012746 000340

017304 012746 016636

017310 013746 002256

017314 012746 000003

017320 104437

017322 062706 000010

017326 012777 177777 162652

017334

017334 013700 002256

017340 104436

017342 005737 002246

017346 061407

017350 013737 002206 002306

017356

017356 104454

017360 000003

017362 006674

017364 011650

017366

017366 104406

017370

017370

017370 104401

.SBTTL **TEST 4** - RLMP WRITE ADDRESSABILITY

BGNTST ;****START OF TEST****

STARS

:TEST TO SEE IF WE CAN ADDRESS THE MULTIPURPOSE
:REGISTER. IF WE TRAP WE WILL REPORT THE ERROR AND
:ABORT. AFTER THIS TEST WE ONLY KNOW THAT WE CAN
:ADDRESS THE REGISTER.

STARS

1\$: CLR TRPFLG ;CLEAR TRAP OCCURANCE
2\$: SETVEC ERRVEC,#TRPHAN,#340 ;SET UP TO CATCH TRAP
MOV #340,-(SP)
MOV #TRPHAN,-(SP)
MOV ERRVEC,-(SP)
MOV #3,-(SP)
TRAP C\$SVEC
ADD #10,SP

MOV #177777,@RLMP ;ADDRESS RLMP
CLRVEC ERRVEC ;RELEASE TRAP VECTOR
MOV ERRVEC,R0
TRAP C\$CVEC
TST TRPFLG ;TRAP OCCURRED???
BEQ 3\$;NO, CONTINUE
MOV RLMP,GDDAT ;SET UP ERROR INFO

ERRSF 3,EM4,ERR1 ;BUS TIMEOUT IN ADDRESSING RLMP
TRAP C\$ERSF
.WORD 3
.WORD EM4
.WORD ERR1
3\$: CKLOOP ;CHECK IF /FL:LOE IS SET
TRAP C\$CLP1

ENDTST ;****END OF TEST****

L10026: TRAP C\$SETST

.SBTTL **TEST 5** - RLCS READ ADDRESSABILITY

BGNTST ;****START OF TEST****

STARS

:TEST TO SEE IF WE CAN ADDRESS THE CONTROL
:AND STATUS REGISTER. IF WE TRAP WE WILL REPORT
:THE ERROR AND ABORT. AFTER THIS TEST WE ONLY KNOW
:THAT WE CAN ADDRESS THE REGISTER.

STARS

1\$: CLR TRPFLG ;CLEAR TRAP OCCURANCE

TEST 5 - RLCS READ ADDRESSABILITY

```
2585 017376          2$: SETVEC ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2586 017376 012746 000340      MOV #340,-(SP)
2587 017402 012746 016636      MOV #TRPHAN,-(SP)
2588 017406 013746 002256      MOV ERRVEC,-(SP)
2589 017412 012746 000003      MOV #3,-(SP)
2590 017416 104437          TRAP C$SVEC
2591 017420 062706 000010      ADD #10,SP
2592
2593 017424 005777 162550      TST @RLCS ;ADDRESS RLCS
2594 017430          CLRVEC ERRVEC ;RELEASE TRAP VECTOR
2595 017430 013700 002256      MOV ERRVEC,RO
2596 017434 104436          TRAP C$CVEC
2597 017436 005737 002246      TST TRPFLG ;TRAP OCCURRED???
2598 017442 001407          BEQ 3$ ;NO, OKAY PROCEED
2599 017444 013737 002200 002306  MOV RLCS,GDDAT ;SET UP ERROR DATA
2600
2601 017452          ERRSF 100,EM1,ERR1 ;BUS TIMEOUT IN ADDRESSING RLCS
2602 017452 104454          TRAP C$ERSF
2603 017454 000144          .WORD 100
2604 017456 006575          .WORD EM1
2605 017460 011650          .WORD ERR1
2606 017462          3$: CKLOOP ;CHECK IF /FL:LOE IS SET
2607 017462 104406          TRAP C$CLP1
2608 017464          ENDTST ;****END OF TEST****
2609 017464          L10027:
2610 017464 104401          TRAP C$ETST
2611
2612
2613          .SBTTL **TEST 6** - RLBA READ ADDRESSABILITY
2614
2615 017466          BGNTST ;****START OF TEST****
2616
2617
2618 017466          STARS
2619          :*****
2620          :TEST TO SEE IF WE CAN ADDRESS THE BUS ADDRESS
2621          :REGISTER. IF WE TRAP WE WILL REPORT THE ERROR
2622          :AND ABORT. AFTER THIS TEST WE ONLY KNOW THAT
2623          :WE CAN ADDRESS THE REGISTER.
2624 017466          STARS
2625          :*****
2626
2627 017466 005037 002246          1$: CLR TRPFLG ;CLEAR TRAP OCCURANCE
2628 017472          2$: SETVEC ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2629 017472 012746 000340      MOV #340,-(SP)
2630 017476 012746 016636      MOV #TRPHAN,-(SP)
2631 017502 013746 002256      MOV ERRVEC,-(SP)
2632 017506 012746 000003      MOV #3,-(SP)
2633 017512 104437          TRAP C$SVEC
2634 017514 062706 000010      ADD #10,SP
2635
2636 017520 005777 162456      TST @RLBA ;ADDRESS RLBA
2637 017524          CLRVEC ERRVEC ;RELEASE TRAP VECTOR
2638 017524 013700 002256      MOV ERRVEC,RO
2639 017530 104436          TRAP C$CVEC
2640 017532 005737 002246      TST TRPFLG ;TRAP OCCURRED???
```

```

2641 017536 001407 BEQ 3$ ;NO, CONTINUE
2642 017540 013737 002202 002306 MOV RLBA,GDDAT ;SETUP ERROR DATA
2643
2644 017546 ERRSF 101,EM2,ERR1 ;BUS TIMEOUT IN ADDRESSING RLBA
2645 017546 104454 TRAP C$ERSF
2646 017550 000145 .WORD 101
2647 017552 006622 .WORD EM2
2648 017554 011650 .WORD ERR1
2649 017556 3$: CKLOOP ;CHECK IF /FL:LOE IS SET
2650 017556 104406 TRAP C$CLP1
2651 017560 ENDTST ;****END OF TEST****
2652 017560 L10030:
2653 017560 104401 TRAP C$ETST
2654
2655
2656
2657

```

.SBTTL **TEST 7** - RLDA READ ADDRESSABILITY

```

2658 017562 BGNST ;****START OF TEST****
2659 017562 STARS
2660 ;*****
2661 ;TEST TO SEE IF WE CAN ADDRESS THE DISK ADDRESS
2662 ;REGISTER IF WE TRAP WE WILL REPORT THE ERROR
2663 ;AND ABORT. AFTER THIS TEST WE ONLY KNOW THAT
2664 ;WE CAN ADDRESS THE REGISTER.
2665 017562 STARS
2666 ;*****
2667
2668

```

```

2669 017562 005037 002246 1$: CLR TRPFLG ;CLEAR TRAP OCCURANCE
2670 017566 2$: SETVEC ERRVEC,#TRPHAN,#340 ;SET TO CATCH TRAP
2671 017566 012746 000340 MOV #340,-(SP)
2672 017572 012746 016636 MOV #TRPHAN,-(SP)
2673 017576 013746 002256 MOV ERRVEC,-(SP)
2674 017602 012746 000003 MOV #3,-(SP)
2675 017606 104437 TRAP C$SVEC
2676 017610 062706 000010 ADD #10,SP
2677
2678 017614 005777 162364 TST @RLDA ;ADDRESS RLDA
2679 017620 CLRVEC ERRVEC ;RELEASE TRAP VECTOR
2680 017620 013700 002256 MOV ERRVEC,R0
2681 017624 104436 TRAP C$CVEC
2682 017626 005737 002246 TST TRPFLG ;TRAP OCCURRED???
2683 017632 001407 BEQ 3$ ;NO, CONTINUE
2684
2685 017634 013737 002204 002306 MOV RLDA,GDDAT ;SETUP ERROR INFO
2686 017642 ERRSF 102,EM3,ERR1 ;BUS TIMEOUT IN ADDRESSING RLDA
2687 017642 104454 TRAP C$ERSF
2688 017644 000146 .WORD 102
2689 017646 006647 .WORD EM3
2690 017650 011650 .WORD ERR1
2691 017652 3$: CKLOOP ;CHECK IF /FL:LOE IS SET
2692 017652 104406 TRAP C$CLP1
2693 017654 ENDTST ;****END OF TEST****
2694 017654 L10031:
2695 017654 104401 TRAP C$ETST
2696

```

2697
2698
2699
2700
2701
2702
2703
2704
2705
2706
2707
2708
2709
2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732
2733
2734
2735
2736
2737
2738
2739
2740
2741
2742
2743
2744
2745
2746
2747
2748
2749
2750
2751
2752

017656
017656

017656

017656 005037 002246

017662

017662 012746 000340

017666 012746 016636

017672 013746 002256

017676 012746 000003

017702 104437

017704 062706 000010

017710 005777 162272

017714

017714 013700 002256

017720 104436

017722 005737 002246

017726 001407

017730 013737 002206 002306

017736

017736 104454

017740 000147

017742 006674

017744 011650

017746

017746 104406

017750

017750

017750 104401

.SBTTL **TEST 8** - RLMP READ ADDRESSABILITY

BGNTST ;****START OF TEST****

STARS

:TEST TO SEE IF WE CAN ADDRESS THE MULTIPURPOSE
:REGISTER. IF WE TRAP WE WILL REPORT THE ERROR AND
:ABORT. AFTER THIS TEST WE ONLY KNOW THAT WE CAN
:ADDRESS THE REGISTER.

STARS

1\$: CLR TRPFLG ;CLEAR TRAP OCCURANCE

2\$: SETVEC ERRVEC,#TRPHAN,#340 ;SET UP TO CATCH TRAP

MOV #340,-(SP)

MOV #TRPHAN,-(SP)

MOV ERRVEC,-(SP)

MOV #3,-(SP)

TRAP C\$SVEC

ADD #10,SP

TST @RLMP ;ADDRESS RLMP

CLRVEC ERRVEC ;RELEASE TRAP VECTOR

MOV ERRVEC,R0

TRAP C\$CVEC

TST TRPFLG ;TRAP OCCURRED???

BEQ 3\$;NO, CONTINUE

MOV RLMP,GDDAT ;SET UP ERROR INFO

ERRSF 103,EM4,ERR1 ;BUS TIMEOUT IN ADDRESSING RLMP

TRAP C\$ERSF

.WORD 103

.WORD EM4

.WORD ERR1

3\$: CKLOOP ;CHECK IF /FL:LOE IS SET

TRAP C\$CLP1

ENDTST ;****END OF TEST****

L10032:

TRAP C\$ETST

.SBTTL **TEST 9** - BUS RESET OF RLCS

BGNTST ;****START OF TEST****

STARS

:TEST THAT A BUS RESET WILL CLEAR THE PROPER BITS
:OF THE CONTROL AND STATUS REGISTER. THOSE BITS ARE
:BITS 6-1,8,9,10,11,12,13,15. BIT 15 WILL CLEAR ONLY
:IF BIT 14 (DRIVE ERROR IS NOT SET). BIT 0 (DRIVE READY)
:IS A DON'T CARE. IF AT THE START UP THIS TEST BIT
:14 (DRIVE ERROR) IS SET WE WILL INSIST IF IS THERE AFTER
:THE "RESET" ALONG WITH BIT 15 (COMPOSITE ERROR). BITS
:15-10 ARE NOT WRITEABLE.

```

2753 017752 STARS
2754 :*****
2755
2756
2757 017752 SETPRI #PRI07 ;PRIORITY TO SEVEN
2758 017752 012700 000340 MOV #PRI07,R0
2759 017756 104441 TRAP C$SPRI
2760 017760 012777 000377 162212 MOV #377,@RLCS ;LOAD ALL RLCS LOADABLE BITS
2761 017766 012737 000200 002306 MOV #CRDY,GDDAT ;SETUP EXPECTED
2762 017774 032777 040000 162176 BIT #DERR,@RLCS ;DRIVE ERR SET?
2763 020002 001403 BEQ 1$ ;IF NOT DON'T EXPECT IT
2764 020004 052737 140000 002306 BIS #DERR!ERR,GDDAT ;IT'S SET, INIT BETTER NOT CLR
2765 020012 012700 0C0100 1$: MOV #100,R0 ;SET UP A WAIT LOOP
2766 020016 BRESET ;BUS RESET
2767 020016 104433 TRAP C$RESET
2768 020020 005300 2$: DEC R0 ;WAIT IN CASE OF DRIVE ERROR
2769 020022 001376 BNE 2$
2770 020024 017737 162150 002310 MOV @RLCS,BDDAT ;READ RLCS
2771 020032 042737 000001 002310 BIC #DRDY,BDDAT ;CLEAR OUT DRDY - DON'T CARE
2772 020040 023737 002310 002306 CMP BDDAT,GDDAT ;DID INIT WORK
2773 020046 001404 BEQ 3$ ;YES, BRANCH
2774
2775 020050 ERRDF 113,EM67,ERR2 ;WRONG DATA IN RLCS
2776 020050 104455 TRAP C$ERDF
2777 020052 000161 .WORD 113
2778 020054 011005 .WORD EM67
2779 020056 011662 .WORD ERR2
2780 020060 3$:
2781 020060 ENDTST ;****END OF TEST****
2782 020060 L10033:
2783 020060 104401 TRAP C$ETST
2784
2785
2786 .SBTTL **TEST 10** - BUS RESET OF RLBA
2787
2788 020062 BGNTST ;****START OF TEST****
2789
2790 020062 STARS
2791 :*****
2792 :TEST THAT A BUS RESET WILL CLEAR THE ENTIRE
2793 :BUS ADDRESS REGISTER. THE BUS ADDRESS IS LOADED WITH 177776
2794 :AND IS EXPECTED TO BE ZERO AFTER THE RESET
2795 020062 STARS
2796 :*****
2797
2798
2799 020062 012777 177776 162112 MOV #-2,@RLBA ;SET BA TO ALL 1'S
2800 020070 005737 002332 TST T.CNTRL ;RL11?
2801 020074 001403 BEQ 2$ ;NO
2802 020076 052777 000001 162076 BIS #1,@RLBA
2803 020104 005037 002306 2$: CLR GDDAT ;CLEAR EXPECTED DATA
2804 020110 BRESET ;ISSUE BUS INIT
2805 020110 104433 TRAP C$RESET
2806 020112 017737 162064 002310 MOV @RLBA,BDDAT ;READ RLBA
2807 020120 001404 BEQ 1$ ;IF CLEAR BRANCH
2808
  
```

```
2809 020122          ERRDF 114.,EM70,ERR2 ;WRONG DATA IN RLBA
2810 020122 104455   TRAP   C$ERDF
2811 020124 000162   .WORD 114
2812 020126 011042   .WORD EM70
2813 020130 011662   .WORD ERR2
2814 020132          1$:
2815
2816 020132          ENDTST          ;****END OF TEST****
2817 020132          L10034:
2818 020132 104401   TRAP   C$ETST
2819
2820
2821          .SBTTL **TEST 11** - BUS RESET OF RLDA
2822
2823 020134          BGNTST          ;****START OF TEST****
2824
2825 020134          STARS
2826          :*****
2827          :TEST THAT A BUS RESET WILL CLEAR THE ENTIRE
2828          :DISK ADDRESS REGISTER. THE DISK ADDRESS IS LOADED WITH 177777
2829          :AND IS EXPECTED TO BE ZERO AFTER THE RESET.
2830 020134          STARS
2831          :*****
2832
2833
2834 020134 012777 177777 162042   MOV    #-1,@RLDA    ;SET DA TO ALL 1'S
2835 020142 005037 002306          CLR    GDDAT        ;CLEAR EXPECTED
2836 020146          @RESET          ;ISSUE BUS INIT
2837 020146 104433   TRAP   C$RESET
2838 020150 017737 162030 002310   MOV    @RLDA,BDDAT ;READ RLDA
2839 020156 001404          BEQ    1$          ;IF CLEAR BRANCH
2840
2841 020160          ERRDF 115.,EM71,ERR2 ;WRONG DATA IN RLDA
2842 020160 104455   TRAP   C$ERDF
2843 020162 000163   .WORD 115
2844 020164 011077   .WORD EM71
2845 020166 011662   .WORD ERR2
2846 020170          1$:
2847
2848 020170          ENDTST          ;****END OF TEST****
2849 020170          L10035:
2850 020170 104401   TRAP   C$ETST
2851
2852
2853          .SBTTL **TEST 12** - READ WRITE OF RLCS
2854
2855 020172          BGNTST          ;****START OF TEST****
2856
2857
2858
2859 020172          STARS
2860          :*****
2861          :TEST THAT WE CAN WRITE/READ BITS 8,9 AND BITS 6-1
2862          :OF THE CONTROL AND STATUS REGISTER. BITS 15-10 AND 0
2863          :ARE DON'T CARE BITS AT THIS TIME AND BIT 7
2864          : (CONTROLLER READY) IS ALWAYS WRITTEN TO A ONE.
```

```

2865 020172 STARS
2866 ;:*****
2867
2868
2869 020172 012703 003160 MOV #CSPAT,R3 ;SET UP TABLE POINTER OF PATTERNS
2870
2871 020176 BGNSEG ;****START OF SEGMENT****
2872 020176 104404 TRAP C$BSEG
2873
2874 020200 C$TEST:
2875 020200 011337 002306 MOV (R3),GDDAT ;GET PATTERN INTO GDDAT
2876 020204 052737 000200 002306 BIS #200,GDDAT ;INSURE GO IS SET
2877 020212 013777 002306 161760 MOV GDDAT,@RLCS ;LOAD RLCS (CONTROL AND STATUS)
2878 020220 032777 040000 161752 BIT #DERR,@RLCS ;IF DRIVE ERROR PRESENT
2879 020226 001403 BEQ 99$ ;THEN EXPECT DRIVE AND
2880 020230 052737 140000 002306 BIS #ERR!DERR,GDDAT ;COMPOSITE ERROR
2881 020236 017737 161736 002310 99$: MOV @RLCS,BDDAT ;READ RLCS BACK
2882 020244 042737 000001 002310 BIC #DRDY,BDDAT ;IGNORE DRIVE READY
2883 020252 023737 002306 002310 CMP GDDAT,BDDAT ;DID WE READ WHAT WE LOADED
2884 020260 001404 BEQ 1$ ;YES, THEN BRANCH
2885
2886 020262 ERRDF 4.,EM5,ERR2 ;WRONG DATA IN RLCS
2887 020262 104455 TRAP C$ERRDF
2888 020264 000004 .WORD 4
2889 020266 006721 .WORD EM5
2890 020270 011662 .WORD ERR2
2891 020272 1$: ESCAPE SEG ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
2892 020272 104410 TRAP C$ESCAPE
2893 020274 000012 .WORD 10000$-.
2894
2895
2896 020276 005723 TST (R3)+ ;BUMP FOR NEXT PATTERN
2897 020300 020327 003256 CMP R3,#CSEND ;CHECK FOR END
2898 020304 001335 BNE C$TEST ;NOT END, LOAD NEXT PATTERN
2899
2900 ENDSEG ;****END OF SEGMENT****
2901 10000$:
2902 TRAP C$ESEG
2903
2904 ENDTST ;****END OF TEST****
2905 L10036: TRAP C$ETST
2906
2907
2908 .SBTTL **TEST 13** - READ WRITE OF RLBA
2909
2910 020312 BGNTEST ;****START OF TEST****
2911
2912 020312 STARS
2913 ;:*****
2914 ;TEST THAT WE CAN WRITE/READ BITS IS THRU 1 OF THE
2915 ;BUS ADDRESS REGISTER. FOUR PATTERNS ARE USED: GROWING 1, SHIFTING 1,
2916 ;GROWING 0 AND SHIFTING 0. BIT 0 IS ALSO LOADED BUT
2917 ;SHOULD ALWAYS COME BACK AS 0
2918 020312 STARS
2919 ;:*****
2920

```

```

2921
2922 020312 012703 002564          MOV      #BEGPAT,R3      ;GET START OF PATTERN LIST
2923 020316          BGNSEG   TRAP          C$BSEG      ;****START OF SEGMENT****
2924 020316 104404          BATEST:  MOV      (R3),GDDAT    ;GET PATTERN TO SEND
2925 020320          TST      T,CN1LR        ;RL11??
2926 020320 011337 002306          BEQ      2$            ;NO
2927 020324 005737 002332          BIC      #BIT0,GDDAT    ;KEEP RLBA EVEN (UNIBUS)
2928 020330 001403          2$:     MOV      GDDAT,@RLBA   ;LOAD PATTERN TO BUS ADDRESS
2929 020332 042737 000001 002306  MOV      @RLBA,BDDAT    ;READ IT BACK
2930 020340 013777 002306 161634  MOV      GDDAT,BDDAT    ;IS IT CORRECT?
2931 020346 017737 161630 002310  CMP      GDDAT,BDDAT    ;IF SO, BRANCH
2932 020354 023737 002306 002310  BEQ      1$
2933 020362 001404          ERRDF   5.,EM6,ERR2    ;DATA WRONG IN RLBA
2934
2935 020364          TRAP    C$ERDF
2936 020364 104455          .WORD   5
2937 020366 000005          .WORD   EM6
2938 020370 006772          .WORD   ERR2
2939 020372 011662          1$:     ESCAPE  SEG
2940 020374          TRAP    C$ESCAPE
2941 020374 104410          .WORD   10000$-.
2942 020376 000012          TST     (R3)+          ;BUMP FOR NEXT PATTERN
2943
2944 020400 005723          CMP     R3,#ENDPAT    ;CHECK FOR END
2945 020402 020327 002772          BNE     BATEST        ;NOT END, BRANCH FOR NEXT
2946 020406 001344          ENDSEG
2947
2948 020410          TRAP    C$ESEG      ;****END OF SEGMENT****
2949 020410 10000$:
2950 020410 104405          ENDTST
2951 020412          L10037: TRAP    C$ETST      ;****END OF TEST****
2952 020412 104401
2953 020412
2954
2955
2956          .SBTTL  **TEST 14** - READ WRITE OF RLDA
2957
2958 020414          BGNSTST
2959
2960 020414          STARS
2961          ;*****
2962          ;TEST THAT WE CAN WRITE/READ THE DISK ADDRESS REGISTER
2963          ;ALL BIT POSITIONS ARE WRITTEN USING FOUR PATTERNS:
2964          ;GROWING 1, SHIFTING 1, GROWING 0 AND SHIFTING 0
2965 020414          STARS
2966          ;*****
2967
2968
2969 020414 012703 002564          MOV      #BEGPAT,R3      ;SET UP POINTER TO PATTERN LIST
2970 020420          BGNSEG   TRAP          C$BSEG      ;****START OF SEGMENT****
2971 020420 104404          DATEST:  MOV      (R3),GDDAT    ;GET PATTERN
2972 020422          MOV      GDDAT,@RLDA   ;LOAD PATTERN IN DA
2973 020422 011337 002306          MOV      @RLDA,BDDAT    ;READ PATTERN BACK
2974 020426 013777 002306 161550
2975
2976 020434 017737 161544 002310

```



```

2977 020442 023737 002306 002310      CMP      GDDAT,BDDAT      ;IS IT CORRECT?
2978 020450 001404                      BEQ      1$              ;BRANCH IF CORRECT
2979
2980 020452                      ERRDF   6,EM7,ERR2      ;WRONG DATA IN RLDA
2981 020452 104455                      TRAP   C$ERRDF
2982 020454 000006                      .WORD  6
2983 020456 007020                      .WORD  EM7
2984 020460 011662                      .WORD  ERR2
2985 020462                      1$:    ESCAPE  SEG      ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
2986 020462 104410                      TRAP   C$ESCAPE
2987 020464 000012                      .WORD  10000$-
2988
2989
2990 020466 005723                      TST    (R3)+           ;BUMP POINTER
2991 020470 020327 002772                      CMP    R3,#ENDPAT     ;AT END OF PATTERNS?
2992 020474 001352                      BNE    DATEST         ;NO, BRANCH BACK
2993
2994 020476                      ENDSEG                ;****END OF SEGMENT****
2995 020476 10000$:
2996 020476 104405                      TRAP   C$ESEG
2997 020500                      ENDTST                ;****END OF TEST****
2998 C20500 L10040:
2999 020500 104401                      TRAP   C$ETST
3000
3001
3002
3003
3004 020502                      .SBTTL **TEST 15** - BIS OF RLCS
3005 020502                      BGNTST                ;****START OF TEST****
3006
3007
3008
3009
3010
3011 020502                      STARS
3012
3013
3014
3015 020502 012703 003160                      MOV    #CSPAT,R3      ;GET BEGINNING OF LIST
3016 020506                      BGNSEG                ;****START OF SEGMENT****
3017 020506 104404                      TRAP   C$BSEG
3018 020510                      1$:
3019 020510 012777 000200 161462                      MOV    #CRDY,@RLCS    ;INSURE GO IS THERE
3020 020516 011337 002306                      MOV    (R3),GDDAT     ;SET UP EXPECTED RLCS
3021 020522 052737 000200 002306                      BIS    #CRDY,GDDAT    ;IN GDDAT
3022 020530 051377 161444                      BIS    (R3),@RLCS     ;BIT SET PATTERN IN RLCS
3023 020534 032777 040000 161436                      BIT    #DERR,@RLCS   ;IF ERROR BIT SET THEN
3024 020542 001403                      BEQ    99$            ;EXPECT IT ON THE READ
3025 020544 052737 140000 002306                      BIS    #ERR!DERR,GDDAT ;BACK
3026 020552 017737 161422 002310                      99$:  MOV    @RLCS,BDDAT   ;READ RLCS TO CHECK "BIS"
3027 020560 042737 000001 002310                      BIC    #DRDY,BDDAT   ;CLEAR OUT DRIVE READY
3028 020566 023737 002310 002306                      CMP    BDDAT,GDDAT   ;DID BIS WORK?
3029 020574 001404                      BEQ    2$            ;BRANCH IF OKAY
3030
3031 020576                      ERRDF   7,EM61,ERR2   ;WRONG DATA IN RLCS
3032 020576 104455                      TRAP   C$ERRDF

```

```

3033 020600 000007          .WORD 7
3034 020602 010331          .WORD EM61
3035 020604 011662          .WORD ERR2
3036 020606 104410          2$: ESCAPE SEG          ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
3037 020606 104410          TRAP C$ESCAPE
3038 020610 000012          .WORD 10000$-
3039                                ;BIT OR CLEARED OTHER BIT
3040
3041 020612 005723          TST (R3)+          ;GET NEXT PATTERN
3042 020614 022703 003256  CMP #CSEND,R3      ;AT END OF LIST
3043 020620 001333          BNE 1$             ;NO GO BACK FOR TEST OF
3044                                ;NEXT PATTERN
3045                                ;****END OF SEGMENT****
3046 020622          ENDSEG
3047 020622 104405          10000$: TRAP C$ESEG
3048 020624          ENDTST
3049 020624 104401          L10041: TRAP C$ETST
3050
3051
3052                                .SBTTL **TEST 16** - BIC OF RLCS
3053
3054                                BGNSTST
3055 020626                                ;****START OF TEST****
3056
3057 020626                                STARS
3058                                ;*****
3059                                ;TEST THAT THE "BIC" INSTRUCTION WILL WORK ON THE
3060                                ;CONTROL AND STATUS REGISTER. BITS 8-9 AND 6-1 ARE
3061                                ;TESTED.
3062 020626                                STARS
3063                                ;*****
3064
3065
3066 020626 012703 003160          BGNSEG MOV #CSPAT,R3          ;GET BEGINNING OF PATTERNS
3067 020632          TRAP C$BSEG          ;****START OF SEGMENT****
3068 020632 104404          1$:
3069 020634          MOV #1776,@RLCS          ;SET ALL SETTABLE BITS
3070 020634 012777 001776 161336  MOV #1776,GDDAT          ;SET UP EXPECT DATA IN
3071 020642 012737 001776 002306  BIC (R3),GDDAT          ;GDDAT
3072 020650 041337 002306          BIC (R3),@RLCS          ;CLEAR BITS IN RLCS VIA "BIC"
3073 020654 041377 161320          BIT #DERR,@RLCS          ;IF DRIVE ERROR BIT SET
3074 020660 032777 040000 161312  BEQ 99$          ;EXPECT IT SET WHEN WE
3075 020666 001403          BIS #ERR!DERR,GDDAT          ;READ IT BACK
3076 020670 052737 140000 002306  99$: MOV @RLCS,BDDAT          ;MOVE RLCS TO BDDAT FOR COMPARE
3077 020676 017737 161276 002310  BIC #DRDY,BDDAT          ;CLEAR DRIVE READY
3078 020704 042737 000001 002310  CMP BDDAT,GDDAT          ;DID "BIC" WORK PROPERLY
3079 020712 023737 002310 002306  BEQ 2$             ;BRANCH IF OKAY
3080 020720 001404
3081
3082 020722          ERRDF 8,EM62,ERR2          ;WRONG DATA IN RLCS
3083 020722 104455          TRAP C$ERDF
3084 020724 000010          .WORD 8
3085 020726 010412          .WORD EM62
3086 020730 011662          .WORD ERR2
3087 020732          2$: ESCAPE SEG          ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
3088 020732 104410          TRAP C$ESCAPE

```

```
3089 020734 000012 .WORD 10000$-.
3090
3091 020736 005723 TST (R3)+ ;GET NEXT PATTERN
3092 020740 020327 003256 CMP R3,#CSEND ;AT END OF LIST
3093 020744 001333 BNE 1$ ;NO, GO BACK WITH NEXT PATTERN
3094 020746 ENDSEG ;****END OF SEGMENT****
3095 020746 10000$:
3096 020746 104405 TRAP C$ESEG
3097 020750 ENDTST ;****END OF TEST****
3098 020750 L10042:
3099 020750 104401 TRAP C$ETST
3100
3101
3102 .SBTTL **TEST 17** - BIS OF RLBA
3103
3104 020752 BGNST ;****START OF TEST****
3105
3106 020752 STARS
3107 ;*****
3108 ;TEST THAT THE 'BIS' INSTRUCTION WILL WORK ON THE BUS
3109 ;ADDRESS REGISTER. BITS 15-0 ARE LOADED, ONLY BITS 15-1
3110 ;ARE EXPECTED BACK. FOUR PATTERNS ARE USED: GROWING 1, SHIFTING 1,
3111 ;GROWING 0, AND SHIFTING 0.
3112 020752 STARS
3113 ;*****
3114
3115
3116 020752 012703 002564 BGNSEG MOV #BEGPAT,R3 ;GET START OF LIST
3117 020756 TRAP C$BSEG ;****START OF SEGMENT****
3118 020756 104404 1$:
3119 020760 CLR @RLBA ;CLEAR 'BA'
3120 020760 005077 161216 MOV (R3),GDDAT ;SET EXPECTED
3121 020764 011337 002306 TST T.CNTR ;RL11
3122 020770 005737 002332 BEQ 3$ ;NO
3123 020774 001403 BIC #1,GDDAT ;BIT 0 CAN'T SET IN RLBA (UNIBUS)
3124 020776 042737 000001 002306 BIS (R3),@RLBA ;BIS RLBA WITH PATTERN
3125 021004 051377 161172 MOV @RLBA,BDDAT ;READ 'BA'
3126 021010 017737 161166 002310 CMP BDDAT,GDDAT ;DID RLBA LOAD PROPERLY?
3127 021016 023737 002310 002306 BEQ 2$ ;BRANCH IF YES
3128 021024 001404
3129
3130 021026 ERRDF 9,EM63,ERR2 ;WRONG DATA IN RLBA
3131 021026 104455 TRAP C$ERRDF
3132 021030 000011 .WORD 9
3133 021032 010475 .WORD EM63
3134 021034 011662 .WORD ERR2
3135 021036 2$: ESCAPE SEG ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
3136 021036 104410 TRAP C$ESCAPE
3137 021040 000012 .WORD 10000$-.
3138
3139 021042 005723 TST (R3)+ ;GET NEXT PATTERN
3140 021044 020327 002772 CMP R3,#ENDPAT ;DID WE COMPLETE LIST
3141 021050 001343 BNE 1$ ;NO, GO BACK FOR NEXT.
3142 021052 ENDSEG ;****END OF SEGMENT****
3143 021052 10000$:
3144 021052 104405 TRAP C$ESEG
```

```
3145 021054          ENDTST          ;****END OF TEST****
3146 021054          L10043:
3147 021054 104401   TRAP      C$ETST
3148
3149
3150          .SBTTL  **TEST 18** - BIC OF RLBA
3151
3152 021056          BGNTST          ;****START OF TEST****
3153
3154 021056          STARS
3155          ;:*****
3156          ;TEST THAT THE "BIC" INSTRUCTION WILL WORK ON THE BUS
3157          ;ADDRESS REGISTER. BITS 15-1 ARE TESTED WITH 4 PATTERNS
3158          ;GROWING 1, SHIFTING 1, GROWING 0 AND SHIFTING 0.
3159 021056          STARS
3160          ;:*****
3161
3162
3163 021056 012703 002564 BGNSEG  MOV      #BEGPAT,R3      ;GET START OF LIST
3164 021062          TRAP      C$BSEG      ;****START OF SEGMENT****
3165 021062 104404   1$:
3166 021064          MOV      #-2,@RLBA      ;SET RLBA TO ALL 1'S (BIT 0=0)
3167 021064 012777 177776 161110  MOV      #-2,GDDAT      ;SET UP EXPECTED RESULTS
3168 021072 012737 177776 002306  BIC      (R3),GDDAT      ;IN GDDAT
3169 021100 041337 002306          BIC      (R3),@RLBA      ;BIC RLBA
3170 021104 041377 161072          MOV      @RLBA,BDDAT      ;READ RLBA
3171 021110 017737 161066 002310  CMP      BDDAT,GDDAT      ;BIC WORK OKAY?
3172 021116 023737 002310 002306  BEQ      2$              ;IF YES BRANCH
3173 021124 001404
3174
3175 021126          ERRDF  10.,EM64,ERR2      ;WRONG DATA IN RLBA
3176 021126 104455   TRAP      C$ERDF
3177 021130 000012   .WORD    10
3178 021132 010556   .WORD    EM64
3179 021134 011662   .WORD    ERR2
3180 021136          2$:  ESCAPE  SEG      ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
3181 021136 174410   TRAP      C$ESCAPE
3182 021140 000012   .WORD    10000$-.
3183
3184 021142 005723          TST      (R3)+          ;GET NEXT PATTERN
3185 021144 020327 002772  CMP      R3,#ENDPAT      ;HAVE WE COMPLETED LIST
3186 021150 001345          BNE      1$              ;NO, GO BACK FOR NEXT
3187 021152          ENDSEG  10000$:
3188 021152          TRAP      C$ESEG      ;****END OF SEGMENT****
3189 021152 104405
3190 021154          ENDTST          ;****END OF TEST****
3191 021154          L10044:
3192 021154 104401   TRAP      C$ETST
3193
3194
3195          .SBTTL  **TEST 19** - BIS OF RLDA
3196
3197 021156          BGNTST          ;****START OF TEST****
3198
3199 021156          STARS
3200          ;:*****
```

```

3201
3202
3203
3204 021156
3205
3206
3207
3208 021156 012703 002564
3209 021162
3210 021162 104404
3211 021164
3212 021164 005077 161014
3213 021170 011337 002306
3214 021174 051377 161004
3215 021200 017737 161000 002310
3216 021206 023737 002310 002306
3217 021214 001404
3218
3219 021216
3220 021216 104455
3221 021220 000013
3222 021222 010641
3223 021224 011662
3224 021226
3225 021226 104410
3226 021230 000012
3227
3228 021232 005723
3229 021234 020327 002772
3230 021240 001351
3231 021242
3232 021242
3233 021242 104405
3234 021244
3235 021244
3236 021244 104401
3237
3238
3239
3240
3241 021246
3242
3243 021246
3244
3245
3246
3247
3248 021246
3249
3250
3251
3252 021246 012703 002564
3253 021252
3254 021252 104404
3255 021254
3256 021254 012777 177777 160722

```

```

:TEST THAT THE 'BIS' INSTRUCTION WILL WORK ON THE DISK ADDRESS
:REGISTER. BITS 15-0 ARE TESTED WITH 4 PATTERNS, GROWING 1,
:SHIFTING 1, GROWING 0, AND SHIFTING 0.
STARS
:*****

```

```

BGNSEG MOV #BEGPAT,R3 ;GET START OF LIST
;*****START OF SEGMENT****
TRAP C$BSEG
1$: CLR @RLDA ;CLEAR 'DA'
MOV (R3),GDDAT ;SET EXPECTED
BIS (R3),@RLDA ;BIS RLDA
MOV @RLDA,BDDAT ;READ RLDA
CMP BDDAT,GDDAT ;IS RLDA CORRECT
BEQ 2$ ;IF OKAY BRANCH
ERRDF 11,EM65,ERR2 ;WRONG DATA IN RLDA
TRAP C$ERDF
.WORD 11
.WORD EM65
.WORD ERR2
2$: ESCAPE SEG ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
TRAP C$ESCAPE
.WORD 10000$-.
TST (R3)+ ;GET NEXT PATTERN
CMP R3,#ENDPAT ;HAVE WE FINISHED?
BNE 1$ ;NO GO BACK
ENDSEG ;*****END OF SEGMENT****
10000$: TRAP C$ESEG
ENDTST ;*****END OF TEST****
L10045: TRAP C$ETST

```

.SBTTL **TEST 20** - BIC OF RLDA

```

BGNST ;*****START OF TEST****
STARS
:*****
:TEST THAT THE 'BIC' INSTRUCTION WORKS ON THE DISK
:ADDRESS REGISTER. ALL BITS ARE TESTED WITH FOUR
:PATTERNS: GROWING 1, SHIFTING 1, GROWING 0 AND SHIFTING 0
STARS
:*****

```

```

BGNSEG MOV #BEGPAT,R3 ;GET START OF LIST
;*****START OF SEGMENT****
TRAP C$BSEG
1$: MOV #-1,@RLDA ;SET RLDA TO ALL 1'S

```

```

3257 021262 012737 177777 002306      MOV    #-1,GDDAT      ;SET EXPECTED DATA
3258 021270 041337 002306      BIC    (R3),GDDAT     ;SET EXPECTED DATA
3259 021274 041377 160704      BIC    (R3),@RLDA     ;"BIC" RLDA
3260 021300 017737 160700 002310      MOV    @RLDA,BDDAT    ;READ RLDA
3261 021306 023737 002306 002310      CMP    GDDAT,BDDAT    ;DID "BIC" WORK?
3262 021314 001404      BEQ    2$             ;IF IT DID BRANCH
3263
3264 021316      ERRDF  12.,EM66,ERR2  ;WRONG DATA IN RLDA
3265 021316 104455      TRAP  C$ERDF
3266 021320 000014      .WORD 12
3267 021322 010722      .WORD EM66
3268 021324 011662      .WORD ERR2
3269 021326      2$:  ESCAPE  SEG      ;IF /FL:LOE SET LOOP, ELSE EXIT SEG
3270 021326 104410      TRAP  C$ESCAPE
3271 021330 000012      .WORD 10000$-
3272
3273 021332 005723      TST    (R3)+          ;GET NEXT PATTERN
3274 021334 020327 002772      CMP    R3,#ENDPAT    ;DONE?
3275 021340 001345      BNE    1$             ;NO GO BACK
3276 021342      ENDSEG 10000$:      ;****END OF SEGMENT****
3277 021342
3278 021342 104405      TRAP  C$ESEG
3279 021344      ENDTST L10046:      ;****END OF TEST****
3280 021344
3281 021344 104401      TRAP  C$ETST
3282
3283
3284      .SBTTL **TEST 21** - BUS RESET OF RLCS
3285
3286 021346      BGNTST              ;****START OF TEST****
3287
3288 021346      STARS
3289      :*****
3290      :TEST THAT A BUS RESET WILL CLEAR THE PROPER BITS
3291      :OF THE CONTROL AND STATUS REGISTER. THOSE BITS ARE
3292      :BITS 6-1,8,9,10,11,12,13,15. BIT 15 WILL CLEAR ONLY
3293      :IF BIT 14 (DRIVE ERROR IS NOT SET). BIT 0 (DRIVE READY)
3294      :IS A DON'T CARE. IF AT THE START UP THIS TEST BIT
3295      :14 (DRIVE ERROR) IS SET WE WILL INSIST IF IS THERE AFTER
3296      :THE "RESET" ALONG WITH BIT 15 (COMPOSITE ERROR). BITS
3297      :15-10 ARE NOT WRITEABLE.
3298 021346      STARS
3299      :*****
3300
3301
3302 021346      SETPRI #PRI07      ;PRIORITY TO SEVEN
3303 021346 012700 000340      MOV    #PRI07,R0
3304 021352 104441      TRAP  C$SPRI
3305 021354 012777 000377 160616      MOV    #377,@RLCS    ;LOAD ALL RLCS LOADABLE BITS
3306 021362 012737 000200 002306      MOV    #CRDY,GDDAT    ;SETUP EXPECTED
3307 021370 032777 040000 160602      BIT    #DERR,@RLCS    ;DRIVE ERR SET?
3308 021376 001403      BEQ    1$             ;IF NOT DON'T EXPECT IT
3309 021400 052737 140000 002306      BIS    #DERR!ERR,GDDAT ;IT'S SET, INIT BETTER NOT CLR
3310 021406 012700 000100      1$:  MOV    #100,R0      ;SET UP A WAIT LOOP
3311 021412      BRESET
3312 021412 104433      TRAP  C$RESET

```

```

3313 021414 005300      2$:  DEC      RO      :WAIT IN CASE OF DRIVE ERROR
3314 021416 001376      BNE      2$      :
3315 021420 017737 160554 0J2310  MOV      @RLCS,BDDAT :READ RLCS
3316 021426 042737 000001 0J2310  BIC      #DRDY,BDDAT :CLEAR OUT DRDY - DON'T CARE
3317 021434 023737 002310 502306  CMP      BDDAT,GDDAT :DID INIT WORK
3318 021442 001404      BEQ      3$      :YES, BRANCH

```

```

3319
3320 021444      ERRDF    13.,EM67,ERR2 :WRONG DATA IN RLCS
3321 021444 104455      TRAP    C$ERDF
3322 021446 000015      .WORD   13
3323 021450 011005      .WORD   EM67
3324 021452 011662      .WORD   ERR2

```

```

3325 021454      3$:
3326 021454      ENDTST      :*****END OF TEST****
3327 021454      L10047:
3328 021454 104401      TRAP    C$ETST

```

```

3329
3330
3331      .SBTTL  **TEST 22** - BUS RESET OF RLBA
3332
3333 021456      BGNTST      :*****START OF TEST****

```

```

3334
3335 021456      STARS
3336      :*****
3337      :TEST THAT A BUS RESET WILL CLEAR THE ENTIRE
3338      :BUS ADDRESS REGISTER. THE BUS ADDRESS IS LOADED WITH 177776
3339      :AND IS EXPECTED TO BE ZERO AFTER THE RESET
3340 021456      STARS
3341      :*****

```

```

3342
3343
3344 021456 012777 177776 160516  MOV      #-2,@RLBA  :SET BA TO ALL 1'S
3345 021464 005737 002332      TST      T.CNTRL    :RL11??
3346 021470 001403      BEQ      2$      :NO

```

```

3347 021472 052777 000001 160502  BIS      #1,@RLBA
3348 021500 005037 002306      2$:  CLR      GDDAT      :CLEAR EXPECTED DATA
3349 021504      BRESET      :ISSUE BUS INIT
3350 021504 104433      TRAP    C$RESET
3351 021506 017737 160470 002310  MOV      @RLBA,BDDAT :READ RLBA
3352 021514 001404      BEQ      1$      :IF CLEAR BRANCH

```

```

3353
3354 021516      ERRDF    14.,EM70,ERR2 :WRONG DATA IN RLBA
3355 021516 104455      TRAP    C$ERDF
3356 021520 000016      .WORD   14
3357 021522 011042      .WORD   EM70
3358 021524 011662      .WORD   ERR2

```

```

3359 021526      1$:
3360
3361 021526      ENDTST      :*****END OF TEST****
3362 021526      L10050:
3363 021526 104401      TRAP    C$ETST

```

```

3364
3365
3366      .SBTTL  **TEST 23** - BUS RESET OF RLDA
3367
3368 021530      BGNTST      :*****START OF TEST****

```

```

3369
3370 021530 STARS
3371 :*****
3372 :TEST THAT A BUS RESET WILL CLEAR THE ENTIRE
3373 :DISK ADDRESS REGISTER. THE DISK ADDRESS IS LOADED WITH 177777
3374 :AND IS EXPECTED TO BE ZERO AFTER THE RESET.
3375 021530 STARS
3376 :*****
3377
3378
3379 021530 012777 177777 160446 MOV #-1,@RLDA ;SET DA TO ALL 1'S
3380 021536 005037 002306 CLR GDDAT ;CLEAR EXPECTED
3381 021542 BRESET ;ISSUE BUS INIT
3382 021542 104433 TRAP C$RESET
3383 021544 017737 160434 002310 MOV @RLDA,BDDAT ;READ RLDA
3384 021552 001404 BEQ 1$ ;IF CLEAR BRANCH
3385
3386 021554 ERRDF 15,EM71,ERR2 ;WRONG DATA IN RLDA
3387 021554 104455 TRAP C$ERDF
3388 021556 000017 .WORD 15
3389 021560 011077 .WORD EM71
3390 021562 011662 .WORD ERR2
3391 021564 1$:
3392
3393 021564 ENDTST ;****END OF TEST****
3394 021564 L10051:
3395 021564 104401 TRAP C$ETST
3396
3397
3398 .SBTTL **TEST 24** - UNIQUENESS OF RLCS
3399
3400 021566 BGNTST ;****START OF TEST****
3401
3402 021566 STARS
3403 :*****
3404 :TEST THE UNIQUENESS OF THE CONTROL AND STATUS
3405 :REGISTER. THE RLBA AND RLDA ARE PRELOADED WITH
3406 :177776 AND 177777 RESPECTIVELY. THE RLCS IS THEN
3407 :LOADED TO INSURE THAT NEITHER THE RLBA OR RLDA
3408 :ARE MODIFIED BY THE WRITING OF THE RLCS.
3409 021566 STARS
3410 :*****
3411
3412
3413 021566 012737 000201 002252 MOV #DRDY!CRDY,LDCSR ;SET DRIVE AND CONTROLLER READY
3414 021574 012777 177776 160400 MOV #-2,@RLBA ;SET RLBA TO ALL 1'S
3415 021602 012777 177777 160374 MOV #-1,@RLDA ;SET RLDA TO ALL 1'S
3416 021610 013777 002252 160362 MOV LDCSR,@RLCS ;WRITE RLCS
3417
3418 ;CHECK THAT RLBA REMAINED UNEFFECTED
3419
3420 021616 022777 177776 160356 CMP #-2,@RLBA ;RLBA OKAY?
3421 021624 001412 BEQ 1$ ;YES, GO CHECK DA
3422
3423 021626 012737 177776 002306 MOV #-2,GDDAT ;SET UP EXPECTED
3424 021634 017737 160342 002310 MOV @RLBA,BDDAT ;READ RLBA
  
```



```

3425
3426 021642          ERRDF 16.,EM72,ERR2 ;CS MODIFIED BA
3427 021642 104455   TRAP  C$ERDF
3428 021644 000020   .WORD 16
3429 021646 011134   .WORD EM72
3430 021650 011662   .WORD ERR2
3431 021652          1$: CKLOOP
3432 021652 104406   TRAP  C$CLP1 ;CHECK IF /FL:LOE IS SET
3433
3434 021654 022777 177777 160322   CMP  #-1,@RLDA ;RLDA OKAY?
3435 021662 001412   BEQ  2$ ;YES, CONTINUE
3436
3437 021664 012737 177777 002306   MOV  #-1,GDDAT ;SET UP EXPECTED
3438 021672 017737 160306 002310   MOV  @RLDA,BDDAT ;READ DA
3439
3440 021700          ERRDF 17.,EM73,ERR2 ;CS MODIFIED DA
3441 021700 104455   TRAP  C$ERDF
3442 021702 000021   .WORD 17
3443 021704 011167   .WORD EM73
3444 021706 011662   .WORD ERR2
3445 021710          2$:
3446
3447
3448 021710          ENDTST ;*****END OF TEST*****
3449 021710          L10052:
3450 021710 104401   TRAP  C$ETST
3451
3452
3453          .SBTTL **TEST 25** - UNIQUENESS OF RLBA
3454
3455 021712          BGNST ;*****START OF TEST*****
3456 021712          STARS
3457          ;*****
3458          ;TEST THE UNIQUENESS OF THE BUS ADDRESS REGISTER. THE
3459          ;RLCS AND RLDA ARE LOADED WITH XXX20X AND 177777
3460          ;RESPECTIVELY. THE RLBA IS THEN WRITTEN TO INSURE
3461          ;THAT NEITHER THE RLCS OR RLDA ARE MODIFIED
3462          ;BY WRITING THE RLBA.
3463 021712          STARS
3464          ;*****
3465
3466
3467 021712 012737 000200 002306   MOV  #CRDY,GDDAT ;CONTROLLER READY
3468 021720 032777 040000 160252   BIT  #DERR,@RLCS ;IF DRIVE ERROR IS
3469 021726 001403   BEQ  99$ ;SET THEN EXPECT IT
3470 021730 052737 140000 002306   BIS  #ERR!DERR,GDDAT ;SET WHEN WE READ IT.
3471 021736 013777 002306 160234 99$: MOV  GDDAT,@RLCS ;LOAD RLCS
3472 021744 012777 177777 160232   MOV  #-1,@RLDA ;LOAD RLDA
3473 021752 005077 160224   CLR  @RLBA ;CLEAR RLBA
3474
3475          ;CHECK IF RLCS IS OKAY
3476
3477 021756 017737 160216 002310   MOV  @RLCS,BDDAT ;READ RLCS
3478 021764 042737 000001 002310   BIC  #DRDY,BDDAT ;IGNORE DRIVE READY
3479 021772 023737 002310 002306   CMP  BDDAT,GDDAT ;CS OK?
3480 022000 001404   BEQ  1$ ;YES, GO CHECK DA
  
```

```

3481
3482 022002          ERRDF 18,EM74,ERR2  :BA MODIFIED CS
3483 022002 104455   TRAP  C$ERDF
3484 022004 000022   .WORD 18
3485 022006 011222   .WORD EM74
3486 022010 011662   .WORD ERR2
3487 022012          1$: CKLOOP          :CHECK IF /FL:LOE IS SET
3488 022012 104406   TRAP  C$CLP1
3489
3490 022014 022777 177777 160162  CMP    #-1,@RLDA  :IS RLDA OKAY?
3491
3492 022022 001412   BEQ    2$          :IF OKAY BRANCH
3493
3494 022024 012737 177777 002306  MOV    #-1,GDDAT  :SET UP EXPECTED
3495 022032 017737 160146 002310  MOV    @RLDA,BDDAT :READ RLDA
3496
3497 022040          ERRDF 19,EM75,ERR2  :BA MODIFIED DA
3498 022040 104455   TRAP  C$ERDF
3499 022042 000023   .WORD 19
3500 022044 011254   .WORD EM75
3501 022046 011662   .WORD ERR2
3502 022050          2$:
3503 022050          ENDTST
3504 022050          L10053:
3505 022050 104401   TRAP  C$ETST
3506
3507
3508          .SBTTL **TEST 26** - UNIQUENESS OF RLDA
3509
3510 022052          BGNTST          :****START OF TEST****
3511
3512
3513 022052          STARS
3514          :*****
3515          :TEST THE UNIQUENESS OF THE DISK ADDRESS REGISTER. THE RLCS
3516          :AND RLBA ARE LOADED WITH XXX20X AND 177776
3517          :RESPECTIVELY. THE RLDA IS THEN WRITTEN TO INSURE
3518          :THAT NEITHER THE RLCS OR THE RLBA ARE MODIFIED
3519          :BY WRITING THE RLDA.
3520 022052          STARS
3521          :*****
3522
3523
3524 022052 012737 000200 002306  MOV    #CRDY,GDDAT  :CONTROLLER READY
3525 022060 032777 040000 160112  BIT    #DERR,@RLCS  :IF DRIVE ERROR SET
3526 022066 001403   BEQ    99$          :THEN EXPECT IT LATER
3527 022070 052737 140000 002306  BIS    #ERR!DERR,GDDAT
3528 022076 013777 002306 160074  99$: MOV    GDDAT,@RLCS  :LOAD CS
3529 022104 012777 177776 160070  MOV    #-2,@RLBA   :LOAD BA WITH ALL 1'S
3530 022112 005077 160066   CLR    @RLDA       :CLEAR RLDA
3531
3532          :CHECK IF RLCS IS OKAY
3533
3534 022116 017737 160056 002310  MOV    @RLCS,BDDAT  :READ RLCS
3535 022124 042737 000001 002310  BIC    #DRDY,BDDAT  :IGNORE DRIVE READY
3536 022132 023737 002306 002310  CMP    GDDAT,BDDAT  :RLCS OKAY?
  
```

```

3537 022140 001404      BEQ      1$          ;YES, THEN BRANCH
3538
3539 022142              ERRDF    20,EM76,ERR2 ;DA MODIFIED CS
3540 022142 104455      TRAP    C$ERDF
3541 022144 000024      .WORD   20
3542 022146 L 306             .WORD   EM76
3543 022150 011662      .WORD   ERR2
3544 022152              1$:      CKLOOP
3545 022152 104406      TRAP    C$CLP1      ;CHECK IF /FL:LOE IS SET
3546
3547 022154 022777 177776 160020      CMP     #-2,@RLBA    ;IS RLBA OKAY?
3548 022162 001412      BEQ     2$          ;BRANCH IF OKAY
3549
3550 022164 012737 177776 002306      MOV     #-2,GDDAT    ;SET UP EXPECTED
3551 022172 017737 160004 002310      MOV     @RLBA,BDDAT ;READ RLBA
3552
3553 022200              ERRDF    21,EM77,ERR2 ;DA MODIFIED BA
3554 022200 104455      TRAP    C$ERDF
3555 022202 000025      .WORD   21
3556 022204 011341      .WORD   EM77
3557 022206 011662      .WORD   ERR2
3558 022210              2$:
3559
3560
3561 022210      ENDTST
3562 022210      L10054:          ;****END OF TEST****
3563 022210 104401      TRAP    C$ETST
3564
3565      .SBTTL **TEST 27** - UNIQUENESS OF RLMP
3566
3567 022212      BGNTST          ;****START OF TEST****
3568
3569
3570 022212      STARS
3571      ;:*****
3572      ;TEST THE UNIQUENESS OF THE MULTI-PURPOSE REGISTER
3573      ;WE WILL WRITE THE RLCS, RLBA, AND THE RLDA, THEN THE
3574      ;RLMP IS WRITTEN. WE THEN GO BACK AN VERIFY THE CONTENTS
3575      ;OF THE RLCS, RLBA, RLDA.
3576 022212      STARS
3577      ;:*****
3578
3579
3580 022212 012737 000200 002306      MOV     #CRDY,GDDAT ;CONTROLLER READY
3581 022220 032777 040000 157752      BIT     #DERR,@RLCS ;IF DRIVE ERROR SET
3582 022226 001403      BEQ     99$        ;THE EXPECT IT LATER
3583 022230 052737 140000 002306      BIS     #ERR!DERR,GDDAT
3584 022236 013777 002306 157734      99$:   MOV     GDDAT,@RLCS ;LOAD CS
3585 022244 012777 177776 157730      MOV     #-2,@RLBA  ;LOAD BA WITH ALL 1'S
3586 022252 012777 177777 157724      MOV     #-1,@RLDA  ;LOAD RLDA
3587 022260 005077 157722      CLR     @RLMP      ;WRITE RLMP
3588
3589      ;CHECK IF RLCS IS OKAY
3590
3591 022264 017737 157710 002310      MOV     @RLCS,BDDAT ;READ RLCS
3592 022272 042737 000001 002310      BIC     #DRDY,BDDAT ;IGNORE DRIVE READY
  
```

```

3593 022300 023737 002306 002310      CMP      GDDAT,BDDAT      :RLCS OKAY?
3594 022306 001404                      BEQ      1$              :YES, THEN BRANCH
3595
3596 022310                      ERRDF    22.,EM44,ERR2   :MP MODIFIED CS
3597 022310 104455                      TRAP    C$ERDF
3598 022312 000026                      .WORD   22
3599 022314 010210                      .WORD   EM44
3600 022316 011662                      .WORD   ERR2
3601 022320                      1$:    CKLOOP
3602 022320 104406                      TRAP    C$CLP1          :CHECK IF /FL:LOE IS SET
3603
3604 022322 022777 177776 157652      CMP      #-2,@RLBA      :IS RLBA OKAY?
3605 022330 001412                      BEQ      2$              :BRANCH IF OKAY
3606
3607 022332 012737 177776 002306      MOV      #-2,GDDAT      :SET UP EXPECTED
3608 022340 017737 157636 002310      MOV      @RLBA,BDDAT    :READ RLBA
3609
3610 022346                      ERRDF    23.,EM45,ERR2   :MP MODIFIED BA
3611 022346 104455                      TRAP    C$ERDF
3612 022350 000027                      .WORD   23
3613 022352 010243                      .WORD   EM45
3614 022354 011662                      .WORD   ERR2
3615 022356                      2$:    CKLOOP
3616 022356 104406                      TRAP    C$CLP1          :CHECK IF /FL:LOE IS SET
3617 022360 022777 177777 157616      CMP      #-1,@RLDA      :DISK ADDRESS OKAY
3618 022366 001412                      BEQ      3$              :YES, CONTINUE
3619
3620 022370 017737 157610 002310      MOV      @RLDA,BDDAT    :SET UP BAD
3621 022376 012737 177777 002306      MOV      #-1,GDDAT      :SET UP EXPECTED
3622
3623 022404                      ERRDF    24.,EM46,ERR2   :MP MODIFIED DA
3624 022404 104455                      TRAP    C$ERDF
3625 022406 000030                      .WORD   24
3626 022410 010276                      .WORD   EM46
3627 022412 011662                      .WORD   ERR2
3628
3629 022414                      3$:
3630
3631
3632 022414                      ENDTST
3633 022414                      L10055:
3634 022414 104401                      TRAP    C$ETST
3635
3636
3637
3638
3639                      .SBTTL  **TEST 28** - RLV11 MAINT. FORCED OPI TEST,LESS THAN 510 WORDS
3640
3641 022416                      BGNTST
3642
3643 022416                      STARS
3644                      :*****
3645                      :PERFORM RLV11 MAINTENANCE FUNCTION 0 WITH LESS THAN 510 WORDS
3646                      :TO FORCE OPI ERROR. THE TEST SHOULD FORCE COMPOSITE ERROR(BIT 15),
3647                      :HEADER NOT FOUND(BIT12) AND OPI(BIT 10). DRIVE ERROR IS IGNORED.
3648 022416                      STARS
  
```

```
3649 ;:*****
3650 022416 005737 002332 TST T.CNTRL ;RLV11?
3651 022422 001040 BNE 10$ ;NO,EXIT TEST
3652 022424 012703 002774 1$: MOV #PATCRC,R3 ;GET CRC PATTERN TABLE
3653 022430 012704 003066 MOV #PATDAT,R4 ;GET DATA PATTERN TABLE
3654 022434 011337 022450 MOV (R3),2$ ;STORE CRC PATTERN
3655 022440 011437 022456 MOV (R4),3$ ;STORE DATA PATTERN
3656 022444 004537 015514 JSR R5,CALCRC ;CALCULATE CRC BEFORE TEST
3657 022450 000000 .WORD 0
3658 022452 004537 015752 2$: JSR R5,SETPAT ;SETUP PATTERN BEFORE TEST
3659 022456 000000 3$: .WORD 0
3660 022460 BGNSEG
3661 022460 104404 TRAP C$BSEG
3662 022462 004537 016114 JSR R5,LDFUN ;PERFORM MAINT FUNCTION
3663 022466 000000 MAINT
3664 022470 177271 -507 ;LESS THAN 510 WORDS
3665 022472 006324 MATMES ;MAINT. MESSAGE
3666 022474 004537 016724 JSR R5,WTCRDY
3667 022500 CKLOOP ;LOOP SWITCH
3668 022500 104406 TRAP C$CLP1
3669 022502 004537 015324 JSR R5,CHKOPI ;CHECK FOR EXPECTED ERRORS
3670 022506 000404 BR 4$ ;EXPECTED ERRORS FOUND,EXIT TEST
3671 022510 ERRDF 30,EM27,ERR10
3672 022510 104455 TRAP C$ERDF
3673 022512 000036 .WORD 30
3674 022514 010037 .WORD EM27
3675 022516 012206 .WORD ERR10
3676 022520 4$: CKLOOP
3677 022520 104406 TRAP C$CLP1
3678 022522 ENDSEG
3679 022522 10000$: TRAP C$ESEG
3680 022522 104405 10$: TRAP C$ESEG
3681 022524
3682
3683 022524 ENDTST
3684 022524 L10056: TRAP C$ETST
3685 022524 104401
3686
3687 .SBTTL **TEST 29** - RLV11 MAINT. FORCED OPI TEST,MORE THAN 511 WORDS
3688
3689 022526 BGNTST ;****START OF TEST****
3690
3691 022526 STARS
3692 ;:*****
3693 ;PERFORM RLV11 MAINTENANCE FUNCTION 0 WITH MORE THAN 511 WORDS
3694 ;TO FORCE OPI ERROR. THE TEST SHOULD FORCE COMPOSITE ERROR(BIT 15),
3695 ;HEADER NOT FOUND(BIT12) AND OPI(BIT 10). DRIVE ERROR IS IGNORED.
3696 022526 STARS
3697 ;:*****
3698 022526 005737 002332 TST T.CNTRL ;RLV11?
3699 022532 001040 BNE 10$ ;NO,EXIT TEST
3700 022534 012703 002774 1$: MOV #PATCRC,R3 ;GET CRC PATTERN TABLE
3701 022540 012704 003066 MOV #PATDAT,R4 ;GET DATA PATTERN TABLE
3702 022544 011337 022560 MOV (R3),2$ ;STORE CRC PATTERN
3703 022550 011437 022566 MOV (R4),3$ ;STORE DATA PATTERN
3704 022554 004537 015514 JSR R5,CALCRC ;CALCULATE CRC BEFORE TEST
```

3705 022560 000000
3706 022562 004537 015752
3707 022566 000000
3708 022570
3709 022570 104404
3710 022572 004537 016114
3711 022576 000000
3712 022600 177266
3713 022602 006324
3714 022604 004537 016724
3715 022610
3716 022610 104406
3717 022612 004537 015324
3718 022616 000404
3719 022620
3720 022620 104455
3721 022622 000037
3722 022624 010113
3723 022626 012206
3724 022630
3725 022630 104406
3726 022632
3727 022632
3728 022632 104405
3729 022634
3730
3731 022634
3732 022634
3733 022634 104401
3734
3735
3736
3737 022636
3738
3739 022636
3740
3741
3742
3743
3744 022636
3745
3746
3747 022636 005737 002332
3748 022642 001052
3749 022644 012703 002774
3750 022650 012704 003066
3751 022654 011337 022670
3752 022660 011437 022676
3753 022664 004537 015514
3754 022670 000000
3755 022672 004537 015752
3756 022676 000000
3757 022700
3758 022700 104404
3759 022702
3760 022702 012700 000000

2\$: .WORD 0
JSR R5,SETPAT ;SETUP PATTERN BEFORE TEST
3\$: .WORD 0
BGNSEG
TRAP C\$BSEG
JSR R5,LDFUN ;PERFORM MAINT FUNCTION
MAINT
-512 ;MORE THAN 511 WORDS
MATMES ;MAINT. MESSAGE
JSR R5,WTCRDY
CKLOOP ;LOOP SWITCH
TRAP C\$CLP1
JSR R5,CHKOPI ;CHECK FOR EXPECTED ERRORS
BR 4\$;EXPECTED ERRORS FOUND,EXIT TEST
ERRDF 31.,EM30,ERR10
TRAP C\$ERDF
.WORD 31
.WORD EM30
.WORD ERR10
4\$: CKLOOP
TRAP C\$CLP1
ENDSEG
10000\$: TRAP C\$ESEG
10\$:
ENDTST
L10057: TRAP C\$ETST

.SBTTL **TEST 30** - RLV11 MAINT. FORCED OPI TEST - INTERRUPT MODE

BGNTST ;****START OF TEST****

STARS

:PERFORM TEST OF INTERRUPT BY ISSUING RLV11 MAINTENANCE FUNCTION 0
:WITH MORE THAN 511 WORDS TO FORCE OPI ERROR. CHECK INTERRUPT
:OPERATION AND REPORT IF ERROR OCCURS.
STARS

STARS

TST T.CNTRL ;RLV11?
BNE 10\$;NO,EXIT TEST
1\$: MOV #PATCRC,R3 ;GET CRC PATTERN TABLE
MOV #PATDAT,R4 ;GET DATA PATTERN TABLE
MOV (R3),2\$;STORE CRC PATTERN
MOV (R4),3\$;STORE DATA PATTERN
JSR R5,CALCRC ;CALCULATE CRC
2\$: .WORD 0
JSR R5,SETPAT ;SETUP PATTERN
3\$: .WORD 0
BGNSEG
TRAP C\$BSEG
SETPRI #PRI00 ;SET PRIORITY TO ZERO
MOV #PRI00,R0

```
3761 022706 104441 TRAP C$SPRI
3762 022710 005037 002250 CLR INTFLG ;CLEAR INT. FLAG
3763 022714 004537 016114 JSR R5, LDFUN
3764 022720 000100 MAINT!INTEN ;MAINT FUNCTION,INT DRIVEN
3765 022722 177266 -512 ;MORE THAN 511 TO FORCE OPI ERROR
3766 022724 006364 MATINT
3767 022726 004537 016724 JSR R5, WTCRDY ;WAIT FOR READY
3768 022732 CKLOOP
3769 022732 104406 TRAP C$CLP1
3770 022734 SETPRI #PRI07
3771 022734 012700 000340 MOV #PRI07, R0
3772 022740 104441 TRAP C$SPRI
3773 022742 005737 002250 TST INTFLG ;CHECK IF INTERRUPT OCCURRED
3774 022746 001004 BNE 4$
3775 022750 ERRDF 32, EM24, ERRO
3776 022750 104455 TRAP C$ERDF
3777 022752 000040 .WORD 32
3778 022754 007664 .WORD EM24
3779 022756 011632 .WORD ERRO
3780 022760 005037 002250 4$: CLR INTFLG ;CLEAR INT. FLAG
3781 022764 CKLOOP
3782 022764 104406 TRAP C$CLP1
3783 022766 ENDSEG
3784 022766 10000$:
3785 022766 104405 TRAP C$ESEG
3786 022770 10$:
3787 022770
3788 022770
3789 022770
3790 022770 104401 TRAP C$ETST
3791
3792
3793 .SBTTL **TEST 31** - RLV11 OPI TIMEOUT TEST
3794
3795 022772 BGNST ;START OF TEST
3796
3797 022772 STARS
3798 ;*****
3799 ;PERFORM RLV11 MAINTENANCE FUNCTION (0) WITH INTERRUPT MODE. FORCE
3800 ;OPI TIMEOUT BY SETTING WORD COUNT TO -512 WORDS. MEASURE OPI TIMEOUT
3801 ;AND COMPARE TO MIN. AND MAX. LIMITS.
3802 022772 STARS
3803 ;*****
3804
3805 022772 005737 002332 TST T.CNTRL ;RLV11?
3806 022776 001402 BEQ 1$ ;YES, PERFORM TEST
3807 023000 000137 023322 JMP 10$ ;RL11, EXIT TEST
3808 023004 012703 002774 1$: MOV #PATCRC, R3 ;GET CRC PATTERN TABLE
3809 023010 012704 003066 MOV #PATDAT, R4 ;GET DATA PATTERN TABLE
3810 023014 011337 023030 MOV (R3), 2$ ;STORE CRC PATTERN
3811 023020 011437 023036 MOV (R4), 3$ ;STORE DATA PATTERN
3812 023024 004537 015514 JSR R5, CALCRC ;CALCULATE CRC BEFORE TEST
3813 023030 000000 2$: .WORD 0
3814 023032 004537 015752 JSR R5, SETPAT ;SETUP PATTERN BEFORE TEST
3815 023036 000000 3$: .WORD 0
3816 023040 BGNSEG
```

3817	023040	104404				TRAP	C\$BSEG	
3818	023042					CLRVEC	BVEC	:CLEAR PRESENT INT. VECTOR
3819	023042	013700	002214			MOV	BVEC,R0	
3820	023046	104436				TRAP	C\$CVEC	
3821	023050					SETVEC	BVEC,#TIMSRV,#340	
3822	023050	012746	000340			MOV	#340,-(SP)	
3823	023054	012746	016652			MOV	#TIMSRV,-(SP)	
3824	023060	013746	002214			MOV	BVEC,-(SP)	
3825	023064	012746	000003			MOV	#3,-(SP)	
3826	023070	104437				TRAP	C\$SVEC	
3827	023072	062706	000010			ADD	#10,SP	
3828	023076	013737	002340	002310		MOV	OPIMX,BDDAT	:TAKE MAX LIMIT AND
3829	023104	005002				CLR	R2	:DIVIDE BY 10
3830	023106	162737	000012	002310	200\$:	SUB	#10.,BDDAT	:RESULT IN R2
3831	023114	100402				BMI	201\$:DONE DIVIDE?
3832	023116	005202				INC	R2	
3833	023120	000772				BR	200\$:NEXT DIVIDE
3834	023122				201\$:	SETPRI	#PRI00	:SETUP FOR WAIT ABORT
3835	023122	012700	000000			MOV	#PRI00,R0	
3836	023126	104441				TRAP	C\$SPRI	
3837	023130	005037	002250			CLR	INTFLG	:CLEAR INTERRUPT FLAG
3838	023134	005000				CLR	R0	:OPI COUNTER
3839	023136	004537	016114			JSR	R5,LDFUN	:PERFORM MAINT. FUNCTION
3840	023142	000100				MAINT!INTEN		:MAINT FUNCTION WITH INT.MODE
3841	023144	177266				-512		:WORD COUNT
3842	023146	006364				MATINT		:MAINT MESSAGE
3843	023150	004537	016032		100\$:	JSR	R5,WDELAY	:DELAY
3844	023154	000012				10.		:APPROX 10 MSECS
3845	023156	062700	000012			ADD	#10.,R0	:10 MSEC DELAY COUNTER
3846	023162	005737	002250			TST	INTFLG	:TEST INTERRUPT FLAG
3847	023166	001002				BNE	110\$:CHECK TIMER IF INTFLG = 1
3848	023170	005302				DEC	R2	:DONE WITH MAX DELAY?
3849	023172	001366				BNE	100\$:DO ANOTHER DELAY
3850	023174	010037	002310		110\$:	MOV	R0,BDDAT	:STORE RESULT
3851	023200	005737	002250			TST	INTFLG	:CHECK INT. FLG
3852	023204	001004				BNE	4\$	
3853	023206					ERRDF	33.,EM24,ERRO	:ERROR ON INTERRUPT
3854	023206	104455				TRAP	C\$ERDF	
3855	023210	000041				.WORD	33	
3856	023212	007664				.WORD	EM24	
3857	023214	011632				.WORD	ERRO	
3858	023216	005037	002250		4\$:	CLR	INTFLG	
3859	023222					CKLOOP		
3860	023222	104406				TRAP	C\$CLP1	
3861								
3862								:CHECK THAT OPI IS WITHIN LIMITS
3863								
3864	023224				7\$:	SETPRI	#PRI07	
3865	023224	012700	000340			MOV	#PRI07,R0	
3866	023230	104441				TRAP	C\$SPRI	
3867	023232	023737	002340	002310		CMP	OPIMX,BDDAT	:IS OPI WITHIN LIMITS
3868	023240	002404				BLT	8\$:NO,REPORT ERROR
3869	023242	023737	002336	002310		CMP	OPIMN,BDDAT	:WITHIN LIMITS?
3870	023250	003404				BLE	9\$:YES
3871	023252				8\$:	ERRDF	34.,EM31,ERR11	:OPI TIMING INCORRECT
3872	023252	104455				TRAP	C\$ERDF	

3873 023254 000042
3874 023256 010167
3875 023260 012250
3876 023262
3877 023262 104406
3878 023264
3879 023264 013700 002214
3880 023270 104436
3881 023272
3882 023272 012746 000340
3883 023276 012746 016644
3884 023302 013746 002214
3885 023306 012746 000003
3886 023312 104437
3887 023314 062706 000010
3888 023320
3889 023320
3890 023320 104405
3891 023322
3892
3893 023322
3894 023322
3895 023322 104401
3896
3897
3898
3899
3900 023324
3901
3902 023324
3903
3904
3905
3906
3907
3908
3909
3910
3911
3912 023324
3913
3914 023324 005737 002332
3915 023330 001402
3916 023332 000137 024134
3917 023336 012703 002774
3918 023342 012737 003066 002352
3919 023350 011337 023366
3920 023354 017737 156772 023376
3921 023362 004537 015514
3922 023366 000000
3923 023370
3924 023370 104404
3925 023372 004537 015752
3926 023376 000000
3927 023400 004537 016114
3928 023404 000000

9\$: .WORD 34
.WORD EM31
.WORD ERR11
CKLOOP
TRAP C\$CLP1
CLRVEC BVEC ;CLEAR PRESENT VECTOR AND RESET OLD
MOV BVEC,RO
TRAP C\$CVEC
SETVEC BVEC,#INTSRV,#340
MOV #340,-(SP)
MOV #INTSRV,-(SP)
MOV BVEC,-(SP)
MOV #3,-(SP)
TRAP C\$SVEC
ADD #10,SP
ENDSEG
10000\$: TRAP C\$ESEG
10\$:
ENDTST
L10061: TRAP C\$ETST

.SBTTL **TEST 32** - TEST RLV11 MAINT. FUNCTION - FLAG MODE

BGNTST ;****START OF TEST****

STARS

:PERFORM RLV11 MAINTENANCE FUNCTION 0 IN FLAG MODE AND CHECK
:FOR PROPER INCREMENT OF THE DA AND BA REGISTERS. CHECK THE SERIAL
:WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER
:THE CRC OF DA+3 AND THE CRC OF CRC OF DA+4 AND COMPARING WITH EXPECTED
:RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE
:FIFO INTO BUF2 MEMORY FOR PROPER DATA.
:CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR
:A VALUE:123456 TO INSURE THAT THE TRANSFER WAS NOT MORE THAN 255 WORDS.
STARS

TST T.CNTRL ;RLV11?
BEQ 100\$;YES,RLV11
JMP 10\$;NO,SKIP TEST
100\$: MOV #PATCRC,R3 ;GET CRC PATTERN TABLE
MOV #PATDAT,PATSAV ;GET DATA PATTERN TABLE
101\$: MOV (R3),102\$;STORE CRC PATTERN FOR CALCULATION
MOV @PATSAV,103\$;STORE DATA PAT. FOR BUFFER FILL
JSR R5,CALCRC ;CALCULATE CRC BEFORE TEST
102\$: .WORD 0 ;PATTERN FOR CRC TEST
BGNSEG
TRAP C\$BSEG
103\$: JSR R5,SETPAT ;SETUP PATTERN IN BUFFER
.WORD 0 ;BUFFER PATTERN
JSR R5,LDFUN ;PERFORM MAINT. FUNCTION
MAINT ;MAINT FUNCTION FLAG DRIVEN

3929	023406	177001				-511.			:WORD COUNT
3930	023410	006324				MATMES			:MESSAGE
3931	023412	004537	016724			JSR	R5,WTCRDY		:WAIT FOR READY
3932	023416					CKLOOP			
3933	023416	104406				TRAP	C\$CLP1		
3934	023420	004537	014600			JSR	R5,CHERR		:CHECK CONTROLLER FOR ERRORS
3935	023424					CKLOOP			
3936	023424	104406				TRAP	C\$CLP1		
3937	023426	012737	005756	002306		MOV	#BUF1+1776,GDDAT		
3938	023434	013737	002234	002310		MOV	E.BA,BDDAT		
3939	023442	023737	002306	002310		CMP	GDDAT,BDDAT		:TEST BA REGISTER
3940	023450	001404				BEQ	1\$		
3941	023452					ERRDF	35.,EM10,ERR4		:DATA WRONG IN BA REGISTER
3942	023452	104455				TRAP	C\$ERDF		
3943	023454	000043				.WORD	35		
3944	023456	007046				.WORD	EM10		
3945	023460	012026				.WORD	ERR4		
3946	023462				1\$:	CKLOOP			:CHECK FOR LOOP MODE
3947	023462	104406				TRAP	C\$CLP1		
3948	023464	013737	002224	002306		MOV	B.DA,GDDAT		:GET BEFORE DA REGISTER
3949	023472	013737	002236	002310		MOV	E.DA,BDDAT		
3950	023500	005037	002274			CLR	TEMP1		
3951	023504	113737	002224	002274		MOVB	B.DA,TEMP1		
3952	023512	062737	000006	002274		ADD	#6,TEMP1		:+6 TO DA LOW BYTE
3953	023520	113737	002274	002306		MOVB	TEMP1,GDDAT		:STORE LOW BYTE OF DA
3954	023526	023737	002306	002310		CMP	GDDAT,BDDAT		
3955	023534	001404				BEQ	2\$		
3956	023536					ERRDF	36.,EM12,ERR4		
3957	023536	104455				TRAP	C\$ERDF		
3958	023540	000044				.WORD	36		
3959	023542	007150				.WORD	EM12		
3960	023544	012026				.WORD	ERR4		
3961	023546				2\$:	CKLOOP			
3962	023546	104406				TRAP	C\$CLP1		
3963	023550	013737	002314	002306		MOV	GDCRCA,GDDAT		:GET CRC OF DA+3 VALUE
3964	023556	013737	002240	002310		MOV	E.MP,BDDAT		:GET CONTROLLER CRC OF DA+3
3965	023564	023737	002306	002310		CMP	GDDAT,BDDAT		
3966	023572	001404				BEQ	3\$		
3967	023574					ERRDF	37.,EM20,ERR4		
3968	023574	104455				TRAP	C\$ERDF		
3969	023576	000045				.WORD	37		
3970	023600	007400				.WORD	EM20		
3971	023602	012026				.WORD	ERR4		
3972	023604				3\$:	CKLOOP			
3973	023604	104406				TRAP	C\$CLP1		
3974	023606	013737	002316	002306		MOV	GDCRCB,GDDAT		
3975	023614	013737	002242	002310		MOV	E.MP1,BDDAT		
3976	023622	023737	002306	002310		CMP	GDDAT,BDDAT		
3977	023630	001404				BEQ	4\$		
3978	023632					ERRDF	38.,EM21,ERR4		
3979	023632	104455				TRAP	C\$ERDF		
3980	023634	000046				.WORD	38		
3981	023636	007453				.WORD	EM21		
3982	023640	012026				.WORD	ERR4		
3983	023642				4\$:	CKLOOP			
3984	023642	104406				TRAP	C\$CLP1		

3985	023644	005037	002360		CLR	SAVCNT	:CLEAR BAD WORD COUNTER	
3986	023650	005037	002304		CLR	CHECK	:CLEAR PRINT HEADER INDICATOR	
3987	023654	012704	003760		MOV	#BUF1,R4	:GOOD DATA STORED IN BUF1	
3988	023660	012702	004760		MOV	#BUF2,R2	:DATA BUFFER WRITTEN INTO BY MAINT.	
3989	023664	012701	000377		MOV	#255,R1		
3990	023670	011437	002306		5\$:	MOV	(R4),GDDAT	:EXPECTED DATA
3991	023674	011237	002310		MOV	(R2),BDDAT	:GET DATA FROM BUFFER	
3992	023700	023737	002306	002310	CMP	GDDAT,BDDAT		
3993	023706	001440			BEQ	7\$:DATA COMPARE	
3994	023710	010237	002276		MOV	R2, TMPO	:DATA ERR-GET ADDRESS	
3995	023714	005237	002360		INC	SAVCNT	:INC BAD WORD COUNTER	
3996	023720	005737	002304		TST	CHECK	:CHECK IF FIRST TIME	
3997	023724	001507			BNE	6\$		
3998	023726				ERRDF	39.,EM22,ERR3		
3999	023726	104455			TRAP	C\$ERDF		
4000	023730	000047			.WORD	39		
4001	023732	007535			.WORD	EM22		
4002	023734	011724			.WORD	ERR3		
4003	023736	005237	002304		INC	CHECK	:PRINT HEADER ONCE	
4004	023742	000422			BR	7\$		
4005	023744				6\$:	PRINTX	#FRMT14,E.BA,E.DA, TMPO,GDDAT,BDDAT	
4006	023744	013746	002310		MOV	BDDAT,-(SP)		
4007	023750	013746	002306		MOV	GDDAT,-(SP)		
4008	023754	013746	002276		MOV	TMPO,-(SP)		
4009	023760	013746	002236		MOV	E.DA,-(SP)		
4010	023764	013746	002234		MOV	E.BA,-(SP)		
4011	023770	012746	013477		MOV	#FRMT14,-(SP)		
4012	023774	012746	000006		MOV	#6,-(SP)		
4013	024000	010600			MOV	SP,R0		
4014	024002	104415			TRAP	C\$PNTX		
4015	024004	062706	000016		ADD	#16,SP		
4016	024010				7\$:	CKLOOP		
4017	024010	104406			TRAP	C\$CLP1		
4018	024012	005722			TST	(R2)+	:INCREMENT BUFFER	
4019	024014	005724			TST	(R4)+	:INCREMENT BUFFER	
4020	024016	005301			DEC	R1	:FINISHED BUFFER?	
4021	024020	001323			BNE	5\$:RETURN FOR NEXT COMPARE	
4022	024022	005737	002304		TST	CHECK	:CHECK FOR ERROR HEADER FLAG	
4023	024026	001412			BEQ	77\$		
4024	024030				PRINTB	#FRMT98,SAVCNT	:PRINT BAD WORD COUNT	
4025	024030	013746	002360		MOV	SAVCNT,-(SP)		
4026	024034	012746	013052		MOV	#FRMT98,-(SP)		
4027	024040	012746	000002		MOV	#2,-(SP)		
4028	024044	010600			MOV	SP,R0		
4029	024046	104414			TRAP	C\$PNTB		
4030	024050	062706	000006		ADD	#6,SP		
4031	024054	012737	123456	002306	77\$:	MOV	#123456,GDDAT	:EXPECTED DATA IN LAST WORD+1
4032	024062	011237	002310		MOV	(R2),BDDAT	:GET LAST WORD+1 FROM BUF2	
4033	024066	023737	002306	002310	CMP	GDDAT,BDDAT		
4034	024074	001404			BEQ	8\$		
4035	024076				ERRDF	40.,EM23,ERR4		
4036	024076	104455			TRAP	C\$ERDF		
4037	024100	000050			.WORD	40		
4038	024102	007624			.WORD	EM23		
4039	024104	012026			.WORD	ERR4		
4040	024106				8\$:	CKLOOP		

```

4041 024106 104406 TRAP C$CLP1
4042 024110 ENDSEG
4043 024110 10000$:
4044 024110 104405 TRAP C$ESEG
4045 024112 005723 TST (R3)+ ;INC CRC PATTERN
4046 024114 062737 000002 002352 ADD #2,PATSAV ;UPDATE PATTERN TABLE
4047 024122 020327 003064 CMP R3,#CRCEND ;CHECK FOR END
4048 024126 001402 BEQ 10$ ;END OF TEST
4049 024130 000137 023350 JMP 101$ ;CONTINUE TEST

```

```

4050
4051 024134 10$:
4052
4053 024134 ENDTST
4054 024134 L10062:
4055 024134 104401 TRAP C$ETST
4056
4057

```

.SBTTL **TEST 33** - TEST RLV11 MAINT. FUNCTION -INTERRUPT MODE

4059 BGNTST ;*****START OF TEST*****

```

4060 024136
4061
4062 024136
4063 STARS
4064 ;*****
4065 ;PERFORM RLV11 MAINTENANCE FUNCTION 0 (INT. MODE) AND CHECK
4066 ;FOR PROPER INCREMENT OF THE DA AND BA REGISTERS. CHECK THE SERIAL
4067 ;WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER
4068 ;THE CRC OF DA+3 AND THE CRC OF CRC OF DA+4 AND COMPARING WITH EXPECTED
4069 ;RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE
4070 ;FIFO INTO BUF2 MEMORY FOR PROPER DATA.
4071 ;CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR
4072 ;VALUE:123456 TO INSURE THAT THE TRANSFER WAS NOT MORE THAN 255 WORDS.

```

4073 STARS ;*****

```

4074 024136 005737 002332 TST T.CNTRL ;RLV11?
4075 024142 001402 BEQ 100$ ;YES,RLV11
4076 024144 000137 025012 JMP 10$ ;NO,SKIP TEST
4077 024150 012703 002774 100$: MOV #PATCRC,R3 ;GET CRC PATTERN
4078 024154 012737 003066 002352 MOV #PATDAT,PATSAV ;GET DATA PATTERN
4079 024162 011337 024200 101$: MOV (R3),102$
4080 024166 017737 156160 024210 MOV @PATSAV,103$
4081 024174 004537 015514 JSR R5,CALCRC ;CALCULATE CRC BEFORE TEST
4082 024200 000000 102$: .WORD 0 ;PATTERN FOR CRC TEST
4083 024202
4084 024202 104404 TRAP C$BSEG
4085 024204 004537 015752 JSR R5,SETPAT ;SETUP PATTERN IN BUFFER
4086 024210 000000 103$: .WORD 0 ;BUFFER PATTERN
4087 024212 SETPRI #PRI00 ;SET PRIORITY TO ZERO
4088 024212 012700 000000 MOV #PRI00,R0
4089 024216 104441 TRAP C$SPRI
4090 024220 005037 002250 CLR INTFLG ;CLEAR INT. FLAG
4091 024224 004537 016114 JSR R5,LDFUN ;PERFORM MAINT. FUNCTION
4092 024230 000100 MAINT!INTEN ;MAINT FUNCTION INT. DRIVEN
4093 024232 177001 -511. ;WORD COUNT
4094 024234 006364 MAT!INT ;MESSAGE
4095 024236 004537 016724 JSR R5,WTCRDY ;WAIT FOR READY
4096 024242 CKLOOP

```

4097	024242	104406				TRAP	C\$CLP1	
4098	024244					SETPRI	#PRI07	
4099	024244	012700	000340			MOV	#PRI07,R0	
4100	024250	104441				TRAP	C\$SPRI	
4101	024252	005737	002250			TST	INTFLG	
4102	024256	001004				BNE	104\$	
4103	024260					ERRDF	41.,EM24,ERR0	
4104	024260	104455				TRAP	C\$ERDF	
4105	024262	000051				.WORD	41	
4106	024264	007664				.WORD	EM24	
4107	024266	011632				.WORD	ERR0	
4108	024270	005037	002250		104\$:	CLR	INTFLG	;CLEAR INT. FLAG
4109	024274					CKLOOP		
4110	024274	104406				TRAP	C\$CLP1	
4111	024276	004537	014600			JSR	R5,CHERR	;CHECK CONTROLLER FOR ERRORS
4112	024302					CKLOOP		
4113	024302	104406				TRAP	C\$CLP1	
4114	024304	012737	005756	002306		MOV	#BUF1+1776,GDDAT	
4115	024312	013737	002234	002310		MOV	E.BA,BDDAT	
4116	024320	023737	002306	002310		CMP	GDDAT,BDDAT	;TEST BA REGISTER
4117	024326	001404				BEQ	1\$	
4118	024330					ERRDF	42.,EM10,ERR4	;DATA WRONG IN BA REGISTER
4119	024330	104455				TRAP	C\$ERDF	
4120	024332	000052				.WORD	42	
4121	024334	007046				.WORD	EM10	
4122	024336	012026				.WORD	ERR4	
4123	024340				1\$:	CKLOOP		;CHECK FOR LOOP MODE
4124	024340	104406				TRAP	C\$CLP1	
4125	024342	013737	002224	002306		MOV	B.DA,GDDAT	;GET BEFORE DA REGISTER
4126	024350	013737	002236	002310		MOV	E.DA,BDDAT	
4127	024356	005037	002274			CLR	TEMP1	
4128	024362	113737	002224	002274		MOVB	B.DA,TEMP1	
4129	024370	062737	000006	002274		ADD	#6,TEMP1	;+6 TO DA LOW BYTE
4130	024376	113737	002274	002306		MOVB	TEMP1,GDDAT	;STORE LOW BYTE OF DA
4131	024404	023737	002306	002310		CMP	GDDAT,BDDAT	
4132	024412	001404				BEQ	2\$	
4133	024414					ERRDF	43.,EM12,ERR4	
4134	024414	104455				TRAP	C\$ERDF	
4135	024416	000053				.WORD	43	
4136	024420	007150				.WORD	EM12	
4137	024422	012026				.WORD	ERR4	
4138	024424				2\$:	CKLOOP		
4139	024424	104406				TRAP	C\$CLP1	
4140	024426	013737	002314	002306		MOV	GDCRCA,GDDAT	;GET CRC OF DA+3 VALUE
4141	024434	013737	002240	002310		MOV	E.MP,BDDAT	;GET CONTROLLER CRC OF DA+3
4142	024442	023737	002306	002310		CMP	GDDAT,BDDAT	
4143	024450	001404				BEQ	3\$	
4144	024452					ERRDF	44.,EM20,ERR4	
4145	024452	104455				TRAP	C\$ERDF	
4146	024454	000054				.WORD	44	
4147	024456	007400				.WORD	EM20	
4148	024460	012026				.WORD	ERR4	
4149	024462				3\$:	CKLOOP		
4150	024462	104406				TRAP	C\$CLP1	
4151	024464	013737	002316	002306		MOV	GDCRCB,GDDAT	
4152	024472	013737	002242	002310		MOV	E.MP1,BDDAT	

4153	024500	023737	002306	002310	CMP	GDDAT,BDDAT	
4154	024506	001404			BEQ	4\$	
4155	024510				ERRDF	45,EM21,ERR4	
4156	024510	104455			TRAP	C\$ERDF	
4157	024512	000055			.WORD	45	
4158	024514	007453			.WORD	EM21	
4159	024516	012026			.WORD	ERR4	
4160	024520				4\$: CKLOOP		
4161	024520	104406			TRAP	C\$CLP1	
4162	024522	005037	002360		CLR	SAVCNT	:CLEAR BAD WORD COUNTER
4163	024526	005037	002304		CLR	CHECK	:CLEAR PRINT HEADER INDICATOR
4164	024532	012704	003760		MOV	#BUF1,R4	:GOOD DATA BUFFER
4165	024536	012702	004760		MOV	#BUF2,R2	:DATA BUFFER WRITTEN INTO BY MAINT.
4166	024542	012701	000377		MOV	#255,R1	
4167	024546	011437	002306		5\$: MOV	(R4),GDDAT	:EXPECTED DATA
4168	024552	011237	002310		MOV	(R2),BDDAT	:GET DATA FROM BUFFER
4169	024556	023737	002306	002310	CMP	GDDAT,BDDAT	
4170	024564	001440			BEQ	7\$:DATA COMPARE
4171	024566	010237	002276		MOV	R2,TMPO	:DATA ERR-GET ADDRESS
4172	024572	005237	002360		INC	SAVCNT	:INC. BAD WORD COUNT
4173	024576	005737	002304		TST	CHECK	:CHECK IF FIRST TIME
4174	024602	001007			BNE	6\$	
4175	024604				ERRDF	46,EM22,ERR3	
4176	024604	104455			TRAP	C\$ERDF	
4177	024606	000056			.WORD	46	
4178	024610	007535			.WORD	EM22	
4179	024612	011724			.WORD	ERR3	
4180	024614	005237	002304		INC	CHECK	:PRINT HEADER ONCE
4181	024620	000422			BR	7\$	
4182	024622				6\$: PRINTX	#FRMT14,E.BA,E.DA,TMPO,GDDAT,BDDAT	
4183	024622	013746	002310		MOV	BDDAT,-(SP)	
4184	024626	013746	002306		MOV	GDDAT,-(SP)	
4185	024632	013746	002276		MOV	TMPO,-(SP)	
4186	024636	013746	002236		MOV	E.DA,-(SP)	
4187	024642	013746	002234		MOV	E.BA,-(SP)	
4188	024646	012746	013477		MOV	#FRMT14,-(SP)	
4189	024652	012746	000006		MOV	#6,-(SP)	
4190	024656	010600			MOV	SP,R0	
4191	024660	104415			TRAP	C\$PNTX	
4192	024662	062706	000016		ADD	#16,SP	
4193	024666				7\$: CKLOOP		
4194	024666	104406			TRAP	C\$CLP1	
4195	024670	005722			TST	(R2)+	:INCREMENT BUFFER
4196	024672	005724			TST	(R4)+	:INCREMENT BUFFER
4197	024674	005301			DEC	R1	:FINISHED BUFFER?
4198	024676	001323			BNE	5\$:RETURN FOR NEXT COMPARE
4199	024700	005737	002304		TST	CHECK	:CHECK ERROR HEADER FLAG
4200	024704	001412			BEQ	77\$	
4201	024706				PRINTB	#FRMT98,SAVCNT	:PRINT BAD WORD COUNT
4202	024706	013746	002360		MOV	SAVCNT,-(SP)	
4203	024712	012746	013052		MOV	#FRMT98,-(SP)	
4204	024716	012746	000002		MOV	#2,-(SP)	
4205	024722	010600			MOV	SP,R0	
4206	024724	104414			TRAP	C\$PNTB	
4207	024726	062706	000006		ADD	#6,SP	
4208	024732	012737	123456	002306	77\$: MOV	#123456,GDDAT	:EXPECTED DATA IN LAST WORD+1

```

4209 024740 011237 002310      MOV      (R2),BDDAT      ;GET LAST WORD+1 FROM BUF2
4210 024744 023737 002306 002310  CMP      GDDAT,BDDAT
4211 024752 001404      BEQ      8$
4212 024754      ERRDF 47.,EM23,ERR4
4213 024754 104455      TRAP    C$ERRDF
4214 024756 000057      .WORD  47
4215 024760 007624      .WORD  EM23
4216 024762 012026      .WORD  ERR4
4217 024764      8$:      CKLOOP
4218 024764 104406      TRAP    C$CLP1
4219 024766      ENDSEG
4220 024766      10000$:
4221 024766 104405      TRAP    C$ESEG
4222 024770 005723      TST     (R3)+           ;INC. CRC PATTERN
4223 024772 062737 000002 002352  ADD     #2,PATSAV       ;UPDATE PATTERN TABLE
4224 025000 020327 003064      CMP     R3,#CRCEND     ;CHECK FOR END
4225 025004 001402      BEQ     10$            ;END OF TEST
4226 025006 000137 024162  JMP     101$          ;CONTINUE TEST
4227
4228 025012      10$:
4229
4230 025012      ENDTST
4231 025012      L10063:
4232 025012 104401      TRAP    C$ETST
4233
4234      .SBTTL **TEST 34** - RLV11 FIFO ADDRESS TEST
4235
4236 025014      BGNTST
4237
4238 025014      STARS
4239      :*****
4240      :TEST THAT FIFO OPERATES CORRECTLY.STORE ADDRESS PATTERN
4241      :IN BUF1 (0-255) THAT CONTAINS A UNIQUE PATTERN IN EACH LOCATION.
4242      :PERFORM MAINTENANCE FUNCTION AND TEST BUF2 FOR PROPER FIFO
4243      :ADDRESSING.
4244 025014      STARS
4245      :*****
4246 025014 005737 002332      TST     T.CNTRL        ;RLV11 OR RLV11
4247 025020 001402      BEQ     1$             ;RLV11;PERFORM TEST
4248 025022 000137 025360  JMP     10$           ;RLV11;SKIP TEST
4249 025026 005001      1$:      CLR     R1
4250 025030 012702 000400  MOV     #256.,R2
4251 025034 012703 003760  MOV     #BUF1,R3       ;SETUP TO STORE PATTERN IN BUF1
4252 025040 010123      2$:      MOV     R1,(R3)+
4253 025042 005201      INC     R1             ;INC. PATTERN
4254 025044 005302      DEC     R2
4255 025046 001374      BNE     2$
4256 025050 012702 000400  MOV     #256.,R2       ;SETUP TO CLEAR BUF2
4257 025054 012703 004760  MOV     #BUF2,R3
4258 025060 005023      3$:      CLR     (R3)+
4259 025062 005302      DEC     R2
4260 025064 001375      BNE     3$
4261 025066 005037 002250  CLR     INTFLG        ;CLEAR INT. FLAG
4262 025072      SETPRJ #PR100
4263 025072 012700 000000  MOV     #PR100,R0
4264 025076 104441      TRAP    C$SPRI

```

4265	025100	004537	016114		JSR	R5,LDFUN	:LOAD FUNCTION
4266	025104	000100			MAINT!INTEN		:MAINT. WITH INTERRUPT
4267	025106	177001			-511.		:WORD COUNT
4268	025110	006364			MATINT		:MAINT. MESSAGE
4269	025112	004537	016724		JSR	R5,WTCRDY	:WAIT FOR READY
4270	025116				CKLOOP		
4271	025116	104406			TRAP	C\$CLP1	
4272	025120				SETPRI	#PRI07	
4273	025120	012700	000340		MOV	#PRI07,R0	
4274	025124	104441			TRAP	C\$SPRI	
4275	025126	005737	002250		TST	INTFLG	:CHECK FOR INTERRUPT
4276	025132	001004			BNE	4\$	
4277	025134				ERRDF	48.,EM24,ERRO	
4278	025134	104455			TRAP	C\$ERDF	
4279	025136	000060			.WORD	48	
4280	025140	007664			.WORD	EM24	
4281	025142	011632			.WORD	ERRO	
4282	025144	005037	002250	4\$:	CLR	INTFLG	
4283	025150				CKLOOP		
4284	025150	104406			TRAP	C\$CLP1	
4285	025152	005037	002360		CLR	SAVCNT	:CLEAR 3AD WORD COUNTER
4286	025156	005037	002304		CLR	CHECK	:CLEAR ERROR HEADER FLAG
4287	025162	005001			CLR	R1	
4288	025164	012702	000377		MOV	#255.,R2	
4289	025170	012703	004760		MOV	#BUF2,R3	
4290	025174	010137	002306	5\$:	MOV	R1,GDDAT	:EXPECTED DATA
4291	025200	011337	002310		MOV	(R3),BDDAT	:DATA IN BUFFER
4292	025204	023737	002306	002310	CMP	GDDAT,BDDAT	
4293	025212	001440			BEQ	7\$	
4294	025214	010337	002276		MOV	R3,TMPO	:GET ADDRESS FOR PRINTOUT
4295	025220	005237	002360		INC	SAVCNT	:INC. BAD WORD COUNTER
4296	025224	005737	002304		TST	CHECK	:CHECK ERROR HEADER FLAG
4297	025230	001007			BNE	6\$	
4298	025232				ERRDF	49.,EM25,ERR3	
4299	025232	104455			TRAP	C\$ERDF	
4300	025234	000061			.WORD	49	
4301	025236	007726			.WORD	EM25	
4302	025240	011724			.WORD	ERR3	
4303	025242	005237	002304		INC	CHECK	
4304	025246	000422			BR	7\$	
4305	025250			6\$:	PRINTX	#FRMT14,E.BA,E.DA,TMPO,GDDAT,BDDAT	
4306	025250	013746	002310		MOV	BDDAT,-(SP)	
4307	025254	013746	002306		MOV	GDDAT,-(SP)	
4308	025260	013746	002276		MOV	TMPO,-(SP)	
4309	025264	013746	002236		MOV	E.DA,-(SP)	
4310	025270	013746	002234		MOV	E.BA,-(SP)	
4311	025274	012746	013477		MOV	#FRMT14,-(SP)	
4312	025300	012746	000006		MOV	#6,-(SP)	
4313	025304	010600			MOV	SP,R0	
4314	025306	104415			TRAP	C\$PNTX	
4315	025310	062706	000016		ADD	#16,SP	
4316	025314			7\$:	CKLOOP		
4317	025314	104406			TRAP	C\$CLP1	
4318	025316	005723			TST	(R3)+	
4319	025320	005201			INC	R1	:UPDATE PATTERN EXPECTED
4320	025322	005302			DEC	R2	

4321 025324 001323
4322 025326 005737 002304
4323 025332 001412
4324 025334
4325 025334 013746 002360
4326 025340 012746 013052
4327 025344 012746 000002
4328 025350 010600
4329 025352 104414
4330 025354 062706 000006
4331
4332 025360
4333
4334 025360
4335 025360
4336 025360 104401
4337
4338
4339
4340 025362
4341
4342 025362
4343
4344
4345
4346
4347
4348 025362
4349
4350 025362 005737 002332
4351 025366 001402
4352 025370 000137 025732
4353 025374 012701 177777
4354 025400 012702 000400
4355 025404 012703 003760
4356 025410 010123
4357 025412 005301
4358 025414 005302
4359 025416 001374
4360 025420 012702 000400
4361 025424 012703 004760
4362 025430 005023
4363 025432 005302
4364 025434 001375
4365 025436 005037 002250
4366 025442
4367 025442 012700 000000
4368 025446 104441
4369 025450 004537 016114
4370 025454 000100
4371 025456 177001
4372 025460 006364
4373 025462 004537 016724
4374 025466
4375 025466 104406
4376 025470

BNE 5\$
TST CHECK ;CHECK ERROR FLAG
BEQ 10\$
PRINTB #FRMT98,SAVCNT ;PRINT NUMBER OF BAD WORDS
MOV SAVCNT, -(SP)
MOV #FRMT98, -(SP)
MOV #2, -(SP)
MOV SP, R0
TRAP C\$PNTB
ADD #6, SP

10\$:

ENDTST
L10064:
TRAP C\$SETST

.SBTTL **TEST 35** - RLV11 FIFO ADDRESS COMPLEMENT TEST

BGNTST

STARS

:TEST THAT FIFO OPERATES CORRECTLY. STORE ADDRESS COMPLEMENT PAT.
:IN BUF1 (0-255) THAT CONTAINS A UNIQUE PATTERN IN EACH LOCATION.
:PERFORM MAINTENANCE FUNCTION AND TEST BUF2 FOR PROPER FIFO
:ADDRESSING.

STARS

1\$: TST T.CNTRL ;RL11 OR RLV11
BEQ 1\$;RLV11:PERFORM TEST
JMP 10\$;RL11:SKIP TEST
MOV #177777,R1
MOV #256.,R2
2\$: MOV #BUF1,R3 ;SETUP TO STORE PATTERN IN BUF1
MOV R1,(R3)+
DEC R1 ;NEXT COMP. PATTERN
DEC R2
BNE 2\$
MOV #256.,R2 ;SETUP TO CLEAR BUF2
MOV #BUF2,R3
3\$: CLR (R3)+
DEC R2
BNE 3\$
CLR INTFLG ;CLEAR INT. FLAG
SETPRI #PRI00
MOV #PRI00,R0
TRAP C\$SPRI
JSR R5,LDFUN ;LOAD FUNCTION
MAINT!INTEN ;MAINT. WITH INTERRUPT
-511. ;WORD COUNT
MATINT ;MAINT. MESSAGE
JSR R5,WTCRDY ;WAIT FOR READY
CKLOOP
TRAP C\$CLP1
SETPRI #PRI07

```
4377 025470 012700 000340      MOV      #PRI07,R0
4378 025474 104441      TRAP     C$SPRI
4379 025476 005737 002250      TST     INTFLG      ;CHECK FOR INTERRUPT
4380 025502 001004      BNE     4$
4381 025504      ERRDF   50.,EM24,ERRO
4382 025504 104455      TRAP     C$ERDF
4383 025506 000062      .WORD   50
4384 025510 007664      .WORD   EM24
4385 025512 011632      .WORD   ERRO
4386 025514 005037 002250      4$:    CLR     INTFLG
4387 025520      CKLOOP
4388 025520 104406      TRAP     C$CLP1
4389 025522 005037 002360      CLR     SAVCNT      ;CLEAR BAD WORD COUNTER
4390 025526 005037 002304      CLR     CHECK       ;CLEAR ERROR HEADER FLAG
4391 025532 012701 177777      MOV     #177777,R1
4392 025536 012702 000377      MOV     #255.,R2
4393 025542 012703 004760      MOV     #BUF2,R3
4394 025546 010137 002306      5$:    MOV     R1,GDDAT      ;EXPECTED DATA
4395 025552 011337 002310      MOV     (R3),BDDAT   ;DATA IN BUFFER
4396 025556 023737 002306 002310      CMP     GDDAT,BDDAT
4397 025564 001440      BEQ     7$
4398 025566 010337 002276      MOV     R3,TMPO      ;GET ADDRESS FOR PRINTOUT
4399 025572 005237 002360      INC     SAVCNT      ;INC. BAD WORD COUNTER
4400 025576 005737 002304      TST     CHECK       ;CHECK ERROR HEADER FLAG
4401 025602 001007      BNE     6$
4402 025604      ERRDF   51.,EM26,ERR3
4403 025604 104455      TRAP     C$ERDF
4404 025606 000063      .WORD   51
4405 025610 007765      .WORD   EM26
4406 025612 011724      .WORD   ERR3
4407 025614 005237 002304      INC     CHECK
4408 025620 000422      BR      7$
4409 025622      6$:    PRINTX #FRMT14,E.BA,E.DA,TMPO,GDDAT,BDDAT
4410 025622 013746 002310      MOV     BDDAT,-(SP)
4411 025626 013746 002306      MOV     GDDAT,-(SP)
4412 025632 013746 002276      MOV     TMPO,-(SP)
4413 025636 013746 002236      MOV     E.DA,-(SP)
4414 025642 013746 002234      MOV     E.BA,-(SP)
4415 025646 012746 013477      MOV     #FRMT14,-(SP)
4416 025652 012746 000006      MOV     #6,-(SP)
4417 025656 010600      MOV     SP,R0
4418 025660 104415      TRAP     C$PNTX
4419 025662 062706 000016      ADD     #16,SP
4420 025666      7$:    CKLOOP
4421 025666 104406      TRAP     C$CLP1
4422 025670 005723      TST     (R3)+
4423 025672 005301      DEC     R1          ;GET NEXT PATTERN
4424 025674 005302      DEC     R2
4425 025676 001323      BNE     5$
4426 025700 005737 002304      TST     CHECK       ;CHECK ERROR FLAG
4427 025704 001412      BEQ     10$
4428 025706      PRINTB #FRMT98,SAVCNT ;PRINT NO. OF BAD WORDS
4429 025706 013746 002360      MOV     SAVCNT,-(SP)
4430 025712 012746 013052      MOV     #FRMT98,-(SP)
4431 025716 012746 000002      MOV     #2,-(SP)
4432 025722 010600      MOV     SP,R0
```

4433 025724 104414
 4434 025726 062706 000006
 4435
 4436 025732
 4437 025732
 4438 025732
 4439 025732 104401
 4440
 4441
 4442
 4443
 4444 025734
 4445
 4446 025734
 4447
 4448
 4449
 4450
 4451
 4452
 4453
 4454
 4455
 4456 025734
 4457
 4458 025734 005737 002332
 4459 025740 001402
 4460 025742 000137 026610
 4461 025746 012703 002774
 4462 025752 012737 003066 002352
 4463 025760 011337 025776
 4464 025764 017737 154362 026006
 4465 025772 004537 015514
 4466 025776 000000
 4467 026000
 4468 026000 104404
 4469 026002 004537 016214
 4470 026006 000000
 4471 026010
 4472 026010 012700 000000
 4473 026014 104441
 4474 026016 005037 002250
 4475 026022 004537 016114
 4476 026026 000100
 4477 026030 177001
 4478 026032 006364
 4479 026034 004537 016724
 4480 026040
 4481 026040 104406
 4482 026042
 4483 026042 012700 000340
 4484 026046 104441
 4485 026050 005737 002250
 4486 026054 001004
 4487 026056
 4488 026056 104455

TRAP C\$PNTB
 ADD #6,SP
 10\$:
 ENDTST
 L10065:
 TRAP C\$ETST
 .SBTTL **TEST 36** - TEST RLV11 MAINT. WITH COMPLEMENT DATA -INT. MODE
 BGNST ;****START OF TEST****
 STARS
 ;*****
 ;PERFORM RLV11 MAINT. FUNCTION WITH COMPLEMENT DATA PATTERNS IN BUF1
 ;CHECK FOR PROPER INCREMENT OF THE DA AND BA REGISTERS. CHECK THE SERIAL
 ;WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER
 ;THE CRC OF DA+3 AND THE CRC OF CRC OF DA+4 AND COMPARING WITH EXPECTED
 ;RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE
 ;FIFO INTO BUF2 MEMORY FOR PROPER DATA.
 ;CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR
 ;VALUE:123456 TO INSURE THAT THE TRANSFER WAS NOT MORE THAN 255 WORDS.
 STARS
 ;*****
 TST T.CNTRL ;RLV11?
 BEQ 100\$;YES,RLV11
 JMP 10\$;NO,SKIP TEST
 100\$: MOV #PATCRC,R3 ;GET CRC PATTERN
 MOV #PATDAT,PATSAV ;GET DATA PATTERN
 101\$: MOV (R3),102\$
 MOV @PATSAV,103\$
 JSR R5,CALCRC ;CALCULATE CRC BEFORE TEST
 102\$: .WORD 0 ;PATTERN FOR CRC TEST
 BGNSEG
 TRAP C\$BSEG
 JSR R5,SETCMP ;SETUP PATTERN IN BUFFER
 103\$: .WORD 0 ;BUFFER PATTERN
 SETPRI #PRI00 ;SET PRIORITY TO ZERO
 MOV #PRI00,R0
 TRAP C\$SPRI
 CLR INTFLG ;CLEAR INT. FLAG
 JSR R5,LDFUN ;PERFORM MAINT. FUNCTION
 MAINT!INTEN ;MAINT FUNCTION INT. DRIVEN
 -511. ;WORD COUNT
 MATINT ;MESSAGE
 JSR R5,WTCRDY ;WAIT FOR READY
 CKLOOP
 TRAP C\$CLP1
 SETPRI #PRI07
 MOV #PRI07,R0
 TRAP C\$SPRI
 TST INTFLG
 BNE 104\$
 ERRDF 52.,EM24,ERRO
 TRAP C\$ERDF

4489	026060	000064				.WORD	52		
4490	026062	007664				.WORD	EM24		
4491	026064	011632				.WORD	ERRO		
4492	026066	005037	002250		104\$:	CLR	INTFLG		:CLEAR INT. FLAG
4493	026072					CKLOOP			
4494	026072	104406				TRAP	C\$CLP1		
4495	026074	004537	014600			JSR	R5,CHERR		:CHECK CONTROLLER FOR ERRORS
4496	026100					CKLOOP			
4497	026100	104406				TRAP	C\$CLP1		
4498	026102	012737	005756	002306		MOV	#BUF1+1776,GDDAT		
4499	026110	013737	002234	002310		MOV	E.BA,BDDAT		
4500	026116	023737	002306	002310		CMP	GDDAT,BDDAT		:TEST BA REGISTER
4501	026124	001404				BEQ	1\$		
4502	026126					ERRDF	53.,EM10,ERR4		:DATA WRONG IN BA REGISTER
4503	026126	104455				TRAP	C\$ERDF		
4504	026130	000065				.WORD	53		
4505	026132	007046				.WORD	EM10		
4506	026134	012026				.WORD	ERR4		
4507	026136				1\$:	CKLOOP			:CHECK FOR LOOP MODE
4508	026136	104406				TRAP	C\$CLP1		
4509	026140	013737	002224	002306		MOV	B.DA,GDDAT		:GET BEFORE DA REGISTER
4510	026146	013737	002236	002310		MOV	E.DA,BDDAT		
4511	026154	005037	002274			CLR	TEMP1		
4512	026160	113737	002224	002274		MOVB	B.DA,TEMP1		
4513	026166	062737	000006	002274		ADD	#6,TEMP1		:+6 TO DA LOW BYTE
4514	026174	113737	002274	002306		MOVB	TEMP1,GDDAT		:STORE LOW BYTE OF DA
4515	026202	023737	002306	002310		CMP	GDDAT,BDDAT		
4516	026210	001404				BEQ	2\$		
4517	026212					ERRDF	54.,EM12,ERR4		
4518	026212	104455				TRAP	C\$ERDF		
4519	026214	000066				.WORD	54		
4520	026216	007150				.WORD	EM12		
4521	026220	012026				.WORD	ERR4		
4522	026222				2\$:	CKLOOP			
4523	026222	104406				TRAP	C\$CLP1		
4524	026224	013737	002314	002306		MOV	GDCRCA,GDDAT		:GET CRC OF DA+3 VALUE
4525	026232	013737	002240	002310		MOV	E.MP,BDDAT		:GET CONTROLLER CRC OF DA+3
4526	026240	023737	002306	002310		CMP	GDDAT,BDDAT		
4527	026246	001404				BEQ	3\$		
4528	026250					ERRDF	55.,EM20,ERR4		
4529	026250	104455				TRAP	C\$ERDF		
4530	026252	000067				.WORD	55		
4531	026254	007400				.WORD	EM20		
4532	026256	012026				.WORD	ERR4		
4533	026260				3\$:	CKLOOP			
4534	026260	104406				TRAP	C\$CLP1		
4535	026262	013737	002316	002306		MOV	GDCRCB,GDDAT		
4536	026270	013737	002242	002310		MOV	E.MP1,BDDAT		
4537	026276	023737	002306	002310		CMP	GDDAT,BDDAT		
4538	026304	001404				BEQ	4\$		
4539	026306					ERRDF	56.,EM21,ERR4		
4540	026306	104455				TRAP	C\$ERDF		
4541	026310	000070				.WORD	56		
4542	026312	007453				.WORD	EM21		
4543	026314	012026				.WORD	ERR4		
4544	026316				4\$:	CKLOOP			

4545	026316	104406		TRAP	C\$CLP1		
4546	026320	005037	002360	CLR	SAVCNT	:CLEAR BAD WORD COUNTER	
4547	026324	005037	002304	CLR	CHECK	:CLEAR PRINT HEADER INDICATOR	
4548	026330	012704	003760	MOV	#BUF1,R4	:GOOD DATA BUFFER	
4549	026334	012702	004760	MOV	#BUF2,R2	:DATA BUFFER WRITTEN INTO BY MAINT.	
4550	026340	012701	000377	MOV	#255,R1		
4551	026344	011437	002306	5\$: MOV	(R4),GDDAT	:EXPECTED DATA	
4552	026350	011237	002310	MOV	(R2),BDDAT	:GET DATA FROM BUFFER	
4553	026354	023737	002306	002310	CMP	GDDAT,BDDAT	
4554	026362	001440		BEQ	7\$:DATA COMPARE	
4555	026364	010237	002276	MOV	R2, TMPO	:DATA ERR-GET ADDRESS	
4556	026370	005237	002360	INC	SAVCNT	:INC. BAD WORD COUNTER	
4557	026374	005737	002304	TST	CHECK	:CHECK IF FIRST TIME	
4558	026400	001007		BNE	6\$		
4559	026402			ERRDF	57, EM22, ERR3		
4560	026402	104455		TRAP	C\$ERDF		
4561	026404	000071		.WORD	57		
4562	026406	007535		.WORD	EM22		
4563	026410	011724		.WORD	ERR3		
4564	026412	005237	002304	INC	CHECK	:PRINT HEADER ONCE	
4565	026416	000422		BR	7\$		
4566	026420			6\$: PRINTX	#FRMT14, E.BA, E.DA, TMPO, GDDAT, BDDAT		
4567	026420	013746	002310	MOV	BDDAT, -(SP)		
4568	026424	013746	002306	MOV	GDDAT, -(SP)		
4569	026430	013746	002276	MOV	TMPO, -(SP)		
4570	026434	013746	002236	MOV	E.DA, -(SP)		
4571	026440	013746	002234	MOV	E.BA, -(SP)		
4572	026444	012746	013477	MOV	#FRMT14, -(SP)		
4573	026450	012746	000006	MOV	#6, -(SP)		
4574	026454	010600		MOV	SP, R0		
4575	026456	104415		TRAP	C\$PNTX		
4576	026460	062706	000016	ADD	#16, SP		
4577	026464			7\$: CKLOOP			
4578	026464	104406		TRAP	C\$CLP1		
4579	026466	005722		TST	(R2)+	:INCREMENT BUFFER	
4580	026470	005724		TST	(R4)+	:INCREMENT BUFFER	
4581	026472	005301		DEC	R1	:FINISHED BUFFER?	
4582	026474	001323		BNE	5\$:RETURN FOR NEXT COMPARE	
4583	026476	005737	002304	TST	CHECK	:CHECK ERROR FLAG	
4584	026502	001412		BEQ	77\$		
4585	026504			PRINTB	#FRMT98, SAVCNT	:PRINT NO OF BAD WORDS	
4586	026504	013746	002360	MOV	SAVCNT, -(SP)		
4587	026510	012746	013052	MOV	#FRMT98, -(SP)		
4588	026514	012746	000002	MOV	#2, -(SP)		
4589	026520	010600		MOV	SP, R0		
4590	026522	104414		TRAP	C\$PNTB		
4591	026524	062706	000006	ADD	#6, SP		
4592	026530	012737	123456	002306	77\$: MOV	#123456, GDDAT	:EXPECTED DATA IN LAST WORD+1
4593	026536	011237	002310	MOV	(R2), BDDAT	:GET LAST WORD+1 FROM BUF2	
4594	026542	023737	002306	002310	CMP	GDDAT, BDDAT	
4595	026550	001404		BEQ	8\$		
4596	026552			ERRDF	58, EM23, ERR4		
4597	026552	104455		TRAP	C\$ERDF		
4598	026554	000072		.WORD	58		
4599	026556	007624		.WORD	EM23		
4600	026560	012026		.WORD	ERR4		

4601 026562
4602 026562 104406
4603 026564
4604 026564
4605 026564 104405
4606 026566 005723
4607 026570 062737 000002 002352
4608 026576 020327 003064
4609 026602 001402
4610 026604 000137 025760
4611
4612 026610
4613 026610
4614 026610
4615 026610 104401
4616
4617
4618
4619 026612
4620
4621 026612
4622
4623
4624
4625
4626
4627
4628
4629
4630
4631
4632
4633
4634 026612
4635
4636 026612 005737 002332
4637 026616 001402
4638 026620 000137 027432
4639 026624 013737 002346 026644
4640 026632 013737 002346 002344
4641 026640 004537 015514
4642 026644 000000
4643 026646 004537 016306
4644 026652
4645 026652 104404
4646 026654
4647 026654 012700 000000
4648 026660 104441
4649 026662 005037 002250
4650 026666 004537 016114
4651 026672 000100
4652 026674 177001
4653 026676 006364
4654 026700 004537 016724
4655 026704
4656 026704 104406

8\$: CKLOOP
TRAP C\$CLP1
ENDSEG
10000\$: TRAP C\$ESEG
TST (R3)+ :INC. CRC PATTERN
ADD #2,PATSAV :UPDATE PATTERN TABLE
CMP R3,#CRCEND :CHECK FOR END
BEQ 10\$:END OF TEST
JMP 101\$:CONTINUE TEST
10\$:
ENDTST
L10066:
TRAP C\$ETST
.SBTTL **TEST 37** - TEST RLV11 MAINT. WITH RANDOM DATA -INT. MODE
BGNTST ;****START OF TEST****
STARS
:*****
:PERFORM RLV11 MAINT. FUNCTION WITH RANDOM DATA PATTERNS IN BUF1
:RANDOM PATTERN IS THE SAME FOR EACH CONTROLLER UNDER TEST.
:RANDOM PATTERN WILL CHANGE AT END OF PASS.
:RANDOM PATTERN WILL INIT AT START OR RESTART.
:CHECK FOR PROPER INCREMENT OF THE DA AND BA REGISTERS. CHECK THE SERIAL
:WRITE/READ DATA PATHS BY READING OUT OF THE FIFO VIA THE MP REGISTER
:THE CRC OF DA+3 AND THE CRC OF DA+4 AND COMPARING WITH EXPECTED
:RESULTS. CHECK THE TRANSFER OF 255 WORDS FROM BUF1 MEMORY THROUGH THE
:FIFO INTO BUF2 MEMORY FOR PROPER DATA.
:CHECK THE PREVIOUSLY WRITTEN DATA IN THE LAST WORD+1 OF BUF2 FOR
:VALUE:123456 TO INSURE THAT THE TRANSFER WAS NOT MORE THAN 255 WORDS.
STARS
:*****
TST T.CNTRL :RLV11?
BEQ 101\$:YES,RLV11
JMP 10\$:NO,SKIP TEST
101\$: MOV TEMLO,102\$:STARTING RANDOM PATTERN
MOV TEMLO,LONUM :RESET RANDOM START
JSR R5,CALCRC :CALCULATE CRC BEFORE TEST
102\$: .WORD 0 :PATTERN FOR CRC TEST
JSR R5,SETRAN :SETUP RANDOM PATTERN IN BUFFER
BGNSEG
TRAP C\$BSEG
SETPRI #PRI00 :SET PRIORITY TO ZERO
MOV #PRI00,R0
TRAP C\$SPRI
CLR INTFLG :CLEAR INT. FLAG
JSR R5,LDFUN :PERFORM MAINT. FUNCTION
MAINT!INTEN :MAINT FUNCTION INT. DRIVEN
-511. :WORD COUNT
MATINT :MESSAGE
JSR R5,WTCRDY :WAIT FOR READY
CKLOOP
TRAP C\$CLP1

4657	026706				SETPR1	#PRI07		
4658	026706	012700	000340		MOV	#PRI07,R0		
4659	026712	104441			TRAP	C\$SPRI		
4660	026714	005737	002250		TST	INTFLG		
4661	026720	001004			BNE	104\$		
4662	026722				ERRDF	59.,EM24,ERR0		
4663	026722	104455			TRAP	C\$ERDF		
4664	026724	000073			.WORD	59		
4665	026726	007664			.WORD	EM24		
4666	026730	011632			.WORD	ERR0		
4667	026732	005037	002250	104\$:	CLR	INTFLG		:CLEAR INT. FLAG
4668	026736				CKLOOP			
4669	026736	104406			TRAP	C\$CLP1		
4670	026740	004537	014600		JSR	R5,CHERR		:CHECK CONTROLLER FOR ERRORS
4671	026744				CKLOOP			
4672	026744	104406			TRAP	C\$CLP1		
4673	026746	012737	005756	002306	MOV	#BUF1+1776,GDDAT		
4674	026754	013737	002234	002310	MOV	E.BA,BDDAT		
4675	026762	023737	002306	002310	MOV	E.BA,BDDAT		
4676	026770	001404			CMP	GDDAT,BDDAT		:TEST BA REGISTER
4677	026772				BEQ	1\$		
4678	026772	104455			ERRDF	60.,EM10,ERR4		:DATA WRONG IN BA REGISTER
4679	026774	000074			TRAP	C\$ERDF		
4680	026776	007046			.WORD	60		
4681	027000	012026			.WORD	EM10		
4682	027002			1\$:	.WORD	ERR4		
4683	027002	104406			CKLOOP			:CHECK FOR LOOP MODE
4684	027004	013737	002224	002306	TRAP	C\$CLP1		
4685	027012	013737	002236	002310	MOV	B.DA,GDDAT		:GET BEFORE DA REGISTER
4686	027020	005037	002274		MOV	E.DA,BDDAT		
4687	027024	113737	002224	002274	CLR	TEMP1		
4688	027032	062737	000006	002274	MOVB	B.DA,TEMP1		
4689	027040	113737	002274	002306	ADD	#6,TEMP1		:+6 TO DA LOW BYTE
4690	027046	023737	002306	002310	MOVB	TEMP1,GDDAT		:STORE LOW BYTE OF DA
4691	027054	001404			CMP	GDDAT,BDDAT		
4692	027056				BEQ	2\$		
4693	027056	104455			ERRDF	61.,EM12,ERR4		
4694	027060	000075			TRAP	C\$ERDF		
4695	027062	007150			.WORD	61		
4696	027064	012026			.WORD	EM12		
4697	027066			2\$:	.WORD	ERR4		
4698	027066	104406			CKLOOP			
4699	027070	013737	002314	002306	TRAP	C\$CLP1		
4700	027076	013737	002240	002310	MOV	GDCRCA,GDDAT		:GET CRC OF DA+3 VALUE
4701	027104	023737	002306	002310	MOV	E.MP,BDDAT		:GET CONTROLLER CRC OF DA+3
4702	027112	001404			CMP	GDDAT,BDDAT		
4703	027114				BEQ	3\$		
4704	027114	104455			ERRDF	62.,EM20,ERR4		
4705	027116	000076			TRAP	C\$ERDF		
4706	027120	007400			.WORD	62		
4707	027122	012026			.WORD	EM20		
4708	027124			3\$:	.WORD	ERR4		
4709	027124	104406			CKLOOP			
4710	027126	013737	002316	002306	TRAP	C\$CLP1		
4711	027134	013737	002242	002310	MOV	GDCRCB,GDDAT		
4712	027142	023737	002306	002310	MOV	E.MP1,BDDAT		
					CMP	GDDAT,BDDAT		

4713	027150	001404		BEQ	4\$	
4714	027152			ERRDF	63.,EM21,ERR4	
4715	027152	104455		TRAP	C\$ERDF	
4716	027154	000077		.WORD	63	
4717	027156	007453		.WORD	EM21	
4718	027160	012026		.WORD	ERR4	
4719	027162			4\$: CKLOOP		
4720	027162	104406		TRAP	C\$CLP1	
4721	027164	005037	002360	CLR	SAVCNT	:CLEAR BAD WORD COUNTER
4722	027170	005037	002304	CLR	CHECK	:CLEAR PRINT HEADER INDICATOR
4723	027174	012703	003760	MOV	#BUF1,R3	:BUFFER WITH RANDOM NUMBERS
4724	027200	012702	004760	MOV	#BUF2,R2	:DATA BUFFER WRITTEN INTO BY MAINT.
4725	027204	012701	000377	MOV	#255.,R1	
4726	027210	011337	002306	5\$: MOV	(R3),GDDAT	:EXPECTED DATA
4727	027214	011237	002310	MOV	(R2),BDDAT	:GET DATA FROM BUFFER
4728	027220	023737	002306	002310	CMP	GDDAT,BDDAT
4729	027226	001440		BEQ	7\$:DATA COMPARE
4730	027230	010237	002276	MOV	R2, TMPO	:DATA ERR-GET ADDRESS
4731	027234	005237	002360	INC	SAVCNT	:INC BAD WORD COUNT
4732	027240	005737	002304	TST	CHECK	:CHECK IF FIRST TIME
4733	027244	001007		BNE	6\$	
4734	027246			ERRDF	64.,EM22,ERR3	
4735	027246	104455		TRAP	C\$ERDF	
4736	027250	000100		.WORD	64	
4737	027252	007535		.WORD	EM22	
4738	027254	011724		.WORD	ERR3	
4739	027256	005237	002304	INC	CHECK	:PRINT HEADER ONCE
4740	027262	000422		BR	7\$	
4741	027264			6\$: PRINTX	#FRMT14,E.BA,E.DA, TMPO,GDDAT,BDDAT	
4742	027264	013746	002310	MOV	BDDAT,-(SP)	
4743	027270	013746	002306	MOV	GDDAT,-(SP)	
4744	027274	013746	002276	MOV	TMPO,-(SP)	
4745	027300	013746	002236	MOV	E.DA,-(SP)	
4746	027304	013746	002234	MOV	E.BA,-(SP)	
4747	027310	012746	013477	MOV	#FRMT14,-(SP)	
4748	027314	012746	000006	MOV	#6,-(SP)	
4749	027320	010600		MOV	SP,R0	
4750	027322	104415		TRAP	C\$PNTX	
4751	027324	062706	000016	ADD	#16,SP	
4752	027330			7\$: CKLOOP		
4753	027330	104406		TRAP	C\$CLP1	
4754	027332	005722		TST	(R2)+	:INCREMENT BUFFER
4755	027334	005723		TST	(R3)+	:INCREMENT GOOD BUFFER
4756	027336	005301		DEC	R1	:FINISHED BUFFER?
4757	027340	001323		BNE	5\$:RETURN FOR NEXT COMPARE
4758	027342	005737	002304	TST	CHECK	:CHECK ERROR FLAG
4759	027346	001412		BEQ	77\$	
4760	027350			PRINTB	#FRMT98,SAVCNT	:PRINT NO. OF BAD WORDS
4761	027350	013746	002360	MOV	SAVCNT,-(SP)	
4762	027354	012746	013052	MOV	#FRMT98,-(SP)	
4763	027360	012746	000002	MOV	#2,-(SP)	
4764	027364	010600		MOV	SP,R0	
4765	027366	104414		TRAP	C\$PNTB	
4766	027370	062706	000006	ADD	#6,SP	
4767	027374	012737	123456	002306	77\$: MOV	#123456,GDDAT
4768	027402	011237	002310	MOV	(R2),BDDAT	:EXPECTED DATA IN LAST WORD+1 :GET LAST WORD+1 FROM BUF2

4769	027406	023737	002306	002310	CMP	GDDAT,BDDAT
4770	027414	001404			BEQ	8\$
4771	027416				ERRDF	65.,EM23,ERR4
4772	027416	104455			TRAP	C\$ERDF
4773	027420	000101			.WORD	65
4774	027422	007624			.WORD	EM23
4775	027424	012026			.WORD	ERR4
4776	027426				8\$: CKLOOP	
4777	027426	104406			TRAP	C\$CLP1
4778	027430				ENDSEG	
4779	027430				10000\$:	
4780	027430	104405			TRAP	C\$ESEG
4781						
4782	027432				10\$:	
4783	027432				ENDTST	
4784	027432				L10067:	
4785	027432	104401			TRAP	C\$ETST
4786						
4787	027434				BGNMOD	HRDPRM
4788						
4789	027434				BGNHRD	
4790	027434	000025			.WORD	L10070-L\$HARD/2
4791						
4792	027436				GPRML	LTYPMS,LTYPE,1,YES
4793	027436	005130			.WORD	T\$CODE
4794	027440	027552			.WORD	LTYPMS
4795	027442	000001			.WORD	1
4796	027444				GPRMA	CSRMSG,CSR,0,160000,177776,YES
4797	027444	000031			.WORD	T\$CODE
4798	027446	027510			.WORD	CSRMSG
4799	027450	160000			.WORD	T\$LOLIM
4800	027452	177776			.WORD	T\$HILIM
4801	027454				GPRMA	VECMMSG,VECT,0,0,776,YES
4802	027454	001031			.WORD	T\$CODE
4803	027456	027535			.WORD	VECMMSG
4804	027460	000000			.WORD	T\$LOLIM
4805	027462	000776			.WORD	T\$HILIM
4806	027464				GPRMD	DRMSG,DRBT,0,03400,0,7,YES
4807	027464	003032			.WORD	T\$CODE
4808	027466	027544			.WORD	DRMSG
4809	027470	003400			.WORD	03400
4810	027472	000000			.WORD	T\$LOLIM
4811	027474	000007			.WORD	T\$HILIM
4812	027476				GPRMD	BRMSG,PRIOR,0,340,0,7,YES
4813	027476	002032			.WORD	T\$CODE
4814	027500	027524			.WORD	BRMSG
4815	027502	000340			.WORD	340
4816	027504	000000			.WORD	T\$LOLIM
4817	027506	000007			.WORD	T\$HILIM
4818						
4819	027510				ENDHRD	
4820					.EVEN	
4821	027510				L10070:	
4822						
4823	027510	052502	020123	042101	CSRMSG:	.ASCIZ /BUS ADDRESS/
4824	027516	051104	051505	000123		

```

4825 027524 051102 046040 053105 BRMSG: .ASCIZ /BR LEVEL/
4826 027532 046105 000
4827 027535 126 041505 047524 VECMSG: .ASCIZ /VECTOR/
4828 027542 000122
4829 027544 051104 053111 000105 DRMSG: .ASCIZ /DRIVE/
4830 027552 030461 031057 020063 LTYPMS: .ASCIZ \11/23 PROCESSOR\
4831 027560 051120 041517 051505
4832 027566 047523 000122
4833 .EVEN
4834
4835 027572 ENDMOD
4836
4837
4838
4839 027572 BGNMOD SFTPRM
4840
4841 027572 BGNSFT
4842 027572 000014 .WORD L10071-L$SOFT/2
4843 027574 GPRML DMSG,DLT,1,YES
4844 027574 000130 .WORD T$CODE
4845 027576 027624 .WORD DMSG
4846 027600 000001 .WORD 1
4847 027602 XFERF 1$
4848 027602 006044 .WORD T$CODE
4849 027604 GPRMD EMSG,ELT,0,177777,0,177777,YES
4850 027604 001032 .WORD T$CODE
4851 027606 027661 .WORD EMSG
4852 027610 177777 .WORD 177777
4853 027612 000000 .WORD T$LOLIM
4854 027614 177777 .WORD T$HILIM
4855 027616 1$: GPRML SMSG,SIZE,1,YES
4856 027616 002130 .WORD T$CODE
4857 027620 027650 .WORD SMSG
4858 027622 000001 .WORD 1
4859 027624 ENDSFT
4860 .EVEN
4861 027624 L10071:
4862
4863
4864 027624 051104 050117 047440 DMSG: .ASCIZ /DROP ON ERROR LIMIT/
4865 027650 052501 047524 044523 SMSG: .ASCIZ /AUTOSIZE/
4866 027661 105 051122 051117 EMSG: .ASCIZ /ERROR LIMIT/
4867
4868 027676 .EVEN
4869
4870 027676 ENDMOD
4871
4872 030514 .=30514
4873 :AREA RESERVED AS PATCH AREA FOR DIAGNOSTIC
4874
4875 LASTAD
.EVEN
.WORD 0
.WORD 0
L$LAST::

```

MAIN. MACY11 30(1046) 31-AUG-82 11:50 PAGE 90
CVRLAC.P11 31-AUG-82 11:25

M 7

TEST 37 - TEST RLV11 MAINT. WITH RANDOM DATA -INT. MODE

SEQ 0090

4876
4877

000001

.END

DRST = 000010	1067#								
DRTIM 006547	1342#	2367							
DSPCOD 013616 G	1621#								
DSO = 000000	1055#								
DS1 = 000400	1056#								
DS2 = 001000	1057#								
DS3 = 001400	1058#								
EF.CON= 000036 G	1014#	1704							
EF.NEW= 000035 G	1015#	1687							
EF.PWR= 000034 G	1016#	1672							
EF.RES= 000037 G	1013#	1677							
EF.STA= 000040 G	1012#	1682							
ELT = 000002	1087#	4850							
EMSG 027661	4851	4863#							
EM1 006575	1342#	2436	2604						
EM10 007046	1342#	3944	4121	4505	4680				
EM101 011374	1342#	1562							
EM102 011441	1342#	1569	1578	1922	2034				
EM11 007107	1342#								
EM12 007150	1342#	3959	4136	4520	4695				
EM13 007211	1342#								
EM14 007243	1342#								
EM15 007271	1342#								
EM16 007317	1342#								
EM17 007345	1342#								
EM2 006622	1342#	2479	2647						
EM20 007400	1342#	3970	4147	4531	4706				
EM21 007453	1342#	3981	4158	4542	4717				
EM22 007535	1342#	4001	4178	4562	4737				
EM23 007624	1342#	4038	4215	4599	4774				
EM24 007664	1342#	3778	3856	4106	4280	4384	4490	4665	
EM25 007726	1342#	4301							
EM26 007765	1342#	4405							
EM27 010037	1342#	3674							
EM3 006647	1342#	2521	2689						
EM30 010113	1342#	3722							
EM31 010167	1342#	3874							
EM4 006674	1342#	2563	2731						
EM44 010210	1342#	3599							
EM45 010243	1342#	3613							
EM46 010276	1342#	3626							
EM5 006721	1342#	2889							
EM6 006772	1342#	2938							
EM61 010331	1342#	3034							
EM62 010412	1342#	3085							
EM63 010475	1342#	3133							
EM64 010556	1342#	3178							
EM65 010641	1342#	3222							
EM66 010722	1342#	3267							
EM67 011005	1342#	2778	3323						
EM7 007020	1342#	2983							
EM70 011042	1342#	2812	3357						
EM71 011077	1342#	2844	3389						
EM72 011134	1342#	3429							
EM73 011167	1342#	3443							
EM74 011222	1342#	3485							

GDCRCA	002314	1138#	2097*	3963	4140	4524	4699											
GDCRCB	002316	1139#	2110*	3974	4151	4535	4710											
GDDAT	002306	1135#	1371	1394	1416	2431*	2474*	2517*	2558*	2599*	2642*	2685*	2726*	2761*				
		2764*	2772	2803*	2835*	2875*	2876*	2877	2880*	2883	2926*	2929*	2930	2932				
		2973*	2974	2977	3020*	3021*	3025*	3028	3071*	3072*	3076*	3079	3121*	3124*				
		3127	3168*	3169*	3172	3213*	3216	3257*	3258*	3261	3306*	3309*	3317	3348*				
		3380*	3423*	3437*	3467*	3470*	3471	3479	3494*	3524*	3527*	3528	3536	3550*				
		3580*	3583*	3584	3593	3607*	3621*	3937*	3939	3948*	3953*	3954	3963*	3965				
		3974*	3976	3990*	3992	4007	4031*	4033	4114*	4116	4125*	4130*	4131	4140*				
		4142	4151*	4153	4167*	4169	4184	4208*	4210	4290*	4292	4307	4394*	4396				
		4411	4498*	4500	4509*	4514*	4515	4524*	4526	4535*	4537	4551*	4553	4568				
		4592*	4594	4673*	4675	4684*	4689*	4690	4699*	4701	4710*	4712	4726*	4728				
		4743	4767*	4769														
GDDATP	002320	1140#	2141*	2144	2212*	2215												
GLBDAT	002174	1095#																
GLBEQA	002174	976#																
GLBERR	011632	1347#																
GLBSUB	014514	1859#																
GLBTXT	005760	1340#																
GODRVR=	000202	1066#																
GSBIT =	000002	1068#																
GSTAT =	000004	1061#	1911	1984														
G\$CNT0=	000200	898#																
G\$DELM=	000372	898#																
G\$DISP=	000003	898#																
G\$EXCP=	000400	898#																
G\$HILI=	000002	898#																
G\$LOLI=	000001	898#																
G\$NO =	000000	898#																
G\$OFFS=	000400	898#	4793	4797	4802	4807	4813	4844	4850	4856								
G\$OF SI=	000376	898#	4793	4797	4802	4807	4813	4844	4850	4856								
G\$PRMA=	000001	898#	4797	4802														
G\$PRMD=	000002	898#	4807	4813	4850													
G\$PRML=	000000	898#	4793	4844	4856													
G\$RADA=	000140	898#																
G\$RADB=	000000	898#																
G\$RADD=	000040	898#																
G\$RADL=	000120	898#	4793	4844	4856													
G\$RADO=	000020	898#	4797	4802	4807	4813	4850											
G\$XFER=	000004	898#	4848															
G\$YES =	000010	898#	4793	4797	4802	4807	4813	4844	4850	4856								
HCRME	006040	1342#	1943															
HDRBUF	003260	1332#																
HDRLST	015320	1995	2016#															
HINUM	002342	1149#	1692*	1700	1733*	2265	2273	2278*										
HNFMES	006046	1342#	1947	2046														
HOE =	100000	1045#																
HPTCOD	013572	1592#																
HRDPRM	027434	4788#																
IBE =	010000	1042#																
IDU =	000040	1035#																
IER =	020000	1043#																
INITCO	013732	1666#																
INTEN =	000100	1047#	1817	1993	2001	3764	3840	4092	4266	4370	4476	4651						
INTFLG	002250	1120#	2342*	2349*	3762*	3773	3780*	3837*	3846	3851	3858*	4090*	4101	4108*				
		4261*	4275	4282*	4365*	4379	4386*	4474*	4485	4492*	4649*	4660	4667*					

LSACP	002110	G	951#		
LSAPT	002036	G	929#		
LSAU	014510	G	943	1846#	
LSAUT	002070	G	943#		
LSAUTO	014440	G	951	1798#	
LSCCP	002106	G	950#		
LSCLEA	014442	G	950	1806#	
LSCO	002032	G	927#		
LSDEPO	002011	G	918#		
LSDESC	002130	G	946	966#	
LSDESP	002076	G	946#		
LSDEVP	002060	G	939#		
LSDISP	013620	G	930	1624#	
LSDLY	002116	G	954#		
LSDTP	002040	G	930#		
LSDTYP	002034	G	928#		
LSDU	014504	G	944	1834#	
LSDUT	002072	G	944#		
LSDVTY	002122	G	939	963#	
LSEF	002052	G	936#		
LSENV!	002044	G	932#		
LSETP	002102	G	948#		
LSEXP1	002046	G	933#		
LSEXP4	002064	G	941#		
LSEXP5	002066	G	942#		
LSHARD	027436	G	921	4790	4791#
LSHIME	002120	G	955#		
LSHPCP	002016	G	921#		
LSHPTP	002022	G	923#		
LSHW	013574	G	923	1594	1595#
LSICP	002104	G	949#		
LSINIT	013752	G	949	1668#	
LSLADP	002026	G	925#		
LSLAST	030520	G	925	4875#	
LSLOAD	002100	G	947#		
LSLUN	002074	G	945#		
LSMREV	002050	G	934#		
LSNAME	002000	G	909#		
LSPRIO	002042	G	931#		
LSPROT	014432	G	952	1792#	
LSPRT	002112	G	952#		
LSREPP	002062	G	940#		
LSREV	002010	G	917#		
LSOFT	027574	G	922	4842	4843#
LSSPC	002056	G	938#		
LSSPCP	002020	G	922#		
LSPTP	002024	G	924#		
LSSTA	002030	G	926#		
LSW	013610	G	924	1609	1610#
LSTEST	002114	G	953#		
LSTIML	002014	G	920#		
LSUNIT	002012	G	919#	1712	
L10000	011646		1355#		
L10001	011660		1364#		
L10002	011722		1379#		
L10003	012024		1405#		

CROSS REFERENCE TABLE -- USER SYMBOLS

RLDA	002204	1102#	1739*	1983*	2118	2128	2194*	2510*	2517	2678	2685	2834*	2838	2974*
		2976	3212*	3214*	3215	3256*	3259*	3260	3379*	3383	3415*	3434	3438	3472*
		3490	3495	3530*	3586*	3617	3620							
RLMP	002206	1103#	1741*	2119	2129	2130	2190*	2552*	2558	2720	2726	3587*		
SAVCNT	002360	1156#	3985*	3995*	4025	4162*	4172*	4202	4285*	4295*	4325	4389*	4399*	4429
		4546*	4556*	4586	4721*	4731*	4761							
SEEK =	000006	1062#												
SETCMP	016214	2210#	4469											
SETPAT	015752	2139#	3658	3706	3755	3814	3925	4085						
SETRAN	016306	2236#	4643											
SFTPRM	027572	4840#												
SIGN =	000004	1070#												
SIMBCC	016464	2093	2101	2106	2297#									
SIZE =	000004	1088#	4856											
SMSG	027650	4857	4863#											
SPTCOD	013606	1607#												
START	013776	1680	1685	1692#										
START1	014030	1690	1699#											
START2	014064	1701	1711#											
START3	014106	1710	1715#											
STHS =	000100	1072#												
SVCGBL =	000000	898#	907	909	917	918	919	920	921	922	923	924	925	926
		927	928	929	930	931	932	933	934	936	938	939	940	941
		942	943	944	945	946	947	948	949	950	951	952	953	954
		955	963	966	976	1095	1340	1347	1349	1359	1367	1384	1411	1429
		1438	1456	1473	1488	1592	1595	1607	1610	1621	1624	1666	1668	1792
		1798	1804	1806	1832	1834	1844	1846	1859	4788	4791	4840	4843	4875#
		4876												
SVCINS =	000000	898#	909	910	911	912	913	914	915	916	917	918	919	920
		921	922	923	924	925	926	927	928	929	930	931	932	933
		934	935	936	937	938	939	940	941	942	943	944	945	946
		947	948	949	950	951	952	953	954	955	956	963	964	965
		966	972	973	1356	1357	1365	1366	1370	1371	1372	1373	1374	1375
		1376	1377	1380	1381	1387	1388	1389	1390	1391	1392	1393	1394	1395
		1396	1397	1398	1399	1400	1401	1402	1403	1406	1407	1415	1416	1417
		1418	1419	1420	1421	1422	1426	1427	1435	1436	1445	1446	1447	1448
		1449	1450	1453	1454	1459	1460	1461	1462	1463	1464	1465	1470	1471
		1477	1478	1479	1480	1481	1482	1485	1486	1491	1492	1493	1494	1495
		1496	1497	1498	1499	1502	1503	1506	1507	1508	1509	1510	1511	1512
		1513	1514	1517	1518	1519	1520	1521	1522	1523	1524	1525	1526	1527
		1528	1529	1530	1531	1532	1533	1534	1535	1536	1537	1538	1539	1540
		1541	1542	1543	1544	1545	1546	1547	1548	1549	1550	1551	1552	1553
		1554	1555	1556	1557	1558	1559	1562	1563	1564	1565	1566	1567	1568
		1569	1570	1571	1572	1573	1574	1575	1578	1579	1580	1581	1582	1583
		1584	1594	1595	1609	1610	1623	1624	1625	1626	1627	1628	1629	1630
		1631	1632	1633	1634	1635	1636	1637	1638	1639	1640	1641	1642	1643
		1644	1645	1646	1647	1648	1649	1650	1651	1652	1653	1654	1655	1656
		1657	1658	1659	1660	1661	1670	1671	1672	1673	1674	1675	1676	1677
		1678	1679	1680	1681	1682	1683	1684	1685	1686	1687	1688	1689	1690
		1691	1704	1705	1706	1707	1708	1719	1720	1721	1722	1723	1747	1748
		1749	1750	1751	1752	1753	1755	1756	1757	1761	1762	1763	1764	1765
		1766	1767	1769	1770	1771	1773	1774	1775	1776	1777	1778	1779	1781
		1782	1783	1784	1788	1789	1800	1801	1808	1809	1810	1815	1816	1817
		1820	1821	1822	1825	1826	1839	1840	1851	1852	1861	1862	1863	1864
		1871	1872	1873	1874	1875	1876	1878	1879	1880	1881	1882	1964	1965
		1966	1967	1968	2346	2347	2365	2366	2367	2368	2369	2386	2387	2388

CROSS REFERENCE TABLE -- USER SYMBOLS

2389	2390	2418	2419	2420	2421	2422	2423	2424	2427	2428	2429	2434
2435	2436	2437	2438	2439	2440	2442	2443	2461	2462	2463	2464	2465
2466	2467	2470	2471	2472	2477	2478	2479	2480	2481	2482	2483	2485
2486	2503	2504	2505	2506	2507	2508	2509	2512	2513	2514	2519	2520
2521	2522	2523	2524	2525	2527	2528	2545	2546	2547	2548	2549	2550
2551	2554	2555	2556	2561	2562	2563	2564	2565	2566	2567	2569	2570
2586	2587	2588	2589	2590	2591	2592	2595	2596	2597	2602	2603	2604
2605	2606	2607	2608	2610	2611	2629	2630	2631	2632	2633	2634	2635
2638	2639	2640	2645	2646	2647	2648	2649	2650	2651	2653	2654	2671
2672	2673	2674	2675	2676	2677	2680	2681	2682	2687	2688	2689	2690
2691	2692	2693	2695	2696	2713	2714	2715	2716	2717	2718	2719	2722
2723	2724	2729	2730	2731	2732	2733	2734	2735	2737	2738	2758	2759
2760	2767	2768	2776	2777	2778	2779	2780	2783	2784	2805	2806	2810
2811	2812	2813	2814	2818	2819	2837	2838	2842	2843	2844	2845	2846
2850	2851	2872	2873	2887	2888	2889	2890	2891	2892	2893	2894	2902
2903	2905	2906	2924	2925	2936	2937	2938	2939	2940	2941	2942	2943
2950	2951	2953	2954	2971	2972	2981	2982	2983	2984	2985	2986	2987
2988	2996	2997	2999	3000	3017	3018	3032	3033	3034	3035	3036	3037
3038	3039	3047	3048	3050	3051	3068	3069	3083	3084	3085	3086	3087
3088	3089	3090	3096	3097	3099	3100	3118	3119	3131	3132	3133	3134
3135	3136	3137	3138	3144	3145	3147	3148	3165	3166	3176	3177	3178
3179	3180	3181	3182	3183	3189	3190	3192	3193	3210	3211	3220	3221
3222	3223	3224	3225	3226	3227	3233	3234	3236	3237	3254	3255	3265
3266	3267	3268	3269	3270	3271	3272	3278	3279	3281	3282	3303	3304
3305	3312	3313	3321	3322	3323	3324	3325	3328	3329	3350	3351	3355
3356	3357	3358	3359	3363	3364	3382	3383	3387	3388	3389	3390	3391
3395	3396	3427	3428	3429	3430	3431	3432	3433	3441	3442	3443	3444
3445	3450	3451	3483	3484	3485	3486	3487	3488	3489	3498	3499	3500
3501	3502	3505	3506	3540	3541	3542	3543	3544	3545	3546	3554	3555
3556	3557	3558	3563	3564	3597	3598	3599	3600	3601	3602	3603	3611
3612	3613	3614	3615	3616	3617	3624	3625	3626	3627	3628	3634	3635
3661	3662	3668	3669	3672	3673	3674	3675	3676	3677	3678	3680	3681
3685	3686	3709	3710	3716	3717	3720	3721	3722	3723	3724	3725	3726
3728	3729	3733	3734	3758	3759	3760	3761	3762	3769	3770	3771	3772
3773	3776	3777	3778	3779	3780	3782	3783	3785	3786	3790	3791	3817
3818	3819	3820	3821	3822	3823	3824	3825	3826	3827	3828	3835	3836
3837	3854	3855	3856	3857	3858	3860	3861	3865	3866	3867	3872	3873
3874	3875	3876	3877	3878	3879	3880	3881	3882	3883	3884	3885	3886
3887	3888	3890	3891	3895	3896	3924	3925	3933	3934	3936	3937	3942
3943	3944	3945	3946	3947	3948	3957	3958	3959	3960	3961	3962	3963
3968	3969	3970	3971	3972	3973	3974	3979	3980	3981	3982	3983	3984
3985	3999	4000	4001	4002	4003	4006	4007	4008	4009	4010	4011	4012
4013	4014	4015	4016	4017	4018	4025	4026	4027	4028	4029	4030	4031
4036	4037	4038	4039	4040	4041	4042	4044	4045	4055	4056	4084	4085
4088	4089	4090	4097	4098	4099	4100	4101	4104	4105	4106	4107	4108
4110	4111	4113	4114	4119	4120	4121	4122	4123	4124	4125	4134	4135
4136	4137	4138	4139	4140	4145	4146	4147	4148	4149	4150	4151	4156
4157	4158	4159	4160	4161	4162	4176	4177	4178	4179	4180	4183	4184
4185	4186	4187	4188	4189	4190	4191	4192	4193	4194	4195	4202	4203
4204	4205	4206	4207	4208	4213	4214	4215	4216	4217	4218	4219	4221
4222	4232	4233	4263	4264	4265	4271	4272	4273	4274	4275	4278	4279
4280	4281	4282	4284	4285	4299	4300	4301	4302	4303	4306	4307	4308
4309	4310	4311	4312	4313	4314	4315	4316	4317	4318	4325	4326	4327
4328	4329	4330	4331	4336	4337	4367	4368	4369	4375	4376	4377	4378
4379	4382	4383	4384	4385	4386	4388	4389	4403	4404	4405	4406	4407
4410	4411	4412	4413	4414	4415	4416	4417	4418	4419	4420	4421	4422

4429	4430	4431	4432	4433	4434	4435	4439	4440	4468	4469	4472	4473
4474	4481	4482	4483	4484	4485	4488	4489	4490	4491	4492	4494	4495
4497	4498	4503	4504	4505	4506	4507	4508	4509	4518	4519	4520	4521
4522	4523	4524	4529	4530	4531	4532	4533	4534	4535	4540	4541	4542
4543	4544	4545	4546	4560	4561	4562	4563	4564	4567	4568	4569	4570
4571	4572	4573	4574	4575	4576	4577	4578	4579	4586	4587	4588	4589
4590	4591	4592	4597	4598	4599	4600	4601	4602	4603	4605	4606	4615
4616	4645	4646	4647	4648	4649	4656	4657	4658	4659	4660	4663	4664
4665	4666	4667	4669	4670	4672	4673	4678	4679	4680	4681	4682	4683
4684	4693	4694	4695	4696	4697	4698	4699	4704	4705	4706	4707	4708
4709	4710	4715	4716	4717	4718	4719	4720	4721	4735	4736	4737	4738
4739	4742	4743	4744	4745	4746	4747	4748	4749	4750	4751	4752	4753
4754	4761	4762	4763	4764	4765	4766	4767	4772	4773	4774	4775	4776
4777	4778	4780	4781	4785	4786	4790	4791	4793	4794	4795	4796	4797
4798	4799	4800	4801	4802	4803	4804	4805	4806	4807	4808	4809	4810
4811	4812	4813	4814	4815	4816	4817	4818	4820	4821	4842	4843	4844
4845	4846	4847	4848	4849	4850	4851	4852	4853	4854	4855	4856	4857
4858	4859	4860	4861	4872	4873	4874	4875					
898#												
898#	899#	1355	1356	1364	1365	1379	1380	1405	1406	1425	1426	1434
1435	1452	1453	1469	1470	1484	1485	1501	1502	1602	1603	1616	1617
1787	1788	1799	1800	1824	1825	1838	1839	1850	1851	2345	2346	2407
2413	2441	2442	2451	2457	2484	2485	2492	2498	2526	2527	2534	2540
2568	2569	2575	2581	2609	2610	2619	2625	2652	2653	2660	2666	2694
2695	2702	2708	2736	2737	2744	2754	2782	2783	2791	2796	2817	2818
2826	2831	2849	2850	2860	2866	2901	2902	2904	2905	2913	2919	2949
2950	2952	2953	2961	2966	2995	2996	2998	2999	3006	3012	3046	3047
3049	3050	3058	3063	3095	3096	3098	3099	3107	3113	3143	3144	3146
3147	3155	3160	3188	3189	3191	3192	3200	3205	3232	3233	3235	3236
3244	3249	3277	3278	3280	3281	3289	3299	3327	3328	3336	3341	3362
3363	3371	3376	3394	3395	3403	3410	3449	3450	3457	3464	3504	3505
3514	3521	3562	3563	3571	3577	3633	3634	3644	3649	3679	3680	3684
3685	3692	3697	3727	3728	3732	3733	3740	3745	3784	3785	3789	3790
3798	3803	3889	3890	3894	3895	3903	3913	4043	4044	4054	4055	4063
4073	4220	4221	4231	4232	4239	4245	4335	4336	4343	4349	4438	4439
4447	4457	4604	4605	4614	4615	4622	4635	4779	4780	4784	4785	4821
4822	4861	4862										
898#	2406	2448	2491	2533	2574	2616	2659	2701	2742	2789	2824	2856
2911	2959	3005	3056	3105	3153	3198	3242	3287	3334	3369	3401	3456
3511	3568	3642	3690	3738	3796	3901	4061	4237	4341	4445	4620	
898#	1356#	1365#	1380#	1406#	1426#	1435#	1453#	1470#	1485#	1502#	1603#	1617#
1788#	1800#	1825#	1839#	1851#	2346#	2442#	2485#	2527#	2569#	2610#	2653#	2695#
2737#	2783#	2818#	2850#	2872#	2905#	2924#	2953#	2971#	2999#	3017#	3050#	3068#
3099#	3118#	3147#	3165#	3192#	3210#	3236#	3254#	3281#	3328#	3363#	3395#	3450#
3505#	3563#	3634#	3661#	3685#	3709#	3733#	3758#	3790#	3817#	3895#	3924#	4055#
4084#	4232#	4336#	4439#	4468#	4615#	4645#	4785#	4822#	4862#			
1152#	1700*	1733										
1151#	1699*	1732	4639	4640								
1130#	2088*	2089	2091*	2092	2099*	2100	3950*	3951*	3952*	3953	4127*	4128*
4129*	4130	4511*	4512*	4513*	4514	4686*	4687*	4688*	4689			
1126#	2300*	2323*										
1127#	2301*	2305*										
1128#	2302*	2304	2314*	2316	2321*	2322*	2325					
1129#	2089*	2090*	2091	2098*	2099							
2349#	3823											
1146#	1911	1914	1994*	2192*								

SVCSUB= 177777
 SVCTAG= 000000

SVCTST= 177777

S&LSYM= 010000

TEMHI 002350
 TEMLO 002346
 TEMP1 002274
 TEMP2 002264
 TEMP3 002266
 TEMP4 002270
 TEMP5 002272
 TIMSRV 016652
 TMPFNC 002334

TMPO 002276	1131#	1395	3994*	4008	4171*	4185	4294*	4308	4398*	4412	4555*	4569	4730*
	4744												
TMP1 002300	1132#												
TMP2 002302	1133#												
TRPFLG 002246	1119#	1745*	1757	2337*	2416*	2429	2459*	2472	2501*	2514	2543*	2556	2584*
	2597	2627*	2640	2669*	2682	2711*	2724						
TRPHAN 016636	1748	2337#	2419	2462	2504	2546	2587	2630	2672	2714			
T\$ARGC= 000002	909#	910#	911#	912#	913#	914#	1370#	1376	1387#	1391	1393#	1402	1415#
	1421	1445#	1449	1459#	1464	1477#	1481	1491#	1498	1506#	1513	1517#	1526
	1528#	1536	1538#	1547	1549#	1558	1562#	1567	1569#	1574	1578#	1583	1761#
	1766	1871#	1875	4006#	4015	4025#	4030	4183#	4192	4202#	4207	4306#	4315
	4325#	4330	4410#	4419	4429#	4434	4567#	4576	4586#	4591	4742#	4751	4761#
	4766												
T\$CODE= 002130	4793#	4797#	4802#	4807#	4813#	4844#	4848#	4850#	4856#				
T\$ERRN= 000101	898#	1965#	2366#	2387#	2435#	2478#	2520#	2562#	2603#	2646#	2688#	2730#	2777#
	2811#	2843#	2888#	2937#	2982#	3033#	3084#	3132#	3177#	3221#	3266#	3322#	3356#
	3388#	3428#	3442#	3484#	3499#	3541#	3555#	3598#	3612#	3625#	3673#	3721#	3777#
	3855#	3873#	3943#	3958#	3969#	3980#	4000#	4037#	4105#	4120#	4135#	4146#	4157#
	4177#	4214#	4279#	4300#	4383#	4404#	4489#	4504#	4519#	4530#	4541#	4561#	4598#
	4664#	4679#	4694#	4705#	4716#	4736#	4773#						
T\$EXCP= 000000	4797#	4801	4802#	4806	4807#	4812	4813#	4818	4850#	4855			
T\$FLAG= 000040	2892#	2941#	2986#	3037#	3088#	3136#	3181#	3225#	3270#				
T\$GMAN= 000000	898#												
T\$HILI= 177777	4797#	4800	4802#	4805	4807#	4811	4813#	4817	4850#	4854			
T\$LAST= 000001	898#	4873#											
T\$LOLI= 000000	4797#	4799	4802#	4804	4807#	4810	4813#	4816	4850#	4853			
T\$LSYM= 010000	898#	1356	1365	1380	1406	1426	1435	1453	1470	1485	1502	1603	1617
	1788	1800	1825	1839	1851	2346	2442	2485	2527	2569	2610	2653	2695
	2737	2783	2818	2850	2905	2953	2999	3050	3099	3147	3192	3236	3281
	3328	3363	3395	3450	3505	3563	3634	3685	3733	3790	3895	4055	4232
	4336	4439	4615	4785	4822	4862							
T\$LTNO= 000045	4876#												
T\$NEST= 177777	898#	907#	958#	976#	1091#	1095#	1338#	1340#	1343#	1347#	1349#	1355#	1359#
	1364#	1367#	1379#	1384#	1405#	1411#	1425#	1429#	1434#	1438#	1452#	1456#	1469#
	1473#	1484#	1488#	1501#	1590#	1592#	1594#	1602#	1605#	1607#	1609#	1616#	1619#
	1621#	1663#	1666#	1668#	1787#	1791#	1792#	1796#	1798#	1799#	1804#	1806#	1824#
	1828#	1832#	1834#	1838#	1842#	1844#	1846#	1850#	1854#	1859#	2341#	2345#	2400#
	2406#	2441#	2448#	2484#	2491#	2526#	2533#	2568#	2574#	2609#	2616#	2652#	2659#
	2694#	2701#	2736#	2742#	2782#	2789#	2817#	2824#	2849#	2856#	2872#	2901#	2904#
	2911#	2924#	2949#	2952#	2959#	2971#	2995#	2998#	3005#	3017#	3046#	3049#	3056#
	3068#	3095#	3098#	3105#	3118#	3143#	3146#	3153#	3165#	3188#	3191#	3198#	3210#
	3232#	3235#	3242#	3254#	3277#	3280#	3287#	3327#	3334#	3362#	3369#	3394#	3401#
	3449#	3456#	3504#	3511#	3562#	3568#	3633#	3642#	3661#	3679#	3684#	3690#	3709#
	3727#	3732#	3738#	3758#	3784#	3789#	3796#	3817#	3889#	3894#	3901#	3924#	4043#
	4054#	4061#	4084#	4220#	4231#	4237#	4335#	4341#	4438#	4445#	4468#	4604#	4614#
	4620#	4645#	4779#	4784#	4788#	4790#	4820#	4836#	4840#	4842#	4848	4860#	4867#
T\$NSO = 000000	907#	958	976#	1091	1095#	1338	1340#	1343	1347#	1590	1592#	1605	1607#
	1619	1621#	1663	1666#	1791	1792#	1796	1798#	1799	1804#	1828	1832#	1842
	1844#	1854	1859#	2400	2406#	2441	2448#	2484	2491#	2526	2533#	2568	2574#
	2609	2616#	2652	2659#	2694	2701#	2736	2742#	2782	2789#	2817	2824#	2849
	2856#	2904	2911#	2952	2959#	2998	3005#	3049	3056#	3098	3105#	3146	3153#
	3191	3198#	3235	3242#	3280	3287#	3327	3334#	3362	3369#	3394	3401#	3449
	3456#	3504	3511#	3562	3568#	3633	3642#	3684	3690#	3732	3738#	3789	3796#
	3894	3901#	4054	4061#	4231	4237#	4335	4341#	4438	4445#	4614	4620#	4784
	4788#	4836	4840#	4867									
T\$NS1 = 000005	1349#	1355	1359#	1364	1367#	1379	1384#	1405	1411#	1425	1429#	1434	1438#

CROSS REFERENCE TABLE -- USER SYMBOLS

	1452	1456#	1469	1473#	1484	1488#	1501	1594#	1602	1609#	1616	1668#	1787
	1806#	1824	1834#	1838	1846#	1850	2341#	2345	2872#	2901	2924#	2949	2971#
	2995	3017#	3046	3068#	3095	3118#	3143	3165#	3188	3210#	3232	3254#	3277
	3661#	3679	3709#	3727	3758#	3784	3817#	3889	3924#	4043	4084#	4220	4468#
	4604	4645#	4779	4790#	4820	4842#	4848	4860					
T\$PTNU= 000000	898#												
T\$SAVL= 177777	898#												
T\$SEGL= 177777	898#	2872#	2893	2901#	2903	2924#	2942	2949#	2951	2971#	2987	2995#	2997
	3017#	3038	3046#	3048	3068#	3089	3095#	3097	3118#	3137	3143#	3145	3165#
	3182	3188#	3190	3210#	3226	3232#	3234	3254#	3271	3277#	3279	3661#	3679#
	3681	3709#	3727#	3729	3758#	3784#	3786	3817#	3889#	3891	3924#	4043#	4045
T\$SEKO= 010000	4084#	4220#	4222	4468#	4604#	4606	4645#	4779#	4781				
	2872#	2893	2901	2924#	2942	2949	2971#	2987	2995	3017#	3038	3046	3068#
	3089	3095	3118#	3137	3143	3165#	3182	3188	3210#	3226	3232	3254#	3271
	3277	3661#	3679	3709#	3727	3758#	3784	3817#	3889	3924#	4043	4084#	4220
	4468#	4604	4645#	4779									
T\$SUBN= 000000	898#	2406#	2448#	2491#	2533#	2574#	2616#	2659#	2701#	2742#	2789#	2824#	2856#
	2911#	2959#	3005#	3056#	3105#	3153#	3198#	3242#	3287#	3334#	3369#	3401#	3456#
	3511#	3568#	3642#	3690#	3738#	3796#	3901#	4061#	4237#	4341#	4445#	4620#	
T\$TAGL= 177777	898#												
T\$TAGN= 010072	898#	1349#	1359#	1367#	1384#	1411#	1429#	1438#	1456#	1473#	1488#	1594#	1609#
	1668#	1792#	1798#	1806#	1834#	1846#	2341#	2406#	2448#	2491#	2533#	2574#	2616#
	2659#	2701#	2742#	2789#	2824#	2856#	2911#	2959#	3005#	3056#	3105#	3153#	3198#
	3242#	3287#	3334#	3369#	3401#	3456#	3511#	3568#	3642#	3690#	3738#	3796#	3901#
	4061#	4237#	4341#	4445#	4620#	4790#	4842#						
T\$TEMP= 000000	958#	1091#	1338#	1343#	1355#	1364#	1379#	1405#	1425#	1434#	1452#	1469#	1484#
	1501#	1590#	1602#	1605#	1616#	1619#	1624#	1625#	1626#	1627#	1628#	1629#	1630#
	1631#	1632#	1633#	1634#	1635#	1636#	1637#	1638#	1639#	1640#	1641#	1642#	1643#
	1644#	1645#	1646#	1647#	1648#	1649#	1650#	1651#	1652#	1653#	1654#	1655#	1656#
	1657#	1658#	1659#	1660#	1661#	1663#	1787#	1791#	1796#	1799#	1824#	1828#	1838#
	1842#	1850#	1854#	2345#	2400#	2407#	2413#	2441#	2451#	2457#	2484#	2492#	2498#
	2526#	2534#	2540#	2568#	2575#	2581#	2609#	2619#	2625#	2652#	2660#	2666#	2694#
	2702#	2708#	2736#	2744#	2754#	2782#	2791#	2796#	2817#	2826#	2831#	2849#	2860#
	2866#	2892#	2893#	2901#	2904#	2913#	2919#	2941#	2942#	2949#	2952#	2961#	2966#
	2986#	2987#	2995#	2998#	3006#	3012#	3037#	3038#	3046#	3049#	3058#	3063#	3088#
	3089#	3095#	3098#	3107#	3113#	3136#	3137#	3143#	3146#	3155#	3160#	3181#	3182#
	3188#	3191#	3200#	3205#	3225#	3226#	3232#	3235#	3244#	3249#	3270#	3271#	3277#
	3280#	3289#	3299#	3327#	3336#	3341#	3362#	3371#	3376#	3394#	3403#	3410#	3449#
	3457#	3464#	3504#	3514#	3521#	3562#	3571#	3577#	3633#	3644#	3649#	3679#	3684#
	3692#	3697#	3727#	3732#	3740#	3745#	3784#	3789#	3798#	3803#	3889#	3894#	3903#
	3913#	4043#	4054#	4063#	4073#	4220#	4231#	4239#	4245#	4335#	4343#	4349#	4438#
	4447#	4457#	4604#	4614#	4622#	4635#	4779#	4784#	4793#	4797#	4802#	4807#	4813#
	4820#	4836#	4844#	4850#	4856#	4860#	4867#						
T\$TEST= 000045	898#	2406#	2448#	2491#	2533#	2574#	2616#	2659#	2701#	2742#	2789#	2824#	2856#
	2911#	2959#	3005#	3056#	3105#	3153#	3198#	3242#	3287#	3334#	3369#	3401#	3456#
	3511#	3568#	3642#	3690#	3738#	3796#	3901#	4061#	4237#	4341#	4445#	4620#	4876
T\$TSM= 177777	898#	1356	1365	1375	1380	1390	1401	1406	1420	1426	1435	1448	1453
	1463	1470	1480	1485	1497	1502	1512	1525	1535	1546	1557	1566	1573
	1582	1670	1673	1678	1683	1688	1705	1720	1751	1756	1765	1770	1777
	1781	1788	1800	1809	1816	1821	1825	1839	1851	1861	1874	1879	1881
	1964	2365	2386	2422	2428	2434	2439	2442	2465	2471	2477	2482	2485
	2507	2513	2519	2524	2527	2549	2555	2561	2566	2569	2590	2596	2602
	2607	2610	2633	2639	2645	2650	2653	2675	2681	2687	2692	2695	2717
	2723	2729	2734	2737	2759	2767	2776	2783	2805	2810	2813	2837	2842
	2850	2872	2887	2892	2902	2905	2924	2936	2941	2950	2953	2971	2981
	2986	2996	2999	3017	3032	3037	3047	3050	3068	3083	3088	3096	3099

T20	021246 G	1643	3242#																	
T21	021346 G	1644	3287#																	
T22	021456 G	1645	3334#																	
T23	021530 G	1646	3369#																	
T24	021566 G	1647	3401#																	
T25	021712 G	1648	3456#																	
T26	022052 G	1649	3511#																	
T27	022212 G	1650	3568#																	
T28	022416 G	1651	3642#																	
T29	022526 G	1652	3690#																	
T3	017176 G	1626	2491#																	
T30	022636 G	1653	3738#																	
T31	022772 G	1654	3796#																	
T32	023324 G	1655	3901#																	
T33	024136 G	1656	4061#																	
T34	025014 G	1657	4237#																	
T35	025362 G	1658	4341#																	
T36	025734 G	1659	4445#																	
T37	026612 G	1660	4620#																	
T4	017274 G	1627	2533#																	
T5	017372 G	1628	2574#																	
T6	017466 G	1629	2616#																	
T7	017562 G	1630	2659#																	
T8	017656 G	1631	2701#																	
T9	017752 G	1632	2742#																	
UAM	= 000200 G	1037#																		
UNITST	002176	1099#	1711*	1715*	1719	1769	1878													
UUT	002174	1098#	1709	1712*	1717*															
VECMG	027535	4803	4827#																	
VECT	= 000002	1078#	4802																	
WDELAY	016032	2165#	2359	2378	3843															
WHY	002330	1144#	1759*	1761																
WRCHK	= 000002	1060#	1914																	
WRITE	= 000012	1064#																		
WTCRDY	016724	2374#	3666	3714	3767	3931	4095	4269	4373	4479	4654									
WTDY	016660	2354#																		
XPOLY	002254	1122#	2310	2321																
X\$ALWA	= 000000	898#																		
X\$FALS	= 000040	898#	4848																	
X\$OFFS	= 000400	898#	4848																	
X\$TRUE	= 000020	898#																		
.	= 030520	900#	1158#	1332#	1335#	1336#	1342#	2893	2942	2987	3038	3089	3137	3182						
		3226	3271	4848	4864#	4868#														

. ABS. 030520 000

ERRORS DETECTED: 0

CVRLAC, CVRLAC/CRF:SYM/NL:TOC/SOL=CVRLAC/ML, CVRLAC.P11
RUN-TIME: 30 30 2 SECONDS
RUN-TIME RATIO: 124/62=1.9
CORE USED: 18K (36 PAGES)