

801

COMBINED EXERCISES

MAC: 11 27 732 21-OCT-76 13:50 PAGE 2

1-11-76

.REM *

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DDDUA-A-D
PRODUCT NAME: DU11 OFFLINE COMBINED EXERCISER
DATE RELEASED: 21 DECEMBER 1975
MAINTAINER: DIAGNOSTIC GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH A LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975 DIGITAL EQUIPMENT CORPORATION

*

GENERAL DESCRIPTION

THIS DIAGNOSTIC CAN CHAIN 16 DU11'S. THIS MEANS THAT 16 DEVICES CAN BE SEQUENTIALLY EXERCISED. THE DIAGNOSTIC MAKES ONE PASS BEFORE PROCEEDING TO THE NEXT DEVICE, AND CONTINUES EXERCISING ALL DEVICES IN THIS FASHION UNTIL HALTED.

THIS DIAGNOSTIC CAN BE RUN WITH OR WITHOUT A CONSOLE TELETYPE.

THE AUTOSIZER PROGRAM MUST BE RUN PRIOR TO THIS DIAGNOSTIC TO MAKE SURE THAT THE DEVICE EXISTS IN THE SYSTEM.

1. THE DU11 OFFLINE COMBINED EXERCIZER FOR PRODUCTION TESTS THAT THE TRANSMITTER AND RECEIVER CHIPS WORK PROPERLY, PERFORM TESTING OF THE ASSOCIATED LOGIC ON THE OPTION AND CHECK THE OPERATION OF THE INTERRUPT LOGIC. IT CAN BE USED ON THE "XOR", DDP ACT 11, AND THE "CHIP TESTER". TO USE ON THE "XOR" TESTER, THE BRANCH AROUND THE "XOR" CODE MUST BE PATCHED TO A "NOP". (SEE LISTINGS FOR DETAILS)

2. REQUIREMENTS

PDP-11 FAMILY STANDARD COMPUTER WITH MINIMUM 4K MEMORY

DU11 SYNCHRONOUS/ISOCRONOUS OPTION

ONE CONSOLE TELETYPE OR EQUIVALENT --- OPTIONAL.

- 2.2 STORAGE

THE PROGRAM LOADS INTO 4K OF MEMORY WITH BOOTSTRAP

3. LOADING PROCEDURE

THE STANDARD PROCEDURE FOR LOADING ABSOLUTE BINARY TAPES IS TO BE USED.

STARTING ADDRESS
FOR ABSOLUTE LOADER

4K	017500
8K	037500
12K	057500
16K	077500
20K	117500
24K	137500
28K	157500

4. STARTING PROCEDURE

- 4.1 CONTROL SWITCH SETTINGS

- 4.1.1 AFTER PROGRAM LOAD (INITIAL PROGRAM START)
ALL CONSOLE SWITCHES DOWN
- 4.1.2 TO MODIFY DEVICE VECTOR AND CONTROL REGISTER ADDRESSES
AFTER PROGRAM RESTART OR TO RUN MULTIPLE DEVICES
- SW00=1
- 4.1.3 TO START PROGRAM AT SELECTED TEST AFTER A PROGRAM RESTART
(ONLY IN SINGLE DEVICE TESTS AND ONLY IF THERE IS A TTY, THAT
IS, THERE CAN BE CONVERSATION BETWEEN TTY AND THE SYSTEM)
SW01=1
- 4.1.4 TO LOCK ON SELECTED TEST AFTER A PROGRAM RESTART
(ONLY IN SINGLE DEVICE TESTS AND ONLY IF THERE IS A TTY)

SW02=1

NOTE1: IN GENERAL SW01 WILL BE USED WHEN SW02=1 IS USED

NOTE2: WITHOUT SW01=1 "LOCK ON TEST" WILL DEFAULT TO TEST 1
STARTING ADDRESS

4.2

THE STARTING ADDRESS FOR ALL TESTS IS 000200

THE RETARTING ADDRESS FOR ALL TESTS IS 000200
 THE STARTING ADDRESS TO ENTER A SELECTED TEST IS 000200
 THE STARTING ADDRESS TO LOCK ON TEST IS 000200

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 INITIAL PROGRAM START

EITHER A) ONLY IF THERE IS NO TTY ---

- 4.3.1.1 LOAD PROGRAM INTO MEMORY WITH ABSOLUTE LOADER
- 4.3.1.2 PATCH THE TAGS TPCSR AND TPDBR WITH 177570
- 4.3.1.3 LOAD ADDRESS 000200
- 4.3.1.4 CLEAR CONSOLE SWITCHES
- 4.3.1.5 SET SW15=1, SW07=1, SW06=1
- 4.3.1.6 PRESS START

IF THERE ARE NO ERRORS, PROGRAM WILL RUN
 FOR ABOUT 22 SECONDS, AT THE END OF WHICH THERE
 WILL BE "5" ON THE DISPLAY LIGHTS FOR COUPLE
 OF SECONDS AND THEN PROGRAM WILL HALT AT ADDRESS
 252 FOR END OF PASS. PRESS CONTINUE TO CONTINUE THE PROGRAM.
 IF ANY ERROR ENCOUNTERED, PROGRAM WILL HALT AT ADDRESS 14340

TO DETERMINE TYPE OF ERROR:

- 4.3.1.7 LOAD ADDRESS 017400

4.3.1.8 PRESS EXAMINE
CONTENT OF THIS LOCATION IS -- - RECEIVER ERROR PC

4.3.1.9 PRESS EXAMINE
CONTENT IS --- ADDRESS OF REGISTER

4.3.1.10 PRESS EXAMINE
CONTENT IS --- EXPECTED VALUE

4.3.1.11 PRESS EXAMINE
CONTENT IS --- ACTUAL VALUE

TO TEST IF THERE IS ANY MORE ERROR IN ANY OTHER TEST

4.3.1.12 LOAD ADDRESS 000200

4.3.1.13 CLEAR CONSOLE SWITCHES

4.3.1.14 SET SW15 = 1

4.3.1.15 SET SW11 = 1

4.3.1.16 SET SW07 = 1

4.3.1.17 SET SW06 = 1

4.3.1.18 PRESS START

PROGRAM WILL HALT FOR THE FIRST ERROR THAT WAS JUST OBSERVED

4.3.1.19 PRESS CONTINUE (SW15 = 1, SW11 = 1, SW07 = 1)

IF THE PROGRAM HALTS AT ADDRESS 014340:

4.3.1.20 LOAD ADDRESS 017400

4.3.1.21 PRESS EXAMINE

CONTENT IS THE NEW RECEIVER ERROR PC FOR THE 2ND ERROR.

NEXT THREE LOCATIONS CONTAIN

ADDRESS OF THE REGISTER, EXPECTED VALUE, AND ACTUAL VALUE

TESTS 4.3.1.12 THRU 4.3.1.21 CAN BE REPEATED FOR ANY
FURTHER ERROR.

OR B) IF THERE IS A TTY ---

- 4.3.1.1 LOAD PROGRAM INTO MEMORY WITH ABSOLUTE LOADER
- 4.3.1.2 LOAD ADDRESS 000200
- 4.3.1.3 CLEAR CONSOLE SWITCHES
- 4.3.1.4 PRESS START
- 4.3.1.5 THE PROGRAM WILL TYPE "DU11 DDJJA-A TAPE COMBINED EXERCIZER" (ONCE ONLY)
- 4.3.1.6 THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT IS ABOUT TO START TESTING AND THEN TESTING WILL BEGIN

IF THE SYSTEM DOES NOT HAVE A TTY DO NOT

PERFORM THE FOLLOWING STEPS :

4.3.2, 4.3.3, 4.3.4, 4.3.5

- 4.3.2 PROGRAM RESTART WITH ALL SWITCHES DOWN
 - 4.3.2.1 THE PROGRAM WILL TYPE "R" AND WILL COMMENCE TESTING
- 4.3.3 PROGRAM RESTART WITH SW00=1
 - 4.3.3.1 LOAD ADDRESS 000200
 - 4.3.3.2 SET SW00=1
 - 4.3.3.3 PRESS START
 - 4.3.3.4 THE PROGRAM WILL TYPE "1ST DEVICE: RECEIVER CONTROL REGISTER ADDRESS" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD
 - 4.3.3.5 TYPE IN THE ADDRESS OF THE FIRST RECEIVER CONTROL REGISTER ADDRESS OF THE DU11 TO BE TESTED FOLLOWED BY A <CARRIAGE RETURN>
 - IF AN INCORRECT ADDRESS IS TYPED THE PROGRAM WILL TYPE "?" AND WILL THEN REPEAT THE MESSAGE OF 4.3.3.4
 - 4.3.3.6 THE PROGRAM WILL TYPE "VECTOR ADDRESS-" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD
 - 4.3.3.7 TYPE IN THE BASE RECEIVER INTERRUPT VECTOR ADDRESS FOR THE DU11 TO BE TESTED FOLLOWED BY A <CARRIAGE RETURN>
 - IF AN INCORRECT ADDRESS IS TYPED THE PROGRAM WILL TYPE "?" AND WILL THEN REPEAT THE MESSAGE OF 4.3.3.6

4.3.3.8 THE PROGRAM WILL TYPE "ARE YOU RUNNING MULTIPLE DEVICES ?"
(Y OR N)-" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.9 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED BY A
<CARRIAGE RETURN>

IF AN INCORRECT ANSWER IS GIVEN, THE PROGRAM WILL TYPE "?"
AND WILL THEN REPEAT THE MESSAGE OF 4.3.3.8

IF A "NO" ANSWER IS GIVEN: JUMP TO SECTION 4.3.3.12
IF A "YES" ANSWER IS GIVEN: THE NEXT QUESTION IS ASKED

4.3.3.10 THE PROGRAM WILL TYPE "LAST DEVICE:RECEIVER CONTROL
REGISTER ADDRESS-" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.11 TYPE IN THE ADDRESS OF THE LAST RECEIVER CONTROL REGISTER
ADDRESS OF THE DU11 TO BE TESTED FOLLOWED BY A <CARRIAGE RETURN>

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL THEN REPEAT THE MESSAGE OF 4.3.3.10
NOTE:ALL ADDRESSES SHALL BE CONTIGUOUS

4.3.3.11.1 IF AN "OUT OF RANGE" ADDRESS IS TYPED
IE. MORE THAN 16 (10) DEVICES AWAY (UPWARDS).....THE
PROGRAM WILL TYPE "OUT OF RANGE:RETYPE LAST DEVICE RXCSR ADDRESS-"
AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.11.2 TYPE IN THE ADDRESS OF THE LAST RECEIVER CONTROL
REGISTER ADDRESS OF THE DU11 TO BE TESTED FOLLOWED
BY A <CARRIAGE RETURN>

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL REPEAT THE MESSAGE OF 4.3.3.11.1

IF A DEVICE ADDRESS LOWER THAN 1ST DEVICE ADDRESS IS TYPED.....
.....SCHOOLS OUT.....THERE IS NO PROTECTION FOR THIS.
THE PROGRAM WILL DEFAULT TO TWO DEVICES ACTIVE (UPWARDS FROM
1ST DEVICE ADDRESS).THE SAME APPLIES TO IDENTICAL ADDRESSES
TYPED FOR FIRST AND LAST DEVICE.
OBSERVE LOCATION 2 ACTREG: SEE SECTION 7.2

4.3.3.12 THE PROGRAM WILL TYPE "DU PRIORITY LEVEL-" AND
WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.13 TYPE IN THE APPROPRIATE DEVICE PRIORITY LEVEL OF THE
DU11 OR DU11'S TO BE TESTED FOLLOWED BY A <CARRIAGE RETURN>
(NOTE THAT ALL MULTIPLE DEVICES MUST BE AT THE SAME PRIORITY
LEVEL). IE "5"

IF AN INCORRECT LEVEL IS TYPED ,THE PROGRAM WILL TYPE "?"
AND REPEAT THE MESSAGE OF 4.3.3.12

4.3.3.14 THE PROGRAM WILL TYPE "# OF SYNC CHARS
SELECTED (1 OR 2)-" AND WAIT FOR AN INPUT FROM THE TELETYPE
KEYBOARD

4.3.3.15 TYPE IN THE APPROPRIATE ANSWER "1" OR "2" FOLLOWED
BY A <CARRIAGE RETURN>. (NOTE: ALL MULTIPLE DEVICES MUST
BE THE SAME)

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL REPEAT THE MESSAGE OF 4.3.3.14

4.3.3.16 THE PROGRAM WILL TYPE " IS SEC XMIT JUMPER #6 IN ? (Y OR N)-"
AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.17 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED
BY A <CARRIAGE RETURN>. (NOTE THAT ALL MULTIPLE DEVICES
MUST BE THE SAME)

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL REPEAT THE MESSAGE OF 4.3.3.16

4.3.3.18 THE PROGRAM WILL TYPE "IS SEC REC JUMPER # 5 IN ?
(Y OR N)-" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.19 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED
BY A <CARRIAGE RETURN>. (NOTE: ALL MULTIPLE DEVICES MUST BE THE SAME)

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL REPEAT THE MESSAGE OF 4.3.3.18

4.3.3.20 THE PROGRAM WILL TYPE "IS OPT CLR ENABLE JUMPER
4 IN ? (Y OR N)-" AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.3.21 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED
BY A <CARRIAGE RETURN>. (NOTE: ALL MULTIPLE DEVICES MUST BE THE SAME)

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"
AND WILL REPEAT THE MESSAGE OF 4.3.3.20

4.3.3.22 THE PROGRAM WILL TYPE "ARE YOU RUNNING IN MAINT.
MODE EXTERNAL ? ANDDO YOU HAVE THE EXTERNAL MODEM
BYPASS JUMPER CONNECTOR ON ? (Y OR N)-" AND WAIT FOR AN
INPUT FROM THE TELETYPE KEYBOARD

4.3.3.23 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED BY
A <CARRIAGE RETURN>. (NOTE: ALL MULTIPLE DEVICES MUST BE THE SAME)

IF AN INCORRECT ANSWER IS TYPED ,THE PROGRAM WILL TYPE "?"

AND WILL REPEAT THE MESSAGE OF 4.3.3.22

4.3.3.24 THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT
HAS STARTED AND WILL COMMENCE TESTING AT TEST 1

4.3.4 PROGRAM RESTART WITH SW01=1
NOTE: THIS WILL ONLY WORK WHEN A SINGLE DEVICE IS SELECTED
...IT WILL NOT WORK IF MULTIPLE DEVICES ARE SELECTED

IF MULTIPLE DEVICES WERE PREVIOUSLY SELECTED, LOAD 000200,
AND SELECT SW00=1 AND ANSWER "NO" TO THE MULTIPLE DEVICE QUESTION
SEE 4.3.3

4.3.4.1 LOAD 000200

4.3.4.2 SET SW01=1

4.3.4.3 PRESS START

4.3.4.4 THE PROGRAM WILL TYPE "TEST PC-" AND WAIT FOR AN INPUT FROM
THE TELETYPE KEYBOARD

4.3.4.5 TYPE IN THE ADDRESS OF THE TEST AT WHICH THE PROGRAM IS TO
BE STARTED FOLLOWED BY A <CARRIAGE RETURN>

4.3.4.6 THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT HAS STARTED
TESTING AT THE SELECTED TEST

NOTE: CARE MUST BE TAKEN WHEN THIS FEATURE IS USED
SINCE THERE IS NO PROTECTION AGAINST SELECTING AN ADDRESS
THAT IS IN THE MIDDLE OF A TEST

4.3.5 PROGRAM RESTART WITH SW02 =1
NOTE: THIS WILL ONLY WORK WHEN A SINGLE DEVICE IS SELECTED
SEE NOTE IN 4.3.4 FOR MORE DETAILS

4.3.5.1 LOAD ADDRESS 000200

4.3.5.2 SET SW02 =1
NOTE: IT MAY BE ADVANTAGEOUS TO SET SW01=1 (OPTIONAL)

4.3.5.3 PRESS START

4.3.5.4 THE PROGRAM WILL TYPE "LOCK ON SELECTED TEST ? (Y OR N)-"
AND WAIT FOR AN INPUT FROM THE TELETYPE KEYBOARD

4.3.5.5 TYPE IN THE APPROPRIATE ANSWER YES OR NO FOLLOWED BY A
<CARRIAGE RETURN>

IF A NO ANSWER IS GIVEN: THIS LOCK ON TEST WILL BE IGNORED
AND THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT HAS STARTED
TESTING AT TEST 1

4.3.5.6 IF A YES ANSWER WAS GIVEN: THE PROGRAM WILL ACT AS FOLLOWS...
THE PROGRAM WILL TYPE "R" TO INDICATE THAT IT HAS STARTED

TESTING AT TEST 1 AND WILL REMAIN IN TEST 1 UNTIL HALTED
OR IF ANY KEY IS STRUCK ON THE TELETYPE THE PROGRAM
WILL FREEZE ON THE NEXT TEST UNTIL A KEY IS STRUCK ON
THE TELETYPE AND SO FORTH THRU THE PROGRAM. IF SW01 =1 IT
WILL PERFORM AS IN SECTION 4.3.4 ALLOWING ONE TO FREEZE
ON A SELECTED TEST RATHER THAN DEFAULTING TO TEST 1

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SW15 =1 HALT ON ERROR
SW14 =1 LOOP ON CURRENT TEST
SW13 =1 INHIBIT ERROR TYPEOUT
SW11 =1 INHIBIT ITERATIONS
SW10 =1 ESCAPE TO NEXT TEST ON ERROR
SW09 =1 LOOP ON ERROR
SW06 =1 HALT ON END OF PASS
SW02 =1 LOCK ON TEST
SW01 =1 RESTART PROGRAM AT SELECTED TEST
SW00 =1 RESELECT VECTOR AND CONTROL REGISTER ADDRESSES
&PARAMETERS AFTER A PROGRAM RESTART
TO INHIBIT "END OF PASS" TYPEOUT - TURN TELETYPE OFF

6. ERRORS

6.1 ERROR HALTS

THERE ARE FOUR DISTINCT ERROR TYPEOUTS

5.1.1 PC+2 = ERROR PC

WHERE PC +2 IS THE ADDRESS OF THE CALL TO THE ERROR HANDLER +2

REFER TO THE ABOVE "HLT" IN DIAGNOSTIC FOR ERROR DESCRIPTION

CHECK ADDRESS @ RXCSR: TO LOCATE THE DEVICE PRESENTLY UNDER
TEST WHEN RUNNING MULTIPLE DEVICES

6.1.2 PC +2 = REGISTER ERROR PC

REGISTER	EXPECTED	ACTUAL
16XXXX	YYYYYY	ZZZZZZ

WHERE 16XXXX IS THE ADDRESS OF THE FAILING DEVICE REGISTER

WHERE YYYYYY IS THE EXPECTED CONTENTS OF THAT REGISTER

WHERE ZZZZZZ IS THE ACTUAL CONTENTS OF THAT REGISTER

6.1.3 PC +2 = RECEIVER ERROR PC

REGISTER	EXPECTED	ACTUAL
16XXXX	YYYYYY	ZZZZZZ

WHERE 16XXXX IS THE ADDRESS OF THE FAILING RECEIVER (RXDBUF) REGISTER

WHERE YYYYYY IS THE EXPECTED DATA CONTENTS OF THAT REGISTER

WHERE ZZZZZZ IS THE ACTUAL DATA CONTENTS OF THAT REGISTER

6.1.4 PC +2 = TRANSMITTER ERROR PC
REGISTER EXPECTED ACTUAL
16XXXX YYYYYY ZZZZZZ

WHERE 16XXXX IS THE ADDRESS OF THE FAILING TRANSMITTER (TXCSR) REGISTER

WHERE YYYYYY IS THE EXPECTED CONTENTS OF THAT REGISTER

WHERE ZZZZZZ IS THE ACTUAL CONTENTS OF THAT REGISTER

6.1.5 ERROR DESCRIPTIONS
SEE LISTINGS FOR DETAILS OF ERRORS

6.2 ERROR RECOVERY

6.2.1 SW15 =0
IF THE PROGRAM IS RUN WITH SW15 =0 ,NO OPERATOR ACTION IS
REQUIRED TO CONTINUE TESTING

6.2.2 SW15 =1
IF THE PROGRAM IS RUN WITH SW15 =1 ,TO CONTINUE TESTING
AFTER THE PROGRAM HAS HALTED ,PRESS THE PROCESSOR
CONSOLE "CONTINUE SWITCH"

NOTE: THE PC + 2 OF THE "HLT" WILL BE DISPLAYED IN THE DATA LIGHTS.

6.2.3 ILLEGAL INTERRUPTS
IF AN INTERRUPT OCCURS TO A VECTOR ADDRESS NOT SELECTED
DURING PROGRAM INITIALIZATION, THE PROGRAM WILL HALT IN
THE TRAPCATCHER. THE ADDRESS AT WHICH THE PROGRAM
HALTS IS 2 GREATER THAN THE ADDRESS TO WHICH THE INTERRUPT
OCCURED. THE PROGRAM MUST BE RESTARTED AT 000200 TO
RECOVER FROM THIS ERROR.

6.2.4 ADDITIONAL TROUBLESHOOTING AIDS ERRCNT: & PASCNT:
CHECK THESE TWO TAG LOCATIONS FOR TOTAL # OF ERRORS AND PASSES RESPECTIVELY.
LOADING 000200 AND RESTARTING WILL CLR THESE LOCATIONS.

6.3 END OF PASS ROUTINE
THIS TIMEOUT IS MENTIONED HERE FOR CONVENIENCE
IT IS IN THE FORM:

END OF PASS TAPE Y
16XXXX = DEVICE

WHERE Y IS THE TAPE LOADED

WHERE 16XXXX IS THE DEVICE'S BASE REGISTER ADDRESS

TO INHIBIT THIS TIMEOUT - TURN TELETYPE OFF

7. RESTRICTIONS

7.1 MULTIPLE DEVICES
UP TO 16(10) DEVICES MAY BE TESTED. HOWEVER, THEY
MUST HAVE CONTIGUOUS ADDRESSES AND VECTORS

NOTE: IF ALL DEVICES UNDER TEST HAVE THE SAME INTERRUPT VECTOR
YOU CAN CHANGE "ZERO: ADD #10,BASEIV ;NEXT BLOCK
(VECTORS)" TO "ZERO: ADD #0,BASEIV";
THEREBY THE VECTOR ADDRESSES WILL NOT BE
UPDATED AFTER EACH PASS.

- 7.2 DISQUALIFYING DEVICES WHEN RUNNING MULTIPLE DEVICES
WHEN RUNNING MULTIPLE DEVICES AN ACTIVE BIT IS SET
FOR EACH DEVICE RUNNING UNDER TEST IE. BIT 0 FOR
DEVICE 0 BIT 15 FOR DEVICE 15
TO DISQUALIFY DEVICES:
 - 7.2.1 IF DEVICE 0 IS TO BE DISQUALIFIED, SIMPLY RESTART
PROGRAM WITH SW00 =1 AND OMIT THE FIRST DEVICE.
 - 7.2.2 IF HOWEVER, DEVICES 1 THRU 15 OR ANY COMBINATION THEREOF
ARE TO BE DISQUALIFIED...LOAD THE LOCATION OF ACTREG:
OBSERVE THE ACTIVE BITS (ACTIVE =1, NONACTIVE = 0)
AND DEPOSIT 0 WHERE THOSE DEVICES ARE TO BE DISQUALIFIED
 - 7.2.2.1 TO RESTART...LOAD 000200 IN SWR AND DEPRESS START....
THE PROGRAM WILL CONTINUE WITH THE DEVICE IT WAS IN BEFORE HALTING.
 - 7.2.2.2ORLOAD 000200 WITH SW00 =1 AND DEPRESS START....
ANSWER THE QUESTION :1ST DEVICE : ETC.....
.....THE PROGRAM WILL CONTINUE WITH DEVICE 0
 - 7.2.2.3 IF ALL DEVICES ARE DISQUALIFIED BY MISTAKE THE PROGRAM
WILL TYPEOUT AN ERROR MESSAGE.....LOAD & START AT 000200
- 7.3 CABLE DELAYS
NOTE: EXTERNAL LOOP BACK TESTS ONLY (MODEM CABLE WITH H315 CONNECTOR ON)
 - 7.3.1 TO PROVIDE SUFFICIENT DELAY FOR CLOCK SIGNAL OVER THE CABLE,
LOCATION "HOLD:" MUST BE MODIFIED TO ACCOMODATE FOR FASTER MACHINES.
PRESENTLY "HOLD:" =20 IS SUFFICIENT TIME ON AN 11/20 MACHINE.
IF RUNNING ON AN 11/40 OR AN 11/45 "HOLD:" MUST BE PPTCHED TO 40
BASICALLY DON'T TRY TO EXCEED 10K TO 12K RATE USING THE EIA DRIVERS
- 7.4 TO USE THE "XOR" TESTER, THE BRANCH AROUND THE "XOR"
CODE MUST BE PATCHED TO A "NOP". (SEE LISTINGS FOR DETAILS)
- 8. DEFAULT PARAMETERS:
1ST DEVICE: RECEIVER CONTROL REGISTER ADDRESS- RXCSR: 160040
VECTOR ADDRESS- DURIV: 770
ARE YOU RUNNING MULTIPLE DEVICES ?- NO MULTD: 0
LAST DEVICE: RECEIVER CONTROL REGISTER ADDRESS- LASTADD: 0
DU PRIORITY LEVEL- LEVEL 5 DUPRT: LEVEL 5

OF SYNC CHARS SELECTED - 2 SYNCNO: 377
IS SEC XMIT JUMPER # 6 IN ?- YES SEXMIT: 377
IS SEC REC JUMPER # 5 IN ?- YES SEREC: 377
IS OPT CLR ENABLE JUMPER # 4 IN ?- YES OPTCLR: 377
DO YOU HAVE THE EXTERNAL MODEM BYPASS JUMPER
CONNECTOR ON (H315)- YES JMRBY: 377

9. PROGRAM DESCRIPTION

9.1 THIS PROGRAM PERFORMS THE OFFLINE COMBINED (TRANSMITTER & RECEIVER)
TIMING & INTERRUPT TESTING OF THE DEVICE
SEE LISTING FOR DETAILS

10. FLOW CHARTS: RECEIVER FLOW, TRANSMITTER FLOW, TRANSMITTER & RECEIVER FLOW

11. LISTINGS

:

*

529
530
531
532

.LIST LUC.BIN.SEG
.ENABLE ABS
.ENABLE AMA

667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722000000
000001
000002
000003
000004
000005
000006
000007

177570
177570
177776
001100

005746
005726
010046
012600
024646
022626

100000
040000
020000
010000
004000
002000
001000
000400
000200
000100
000040
000020
000010
000004
000002
000001

000340
000300
000240
000200
000140
000100
000040

;REGISTER DEFINITIONS

R0=%0 ;GENERAL REGISTER
R1=%1 ;GENERAL REGISTER
R2=%2 ;GENERAL REGISTER
R3=%3 ;GENERAL REGISTER
R4=%4 ;GENERAL REGISTER
R5=%5 ;GENERAL REGISTER
SP=%6 ;PROCESSOR STACK POINTER
PC=%7 ;PROGRAM COUNTER

;LOCATION EQUIVALENCIES

SWR=177570 ;CONSOLE SWITCH REGISTER
LIGHTS=177570 ;PDP-11/45 DISPLAY REGISTER
PS=177776 ;PROCESSOR STATUS WORD
STACK=1100 ;START OF PROCESSOR STACK

;INSTRUCTION DEFINITIONS

PUSH1SP=5746 ;DECREMENT PROCESSOR STACK 1 WORD =TST -(SP)
POP1SP=5726 ;INCREMENT PROCESSOR STACK 1 WORD =TST (SP)+
PUSHRO=10046 ;SAVE RO ON STACK =MOV RO, -(SP)
POPRO=12600 ;RESTORE RO FROM STACK =MOV (SP)+, RO
PUSH2SP=24646 ;DECREMENT STACK TWICE =CMP -(SP), -(SP)
POP2SP=22626 ;INCREMENT STACK TWICE =CMP (SP)+, (SP)+
.EQUIV EMT,HLT ;BASIC DEFINITION OF ERROR CALLBIT15=100000
BIT14=40000
BIT13=20000
BIT12=10000
BIT11=4000
BIT10=2000
BIT9=1000
BIT8=400
BIT7=200
BIT6=100
BIT5=40
BIT4=20
BIT3=10
BIT2=4
BIT1=2
BIT0=1

;PROCESSOR LEVELS

LEVEL7=340
LEVEL6=300
LEVEL5=240
LEVEL4=200
LEVEL3=140
LEVEL2=100
LEVEL1=040

```

723          000000          _LEVEL=000
724          ;REGISTER DEFINITIONS
725          ;RXCSR BIT DEFINITIONS
726          100000          DSC=BIT15          ;DATA SET CHANGE
727          040000          RING=BIT14          ;RING
728          020000          CTS=BIT13          ;CLR TO SEND
729          010000          CARDET=BIT12         ;CARRIER DETECT
730          004000          RECACT=BIT11        ;REC ACTIVE
731          002000          SRD=BIT10          ;SEC REC DATA
732          001000          DSR=BIT9          ;DATA SET RDY
733          000400          STPSYN=BIT8         ;STRIP SYNC
734          000200          RXDONE=BIT7        ;REC DONE
735          000100          RINTEN=BIT6        ;REC INTR ENABLE
736          000040          DSINTE=BIT5        ;DSC INTR ENABLE
737          000020          SYNSch=BIT4        ;SYNC SEARCH
738          000010          STD=BIT3          ;SEC XMIT DATA
739          000004          RTS=BIT2          ;REQ TO SEND
740          000002          DTR=BIT1          ;DATA TERM RDY
741          000001          VOID=BIT0
742          ;RXDBUF BIT DEFINITIONS
743          100000          RXERR=BIT15         ;REC ERROR
744          040000          OVRUN=BIT14        ;OVERRUN
745          020000          FRMERR=BIT13       ;FRAME ERROR
746          010000          PARER=BIT12       ;PARITY ERROR
747          ;PARCSR BIT DEFINITIONS
748          001000          PAREN=BIT9         ;PARITY ENABLE
749          000400          EVPAR=BIT8        ;EVEN PARITY SENSE
750          ;PARCSR WRD DEFINITIONS
751          030000          SYNINT=30000       ;SYNC EXTERNAL MODE
752          020000          SYNEXT=20000     ;SYNC INTERNAL MODE
753          000000          ISYMOD=0         ;ISOC MODE
754          000000          FIVE=0          ;WORD LENGTH 5 BITS
755          002000          SIX=2000        ;WORD LENGTH 6 BITS
756          004000          SEVEN=4000      ;WORD LENGTH 7 BITS
757          006000          EIGHT=6000     ;WORD LENGTH 8 BITS
758          000000          NOPAR=0         ;NO PARITY
759          001000          ODDPAR=1000     ;ODD PARITY
760          001400          EVEPAR=1400     ;EVEN PARITY
761          ;TXCSR BIT DEFINITIONS
762          100000          DNA=BIT15         ;DATA NOT AVAILABLE
763          040000          MTDATA=BIT14      ;MAINT DATA
764          020000          CLK=BIT13        ;CLK
765          002000          BITW=BIT10       ;BIT WINDOW
766          000400          MRESET=BIT8      ;MASTER RESET
767          000200          TXDONE=BIT7      ;XMIT DONE
768          000100          TXINTE=BIT6     ;XMIT INTR ENABLE
769          000040          DNAINTE=BIT5     ;DNA INTR ENAB
770          000020          SEND=BIT4       ;SEND
771          000010          HDXEN=BIT3       ;HDX/FDX
772          000001          BREAK=BIT0       ;BREAK
773          ;TXCSR WRD DEFINITIONS
774          000000          USER=0          ;USER MODE
775          004000          MINT=4000        ;MAINT INT MODE
776          010000          MEXT=10000      ;MAINT EXT MODE
777          014000          SYSTST=14000    ;SYSTEM TEST MODE

```


890	000334	000336	.+2	: UNEXPECTED TRAP TO THIS LOCATION
891	000336	000330	HALT	: EXAMINE STACK TO FIND CAUSE
892	000340	000342	.+2	: UNEXPECTED TRAP TO THIS LOCATION
893	000342	000000	HALT	: EXAMINE STACK TO FIND CAUSE
894	000344	000346	.+2	: UNEXPECTED TRAP TO THIS LOCATION
895	000346	000000	HALT	: EXAMINE STACK TO FIND CAUSE
896	000350	000352	.+2	: UNEXPECTED TRAP TO THIS LOCATION
897	000352	000000	HALT	: EXAMINE STACK TO FIND CAUSE
898	000354	000356	.+2	: UNEXPECTED TRAP TO THIS LOCATION
899	000356	000000	HALT	: EXAMINE STACK TO FIND CAUSE
900	000360	000362	.+2	: UNEXPECTED TRAP TO THIS LOCATION
901	000362	000000	HALT	: EXAMINE STACK TO FIND CAUSE
902	000364	000366	.+2	: UNEXPECTED TRAP TO THIS LOCATION
903	000366	000000	HALT	: EXAMINE STACK TO FIND CAUSE
904	000370	000372	.+2	: UNEXPECTED TRAP TO THIS LOCATION
905	000372	000000	HALT	: EXAMINE STACK TO FIND CAUSE
906	000374	000376	.+2	: UNEXPECTED TRAP TO THIS LOCATION
907	000376	000000	HALT	: EXAMINE STACK TO FIND CAUSE
908	000400	000402	.+2	: UNEXPECTED TRAP TO THIS LOCATION
909	000402	000000	HALT	: EXAMINE STACK TO FIND CAUSE
910	000404	000406	.+2	: UNEXPECTED TRAP TO THIS LOCATION
911	000406	000000	HALT	: EXAMINE STACK TO FIND CAUSE
912	000410	000412	.+2	: UNEXPECTED TRAP TO THIS LOCATION
913	000412	000000	HALT	: EXAMINE STACK TO FIND CAUSE
914	000414	000416	.+2	: UNEXPECTED TRAP TO THIS LOCATION
915	000416	000000	HALT	: EXAMINE STACK TO FIND CAUSE
916	000420	000422	.+2	: UNEXPECTED TRAP TO THIS LOCATION
917	000422	000000	HALT	: EXAMINE STACK TO FIND CAUSE
918	000424	000426	.+2	: UNEXPECTED TRAP TO THIS LOCATION
919	000426	000000	HALT	: EXAMINE STACK TO FIND CAUSE
920	000430	000432	.+2	: UNEXPECTED TRAP TO THIS LOCATION
921	000432	000000	HALT	: EXAMINE STACK TO FIND CAUSE
922	000434	000436	.+2	: UNEXPECTED TRAP TO THIS LOCATION
923	000436	000000	HALT	: EXAMINE STACK TO FIND CAUSE
924	000440	000442	.+2	: UNEXPECTED TRAP TO THIS LOCATION
925	000442	000000	HALT	: EXAMINE STACK TO FIND CAUSE
926	000444	000446	.+2	: UNEXPECTED TRAP TO THIS LOCATION
927	000446	000000	HALT	: EXAMINE STACK TO FIND CAUSE
928	000450	000452	.+2	: UNEXPECTED TRAP TO THIS LOCATION
929	000452	000000	HALT	: EXAMINE STACK TO FIND CAUSE
930	000454	000456	.+2	: UNEXPECTED TRAP TO THIS LOCATION
931	000456	000000	HALT	: EXAMINE STACK TO FIND CAUSE
932	000460	000462	.+2	: UNEXPECTED TRAP TO THIS LOCATION
933	000462	000000	HALT	: EXAMINE STACK TO FIND CAUSE
934	000464	000466	.+2	: UNEXPECTED TRAP TO THIS LOCATION
935	000466	000000	HALT	: EXAMINE STACK TO FIND CAUSE
936	000470	000472	.+2	: UNEXPECTED TRAP TO THIS LOCATION
937	000472	000000	HALT	: EXAMINE STACK TO FIND CAUSE
938	000474	000476	.+2	: UNEXPECTED TRAP TO THIS LOCATION
939	000476	000000	HALT	: EXAMINE STACK TO FIND CAUSE
940	000500	000502	.+2	: UNEXPECTED TRAP TO THIS LOCATION
941	000502	000000	HALT	: EXAMINE STACK TO FIND CAUSE
942	000504	000506	.+2	: UNEXPECTED TRAP TO THIS LOCATION
943	000506	000000	HALT	: EXAMINE STACK TO FIND CAUSE
944	000510	000512	.+2	: UNEXPECTED TRAP TO THIS LOCATION
945	000512	000000	HALT	: EXAMINE STACK TO FIND CAUSE

946	000514	000516	.+2	:UNEXPECTED TRAP TO THIS LOCATION
947	000516	000000	HALT	:EXAMINE STACK TO FIND CAUSE
948	000520	000522	.+2	:UNEXPECTED TRAP TO THIS LOCATION
949	000522	000000	HALT	:EXAMINE STACK TO FIND CAUSE
950	000524	000526	.+2	:UNEXPECTED TRAP TO THIS LOCATION
951	000526	000000	HALT	:EXAMINE STACK TO FIND CAUSE
952	000530	000532	.+2	:UNEXPECTED TRAP TO THIS LOCATION
953	000532	000000	HALT	:EXAMINE STACK TO FIND CAUSE
954	000534	000536	.+2	:UNEXPECTED TRAP TO THIS LOCATION
955	000536	000000	HALT	:EXAMINE STACK TO FIND CAUSE
956	000540	000542	.+2	:UNEXPECTED TRAP TO THIS LOCATION
957	000542	000000	HALT	:EXAMINE STACK TO FIND CAUSE
958	000544	000546	.+2	:UNEXPECTED TRAP TO THIS LOCATION
959	000546	000000	HALT	:EXAMINE STACK TO FIND CAUSE
960	000550	000552	.+2	:UNEXPECTED TRAP TO THIS LOCATION
961	000552	000000	HALT	:EXAMINE STACK TO FIND CAUSE
962	000554	000556	.+2	:UNEXPECTED TRAP TO THIS LOCATION
963	000556	000000	HALT	:EXAMINE STACK TO FIND CAUSE
964	000560	000562	.+2	:UNEXPECTED TRAP TO THIS LOCATION
965	000562	000000	HALT	:EXAMINE STACK TO FIND CAUSE
966	000564	000566	.+2	:UNEXPECTED TRAP TO THIS LOCATION
967	000566	000000	HALT	:EXAMINE STACK TO FIND CAUSE
968	000570	000572	.+2	:UNEXPECTED TRAP TO THIS LOCATION
969	000572	000000	HALT	:EXAMINE STACK TO FIND CAUSE
970	000574	000576	.+2	:UNEXPECTED TRAP TO THIS LOCATION
971	000576	000000	HALT	:EXAMINE STACK TO FIND CAUSE
972	000600	000602	.+2	:UNEXPECTED TRAP TO THIS LOCATION
973	000602	000000	HALT	:EXAMINE STACK TO FIND CAUSE
974	000604	000606	.+2	:UNEXPECTED TRAP TO THIS LOCATION
975	000606	000000	HALT	:EXAMINE STACK TO FIND CAUSE
976	000610	000612	.+2	:UNEXPECTED TRAP TO THIS LOCATION
977	000612	000000	HALT	:EXAMINE STACK TO FIND CAUSE
978	000614	000616	.+2	:UNEXPECTED TRAP TO THIS LOCATION
979	000616	000000	HALT	:EXAMINE STACK TO FIND CAUSE
980	000620	000622	.+2	:UNEXPECTED TRAP TO THIS LOCATION
981	000622	000000	HALT	:EXAMINE STACK TO FIND CAUSE
982	000624	000626	.+2	:UNEXPECTED TRAP TO THIS LOCATION
983	000626	000000	HALT	:EXAMINE STACK TO FIND CAUSE
984	000630	000632	.+2	:UNEXPECTED TRAP TO THIS LOCATION
985	000632	000000	HALT	:EXAMINE STACK TO FIND CAUSE
986	000634	000636	.+2	:UNEXPECTED TRAP TO THIS LOCATION
987	000636	000000	HALT	:EXAMINE STACK TO FIND CAUSE
988	000640	000642	.+2	:UNEXPECTED TRAP TO THIS LOCATION
989	000642	000000	HALT	:EXAMINE STACK TO FIND CAUSE
990	000644	000646	.+2	:UNEXPECTED TRAP TO THIS LOCATION
991	000646	000000	HALT	:EXAMINE STACK TO FIND CAUSE
992	000650	000652	.+2	:UNEXPECTED TRAP TO THIS LOCATION
993	000652	000000	HALT	:EXAMINE STACK TO FIND CAUSE
994	000654	000656	.+2	:UNEXPECTED TRAP TO THIS LOCATION
995	000656	000000	HALT	:EXAMINE STACK TO FIND CAUSE
996	000660	000662	.+2	:UNEXPECTED TRAP TO THIS LOCATION
997	000662	000000	HALT	:EXAMINE STACK TO FIND CAUSE
998	000664	000666	.+2	:UNEXPECTED TRAP TO THIS LOCATION
999	000666	000000	HALT	:EXAMINE STACK TO FIND CAUSE
1000	000670	000672	.+2	:UNEXPECTED TRAP TO THIS LOCATION
1001	000672	000000	HALT	:EXAMINE STACK TO FIND CAUSE

1002	000674	000676	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1003	000676	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1004	000700	000702	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1005	000702	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1006	000704	000706	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1007	000706	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1008	000710	000712	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1009	000712	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1010	000714	000716	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1011	000716	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1012	000720	000722	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1013	000722	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1014	000724	000726	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1015	000726	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1016	000730	000732	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1017	000732	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1018	000734	000736	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1019	000736	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1020	000740	000742	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1021	000742	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1022	000744	000746	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1023	000746	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1024	000750	000752	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1025	000752	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1026	000754	000756	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1027	000756	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1028	000760	000762	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1029	000762	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1030	000764	000766	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1031	000766	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1032	000770	000772	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1033	000772	000000	HALT	: EXAMINE STACK TO FIND CAUSE
1034	000774	000776	.+2	: UNEXPECTED TRAP TO THIS LOCATION
1035	000776	000000	HALT	: EXAMINE STACK TO FIND CAUSE

```

1036                                     ;STANDARD INTERRUPT VECTORS
1037
1038
1039                                     .=24
1040 000024 014414                       .PFAIL                       ;POWER FAIL HANDLER
1041 000026 000340                       340                          ;SERVICE AT LEVEL 7
1042 000030 014122                       .HLT                          ;ERROR HANDLER
1043 000032 003340                       340                          ;SERVICE AT LEVEL 7
1044 000034 014070                       .TRPSRV                       ;GENERAL HANDLER DISPATCH SERVICE
1045 000036 000340                       340                          ;SERVICE AT LEVEL 7
1046                                     .=200
1047 000200 000137 001246               JMP .START                    ;GO TO START OF PROGRAM
1048
1049                                     .=250
1050 000250 000000                       EOPHLT: HALT                  ;THIS IS AN END OF PASS HALT.
1051                                     ;NOT AN ERROR HALT.
1052                                     ;THIS HAPPENS ONLY IF SW6
1053                                     ;IS UP.PRESS CONTINUE
1054                                     ;TO RESUME PROGRAM
1055
1056 000252 000207                       RTS PC
1057
1058
1059
1060                                     .=1100
1061
1062                                     ;INDIRECT POINTERS TO TELETYPE VECTORS AND REGISTERS
1063
1064 001100 177560                       TKCSR: 177560                 ;TELETYPE KEYBOARD CONTROL REGISTER
1065 001102 177562                       TKDBR: 177562                 ;TELETYPE KEYBOARD DATA BUFFER
1066 001104 177564                       TPCSR: 177564                 ;TELEPRINTER CONTROL REGISTER
1067 001106 177566                       TPDBR: 177566                 ;TELEPRINTER DATA BUFFER
1068
1069                                     ;PROGRAM CONTROL PARAMETERS
1070
1071 001110 000000                       RETURN: 0                     ;SCOPE ADDRESS FOR LOOP ON TEST
1072 001112 000000                       NEXT: 0                       ;ADDRESS OF NEXT TEST TO BE EXECUTED
1073 001114 000000                       LOCK: 0                       ;ADDRESS FOR LOCK ON CURRENT DATA
1074 001116 000000                       ICOUNT: 0                     ;NUMBER OF ITERATIONS THAT CURRENT TEST WILL BE EXECUTED
1075 001120 000000                       LPCNT: 0                      ;NUMBER OF ITERATIONS COMPLETED
1076 001122 000000                       TSTNO: 0                     ;NUMBER OF TEST IN PROGRESS
1077 001124 000000                       PASCNT: 0                    ;NUMBER OF PASSES COMPLETED
1078 001126 000000                       ERRCNT: 0                    ;TOTAL NUMBER OF ERRORS
1079 001130 000000                       LSTERR: 0                    ;PC OF LAST ERROR CALL
1080
1081                                     ;PROGRAM VARIABLES
1082
1083 001132 000020                       HOLD: 20                     ;TEMPORARY STORAGE=DELAY TIME FOR CABLES
1084 001134 000000                       SHIFT: 0                    ;TEMPORARY STORAGE= # OF SHIFTS PER CHAR
1085 001136 000000                       COUNT: 0                    ;TEMPORARY STORAGE= # OF TIMES A CHAR WILL BE SENT
1086 001140 000000                       TEMP1: 0                    ;TEMPORARY STORAGE
1087 001142 000000                       TEMP2: 0                    ;TEMPORARY STORAGE
1088 001144 000000                       TEMP3: 0                    ;TEMPORARY STORAGE
1089 001146 000000                       TEMP4: 0                    ;TEMPORARY STORAGE
1090 001150 000000                       TEMP5: 0                    ;TEMPORARY STORAGE
1091 001152 000000                       SAVRO: 0                    ;RO STORAGE

```

1092 001154 000000
1093 001156 000000
1094 001160 000000
1095 001162 000000
1096 001164 000000
1097 001166 000000
1098 001170 000000

SAVR1: 0
SAVR2: 0
SAVR3: 0
SAVR4: 0
SAVR5: 0
SAVSP: 0
SAVPC: 0

:R1 STORAGE
:R2 STORAGE
:R3 STORAGE
:R4 STORAGE
:R5 STORAGE
:STACK POINTER STORAGE
:PROGRAM COUNTER STORAGE

```
1099 ;PROGRAM CONVERSATIONAL PARAMETERS
1100 001172 377 SYNCNO: .BYTE 377 ;# OF SYNC CHARS REQ'D FOR SYNC'ZATION
1101 001173 377 SEXMIT: .BYTE 377 ;SEC XMIT JUMPER "IN"
1102 001174 377 SEREC: .BYTE 377 ;SEC REC JUMPER "IN"
1103 001175 377 OPTCLR: .BYTE 377 ;OPTIONAL JUMPER CLR "IN"
1104 001176 000 MULTD: .BYTE 0 ;NO MULTIPLE DEVICE FLAG
1105 001177 377 JMRBY: .BYTE 377 ;EXTERNAL MODEM BYPASS JUMPER "IN"
1106 .EVEN
1107
1108 ;PROGRAM MULTIPLE DEVICE PARAMETERS
1109 001200 000000 BASEADD: 0 ;PROG CONTROLLED 1ST DEVICE ADDR
1110 001202 000000 KEEPADD: 0 ;SAVED 1ST DEVICE ADDR
1111 001204 000000 LASTADD: 0 ;LAST DEVICE RXCSR ADDR
1112 001206 000000 BASEIV: 0 ;PROG CONTROLLED IV
1113 001210 000000 KEEPIV: 0 ;SAVED INTR VECTOR
1114 001212 000000 ACTREG: 0 ;ACTIVE REGISTER , MODIFY THIS
1115 ;LOCATION TO DISQUALIFY OR QUALIFY
1116 ;DEVICES (1= RUN , 0= DON'T RUN)
1117 001214 000000 ROTADD: 0 ;ROTATING POINTER FOR ACTREG. POINTS
1118 ;TO DEVICE PRESENTLY UNDER TEST WHEN RUNNING MULTIPLE DEVICES
1119
1120 ;PROGRAM CONTROL FLAGS
1121
1122 001216 000 INIFLG: .BYTE 0 ;PROGRAM INITIALIZATION FLAG
1123 001217 000 STFLG: .BYTE 0 ;TEST START FLAG
1124 001220 000 ERRFLG: .BYTE 0 ;ERROR OCCURED FLAG
1125 001221 000 LOKFLG: .BYTE 0 ;LOCK ON CURRENT TEST FLAG
1126
1127 ;DEFINITIONS FOR TRAP SUBROUTINE CALLS
1128 ;POINTERS TO SUBROUTINES CAN BE FOUND
1129 ;IN THE TABLE IMMEDIATLY FOLLOWING THE DEFINITIONS
1130
1131 001222 .TRPTAB:
1132 ;*****
1133 104400 SCOPE=TRAP+0 ;CALL TO SCOPE LOOP AND ITERATION HANDLER
1134 001222 013032 .SCOPE
1135 ;*****
1136 104401 SCOPI=TRAP+1 ;CALL TO LOOP ON CURRENT DATA HANDLER
1137 001224 013214 .SCOPI
1138 ;*****
1139 104402 TYPE=TRAP+2 ;CALL TO TELETYPE OUTPUT ROUTINE
1140 001226 013232 .TYPE
1141 ;*****
1142 104403 INSTR=TRAP+3 ;CALL TO ASCII STRING INPUT ROUTINE
1143 001230 013264 .INSTR
1144 ;*****
1145 104404 INSTER=TRAP+4 ;CALL TO INPUT ERROR HANDLER
1146 001232 013356 .INSTER
1147 ;*****
1148 104405 PARAM=TRAP+5 ;CALL TO NUMERICAL DATA INPUT ROUTINE
1149 001234 013366 .PARAM
1150 ;*****
1151 104406 SAVOS=TRAP+6 ;CALL TO REGISTER SAVE ROUTINE
1152 001236 013552 .SAVOS
1153 ;*****
1154 104407 RESOS=TRAP+7 ;CALL TO REGISTER RESTORE ROUTINE
```

```

1155 001240 013612 .RES05
1156 ;*****
1157 104410 CONVRT=TRAP+10 ;CALL TO DATA OUTPUT ROUTINE
1158 001242 013644 .CONVRT
1159 ;*****
1160 104411 SETFLG=TRAP+11 ;CALL TO FLAG SET ROUTINE
1161 001244 014022 .SETFLG
1162
1163 ;PROGRAM INITIALIZATION
1164 ;LOCK OUT INTERRUPTS
1165 ;SET UP PROCESSOR STACK
1166 ;SET UP POWER FAIL VECTOR
1167 ;CLEAR PROGRAM CONTROL FLAGS AND COUNTS
1168 ;TYPE TITLE MESSAGE
1169
1170 001246 012737 000240 177776 .START: MOV #340,PS ;LOCK OUT INTERRUPTS
1171 001254 012706 001100 MOV #STACK,SP ;SET UP STACK
1172 001260 012737 014414 000024 MOV #.PFAIL,0#24 ;SET UP POWER FAIL VECTOR
1173 001266 005037 001120 CLR LPCNT ;CLEAR # OF ITERATION COMPLETED LOCATION
1174 001272 105037 001217 CLRB STFLG ;CLEAR START FLAG
1175 001276 005037 001124 CLR PASCNT ;CLEAR PASS COUNT
1176 001302 005037 001220 CLRB ERRFLG ;CLEAR ERROR FLAG
1177 001306 005037 001126 CLR ERRCNT ;CLEAR ERROR COUNT
1178 001312 005037 001130 CLR LSTERR ;CLEAR LAST ERROR POINTER
1179 001316 012737 000001 001122 MOV #1,TSTNO ;SET UP FOR TEST 1
1180 001324 012737 001246 001110 MOV #.START,RETURN ;SET UP FOR POWER FAIL BEFORE
1181 ;TESTING STARTS
1182 001332 105737 001216 TSTB INIFLG ;HAS INITIALIZATION BEEN PERFORMED
1183 001336 001004 BNE ONCE
1184 001340 104402 014556 TYPE #TITLE ;TYPE TITLE MESSAGE
1185 001344 105137 001216 COMB INIFLG ;IF NOT SET FLAG AND DO
1186 001350 032737 000001 177570 ONCE: BIT #SW00,SWR ;RESELECT VECTOR & CONTROL REG?
1187 001356 001002 BNE 1$
1188 001360 000137 002032 JMP .BEGIN
1189 001364 012700 000300 1$: MOV #300,R0 ;RESTORE VECTOR AREA TO TRAPCATCHER
1190 001370 012701 000302 MOV #302,R1 ;START AT LOCATION 300
1191 001374 012702 000004 MOV #4,R2
1192 001400 010110 2$: MOV R1,(R0)
1193 001402 005011 CLR (R1)
1194 001404 060200 ADD R2,R0
1195 001406 060201 ADD R2,R1
1196 001410 022701 001000 CMP #1000,R1 ;END AT LOCATION 776
1197 001414 002771 BLT 2$
1198 001416 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1199 001420 014653 MREGAD ;MESSAGE
1200 001422 104405 PARAM ;CONVERT STRING
1201 001424 160000 ;LOW LIMIT
1202 001426 167776 ;HIGH LIMIT
1203 001430 016524 DUBASE ;STORE AT THIS LOCATION
1204 001432 001 .BYTE 1 ;MASK
1205 001433 001 .BYTE 1 ;HOW MANY TIMES + 2
1206 001434 013737 016524 001202 MOV DUBASE,KEEPPADD ;SAVE
1207 001442 004737 016372 JSR PC,DUADDR
1208 001446 013737 001202 001200 MOV KEEPPADD,BASEADD ;RESTORE FOR ROTATION
1209 001454 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1210 001456 014631 MVECTO ;MESSAGE

```

```

1211 001460 104405 PARAM ;CONVERT STRING
1212 001462 000300 300 ;LOW LIMIT
1213 001464 000776 776 ;HIGH LIMIT
1214 001466 017046 DURIV ;STORE AT THIS LOCATION
1215 001470 001 .BYTE 1 ;MASK
1216 001471 004 .BYTE 4 ;HOW MANY TIMES + 2
1217 001472 013737 017046 001210 MOV DURIV,KEEPIV ;SAVE
1218 001500 013737 017046 001206 MOV DURIV,BASEIV ;SET UP FOR ROTATION
1219 001506 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1220 001510 014734 MMULT ;MESSAGE
1221 001512 104411 SETFLG ;SET FLAG BASED UPON INPUT STRING
1222 001514 001176 MULTD ;THIS FLAG
1223 001516 105737 001176 TSTB MULTD ;ARE THERE MULTIPLE DEVICES
;ON THE SYSTEM ?
1225 001522 100406 BMI BBB ;YES,ASK NEXT QUESTION
1226 001524 005037 001212 CLR ACTREG
1227 001530 005037 001214 CLR ROTADD
1228 001534 000137 001700 JMP OUTMUL ;JUMP AROUND NEXT QUESTION
1229 001540 BBB:
1230 001540 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1231 001542 015013 MLASTD ;MESSAGE
1232 001544 104405 PARAM ;CONVERT STRING
1233 001546 160000 160000 ;LOW LIMIT
1234 001550 167776 167776 ;HIGH LIMIT
1235 001552 001204 LASTADD ;STORE AT THIS LOCATION
1236 001554 001 .BYTE 1 ;MASK
1237 001555 001 .BYTE 1 ;HOW MANY TIMES + 2
;THE FOLLOWING ROUTINE SETS UP ACTREG FOR THE FIRST TIME
1239 001556 012737 000001 001214 15: MOV #1,ROTADD ;SET UP POINTER
1240 001564 005037 001212 CLR ACTREG ;CLR ACTIVE REGISTER
1241 001570 053737 001214 001212 25: BIS ROTADD,ACTREG ;MAKE THIS DEVICE ACTIVE
1242 001576 000241 CLC
1243 001600 006137 001214 ROL ROTADD ;SET UP POINTER
1244 001604 103421 BCS 35 ;ARE YOU OUT OF RANGE ?
1245 001606 062737 000010 001200 ADD #10,BASEADD ;SET UP BASE ADDRESS
1246 001614 023737 001204 001200 CMP LASTADD,BASEADD ;IS THIS THE LAST DEVICE ?
1247 001622 101362 BHI 25 ;NO DO IT AGAIN
1248 001624 053737 001214 001212 BIS ROTADD,ACTREG ;THIS ASSUMES THAT THERE ARE AT
;LEAST TWO DEVICES WHEN YOU ANSWER YES TO
;MULTIPLE DEVICE QUESTION
1251 001632 012737 000001 001214 45: MOV #1,ROTADD ;SET UP FOR LATER USE IN END OF PASS ROUTINE
1252 001640 013737 001202 001200 MOV KEEPADD,BASEADD ;DITTO
1253 001646 000414 BR OUTMUL ;CONTINUE QUESTIONS
1254 001650 013737 001202 001200 35: MOV KEEPADD,BASEADD ;RESTORE
1255 001656 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1256 001660 015176 MRANGE ;MESSAGE
1257 001662 104405 PARAM ;CONVERT STRING
1258 001664 160000 160000 ;LOW LIMIT
1259 001666 167776 167776 ;HIGH LIMIT
1260 001670 001204 LASTADD ;STORE AT THIS LOCATION
1261 001672 001 .BYTE 1 ;MASK
1262 001673 001 .BYTE 1 ;HOW MANY TIMES + 2
1263 001674 000137 001556 JMP 15 ;DO IT AGAIN
1264 001700 OUTMUL:
1265 001700 104403 INSTR ;OUTPUT MESSAGE & GET INPUT STRING
1266 001702 015470 MLEVEL ;MESSAGE

```

```

1267 001704 104405 PHRAM ; CONVERT STRING
1268 001706 000004 4 ; LOW LIMIT
1269 001710 000007 7 ; HIGH LIMIT
1270 001712 016366 DUPRT ; STORE AT THIS LOCATION
1271 001714 000 .BYTE 0 ; MASK
1272 001715 001 .BYTE 1 ; HOW MANY TIMES + 2
1273 001716 004737 016316 JSR PC DULEV
1274 ; COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
1275 ; BUFFER TO THE CHARACTERS "1" AND "2"
1276 ; IF THE CHARACTER IS "1" CLEAR THE FLAG
1277 ; IF THE CHARACTER IS "2" SET THE FLAG
1278 001722 AAA:
1279 001722 104403 INSTR ; OUTPUT MESSAGE & GET INPUT STRING
1280 001724 015515 MSYNC ; MESSAGE
1281 001726 122737 000061 016150 3$: CMPB #'1, INBUF ; IS IT "1" ?
1282 001734 001003 BNE 1$
1283 001736 105037 001172 CLRB SYNCNO ; 000
1284 001742 000412 BR 4$
1285 001744 122737 000062 016150 1$: CMPB #'2, INBUF ; IS IT "2" ?
1286 001752 001004 BNE 2$
1287 001754 112737 177777 001172 MOVB #-1, SYNCNO ; 377
1288 001762 000402 BR 4$
1289 001764 104404 2$: INSTER ; RETRY
1290 001766 000757 BR 3$
1291 001770 000240 4$: NOP
1292 001772 104403 INSTR ; OUTPUT MESSAGE & GET INPUT STRING
1293 001774 015563 MWIRE6 ; MESSAGE
1294 001776 104411 SETFLG ; SET FLAG BASED UPON INPUT STRING
1295 002000 001173 SEXMIT ; THIS FLAG
1296 002002 104403 INSTR ; OUTPUT MESSAGE & GET INPUT STRING
1297 002004 015631 MWIRES ; MESSAGE
1298 002006 104411 SETFLG ; SET FLAG BASED UPON INPUT STRING
1299 002010 001174 SEREC ; THIS FLAG
1300 002012 104403 INSTR ; OUTPUT MESSAGE & GET INPUT STRING
1301 002014 015676 MWIRE4 ; MESSAGE
1302 002016 104411 SETFLG ; SET FLAG BASED UPON INPUT STRING
1303 002020 001175 OPTCLR ; THIS FLAG
1304 002022 104403 INSTR ; OUTPUT MESSAGE & GET INPUT STRING
1305 002024 015752 NEXTJ ; MESSAGE
1306 002026 104411 SETFLG ; SET FLAG BASED UPON INPUT STRING
1307 002030 001177 JMRBY ; THIS FLAG
1308
1309 ; TEST START AND RESTART
1310
1311 002032 012737 000340 177776 .BEGIN: MOV #340, PS ; LOCK OUT INTERRUPTS
1312 002040 012706 001100 MOV #STACK, SP ; SET UP STACK
1313 002044 005737 000042 TST 2#42 ; IS PROGRAM UNDER MONITOR CONTROL
1314 002050 001056 BNE 3$
1315 002052 105737 001176 TSTB MULTD ; DON'T ALLOW LOCK ON TEST IF RUNNING
1316 ; MULTIPLE DEVICES
1317 002056 001407 BEQ 5$ ; IF NO, TEST FOR LOCK ON TEST
1318 002060 013737 013210 013112 MOV BRW, TTST ; RESTORE NORMAL SCOPE LOOP
1319 002066 013737 013212 013114 MOV BRX, TTST+2 ; DITTO
1320 002074 000444 BR 3$ ; JUMP AROUND IF YES
1321 002076 032737 000004 177570 5$: BIT #BIT2, SWR ; CHECK FOR LOCK ON TEST
1322 002104 001416 BEQ 1$

```

```

1323 002106 104403 INSTR :OUTPUT MESSAGE & GET INPUT STRING
1324 002110 015425 MLOCK :MESSAGE
1325 002112 104411 SETFLG :SET FLAG BASED UPON INPUT STRING
1326 002114 001221 LOKFLG :THIS FLAG
1327 002116 105737 001221 TSTB LOKFLG :IS LOCK ON TEST OPTION SELECTED
1328 002122 001407 BEQ 1$
1329 002124 012737 000240 013112 MOV #NOP,TTST
1330 002132 012737 000240 013114 MOV #NOP,TTST+2 ;SET UP TO LOCK.
1331 002140 000406 BR 2$
1332 002142 013737 013210 013112 1$: MOV BRW,TTST
1333 002150 013737 013212 013114 MOV BRX,TTST+2 ;LOCK NOT SELECTED, SET UP FOR NORMAL SCOPE LOOP
1334 002156 032737 000002 177570 2$: BIT #SW01,SWR ;IF SW01=1, GET STARTING PC
1335 002164 001410 BEQ 3$
1336 002166 104403 INSTR :OUTPUT MESSAGE & GET INPUT STRING
1337 002170 015412 MTSTPC :MESSAGE
1338 002172 104405 PARAM :CONVERT STRING
1339 002174 002224 TST1 :LOW LIMIT
1340 002176 012176 TLAST :HIGH LIMIT
1341 002200 000207 RETURN :STORE AT THIS LOCATION
1342 002202 001 .BYTE 1 :MASK
1343 002203 001 .BYTE 1 :HOW MANY TIMES + 2
1344 002204 000403 BR 4$
1345 002206 012737 002224 001110 3$: MOV #TST1,RETURN ;START AT TEST 1
1346 002214 104402 015406 4$: TYPE MR ;TYPE R
1347 002220 000177 176664 JMP @RETURN ;START TESTING
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357 002224 012737 000001 001122 TST1: MOV #1,TSTNO ;SAVE THIS
1358 002232 012737 002466 001112 MOV #TST2,NEXT ;GO TO THIS TEST WHEN THRU
1359 002240 052777 000400 014570 BIS #MRESET,@TXCSR ;MASTER RESET
1360 002246 012777 000000 014556 MOV #ISYMOD,@PARCSR ;SET THE MODE
1361 002254 052777 000400 014554 BIS #MRESET,@TXCSR ;MASTER RESET
1362
1363 ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
1364 002262 012777 064001 014546 MOV #MTDATA:CLK!MINT!BREAK,@TXCSR
1365
1366 ;SET MODE # OF BITS,PARITY SENSE,&LOAD SYNC REG
1367 002270 012777 006J00 014534 MOV #ISYMOD:EIGHT!NOPAR!0,@PARCSR
1368 002276 052777 000020 014516 BIS #SYNSCH,@TXCSR ;SET SYNC SEARCH
1369 ;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
1370 002304 042777 020000 014524 BIC #CLK,@TXCSR ;POKE CLK DOWN
1371 002312 052777 020000 014516 BIS #CLK,@TXCSR ;POKE CLK UP
1372 ;POKE CLK TO GET LOGIC INTO SYNCRIZATION
1373 002320 042777 020000 014510 BIC #CLK,@TXCSR ;POKE CLK DOWN
1374 002326 052777 020000 014502 BIS #CLK,@TXCSR ;POKE CLK UP
1375 002334 013703 017026 MOV RXDBUF,R3 ;SET UP FOR ERROR MESSAGE
1376 002340 012700 000125 MOV #125,R0 ;EXPECTED
1377 002344 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1378 002352 012737 001252 001140 MOV #1252,TEMP1 ;DATA CHAR

```

```

1379 002360 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1380 002364 105777 014432 TSTB @RXCSR ;RXDONE
1381 002370 100401 BMI .+4
1382 002372 104000 HLT ;RXDONE SHOULD BE SET
1383 002374 017701 014426 MOV @RXDBUF,R1 ;ACTUAL
1384 002400 020001 CMP R0,R1 ;COMPARE EXPECTED VS. ACTUAL
1385 002402 001401 BEQ .+4
1386 002404 104002 HLT 2 ;RECEIVED DATA DID NOT MATCH
;EXPECTED DATA - CHECK MAINT DATA
;OR RECEIVER LOGIC
1389 002406 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1390 002414 012737 001252 001140 MOV #1252,TEMP1 ;DATA CHAR
1391 002422 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1392 ;NOW SHIFT IN A SECOND CHARACTER WITHOUT READING RXDBUF
1393 002426 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1394 002434 012737 001252 001140 MOV #1252,TEMP1 ;DATA CHAR
1395 002442 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1396 002446 012700 140125 MOV #140000!125,R0 ;EXPECTED DATA PLUS
;RXERR & OVRUN
1397 ;ACTUAL
1398 002452 017701 014350 MOV @RXDBUF,R1 ;ACTUAL
1399 002456 020001 CMP R0,R1 ;COMPARE EXP VS. ACT
1400 002460 001401 BEQ .+4
1401 002462 104002 HLT 2 ;SPECIFICALLY LOOK AT RXERR &
;OVRUN BITS...THEY BOTH SHOULD BE SET
1402
1403 002464 104400 SCOPE
1404 ;;THIS TEST VERIFYS WORD LENGTH SELECT OF THE
1405 ;;RECEIVER SECTION, IT USES THE ERROR FLAGS
1406 ;;TO DETERMINE THAT IT WAS SELECTED CORRECTLY
1407 ;;(OVRUN,RXERR)
1408 ;;MODE:ISYMOD
1409 ;;LENGTH:EIGHT
1410 ;;CHAR:252
1411
1412 002466 012737 000002 001122 TST2: MOV #2,TSTNC ;SAVE THIS
1413 002474 012737 002730 001112 MOV #TST3,NEXT ;GO TO THIS TEST WHEN TRUL
1414 002502 052777 000400 014326 BIS #MRESET,@TXCSR ;MASTER RESET
1415 002510 012777 000000 014314 MOV #ISYMOD,@PARCSR ;SET THE MODE
1416 002516 052777 000400 014312 BIS #MRESET,@TXCSR ;MASTER RESET
1417
1418 ;SET MAINT DATA,CLK,BREAK, & MAINTENANCE MODE
1419 002524 012777 064001 014304 MOV #MTOATA!CLK!MINT!BREAK,@TXCSR
1420
1421 ;SET MODE, # OF BITS, PARITY SENSE, & LOAD SYNC REG
1422 002532 012777 006000 014272 MOV #ISYMOD!EIGHT!NOPAR!0,@PARCSR
1423 002540 052777 000020 014254 BIS #SYNSCH,@RXCSR ;SET SYNC SEARCH
1424 ;POKE CLK TO GET RECEIVER INTO SYNCHRONIZATION....
1425 002546 042777 020000 014262 BIC #CLK,@TXCSR ;POKE CLK DOWN
1426 002554 052777 020000 014254 BIS #CLK,@TXCSR ;POKE CLK UP
1427 ;POKE CLK TO GET LOGIC INTO SYNCHRONIZATION
1428 002562 042777 020000 014246 BIC #CLK,@TXCSR ;POKE CLK DOWN
1429 002570 052777 020000 014240 BIS #CLK,@TXCSR ;POKE CLK UP
1430 002576 013703 017026 MOV RXDBUF,R3 ;SET UP FOR ERROR MESSAGE
1431 002602 012700 000252 MOV #252,R0 ;EXPECTED
1432 002606 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1433 002614 012737 001524 001140 MOV #1524,TEMP1 ;DATA CHAR
1434 002622 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR

```

```

1435 002626 105777 014170 TSTB @RXCSR ;RXDONE ?
1436 002632 100401 BMI .+4
1437 002634 104000 HLT ;RXDONE SHOULD BE SET
1438 002636 017701 014164 MOV @RXDBUF,R1 ;ACTUAL
1439 002642 020001 CMP R0,R1 ;COMPARE EXPECTED VS. ACTUAL
1440 002644 001401 BEQ .+4
1441 002646 104002 HLT 2 ;RECEIVED DATA DID NOT MATCH
1442 ;EXPECTED DATA - CHECK MAINT DATA
1443 ;OR RECEIVER LOGIC
1444 002650 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1445 002656 012737 001524 001140 MOV #1524,TEMP1 ;DATA CHAR
1446 002664 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1447 ;NOW SHIF IN A SECOND CHARACTER WITHOUT READING RXDBUF
1448 002670 012737 000012 001134 MOV #10,SHIFT ;# OF SHIFTS
1449 002676 012737 001524 001140 MOV #1524,TEMP1 ;DATA CHAR
1450 002704 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1451 002710 012700 140252 MOV #140000!252,R0 ;EXPECTED DATA PLUS
1452 ;RXERR & OVRUN
1453 002714 017701 014106 MOV @RXDBUF,R1 ;ACTUAL
1454 002720 020001 CMP R0,R1 ;COMPARE EXP VS. ACT
1455 002722 001401 BEQ .+4
1456 002724 104002 HLT 2 ;SPECIFICALLY LOOK AT RXERR &
1457 ;OVRUN BITS...THEY BOTH SHOULD BE SET
1458 002726 104400 SCOPE
1459 ;:THIS TEST VERIFYS WORD LENGTH SELECT OF THE
1460 ;:RECEIVER SECTION,IT USES THE ERROR FLAGS
1461 ;:TO DETERMINE THAT IT WAS SELECTED CORRECTLY
1462 ;:(OVRUN,RXERR)
1463 ;:MODE:SYNEXT
1464 ;:LENGTH:EIGHT
1465 ;:CHAR:252
1466
1467 002730 012737 000003 001122 TST3: MOV #3,ISTNO ;SAVE THIS
1468 002736 012737 003156 001112 MOV #TST4,NEXT ;GO TO THIS TEST WHEN THRU
1469 002744 052777 000400 014064 BIS #MRESET,@TXCSR ;MASTER RESET
1470 002752 012777 020000 014052 MOV #SYNEXT,@PARCSR ;SET THE MODE
1471 002760 052777 000400 014050 BIS #MRESET,@TXCSR ;MASTER RESET
1472
1473 ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
1474 002766 012777 064001 014042 MOV @MNTDATA!CLK!MINT!BREAK,@TXCSR
1475
1476 ;SET MODE ,# OF BITS,PARITY SENSE,&LOAD SYNC REG
1477 002774 012777 026000 014030 MOV #SYNEXT!EIGHT!NOPAR!0,@PARCSR
1478 003002 052777 000020 014012 BIS #SYNSCH,@RXCSR ;SET SEARCH SYNC
1479 ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
1480 003010 042777 020000 014020 BIC #CLK,@TXCSR ;POKE CLK DOWN
1481 003016 052777 020000 014012 BIS #CLK,@TXCSR ;POKE CLK UP
1482 003024 013703 017026 MOV @RXDBUF,R3 ;SET UP FOR ERROR MESSAGE
1483 003030 012700 000252 MOV #252,R0 ;EXPECTED
1484 003034 012737 000010 001134 MOV #8,SHIFT ;# OF SHIFTS
1485 003042 012737 000252 001140 MOV #252,TEMP1 ;DATA CHAR
1486 003050 004737 016526 JSR PC,RPOKE ;SHIFT IN THIS CHAR
1487 003054 105777 013742 TSTB @RXCSR ;RXDONE ?
1488 003060 100401 BMI .+4
1489 003062 104000 HLT ;RXDONE SHOULD BE SET
1490 003064 017701 013736 MOV @RXDBUF,R1 ;ACTUAL

```

```

1491 003070 020001      CMP      R0,R1      ;COMPARE EXPECTED VS. ACTUAL
1492 003072 001401      BEQ      ;+4
1493 003074 104002      HLT      2          ;RECEIVED DATA DID NOT MATCH
1494                                     ;EXPECTED DATA - CHECK MAINT DATA
1495                                     ;OR RECEIVER LOGIC
1496 003076 012737 000010 001134      MOV      #8,SHIFT   ;# OF SHIFTS
1497 003104 012737 000252 001140      MOV      #252,TEMP1 ;DATA CHAR
1498 003112 004737 016526      JSR      PC,RPOKE   ;SHIFT IN THIS CHAR
1499                                     ;NOW SHIFT IN A SECOND CHARACTER WITHOUT READING RXDBUF
1500 003116 012737 000010 001134      MOV      #8,SHIFT   ;# OF SHIFTS
1501 003124 012737 000252 001140      MOV      #252,TEMP1 ;DATA CHAR
1502 003132 004737 016526      JSR      PC,RPOKE   ;SHIFT IN THIS CHAR
1503 003136 012700 140252      MOV      #140000!252,R0 ;EXPECTED DATA PLUS
1504                                     ;RXERR & OVRUN
1505 003142 017701 013660      MOV      @RXDBUF,R1 ;ACTUAL
1506 003146 020001      CMP      R0,R1      ;COMPARE EXP VS. ACT
1507 003150 001401      BEQ      ;+4
1508 003152 104002      HLT      2          ;SPECIFICALLY LOOK AT RXERR &
1509                                     ;OVRUN BITS...THEY BOTH SHOULD BE SET
1510 003154 104400      SCOPE
1511                                     ;; THIS TEST PERFORMS BINARY DATA CHECK ON THE
1512                                     ;; RECEIVER
1513                                     ;; LENGTH:EIGHT PLUS PARITY
1514                                     ;; MODE:ISYMOD
1515                                     ;; PARITY:EVEPAR
1516                                     ;;
1517 003156 012737 000004 001122      TST4:  MOV      #4,TSTNO ;SAVE THIS
1518 003164 012737 003356 001112      MOV      #TSTS,NEXT  ;GO TO THIS TEST WHEN TRUE
1519 003172 052777 000400 013636      BIS      #MRESET,@TXCSR ;MASTER RESET
1520 003200 012777 000000 013624      MOV      #ISYMOD,@PARCSR ;SET THE MODE
1521 003206 052777 000400 013622      BIS      #MRESET,@TXCSR ;MASTER RESET
1522
1523                                     ;SET MAINT DATA,CLK BREAK, & MAINTENANCE MODE
1524 003214 012777 064001 013614      MOV      #MNTDATA!CLK!MINT!BREAK,@TXCSR
1525
1526                                     ;SET MODE, # OF BITS, PARITY SENSE & LOAD SYNC REG
1527 003222 012777 007400 013602      MOV      #ISYMOD!EIGHT!EVEPAR!0,@PARCSR
1528 003230 052777 000020 013564      BIS      #SYNSCH,@RXCSR ;SET SYNC SEARCH
1529                                     ;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
1530 003236 042777 020000 013572      BIC      #CLK,@TXCSR  ;POKE CLK DOWN
1531 003244 052777 020000 013564      BIS      #CLK,@TXCSR  ;POKE CLK UP
1532                                     ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
1533 003252 042777 020000 013556      BIC      #CLK,@TXCSR  ;POKE CLK DOWN
1534 003260 052777 020000 013550      BIS      #CLK,@TXCSR  ;POKE CLK UP
1535 003266 013703 017026      MOV      RXDBUF,R3   ;SET UP ERROR MESSAGE
1536 003272 005004      CLR      R4          ;DATA CHAR
1537 003274 010400      MOV      R4,R0      ;EXPECTED
1538 003276 012737 000013 001134      MOV      #11,SHIFT   ;# OF SHIFTS
1539 003304 010437 001140      MOV      R4,TEMP1    ;"TO BE SHIFTED CHARACTER"
1540 003310 004737 016700      JSR      PC,EVEN8    ;CALC PARITY
1541 003314 000241      CLC
1542 003316 006137 001140      ROL      TEMP1      ;GENERATE START BIT
1543 003322 052737 002000 001140      BIS      #BIT10,TEMP1 ;GENERATE STOP BIT
1544                                     ;TEMP1 NOW HAS CHARACTER TO BE POKED INTO RECEIVER
1545 003330 004737 016526      JSR      PC,RPOKE   ;SHIFT IN THIS CHAR
1546 003334 017701 013466      MOV      @RXDBUF,R1 ;ACTUAL

```

```

1547 003340 020001      CMP      R0,R1      ;COMPARE EXP VS ACT
1548 003342 001401      BEQ      +4
1549 003344 104002      HLT      2          ;DATA CHARS SHOULD MATCH
1550                                ;THERE SHOULD BE NO PARITY ERROR
1551 003346 005204      INC      R4          ;UPGRADE NEXT CHAR
1552 003350 105704      TSTB    R4          ;LAST CHAR ?
1553 003352 001350      BNE     1$
1554 003354 104400      SCOPE
1555                                ;; THIS TEST PERFORMS BINARY DATA CHECK ON THE
1556                                ;; RECEIVER
1557                                ;; LENGTH:EIGHT PLUS PARITY
1558                                ;; MODE:SYNEXT
1559                                ;; PARITY:EVEPAR
1560
1561 003356 012737 000005 001122  TST5:  MOV      #5,TSTNO      ;SAVE THIS
1562 003364 012737 003526 001112      MOV      #TST6,NEXT     ;GO TO THIS TEST WHEN THRU
1563 003372 052777 000400 013436      BIS      #MRESET,@TXCSR ;MASTER RESET
1564 003400 012777 020000 013424      MOV      #SYNEXT,@PARCSR ;SET THE MODE
1565 003406 052777 000400 013422      BIS      #MRESET,@TXCSR ;MASTER RESET
1566
1567                                ;SET MAINT DATA,CLK BREAK,&MAINTENANCE MODE
1568 003414 012777 064001 013414      MOV      #MTDATA:CLK!MINT!BREAK,@TXCSR
1569
1570                                ;SET MODE , # OF BITS,PARITY SENSE,&LOAD SYNC REG
1571 003422 012777 027400 013402      MOV      #SYNEXT!EIGHT!EVEPAR!D,@PARCSR
1572 003430 052777 000020 013364      BIS      #SYNSCH,@TXCSR  ;SET SEARCH SYNC
1573                                ;POKE CLK TO GET LOGIC INTO SYNCHRONIZATION
1574 003436 042777 020000 013372      BIC      #CLK,@TXCSR    ;POKE CLK DOWN
1575 003444 052777 020000 013364      BIS      #CLK,@TXCSR    ;POKE CLK UP
1576 003452 013703 017026      MOV      RxDBUF,R3     ;SET UP ERROR MESSAGE
1577 003456 005004      CLR     R4            ;DATA CHAR
1578 003460 010400      1$:  MOV      R4,R0        ;EXPECTED
1579 003462 012737 000011 001134      MOV      #9,SHIFT     ;# OF SHIFTS
1580 003470 010437 001140      MOV      R4,TEMP1     ;"TO BE SHIFTED CHARACTER"
1581 003474 004737 016700      JSR     PC,EVENB      ;CALC PARITY
1582                                ;TEMP1 NOW HAS CHARACTER TO BE POKED INTO RECEIVER
1583 003500 004737 016526      JSR     PC,RPOKE     ;SHIFT IN THIS CHAR
1584 003504 017701 013316      MOV      @RxDBUF,R1   ;ACTUAL
1585 003510 020001      CMP     R0,R1        ;COMPARE EXP VS ACT
1586 003512 001401      BEQ     +4
1587 003514 104002      HLT     2          ;DATA CHARS SHOULD MATCH
1588                                ;THERE SHOULD BE NO PARITY ERROR
1589 003516 005204      INC     R4          ;UPGRADE NEXT CHAR
1590 003520 105704      TSTB   R4          ;LAST CHAR ?
1591 003522 001356      BNE    1$
1592 003524 104400      SCOPE
1593                                ;; THIS TEST CHECKS THE STRIP SYNC FUNCTION
1594                                ;; OF THE RECEIVER LOGIC
1595                                ;; MODE:SYNINT
1596                                ;; LENGTH:FIVE
1597                                ;; NOTE: RxDONE SHOULD NEVER ASSERT
1598                                ;; CHAR: 26 (SYNC)
1599
1600 003526 012737 000006 001122  TST6:  MOV      #6,TSTNO      ;SAVE THIS
1601 003534 012737 003712 001112      MOV      #TST7,NEXT     ;GO TO THIS TEST WHEN THRU
1602 003542 052777 000400 013266      BIS      #MRESET,@TXCSR ;MASTER RESET

```

```

1603 003550 012777 030000 013254      MOV      #SYNINT,@PARCSR ;SET THE MODE
1604 003556 052777 000400 013252      BIS      #MRESET,@TXCSR ;MASTER RESET
1605
1606                                     ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
1607 003564 012777 064001 013244      MOV      #MTDATA!CLK!MINT!BREAK,@TXCSR
1608
1609                                     ;SET MODE , # OF BITS PARITY SENSE &LOAD SYNC REG
1610 003572 012777 030026 013232      MOV      #SYNINT!FIVE!NOPAR!26,@PARCSR
1611 003600 052777 000020 013214      BIS      #SYNSCH,@RXCSR ;SET SYNC SEARCH
1612                                     ;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
1613 003606 042777 020000 013222      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1614 003614 052777 020000 013214      BIS      #CLK,@TXCSR ;POKE CLK UP
1615                                     ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
1616 003622 042777 020000 013206      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1617 003630 052777 020000 013200      BIS      #CLK,@TXCSR ;POKE CLK UP
1618 003636 052777 000400 013156      BIS      #STPSYN,@RXCSR ;SET STRIP SYNC
1619 003644 012737 000003 001136      MOV      #3,COUNT ;# OF SYNC CHARS
1620 003652 012737 000026 001140 1$:      MOV      #26,TEMP1 ;CHAR TO BE SHIFTED
1621 003660 012737 000005 001134      MOV      #5,SHIFT ;# OF SHIFTS
1622 003666 004737 016526      JSR      PC,RPOKE ;SHIFT IN THIS CHAR
1623 003672 105777 013124      TSTB     @RXCSR ;RXDONE
1624 003676 100001      BPL      -+4
1625 003700 104000      HLT
1626 003702 005337 001136      DEC      COUNT ;# OF SYNC CHARS
1627 003706 001361      BNE      1$
1628 003710 104400      SCOPE
1629                                     ;;THIS TEST CHECKS THE STRIP SYNC FUNCTION
1630                                     ;;OF THE RECEIVER LOGIC
1631                                     ;;MODE:SYNINT
1632                                     ;;LENGTH:EIGHT
1633                                     ;;NOTE:RXDONE SHOULD NEVER ASSERT
1634                                     ;;CHAR: 26 (SYNC)
1635
1636 003712 012737 000007 001122  TST7:   MOV      #7,TSTNO ;SAVE THIS
1637 003720 012737 004076 001112      MOV      #TSTB_NEXT ;GO TO THIS TEST WHEN THRU
1638 003726 052777 000400 013102      BIS      #MRESET,@TXCSR ;MASTER RESET
1639 003734 012777 030000 013070      MOV      #SYNINT,@PARCSR ;SET THE MODE
1640 003742 052777 000400 013066      BIS      #MRESET,@TXCSR ;MASTER RESET
1641
1642                                     ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
1643 003750 012777 064001 013060      MOV      #MTDATA!CLK!MINT!BREAK,@TXCSR
1644
1645                                     ;SET MODE , # OF BITS PARITY SENSE &LOAD SYNC REG
1646 003756 012777 036026 013046      MOV      #SYNINT!EIGHT!NOPAR!26,@PARCSR
1647 003764 052777 000020 013030      BIS      #SYNSCH,@RXCSR ;SET SYNC SEARCH
1648                                     ;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
1649 003772 042777 020000 013036      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1650 004000 052777 020000 013030      BIS      #CLK,@TXCSR ;POKE CLK UP
1651                                     ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
1652 004006 042777 020000 013022      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1653 004014 052777 020000 013014      BIS      #CLK,@TXCSR ;POKE CLK UP
1654 004022 052777 000400 012772      BIS      #STPSYN,@RXCSR ;SET STRIP SYNC
1655 004030 012737 000003 001136      MOV      #3,COUNT ;# OF SYNC CHARS
1656 004036 012737 000026 001140 1$:      MOV      #26,TEMP1 ;CHAR TO BE SHIFTED
1657 004044 012737 000010 001134      MOV      #8,SHIFT ;# OF SHIFTS
1658 004052 004737 016526      JSR      PC,RPOKE ;SHIFT IN THIS CHAR

```

1659 004056 105777 012740
 1660 004062 100001
 1661 004064 104000
 1662 004066 005337 001136
 1663 004072 001361
 1664 004074 104400
 1665
 1666
 1667
 1668
 1669
 1670
 1671
 1672
 1673
 1674
 1675
 1676
 1677
 1678
 1679
 1680
 1681
 1682 004076 012737 000010 001122
 1683 004104 012737 004500 001112
 1684 004112 052777 000400 012716
 1685 004120 012777 000000 012704
 1686 004126 052777 000400 012702
 1687
 1688
 1689 004134 012777 064001 012674
 1690
 1691
 1692 004142 012777 007426 012662
 1693 004150 013703 017026
 1694 004154 012737 000003 001136
 1695 004162 052777 000020 012632
 1696
 1697 004170 042777 020000 012640
 1698 004176 052777 020000 012632
 1699
 1700 004204 042777 020000 012624
 1701 004212 052777 020000 012616
 1702 004220 052777 000400 012574
 1703 004226 012737 000013 001134
 1704 004234 012737 003054 001140
 1705 004242 004737 016526
 1706 004246 105777 012550
 1707 004252 100001
 1708 004254 104000
 1709 004256 005337 001136
 1710 004262 001361
 1711 004264 012700 000026
 1712 004270 017701 012532
 1713
 1714

```

TSTB @RXCSR ;RXDONE ?
BPL .+4
HLT ;RXDONE SHOULD NOT BE ASSERTED
DEC COUNT ;# OF SYNC CHARS
BNE 1$
SCOPE
:: THIS TEST PROVES THAT RXERR FREEZES THE "RECEIVER RESE"
:: WHILE IN STRIP SYNC MODE
:: THIS TEST FIRST PROVES THAT AUTOMATIC RESETS OCCUR WHEN
:: STRIP SYNC IS SET & SYNC CHARACTERS ARE SENT
:: ..... BUT IF AN ERROR SHOULD OCCUR.... THIS AUTOMATIC RESET
:: IS DISCOMBOBULATED
:: IE. FORCE PARITY ERROR WHILE STRIP SYNC IS SET
:: NOTE: NORMALLY THE LOGIC RESETS THE RXDONE & ERROR FLAGS
:: PROVIDING THAT ONLY GOOD SYNC CHARACTERS ARE SENT....
:: BUT IF AN RXERR OCCURS RXDONE PLUS RXERR ARE ASSERTED
:: MODE: ISOC (ISYMOD)
:: LENGTH: EIGHT
:: PARITY: EVEPAR
:: CHARACTER EXPECTED: 26
:: CHARACTER SENT: SYNC CHARACTER
:: NOTE: THIS TEST USES ONLY THE RECEIVER LOGIC
TSTB: MOV #8 TSTNO ;SAVE THIS
MOV #TST9 NEXT ;GO TO THIS TEST WHEN THRU
BIS #MRESET,@TXCSR ;MASTER RESET
MOV #ISYMOD,@PARCSR ;SET THE MODE
BIS #MRESET,@TXCSR ;MASTER RESET

;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
MOV #MNTDATA!CLK!MINT!BREAK,@TXCSR

;SET MODE # OF BITS,PARITY SENSE & LOAD SYNC REG
MOV #ISYMOD!EIGHT!EVEPAR!26,@PARCSR
MOV RXDBUF,R3 ;SET UP FOR ERROR MSG
MOV #3,COUNT ;# OF TIMES SYNC CHAR WILL BE SENT
BIS #SYNSCH,@RXCSR ;SET SYNC SEARCH
;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
BIC #CLK,@TXCSR ;POKE CLK DOWN
BIS #CLK,@TXCSR ;POKE CLK UP
;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
BIC #CLK,@TXCSR ;POKE CLK DOWN
BIS #CLK,@TXCSR ;POKE CLK UP
BIS #STPSYN,@RXCSR ;SET STRIP SYNC
2$: MOV #11,SHIFT ;# OF SHIFTS
MOV #3054,TEMP1 ;SYNC CHAR + START&STOP+ PARITY
1$: JSR PC,RPOKE ;SHIFT IN THIS CHARACTER
TSTB @RXCSR ;RXDONE = 0 ?
BPL .+4
HLT ;RXDONE SHOULD NOT BE SET
DEC COUNT ;# OF SYNC CHARS
2$: GO AGAIN ?
MOV #26,R0 ;EXPECTED
MOV @RXDBUF,R1 ;ACTUAL
;NOTE THAT THIS IS THE FIRST TIME
;RXDBUF IS READ.....THERE SHOULD BE
    
```

```

1715                                     ;NO OVER RUN ERRORS
1716 004274 020001                      CMP    RD,R1      ;COMPARE EXPECTED VS ACTUAL
1717 004276 001401                      BEQ    +4
1718 004300 104002                      HLT    2          ;DATA CHARS SHOULD COMPARE
1719                                     ;THERE SHOULD BE NO RXERR'S
1720 004302 012737 000004 001136        MOV    #4,COUNT  ;# OF TIMES
1721 004310 012700 110026                MOV    #RXERR!PARER!26,R0 ;EXPECTED
1722 004314 012737 002054 001140        MOV    #2054,TEMP1 ;BAD SYNC CHAR (WRONG PARITY)
1723 004322 012737 000013 001134 3$:   MOV    #11,SHIFT ;# OF SHIFTS
1724 004330 004737 016526                JSR    PC,RPOKE  ;SHIFT IN THIS CHAR
1725 004334 105777 012462                TSTB   @RXCSR   ;RXDONE = 1?
1726 004340 100401                      BMI    +4
1727 004342 104000                      HLT    ;RXDONE SHOULD BE SET
1728 004344 017701 012456                MOV    @RXDBUF,R1 ;ACTUAL DATA
1729 004350 020001                      CMP    RD,R1     ;COMPARE EXP VS ACT
1730 004352 001401                      BEQ    +4
1731 004354 104002                      HLT    2          ;DID THE RESPECTIVE ERROR STOP THE
1732                                     ;AUTOMATIC RESETTING OF RXDONE & ERROR FLAGS
1733                                     ;...CHECK THIS....
1734 004356 005337 001136                DEC    COUNT    ;# OF SYNC CHARS
1735 004362 001445                      BEQ    5$       ;FINISHED? GET OUT OF TEST
1736 004364 022737 000003 001136        CMP    #3,COUNT ;# OF SYNC CHARS
1737 004372 001423                      BEQ    6$       ;CHECK FRAME ERROR?
1738 004374 022737 000002 001136        CMP    #2,COUNT ;# OF SYNC CHARS
1739 004402 001426                      BEQ    7$       ;CHECK FRAME ERROR & BAD PARITY?
1740                                     ;NOPE THEN IT (COUNT) MUST BE = 1 THEREFORE....
1741 004404 012737 000013 001134        MOV    #11,SHIFT ;# OF SHIFTS
1742 004412 012737 000054 001140        MOV    #54,TEMP1 ;FRAME & PARITY ERROR
1743 004420 004737 016526                JSR    PC,RPOKE  ;SHIFT IN THIS CHAR
1744                                     ;NOW DON'T READ THE RXDBUF TO CREATE OVER RUN
1745 004424 012737 000054 001140        MOV    #54,TEMP1 ;FRAME & PARITY ERROR
1746 004432 012700 170026                MOV    #RXERR!OVRUN!FRMERR!PARER!26,R0 ;EXPECTED
1747 004436 000137 004322                JMP    3$       ;DO IT AGAIN
1748 004442 012737 001054 001140 6$:   MOV    #1054,TEMP1 ;BAD STOP BIT FOR FRAME ERROR
1749 004450 012700 120026                MOV    #RXERR!FRMERR!26,R0 ;EXPECTED
1750 004454 000137 004322                JMP    3$       ;DO IT AGAIN
1751 004460 012737 000054 001140 7$:   MOV    #54,TEMP1 ;BAD STOP BIT & PARITY
1752 004466 012700 130026                MOV    #RXERR!FRMERR!PARER!26,R0 ;EXPECTED
1753 004472 000137 004322                JMP    3$       ;DO IT AGAIN
1754 004476 104400 5$:                 SCOPE
1755                                     ;; THIS TEST VERIFYS WORD LENGTH SELECT OF
1756                                     ;; THE TRANSMITTER SECTION, IT USES THE DNA FLAG
1757                                     ;; AND BIT WINDOW TO DETERMINE THAT IT WAS SELECTED
1758                                     ;; CORRECTLY
1759                                     ;; NOTE: DNA COMES UP ON THE FIRST RISING BIT
1760                                     ;; EDGE OF THE NEXT CHARACTER IF NO NEW CHARACTER IS
1761                                     ;; LOADED INTO TXDBUF
1762                                     ;; MODE:SYNINT
1763                                     ;; PARITY:NO PARITY
1764                                     ;; LENGTH:EIGHT
1765
1766 004500 012737 000011 001122  TST9:  MOV    #9,TSTNO  ;SAVE THIS
1767 004506 012737 004732 001112        MOV    #TST10,NEXT ;GO TO THIS TEST WHEN THRL
1768 004514 052777 000400 012314        BIS    #MRESET,@TXCSR ;MASTER RESET
1769 004522 012777 030000 012302        MOV    #SYNINT,@PARCSR ;SET THE MODE
1770 004530 052777 000400 012300        BIS    #MRESET,@TXCSR ;MASTER RESET

```

```

1771
1772 ;SET MAINTENANCE MODE & SEND
1773 ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
1774 004536 012777 004020 012272 MOV #MINT!SEND,@TXCSR
1775
1776 ;SET MODE # OF BITS,PARITY SENSE, & LOAD SYNC REG
1777 004544 012777 036026 012260 MOV #SYNINT!EIGHT!NOPAR!26,@PARCSR
1778 004552 013703 017036 MOV TXCSR,R3 ;SET UP FOR ERROR MSG
1779 004556 112777 000021 012256 MOVB #21,@TXDBUF ;LOAD CHAR
1780 004564 012737 000021 001140 MOV #21,TEMP1 ;SHIFTED CHAR
1781 004572 012737 000010 001134 MOV #8,SHIFT ;# OF SHIFTS
1782 ;POKE CLK TO GET INTO SYNCRONIZATION
1783 004600 052777 020000 012230 BIS #CLK,@TXCSR ;POKE CLK UP
1784 004606 042777 020000 012222 BIC #CLK,@TXCSR ;POKE CLK DOWN
1785 004614 005000 1$: CLR RO
1786 004616 006037 001140 ROR TEMP1 ;FORCE CARRY
1787 004622 103002 BCC 2$
1788 004624 052700 002000 BIS #BITW,RO ;EQUIV OF BIT WINDOW
1789 004630 2$: BIS #CLK,@TXCSR ;POKE CLK UP
1790 004630 052777 020000 012200 BIC #CLK,@TXCSR ;POKE CLK DOWN
1791 004636 042777 020000 012172 MOV @TXCSR,R1 ;ACTUAL
1792 004644 017701 012166 BIC #075777,R1 ;SAVE BITW & DNA
1793 004650 042701 075777 CMP RO,R1 ;COMPARE EXP VS ACT
1794 004654 020001 BEQ +4
1795 004656 001401 HLT 3 ;BIT WINDOW DID NOT MATCH ACTUAL DATA
1796 004660 104003 ;BIT... ALSO CHECK DNA
1797 ;# OF SHIFTS
1798 004662 005337 001134 DEC SHIFT ;# OF SHIFTS
1799 004666 001352 BNE 1$ ;DO IT AGAIN ?
1800 ;NOW POKE CLK TO SEE DNA
1801 004670 052777 020000 012140 BIS #CLK,@TXCSR ;POKE CLK
1802 004676 012700 100000 MOV #100000,RO ;EXPECTED
1803 004702 017701 012130 MOV @TXCSR,R1 ;ACTUAL
1804 004706 042701 077777 BIC #77777,R1 ;SAVE DNA ONLY
1805 004712 020001 CMP RO,R1 ;COMPARE EXPECTED VS ACTUAL
1806 004714 001401 BEQ +4
1807 004716 104003 HLT 3 ;DNA SHOULD BE SET
1808 ;IF DNA DID NOT SET,CHECK WORD LENGTH
1809 ;SELECT LOGIC OF THE TRANSMITTER
1810 004720 005777 012112 TST @TXCSR ;DNA ?
1811 004724 100001 BPL +4
1812 004726 104000 HLT ;DNA SHOULD NOT BE SET
1813 ;IT SHOULD HAVE BEEN CLEARED FROM
1814 ;PREVIOUS READ
1815 004730 104400 SCOPE
1816 ;;THIS TEST VERIFYS CHARACTER PLUS PARITY GENERATION
1817 ;;OF THE TRANSMITTER SECTION.
1818 ;;IT ALSO CHECKS DNA TIMING
1819 ;;MODE:ISYMOD
1820 ;;LENGTH:SEVEN PLUS PARITY
1821 ;;PARITY:EVEPAR
1822 ;;CHARACTER:125
1823
1824 004732 012737 000012 001122 TST10: MOV #10,TSTNO ;SAVE THIS
1825 004740 012737 005154 001112 MOV #TST11,NEXT ;GO TO THIS TEST WHEN THRU
1826 004746 052777 000400 012062 BIS #MRESET,@TXCSR ;MASTER RESET

```

```

1827 004754 012777 000000 012050      MOV      #ISYMOD,@PARCSR ;SET THE MODE
1828 004762 052777 000400 012046      BIS      #MRESET,@TXCSR ;MASTER RESET
1829
1830      ;SET MAINTENANCE MODE & SEND
1831      ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=C)
1832 004770 012777 004020 012040      MOV      #MINT!SEND,@TXCSR
1833
1834      ;SET MODE, # OF BITS,PARITY SENSE, & LOAD SYNC REG
1835 004776 012777 005426 012026      MOV      #ISYMOD!SEVEN!EVEPAR!26,@PARCSR
1836 005004 013703 017036      MOV      TXCSR,R3 ;SET UP FOR ERROR MSG
1837 005010 112777 000125 012024      MOV      #125,@TXDBUF ;LOAD DATA CHAR
1838 005016 012737 001252 001140      MOV      #1252,TEMP1 ;TO BE SHIFTED CHAR
1839 005024 012737 000012 001134      MOV      #10,SHIFT ;# OF SHIFTS
1840      ;POKE CLK TO GET INTO SYNCHRONIZATION
1841 005032 052777 020000 011776      BIS      #CLK,@TXCSR ;POKE CLK UP
1842 005040 042777 020000 011770      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1843 005046 005000      1$: CLR      R0
1844 005050 006037 001140      ROR      TEMP1 ;FORCE CARRY
1845 005054 103002      BCC     2$ ;BR IF CARRY CLR
1846 005056 052700 002000      BIS      #BITW,R0 ;EQUIV OF BITW
1847 005062
1848 005062 052777 020000 011746      BIS      #CLK,@TXCSR ;POKE CLK UP
1849 005070 042777 020000 011740      BIC      #CLK,@TXCSR ;POKE CLK DOWN
1850 005076 017701 011734      MOV      @TXCSR,R1 ;ACTUAL
1851 005102 042701 075777      BIC      #075777,R1 ;SAVE BITW & DNA
1852 005106 020001      CMP      R0,R1 ;COMPARE EXP VS ACT
1853 005110 001401      BEQ     +4
1854 005112 104003      HLT     3 ;BIT WINDOW DID NOT MATCH ACTUAL DATA
1855      ;BIT...ALSO CHECK DNA
1856 005114 005337 001134      DEC      SHIFT ;# OF SHIFTS
1857 005120 001352      BNE     1$ ;DO IT AGAIN ?
1858      ;NOW POKE CLK TO SEE DNA
1859 005122 052777 020000 011706      BIS      #CLK,@TXCSR ;POKE CLK
1860 005130 012700 000000      MOV      #0,R0 ;EXPECTED
1861 005134 017701 011676      MOV      @TXCSR,R1 ;ACTUAL
1862 005140 042701 077777      BIC      #77777,R1 ;SAVE DNA ONLY
1863 005144 020001      CMP      R0,R1 ;COMPARE EXP VS ACT
1864 005146 001401      BEQ     +4
1865 005150 104003      HLT     3 ;DNA SHOULD BE SET
1866      ;IF DNA DID NOT SET
1867      ;CHECK WORD LENGTH SELECT LOGIC
1868 005152 104400
1869      SCOPE
1870      ;; THIS TEST VERIFYS CHARACTER PLUS PARITY GENERATION
1871      ;; OF THE TRANSMITTER SECTION.
1872      ;; IT ALSO CHECKS DNA TIMING
1873      ;; MODE:SYNINT
1874      ;; LENGTH:EIGHT PLUS PARITY
1875      ;; PARI /:EVEPAR
1876      ;; CHARACTER:125
1877 005154 012737 000013 001122      TST11: MOV      #11,TSTNO ;SAVE THIS
1878 005162 012737 005376 001112      MOV      #TST12,NEXT ;GO TO THIS TEST WHEN THRU
1879 005170 052777 000400 011640      BIS      #MRESET,@TXCSR ;MASTER RESET
1880 005176 012777 030000 011626      MOV      #SYNINT,@PARCSR ;SET THE MODE
1881 005204 052777 000400 011624      BIS      #MRESET,@TXCSR ;MASTER RESET
1882

```

```

1883 ;SET MAINTENANCE MODE & SEND
1884 ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
1885 005212 012777 004020 011616 MOV #MINT!SEND,@TXCSR
1886
1887 ;SET MODE, # OF BITS, PARITY SENSE, & LOAD SYNC REG
1888 005220 012777 037426 011604 MOV #SYNINT!EIGHT!EVEPAR!26,@PARCSR
1889 005226 013703 017036 MOV TXCSR,R3 ;SET UP FOR ERROR MSG
1890 005232 112777 000125 011602 MOVB #125,@TXDBUF ;LOAD DATA CHAR
1891 005240 012737 000125 001140 MOV #125,TEMP1 ;TO BE SHIFTED CHAR
1892 005246 012737 000011 001134 MOV #9,SHIFT ;# OF SHIFTS
1893 ;POKE CLK TO GET INTO SYNCRONIZATION
1894 005254 052777 020000 011554 BIS #CLK,@TXCSR ;POKE CLK UP
1895 005262 042777 020000 011546 BIC #CLK,@TXCSR ;POKE CLK DOWN
1896 005270 005000 CLR RO
1897 005272 006037 001140 ROR TEMP1 ;FORCE CARRY
1898 005276 103002 BCC 2$ ;BR IF CARRY CLR
1899 005300 052700 002000 BIS #BITW,RO ;EQUIV OF BITW
1900 005304
1901 005304 052777 020000 011524 BIS #CLK,@TXCSR ;POKE CLK UP
1902 005312 042777 020000 011516 BIC #CLK,@TXCSR ;POKE CLK DOWN
1903 005320 017701 011512 MOV @TXCSR,R1 ;ACTUAL
1904 005324 042701 075777 BIC #075777,R1 ;SAVE BITW & DNA
1905 005330 020001 CMP RO,R1 ;COMPARE EXP VS ACT
1906 005332 001401 BEQ +4
1907 005334 104003 HLT 3 ;BIT WINDOW DID NOT MATCH ACTUAL DATA
1908 ;BIT...ALSO CHECK DNA
1909 005336 005337 001134 DEC SHIFT ;# OF SHIFTS
1910 005342 001352 BNE 1$ ;DO IT AGAIN ?
1911 ;NOW POKE CLK TO SEE DNA
1912 005344 052777 020000 011464 BIS #CLK,@TXCSR ;POKE CLK
1913 005352 012700 100000 MOV #100000,RO ;EXPECTED
1914 005356 017701 011454 MOV @TXCSR,R1 ;ACTUAL
1915 005362 042701 077777 BIC #77777,R1 ;SAVE DNA ONLY
1916 005366 020001 CMP RO,R1 ;COMPARE EXP VS ACT
1917 005370 001401 BEQ +4
1918 005372 104003 HLT 3 ;DNA SHOULD BE SET
1919 ;IF DNA DID NOT SET
1920 ;CHECK WORD LENGTH SELECT LOGIC
1921 005374 104400 SCOPE
1922 ;;THIS TEST VERIFYS CHARACTER PLUS PARITY GENERATION
1923 ;;OF THE TRANSMITTER SECTION.
1924 ;;IT ALSO CHECKS DNA TIMING
1925 ;;MODE:SYNINT
1926 ;;LENGTH:EIGHT PLUS PARITY
1927 ;;PARITY:EVEPAR
1928 ;;CHARACTER:252
1929 ;;
1930 005376 012737 000014 001122 TST12: MOV #12,TSTNO ;SAVE THIS
1931 005404 012737 005620 001112 MOV #TST13,NEXT ;GO TO THIS TEST WHEN THRU
1932 005412 052777 00C400 011416 BIS #MRESET,@TXCSR ;MASTER RESET
1933 005420 012777 030000 011404 MOV #SYNINT,@PARCSR ;SET THE MODE
1934 005426 052777 000400 011402 BIS #MRESET,@TXCSR ;MASTER RESET
1935
1936 ;SET MAINTENANCE MODE & SEND
1937 ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
1938 005434 012777 0C4020 011374 MOV #MINT!SEND,@TXCSR

```



```

1995
1996
1997 005664 012777 064001 011144 ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
1998
1999
2000 005672 012777 036026 011132 MOV #SYNINT!EIGHT!NOPAR!26,@PARCSR
2001 005700 052777 000020 011114 BIS #SYNSCH,@RXCSR ;SET SYNC SEARCH
2002 ;POKE CLK TO GET RECEIVER INTO SYNCRIZATION....
2003 005706 042777 020000 011122 BIC #CLK,@TXCSR ;POKE CLK DOWN
2004 005714 052777 020000 011114 BIS #CLK,@TXCSR ;POKE CLK UP
2005 ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
2006 005722 042777 020000 011106 BIC #CLK,@TXCSR ;POKE CLK DOWN
2007 005730 052777 020000 011100 BIS #CLK,@TXCSR ;POKE CLK UP
2008 005736 012737 000010 001134 MOV #8.,SHIFT ;# OF SHIFTS
2009 005744 012737 000026 001140 MOV #26,TEMP1 ;SYNC CHAR TO BE SHIFTED IN
2010 005752 004737 016526 JSR PC,@POKE ;SHIFT IN THIS SYNC CHAR
2011 005756 032777 004000 011036 BIT #REACT,@RXCSR ;REACT = 0 ?
2012 005764 001401 BEQ .+4
2013 005766 104000 HLT ;REACT SHOULD BE 0
2014 005770 012737 000010 001134 MOV #8.,SHIFT ;# OF SHIFTS
2015 005776 012737 000025 001140 MOV #25,TEMP1 ;ANY CHARACTER
2016 006004 004737 016526 JSR PC,@POKE ;SHIFT IN THIS CHARACTER
2017 ;YOU HAVE JUST LOST SYNCRONIZATION.....
2018 ;POKE THE CLK TWICE TO GET INTO SYNCRONIZATION
2019 ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
2020 006010 042777 020000 011020 BIC #CLK,@TXCSR ;POKE CLK DOWN
2021 006016 052777 020000 011012 BIS #CLK,@TXCSR ;POKE CLK UP
2022 ;POKE CLK TO GET LOGIC INTO SYNCRONIZATION
2023 006024 042777 020000 011004 BIC #CLK,@TXCSR ;POKE CLK DOWN
2024 006032 052777 020000 010776 BIS #CLK,@TXCSR ;POKE CLK UP
2025 006040 012737 000002 001136 MOV #2,COUNT ;# OF SYNC CHARS
2026 006046 032777 004000 010746 1$: BIT #REACT,@RXCSR ;REACT = 0 ?
2027 006054 001401 BEQ .+4
2028 006056 104000 HLT ;REACT SHOULD BE 0
2029 006060 012737 000010 001134 MOV #8.,SHIFT ;# OF SHIFTS
2030 006066 012737 000026 001140 MOV #26,TEMP1 ;SYNC CHAR
2031 006074 004737 016526 JSR PC,@POKE ;SHIFT IN THIS SYNC CHAR
2032 006100 005337 001136 DEC COUNT
2033 006104 001360 BNE 1$ ;IS COUNT = 0 ? NO GO AGAIN
2034 006106 032777 004000 010706 BIT #REACT,@RXCSR ;REACT = 1 ?
2035 006114 001001 BNE .+4
2036 006116 104000 HLT ;REACT SHOULD BE ASSERTED
2037 006120 104400 2$: SCOPE
2038 ;: THIS TEST VERIFYS TX DONE FUNCTION, DONE = 1
2039 ;: ALSO VERIFYS THAT THE TRANSMITTER CHIP IDLES "SYNC" CHARACTER
2040 ;: WHEN NO NEW CHARACTER IS LOADED INTO TXDBUF("SYNC" = BINARY COUNT PATTERN)
2041 ;: MODE: SYNC INTERNAL
2042 ;: PARITY: NO PARITY (NOPAR)
2043 ;: LENGTH: EIGHT
2044
2045 006122 012737 000016 001122 1$T14: MOV #14,TSTNO ;SAVE THIS
2046 006130 012737 006420 001112 MOV #TST15,NEXT ;GO TO THIS TEST WHEN THRU
2047 006136 012737 006322 001114 MOV #6$,LOCK ;SET UP FOR SCOPE LOOP
2048 006144 012704 036000 MOV #SYNINT!EIGHT!NOPAR!0,R4 ;MODE ETC.
2049 006150 052777 000400 010660 5$: BIS #MRESET,@TXCSR ;MASTER RESET
2050 006156 012777 030000 010646 MOV #SYNINT,@PARCSR ;SET THE MODE

```

```

2051 006164 052777 000400 010644 B1S #MRESET,@TXCSR ;MASTER RESE*
2052 006172 012777 004020 010636 MOV #MINT!SEND,@TXCSR
2053 006200 010477 010626 MOV R4,@PARCSR
2054 006204 105777 010626 TSTB @TXCSR ;TXDONE?
2055 006210 100401 BMI .+4
2056 006212 104000 HLT ;TXDONE SHOULD BE SET
2057 006214 112777 000021 010620 MOVB #21,@TXDBUF ;LOAD ANY CHAR
2058 :POKE CLK TO GET INTO SYNCRONIZATION
2059 006222 052777 020000 010606 B1S #CLK,@TXCSR ;POKE CLK UP
2060 006230 042777 020000 010600 B1C #CLK,@TXCSR ;POKE CLK DOWN
2061 006236 105777 010574 TSTB @TXCSR
2062 006242 100001 BPL .+4
2063 006244 104000 HLT ;TXDONE SHOULD BE CLF
2064
2065 006246 052777 020000 010562 B1S #CLK,@TXCSR ;POKE CLK UP
2066 006254 042777 020000 010554 B1C #CLK,@TXCSR ;POKE CLK DOWN
2067 006262 105777 010550 TSTB @TXCSR
2068 006266 100401 BMI .+4
2069 006270 104000 HLT ;TXDONE SHOULD BE SET
2070 006272 012737 000007 001134 MOV #7,SHIFT
2071 006300 1S:
2072 006300 052777 020000 010530 B1S #CLK,@TXCSR ;POKE CLK UP
2073 006306 042777 020000 010522 B1C #CLK,@TXCSR ;POKE CLK DOWN
2074 006314 005337 001134 DEC SHIFT
2075 006320 001367 1S:
2076 006322 013703 017036 6S: MOV TXCSR,R3 ;SHIFT OUT THE "21"
;FOR ERROR MESSAGE
;THE BIT WINDOW IS RE GENERATED INTO
;A CHARACTER AND LEFT PRESENTED IN R1
;FOR THE COMPARE OPERATION. IF YOU WANT TO
;LOCK ON A PARTICULAR SYNC CHARACTER...
;SET SMRO9=1
2077
2078
2079
2080
2081
2082 006326 005000 CLR R0
2083 006330 150400 BISB R4,R0 ;EXPECT "SYNC"
2084 006332 012737 000010 001134 MOV #8,SHIFT ;# OF SHIFTS
2085 006340 005001 CLR R1
2086 006342 3S:
2087 006342 052777 020000 010466 B1S #CLK,@TXCSR ;POKE CLK UP
2088 006350 042777 020000 010460 B1C #CLK,@TXCSR ;POKE CLK DOWN
2089 006356 000241 CLC
2090 006360 032777 002000 010450 BIT #BITW,@TXCSR ;BITW = ?
2091 006366 001401 BEQ 2S
2092 006370 000261 SEC ;SET CARRY
2093 006372 106001 RORB R1 ;PICK UP CARRY
2094 006374 005337 001134 DEC SHIFT
2095 006400 001360 BNE 3S ;FINISH THAT CHARACTER
2096 006402 020001 CMP R0,R1 ;CMP EXPECTED VS ACTUAL
2097 006404 001401 BEQ .+4
2098 006406 104003 HLT 3 ;SYNC CHAR IS NOT CORRECT
2099 006410 104401 SCOPI
2100 006412 105204 INCB R4 ;SET UP FOR NEXT SYNC HOLDING REG.
2101 006414 001255 BNE 5S ;FINISHED WITH BINARY COUNT PATTERN ^
2102
2103 006416 104400 SCOPE
2104
2105
2106

```

```

;;THIS TEST PROVES THAT RXERR FREEZES THE "RECEIVER
;;RESET" WHILE IN STRIP SYNC MODE

```

```

2107 :: THIS TEST FIRST PROVES THAT AUTOMATIC RESETS OCCUR
2108 :: WHEN STRIP SYNC IS SET AND SYNC CHARACTERS ARE SENT
2109 :: BUT IF AN ERROR SHOULD OCCUR...THIS AUTOMATIC RESET
2110 :: IS DISCOMBOBULATED
2111 :: IE: FORCE OVERRUN (OVERRUN) WHILE STRIP SYNC IS SET
2112 :: BY TRANSMITTING A DATA CHARACTER THEN TRANSMIT A SYNC CHARACTER
2113 :: AND DON'T READ THAT DATA CHARACTER. NOTE: NORMALLY THE LOGIC
2114 :: RESETS THE RXDONE & ERROR FLAGS PROVIDING THAT ONLY SYNC CHARACTERS ARE
2115 :: STRIPPED
2116 :: MODE: SYNC EXTERNAL (SYNEXT)
2117 :: LENGTH: EIGHT
2118 :: NOTE: THIS TEST USES BOTH RECEIVER AND TRANSMITTER LOGIC
2119 ::
2120
2121 006420 012737 000017 001122 TST15: MOV #15,TSTNO ;SAVE THIS
2122 006426 012737 006722 001112 MOV #TST16,NEXT ;GO TO THIS TEST WHEN THE
2123
2124 006434 052777 000400 010374 BIS #MRESET,@TXCSR ;MASTER RESET
2125 006442 012777 020000 010362 MOV #SYNEXT,@PARCSR ;SET THE MODE
2126 006450 052777 000400 010360 BIS #MRESET,@TXCSR ;MASTER RESET
2127
2128 ;SET MAINTENANCE MODE & SEND
2129 ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
2130 006456 012777 004020 010352 MOV #MINT!SEND,@TXCSR
2131
2132 ;SET MODE, # OF BITS, PARITY SENSE, & LOAD SYNC REG
2133 006464 012777 026026 010340 MOV #SYNEXT!EIGHT!NOPAR!26,@PARCSR
2134 006472 112777 000026 010342 MOVB #26,@TXDBUF ;LOAD SYNC CHAR
2135 006500 052777 000420 010314 BIS #SYNSCH!STPSYN,@TXCSR ;SET SYNC SEARCH & STRIP SYNC

```


SUMMARY: THE OVRUN STOPPED
THE AUTOMATIC RESETTING OF
RXDONE & ERROR FLAGS.....CHECK THIS

```

2183
2184
2185
2186 006720 104400
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198 006722 012737 000020 001122
2199 006730 012737 007452 001112
2200
2201 006736 105737 001172
2202 006742 100002
2203 006744 000137 007450
2204 006750 052777 000400 010060
2205 006756 012777 030000 010046
2206 006764 052777 000400 010044
2207
2208
2209 006772 012777 064001 010036
2210
2211
2212 007000 012777 036026 010024
2213
2214 007006 052777 000020 010006
2215
2216 007014 042777 020000 010014
2217 007022 052777 020000 010006
2218
2219 007030 042777 020000 010000
2220 007036 052777 020000 007772
2221 007044 012737 000002 001136
2222 007052 013703 017026
2223 007056 012737 000010 001134
2224 007064 012737 000026 001140
2225 007072 004737 016526
2226 007076 005337 001136
2227 007102 001403
2228
2229 007104 105737 001172
2230 007110 100762
2231
2232 007112 032777 004000 007702
2233 007120 001001
2234 007122 104000
2235 007124 012737 000004 001134
2236 007132 012737 000026 001140
2237 007140 004737 016526
2238 007144 032777 004000 007650

```

```

SCOPE
:: THIS TEST VERIFYS THAT BY DROPPING SYNCSCH
:: IN THE MIDDLE OF A CHARACTER, SYNC CHARACTER SEQUENCE
:: IS NEEDED BEFORE RECACT, RXDONE ASSERT AGAIN.
:: ALSO NOTE: SINCE RECACT IS DEPENDENT ON MATCH DETECT,
:: AND IF SYNCSCH IS DROPPED IN THE MIDDLE OF
:: A SYNC CHARACTER AND THEN RAISED AGAIN, RXDONE SHOULD
:: NOT ASSERT UNTIL NEW SYNC CHARACTER SEQUENCE
:: MODE: SYNC INTERNAL (SYNINT)
:: LENGTH: EIGHT
::
TST16: MOV #16, TSTNO ;SAVE THIS
MOV #TST17, NEXT ;GO TO THIS TEST WHEN THRU

TSTB SYNCNO ;TWO SYNC CHARACTERS SELECTED ?
BPL .+6 ;IF ANSWER WAS NO DO THIS TEST
JMP 4$ ;IF ANSWER WAS YES JUMP OVER THIS TEST
BIS #MRESET, @TXCSR ;MASTER RESET
MOV #SYNINT, @PARCSR ;SET THE MODE
BIS #MRESET, @TXCSR ;MASTER RESET

;SET MAINT DATA, CLK BREAK, & MAINTENANCE MODE
MOV #MTDATA:CLK:MINT:BREAK, @TXCSR

;SET MODE, # OF BITS, PARITY SENSE, & LOAD SYNC REG
MOV #SYNINT:EIGHT:NOPAR:26, @PARCSR

BIS #SYNCSCH, @RXCSR ;SET SYNC SEARCH
;POKE CLK TO GET RECEIVER INTO SYNCHRONIZATION....
BIC #CLK, @TXCSR ;POKE CLK DOWN
BIS #CLK, @TXCSR ;POKE CLK UP
;POKE CLK TO GET LOGIC INTO SYNCHRONIZATION
BIC #CLK, @TXCSR ;POKE CLK DOWN
BIS #CLK, @TXCSR ;POKE CLK UP
MOV #2, COUNT ;# OF TIMES
MOV RXDBUF, R3 ;FOR ERROR MESSAGE
1$: MOV #8, SHIFT ;# OF SHIFTS
MOV #26, TEMP1 ;SYNC CHAR.
JSR PC, @POKE
DEC COUNT
BEQ 2$

;TEST TO SEE HOW MANY SYNC CHARACTERS NEEDED
TSTB SYNCNO
BMI 1$

2$: BIT #RECACT, @RXCSR ;RECACT=1?
BNE .+4
HLT ;RECACT SHOULD BE SET
MOV #4, SHIFT ;# OF SHIFTS
MOV #26, TEMP1 ;SYNC CHAR.
JSR PC, @POKE
BIT #RECACT, @RXCSR ;RECACT=1?

```

2239	007152	001001			BNE	.+4	
2240	007154	104000			HLT		;REACT SHOULD STILL BE SET
2241	007156	042777	000020	007636	BIC	#5,SYNSCH,DRXCSR	;DROP SEARCH SYNC
2242	007164	032777	004000	007630	BIT	#REACT,DRXCSR	;REACT=0?
2243	007172	001401			BEQ	.+4	
2244	007174	104000			HLT		;REACT SHOULD NOT BE SET
2245							;NOW SHIFT TWO BITS TO ALLOW SEARCH SYNC =0 TO TAKE
2246							;EFFECT IN THE LOGIC(THIS ALLOWS THE RECEIVER CHIP TO SEE
2247							;THE DROPPING OF SEARCH SYNC)...MATCH DETECT IN THE REC.CHIP SHOULD ALSO DROP
2248	007176	012737	000002	001134	MOV	#2,SHIFT	;# OF SHIFTS
2249	007204	004737	016526		JSR	PC,RPOKE	
2250	007210	052777	000020	007604	BIS	#SYNSCH,DRXCSR	;SET SEARCH SYNC
2251	007216	032777	004000	007576	BIT	#REACT,DRXCSR	
2252	007224	001401			BEQ	.+4	
2253	007226	104000			HLT	;REACT =0 ?	
2254	007230	105777	007566		TSTB	DRXCSR	
2255	007234	100001			BPL	.+4	
2256	007236	104000			HLT	;RXDONE = 0 ?	
2257	007240	012737	000002	001134	MOV	#2,SHIFT	;# OF SHIFTS
2258	007246	004737	016526		JSR	PC,RPOKE	
2259	007252	032777	004000	007542	BIT	#REACT,DRXCSR	;REACT=0?
2260	007260	001401			BEQ	.+4	
2261	007262	104000			HLT		;REACT SHOULD NOT BE SET
2262	007264	105777	007532		TSTB	DRXCSR	;RXDONE=0?
2263	007270	100001			BPL	.+4	
2264	007272	104000			HLT		;RXDONE SHOULD NOT BE ASSERTED
2265	007274	012700	000026		MOV	#26,RO	;EXPECTED
2266	007300	017701	007522		MOV	DRXDBUF,R1	;ACTUAL
2267	007304	020001			CMP	RO,R1	
2268	007306	001401			BEQ	.+4	
2269	007310	104002			HLT	2	;CHARACTERS SHOULD BE MATCHED
2270	007312	012737	000002	001136	MOV	#2,COUNT	;# OF TIMES OF SYNC CHARS.
2271							;TEST TO SEE HOW MANY SYNC CHARS NEEDED
2272	007320	105737	001172		TSTB	SYNSCH	
2273	007324	100402			BMI	3\$;WILL IT BE TWO OR ONE ?
2274	007326	005337	001136		DEC	COUNT	;IT WAS ONLY ONE NEEDED
2275	007332	012737	000010	001134	MOV	#8,SHIFT	;#OF SHIFTS
2276	007340	012737	000026	001140	MOV	#26,TEMP1	;SYNC CHAR
2277	007346	004737	016526		JSR	PC,RPOKE	
2278	007352	005337	001136		DEC	COUNT	;IS IT THE LAST SYNC CHAR ?
2279	007356	001365			BNE	3\$;GO AGAIN AND SHIFT IN ANOTHER SYNC CHAR
2280	007360	032777	004000	007434	BIT	#REACT,DRXCSR	;REACT=1?
2281	007366	001001			BNE	.+4	
2282	007370	104000			HLT		;REACT SHOULD BE ASSERTED
2283	007372	105777	007424		TSTB	DRXCSR	;RXDONE=0?
2284	007376	100001			BPL	.+4	
2285	007400	104000			HLT		;RXDONE SHOULD NOT BE ASSERTED
2286	007402	012737	000010	001134	MOV	#8,SHIFT	;#OF SHIFTS
2287	007410	012737	000025	001140	MOV	#25,TEMP1	;ANY CHARACTER
2288	007416	004737	016526		JSR	PC,RPOKE	
2289	007422	105777	007374		TSTB	DRXCSR	;RXDONE=1?
2290	007426	100401			BMI	.+4	
2291	007430	104000			HLT		;RXDONE SHOULD NOW BE ASSERTED
2292	007432	012700	000025		MOV	#25,RO	;EXPECTED
2293	007436	017701	007364		MOV	DRXDBUF,R1	;ACTUAL
2294	007442	020001			CMP	RO,R1	

2295 007444 001401
2296 007446 104002

BLO
HLT 2 +4

;CHARACTERS SHOULD BE MATCHED
;IF THIS FAILS THEN CHECK THAT THE CORRECT
;RECEIVER CHIP IS BEING USED...WHAT IS
;HAPPENING IS THAT MATCH DETECT IS ASSERTING
;BEFORE A NEW SYNC CHARACTER SEQUENCE
;TRANSPIRES THUS RXDONE ASSERTS TOO SOON
;AND OVER RUN OCCURS SINCE THE RECEIVER WAS NOT READ
;CONCLUSION::: IF OLDER RECEIVER CHIP
;IS BEING USED THEN REPLACE IT WITH A NEW
;RECEIVER CHIP IF 1 SYNC CHARACTER SEQUENCE IS DECIPHERED

2307 007450 104400

4\$: SCOPE
;: THIS TEST VERIFYS THAT DSC CAUSES AN INTERRUPT
;: THIS TEST ONLY WORKS IN MAINT EXTERNAL MODE
;: INTERRUPT VECTOR: DURIV

2311 007452 012737 000021 001122
2312 007460 012737 007652 001112
2313 007466 105737 001177
2314 007472 100066
2315 007474 052777 000400 007334
2316 007502 012777 007526 007336
2317 007510 013777 016366 007332
2318 007516 013737 016370 177776
2319 007524 000423

TST17: MOV #17,TSTNO ;SAVE THIS
MOV #TST18,NEXT ;GO TO THIS TEST WHEN THRU
TSTB JMRBY ;IN MAINT EXTERNAL?
BPL 3\$;IF ANSWER NO JUMP AROUND TEST
BIS #MRESET,DXCSR ;MASTER RESET
MOV #4\$,DURIV ;SET UP TRAPCATCHER
MOV DUPRT,DURIS
MOV LESS1,PS ;ALLOW INTERRUPTS
BR 1\$;JUMP AROUND INTERRUPT SVC ROUTINE

2320
2321 007526 012737 000340 177776
2322 007534 005777 007262
2323 007540 100401
2324 007542 104000
2325 007544 042777 000040 007250
2326 007552 012716 007642
2327 007556 013777 017050 007262
2328 007564 012777 000000 007256
2329 007572 000002

;THE FOLLOWING IS THE INTERRUPT SVC ROUTINE
4\$: MOV #LEVEL7,PS ;DON'T ALLOW ANYMORE INTERRUPTS
TST DXCSR ;DSC=1?
BMI .+4
HLT ;FALSE INTERRUPT
BIC #DSINTE,DXCSR ;CLEAR INTERRUPT ENABLE
MOV #2\$,SP ;SET UP RETURN LOCATION
MOV DURIS,DURIV ;RESTORE TRAPCATCHER
MOV #0,DURIS
RTI

2330
2331 007574 052777 000040 007220
2332 007602 052777 000002 007212
2333 007610 005000
2334 007612 005200
2335 007614 001376
2336 007616 013777 017050 007222
2337 007624 012777 000000 007216
2338

1\$: BIS #DSINTE,DXCSR ;SET INTERRUPT ENABLE
BIS #DTR,DXCSR ;TRY TO CAUSE INTERRUPT
CLR RO
INC RO ;WAIT FOR INTERRUPT
BNE .-2
MOV DURIS,DURIV ;RESTORE TRAPCATCHER
MOV #0,DURIS

2339 007632 042777 000040 007162
2340 007640 104000
2341 007642 012737 000340 177776
2342 007650 104400
2343
2344
2345
2346
2347

BIC #DSINTE,DXCSR ;CLEAR INTERRUPT ENABLE
HLT ;INTERRUPT FAILED TO OCCUR
2\$: MOV #LEVEL7,PS
3\$: SCOPE

2348 007652 012737 000022 001122
2349 007660 012737 010316 001112
2350 007666 105737 001177

;: THIS TEST VERIFYS THAT TWO INTERRUPTS THAT TRAP TO
;: THE SAME VECTOR ARE BOTH EXECUTED
;: INTERRUPT VECTOR: DURIV
;: THIS TEST ONLY WORKS IN MAINT EXTERNAL MODE
TST18: MOV #18,TSTNO ;SAVE THIS
MOV #TST19,NEXT ;GO TO THIS TEST WHEN THRU
TSTB JMRBY ;IN MAINT. EXTERNAL?

```

2351 007672 100402 BMI .+6 ;IF ANSWER WAS YES DO THIS TEST
2352 007674 000137 010314 JMP 1$ ;IF ANSWER WAS NO JUMP AROUND TEST
2353 007700 052777 000400 007130 BIS #MRESET,@TXCSR ;MASTER RESET
2354 007706 012777 020000 007116 MOV #SYNEXT,@PARCSR ;SET THE MODE
2355 007714 052777 000400 007114 BIS #MRESET,@TXCSR ;MASTER RESET
2356
2357 ;SET MAINT DATA,CLK,BREAK,&MAINTENANCE MODE
2358 007722 012777 064001 007106 MOV #MTDATA!CLK!MINT!BREAK,@TXCSR
2359
2360 ;SET MODE ,# OF BITS,PARITY SENSE,&LOAD SYNC REG
2361 007730 012777 026026 007074 MOV #SYNEXT!EIGHT!NOPAR!26,@PARCSR
2362 007736 052777 000020 007056 BIS #SYNSCH,@RXCSR ;SET SEARCH SYNC
2363 ;POKE CLK TO GET LOGIC INTO SYNCHRONIZATION
2364 007744 042777 020000 007064 BIC #CLK,@TXCSR ;POKE CLK DOWN
2365 007752 052777 020000 007056 BIS #CLK,@TXCSR ;POKE CLK UP
2366 007760 012777 010004 007060 MOV #25,@DURIV ;SET UP TRAPCATCHER
2367 007766 013777 016356 007054 MOV DUPRT,@DURIS
2368 007774 013737 016370 177776 MOV LESS1,PS ;ALLOW INTERRUPT
2369 010002 000457 BR 3$ ;JUMP AROUND SVC ROUTINE
2370
2371 ;THE FOLLOWING IS THE 1ST INTERRUPT SVC ROUTINE
2372 010004 012737 000340 177776 2$: MOV #LEVEL7,PS ;DON'T ALLOW ANY MORE INTERRUPTS
2373 010012 105777 007004 TSTB @RXCSR ;RXDONE = 1 ?
2374 010016 100401 BMI .+4
2375 010020 104000 HLT ;FALSE INTERRUPT
2376 010022 012716 010306 MOV #5$, (SP) ;SET UP RETURN LOCATION
2377 010026 012777 010110 007012 MOV #4$,@DURIV ;SET UP TRAPCATCHER FOR SECOND
2378 ;INTERRUPT
2379 010034 052777 000002 006760 BIS #DTR,@RXCSR ;TRY TO CAUSE SECOND INTERRUPT
2380 010042 017701 006760 MOV @RXDBUF,R1 ;JUST READ RXDBUF TO CLR RXDONE
2381 ;TO ALLOW SECOND INTERRUPT
2382 010046 013737 016370 177776 MOV LESS1,PS ;ALLOW INTERRUPT
2383 010054 005000 CLR R0
2384 010056 005200 INC R0 ;WAIT FOR INTERRUPT
2385 010060 001376 BNE .-2
2386 010062 042777 000140 006732 BIC #RINTEN!DSINTE,@RXCSR ;CLR INTR ENABLES
2387 010070 104000 HLT ;2ND INTERRUPT FAILED TO OCCUR
2388
2389 010072 013777 017050 006746 6$: MOV @DURIS,@DURIV ;RESTORE TRAPCATCHER
2390 010100 012777 000000 006742 MOV #0,@DURIS
2391 010106 000002 RTI
2392
2393 ;THE FOLLOWING IS THE 2ND INTERRUPT SVC ROUTINE
2394 010110 012737 000340 177776 4$: MOV #LEVEL7,PS ;DON'T ALLOW ANYMORE INTERRUPTS
2395 010116 005777 006700 TST @RXCSR ;DSC = 1 ?
2396 010122 100401 BMI .+4
2397 010124 104000 HLT ;FALSE INTERRUPT
2398 010126 042777 000140 006666 BIC #RINTEN!DSINTE,@RXCSR ;CLR BOTH INTR ENABLES
2399 010134 012716 010072 MOV #6$, (SP) ;SET UP RETURN LOCATION
2400 010140 000002 RTI
2401
2402 010142 052777 000140 006652 3$: BIS #RINTEN!DSINTE,@RXCSR ;SET INTERRUPT ENABLES
2403 010150 012737 000010 001134 MOV #8,SHIFT ;# OF SHIFTS
2404 010156 012737 000025 001140 MOV #25,TEMP1
2405 ;THE FOLLOWING POKES THE MAINT DATA BASED UPON THE
2406 ;INFORMATION CONTAINED IN TEMP1 AND IT IS

```

```

2407 ;SHIFTED IN BY THE CONTENTS OF SHIFT
2408 010164 042777 040000 006644 8$: BIC #MTDATA,@TXCSR
2409 010172 000241 CLC
2410 010174 006037 001140 ROR TEMP1 ;FORCE CARRY
2411 010200 103003 BCC 7$
2412 010202 052777 040000 006626 BIS #MTDATA,@TXCSR
2413 010210 042777 020000 006620 7$: BIC #CLK,@TXCSR
2414 010216 052777 020000 006612 BIS #CLK,@TXCSR
2415 010224 005337 001134 DEC SHIFT
2416 010230 001355 BNE 8$
2417 ;1ST INTERRUPT SHOULD NOW OCCUR
2418 010232 005000 CLR RO
2419 010234 005200 INC RO ;WAIT FOR INTERRUPT
2420 010236 001376 BNE -2 ;
2421 010240 013777 017050 006600 MOV DURIS,@DURIV ;RESTORE TRAPCATCHER
2422 010246 012777 000000 006574 MOV #0,@DURIS ;
2423 010254 013703 017026 MOV RXDBUF,R3 ;FOR ERROR MESSAGE
2424 010260 012700 000025 MOV #25,RO ;EXPECTED
2425 010264 017701 006536 MOV @RXDBUF,R1 ;
2426 010270 042777 000140 006524 BIC #RINTEN!DSINTE,@RXCSR ;CLR INTERRUPT ENABLES
2427 010276 020001 CMP RO,R1 ;
2428 010300 001401 BEQ +4 ;
2429 010302 104002 HLT 2 ;CHARACTERS SHOULD COMPARE
2430 010304 104000 HLT ;INTERRUPT FAILED TO OCCUR
2431
2432 010306 012737 000340 177776 5$: MOV #LEVEL7,PS ;DON'T ALLOW ANY MORE INTERRUPTS
2433 010314 104400 1$: SCOPE ;
2434
2435 ;;THIS TEST VERIFYS THAT DMA CAUSES AN INTERRUPT
2436 ;;MODE: SYNC EXTERNAL
2437 ;;INTERRUPT VECTOR: DUTIV
2438
2439 010316 012737 000023 001122 TST19: MOV #19,TSTNO ;SAVE THIS
2440 010324 012737 010612 001112 MOV #TST20,NEXT ;GO TO THIS TEST WHEN THRU
2441
2442 010332 052777 000400 006476 BIS #MRESET,@TXCSR ;MASTER RESET
2443 010340 012777 020000 006464 MOV #SYNEXT,@PARCSR ;SET THE MODE
2444 010346 052777 000400 006462 BIS #MRESET,@TXCSR ;MASTER RESET
2445
2446 ;SET MAINTENANCE MODE & SEND
2447 ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
2448 010354 012777 004020 006454 MOV #MINT!SEND,@TXCSR
2449
2450 ;SET MODE # OF BITS,PARITY SENSE & LOAD SYNC REG
2451 010362 012777 026026 006442 MOV #SYNEXT!EIGHT!NOPAR!26,@PARCSR
2452 010370 112777 000025 006444 MOV# #25,@TXDBUF ;LOAD CHARACTER
2453 010376 012737 000010 001134 MOV #8,SHIFT
2454 ;POKE CLK TO GET INTO SYNCHRONIZATION
2455 010404 052777 020000 006424 BIS #CLK,@TXCSR ;POKE CLK UP
2456 010412 042777 020000 006416 BIC #CLK,@TXCSR ;POKE CLK DOWN
2457
2458 1$:
2459 010420 052777 020000 006410 BIS #CLK,@TXCSR ;POKE CLK UP
2460 010426 042777 020000 006402 BIC #CLK,@TXCSR ;POKE CLK DOWN
2461 010434 005337 001134 DEC SHIFT ;LAST SHIFT?
2462 010440 001367 BNE 1$

```

```

2463 010442 012777 010512 006402      MOV     #2$, @DUTIV      ;SET UP TRAPCATCHER
2464 010450 013777 016366 006376      MOV     DUPRT, @DUTIS   ;
2465 010456 013737 016370 177776      MOV     LESS1, PS       ;ALLOW INTERRUPTS
2466 010464 052777 000040 006344      BIS     #DNAINTE, @TXCSR;ENABLE INTERRUPT
2467      ;NOW POKE CLK TO GET DNA
2468 010472 052777 020000 006336      BIS     #CLK, @TXCSR    ;POKE CLK
2469 010500 005000      CLR     RO              ;
2470 010502 005200      INC     RO              ;WAIT FOR INTERRUPT
2471 010504 001376      BNE     .-2
2472 010506 104000      HLT     ;INTERRUPT FAILED TO OCCUR
2473 010510 000423      BR     3$              ;JUMP AROUND SVC ROUTINE
2474      ;THE FOLLOWING IS THE INTERRUPT SERVICE ROUTINE
2475 010512 012737 000340 177776 2$: MOV     #LEVEL7, PS     ;DON'T ALLOW ANYMORE INTERRUPTS
2476 010520 005777 006312      TST     @TXCSR         ;DNA?
2477 010524 100401      BMI     .+4
2478 010526 104000      HLT     ;FALSE INTERRUPT
2479 010530 042777 000040 006300      BIC     #DNAINTE, @TXCSR;CLR INTR ENABLE
2480 010536 012716 010602      MOV     #4$, (SP)      ;SET UP RETURN LOCATION
2481 010542 013777 017054 006302      MOV     DUTIS, @DUTIV  ;RESTORE TRAPCATCHER
2482 010550 012777 000000 006276      MOV     #0, @DUTIS    ;
2483 010556 000002      RTI
2484
2485 010560 013777 017054 006264 3$: MOV     DUTIS, @DUTIV  ;RESTORE TRAPCATCHER
2486 010566 012777 000000 006260      MOV     #0, @DUTIS    ;
2487
2488 010574 042777 000040 006234      BIC     #DNAINTE, @TXCSR;CLR INTERRUPT ENABLE
2489 010602 012737 000340 177776 4$: MOV     #LEVEL7, PS     ;RESTORE NO INTERRUPT STATUS
2490 010610 104400      SCOPE
2491      ;: THIS TEST VERIFYS THAT TXDONE CAUSES ONLY ONE INTERRUPT
2492      ;: PROVIDING THAT TXCSR IS NOT READ
2493      ;: AND TXDBUF IS NOT LOADED (WRITTEN)
2494      ;: THIS TEST CHECKS THE ONCE ONLY FLIP/FLOP (V2)
2495      ;: OF THE INTERRUPT CONTROL LOGIC
2496      ;: INTERRUPT VECTOR: DUTIV
2497      ;: NOTE: TXDONE = 1 AFTER A MASTER RESET
2498
2499 010612 012737 000024 001122 1$T20: MOV     #20, TSTNO   ;SAVE THIS
2500 010620 012737 011006 001112      MOV     #1$T21, NEXT   ;GO TO THIS TEST WHEN THRU
2501 010626 052777 000400 006202      BIS     #MRESET, @TXCSR;MASTER RESET
2502 010634 012777 010676 006210      MOV     #1$, @DUTIV    ;SET UP TRAPCATCHER
2503 010642 013777 016366 006204      MOV     DUPRT, @DUTIS  ;
2504 010650 013737 016370 177776      MOV     LESS1, PS      ;ALLOW INTERRUPTS
2505 010656 052777 000100 006152      BIS     #TXINTE, @TXCSR;ENABLE INTR ENABLE
2506 010664 005000      CLR     RO              ;
2507 010666 005200      INC     RO              ;
2508 010670 001376      BNE     .-2
2509 010672 104000      HLT     ;INTERRUPT FAILED TO OCCUR
2510 010674 000427      BR     4$
2511      ;THE FOLLOWING IS THE INTR SVC ROUTINE
2512 010676 012737 000340 177776 1$: MOV     #LEVEL7, PS     ;DON'T ALLOW ANYMORE INTR
2513 010704 012716 010746      MOV     #3$, (SP)      ;SET UP RETURN LOCATION
2514 010710 012777 010720 006134      MOV     #2$, @DUTIV    ;SET UP TRAPCATCHER TO
2515      ;PROVE THAT THE INTERRUPT DOES NOT OCCUR
2516      ;TWICE (AFTER RTI 'ING FROM THIS
2517      ;SVC ROUTINE
2518 010716 000002      RTI

```

```

2519      :THE FOLLOWING INTERRUPT SVC ROUTINE WILL CATCH THE SECOND INTR
2520 010720 012737 000340 177776 25:  MOV    #LEVEL7,PS    ;DON'T ALLOW INTER
2521 010726 012716 010754          MOV    #4$, (SP)      ;SET UP RETURN LOCATION
2522 010732 105777 006100          TSTB   @TXCSR    ;TXD.C.E = 1?
2523 010736 100401          BMI    +4
2524 010740 104000          HLT    ;TXDONE SHOULD BE SET
2525 010742 104000          HLT    ;THE INTERRUPT WAS TAKEN TWICE.....
2526          ;CHECK OUT THE V2 FLIP/FLOP LOGIC
2527          ;IN THE INTERRUPT CONTROL LOGIC
2528 010744 000002          RTI
2529 010746 005000          3$:  CLR    RO    ;ALLOW TIME TO CATCH SECOND
2530 010750 005200          INC    RO    ;IF IT WERE TO OCCUR
2531 010752 001376          BNE    -2
2532 010754 013777 017054 006070 4$:  MOV    @DUTIS,@DUTIV ;RESTORE TRAPCATCHER
2533 010762 012777 000000 006064          MOV    #0,@DUTIS
2534 010770 042777 000100 006040          BIC    @TXINTE,@TXCSR ;CLR INTERRUPT ENABLE
2535 010776 012737 000340 177776          MOV    #LEVEL7,PS    ;RESTORE NO INTERRUPT STATUS
2536 011004 104400          SCOPE
2537          ;; THIS TEST VERIFYS CTP MODE (IE SYSTST MODE)
2538          ;; IT BASICALLY CHECKS THE EXISTANCE OF
2539          ;; THE FREE RUNNING OSCILLATOR
2540          ;; MODE: SYNINT
2541          ;; LENGTH: EIGHT
2542          ;; THIS TEST USES BOTH THE RECEIVER & TRANSMITTER LOGIC
2543          ;;
2544 011006 012737 000025 001122 1ST21: MOV    #21,TSTNO    ;SAVE THIS
2545 011014 012737 011650 001112          MOV    #TST22,NEXT    ;GO TO THIS TEST WHEN THRU
2546 011022 052777 000400 006006          BIS    #MRESET,@TXCSR ;MASTER RESET
2547 011030 012777 030000 005774          MOV    #SYNINT,@PARCSR ;SET THE MODE
2548 011036 052777 000400 005772          BIS    #MRESET,@TXCSR ;MASTER RESET
2549          ;;
2550          ;SET MAINTENANCE MODE & SEND
2551          ;NOTE:BIT WINDOW&CLK ARE CLEARED (MTDATA=0)
2552 011044 012777 014020 005764          MOV    #SYSTST!SEND,@TXCSR
2553          ;;
2554          ;SET MODE # OF BITS,PARITY SENSE, & LOAD SYNC REG
2555 011052 012777 036026 005752          MOV    #SYNINT!EIGHT!NOPAR!26,@PARCSR
2556 011060 052777 000420 005734          BIS    #SYNSCH!STPSYN,@RXCSR ;SET SEARCH SYNC &
2557          ;STRIP SYNC SO THAT RXDONE ASSERTS
2558          ;WHEN CHAR "25" ARRIVES AND NOT BEFORE...
2559          ;... THEREFORE, SET STRIP SYNC
2560          ;... WAIT FOR SYNSCH TO BE
2561          ;CLOCKED IN BY SYSTST CLK
2562 011066 005037 001150          CLR    TEMPS
2563 011072 005002          CLR    R2
2564 011074 005202          INC    R2    ;WAIT
2565 011076 001376          BNE    -2
2566 011100 005237 001150          INC    TEMPS
2567 011104 022.37 000003 001150          CMP    #3,TEMPS
2568 011112 002367          BGE    -20    ;GO BACK TO CLR R2 AND WAIT SOME MORE
2569 011114 012777 011334 005724          MOV    #25,@DURIV    ;SET UP TRAPCATCHER
2570 011122 013777 016366 005720          MOV    DUPRT,@DURIS
2571 011130 012777 011430 005714          MOV    #3,@DUTIV
2572 011136 013777 016366 005710          MOV    DUPRT,@DUTIS
2573 011144 013737 016370 177776          MOV    LESS1,PS    ;ALLOW INTERRUPTS
2574 011152 013703 017026          MOV    RXDBUF,R3    ;SET UP FOR ERROR MSG

```

```

2575 011156 012700 000025      MOV      #25,R0 ;EXPECTED CHAR
2576 011162 012737 000002 001136  MOV      #2,COUNT ;# OF SYNC CHARS TO GET INTO
2577                                     ;SYNCRONIZATION
2578 011170 105737 001172      TSTB     SYNCNO ;TEST TO SEE HOW MANY SYNC CHARS NEEDED
2579 011174 100402                BMI      9$
2580 011176 005337 001136      DEC      COUNT ;MAKE IT ONE LESS
2581 011202 052777 000100 005612 9$:      BIS      #RINTEN,#RXCSR ;SET INTERRUPT ENABLES
2582 011210 052777 000100 005620      BIS      #TXINTE,#TXCSR ;
2583 011216 000137 011234      JMP      8$ ;THE FIRST XMIT INTERRUPT SHOULD COME
2584                                     ;FROM TXDONE = 1 AFTER A MASTER RESET
2585 011222 112777 000026 005612 1$:      MOVB    #26,#TXDBUF ;LOAD SYNC CHAR
2586 011230 005037 001150      CLR      TEMPS
2587 011234 005002                CLR      R2 ;WAIT FOR INTERRUPT
2588 011236 005202                INC      R2
2589 011240 001376                BNE     .-2 ;
2590 011242 005237 001150      INC      TEMPS
2591 011246 022737 000003 001150      CMP      #3,TEMPS
2592 011254 002367                BGE     8$
2593 011256 012737 000340 177776      MOV      #LEVEL7,PS ;PREVENT INTERRUPTS
2594 011264 042777 000100 005544      BIC      #TXINTE,#TXCSR ;CLR INTR ENABLES
2595 011272 042777 000100 005522      BIC      #RINTEN,#RXCSR ;
2596 011300 013777 017050 005540      MOV      DURIS,#DURIV ;RESTORE TRAPCATCHER
2597 011306 012777 000000 005534      MOV      #0,#DURIS ;
2598 011314 013777 017054 005530      MOV      DUTIS,#DUTIV ;
2599 011322 012777 000000 005524      MOV      #0,#DUTIS ;
2600 011330 104000                HLT     ;TXDONE INTERRUPT FAILED TO OCCUR
2601                                     ;WATCH OUT HERE::: THIS FAILURE MAY
2602                                     ;ALSO BE CAUSED BY TRANSMIT DATA NOT
2603                                     ;BEING CLOCKED OUT. I.E. TXDONE
2604                                     ;NOT RE-ASCERTING SO THAT THE 2ND
2605                                     ;SYNC CHARACTER CAN BE LOADED
2606
2607 011332 000542                BR      7$ ;GET OUT OF THE TEST
2608
2609                                     ;THE FOLLOWING IS THE RECEIVER INTERRUPT SVC ROUTINE
2610 011334 012737 000340 177776 2$:      MOV      #LEVEL7,PS ;PREVENT INTERRUPTS
2611 011342 017704 005454                MOV      #RXCSR,R4 ;SAVE
2612 011346 017701 005454                MOV      #RXDBUF,R1 ;ACTUAL
2613 011352 013777 017050 005466      MOV      DURIS,#DURIV ;RESTORE TRAPCATCHER
2614 011360 012777 000000 005462      MOV      #0,#DURIS ;
2615 011366 013777 017054 005456      MOV      DUTIS,#DUTIV ;
2616 011374 012777 000000 005452      MOV      #0,#DUTIS ;
2617 011402 012716 011564                MOV      #4,(SP) ;SET UP RETURN LOCATION
2618 011406 042777 000100 005406      BIC      #RINTEN,#RXCSR ;CLR INTERRUPT ENABLES
2619 011414 042777 000100 005414      BIC      #TXINTE,#TXCSR ;
2620 011422 013705 001136      MOV      COUNT,R5 ;SAVE COUNT
2621 011426 000002                RTI
2622                                     ;END OF RECEIVER INTERRUPT SVC ROUTINE
2623                                     ;...THE FOLLOWING IS THE XMITTER INTERRUPT SVC ROUTINE
2624 011430 005337 001136 3$:      DEC      COUNT
2625 011434 100403                BMI      5$
2626 011436 012716 011222      MOV      #1,(SP) ;SET UP RETURN LOCATION
2627                                     ;(LOAD SYNC CHARACTER AGAIN)
2628 011442 000002                RTI
2629 011444 012716 011452 5$:      MOV      #6,(SP) ;SET UP RETURN LOCATION
2630 011450 000002                RTI

```

```

2631          :END OF XMITTER INTERRUPT SVC ROUTINE
2632 011452 112777 000025 005362 65:  MOV  #25, TXDBUF ;LOAD CHARACTER
2633 011460 042777 000100 005350  BIC  #TXINTE, TXCSR ;CLR INTR ENABLE
2634 011466 005037 001150          CLR  TEMPS
2635 011472 005002          10$: CLR  R2 ;WAIT FOR INTERRUPT(RECEIVER)
2636 011474 005202          INC  R2
2637 011476 001376          SNE  #-2 ;
2638 011500 005237 001150          INC  TEMPS
2639 011504 022737 000003 001150  CMP  #3, TEMPS
2640 011512 002367          BGE  10$
2641 011514 012737 000340 177776  MOV  #LEVEL7, PS ;PREVENT INTERRUPTS
2642 011522 042777 000100 005272  BIC  #RINTEN, RXCSR ;CLR INTR ENABLE
2643 011530 013777 017050 005310  MOV  #DURIS, DOURIV ;RESTORE TRAPCATCHER
2644 011536 012777 000000 005304  MOV  #0, DOURIS
2645 011544 013777 017054 005300  MOV  #DUTIS, DOUTIV
2646 011552 012777 000000 005274  MOV  #0, DOUTIS
2647 011560 104000          HLT  ;RECEIVER INTR FAILED TO OCCUR
2648 011562 000426          BR   7$ ;GET OUT OF TEST
2649 011564 020001          4$: CMP  R0, R1
2650 011566 001401          BEQ  .+4
2651 011570 104002          HLT  2 ;CHARACTERS DID NOT MATCH
2652 011572 013703 017022          MOV  RXCSR, R3 ;SET UP FOR ERROR MSG
2653 011576 012700 000200          MOV  #200, R0 ;EXPECTED RXDONE
2654 011602 010401          MOV  R4, R1 ;ACTUAL
2655 011604 042701 177577          BIC  #177577, R1 ;SAVE ONLY RXDONE
2656 011610 020001          CMP  R0, R1
2657 011612 001401          BEQ  .+4
2658 011614 104001          HLT  1 ;FALSE INTERRUPT
2659 011616 020527 177777          CMP  R5, #-1 ;WAS COUNT ==-1 WHEN RECEIVER
                ;INTERRUPTED ?
2660
2661          BEQ  .+4
2662 011624 104000          HLT  ;IF R5 IS GREATER THAN -1.....
2663          ;THEN EITHER THE # OF SYNC STRAP IS WRONG
2664          ;OR RXDONE IS OCCURING TOO SOON
2665 011626 023727 001136 177777          CMP  COUNT, #-1
2666 011634 001401          BEQ  .+4
2667 011636 104000          HLT  ;IF THIS TEST FAILS, BUT THE ABOVE TEST
2668          ;DOESN'T.....IT MAY BE THAT CLEARING
2669          ;TXINTE IN THE RECEIVER SVC ROUTINE
2670          ;IS NOT STOPPING TXDONE INTERRUPTS
2671 011640 012737 000340 177776 7$: MOV  #LEVEL7, PS ;INHIBIT INTERRUPTS
2672 011646 104400          SCOPE
2673          ;; THIS TEST VERIFYS MATCH DETECT & DATA RDY
2674          ;; FLAGS FOR EVERY POSSIBLE MATCH CHARACTER
2675          ;; BY OBSERVING RECACT BIT
2676          ;; IT WILL TAKE TWO SYNC # CHARACTERS TO GET RECACT BIT
2677          ;; #: DEPENDENT ON MONITOR .....
2678          ;; IF ONE SYNC STRAP IS SELECTED, IT WILL
2679          ;; ONLY TAKE ONE SYNC CHARACTER BEFORE RECACT TO
2680          ;; ASSERT
2681          ;; MODE: SYNC INTERNAL
2682          ;; LENGTH: FIVE
2683          ;; SYNC CHARACTER FOR MATCH: B/C
2684          ;; THIS TEST USES THE TRANSMITTER AND RECEIVER CHIPS
2685
2686 011650 012737 000026 001122 TST22: MOV  #22, TSTNO ;SAVE THIS

```

```

2687 011656 012737 012176 001112      MOV      #TST23,NEXT      ;GO TO THIS TEST WHEN THRU
2688 011664 012737 012000 001114      MOV      #55,LOCK       ;SET UP FOR SCOPE LOOP
2689 011672 052777 000400 005136      BIS      #MRESET,@TXCSR ;MASTER RESET
2690 011700 013703 017026      MOV      @RXDBUF,R3     ;SET UP FOR ERROR MESSAGE
2691                                     ;SET SYNC INTERNAL,FIVE,NO PARITY,0 SYNC REGISTER
2692 011704 012704 030000      MOV      #SYNINT!FIVE!NOPAR,R4 ;CREATE PARAMETERS
2693 011710 012777 004020 005120 65:    MOV      #MINT!SEND,@TXCSR ;SET SEND & MAINT INTER
2694 011716 010477 005110      MOV      R4,@PARCSR    ;LOAD CSR
2695 011722 052777 000020 005072      BIS      #SYNSCH,@RXCSR ;SET SYNC SEARCH
2696                                     ;POKE CLK TO GET INTO SYNCHRONIZATION
2697                                     ;BOTH THE LOGIC & RECEIVER
2698 011730 052777 020000 005100      BIS      #CLK,@TXCSR    ;POKE CLK UP
2699 011736 042777 020000 005072      BIC      #CLK,@TXCSR    ;POKE CLK DOWN
2700 011744 110477 005072      MOV      R4,@XDBUF     ;LOAD DATA CHARACTER
2701                                     ;POKE CLK TO GET TRANSMITTER & RECEIVER INTO SYNCHRONIZATION
2702 011750 052777 020000 005060      BIS      #CLK,@TXCSR    ;POKE CLK UP
2703 011756 042777 020000 005052      BIC      #CLK,@TXCSR    ;POKE CLK DOWN
2704 011764 032777 004000 005030      BIT      #REACT,@RXCSR ;REACT ?
2705 011772 001401      BEQ      .+4
2706 011774 104000      HLT
2707 011776 000404      BR      4$
2708 012000 010477 005026 55:    MOV      R4,@PARCSR    ;LOAD PARCSR WITH PARAMETERS
2709 012004 110477 005032      MOV      R4,@XDBUF     ;LOAD SYNC CHAR
2710 012010 012737 000002 001136 4$:    MOV      #2,COUNT     ;# OF SYNC CHARS
2711 012016 005777 005014 25:    TST      @TXCSR       ;DNA ?
2712 012022 100001      BPL      .+4          ;BR IF NOT SET
2713 012024 104000      HLT
2714                                     ;DNA SHOULD NOT BE SET OR...
2715                                     ;IT SHOULD BE CLEARED FROM PREVIOUS READ
2716 012026 012737 000005 001134      MOV      #5,SHIFT     ;# OF SHIFTS
2717 012034 052777 020000 004774 1$:    BIS      #CLK,@TXCSR    ;POKE CLK UP
2718 012042 042777 020000 004766      BIC      #CLK,@TXCSR    ;POKE CLK DOWN
2719 012050 005337 001134      DEC      SHIFT        ;# OF SHIFTS
2720 012054 001367      IS
2721 012056 005337 001136      DEC      COUNT        ;# OF SYNC CHARS
2722 012062 001403      BEQ      3$
2723                                     ;TEST SYNCNO TO SEE HOW MANY SYNC CHARACTERS NEEDED
2724 012064 105737 001172      TSTB    SYNCNO
2725 012070 100752      BMI      2$           ;TWO SYNC CHARACTERS..
2726 012072 032777 004000 004722 3$:    BIT      #REACT,@RXCSR ;REACT ?
2727 012100 001001      BNE      .+4
2728 012102 104000      HLT
2729                                     ;REACT FAILED TO SET POSSIBLE
2730                                     ;THAT THE RECEIVER FAILED TO MATCH
2731                                     ;THE SYNC CHARACTER
2731 012104 017701 004716      MOV      @RXDBUF,R1   ;SAVE ACTUAL
2732 012110 010400      MOV      R4,R0        ;SAVE EXPECTED
2733 012112 042700 177400      BIC      #177400,R0   ;CLR UPPER BYTE
2734 012116 020001      CMP      R0,R1        ;DO THEY COMPARE ?
2735 012120 001401      BEQ      .+4
2736 012122 104002      HLT      2
2737                                     ;IF REACT FAILED ALONG WITH THIS
2738                                     ;...IT PROBABLY IS A TRANSMITTER ERROR
2739                                     ;HOWEVER,...IF ONLY THIS FAILED IT
2740                                     ;PROBABLY IS A RECEIVER ERROR
2740 012124 104401      SCOPI
2741                                     ;POKE CLK TO SEE DNA...DNA COMES UP ON THE FIRST
2742                                     ;BIT OF THE NEXT CHARACTER IF NO CHARACTER IS LOADED INTO

```



```

2799
2800 012350 013702 001132
2801 012354 005302
2802 012356 001376
2803
2804 012360 042777 020000 004450
2805
2806 012366 013702 001132
2807 012372 005302
2808 012374 001376
2809
2810 012376 005337 001134
2811 012402 022737 000003 001134
2812 012410 001003
2813 012412 005204
2814 012414 110477 004422
2815 012420 005737 001134
2816 012424 001346
2817 012426 105777 004370
2818 012432 100401
2819 012434 104000
2820 012436 017701 004364
2821 012442 020001
2822 012444 001401
2823 012446 104002
2824
2825 012450 105704
2826 012452 001327
2827 012454 104400
2828
2829
2830
2831
2832
2833
2834
2835
2836 012456 012700 000062
2837 012462 000005
2838 012464 005300
2839 012466 001375
2840 012470 032737 000100 177570
2841 012476 001402
2842 012500 004737 000250
2843 012504 104402
2844 012506 015353
2845 012510 104410 012742
2846 012514 104402 015074
2847 012520 105737 001176
2848 012524 001511
2849 012526 005737 001212
2850 012532 001007
2851 012534 104402 015106
2852 012540 013700 001212
2853 012544 000000
2854

```

```

;WAIT FOR CABLE & DRIVER DELAYS
MOV HOLD,R2 ;WAIT THIS AMT
DEC R2 ;WAIT
BNE -2
;EXIT...
BIC #CLK,ATXCSR ;POKE CLK DOWN
;WAIT FOR CABLE & DRIVER DELAYS
MOV HOLD,R2 ;WAIT THIS AMT
DEC R2 ;WAIT
BNE -2
;EXIT...
DEC SHIFT ;# OF SHIFTS
CMP #3,SHIFT ;TIME TO LOAD NEXT CHAR ?
BNE 3$ ;NO ?
INC R4 ;GENERATE NEXT CHAR
MOVB R4,ATXDBUF ;LOAD NEXT CHARACTER
3$: TST SHIFT ;IS IT 0 ?
BNE 2$
TSTB @RXCSR ;RXDONE = 1 ?
BMI .+4
HLT ;RXDONE SHOULD BE SET
MOV @RXDBUF,R1 ;ACTUAL
CMP R0,R1 ;COMPARE EXP VS ACT
BEQ .+4
HLT 2 ;CHARACTERS SHOULD COMPARE
;CHECK OUT MODEM BYPASS JUMPER
TSTB R4 ;LAST CHARACTER ?
BNE 1$ ;NO
4$: SCOPE

;END OF PASS
;TYPE NAME OF TEST
;UPDATE PASS COUNT
;CHECK FOR EXIT TO ACT-11
;RESTART TEST
.EOP:
2$: MOV #50.,R0
RESET
DEC R0
BNE 2$
BIT #SW06,SWR
BEQ 1$
JSR PC,EOPHLT
1$: TYPE ;TYPE NAME OF TEST
MEPASS
CONVRT ,OUTCRY
TYPE ,DEVICE
TSTB MULTD ;ARE YOU RUNNING MULTIPLE DEVICES ?
BEQ CCC ;NO, JUMP AROUND
TST ACTREG ;ARE ANY DEVICES ACTIVE ?
BNE RUNIT ;YES
TYPE MCOV ;NO
MOV ACTREG,R0 ;DISPLAY ACTREG
HALT ;SELECT SOMETHING TO RUN @ ACTREG:
;SELECT SWITCHES & HIT CONTINUE (PUT SW00 =1)

```

```

2855 012546 00C137 001246 JMP .START :START OVER AGAIN.....YOU DESELECTED EVERY THING
2856 012552 062737 000010 001200 RUNIT: ADD #10,BASEADD ;NEXT BLOCK (ADDRESSES)
2857 012560 062737 000010 001206 ZERO: ADD #10,BASEIV ;NEXT BLOCK (VECTORS)
2858 012566 000241 CLC
2859 012570 006137 001214 ROL ROTADD ;UP DATE ROTATING POINTER
2860 012574 103410 BCS Z$ ;IS IT THE LAST DEVICE
2861 ;TO BE TESTED IN THIS PASS ?
2862 012576 033737 001214 001212 BIT ROTADD,ACTREG ;TEST THIS DEVICE FOR ACTIVE STATUS
2863 012604 001762 SEQ RUNIT ;IF NOT ACTIVE, TRY NEXT ADDRESS
2864 012606 004737 012646 JSR PC,REPLAY ;CALCULATE NEW PARAMETERS
2865 012612 000137 013012 JMP RESTRT ;YES IT WAS ACTIVE,TEST THIS DEVICE
2866 012616 012737 000001 001214 Z$: MOV #1,ROTADD ;OK!,NOW SET UP ROTATING
2867 ;POINTER FOR NEXT MULTIPLE PASS
2868 012624 013737 001202 001200 MOV KEEPADD,BASEADD ;RESTORE BASE ADDRESS
2869 012632 013737 001210 001206 MOV KEEPIV,BASEIV ;RESTORE BASE INTERRUPT VECTORS
2870 012640 004737 012646 JSR PC,REPLAY ;CALC NEW PARAMETERS
2871 012644 000441 BR CCC ;JUMP AROUND REPLAY
2872 012646 013737 001200 016524 REPLAY: MOV BASEADD,DUBASE ;SET UP FOR NEW ADDRESSES
2873 012654 004737 016372 JSR PC,DUADDR ;CREATE NEW ADDRESSES
2874 012660 013737 001206 017046 MOV BASEIV,DURIV ;CREATE DURIV
2875 012666 062737 000002 001206 ADD #2,BASEIV
2876 012674 013737 001206 017050 MOV BASEIV,DURIS ;CREATE DURIS
2877 012702 062737 000002 001206 ADD #2,BASEIV
2878 012710 013737 001206 017052 MOV BASEIV,DUTIV ;CREATE DUTIV
2879 012716 062737 000002 001206 ADD #2,BASEIV
2880 012724 013737 001206 017054 MOV BASEIV,DUTIS ;CREATE DUTIS
2881 012732 013737 017046 001206 MOV DURIV,BASEIV ;RESTORE
2882 012740 000207 RTS PC
2883
2884 012742 000001 OUTCRY: 1
2885 012744 006 002 .BYTE 6,2
2886 012746 017022 RXCSR
2887
2888 012750 CCC:
2889 012750 005037 001130 CLR LSTERR ;CLEAR LAST ERROR PC
2890 012754 005037 001220 CLR ERRFLG ;CLEAR ERROR FLAG
2891 012760 005237 001124 INC PASCNT ;UPDATE PASS COUNT
2892 012764 013737 001124 177570 MOV PASCNT,LIGHTS ;DISPLAY PASS COUNT
2893 012772 013701 000042 MOV #42,R1 ;CHECK FOR ACT-11 OR DDF
2894 012776 001405 BEQ RESTRT ;IF NOT, CONTINUE TESTING
2895 013000 000005 RESET
2896 013002 004711 LOGICAL: JSR PC,(R1)
2897 013004 000240 NOP
2898 013006 000240 NOP
2899 013010 000240 NOP
2900 013012 012737 000340 177776 RESTRT: MOV #340,PS ;PREVENT INTERRUPTS (PRIO: 7)
2901 013020 012737 002224 001110 MOV #TST1,RETURN
2902 013026 000137 002224 JMP TST1
2903
2904 ;SCOPE LOOP AND INTERPATIION HANDLER
2905
2906 013032 .SCOPE:
2907 ;**** START OF CODE FOR THE X OR TESTER ****
2908 013032 000424 BR 45 ;IF RUNNING ON THE X OR TESTER CHANGE
2909 THIS INSTRUCTION TO A "NOP"(NOP=240)
2910 013034 012746 000004 MOV #4,-(SP) ;SAVE CONTENTS OF ERROR VECTOR

```

```

2911 013040 012737 013060 000004      MOV      #15,0#4      ;SET FOR TIME OUT
2912 013046 005737 177060      TST      0#177060    ;TIME OUT ON X OR ?
2913 013052 012637 000004      MOV      (SP)+,0#4   ;RESTORE ERROR VECTOR
2914 013056 000404      BR       2$         ;GO TO NEXT TEST
2915 013060 022626      1$:      CMP      (SP)+,(SP)+ ;CLEAR THE STACK AFTER A TIMEOUT
2916 013062 012637 000004      MOV      (SP)+,0#4   ;RESTORE ERROR VECTOR
2917 013066 000403      BR       3$         ;LOOP ON PRESENT TEST
2918 013070 013737 001112 001110 2$:      MOV      NEXT,RETURN ;SET UP NEXT TEST IN RETURN
2919 013076 013716 001110 3$:      MOV      RETURN,(SP) ;SET UP STACK FOR RTI
2920 013102 000002      RTI
2921 013104      4$:      ;**** END OF CODE FOR THE X OR TESTER *****
2922 013104 032737 040000 177570      BIT      #SW14,SWR   ;LOOP ON CURRENT TEST ?
2923 013112 001407      TTST:   1$
2924 013114 000432      BR       3$
2925 013116 105777 165756      TSTB    @TKCSR ;TEST TTY FLAG
2926 013122 100027      BPL     3$
2927 013124 017700 165752      MOV      @TKDBR,R0  ;CLR DONE BIT
2928 013130 000412      BR       2$         ;IF A TTY KEY IS STRUCK GO TO NEXT TEST
2929 013132 032737 004000 177570 1$:      BIT      #SW11,SWR   ;INHIBIT ITERATIONS ?
2930 013140 001006      BNE     2$
2931 013142 005237 001120      INC     LPCNT
2932 013146 023737 001120 001116      CMP      LPCNT,ICOUNT ;CHECK FOR ITERATION CNT FINISH
2933 013154 101412      BLOS    3$
2934 013156 105027 001220      2$:      CLRB    ERRFLG
2935 013162 005037 001120      CLR     LPCNT
2936 013166 012737 000005 001116      MOV      #5,ICOUNT  ;SET UP ITERATION COUNT
2937 013174 013737 001112 001110      MOV      NEXT,RETURN ;SET UP NEXT TEST IN RETURN
2938 013202 013716 001110 3$:      MOV      RETURN,(SP) ;SET UP STACK FOR RTI
2939 013206 000002      RTI
2940 013210 001407      BRW:    1407        ;RESTORE "BEG 1$" INSTRUCTION
2941 013212 000432      BRX:    432         ;RESTORE "BR 3$" INSTRUCTION
2942
2943      ;CHECK FOR FREEZE ON CURRENT DATA
2944
2945 013214 032737 001000 177570 .SCOPI: BIT      #SW09,SWR
2946 013222 001402      BEQ     1$
2947 013224 013716 001114      MOV      LOCK,(SP)
2948 013230 000002      1$:      RTI
2949
2950      ;TELETYPE OUTPUT ROUTINE
2951
2952 013232 017605 000000 .TYPE:  MOV      2(SP),R5
2953 013236 062716 000002      ADD     #2,(SP)
2954 013242 105715      1$:      TSTB    (R5) ;LOOK FOR "0"
2955 013244 001406      BEQ     3$
2956 013246 105777 165632      2$:      TSTB    @TPCSR ;TEST DONE BIT
2957 013252 100375      BPL     2$
2958 013254 112577 165626      MOVB   (R5)+,@TPDBR ;TYPE CHAR
2959 013260 000770      BR      1$         ;DO IT AGAIN UNTIL "0" IS SEEN
2960 013262 000002      3$:      RTI
2961
2962      ;ASCII STRING INPUT ROUTINE
2963
2964 013264 017637 000000 013300 .INSTR: MOV      2(SP),MSG ;PICK UP MESSAGE
2965 013272 062716 000002      ADD     #2,(SP) ;JUMP AROUND MESSAGE FOR RTI
2966 013276 104402      .INST1: TYPE

```

2967 013300 000000
 2968 013302 012704 016150
 2969 013306 012703 000007
 2970 013312 105777 165562
 2971 013316 100375
 2972 013320 117714 165556
 2973 013324 142714 000200
 2974 013330 122427 000015
 2975 013334 001413
 2976 013336 105777 165542
 2977 013342 100375
 2978 013344 117777 165532 165534
 2979 013352 005303
 2980 013354 001356
 2981 013356 104402
 2982 013360 015257
 2983 013362 000745
 2984 013364 000002
 2985
 2986
 2987
 2988 013366 011605
 2989 013370 012537 013542
 2990 013374 012537 013544
 2991 013400 012537 013546
 2992 013404 112537 013550
 2993 013410 112537 013551
 2994 013414 010516
 2995 013416 005005
 2996 013420 012704 016150
 2997 013424 122714 000015
 2998 013430 001420
 2999 013432 121427 000060
 3000 013436 002415
 3001 013440 121427 000067
 3002 013444 003012
 3003 013446 142714 000060
 3004 013452 152405
 3005 013454 122714 000015
 3006 013460 001406
 3007 013462 006305
 3008 013464 006305
 3009 013466 006305
 3010 013470 000760
 3011 013472 104404
 3012 013474 000750
 3013
 3014
 3015
 3016 013476 020537 013544
 3017 013502 101373
 3018 013504 020537 013542
 3019 013510 103770
 3020 013512 133705 013550
 3021 013516 001365
 3022

```

.MSG: 0
MOV #INBUF,R4 ;GET STARTING LOC OF INBUF
MOV #7,R3 ;MAX # OF CHARS
1$: TST @TKCSR ;TTY FLAG
BPL 1$
MOV @TKDBR,(R4) ;TAKE CHAR
BICB #200,(R4) ;STRIP
CMPB (R4)+,#15 ;CHECK FOR CR
BEQ INSTR2
2$: TST @TPCSR ;TEST FLAG
BPL 2$
MOV @TKDBR,@TPDBR ;ECHO CHARACTER
DEC R3 ;DID YOU TYPE TOO MANY CHARS ?
BNE 1$
.INSTE: TYPE
MQM ;?
BR .INST1 ;RETRY
INSTR2: RTI

;CONVERT ASCII STRING TO OCTAL
.PARAM: MOV (SP),R5 ;PUT CONTENTS OF SP INTO R5
MOV (R5)+,LOLIM ;PUT LOW LIMIT INTO LOLIM
MOV (R5)+,HILIM ;PUT HIGH LIMIT INTO HILIM
MOV (R5)+,DEVADR ;PUT STORE LOC INTO DEVADR
MOVB (R5)+,LOBITS ;PUT MASK INTO LOBITS
MOVB (R5)+,ADRCNT ;PUT COUNT INTO ADRCNT
MOV R5,(SP) ;RESTORE RETURN ADDR ON STACK FOR RTI
PARAM1: CLR R5
MOV #INBUF,R4
CMPB #15,(R4) ;CR ?
BEQ PARERR ;YOU TYPED CR TOO SOON !
1$: CMPB (R4),#60 ;LOW LIMIT ASCII 0
BLT PARERR
CMPB (R4),#67 ;HIGH LIM?: ASCII 7
BGT PARERR
BICB #60,(R4) ;CONVERT TO OCTAL
BISB (R4)+,R5 ;STORE AWAY ITS AN OK CHAR
CMPB #15,(R4) ;CR ?
BEQ LIMITS ;NOW CHECK FOR HIGH & LOW LIMIT CONDS
ASL R5 ;ALLOCATE ROOM FOR NEXT CHAR
ASL R5
ASL R5
BR 1$
PARERR: INSTR ;RETRY
BR PARAM1

;TEST TO SEE IF NUMBER IS WITHIN LIMITS
LIMITS: CMP R5,HILIM
BHI PARERR ;THE # IS TOO HIGH
CMP R5,LOLIM
BLO PARERR ;THE # IS TOO LOW
BITB LOBITS,R5 ;TEST BY MASKINGTHE #
BNE PARERR

```

```

3023                                     ;STORE NUMBER AT SPECIFIED ADDRESS
3024
3025 013520 013704 013546
3026 013524 010524
3027 013526 062705 000002
3028 013532 105337 013551
3029 013536 001372
3030 013540 000002
3031 013542 000000
3032 013544 000000
3033 013546 000000
3034 013550 000000
3035                                     013551
3036
3037                                     ;SAVE PC OF TEST THAT FAILED AND RC-R5
3038
3039 013552 016637 000004 001170 .SAV05: MOV 4(SP),SAVPC
3040
3041                                     ;SAVE RO-R5
3042
3043 013560 010537 001164 SV05: MOV R5,SAVR5
3044 013564 010437 001162 MOV R4,SAVR4
3045 013570 010337 001160 MOV R3,SAVR3
3046 013574 010237 001156 MOV R2,SAVR2
3047 013600 010137 001154 MOV R1,SAVR1
3048 013604 010037 001152 MOV R0,SAVR0
3049 013610 000002 RTI
3050
3051                                     ;RESTORE RO-R5
3052
3053 013612 013700 001152 .RES05: MOV SAVR0,R0
3054 013616 013701 001154 MOV SAVR1,R1
3055 013622 013702 001156 MOV SAVR2,R2
3056 013626 013703 001160 MOV SAVR3,R3
3057 013632 013704 001162 MOV SAVR4,R4
3058 013636 013705 001164 MOV SAVR5,R5
3059 013642 000002 RTI
3060
3061                                     ;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER
3062
3063 013644 104402 .CONVR: TYPE
3064 013646 015263 MCRLF :CR LF
3065 013650 017601 000000 MOV 2(SP),R1 :PICK UP DATA POINTER
3066 013654 062716 000002 ADD #2(SP) :SET UP SP FOR RTI
3067 013660 012137 014014 MOV (R1)+,WRCNT :PICK UP # OF WORDS FROM TABLE
3068 013664 112137 014016 1$: MOV#B (R1)+,CHRCNT :PICK UP # OF CHARS FROM TABLE
3069 013670 112137 014017 MOV#B (R1)+,SPACNT :PICK UP # OF SPACES FROM TABLE
3070 013674 013137 014020 MOV 2(R1)+,BINWRD :PICK UP ADDRESS OF MSG
3071 :FROM TABLE
3072 2$: MOV BINWRD,R4 :SAVE
3073 013704 113705 014016 MOV#B CHRCNT,R5 :SAVE
3074 013710 012700 016212 MOV #TEMP,R0 :STARTING ADDRESS OF TEMP BLOCK
3075 013714 010403 3$: MOV R4,R3 :SAVE
3076 013716 042703 177770 BIC #177770,R3 :CLR OUT UPPER BITS .. SAVE CHAR
3077 013722 062703 000260 ADD #260,R3 ;CONVERT TO ASCII
3078 013726 110320 MOV#B R3,(R0)+ ;STORE AWAY

```

3079 013730 006204
 3080 013732 006204
 3081 013734 006204
 3082 013736 005305
 3083 013740 001365
 3084 013742 012703 016254
 3085 013746 114023
 3086 013750 105337 014016
 3087 013754 001374
 3088 013756 105737 014017
 3089 013762 001405
 3090 013764 112723 000240
 3091 013770 105337 014017
 3092 013774 001373
 3093 013776 105013
 3094 014000 104402
 3095 014002 016254
 3096 014004 005337 014014
 3097 014010 001325
 3098 014012 000002
 3099 014014 000000
 3100 014016 000000
 3101 014017 014017
 3102 014020 000000
 3103
 3104
 3105
 3106
 3107
 3108
 3109 014022 017605 000000
 3110 014026 122737 000116 016150
 3111 014034 001002
 3112 014036 105015
 3113 014040 000406
 3114 014042 122737 000131 016150
 3115 014050 001005
 3116 014052 112715 177777
 3117 014056 062716 000002
 3118 014062 000002
 3119 014064 104404
 3120 014066 000755
 3121
 3122
 3123
 3124
 3125
 3126 014070 011646
 3127 014072 162716 000002
 3128 014076 017616 000000
 3129 014102 006316
 3130 014104 042716 177001
 3131 014110 062716 001222
 3132 014114 017616 000000
 3133 014120 000136
 3134

```

ASR R4 ;SHIFT FOR NEXT #
ASR R4 ;DITTO
ASR R4 ;DITTO
DEC R5 ;DEC CHAR COUNT
BNE 3$ ;DO IT AGAIN ?
MOV #MDATA,R3 ;STARTING ADDRESS OF MDATA BLOCK
4$: MOVB -(R0),(R3)+ ;REVERSE THE ORDER OF NUMBERS
DECB CHR CNT ;DEC CHAR COUNT
BNE 4$ ;DO IT AGAIN ?
TSTB SPACNT ;HOW MANY SPACES ?
BEQ 6$ ;TYPE # IF BR =0
5$: MOVB #240,(R3)+ ;"SPACE" IN ASCII
DECB SPACNT ;DEC # OF SPACE COUNT
BNE 5$ ;DO IT AGAIN ?
6$: CLRB (R3) ;INSERT "0" FOR TTY OUTPUT ROUTINE
TYPE
MDATA ;THIS MESSAGE
DEC WRDCNT ;HOW MANY #'S ?
BNE 1$ ;DO THIS ROUTINE AGAIN IF NOT EQUAL TO 0
RTI ;RETURN TO PROGRAM
WRDCNT: 0
CHARCNT: 0
SPACNT=CHARCNT+1
BINWRC: 0
    
```

```

;COMPARE THE FIRST CHARACTER IN THE TELETYPE INPUT
;BUFFER TO THE CHARACTERS "N" AND "Y".
;IF THE CHARACTER IS "N" CLEAR THE FLAG
;IF THE CHARACTER IS "Y" SET THE FLAG
    
```

```

.SETFLG: MOV 3(SP),R5
CMPB #'N,INBUF ;IS IT "N" ?
BNE 1$
CLRB (R5) ;000
BR 2$
1$: CMPB #'Y,INBUF ;IS IT "Y" ?
BNE 3$
MOVB #-1,(R5) ;377
ADD #2,(SP)
RTI
3$: INSTER ;RETRY
BR ;SETFLG
    
```

```

;TRAP DISPATCH SERVICE
;ARGUMENT OF TRAP IS EXTRACTED
;AND USED AS OFFSET TO OBTAIN POINTER
;TO SELECTED SUBROUTINE
    
```

```

.TRPSR: MOV (SP),-(SP) ;GET PC OF RETURN
SUB #2,(SP) ;=PC OF TRAP
MOV 3(SP),(SP) ;GET TRP
TRPOK: ASL (SP) ;MULTIPLY TRAP ARG BY 2
BIC #177001,(SP) ;CLEAR UNWANTED BITS
ADD #.TRPTAB,(SP) ;POINTER TO SUBROUTINE ADDRESS
MOV 3(SP),(SP) ;SUBROUTINE ADDRESS
JMP 3(SP)+ ;GO TO SUBROUTINE
    
```

```

3135                                     ;ERROR HANDLER
3136
3137 014122 032737 020000 177570 .HLT: BIT      #SW13,SWR      ;INHIBIT FRPOR TYPE OUT ?
3138 014130 001074          BNE      HALTS
3139 014132 021637 001130          CMP      (SP),LSTERR
3140 014136 001404          BEQ      1$
3141 014140 011637 001130          MOV      (SP),LSTERR
3142 014144 105037 001220          CLR      ERRFLG
3143 014150 104406          1$:      SAVOS
3144 014152 011605          MOV      (SP),R5
3145 014154 162705 000002          SUB      #2,R5
3146 014160 012702 017400          MOV      #ERRST,R2
3147 014164 010522          MOV      R5,(R2)+
3148 014166 011504          MOV      (R5),R4
3149 014170 006304          ASL      R4
3150 014172 061504          ADD      (R5),R4
3151 014174 006304          ASL      R4
3152 014176 042704 177001          BIC      #177001,R4
3153 014202 062704 016772          ADD      #.ERRTAB,R4
3154 014206 012437 014252          MOV      (R4)+,ERRMSG
3155 014212 012437 014264          MOV      (R4)+,DATAHD
3156 014216 011437 014316          MOV      (R4),DATABP
3157 014222 105737 001220          TST      ERRFLG
3158 014226 001403          BEQ      TYPMSG
3159 014230 005737 014316          TST      DATABP
3160 014234 001014          BNE      TYPOAT
3161 014236 104410          TYPMSG: CONVRT
3162 014240 014406          ERTABO
3163 014242 112737 177777 001220          MOVB    #-1,ERRFLG
3164 014250 104402          TYPE
3165 014252 000000          ERRMSG: 0
3166 014254 005737 014264          TST      DATAHD
3167 014260 001402          BEQ      TYPDAT
3168 014262 104402          TYPE
3169 014264 000000          DATAHD: 0
3170 014266 005737 014316          TYPDAT: TST      DATABP
3171 014272 001412          BEQ      RESREG
3172 014274 013722 001160          MOV      SAVR3,(R2)+
3173 014300 013722 001152          MOV      SAVR0,(R2)+
3174 014304 013722 001154          MOV      SAVR1,(R2)+
3175 014310 012722 000000          MOV      #0,(R2)+
3176 014314 104410          CONVRT
3177 014316 000000          DATABP: 0
3178 014320 104407          RESREG: RESOS
3179 014322 005737 177570          HALTS:  TST      SWR
3180 014326 100005          BPL      EXITER
3181 014330 010046          PUSHRO
3182 014332 016600 000002          MOV      2(SP),R0
3183 014336 000000          HALT
3184 014340 012600          POPRO
3185 014342 005237 001126          EXITER: INC      ERRCNT
3186 014346 032737 000400 177570          BIT      #SW0B,SWR      ;LOOP ON ERROR ?
3187 014354 001007          BNE      1$
3188 014356 032737 002000 177570          BIT      #SW10,SWR      ;ESCAPE TO NEXT ON ERROR ?
3189 014364 001407          BEQ      2$
3190 014366 013737 001112 001110          MOV      NEXT,RETURN    ;SET UP FOR NEXT TEST

```

3191	014374	012706	001100		1\$:	MOV	#STACK,SP	;REINITIALIZE SP
3192	014400	000177	164504			JMP	3RETURN	
3193	014404	000002			2\$:	RTI		
3194	014406	000001			ERTAB0:	1		
3195	014410	005	002			.BYTE	6,2	
3196	014412	00117C				SAVPC		
3197								;ENTER HERE ON POWER FAILURE
3198								
3199								
3200	014414	010046			.PFAIL:	MOV	RO,-(SP)	;SAVE RO-R5 ON PROCESSOR STACK
3201	014416	010146				MOV	R1,-(SP)	
3202	014420	010246				MOV	R2,-(SP)	
3203	014422	010346				MOV	R3,-(SP)	
3204	014424	010446				MOV	R4,-(SP)	
3205	014426	010546				MOV	R5,-(SP)	
3206	014430	013746	000024			MOV	24,-(SP)	
3207	014434	010637	001166			MOV	SP,SAVSP	;SAVE STACK POINTER
3208	014440	012737	014452	000024		MOV	#RESTART,24	;SET UP FOR POWER UP TRAP
3209	014446	000000				HALT		;HALT ON POWER DOWN NORMAL
3210	014450	000777				BR	.	
3211								
3212								;PROCESSOR WILL TRAP HERE WHEN POWER IS RESTORED
3213								
3214	014452	013706	001166		RESTAR:	MOV	SAVSP,SP	;RESTORE STACK POINTER
3215	014456	012605				MOV	(SP)+,R5	;RESTORE RO-R5
3216	014460	012604				MOV	(SP)+,R4	
3217	014462	012603				MOV	(SP)+,R3	
3218	014464	012602				MOV	(SP)+,R2	
3219	014466	012601				MOV	(SP)+,R1	
3220	014470	012600				MOV	(SP)+,RO	
3221	014472	012737	014414	000024		MOV	#.PFAIL,24	;SET UP FOR POWER FAILURE
3222	014500	012737	000340	177776		MOV	#340,PS	
3223	014506	012706	001100			MOV	#STACK,SP	
3224	014512	005037	016212			CLR	TEMP	
3225	014516	005237	016212			INC	TEMP	
3226	014522	001375				BNE	-.4	
3227	014524	104410				CONVRT		
3228	014526	014550				PFTAB		
3229	014530	104402				TYPE		
3230	014532	015266				MPFAIL		
3231	014534	005037	001220			CLR	ERRFLG	
3232	014540	005037	001130			CLR	LSTERR	
3233	014544	000177	164340			JMP	3RETURN	
3234	014550	000001			PFTAB:	1		
3235	014552	006	002			.BYTE	6,2	
3236	014554	000207				RETURN		
3237	014556	005015	042012	030525	MTITLE:	.ASCIZ	<15><12><12>/DU11 DDDUA-A TAPE COMBINED EXERCIZER <<15><12>	
3238	014564	020061	042104	052504				
3239	014572	026501	020101	040524				
3240	014600	042520	041440	046517				
3241	014606	044502	042516	020104				
3242	014614	054105	051105	044503				
3243	014622	042532	020122	005015				
3244	014630	000						
3245	014631	015	053012	041505	MVECTO:	.ASCIZ	<15><12>/VECTOR ADDRESS-/	
3246	014636	047524	020122	042101				

3247	014644	051104	051505	026523	
3248	014652	000			
3249	014653	015	030412	052123	MREGAD: .ASCIZ <15><12>/1ST DEVICE: RECEIVER CONTROL REGISTER ADDRESS--/
3250	014660	042040	053105	041511	
3251	014666	035105	051040	041505	
3252	014674	044505	042526	020122	
3253	014702	047503	052116	047522	
3254	014710	020114	042522	044507	
3255	014716	052122	051105	040440	
3256	014724	042104	042522	051523	
3257	014732	000055			
3258	014734	005015	051101	020105	MMULT: .ASCIZ <15><12>/ARE YOU RUNNING MULTIPLE DEVICES ? (Y OR N)--/
3259	014742	047531	020125	052522	
3260	014750	047116	047111	020107	
3261	014756	052515	052114	050111	
3262	014764	042514	042040	053105	
3263	014772	041511	051505	037440	
3264	015000	024040	020131	051117	
3265	015006	047040	026451	000	
3266	015013	015	046012	051501	MLASTD: .ASCIZ <15><12>/LAST DEVICE:RECEIVER CONTROL REGISTER ADDRESS--/
3267	015020	020124	042504	044526	
3268	015026	042503	051072	041505	
3269	015034	044505	042526	020122	
3270	015042	047503	052116	047522	
3271	015050	020114	042522	044507	
3272	015056	052123	051105	040440	
3273	015064	042104	042522	051523	
3274	015072	000055			
3275	015074	042075	053105	041511	DEVICE: .ASCIZ /=DEVICE /
3276	015102	020105	000040		
3277	015106	005015	047510	020127	MCOW: .ASCIZ <15><12>/HOW NOW BROWN COW? ...SELECT SOMETHING TO RUN JACTREG/
3278	015114	047516	020127	051102	
3279	015122	053517	020116	047503	
3280	015130	037527	027040	027056	
3281	015136	042523	042514	052103	
3282	015144	051440	046517	052105	
3283	015152	044510	043516	052040	
3284	015160	020117	052522	020116	
3285	015166	040500	052103	042522	
3286	015174	000107			
3287	015176	005015	052517	020124	MRANGE: .ASCIZ <15><12>/OUT OF RANGE:RETYPE LAST DEVICE RXCSR ADDRESS--/
3288	015204	043117	051040	047101	
3289	015212	042507	051072	052105	
3290	015220	050131	020105	040514	
3291	015226	052123	042040	053105	
3292	015234	041511	020105	054122	
3293	015242	051503	020122	042101	
3294	015250	051104	051505	026523	
3295	015256	000			
3296	015257	040	037440	000	MQM: .ASCIZ / ?/
3297	015263	015	000012		MCRLF: .ASCIZ <15><12>
3298	015266	020040	047520	042527	MPFAIL: .ASCIZ / POWER FAILURE, PROGRAM RESTART AT TEST IN PROGRESS--/
3299	015274	020122	040506	046111	
3300	015302	051125	026105	050040	
3301	015310	047522	051107	046501	
3302	015316	051040	051505	040524	

3303	015324	052122	040440	020124	
3304	015332	042524	052123	044440	
3305	015340	020116	051120	043517	
3306	015346	042522	051523	000	
3307	015353	015	042412	042116	MEPASS: .ASCIZ <15><12>/END OF PASS TAPE DDCUA-A/
3308	015360	047440	020106	040520	
3309	015366	051523	052040	050101	
3310	015374	020105	042104	052504	
3311	015402	026501	000101		
3312	015406	005015	000122		MR: .ASCIZ <15><12>/R/
3313	015412	005015	042524	052123	MTSTPC: .ASCIZ <15><12>/TEST PC-/
3314	015420	050040	026503	000	
3315	015425	015	046012	041517	MLOCK: .ASCIZ <15><12>/LOCK ON SELECTED TEST? (Y OR N)-/
3316	015432	020113	047117	051440	
3317	015440	046105	041505	042524	
3318	015446	020104	042524	052123	
3319	015454	020077	054450	047440	
3320	015462	020122	024516	000055	
3321	015470	005015	052504	050040	MLEVEL: .ASCIZ <15><12>/DU PRIORITY LEVEL-/
3322	015476	044522	051117	052111	
3323	015504	020131	042514	042526	
3324	015512	026514	000		
3325	015515	015	021412	047440	MSYNC: .ASCIZ <15><12>/# OF SYNC CHARS SELECTED (1 OR 2)-/
3326	015522	020106	054523	041516	
3327	015530	041440	040510	051522	
3328	015536	051440	046105	041505	
3329	015544	042524	020104	020050	
3330	015552	020061	051117	031040	
3331	015560	026451	000		
3332	015563	015	044412	020123	MWIRE6: .ASCIZ <15><12>/IS SEC XMIT JUMPER #6 IN? (Y OR N)-/
3333	015570	042523	020103	046530	
3334	015576	052111	045040	046525	
3335	015604	042520	020122	033043	
3336	015612	044440	037516	024040	
3337	015620	020131	051117	047040	
3338	015626	026451	000		
3339	015631	015	044412	020123	MWIRE5: .ASCIZ <15><12>/IS SEC REC JUMPER #5 IN? (Y OR N)-/
3340	015636	042523	020103	042522	
3341	015644	020103	052512	050115	
3342	015652	051105	021440	020065	
3343	015660	047111	020077	054450	
3344	015666	047440	020122	024516	
3345	015674	000055			
3346	015676	005015	051511	047440	MWIRE4: .ASCIZ <15><12>/IS OPT CLR ENABLE JUMPER #4 IN? (Y OR N)-/
3347	015704	052120	041440	051114	
3348	015712	042440	040516	046102	
3349	015720	020105	052512	050115	
3350	015726	051105	021440	020064	
3351	015734	047111	020077	054450	
3352	015742	047440	020122	024516	
3353	015750	000055			
3354	015752	005015	051101	020105	MEXTJ: .ASCII <15><12>/ARE YOU RUNNING IN MAINT MODE EXTERNAL?/
3355	015760	047531	020125	052522	
3356	015766	047116	047111	020107	
3357	015774	047111	046440	044501	
3358	016002	052116	046440	042117	

```

3359 016010 020105 054105 042524
3360 016016 047122 046101 077
3361 016023 015 000412 047101
3362 016030 020104 027056 027056
3363 016036 020056 047504 054440
3364 016044 052517 044040 0531C1
3365 016052 020105 044124 020105
3366 016060 054105 042524 047122
3367 016066 046101 046440 042117
3368 016074 046505 041040 050131
3369 016102 051501 123
3370 016105 015 000412 052512
3371 016112 050115 051105 041440
3372 016120 047117 042518 052103
3373 016126 051117 047440 020116
3374 016134 024077 020131 051117
3375 016142 047040 026451 000
3376
3377
3378
3379
3380 016150 000000
3381 016212 016212 000000
3382 016212 000000
3383 016254 016254
3384 016254 000000
3385 016315 016315
3386
3387
3388
3389
3390
3391 016316 006337 016366
3392 016322 006337 016366
3393 016326 006337 016366
3394 016332 006337 016366
3395 016336 006337 016366
3396 016342 013737 016366 016370
3397 016350 162737 000001 016370
3398 016356 042737 000037 016370
3399 016364 000207
3400 016366 000240
3401 016370 000200
3402
3403
3404 016372 013737 016524 017022
3405 016400 005237 016524
3406 016404 013737 016524 017024
3407 016412 005237 016524
3408 016416 013737 016524 017026
3409 016424 013737 016524 017032
3410 016432 005237 016524
3411 016436 013737 016524 017030
3412 016444 013737 016524 017034
3413 016452 005237 016524
3414 016456 013737 016524 017036

```

```

.ASCII 15 12<<1>>AND ..... DO YOU HAVE THE EXTERNAL MODEM BYPASS/
.ASCIIZ 15<<12><1>>JUMPER CONNECTOR ON ?(Y OR N)-/

.EVEN

;BUFFERS FOR INPUT-OUTPUT

INBUF: 0
.=.+40
TEMP: 0
.=.+40
MDATA: 0
.=.+40
;*****
;UTILITIES
;*****

;THIS UTILITY CALCULATES PRIORITY LEVEL
DULEV: ASL DUPRT ;SHIFT LEFT
ASL DUPRT ;
ASL DUPRT ;
ASL DUPRT ;
ASL DUPRT ;
MOV DUPRT,LESS1 ;MOVE THIS TO LESS1
SUB #1,LESS1 ;CREATE LESS1
BIC #37,LESS1 ;CLEAR TNZVC
RTS PC

DUPRT: LEVEL5
LESS1: LEVEL4 ;LEVEL TO ALLOW INTERRUPTS

;NEW DU ADDRESSES
DUADDR: MOV DUBASE,RXCSCR ;XXX0
INC DUBASE
MOV DUBASE,HRXCSCR ;XXX1
INC DUBASE
MOV DUBASE,RXDBUF ;XXX2
INC DUBASE
MOV DUBASE,PARCSR ;XXX2
INC DUBASE
MOV DUBASE,HRXDBUF ;XXX3
INC DUBASE
MOV DUBASE,HPARCSR ;XXX3
INC DUBASE
MOV DUBASE,TXCSR ;XXX4

```

```

3415 016464 005237 016524
3416 016470 013737 016524 017040
3417 016476 005237 016524
3418 016502 013737 016524 017042
3419 016510 005237 016524
3420 016514 013737 016524 017044
3421 016522 000207
3422 016524 000000
3423
3424
3425
3426
3427
3428
3429
3430
3431
3432
3433
3434
3435
3436
3437
3438
3439
3440
3441
3442
3443
3444
3445
3446
3447
3448
3449
3450
3451
3452
3453
3454
3455
3456
3457
3458
3459
3460
3461
3462
3463
3464
3465
3466
3467
3468
3469
3470

```

```

INC DUBASE
MOV DUBASE,HTXCSR ;XXX5
INC DUBASE
MOV DUBASE,TXDBUF ;XXX6
INC DUBASE
MOV DUBASE,HTXDBUF ;XXX7
RTS PC
DUBASE: 0

; THIS UTILITY POKES THE MAINT DATA BASED UPON THE
; INFORMATION CONTAINED IN TEMP1 AND IT IS
; SHIFTED IN BY THE CONTENTS OF SHIFT
RPOKE: BIC #MTDATA,@TXCSR
CLR TEMP2
ROR TEMP1 ;FORCE CARRY
ROR TEMP2 ;PICK UP CARRY IN BIT 15
ASR TEMP2 ;SHIFT INTO BIT 14
BIC #BIT15,TEMP2 ;CLR BIT 15
BIS TEMP2,@TXCSR ;POKE MAINT DATA
BIC #CLK,@TXCSR ;POKE CLK
BIS #CLK,@TXCSR ;
DEC SHIFT
BNE RPOKE
RTS PC

; THIS ROUTINE CALCULATES ODD PARITY FOR AN 8 BIT CHAR
ODD8: MOV TEMP1,TEMP2 ;SAVE TEMP1
CLR TEMP3
MOV #8,(PC)+
4$: 0
1$: ROR TEMP2
ADC TEMP3
DEC 4$
BNE 1$
ROR TEMP3
BCS 2$
BIS #BIT8,TEMP1 ;SET ODD PARITY
BR 3$
2$: BIC #BIT8,TEMP1 ;CLR EVEN PARITY
;TEMP1 NOW HAS ODD PARITY CHARACTER
3$: RTS PC

; THIS ROUTINE CALCULATES EVEN PARITY FOR AN 8 BIT CHARACTER
EVEN8: MOV TEMP1,TEMP2 ;SAVE TEMP1
CLR TEMP3
MOV #8,(PC)+
4$: 0
1$: ROR TEMP2
ADC TEMP3
DEC 4$
BNE 1$
ROR TEMP3
BCS 2$
BIS #BIT8,TEMP1 ;SET EVEN PARITY
BR 3$
2$: BIC #BIT8,TEMP1 ;CLR ODD PARITY
;TEMP1 NOW HAS EVEN PARITY CHARACTER
3$:

```

```

3471 016762 000207
3472
3473 016764 062716 000002
3474
3475 016770 000002
3476
3477 016772 017056
3478 016774 000000
3479 016776 000000
3480 017000 017072
3481 017002 017243
3482 017004 017264
3483 017006 017134
3484 017010 017243
3485 017012 017264
3486 017014 017176
3487 017016 017243
3488 017020 017264
3489
3490 017022 160040
3491 017024 160041
3492 017026 160042
3493 017030 160043
3494 017032 160042
3495 017034 160043
3496 017036 160044
3497 017040 160045
3498 017042 160046
3499 017044 160047
3500
3501 017046 000330
3502 017050 000332
3503 017052 000334
3504 017054 000336
3505
3506 017056 036440 042440 051122
3507 017064 051117 050040 000103
3508 017072 036440 051040 043505
3509 017100 051511 042524 020122
3510 017106 051105 047522 020122
3511 017114 041520 005015 051001
3512 017122 043505 051511 042524
3513 017130 020122 000040
3514 017134 036440 051040 041505
3515 017142 044505 042526 020122
3516 017150 051105 047522 020122
3517 017156 041520 005015 051001
3518 017164 043505 051511 042524
3519 017172 020122 000040
3520 017176 036440 052040 040522
3521 017204 051516 044515 052124
3522 017212 051105 042440 051122
3523 017220 051117 050040 006503
3524 017226 000412 042522 044507
3525 017234 052123 051105 020040
3526 017242 000

```

```

35:   RIS   PC
TRPREG: ADD   #2,(SP) ;ALLOW IT TO "CRUNCH" INTO HLT BACK
;IN MAIN PART OF THE PROGRAM
RTI
;ERROR HLT TABLE
.ERRTAB:      EM0   ;HLT 0 BIT ERROR (GENERAL)
              0
              0
              EM1   ;HLT 1 REGISTER ERROR
              DH1
              DT1
              EM2   ;HLT 2 RECEIVER ERROR
              DH1
              DT1
              EM3   ;HLT 3 TRANSMITTER ERROR
              DH1
              DT1
              :DEFAULT DU ADDRESSES
RXCSR: 160040
HRXCSR: 160041
RXD8BUF: 160042
HRXD8BUF: 160043
PARCSR: 160042
HPARCSR: 160043
TXCSR: 160044
HTXCSR: 160045
TXD8BUF: 160046
HTXD8BUF: 160047
              :DEFAULT DU VECTORS
DURIV: 330 ;REC INTR VECTOR
DURIS: 332 ;REC INTR STATUS
DUTIV: 334 ;XMIT INTR VECTOR
DUTIS: 336 ;XMIT INTR STATUS
;ERROR MESSAGES
EM0: .ASCIZ / = ERROR PC/
EM1: .ASCIZ / = REGISTER ERROR PC/<15><12><1>/REGISTER /
EM2: .ASCIZ / = RECEIVER ERROR PC/<15><12><1>/REGISTER /
EM3: .ASCIZ / = TRANSMITTER ERROR PC/<15><12><1>/REGISTER /

```

```

3527
3528 017243      105 050130 041505
3529 017250 042524 020104 040440
3530 017256 052103 040525 000114
3531
3532
3533 017264 000003
3534 017266      006      004
3535 017270 001160
3536 017272      006      004
3537 017274 001152
3538 017276      006      002
3539 017300 001154
3540      017400
3541 017400 000020
3542      000001

```

```

DH1: ;DATA HEADERS FOR ERROR MESSAGES
      .ASCIZ /EXPECTED ACTUAL/
.EVEN
;DATA TABLES FOR ERROR MESSAGES
DT1: 3
      .BYTE 6,4
      SAVR3 ;REGISTER
      .BYTE 6,4
      SAVR0 ;EXPECTED DATA
      .BYTE 6,2
      SAVR1 ;ACTUAL DATA
.=017400
ERRST: .BLKW 20
.END

```


CUTMUL	001700	1228	1253	1264*																	
CVRRUN=	040000	744*	1746	2176																	
PARAM =	104405	1148*	1200	1211	1232	1257	1267	1338													
PARAM1	013416	2995*	3012																		
PARCSR	017032	1360*	1367*	1415*	1422*	1470*	1477*	1520*	1527*	1564*	1571*	1603*	1610*	1639*							
		1546*	1685*	1692*	1769*	1777*	1827*	1835*	1880*	1882*	1933*	1941*	1993*	2000*							
		2050*	2053*	2125*	2133*	2205*	2212*	2354*	2361*	2443*	2451*	2547*	2555*	2694*							
		2708*	2769*	2777*	3409*	3494*															
PAREN =	001000	748*																			
PARER =	010000	746*	1721	1746	1752																
PARERR	013472	2998	3000	3002	3011*	3017	3019	3021													
PASCNT	001124	1077*	1175*	2891*	2892																
PC =	=%000007	678*	1056*	1207*	1273*	1379*	1391*	1395*	1434*	1446*	1450*	1486*	1498*	1502*							
		1540*	1545*	1581*	1583*	1622*	1658*	1705*	1724*	1743*	2010*	2015*	2031*	2225*							
		2237*	2249*	2258*	2277*	2288*	2842*	2864*	2870*	2873*	2882*	2896*	3399*	3421*							
		3438*	3442*	3454*	3459*	3471*															
PFTAB	014550	3228	3234*																		
POPPO =	012600	692*	3184																		
POP1SP=	005726	690*																			
POP2SP=	022626	694*																			
PS =	177776	684*	1170*	1311*	2318*	2321*	2341*	2368*	2372*	2382*	2394*	2432*	2465*	2475*							
		2489*	2504*	2512*	2520*	2535*	2573*	2593*	2610*	2641*	2671*	2900*	3222*								
PUSHRO=	010046	691*	3181																		
PUSHIS=	005746	689*																			
PUSH2S=	024646	693*																			
REACT=	004000	730*	2011	2026	2034	2232	2238	2242	2251	2259	2280	2704	2726								
REPLAY	012646	2864	2870	2872*																	
RESREG	014320	3171	3178*																		
RESTAR	014452	3208	3214*																		
RESTRT	013012	2865	2894	2900*																	
RESOS =	104407	1154*	3178																		
RETURN	001110	1071*	1180*	1345*	1347	2901*	2918*	2919	2937*	2938	3190*	3192	3233								
RING =	040000	727*																			
RINTEN=	000100	735*	2386	2398	2402	2426	2581	2595	2618	2642											
ROTADD	001214	1117*	1227*	1239*	1241	1243*	1248	1251*	2859*	2862	2866*										
RPOKE	016526	1379	1391	1395	1434	1446	1450	1486	1498	1502	1545	1583	1622	1658							
		1705	1724	1743	2010	2016	2031	2225	2237	2249	2258	2277	2289	3427*							
		3437																			
RTS =	000004	734*																			
RUNIT	012552	2850	2856*	2863																	
RXCSP	017022	1368*	1380	1423*	1435	1478*	1487	1528*	1572*	1611*	1618*	1623	1647*	1654*							
		1659	1695*	1702*	1706	1725	2001*	2011	2026	2034	2135*	2146	2173	2214*							
		2232	2238	2241*	2242	2250*	2251	2254	2259	2262	2280	2283	2289	2322							
		2325*	2331*	2332*	2339*	2362*	2373	2379*	2386*	2395	2398*	2402*	2426*	2556*							
		2581*	2595*	2611	2618*	2642*	2652	2695*	2704	2726	2750	2781*	2817	2886							
		3404*	3490*																		
PXDBUF	017026	1375	1383	1398	1430	1438	1453	1482	1490	1505	1535	1546	1576	1584							
		1693	1712	1728	2136	2152	2177	2222	2266	2293	2380	2423	2425	2574							
		2612	2690	2731	2778	2820	3408*	3492*													
PXDOME=	000200	734*																			
PXERR =	100000	743*	1721	1746	1749	1752	2176														
PQ =	=%000000	671*	1189*	1192*	1194*	1376*	1384	1396*	1399	1431*	1439	1451*	1454	1483*							
		1491	1503*	1506	1537*	1547	1578*	1585	1711*	1716	1721*	1729	1746*	1749*							
		1752*	1785*	1788*	1794	1802*	1805	1843*	1846*	1852	1860*	1863	1896*	1899*							
		1905	1913*	1916	1949*	1952*	1958	1966*	1969	2082*	2083*	2096	2151*	2153							
		2176*	2178	2265*	2267	2292*	2294	2333*	2334*	2383*	2384*	2418*	2419*	2424*							

.SRDOC	18
.SREAC	18
.SR2AZ	18
.SSAVE	18
.SSB20	18
.SSB20	18
.SSCOP	18
.SSIZE	18
.SSUPR	18
.STRAP	18
.STYPB	18
.STYPD	18
.STYPE	18
.STYPE	18
.STYPE	18
.SHOOR	18
.....	18

ADJ	3445	3462													
ADJ	1194	1195	1245	2856	2857	2875	2877	2879	2953	2965	3027	3066	3077	3117	3131
	3150	3153	3473												
ADJ	3007	3008	3009	3129	3149	3151	3391	3392	3393	3394	3395				
ADJ	3079	3080	3081	3431											
ADJ	1787	1845	1898	1951	2411	3466									
ADJ	1244	2860	3449												
ADJ	1317	1322	1328	1335	1385	1400	1440	1455	1492	1507	1548	1586	1717	1730	1735
	1737	1739	1795	1806	1853	1864	1906	1917	1959	1970	2012	2027	2091	2097	2154
	2179	2227	2243	2252	2260	2268	2295	2428	2650	2657	2661	2666	2705	2722	2735
	2751	2822	2841	2848	2863	2894	2923	2946	2955	2975	2998	3006	3089	3140	3158
	3167	3171	3189												
	2568	2592	2640												
	3002														
	1247	3017													
	1370	1373	1425	1428	1480	1530	1533	1574	1613	1616	1649	1652	1697	1700	1784
	1791	1793	1804	1842	1849	1851	1862	1895	1902	1904	1915	1948	1955	1957	1968
	2003	2005	2020	2023	2060	2066	2073	2088	2139	2143	2168	2216	2219	2241	2325
	2139	2364	2386	2398	2408	2413	2426	2456	2460	2479	2488	2534	2594	2595	2618
	2519	2633	2642	2655	2699	2703	2718	2733	2789	2804	3076	3130	3152	2398	3427
	3432	3434	3452	3469											
	2973	3003													
	1241	1248	1359	1361	1368	1371	1374	1414	1416	1423	1426	1429	1469	1471	1478
	1481	1519	1521	1528	1531	1534	1543	1563	1565	1572	1575	1602	1604	1611	1614
	1517	1618	1638	1640	1647	1650	1653	1654	1684	1686	1695	1698	1701	1702	1768
	1770	1783	1788	1790	1801	1826	1828	1841	1846	1848	1859	1879	1881	1894	1899
	1901	1912	1932	1934	1947	1952	1954	1965	1992	1994	2001	2004	2007	2021	2024
	2049	2051	2059	2065	2072	2087	2124	2126	2135	2138	2142	2167	2204	2206	2214
	2217	2220	2250	2315	2331	2332	2353	2355	2362	2365	2379	2402	2412	2414	2442
	2444	2455	2459	2466	2468	2501	2505	2546	2548	2556	2581	2582	2689	2695	2698
	2702	2717	2744	2749	2768	2770	2781	2783	2798	3433	3435	3450	3467		
	2083	3004													
	1186	1321	1301	2011	2026	2034	2090	2232	2238	2242	2251	2259	2290	2704	2726
	2750	2840	2862	2922	2929	2945	3137	3185	3188						
	3020														
	3019														
	2933														
	1197	3000													
	1225	1381	1436	1488	1726	2055	2068	2174	2230	2273	2290	2323	2351	2374	2396
	2477	2523	2579	2625	2725	2746	2818								
	1183	1187	1282	1286	1314	1553	1591	1627	1663	1710	1799	1857	1910	1963	2033
	2035	2075	2095	2101	2145	2150	2170	2172	2233	2239	2279	2281	2335	2385	2416
	2420	2462	2471	2508	2531	2565	2589	2637	2720	2727	2755	2787	2793	2802	2808
	2912	2816	2826	2839	2850	2930	2980	3021	3029	3083	3087	3092	3097	3111	3115
	3138	3160	3187	3226	3437	3447	3464								
	1624	1660	1707	1811	1991	2062	2147	2202	2255	2263	2284	2314	2712	2767	2926
	2957	2971	2977	3180											
	1253	1284	1288	1290	1320	1331	1344	2319	2369	2473	2510	2607	2648	2707	2871
	2908	2914	2917	2924	2928	2959	2983	3010	3012	3113	3120	3210	3451	3468	
	1242	1541	2089	2409	2858										
	1173	1175	1177	1178	1193	1226	1227	1240	1536	1577	1785	1843	1896	1949	2082
	2085	2333	2382	2418	2469	2506	2529	2562	2563	2586	2587	2634	2635	2779	2889
	2890	2935	2995	3224	3231	3232	3428	3441	3458						
	1174	1176	1283	2934	3093	3112	3142								
	1196	1246	1384	1399	1439	1454	1491	1506	1547	1585	1716	1729	1736	1738	1794
	1805	1852	1863	1905	1916	1958	1969	2096	2153	2178	2267	2294	2427	2567	2591

	2639	2649	2656	2659	2665	2734	2811	2821	2915	2932	3016	3018	3139		
COMP	1281	1285	2754	2974	2997	2999	3001	3005	3110	3114					
COMB	1185														
DEC	1626	1662	1709	1734	1798	1856	1909	1962	2032	2074	2094	2144	2149	2169	2171
	2226	2274	2278	2415	2461	2580	2624	2719	2721	2786	2792	2801	2807	2810	2838
	2979	3082	3096	3436	3446	3463									
DECS	3028	3086	3091												
EMT	695														
FM	781	783	785	787	789	791	793	795	797	799	801	803	805	807	809
	911	813	815	817	819	821	823	825	827	829	831	833	835	837	839
	841	843	845	847	849	851	853	855	857	859	861	863	865	867	869
	871	873	875	877	879	881	883	885	887	889	891	893	895	897	899
	901	903	905	907	909	911	913	915	917	919	921	923	925	927	929
	931	933	935	937	939	941	943	945	947	949	951	953	955	957	959
	961	963	965	967	969	971	973	975	977	979	981	983	985	987	989
	991	993	995	997	999	1001	1003	1005	1007	1009	1011	1013	1015	1017	1019
	1021	1023	1025	1027	1029	1031	1033	1035	1050	2853	3183	3209			
INC	1551	1589	2334	2384	2419	2470	2507	2530	2564	2566	2588	2590	2636	2638	2750
	2813	2891	2931	3185	3225	3405	3407	3410	3413	3415	3417	3419			
INCB	2100														
JMP	1047	1188	1228	1263	1347	1747	1750	1753	2203	2352	2583	2855	2865	2902	3133
	3192	3233													
JSR	1207	1273	1379	1391	1395	1434	1446	1450	1486	1498	1502	1540	1545	1581	1583
	1622	1658	1705	1724	1743	2010	2016	2031	2225	2237	2249	2258	2277	2288	2842
	2964	2870	2873	2896											
MOV	1170	1171	1172	1179	1180	1189	1190	1191	1192	1206	1208	1217	1218	1239	1251
	1252	1254	1311	1312	1318	1319	1329	1330	1332	1333	1345	1357	1358	1360	1364
	1367	1375	1376	1377	1378	1383	1389	1390	1393	1394	1396	1398	1412	1413	1415
	1419	1422	1430	1431	1432	1433	1438	1444	1445	1448	1449	1451	1453	1468	1468
	1470	1474	1477	1482	1483	1484	1485	1490	1496	1497	1500	1501	1503	1505	1517
	1518	1520	1524	1527	1535	1537	1538	1539	1546	1561	1562	1564	1568	1571	1576
	1578	1579	1580	1584	1600	1601	1603	1607	1610	1619	1620	1621	1636	1637	1639
	1643	1646	1655	1656	1657	1682	1683	1685	1689	1692	1693	1694	1703	1704	1711
	1712	1720	1721	1722	1723	1728	1741	1742	1745	1746	1748	1749	1751	1752	1765
	1767	1769	1774	1777	1778	1780	1781	1792	1802	1803	1824	1825	1827	1832	1835
	1836	1838	1839	1850	1860	1861	1877	1878	1880	1885	1888	1889	1891	1892	1903
	1913	1914	1930	1931	1933	1938	1941	1942	1944	1945	1956	1966	1967	1988	1989
	1993	1997	2000	2006	2009	2014	2015	2025	2029	2030	2045	2046	2047	2048	2050
	2052	2053	2070	2076	2084	2121	2122	2125	2130	2133	2136	2137	2140	2151	2152
	2158	2164	2176	2177	2198	2199	2205	2209	2212	2221	2222	2223	2224	2235	2236
	2248	2257	2265	2266	2270	2275	2276	2286	2287	2292	2293	2311	2312	2316	2317
	2318	2321	2326	2327	2328	2336	2337	2341	2348	2349	2354	2358	2361	2366	2367
	2368	2372	2376	2377	2380	2382	2389	2390	2394	2399	2403	2404	2421	2422	2423
	2424	2425	2432	2439	2440	2443	2448	2451	2453	2463	2464	2465	2475	2480	2481
	2482	2485	2486	2489	2499	2500	2502	2503	2504	2512	2513	2514	2520	2521	2532
	2533	2535	2544	2545	2547	2552	2555	2569	2570	2571	2572	2573	2574	2575	2576
	2593	2596	2597	2598	2599	2610	2611	2612	2613	2614	2615	2616	2617	2620	2626
	2629	2641	2643	2644	2645	2646	2652	2653	2654	2671	2686	2687	2688	2690	2692
	2693	2694	2708	2710	2715	2731	2732	2764	2765	2769	2774	2777	2778	2785	2791
	2795	2796	2800	2806	2820	2836	2852	2866	2868	2869	2872	2874	2876	2878	2880
	2881	2892	2893	2900	2901	2910	2911	2913	2916	2918	2919	2927	2936	2937	2938
	2947	2952	2964	2968	2969	2988	2989	2990	2991	2994	2996	3025	3026	3039	3043
	3044	3045	3046	3047	3048	3053	3054	3055	3056	3057	3058	3065	3067	3070	3072
	3074	3075	3084	3109	3126	3128	3132	3141	3144	3146	3147	3148	3154	3155	3156
	3172	3173	3174	3175	3182	3190	3191	3200	3201	3202	3203	3204	3205	3206	3207
	3208	3214	3215	3216	3217	3218	3219	3220	3221	3222	3223	3396	3404	3406	3409

MOV8	3409 1297 2958	3411 1779 2972	3412 1837 2978	3414 1890 2992	3416 1943 2993	3418 2057 3068	3420 2134 3069	3440 2159 3073	3442 2452 3078	3457 2585 3085	3459 2632 309C	2700 311E	2709 3163	2780	2814
NOP	1291	1329	1330	2897	2898	2899									
RESET	2827	2895													
RETURN	1341	3236													
ROL	1243	1542	2859												
ROR	1786	1844	1897	1950	2410	3429	3430	3444	3448	3461	3465				
RORB	2093														
RTI	2329 3049	2391 3059	2400 3098	2483 3119	2518 3193	2528 3475	2621	2628	2630	2920	2939	2948	2960	2984	3030
RTE	1056	2882	3399	3421	3438	3454	3471								
SEC	2092														
SUB	3127	3145	3397												
TAP	1133	1136	1139	1142	1145	1148	1151	1154	1157	1160					
TST	1313	1810	2322	2395	2476	2711	2745	2815	2849	2912	3159	3166	3170	3179	
TSTB	1182	1223	1315	1327	1380	1435	1487	1552	1590	1623	1659	1706	1725	1990	2054
	2061	2067	2146	2173	2201	2229	2254	2262	2272	2283	2289	2313	2350	2373	2522
	2578	2724	2766	2817	2825	2847	2925	2954	2956	2970	2976	3088	3157		
.ASCII	3354	3361													
.ASCIZ	3237	3245	3249	3258	3266	3275	3277	3287	3296	3297	3298	3307	3312	3313	3315
	3321	3325	3332	3339	3346	3370	3506	3508	3514	3520	3528				
.BLKW	3541														
.BYTE	1100	1101	1102	1103	1104	1105	1122	1123	1124	1125	1204	1205	1215	1216	1236
	1237	1261	1262	1271	1272	1342	1343	2885	3195	3235	3534	3536	3538		
.ENABL	1	630	632	634											
.END	3542														
.ENDC	1359	1375	1414	1430	1469	1482	1519	1535	1544	1563	1576	1582	1602	1618	1638
	1654	1679	1684	1734	1768	1826	1861	1879	1914	1932	1967	1990	2047	2123	2200
	2313	2350	2441	2501	2546	2688	2766	2768	2795	2810					
EQUIV	695														
.EVEN	1106	3376	3531												
.IF	1358	1368	1413	1423	1468	1478	1518	1528	1541	1562	1572	1582	1601	1611	1637
	1647	1679	1683	1734	1767	1825	1860	1879	1913	1931	1966	1989	2046	2122	2199
	2312	2349	2440	2500	2545	2687	2765	2766	2783	2797					
.IFF	1358	1359	1368	1413	1414	1423	1468	1469	1482	1518	1519	1528	1562	1563	1576
	1601	1602	1611	1637	1638	1647	1683	1684	1767	1768	1825	1826	1861	1878	1879
	1913	1931	1932	1966	1989	1990	2046	2047	2122	2123	2199	2200	2312	2313	2349
	2350	2440	2441	2500	2501	2545	2546	2687	2688	2765	2795	2810			
.IFT	1368	1423	1478	1528	1572	1611	1647	1679	1734	1860	1913	1966	2783	2797	
.IIF	1358	1359	1413	1414	1468	1469	1518	1519	1562	1563	1601	1602	1637	1638	1683
	1684	1767	1768	1825	1826	1878	1879	1931	1932	1989	1990	2046	2047	2122	2123
	2199	2200	2312	2313	2349	2350	2440	2441	2500	2501	2545	2546	2687	2688	2765
	2766	2824													
.IRP	1132	1135	1138	1141	1144	1147	1150	1153	1156	1159	1357	1358	1412	1413	1467
	1468	1517	1518	1561	1562	1600	1601	1636	1637	1682	1683	1766	1767	1824	1825
	1877	1878	1930	1931	1988	1989	2045	2046	2121	2122	2198	2199	2311	2312	2348
	2349	2439	2440	2499	2500	2544	2545	2686	2687	2764	2765	2830			
.LIST	1	4	629	634	648	1126	1135	1138	1141	1144	1147	1150	1153	1156	1159
	1162	1357	1358	1359	1412	1413	1414	1467	1468	1469	1517	1518	1519	1561	1562
	1563	1600	1601	1602	1636	1637	1638	1682	1683	1684	1766	1767	1768	1824	1825
	1826	1877	1878	1879	1930	1931	1932	1988	1989	1990	2045	2046	2047	2048	2121
	2122	2123	2198	2199	2200	2311	2312	2313	2348	2349	2350	2439	2440	2441	2499
	2500	2501	2544	2545	2546	2686	2687	2688	2689	2764	2765	2766	2830		
.MACRO	1	634													
.MLIST	1	4	634	648	1126	1135	1138	1141	1144	1147	1150	1153	1156	1159	1162

	1357	1358	1359	1412	1413	1414	1467	1466	1469	1517	1518	1519	1561	1562	1563
	1600	1601	1602	1636	1637	1638	1682	1683	1684	1766	1767	1768	1824	1825	1826
	1877	1878	1879	1930	1931	1932	1988	1989	1990	2045	2046	2047	2048	2121	2122
	2123	2198	2199	2200	2311	2312	2313	2348	2349	2350	2439	2440	2441	2499	2500
	2501	2544	2545	2546	2686	2687	2688	2689	2764	2765	2766	2830			
PAGE	4	48	633	667	778	1036	1099								
CRF	1357	1358	1359	1412	1413	1414	1467	1468	1469	1517	1518	1519	1561	1562	1563
	1600	1601	1602	1636	1637	1638	1682	1683	1684	1766	1767	1768	1824	1825	1826
	1877	1878	1879	1930	1931	1932	1988	1989	1990	2045	2046	2047	2048	2121	2122
	2123	2198	2199	2200	2311	2312	2313	2348	2349	2350	2439	2440	2441	2499	2500
	2501	2544	2545	2546	2686	2687	2688	2689	2764	2765	2766	2830			
REF	5	48													
ADPT	780														
FILE	648														

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

* DDDUAA.SEQ/SOL/CRF/PAGNUM/NL:TOC/DS:ERFZ=SYSMAC.CO,DDDUAA.P11
RUN-TIME: 40 51 5 SECONDS
RUN-TIME RATIO: 381/97=3.8
CORE USED: 44K (87 PAGES)