

.REM %

IDENTIFICATION

PRODUCT CODE: AC-9244F-MC
PRODUCT NAME: CZRKKF0 RK11 BASIC LOGIC TEST 2
DATE CREATED: JUNE 1978
MAINTAINER: DIAGNOSTIC GROUP
AUTHOR: JIM KAPADIA
REVISED BY: PERVEZ ZAKI
TOM SAWYER
CHUCK HESS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1975, 1978 BY DIGITAL EQUIPMENT CORPORATION

MAIN DEC CHANGE NOTICE
MAY BE REQUIRED FOR
PROGRAM TO OPERATE

FOR A QUICK REFERENCE, LOOK UP THE FOLLOWING SECTIONS:

- 1.0 ABSTRACT
- 2.0 REQUIREMENTS
- 4.1 LOADING AND OPERATOR ACTION
- 7.0 SWITCH OPTIONS

FOR A MORE COMPLETE EXPLANATION REFER TO THE TABLE OF CONTENTS BELOW AND THE FOLLOWING DOCUMENT.

TABLE OF CONTENTS

1.0	ABSTRACT
2.0	REQUIREMENTS
2.1	EQUIPMENT
2.2	PRELIMINARY PROGRAMS
2.3	EXECUTION TIME
3.0	STARTING ADDRESS
4.0	PROGRAM CONTROL MODES & OPERATOR ACTION
4.1	PAPER TAPE
4.2	RKDP DUMP MODE
4.3	RKDP CHAIN MODE
4.4	ACT11
5.0	DRIVE SELECTION
6.0	DRIVE-LESS TEST
7.0	SWITCH OPTIONS
8.0	SCOPE LOOPS
9.0	PROGRAM STRUCTURE
9.1	SET-UP PHASE
9.2	DRIVE DEPENDENT CONTROLLER TESTS
10.0	ERROR REPORTING
11.0	ERROR INTERPRETATION
12.0	HANDLERS AND COMMON ROUTINES
12.1	TRAP HANDLER
12.2	SCOPE HANDLER
12.3	ERROR HANDLER
12.4	CONTROL RESET ROUTINE
12.5	CONTROL READY ROUTINE
12.6	DRIVE RESET ROUTINE
12.7	TIME DELAY ROUTINE
12.8	WAIT FOR INTERRUPT ROUTINE
12.9	OTHER ROUTINES
	TTY HANDLER (I/O), ERROR TYPEOUT ROUTINE
	POWER DOWN/POWER UP ROUTINE
13.0	UNEXPECTED TIMEOUTS & RK11 INTERRUPTS
14.0	QUICK VERIFYING MODE

1.0 ABSTRACT

THE RK11 LOGIC TESTS CONSIST OF A SERIES OF TESTS AIMED AT CHECKING THE BASIC LOGIC OF THE RK11 CONTROLLER. THIS PROGRAM IS THE SECOND PART OF THE TWO-PART RK11 LOGIC TESTS. IT SHOULD BE NOTED THAT LOGIC TEST I AND LOGIC TEST II TOGETHER CONSTITUTE A COMPLETE PROGRAM AND BOTH OF THEM SHOULD BE RUN.

WHEN USED IN CONJUNCTION WITH A DRIVE IT IS CAPABLE OF DETECTING FAULTS IN THE DRIVE ALSO.

USED CORRECTLY THIS PROGRAM CAN BE AN EFFECTIVE ANALYTIC AND DIAGNOSTIC TOOL.

2.0 REQUIREMENTS

2.1 EQUIPMENT

- A. PDP11 WITH CONSOLE TELETYPE.
- B. 8K OF MEMORY
- C. RK11 OR RKV11 CONTROLLER
- D. 1-8 RK05 OR RK05F DRIVES OR THE RK05 SIMULATOR (DRIVE TYPES MAY BE MIXED)

2.2 PRELIMINARY PROGRAMS

RK11 BASIC LOGIC TEST I (MD-11-DZRRKJ)

2.3 EXECUTION TIME

ERROR FREE FIRST PASS ON PDP11/20 WITH CORE MEMORY TAKES APPROXIMATELY TWO MINUTES. CONSIDERABLY LESS FOR FASTER MACHINES OR MEMORIES.

3.0 STARTING ADDRESS

200 FOR ANY MODE OF OPERATION. NORMAL START UP WITH ALL SWITCHES DOWN.

4.0 PROGRAM CONTROL MODES & OPERATOR ACTION

PAPER TAPE LOADING
RKDP DUMP MODE
RKDP CHAIN MODE
ACT11

4.1 PAPER TAPE LOADING

4.1.1 LOAD PROGRAM INTO MEMORY USING STANDARD PROCEDURE FOR .ABS TAPES.

4.1.2 MAKE SURE THAT THE DRIVES TO BE CHECKED ARE LOADED WITH DISKS AND ARE IN 'RUN'. 'WRT ENABLE' THEM. CHECK THAT 'WRT PROT' LIGHT ON THESE DRIVES IS OFF. PUT DRIVES THAT ARE NOT TO BE TESTED ON 'LOAD'.

4.1.3 LOAD ADDRESS 200

4.1.4 SET SWITCHES IF DESIRED (SEE SEC 7.0) IF TESTING ON SIMULATOR PUT SW<10> UP.

PRESS START.

4.1.5 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO), THEN THE FOLLOWING QUESTION IS ASKED:

DRIVES TO BE TESTED?

THE USER SHOULD TYPE IN THE DRIVE NUMBERS THAT ARE IN 'RUN' AND TO BE TESTED. CARRIAGE RETURN SHOULD TERMINATE THE STRING. IF AN RK-05F IS TO BE TESTED, TYPE THE SUFFIX 'F' WITH THE FIRST DRIVE OF THE PAIR. FOR EXAMPLE, IF DRIVES 2 AND 3 ARE ON AN RK-05F, TYPE ONLY 2F.

EXMP: DRIVES TO BE TESTED? 0,1,2<CR>

THE DRIVES DO NOT HAVE TO BE IN LOGICAL ORDER.

EXMP: DRIVES TO BE TESTED? 2,4<CR>

IF ANY ONE DRIVE IS TO BE TESTED, TYPE IN THAT NUMBER. IT DOES NOT HAVE TO BE DRIVE 0.

THUS A NORMAL SEQUENCE WITH DRIVES 0,1 WOULD BE:

RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED? 0,1<CR>

4.1.6 THERE IS A "RUBOUT" FEATURE WHICH ALLOWS RUBBING OUT ANY NUMBER OF CHARACTERS THAT WERE TYPED IN WRONG. THE RUBBED OUT CHARACTERS ARE ECHOED BACK WITHIN SLASHES.

"^U" DELETES THE ENTIRE LINE

4.1.7 IF REPLY TO ANY OF THE ABOVE QUESTION IS IN A WRONG
FORMAT (EX: 012<CR>0,8<CR>; 0,A<CR>; M<CR> ETC), IT
IS AUTOMATICALLY REJECTED, A "??" IS PRINTED OUT;

THE CORRECT ANSWER CAN NOW BE RETYPED AGAIN.

4.1.8 THE DRIVE NUMBER BEING TESTED OUT IS PRINTED:

DRIVE #:N=0,1...7
IF THE DRIVE IS AN RK-05F, AN F IS APPENDED
AT THE END OF A PASS THE FOLLOWING TYPE-OUT OCCURS
END PASS # X

WHERE X= PASS NUMBER (1,2,3---), CONTROL IS PASSED
TO THE BEGINNING OF THE PROGRAM AND RE-EXECUTION
BEGINS. NO QUESTIONS ARE TO BE ANSWERED AGAIN.

4.1.9 ERROR FREE PASSES OF THE PROGRAM APPEAR AS SHOWN
BELOW.

RK11 BASIC LOGIC TEST 2
MAINDEC-11-CZRKKF
DRIVES TO BE TESTED?
0,1<CR>
DRIVE 0
DRIVE 1
END PASS # 1
0
DRIVE 1
END PASS # 2
...
...

4.2 RKDP DUMP MODE

4.2.1 THE PROGRAM IS LOADED INTO THE MEMORY BY THE RKDP
MONITOR

4.2.2 START AS NORMALLY USING SA 200

4.2.3 THE PROGRAM IDENTIFIES ITSELF (NAME,MAINDEC NO.).
ON FINDING OUT THAT THE LOADING WAS BY RKDP (DUMP
MODE), THE FOLLOWING MESSAGE APPEARS:

'TO TEST DRIVE 'N' HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT
WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM'
IF DRIVE 'N' IS TO BE TESTED, THE RKDP PACK ON THAT

DRIVE SHOULD BE REPLACED BY ANOTHER PACK, THE DRIVE SHOULD BE PUT ON 'WRT ENABL' (BECAUSE RKDP WRITE PROTECTS THE DRIVE).

IF DRIVE 'N' IS NOT TO BE CHECKED, THEN THE MESSAGE SHOULD BE IGNORED.

AFTER THIS, THE SEQUENCE OF QUESTIONING IS AS EXPLAINED IN SEC 4.1.5.

4.3 RKDP CHAIN MODE

THE PROGRAM IS CHAIN-LOADED FROM THE RKDP PACK ON DRIVE 'N'. AFTER THE PROGRAM IDENTIFIES ITSELF THE FOLLOWING PRINTOUT OCCURS.

'DRIVE 'N' NOT TESTED'

THERE IS NO OPERATOR INTERVENTION REQUIRED. THE PROGRAM FINDS OUT THE NUMBER OF DRIVES PRESENT.

4.4 ACT11 MODE

THE PROGRAM IS LOADED BY THE ACT11 MONITOR. ON STARTING, IDENTIFIES ITSELF, ASCERTAINS THE NUMBER OF DRIVES AND PROCEEDS WITH THE EXECUTION OF THE TESTS AS BEFORE.

5.0 DRIVE SELECTION

IF ANY PARTICULAR DRIVE IS TO BE SELECTED FOR TESTING, PUT THAT DRIVE ON 'RUN', 'WRITE ENABLE'; PUT REST OF THE DRIVES ON 'LOAD', 'WRITE LOCK' AND IN REPLY TO THE QUESTION (WHICH DRIVES TO BE TESTED?) TYPE IN THE DRIVE NUMBER FOLLOWED BY CR. SEE SEC 4.1.5.

6.0 DRIVE-LESS TEST

USE RK11 BASIC LOGIC TEST I, WHICH IS ACTUALLY THE FIRST PART OF THE TWO-PART RK11 BASIC LOGIC TESTS. SEE SEC 1.0, 2.2.

7.0 SWITCH OPTIONS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' WHENEVER THE PROGRAM ENTERS

THE SCOPE ROUTINE OR BEGINS A NEW TEST. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNN NEW = '

EACH TIME SWITCH SETTING ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED., 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

SW<15>=1 HALT ON ERROR
SW<14>=1 LOOP ON TEST
SW<13>=1 INHIBIT ERROR PRINTOUTS
SW<12>=1 CYCLE ON ERROR TO THE PREVIOUS
'SCOPE' STATEMENT
SW<11>=1 INHIBIT ITERATIONS
SW<10>=1 TESTING ON SIMULATOR
SW<09>=1 LOOP ON SPECIFIC ERROR
SW<08>=1 LOOP ON TEST AS PER SW<07:00>
SW<06>=1 DROP THE DRIVE AFTER MAXIMUM
ALLOWABLE NUMBER OF ERRORS OCCUR

7.1 SW<15>

THE PROGRAM HALTS ON ENCOUNTERING AN ERROR, AFTER TYPING OUT THE ERROR MESSAGE AND PERTINENT INFORMATION. PRESSING "CONTINUE" RESTORES NORMAL OPERATION OF THE PROGRAM.

7.2 SW<14>

THE PROGRAM LOOPS ON THE SUBTEST THAT IS BEING EXECUTED WHEN THE SWITCH IS PUT ON. THIS SWITCH IS USED NORMALLY ALONG SW 15. SEE SEC 8.0.

7.3 SW <13>

THIS SWITCH INHIBITS ALL ERROR MESSAGES. NORMALLY USED WHEN LOOPING ON TEST (SW 14) OR LOOPING ON ERROR (SW 9).

7.4 SW <12>

THIS SWITCH ALLOWS THE PROGRAM TO CYCLE FROM THE POINT OF ERROR TO THE PREVIOUS SCOPE STATEMENT. NOTE THAT IN DOING SO ANY INITIALIZATION BEING DONE AT THE BEGINNING OF THE SUBTEST WILL BE DONE AGAIN AND AGAIN. SEE SEC 8.0 FOR DIFFERENT SCOPE LOOPS

AVAILABLE.

7.5 SW <11>

EACH SUBTEST WILL BE EXECUTED ONLY ONCE. NORMALLY
AFTER THE FIRST PASS, EACH SUBTEST IS ITERATED A
NUMBER OF TIMES (USUALLY 50, 5 IN SOME CASES).
SETTING THIS SWITCH INHIBITS ITERATIONS, SO THAT
QUICK PASSES CAN BE MADE.

7.6 SW <10>

THIS SWITCH WHEN SET INDICATES THAT TESTING IS BEING
DONE ON A SIMULATOR. THE SWITCH SHOULD BE PUT UP
BEFORE STARTING THE PROGRAM. NOTE THAT RK11C IS
NOT COMPATIBLE WITH THE SIMULATOR.

7.7 SW <09>

THIS SWITCH PROVIDES THE TIGHTEST POSSIBLE SCOPE
LOOP. NOTE THAT SW12 THE INITIALIZATION OF
PARAMETERS AT THE BEGINNING OF THE SUBTEST MAY NOT
BE DONE IN THIS CASE. THIS SWITCH IS HELPFUL WHEN A
PARTICULAR PART OF A SUBTEST IS BEING REPEATED USING
DIFFERENT PARAMETERS AND YOU WANT TO SCOPE ON THE
PARAMETER IN ERROR. (EXAMPLE: RKDA IS BEING WRITTEN
AND READ BACK WITH COUNT PATTERNS FROM 1 TO 177777.
PATTERN 561 IS GIVING ERROR, YOU MIGHT NOT WANT TO
GO THROUGH THE 560 PATTERNS BEFORE HITTING ERROR ON
THE 561TH PATTERN. IN THIS CASE SW 9 WILL GIVE YOU
A SCOPE LOOP ON THE 561TH PATTERN ONLY
SW <08>

7.8

THIS SWITCH IS USED TO SELECT A PARTICULAR TEST (AS
PER SW<00-07>) FOR EXECUTION AND SUBSEQUENT LOOPING.
THUS IF TEST 15 IS TO BE SELECTED THE SWITCH SETTING
WOULD BE 000415. IT SHOULD BE NOTED THAT BEFORE
SELECTING TEST 15, ALL THE PREVIOUS TESTS (1-14)
WILL BE EXECUTED.

7.9 SW<06>

THIS SWITCH ALLOWS THE PROGRAM TO DROP A DRIVE FROM
THE SELECTION LIST AND TESTING AFTER MAXIMUM
ALLOWABLE ERROR COUNT (TOTAL NUMBER OF ERRORS) ON
THAT DRIVE IS EXCEEDED. THE MAXIMUM ALLOWABLE ERROR
COUNT IS 5, AFTER 5 ERRORS HAVE OCCURRED DRIVE
IS DROPPED, AND A MESSAGE (DRIVE # XXX DROPPED) IS
PRINTED.

8.0 SCOPE LOOPS

THERE ARE THREE KINDS OF SCOPE LOOPS AVAILABLE

1. SW14: LOOPING IS DONE FOR THE ENTIRE SUB-TEST
2. SW12: LOOPING IS DONE FROM THE POINT OF ERROR BACK TO THE PREVIOUS 'SCOPE' STATEMENT.
3. SW09: PROVIDE THE TIGHTEST POSSIBLE SCOPE LOOP SEE SEC. 7.7

EXAMPLE:
TST1: SCOPE
:

INITIALIZATION

ERROR 1
:
ERROR 2
:
ERROR 3
:
ERROR 4
:
:
TST2: SCOPE
:

THE SEQUENCE OF LOOPING FOR DIFFERENT CASES IS EXPLAINED BELOW. NOTE THAT 'TST1' AND 'TST2' ARE TAGS WHICH DEFINE THE BOUNDARY OF A TEST. (IN THIS CASE TEST 1). TEST 1 STARTS AT 'TST1' AND ENDS JUST BEFORE 'TST2'.

IN THE ILLUSTRATION BELOW --> INDICATES THE POINT FROM WHERE RETURN IS MADE AND LOOPING IS DONE.

1. ERROR 2 OCCURS, SW 14 SET.
TST1..ERROR 2..TST2-->TST1..ERROR 2..TST2-->TST1...
2. ERROR 2 OCCURS, SW 12 SET.
TST1...ERROR 2-->TST1...ERROR2-->TST1...
3. ERROR 2,3; SW 14 SET.
TST1..ERROR 2..ERROR 3..TST2-->TST1..ERROR 2..ERROR 3..TST2-->TST1...
4. ERROR 2,3; SW 12 SET.
TST1...ERROR 2-->TST1...ERROR 2-->TST1....

WHICH DRIVES ARE TO BE TESTED, ETC.

9.2 DRIVE DEPENDENT CONTROLLER TESTS

THIS SECTION FORMS A MAJOR PART OF THE PROGRAM WHEREIN MOST OF THE CONTROLLER IS CHECKED.

JUST BEFORE ENTERING THIS SECTION THE PROGRAM FINDS OUT WHICH DRIVE IS TO BE CHECKED. IF IN RKDP CHAIN MODE, DRIVE 'N' IF PRESENT, IS SKIPPED AND THE NEXT AVAILABLE DRIVE IS SELECTED.

THE DRIVE NUMBER BEING TESTED IS PRINTED OUT:

```
DRIVE N      ;N=0,1,2...7
```

THE TESTING IS DONE IN A LOGICAL HIERCHY, SIMPLER THINGS FIRST, THEN MORE COMPLEX AND SO ON.

IN ONE OF THE TESTS THE ENTIRE DISK PACK IS FORMATTED, CHECKS ARE MADE FOR ERROR CONDITIONS. THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A PSUEDO-HEADER, REFLECTING THE ABSOLUTE ADDRESS OF THAT SECTOR (DRIVE #, CYLINDER #, SURFACE #, SECTOR #). EXAMPLE: THE PSUEDO-HEADER FOR SECTOR 5, SURFACE 0, CYLINDER 20, DRIVE 0 WOULD BE 001005.

IN THE NEXT TEST THE HEADERS FROM THE ENTIRE PACK ARE READ AND CHECKED FOR CORRECTNESS. IN A SUBSEQUENT TEST ALL THE PSUEDO-HEADERS ARE READ AND VERIFIED.

ALL THE FUNCTIONS ARE CHECKED OUT. 'SEEK' IS CHECKED IN THE THREE DIFFERENT VELOCITY MODES (HIGH, MEDIUM, LOW). VARIOUS ERRORS LIKE 'NXD', 'NXC', ETC. ARE SIMULATED AND CHECKED.

HARDWARE POGIC IS CHECKED USING ALL THE DRIVES THAT HAVE BEEN INDICATED.

AT THE END OF THIS SECTION, A CHECK IS MADE IF ALL INDICATED DRIVES HAVE BEEN TESTED. IF NOT, CONTROL IS TRANSFERRED TO THE BEGINNING OF THIS SECTION.

THUS ONE PASS OF THE PROGRAM INVOLVES DOING:

1. SUBTEST #1 ONCE
2. DRIVE-DEPENDENT TESTS FOR ALL THE SELECTED DRIVES.

10.0 ERROR REPORTING

THE ERROR TABLE STARTING AT \$ERRTB CONTAINS INFORMATION PERTAINING TO EVERY ERROR THAT CAN OCCUR. EACH ITEM IN THE TABLE CONSISTS OF FOUR

ENTRIES.

- A. EM - THIS IS A POINTER TO THE ERROR MESSAGE TO BE TYPED OUT WHEN THE ERROR OCCURS.
- B. DH - THIS IS A POINTER TO THE DATA HEADER TO BE TYPED OUT.
- C. DT - THIS IS A POINTER TO THE DATA WHICH IS TO BE TYPED OUT UNDER THE HEADERS.
- D. O - THIS IS A TERMINATOR SIGNIFYING THE END OF THE ITEM.

THE ERROR CALL IS AN EMT INSTRUCTION WITH ITS LOWER BYTE ENCODED TO INDICATE THE ERROR NUMBER. THUS OR 1" WOULD BE (EMT+1) IE 104001.

EVERY ERROR CORRESPONDS TO AN ITEM IN THE ERROR TABLE. THUS "ERROR 14" WOULD CORRESPOND TO ITEM 14. AS FAR AS POSSIBLE, THE ERROR MESSAGES HAVE BEEN KEPT SHORT, BUT CLARITY IS NOT SACRIFICED FOR BREVITY. INSPITE OF THIS, IF THE USER FINDS A NEED, HE CAN LOOK UP THE ENTIRE ERROR MESSAGE IN THE ERROR ITEMS TABLE FOUND IN THE BEGINNING OF THE LISTINGS. THUS FOR "ERROR 14", "ITEM 14" IN THE ITEM TABLE CAN BE LOOKED UP. WHEN THE ERROR INSTRUCTION IS EXECUTED A TRAP OCCURS TO THE ERROR HA LOCATED AT \$ERROR WHICH PROCESSES THE ERROR CALL. SEE SEC 12.3

11.0 ERROR INTERPRETATION

WHENEVER AN ERROR MESSAGE IS PRINTED OUT, ALL REGISTERS AND OTHER DATA PERTAINING TO THE ERROR ARE ALSO GIVEN. RKDS, RKER...RKBA INDICATE THE CONTENTS OF THE CORRESPONDING REGISTERS AT THE TIME OF ERROR.

EVERY ERROR MESSAGE CONTAINS A PC. THIS PC INDICATES THE POSITION IN PROGRAM WHERE THE ERROR CALL IS LOCATED. THE ERROR MESSAGE, BECAUSE OF PRACTICAL CONSIDERATIONS IS MADE SHORT AND MEANINGFUL. THE USER IS ADVTD LOOK UP THE PC IN THE PROGRAM LISTING, WHERE HE WILL FIND MORE INFORMATION ABOUT THE ERROR. IN MANY INSTANCES, A SINGLE FAULT WILL GIVE RISE TO MORE THAN ONE ERROR REPORT. A LITTLE DELIBERATION AND CAREFUL EXAMINATION OF THE DATA GIVEN WILL BE CERTAINLY VERY HELPFUL IN PINPOINTING THE FAULT. A BRIEF EXPLANATION OF WHAT IS BEING CHECKED IN THE SUBTEST IS GIVEN AT THE BEGINNING OF EVERY SUBTEST. ALL THE NUMBERS GIVEN WITH ERROR MESSAGES ARE IN OCTAL.

12.0 HANDLERS AND COMMON ROUTINES

THE COMPOSED ROUTINES USED IN THE PROGRAM ARE CALLED IN TWO WAYS.

- A. AS A SUBROUTINE THROUGH 'JSR' CALL
- B. THROUGH A 'TRAP' HANDLER

12.1 TRAP HANDLER

MANY COMMONLY USED ROUTINES IN THE PROGRAM ARE CALLED USING THE TRAP INSTRUCTION AND THE 'TRAP' HANDLER. THE LOWER BYTE OF THE TRAP INSTRUCTION IS ENCODED DIFFERENTLY FOR DIFFERENT ROUTINES. THE TRAP HANDLER IS LOCATED AT '\$TRAP'. WHEN A CALL FOR A ROUTINE IS EXECUTED, A TRAP OCCURS TO THE HANDLER 'ARAP'. THE HANDLER PICKS UP THE LOWER BYTE OF THE "CALL INSTRUCTION" AND USES IT TO FORM THE STARTING ADDRESS OF THE ROUTINE TO GO TO FOR SERVICE.

12.2 SCOPE HANDLER

THE 'IOT' TRAP IS USED BY THE 'SCOPE' STATEMENT. WHEN 'SCOPE' IS EXECUTED, AN IOT TRAP OCCURS TO MEMORY LOCATION '\$SCOPE'. THE SCOPE HANDLER STARTS AT '\$SCOPE'. DEPENDING ON THE SWITCH SETTINGS THE HANDLER DECIDES TO LOOP ON TEXT, INHIBIT ITERATIONS ETC. THERE ARE CERTAIN POINTERS AND FLAGS WHICH ARE ADJUSTED. THUS, IT IS NOT ADVISABLE START THE PROGRAM AT ANY GIVEN LOCATION SINCE THE VARIOUS POINTERS AND FLAGS MAY NOT BE CORRECTLY ADJUSTED.

12.3 ERROR HANDLER

AN EMT TRAP INSTRUCTION IS USED BY THE ERROR CALL. THE LOWER BYTE IS ENCODED TO GIVE DIFFERENT ERROR CALLS. (EX: ERROR 1 = 104000+1; ERROR 16 = 104000+16). WHEN THE ERROR STATEMENT IS EXECUTED, A TRAP OCCURS TO MEMORY LOCATION '\$ERROR'. THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE HANDLER FORMS THE POINTER TO ERROR TABLE, WHICH IS USED IF AN ERROR MESSAGE IS TO BE TYPED DEPENDING ON THE SWITCH SETTINGS, A DECISION ABOUT HALTING ON ERROR, INHIBITING TYPEOUT, LOOPING ON ERROR ETC. IS MADE. IF AN ERROR MESSAGE IS TO BE TYPED OUT AN EXIT IS MADE TO THE ERROR MESSAGE TYPEOUT ROUTINE LOCATED AT '\$ERRTYP'.

12.4 CONTROL RESET ROUTINE

THE CALL FOR THIS ROUTINE IS "CNT.RESET" AND IS AN ENCODED 'TRAP' INSTRUCTION. WHEN "CNT.RESET" IS EXECUTED THE CONTROL RESET ROUTINE STARTING AT

"CN.RST" IS ENTERED. A CONTROL RESET IS ISSUED THE PROGRAM WAITS TILL THE CONTROL READY SETS, ON WHICH THE ROUTINE IS EXITED. IF CONTROL READY DOES NOT SET WITHIN A CERTAIN TIME AN ERROR IS REPORTED. THE PC TYPED OUT IS THE LOCATION WHERE THE "CNT.RESET" CALL IS LOCATED. THE WAITING TIME IS 2.8 MS FOR 11/20 AND 560 US FOR 11/45 WITH BIPOLAR MEMORY.

12.5 CONTROL READY ROUTINE

THIS ROUTINE IS CALLED BY "CNT.RDY" (AN ENCODED 'TRAP' INSTRUCTION) AND IS LOCATED AT "CN.RDY". THE ROUTINE WAITS FOR THE CONTROL READY TO SET AND WHEN IT DOES, EXITS IF CONTROL READY DOES NOT SET WITHIN A SPECIFIED TIME AN ERROR MESSAGE IS GIVEN

CNTRL RDY DIDN'T SET
PC = XXXXXX RKCS = YYYYYY

THE PC IS THE LOCATION AT WHICH THE "CNT.RDY" CALL IS LOCATED. THE WAITING TIME IS 949 MS FOR 11/20 AND 189 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.6 DRIVE RESET ROUTINE

THE DRIVE - RESET ROUTINE IS LOCATED AT "DRESET" AND IS CALLED BY A "JSR". IT ISSUES A DRIVE RESET AND WAITS FOR THE R/W/S RDY TO SET, ON WHICH THE ROUTINE IS EXITED. THE WAITING TIME IS 4959 MS FOR 11/20 AND 991 MS FOR 11/45 WITH BIPOLAR MEMORY.

12.7 TIME DELAY ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL IS DELAY ,N WHERE N=1 TO 177777 (OCTAL) TIME DELAY PROVIDED= 7.5 TIMES(X) N MICRO SECS FOR 11/20, 1.5N US FOR 11/45 (N CONVERTED TO DECIMAL BEFORE COMPUTING DELAY) IF THE USER WANTS TO CHANGE THE DELAY AT ANY POINT IT CAN BE DONE BY SIMPLY CHANGING VARIABLE 'N'.

12.8 WAIT FOR INTERRUPT ROUTINE

THIS ROUTINE PROVIDES A VARIABLE TIME LIMIT DURING WHICH RK11 INTERRUPT MAY OCCUR. THE IS WAT.INT .N N=1 TO 1777777 (OCTAL) WAITING TIME=7.5 TIMES(X) N US FOR 11/20, 1.5N US

FOR 11/45 UPON ENTERING THE ROUTINE CPU PRIORITY IS DROPPED SO THAT RK11 CAN INTERRUPT.

12.9 OTHER ROUTINES

THERE ARE OTHER COMMONLY USED ROUTINES AS LISTED BELOW.

\$TYPE:
ROUTINE FOR TYPING OUT ASCII STRINGS.
LOCATED AT "\$TYPE"
CALLED BY "TYPE"

\$TYPOC:
ROUTINE FOR TYPING OUT OCTAL NUMBERS.
LOCATED AT "\$TYPOC"
CALLED BY "TYPOC"

\$TYPDS:
ROUTINE FOR TYPING OUT DECIMAL NUMBERS.
LOCATED AT "\$TYPDS"
CALLED BY "TYPDS"

\$RDLIN:
ROUTINE FOR INPUTTING ASCII STRINGS FROM TTY.
LOCATED AT "\$RDLIN"
CALLED BY "RDLIN"

\$ERTYP:
ROUTINE FOR TYPING OUT ERROR MESSAGES.
LOCATED AT \$ERTYP
CALLED BY "JSR \$ERTYP"

\$PWRDN:
ROUTINE FOR HANDLING POWER FAILURE.
LOCATED AT \$PWRDN
CALLED WHEN THERE IS A POWER FAILURE.

\$PWRUP:
ROUTINE FOR HANDLING POWER UP AFTER A POWER FAIL.
LOCATED \$PWRUP
CALLED WHEN POWER RETURNS AFTER HAVING GONE DOWN.

13.0 UNEXPECTED TIMEOUTS AND RK11 INTERRUPTS

WHEN AN UNEXPECTED TIMEOUT OCCURS, THE PC AT WHICH TIME OUT OCCURED IS TYPED OUT AND THE PROGRAM HALTS. IF IT IS INTACT, IT CAN BE RESTARTED BY PRESSING CONTINUE.

IF AN UNEXPECTED RK11 INTERRUPT OCCURS THE PROGRAM TYPES OUT THE PC AT WHICH THE INTERRUPT CAME IN AND THEN HALTS. PRESSING CONTINUE WOULD RESTART THE PROGRAM FROM BEGINING. SW 9- LOOPING CAITY IS PROVIDED AS A TROUBLE SHOOTING AID.

14.0 QUICK VERIFYING MODE

THE FIRST PASS OF THE PROGRAM IS A QUICK VERIFYING MODE. ALL THE TESTS ARE DONE ONLY ONCE, ON SUBSEQUENT PASSES THE TESTS ARE ITERATED (NORMALLY 50 TIMES, 5 IN SOME CASES). THUS THE FIRST PASS TAKES A SHORTER TIME TO COMPLETE, WHEREAS SUBSEQUENT PASSES TAKE MORE TIME.

%

852
 853
 854
 855
 856
 857
 858
 859
 860
 861
 862
 863
 864
 865
 866
 867
 868
 869
 870
 871
 872
 873
 874
 875
 876
 877
 878
 879
 880
 881
 882
 883
 884
 885
 886
 887
 888
 889
 890
 891
 892
 893

```

.TITLE MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2
;*COPYRIGHT (C) 1974,1977
;*DIGITAL EQUIPMENT CORP.
;*MAYNARD, MASS. 01754
;*
;*PROGRAM BY JIM KAPADIA
;*
;*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
;*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
;*
;*PROGRAM REVISED BY TOM SAWYER, MARCH, 1976
;*REVISED BY CHUCK HESS, AUGUST, 1976
.SBTTL OPERATIONAL SWITCH SETTINGS
;*
;*          SWITCH          USE
;*          -----          -----
;*          15          HALT ON ERROR
;*          14          LOOP ON TEST
;*          13          INHIBIT ERROR TYPEOUTS
;*          12          CYCLE ON ERROR TO PREVIOUS 'SCOPE' STATEMENT
;*          11          INHIBIT ITERATIONS
;*          10          TESTING ON SIMULATOR
;*           9          LOOP ON ERROR
;*           8          LOOP ON TEST IN SWR<7:0>
;*           6          DROP THE DRIVE IF MORE THAN 5 ERRORS
    
```

```

;*****
;YOU ARE ADVISED TO READ THE DOCUMENT BEFORE USING THIS PROGRAM.
;ON GETTING AN ERROR REFER TO THE LISTINGS AT THE PC POINTED
    
```

```

894 ;OUT IN THE ERROR MESSAGE. ADJACENT ERROR MESSAGES IF FOLLOWED
895 ;CAREFULLY COULD LEAD TO AN EASY PINPOINTING OF THE FAULT
896
897 ;*****
898 .SBTTL BASIC DEFINITIONS
899
900 ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
901 STACK= 1100
902 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
903 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
904
905 ;*MISCELLANEOUS DEFINITIONS
906 HT= 11 ;;CODE FOR HORIZONTAL TAB
907 LF= 12 ;;CODE FOR LINE FEED
908 CR= 15 ;;CODE FOR CARRIAGE RETURN
909 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
910 PS= 177776 ;;PROCESSOR STATUS WORD
911 .EQUIV PS,PSW
912 STKLMT= 177774 ;;STACK LIMIT REGISTER
913 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
914 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
915 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
916
917 ;*GENERAL PURPOSE REGISTER DEFINITIONS
918 R0= %0 ;;GENERAL REGISTER
919 R1= %1 ;;GENERAL REGISTER
920 R2= %2 ;;GENERAL REGISTER
921 R3= %3 ;;GENERAL REGISTER
922 R4= %4 ;;GENERAL REGISTER
923 R5= %5 ;;GENERAL REGISTER
924 R6= %6 ;;GENERAL REGISTER
925 R7= %7 ;;GENERAL REGISTER
926 SP= %6 ;;STACK POINTER
927 PC= %7 ;;PROGRAM COUNTER
928
929 ;*PRIORITY LEVEL DEFINITIONS
930 PRO= 0 ;;PRIORITY LEVEL 0
931 PR1= 40 ;;PRIORITY LEVEL 1
932 PR2= 100 ;;PRIORITY LEVEL 2
933 PR3= 140 ;;PRIORITY LEVEL 3
934 PR4= 200 ;;PRIORITY LEVEL 4
935 PR5= 240 ;;PRIORITY LEVEL 5
936 PR6= 300 ;;PRIORITY LEVEL 6
937 PR7= 340 ;;PRIORITY LEVEL 7
938
939 ;*SWITCH REGISTER* SWITCH DEFINITIONS
940 SW15= 100000
941 SW14= 40000
942 SW13= 20000
943 SW12= 10000
944 SW11= 4000
945 SW10= 2000
946 SW09= 1000
947 SW08= 400
948 SW07= 200
949 SW06= 100

```

```

950 SW05= 40
951 SW04= 20
952 SW03= 10
953 SW02= 4
954 SW01= 2
955 SW00= 1
956 .EQUIV SW09,SW9
957 .EQUIV SW08,SW8
958 .EQUIV SW07,SW7
959 .EQUIV SW06,SW6
960 .EQUIV SW05,SW5
961 .EQUIV SW04,SW4
962 .EQUIV SW03,SW3
963 .EQUIV SW02,SW2
964 .EQUIV SW01,SW1
965 .EQUIV SW00,SW0
966
967 ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
968 BIT15= 100000
969 BIT14= 40000
970 BIT13= 20000
971 BIT12= 10000
972 BIT11= 4000
973 BIT10= 2000
974 BIT09= 1000
975 BIT08= 400
976 BIT07= 200
977 BIT06= 100
978 BIT05= 40
979 BIT04= 20
980 BIT03= 10
981 BIT02= 4
982 BIT01= 2
983 BIT00= 1
984 .EQUIV BIT09,BIT9
985 .EQUIV BIT08,BIT8
986 .EQUIV BIT07,BIT7
987 .EQUIV BIT06,BIT6
988 .EQUIV BIT05,BIT5
989 .EQUIV BIT04,BIT4
990 .EQUIV BIT03,BIT3
991 .EQUIV BIT02,BIT2
992 .EQUIV BIT01,BIT1
993 .EQUIV BIT00,BIT0
994
995 ;*BASIC "CPU" TRAP VECTOR ADDRESSES
996 ERRVEC= 4 ;;TIME OUT AND OTHER ERRORS
997 RESVEC= 10 ;;RESERVED AND ILLEGAL INSTRUCTIONS
998 TBITVEC= 14 ;; "T" BIT
999 TRTVEC= 14 ;;TRACE TRAP
1000 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
1001 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
1002 PWRVEC= 24 ;;POWER FAIL
1003 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
1004 TRAPVEC= 34 ;; "TRAP" TRAP
1005 TKVEC= 60 ;;TTY KEYBOARD VECTOR

```

1006 000064
1007 000240
1008
1009
1010 000000
1011
1012
1013
1014 000174
1015 000174 000000
1016 000175 000000
1017
1018 000200 000137 002636
1019
1020
1021
1022
1023 000204
1024 000046
1025 000046 020740
1026 000052
1027 000052 000000
1028 000204

TPVEC= 64 ;:TTY PRINTER VECTOR
PIROVEC=240 ;:PROGRAM INTERRUPT REQUEST VECTOR
.SBTTL TRAP CATCHER
.
.=0
;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
.
.=174
DISPREG: .WORD 0 ;:SOFTWARE DISPLAY REGISTER
SWREG: .WORD 0 ;:SOFTWARE SWITCH REGISTER
.SBTTL STARTING ADDRESS(ES)
JMP @#START ;:JUMP TO STARTING ADDRESS OF PROGRAM
.SBTTL ACT11 HODKS
;:*****
;HOOKS REQUIRED BY ACT11
\$SVPC=. ;:SAVE PC
.=46
\$ENDAD ;:1)SET LOC.46 TO ADDRESS OF SENDAD IN .\$EOP
.=52
;:2)SET LOC.52 TO ZERO
.WORD 0 ;: RESTORE PC
.=\$SVPC ;: RESTORE PC

1029
1030
1031
1032
1033
1034
1035 001100
1036 001100
1037 001100 000000
1038 001102 000
1039 001103 000
1040 001104 000000
1041 001106 000000
1042 001110 000000
1043 001112 000000
1044 001114 000
1045 001115 001
1046 001116 000000
1047 001120 000000
1048 001122 000000
1049 001124 000000
1050 001126 000000
1051 001130 000000
1052 001132 000000
1053 001134 000
1054 001135 000
1055 001136 000000
1056 001140 177570
1057 001142 177570
1058 001144 177560
1059 001146 177562
1060 001150 177564
1061 001152 177566
1062 001154 000
1063 001155 002
1064 001156 012
1065 001157 000
1066 001160 000000
1067
1068 001162 000000
1069 001164 000000
1070 001166 000000
1071 001170 000000
1072 001172 000000
1073 001174 000000
1074 001176 000000
1075 001200 000000
1076 001202 000000
1077 001204 000000
1078 001206 000000
1079 001210 000000
1080 001212 077
1081 001213 015
1082 001214 000012
1083
1084 001216 005015 051104 053111

.SBTTL COMMON TAGS
;:*****
;THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
;USED IN THE PROGRAM.
.
.=1100
\$CMTAG: ;:START OF COMMON TAGS
\$PASS: .WORD 0 ;:CONTAINS PASS COUNT
\$STNM: .BYTE 0 ;:CONTAINS THE TEST NUMBER
\$ERFLG: .BYTE 0 ;:CONTAINS ERROR FLAG
\$ICNT: .WORD 0 ;:CONTAINS SUBTEST ITERATION COUNT
\$LPADR: .WORD 0 ;:CONTAINS SCOPE LOOP ADDRESS
\$LPERR: .WORD 0 ;:CONTAINS SCOPE RETURN FOR ERRORS
\$ERTTL: .WORD 0 ;:CONTAINS TOTAL ERRORS DETECTED
\$ITEMB: .BYTE 0 ;:CONTAINS ITEM CONTROL BYTE
\$ERMAX: .BYTE 1 ;:CONTAINS MAX. ERRORS PER TEST
\$ERRPC: .WORD 0 ;:CONTAINS PC OF LAST ERROR INSTRUCTION
\$GDADR: .WORD 0 ;:CONTAINS ADDRESS OF 'GOOD' DATA
\$BDADR: .WORD 0 ;:CONTAINS ADDRESS OF 'BAD' DATA
\$GDADR: .WORD 0 ;:CONTAINS 'GOOD' DATA
\$BDADR: .WORD 0 ;:CONTAINS 'BAD' DATA
\$RESV: .WORD 0 ;:RESERVED--NOT TO BE USED
\$AUTOB: .BYTE 0 ;:AUTOMATIC MODE INDICATOR
\$INTAG: .BYTE 0 ;:INTERRUPT MODE INDICATOR
.
\$SWR: .WORD DSWR ;:ADDRESS OF SWITCH REGISTER
\$DISPLAY: .WORD DDISP ;:ADDRESS OF DISPLAY REGISTER
\$TKS: 177560 ;:TTY KBD STATUS
\$TKB: 177562 ;:TTY KBD BUFFER
\$TPS: 177564 ;:TTY PRINTER STATUS REG. ADDRESS
\$TPB: 177566 ;:TTY PRINTER BUFFER REG. ADDRESS
\$NULL: .BYTE 0 ;:CONTAINS NULL CHARACTER FOR FILLS
\$FILLS: .BYTE 2 ;:CONTAINS # OF FILLER CHARACTERS REQUIRED
\$FILLC: .BYTE 12 ;:INSERT FILL CHARS. AFTER A "LINE FEED"
\$TPFLG: .BYTE 0 ;:"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)
\$REGAD: .WORD 0 ;:CONTAINS THE ADDRESS FROM
;WHICH (\$REG0) WAS OBTAINED
\$REG0: .WORD 0 ;:CONTAINS ((\$REGAD)+0)
\$REG1: .WORD 0 ;:CONTAINS ((\$REGAD)+2)
\$REG2: .WORD 0 ;:CONTAINS ((\$REGAD)+4)
\$REG3: .WORD 0 ;:CONTAINS ((\$REGAD)+6)
\$REG4: .WORD 0 ;:CONTAINS ((\$REGAD)+10)
\$REG5: .WORD 0 ;:CONTAINS ((\$REGAD)+12)
\$REG6: .WORD 0 ;:CONTAINS ((\$REGAD)+14)
\$REG7: .WORD 0 ;:CONTAINS ((\$REGAD)+16)
\$REG10: .WORD 0 ;:CONTAINS ((\$REGAD)+20)
\$REG11: .WORD 0 ;:CONTAINS ((\$REGAD)+22)
\$TIMES: 0 ;:MAX. NUMBER OF ITERATIONS
\$ESCAPE: 0 ;:ESCAPE ON ERROR ADDRESS
\$QUES: .ASCII /?/ ;:QUESTION MARK
\$CRLF: .ASCII <15> ;:CARRIAGE RETURN
\$LF: .ASCII <12> ;:LINE FEED
;:*****
MSG1: .ASCII <15><12>/DRIVE PRESENT/

```

1085 001224 020105 051120 051505
1086 001232 052116 000
1087 001236 001236 .EVEN
1088 001236 005015 047516 042516 MSG2: .ASCIZ <15><12>/NONE/
1089 001244 000
1090
1091 001245 015 041412 052116 MSG3: .ASCIZ <15><12>/CNT RDY DIDN'T SET/
1092 001252 051040 054504 042040
1093 001260 042111 023516 020124
1094 001266 042523 000124
1095
1096 001272 005015 051104 053111 MSG4: .ASCIZ <15><12>/DRIVE /
1097 001300 020105 000
1098
1099 001303 015 040412 046114 MSG5: .ASCII <15><12>/ALL DRVS/
1100 001310 042040 053122 123
1101
1102 001315 040 051104 050117 MSG6: .ASCIZ / DROPPD/<15><12>
1103 001322 006504 000012
1104 .EVEN
1105
1106 ;RK11 REGISTERS
1107 ;IF FOR ANY REASON THE REGISTER ADDRESSES ARE DIFFERENT FROM THESE
1108 ;(GIVEN BELOW), THE CONTENTS OF THE APPROPRIATE POINTERS SHOULD BE
1109 ;MODIFIED SO THAT THE CORRECT ADDRESS IS USED.
1110 ;
1111 .EVEN
1112 001326 177400 RKDS: 177400
1113 001330 177402 RKER: 177402
1114 001332 177404 RKCS: 177404
1115 001334 177406 RKWC: 177406
1116 001336 177410 RKBA: 177410
1117 001340 177412 RKDA: 177412
1118 001342 177416 RKDB: 177416
1119
1120
1121 ;TAGS AND GENERAL DATA AREA
1122 ;
1123 ;
1124
1125 001344 000000 SIMUL: 0 ;FLAG TO BE SET TO 1 WHEN ON SIMULATOR
1126 001346 000000 FTITLE: 0 ;FLAG FOR PRINTING PROGRAM TITLE
1127 001350 000000 DRIVAD: 0 ;CONTAINS ADDRESS OF THE DRIVE UNDER TEST
1128 001352 000000 DRVDON: 0 ;CONTAINS THE NUMBER OF DRIVES CHECKED.
1129 ;IT IS INCREMENTED EACH TIME THE TESTS FOR
1130 ;A DRIVE IS COMPLETED.
1131 001354 000000 DRVPTR: 0 ;CONTAINS THE POINTER TO THE DRIVE FLAG (DRIVE0
1132 ;DRIVE7) OF THE DRIVE TO BE CHECKED NEXT.
1133 001356 000000 INDX1: 0 ;GENERAL INDEX FOR KEEPING COUNT
1134 001360 000000 INDX2: 0 ;GENERAL INDEX
1135 001362 000000 COUNT: 0 ;GENERAL COUNT REGISTER
1136 001364 000000 COUNT1: 0 ;COUNT REGISTER USED FOR 'DRESET' SUBROUTINE
1137 001366 000000 TIMER: 0 ;TIMER REGISTER
1138 001370 000000 EFLG1: 0 ;SET, TO INDICATE A PARTICULAR
1139 ;ERROR CONDITION
1140

```

```

1141 001372 000100 SEEK0: 100 ;CONTAINS ADDRESS OF CYLINDER 2
1142 001374 001000 SEEK1: 1000 ;CONTAINS ADDRESS OF CYLINDER 20
1143 001376 014500 SEEK2: 14500 ;CONTAINS ADDRESS OF CYLINDER 312
1144 001400 000200 RKPRI: 200 ;CONTAINS THE CPU LEVEL AT WHICH
1145 ;RK11 NORMALLY INTERRUPTS. THIS WORD
1146 ;SHOULD BE CHANGED IF RK11 IS DESINGATED
1147 ;A BR LEVEL OTHER THAN 5. E.G. IF IT IS CHANGED
1148 ;TO 6, THIS WORD SHOULD BE CHANGED TO 240.
1149 001402 000220 RKVEC: 220 ;CONTAINS THE NORMAL VECTOR ADDRESS TO WHICH
1150 ;RK11 INTERRUPTS. IF THIS IS NOT SO, CHANGE
1151 ;THIS WORD TO CONTAIN MODIFIED VECTOR ADDRESS.
1152 001404 000000 FFLAG: 0
1153 001406 000000 ODDEVN: 0 ;USED TO DETERMINE WHICH OF RK-05F DRIVES ACTIVE
1154 ;0 IF EVEN DRIVE
1155 ;-1 IF ODD DRIVE
1156 001410 000000 DDPCH: 0 ;IF PROGRAM LOADED FROM RK05, CONTAINS
1157 ;ADDRESS OF DRIVE WITH RKDP PACK
1158 001412 000000 DRVS: 0 ;CONTAINS THE NUMBER OF DRIVES PRESENT
1159
1160
1161
1162
1163 ;THE FLAGS BELOW (BIT 0) ARE SET TO 1 TO INDICATE THAT A PARTICULAR DRIVE
1164 ;IS PRESENT AND IS TO BE TESTED. BIT 12, IF SET, INDICATES THAT THE DRIVE
1165 ;WAS DROPPED AFTER MAXIMUM ALLOWABLE NUMBER OF ERRORS OCCURED ON THAT
1166 ;DRIVE (SW 6 SET).
1167 ;IF MORE THAN 5 ERRORS OCCUR IN THE HARDWARE POLLING TEST (LAST)
1168 ;THEN ALL DRIVES ARE DROPPED. BUT BIT 12 IS NOT SET.
1169
1170 001414 000000 DRIV0: 0 ;FLAG SET TO 1 WHEN DRIVE 0 PRESENT
1171 001416 000000 DRIV1: 0 ;FOR DRIVE 1
1172 001420 000000 DRIV2: 0 ;FOR DRIVE 2
1173 001422 000000 DRIV3: 0 ;FOR DRIVE 3
1174 001424 000000 DRIV4: 0 ;FOR DRIVE 4
1175 001426 000000 DRIV5: 0 ;FOR DRIVE 5
1176 001430 000000 DRIV6: 0 ;FOR DRIVE 6
1177 001432 000000 DRIV7: 0 ;FOR DRIVE 7
1178
1179 001434 000000 T56FLG: 0
1180 001436 000000 PHYDRV: 0
1181 001440 000000 SIZYET: 0

```

1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237

001442

.SBTTL ERROR POINTER TABLE
:*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
:*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
:*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
:*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
:*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
:* EM ::POINTS TO THE ERROR MESSAGE
:* DH ::POINTS TO THE DATA HEADER
:* DT ::POINTS TO THE DATA
:* DF ::POINTS TO THE DATA FORMAT

\$ERRTB:

;THE ERROR ITEMS TABLE CONSISTS OF ALL THE POSSIBLE ERROR MESSAGES
;USED IN THIS PROGRAM. AN ERROR CALL IN THE PROGRAM CORRESPONDS TO
;THE ITEM NUMBER IN THE ERROR TABLE. THUS 'ERROR 1' IN THE
;PROGRAM CORRESPONDS TO 'ITEM 1' IN THE ERROR TABLE.
;'EM###' IS THE POINTER TO THE ERROR MESSAGE WHICH WILL BE TYPED
;OUT IN CASE THAT ERROR WERE TO OCCUR. THUS FOR 'ERROR 1' THE ERROR
;MESSAGE TYPE OUT WILL BE 'TIME OUT ON RK11 REG'.
;'DH###' IS THE POINTER TO THE HEADER BLOCK WHICH WILL BE TYPED OUT
;IMMEDIATELY AFTER THE ERROR MESSAGE.
;'DT###' SERVES AS A POINTER TO THE MEMORY LOCATIONS WHERE
;THE INFORMATION RELEVANT TO THE ERROR TYPE OUTS (LIKE PC, CONTENTS
;OF RKCS ETC.) WILL BE PICKED UP FROM.
;THE LAST ROW CONTAINING '0' SERVES AS A TERMINATOR.
;EXAMPLE:
;IF ON RUNNING THIS PROGRAM A TIMEOUT WERE TO OCCUR ON ADDRESSING RKDS
;(177400), BECAUSE OF SOME FAULT, THE FOLLOING TYPEOUT WOULD
;OCCUR ON THE TELETYPE.
;
; TIME OUT ON RK11 REG
; PC REG
; ##### 177400
;NOTE THAT ##### WOULD BE THE ACTUAL PC WHERE 'ERROR 1' IS LOCATED.
;
;THE ERROR HANDLER IS LOCATED AT '\$ERROR'. THE ERROR CALL IS AN 'EMT'
;INSTRUCTION WITH ITS LOWER BYTE ENCODED TO PROVIDE INDEXING TO THE
;ITEMS IN THE ERROR TABLE.
;THUS 'ERROR 1' IS 104001
; 'ERROR 103' IS 104126 ETC.

;ERROR ITEMS TABLE

1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293

001442 025402
001444 032327
001446 031742
001450 000000

001452 027253
001454 032113
001456 031762
001460 000000

001462 025427
001464 032047
001466 031732
001470 000000

001472 025456
001474 032213
001476 031724
001500 000000

001502 025470
001504 032155
001506 031762
001510 000000

001512 025500
001514 032155
001516 031762
001520 000000

001522 025510
001524 032213
001526 031724
001530 000000

001532 025531
001534 032327
001536 031742
001540 000000

;ITEM 1
EM12 ;'SIN' IS SET
DH44 ;PC RKCS RKER RKDS RKDA
DT20 ;\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
0

;ITEM 2
EM70 ;CNTRL RDY DIDN'T SET ON READ/FMT FROM DISK ADDRESS
DH14 ;PC RKCS RKER RKWC
DT26 ;\$ERRPC \$REG0 \$REG1 \$REG2
0

;ITEM 3
EM16 ;RKDA WRONG AFTER SSE
DH4 ;PC EXPT RECVD
DT2 ;\$ERRPC \$REG0 \$REG1
0

;ITEM 4
EM21 ;RKDS ERROR
DH34 ;PC RKDS
DT1 ;\$ERRPC \$REG0
0

;ITEM 5
EM30 ;'DPL' BIT SET, CHECK DRIVE POWER
DH30 ;PC RKCS RKER RKDS
DT26 ;\$ERRPC \$REG0 \$REG1 \$REG2
0

;ITEM 6
EM31 ;'DRU' BIT SET, CHECK DRIVE
DH30 ;PC RKCS RKER RKDS
DT26 ;\$ERRPC \$REG0 \$REG1 \$REG2
0

;ITEM 7
EM32 ;'RK05' BIT NOT SET
DH34 ;PC RKDS
DT1 ;\$ERRPC \$REG0
0

;ITEM 10
EM33 ;'DRY' NOT SET
DH44 ;PC RKCS RKER RKDS RKDA
DT20 ;\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
0

1294			;ITEM	11	
1295					
1296	001542	025551	EM34		;'SOK' DID NOT SET
1297	001544	032213	DH34		;'PC RKDS
1298	001546	031724	DT1		;'\$ERRPC \$REG0
1299	001550	000000	0		
1300					
1301			;ITEM	12	
1302					
1303	001552	025570	EM35		;'SEC COUNTR' DIDN'T COUNT TO 0
1304	001554	032231	DH35		;'PC SEC-CNTR
1305	001556	031724	DT1		;'\$ERRPC \$REG0
1306	001560	000000	0		
1307					
1308			;ITEM	13	
1309					
1310	001562	025623	EM36		;'SEC COUNTR' DIDN'T INCREMENT
1311	001564	032251	DH36		;'PC PRSNT-COUNT NXT-COUNT
1312	001566	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1313	001570	000000	0		
1314					
1315			;ITEM	14	
1316					
1317	001572	025653	EM37		;'SECTOR COUNTER' INCREMENTED WRONG
1318	001574	032047	DH4		;'PC EXPCTD RECVD
1319	001576	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1320	001600	000000	0		
1321					
1322			;ITEM	15	
1323					
1324	001602	025707	EM40		;'DIDN'T GET SC=SA FOR THIS SECTOR
1325	001604	032301	DH40		;'PC SECTOR RKDS
1326	001606	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1327	001610	000000	0		
1328					
1329			;ITEM	16	
1330					
1331	001612	025747	EM41		;'ERROR-'R/W/S RDY' SHOULD BE SET
1332	001614	032213	DH34		;'PC RKDS
1333	001616	031724	DT1		;'\$ERRPC \$REG0
1334	001620	000000	0		
1335					
1336			;ITEM	17	
1337					
1338	001622	025415	EM13		;'RKBA ERROR
1339	001624	032047	DH4		;'PC EXPCT RECVD
1340	001626	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1341	001630	000000	0		
1342					
1343			;ITEM	20	
1344					
1345	001632	026004	EM43		;'UNEXPECTED RK11 INTERRUPT
1346	001634	032150	DH21		;'PC
1347	001636	031756	DT21		;'\$ERRPC
1348	001640	000000	0		
1349					

1350			;ITEM	21	
1351					
1352	001642	026036	EM44		;'CNTRL RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1353	001644	032327	DH44		;'PC RKCS RKER RKDS RKDA
1354	001646	031742	DT20		;'\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1355	001650	000000	0		
1356					
1357			;ITEM	22	
1358					
1359	001652	026112	EM45		;'ERR' OR 'HE' SET ON SEEK OR DRIVE RESET
1360	001654	032327	DH44		;'PC RKCS RKER RKDS RKDA
1361	001656	031742	DT20		;'\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1362	001660	000000	0		
1363					
1364			;ITEM	23	
1365					
1366	001662	026160	EM46		;'RKER BIT, ON SEEK OR DRIVE RESET
1367	001664	032155	DH30		;'PC RKCS RKER RKDS
1368	001666	031762	DT26		;'\$ERRPC \$REG0 \$REG1 \$REG2
1369	001670	000000	0		
1370					
1371			;ITEM	24	
1372					
1373	001672	026216	EM47		;'RKCS CHANGED AFTER FUNCTION WAS DONE
1374	001674	032047	DH4		;'PC EXPCT RECVD
1375	001676	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1376	001700	000000	0		
1377					
1378			;ITEM	25	
1379					
1380	001702	026260	EM50		;'R/W/S RDY' DID NOT CLEAR
1381	001704	032155	DH30		;'PC RKCS RKER RKDS
1382	001706	031762	DT26		;'\$ERRPC \$REG0 \$REG1 \$REG2
1383	001710	000000	0		
1384					
1385			;ITEM	26	
1386					
1387	001712	026307	EM51		;'R/W/S RDY' DIDN'T SET AFTER SEEK OR DRIVE RESET
1388	001714	032327	DH44		;'PC RKCS RKER RKDS RKDA
1389	001716	031742	DT20		;'\$ERRPC \$REG0 \$REG1 \$REG2 \$REG3
1390	001720	000000	0		
1391					
1392			;ITEM	27	
1393					
1394	001722	026362	EM52		;'RKDA CHANGED AFTER SEEK
1395	001724	032047	DH4		;'PC EXPCT REGVD
1396	001726	031732	DT2		;'\$ERRPC \$REG0 \$REG1
1397	001730	000000	0		
1398					
1399			;ITEM	30	
1400					
1401	001732	026407	EM53		;'CNTRL RDY' DIDN'T CLEAR AS GO WAS SET
1402	001734	032155	DH30		;'PC RKCS RKER RKDS
1403	001736	031762	DT26		;'\$ERRPC \$REG0 \$REG1 \$REG2
1404	001740	000000	0		
1405					

```
1406 ;ITEM 31
1407 EM54 ;'CNTRL RDY' DIDN'T SET ON DOING WRITE/FMT STARTING
1408 001742 026452 ; FROM <DSK-ADRES>
1409 DH54 ;PC RKCS RKER RKDS RKDA
1410 001744 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1411 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1412 001746 031774 ;$REG4 $REG5 $REG6 $REG7
1413 0
1414 001750 000000
1415 ;ITEM 32
1416 EM55 ;'HE' OR 'ERR' ON WRITE/FMT STARTING FROM
1417 ;<DSK-ADRES>
1418 001752 026544 ;PC RKCS RKER RKDS RKDA
1419 001754 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1420 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1421 001756 031774 ;$REG4 $REG5 $REG6 $REG7
1422 001760 000000
1423 0
1424 ;ITEM 33
1425 EM56 ;RKDA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1426 DH56 ;PC EXPCT: DRV# CYL SUR SECTR
1427 001762 026623 ;RECVD: DRV# CYL SUR SECTR
1428 001764 032503 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1429 DT54 ;$REG4 $REG5 $REG6 $REG7
1430 001766 031774
1431 0
1432 ;ITEM 34
1433 EM57 ;RKWC DIDN'T OVERFLOW ON WRITE OR WRITE FORMAT
1434 DH5 ;PC RECVD
1435 001772 026662 DT1 ;$ERRPC $REG0
1436 001774 032075
1437 001776 031724
1438 002000 000000
1439 ;ITEM 35
1440 EM60 ;RKBA INCREMENTED WRONG ON WRITE OR WRITE FORMAT
1441 DH4 ;PC EXPCT RECVD
1442 002002 026720 DT2 ;$ERRPC $REG0 $REG1
1443 002004 032047
1444 002006 031732
1445 002010 000000
1446 ;ITEM 36
1447 EM61 ;RKER SET. ON WRITE/READ/FORMAT
1448 DH30 ;PC RKCS RKER RKDS
1449 002012 026757 DT26 ;$ERRPC $REG0 $REG1 $REG2
1450 002014 032155
1451 002016 031762
1452 002020 000000
1453 ;ITEM 37
1454 EM62 ;RKDB ERROR
1455 DH4 ;PC EXPCT RECVD
1456 002022 027014 DT2 ;$ERRPC $REG0 $REG1
1457 002024 032047
1458 002026 031732
1459 002030 000000
```

```
1462 ;ITEM 40
1463 EM63 ;RKDA INCREMENTED WRONG ON READ OR READ FORMAT
1464 002032 027026 DH56 ;PC EXPCT: DRV# CYL SUR SECTR
1465 002034 032503 ;RECVD: DRV# CYL SUR SECTR
1466 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1467 002036 031774 ;$REG4 $REG5 $REG6 $REG7
1468 0
1469 ;ITEM 41
1470 EM64 ;RKWC DID NOT OVERFLOW ON READ OR READ FORMAT
1471 DH64 ;PC RKWC RKDA
1472 002042 027072 DT2 ;$ERRPC $REG0 $REG1
1473 002044 032610
1474 002046 031732
1475 002050 000000
1476 ;ITEM 42
1477 EM65 ;RKBA INCREMENTED WRONG ON READ OR READ FORMAT
1478 DH4 ;PC EXPCT RECVD
1479 002052 027135 DT2 ;$ERRPC $REG0 $REG1
1480 002054 032047
1481 002056 031732
1482 002060 000000
1483 ;ITEM 43
1484 EM66 ;INCORRECT HEADER FROM 'SECTOR'
1485 DH66 ;PC SECTR EXPCT RECVD
1486 002062 027201 DT26 ;$ERRPC $REG0 $REG1 $REG2.
1487 002064 032634
1488 002066 031762
1489 002070 000000
1490 ;ITEM 44
1491 EM67 ;DATA ERROR
1492 DH67 ;PC EXPCT RECVD DSK-ADRES
1493 002072 027240 DT26 ;$ERRPC $REG0 $REG1 $REG2
1494 002074 032672
1495 002076 031762
1496 002100 000000
1497 ;ITEM 45
1498 EM70 ;'CNTRL RDY' DIDN'T SET ON DOING READ/FMT STARTING
1499 DH54 ; FROM <DSK-ADRES>
1500 002102 027253 ;PC RKCS RKER RKDS RKDA
1501 002104 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1502 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1503 002106 031774 ;$REG4 $REG5 $REG6 $REG7
1504 0
1505 ;ITEM 46
1506 EM71 ;'HE' OR 'ERR' BIT SET ON READ/FMT STARTING
1507 DH54 ; FROM <DSK-ADRES>
1508 002112 027344 ;PC RKCS RKER RKDS RKDA
1509 002114 032374 ;DRV# CYL <DSK-ADRES> SUR SECTR
1510 DT54 ;$ERRPC $REG0 $REG1 $REG2 $REG3
1511 002116 031774 ;$REG4 $REG5 $REG6 $REG7
1512
```

1518	002120	000000							0
1519									
1520									
1521									
1522	002122	027422		EM72					;WRONG DRIVE ID IN RKDS AFTER SEEK
1523	002124	032047		DH4					;PC EXPCT RECVD
1524	002126	031732		DT2					;SERRPC \$REG0 \$REG1
1525	002130	000000							0
1526									
1527									
1528									
1529	002132	027464		EM73					;HARDWARE POLL, DRIVE ID BITS(13-15) SHOULD BE CLEAR
1530	002134	032213		DH34					;PC RKDS
1531	002136	031732		DT2					;SERRPC \$REG0
1532	002140	000000							0
1533									
1534									
1535									
1536	002142	027536		EM74					;HARDWARE POLL, INTERRUPTING DRIVE # NOT PRESENT
1537	002144	032732		DH74					;PC DRIVE #
1538	002146	031724		DT1					;SERRPC \$REG0
1539	002150	000000							0
1540									
1541									
1542									
1543	002152	027606		EM75					;DRIVE # DID NOT INTERRUPT DURING HARDWARE POLL
1544	002154	032732		DH74					;PC DRIVE #
1545	002156	031724		DT1					;SERRPC \$REG0
1546	002160	000000							0
1547									
1548									
1549									
1550	002162	027656		EM76					;SCP DID NOT SET AFTER WAS DONE
1551	002164	033106		DH117					;PC RKCS
1552	002166	031724		DT1					;SERRPC \$REG0
1553	002170	000000							0
1554									
1555									
1556									
1557	002172	027721		EM77					;RKDA CHANGED AFTER DRIVE RESET
1558	002174	032047		DH4					;PC EXPCT RECVD
1559	002176	031732		DT2					;SERRPC \$REG0 \$REG1
1560	002200	000000							0
1561									
1562									
1563									
1564	002202	027756		EM100					;DATA ERROR AT WORD#
1565	002204	032753		DH100					;PC WORD# EXPCT RECVD
1566	002206	031762		DT26					;SERRPC \$REG0 \$REG1 \$REG2
1567	002210	000000							0
1568									
1569									
1570									
1571	002212	030001		EM101					;CNTRL RDY DID NOT SET AFTER READ CHECK
1572	002214	032327		DH44					;PC RKCS RKER RKDS RKDA
1573	002216	031742		DT20					;SERRPC \$REG0 \$REG1 \$REG2 \$REG3

1574	002220	000000							0
1575									
1576									
1577									
1578	002222	030043		EM102					;ERR' OF 'HE' SET ON READ CHECK
1579	002224	032155		DH30					;PC RKCS RKER RKDS
1580	002226	031762		DT26					;SERRPC \$REG0 \$REG1 \$REG2
1581	002230	000000							0
1582									
1583									
1584									
1585	002232	030067		EM103					;CSE' ON READ CHECK
1586	002234	033010		DH103					;PC RKER
1587	002236	031724		DT1					;SERRPC \$REG0
1588	002240	000000							0
1589									
1590									
1591									
1592	002242	030105		EM104					;RKWC DID NOT OVERFLOW ON READ CHECK OR WRITE CHECK
1593	002244	033024		DH104					;PC RECVD RKCS
1594	002246	031732		DT2					;SERRPC \$REG0 \$REG1
1595	002250	000000							0
1596									
1597									
1598									
1599	002252	030156		EM105					;RKDA INCREMENTED WRONG ON READ CHECK
1600	002254	032047		DH4					;PC EXPCT RECVD
1601	002256	031732		DT2					;SERRPC \$REG0 \$REG1
1602	002260	000000							0
1603									
1604									
1605									
1606	002262	030214		EM106					;RKBA CHANGED AFTER READ CHECK
1607	002264	032047		DH4					;PC EXPCT RECVD
1608	002266	031732		DT2					;SERRPC \$REG0 \$REG1
1609	002270	000000							0
1610									
1611									
1612									
1613	002272	030245		EM107					;MEMORY WORD CHANGED AFTER READ CHECK
1614	002274	033050		DH107					;PC LOC EXPCT RECVD
1615	002276	031762		DT26					;SERRPC \$REG0 \$REG1 \$REG2
1616	002300	000000							0
1617									
1618									
1619									
1620	002302	030306		EM110					;CNTRL RDY DID NOT SET AFTER WRITE CHECK
1621	002304	032327		DH44					;PC RKCS RKER RKDS RKDA
1622	002306	031742		DT20					;SERRPC \$REG0 \$REG1 \$REG2 \$REG3
1623	002310	000000							0
1624									
1625									
1626									
1627	002312	030351		EM111					;HE OR ERR BIT SET AFTER DOING WRITE CHECK
1628	002314	032155		DH30					;PC RKCS RKER RKDS
1629	002316	031762		DT26					;SERRPC \$REG0 \$REG1 \$REG2

1630	002320	000000		0
1631				
1632			:ITEM	67
1633				
1634	002322	030376	EM112	:WRITE CHECK ERROR
1635	002324	032155	DH30	:PC RKCS RKER RKDS
1636	002326	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1637	002330	000000		0
1638				
1639			:ITEM	70
1640				
1641	002332	030417	EM113	:RKDA INCREMENTED WRONG ON WRITE CHECK
1642	002334	032047	DH4	:PC EXPCT RECVD
1643	002336	031732	DT2	;\$ERRPC \$REGO \$REG1
1644	002340	000000		0
1645				
1646			:ITEM	71
1647				
1648	002342	030456	EM114	:RKBA INCREMENTED WRONG ON WRITE CHECK
1649	002344	032047	DH4	:PC EXPCT RECVD
1650	002346	031732	DT2	;\$ERRPC \$REGO \$REG1
1651	002350	000000		0
1652				
1653			:ITEM	72
1654				
1655	002352	030515	EM115	:RKBA INCREMENTED WITH IBA SET
1656	002354	032047	DH4	:PC EXPCT RECVD
1657	002356	031732	DT2	;\$ERRPC \$REGO \$REG1
1658	002360	000000		0
1659				
1660			:ITEM	73
1661				
1662	002362	030551	EM116	:WRONG MEMORY LOCATION CHANGED WITH IBA SET
1663	002364	032753	DH100	:PC WORD# EXPCT RECVD
1664	002365	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1665	002370	000000		0
1666				
1667			:ITEM	74
1668				
1669	002372	030624	EM117	:RK11 DID NOT INTERRUPT WHEN IDE WAS SET
1670	002374	033106	DH117	:PC RKCS
1671	002376	031724	DT1	;\$ERRPC \$REGO
1672	002400	000000		0
1673				
1674			:ITEM	75
1675				
1676	002402	030671	EM120	:RK11 DID NOT INTERRUPT AFTER SEEK WAS INITIATED
1677	002404	033106	DH117	:PC RKCS
1678	002406	031724	DT1	;\$ERRPC \$REGO
1679	002410	000000		0
1680				
1681			:ITEM	76
1682				
1683	002412	030744	EM121	:SCP SET BEFORE SEEK COMPLETED
1684	002414	033106	DH117	:PC RKCS
1685	002416	031724	DT1	;\$ERRPC \$REGO

1686	002420	000000		0
1687				
1688			:ITEM	77
1689				
1690	002422	031002	EM122	:RK11 DID NOT INTERRUPT AFTER SEEK COMPLETED
1691	002424	032155	DH30	:PC RKCS RKER RKDS
1692	002426	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1693	002430	000000		0
1694				
1695			:ITEM	100
1696				
1697	002432	031051	EM123	:CNTRL RESET DID NOT CLEAR 'SCP' BIT
1698	002434	033106	DH117	:PC RKCS
1699	002436	031724	DT1	;\$ERRPC \$REGO
1700	002440	000000		0
1701				
1702			:ITEM	101
1703				
1704	002442	031110	EM124	:RK11 DID NOT INTERRUPT AFTER READ WAS DONE
1705	002444	033106	DH117	:PC RKCS
1706	002446	031724	DT1	;\$ERRPC \$REGO
1707	002450	000000		0
1708				
1709			:ITEM	102
1710				
1711	002452	031152	EM125	:CNTRL RESET DID NOT CLEAR REGISTER
1712	002454	032020	DH2	:PC REGADD RECVD
1713	002456	031732	DT2	;\$ERRPC \$REGO \$REG1
1714	002460	000000		0
1715				
1716			:ITEM	103
1717				
1718	002462	031211	EM126	:RK11 DID NOT INTERRUPT AT CPU LEVEL
1719	002464	033122	DH126	:PC LEVEL RKCS
1720	002466	031732	DT2	;\$ERRPC \$REGO \$REG1
1721	002470	000000		0
1722				
1723			:ITEM	104
1724				
1725	002472	031252	EM127	:RK11 INTERRUPTED AT WRONG CPU LEVEL
1726	002474	033122	DH126	:PC LEVEL RKCS
1727	002476	031732	DT2	;\$ERRPC \$REGO \$REG1
1728	002500	000000		0
1729				
1730			:ITEM	105
1731				
1732	002502	031314	EM130	: 'ERR BIT' DID NOT SET IN RKER
1733	002504	033150	DH130	:PC RKCS RKER ERR BIT
1734	002506	031762	DT26	;\$ERRPC \$REGO \$REG1 \$REG2
1735	002510	000000		0
1736				
1737				
1738			:ITEM	106
1739				
1740	002512	031351	EM131	:HE OR ERR DID NOT SET
1741	002514	033207	DH131	:PC RKCS RKER


```

1814 002636 000005          START: RESET                ;CLEAR THE BUS
1815          ;;GIVE DRIVES TIME TO LOAD HEADS IN CASE OF AN APT START.
1816 002640 023737 000042 000046  CMP      @#42,@#46          ;ARE WE IN ACT11 AUTOMATIC MODE?
1817 002646 001016          BNE     STARTA            ;NO, SKIP DELAY
1818 002650 005077 176464          CLR     @RKDA            ;SELECT UNIT 0
1819 002654 012700 000250          MOV     #250,R0          ;WAIT FOR..
1820 002660 032777 000200 176440 20$:  BIT     #200,@RKDS        ;DRIVE READY..
1821 002666 001006          BNE     STARTA            ;IN CASE..
1822 002670 005001          CLR     R1              ;OF APT..
1823 002672 005301          DEC     R1              ;START, BUT..
1824 002674 001376          BNE     -2              ;DON'T WAIT..
1825 002676 005300          DEC     R0              ;FDEVER.
1826 002700 001367          BNE     20$            ;RKDS BIT 7 (DRIVE READY) N'VER SET
1827 002702 000000          HALT
1828 002704          ;
1829          ;
1830          ;
1831 002704 012706 001100          .SBTTL INITIALIZE THE COMMON TAGS
1832 002710 005026          ;;CLEAR THE COMMON TAGS ($CMTAG) AREA
1833 002712 022706 001140          MOV     #$CMTAG,R6      ;FIRST LOCATION TO BE CLEARED
1834 002716 001374          CLR     (R6)+           ;CLEAR MEMORY LOCATION
1835 002720 012706 001100          CMP     #SWR,R6 ;;DONE?
1836          BNE     -6          ;;LOOP BACK IF NO
1837 002724 012737 022140 000020  MOV     #STACK,_P       ;;SETUP THE STACK POINTER
1838 002732 012737 000340 000022  ;;INITIALIZE A FEW VECTORS
1839 002740 012737 022412 000030  MOV     #SCOPE,@#IOTVEC ;;IOT VECTOR FOR SCOPE ROUTINE
1840 002746 012737 000340 000032  MOV     #340,@#IOTVEC+2 ;;LEVEL 7
1841 002754 012737 024676 000034  MOV     #ERROR,@#EMTVEC ;;EMT VECTOR FOR ERROR ROUTINE
1842 002762 012737 000340 000036  MOV     #340,@#EMTVEC+2 ;;LEVEL 7
1843 002770 012737 024776 000024  MOV     #STRAP,@#TRAPVEC ;;TRAP VECTOR FOR TRAP CALLS
1844 002776 012737 000340 000026  MOV     #340,@#TRAPVEC+2 ;;LEVEL 7
1845 003004 005037 001206          MOV     #SPWRN,@#PWRVEC ;;POWER FAILURE VECTOR
1846 003010 005037 001210          MOV     #340,@#PWRVEC+2 ;;LEVEL 7
1847 003014 112737 000001 001115  CLR     $TIMES          ;;INITIALIZE NUMBER OF ITERATIONS
1848 003022 012737 003022 001106  CLR     $ESCAPE        ;;CLEAR THE ESCAPE ON ERROR ADDRESS
1849 003030 012737 003030 001110  MOV     #1,$ERMAX      ;;ALLOW ONE ERROR PER TEST
1850          MOV     #.,$LPADR    ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
1851          MOV     #.,$LPERR  ;;SETUP THE ERROR LOOP ADDRESS
1852 003036 013746 000004          ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
1853 003042 012737 003076 000004  ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
1854 003050 012737 177570 001140  MOV     @#ERRVEC,-(SP)  ;;SAVE ERROR VECTOR
1855 003056 012737 177570 001142  MOV     #64$,@#ERRVEC  ;;SET UP ERROR VECTOR
1856 003064 022777 177777 176046  MOV     #DSWR,$SWR     ;;SETUP FOR A HARDWARE SWICH REGISTER
1857 003072 001012          MOV     #DDISP,$DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
1858          CMP     #-1,$SWR  ;;TRY TO REFERENCE HARDWARE SWR
1859 003074 000403          BNE     66$          ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
1860 003076 012716 003104          BR     65$          ;;AND THE HARDWARE SWR IS NOT = -1
1861 003102 000002          BR     65$          ;;BRANCH IF NO TIMEOUT
1862 003104 012737 000176 001140 64$:  MOV     #SWREG,$SWR    ;;POINT TO SOFTWARE SWR
1863 003112 012737 000174 001142  RTI     #DISPREG,$DISPLAY
1864 003120 012637 000004          MOV     (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
1865          ;
1866 003124 023737 000042 000046  CMP     @#42,@#46      ;ARE WE IN ACT11 AUTOMATIC MODE?
1867 003132 001416          BEQ     69$          ;YES, SKIP TITLE
1868          ;
1869          .SBTTL TYPE PROGRAM NAME
1870          ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
    
```

```

1870 003134 005227 177777          INC     #-1            ;FIRST TIME?
1871 003140 001043          BNE     67$          ;BRANCH IF NO
1872 003142 104401 003200          TYPE   ,68$          ;TYPE ASCIZ STRING
1873          .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
1874 003146 005737 000042          TST     @#42          ;ARE WE RUNNING UNDER XXDP/ACT?
1875 003152 001006          BNE     69$          ;BRANCH IF YES
1876 003154 023727 001140 000176  CMP     SWR,#SWREG    ;SOFTWARE SWITCH REG SELECTED?
1877 003162 001005          BNE     70$          ;BRANCH IF NO
1878 003164 104406          GTSWR  70$          ;GET SOFT-SWR SETTINGS
1879 003166 000403          BR     70$
1880 003170 112737 000001 001134 69$:  MOV     #1,$AUTOB     ;SET AUTO-MODE INDICATOR
1881 003176          70$:
1882 003176 000424          BR     67$          ;GET OVER THE ASCIZ
1883          ;;68$: .ASCIZ <CRLF>/RK11 LOGIC TEST 2/<15><12>/MAINDEC-11-CZRKKF/<CRLF>
1884          67$:
1885 003250 012700 001410          MOV     #DDPCH,R0
1886 003254 012701 177764          MOV     #-14,R1
1887 003260 005020          CLR     (R0)+
1888 003262 005201          INC     R1
1889 003264 001375          BNE     1$
1890 003266 005227 177777          INC     #-1          ;FIRST START ?
1891 003272 001020          BNE     START1       ;BR IF NOT
1892 003274 013746 000004          MOV     ERRVEC,-(SP) ;SAVE ERROR VECTOR ADDRESS
1893 003300 012737 003314 000004  MOV     #2$,ERRVEC   ;NEW VECTOR ADDRESS
1894 003306 005737 177776          TST     PS           ;SEE IF PROGRAM CAN REFERENCE THE
1895          ;PROCESSOR STATUS WORD
1896 003312 000406          BR     3$           ;BR IF REFERENCE DIDN'T CAUSE TRAP
1897 003314 012737 000140 001400 2$:  MOV     #140,RKPRI   ;SETUP INTERRUPTING PRIORITY TO VALUE
1898          ;WHICH WILL ALLOW INTERRUPT ON AN LSI-11
1899 003322 012716 003330          MOV     #3$,(SP)    ;SETUP RETURN ADDRESS
1900 003326 000002          RTI
1901 003330 012637 000004          3$:  MOV     (SP)+,ERRVEC ;RESTORE THE ERROR VECTOR
1902          ;
1903          ;
1904          ;FIND OUT IF ACT11, 'XXDP' CHAIN OR DUMP MODE
1905          ;
1906 003334 012700 001410          START1: MOV    #DDPCH,R0
1907 003340 012701 177766          MOV     #-12,R1     ;CLEAR OUT DRIVE TABLE AREA
1908 003344 005020          1$:  CLR     (R0)+
1909 003346 005201          INC     R1
1910 003350 001375          BNE     1$
1911 003352 122737 000002 000041  CMPB   #2,41        ;LOADED FROM AN RK05 ?
1912 003360 001166          BNE     ST2          ;BR IF NOT
1913 003362 013737 000040 001410  MOV     40,DDPCH    ;GET DEVICE INDICATOR AND DRIVE ADDRESS OF
1914          ;LOADING RK05
1915 003370 101002          CMPB   #10,DDPCH   ;VALID DRIVE NUMBER IN BYTE 40 ?
1916 003400 105037 001410          BHI     2$          ;BR IF YES
1917          ;MUST BE DRIVE ZERO WHICH LOADED
1918 003404 005737 000042          2$:  TST     42          ;THIS PROGRAM
1919 003410 001432          BEQ     4$          ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
1920 003412 005737 001410          TST     DDPCH       ;BR IF NEITHER
1921 003416 001002          BNE     3$          ;RUNNING FROM AN RK05 ?
1922 003420 000137 004262          JMP     ST3          ;BR IF YES
1923          ;FIND OUT NUMBER OF DRIVES
1924 003424 104401 003432          3$:  TYPE   ,65$          ;TYPE ASCIZ STRING
1925 003430 000413          BR     64$          ;GET OVER THE ASCIZ
    
```

```

1926      ;:65$: .ASCIZ <15><12>/NOT TESTING DRIVE /
1927      64$:
1928      CLR      -(SP)      ;CLEAR WORD ON STACK
1929      MOV      DDPCH,(SP) ;GET DRIVE ADDRESS
1930      TYPOS    ;TYPE THE ADDRESS
1931      .BYTE    1          ;ONLY 1 CHARACTER
1932      .BYTE    0          ;SUPPRESS LEADING ZEROS
1933      JMP      ST3        ;GET NUMBER OF DRIVES
1934      4$: INC      #-1     ;FIRST TIME THROUGH HERE ?
1935      BNE      ST2        ;BR IF NOT
1936      TYPE     ,67$      ;:TYPE ASCIZ STRING
1937      BR       66$       ;:GET OVER THE ASCIZ
1938      ;:67$: .ASCIZ <15><12>/TO TEST DRIVE /
1939      66$:
1940      CLR      -(SP)      ;CLEAR WORD ON THE STACK
1941      MOV      DDPCH,(SP) ;GET DRIVE ADDRESS
1942      TYPOS    ;TYPE THE DRIVE ADDRESS
1943      .BYTE    1          ;ONLY 1 CHARACTER
1944      .BYTE    0          ;SUPPRESS LEADING ZEROS
1945      TYPE     ,69$      ;:TYPE ASCIZ STRING
1946      BR       68$       ;:GET OVER THE ASCIZ
1947      ;:69$: .ASCIZ / HALT PROGRAM, REMOVE RKDP PACK AND REPLACE IT/<15><12>
1948      68$:
1949      TYPE     ,71$      ;:TYPE ASCIZ STRING
1950      BR       70$       ;:GET OVER THE ASCIZ
1951      ;:71$: .ASCIZ /WITH A WORK PACK, CLEAR LOCATION 40, AND RESTART PROGRAM/
1952      70$:
1953      ;FIND OUT FROM USER WHICH DRIVES (LOGICAL ADDRESSES) ARE TO BE
1954      ;TESTED (DRIVES TO BE TESTED ?). IN REPLY THE USER SHOULD TYPE IN THE
1955      ;LOGICAL ADDRESSES SEPERATED BY COMMAS. THUS IF 2 DRIVES 0,1 ARE PRESENT:
1956      ;
1957      ; 'DRIVS TO B TSTD?'
1958      ; '0,1<CR>' A CAR. RET. SHOULD BE TYPED TO TERMINATE THE LIST.
1959      ST2: MOV      #DRIVS,R0
1960      MOV      #-13,R1
1961      13$: CLR      (R0)+
1962      INC      R1
1963      BNE      13$
1964      TYPE     ,65$      ;:TYPE ASCIZ STRING
1965      BR       64$       ;:GET OVER THE ASCIZ
1966      ;:65$: .ASCIZ <15><12>/DRIVES TO BE TESTED ?/<15><12>
1967      64$:
1968      RDLIN
1969      MOV      (SP)+,R0    ;GET STARTING ADRES OF ASCII STRING
1970      MOV      #-10,R1    ;SET UP COUNT
1971      1$: MOV      (R0)+,R2 ;GET ASCII CHARACTER
1972      BIC      #177400,R2 ;MASK UNWANTED BITS
1973      MOV      #DRIVO,R3
1974      MOV      #-10,R4
1975      MOV      #60,R5
1976      2$: CMP      R5,R2
1977      ;:WAS THE TYPED IN CHARACTER
1978      ;:A NUMBER BETWEEN 0-7?
1979      BEQ      3$
1980      INC      R5
1981      TST      (R3)+
1982      INC      R4
1983      ;:YES, BRANCH
1984      ;:NO, INCREMENT
1985      ;:INCREMENT POINTER TO DRV FLAG
1986      ;:CHARACTER THAT WAS INPUT

```

```

1982      BNE      2$
1983      ;:SHOULD BE 0-7, IF ANY OTHER
1984      ;:TYPE ?? & AGAIN ASK FOR
1985      ;:DRIVS TO BE TSTD?
1986      TST      R2
1987      4$: BEQ      6$
1988      ;:IS IT A TERMINATOR?
1989      ;:YES, EXIT. NO DRIVES INDICATED.
1990      TYPE     ,67$      ;:TYPE ASCIZ STRING
1991      BR       66$       ;:GET OVER THE ASCIZ
1992      ;:67$: .ASCIZ /?/?/
1993      66$:
1994      BR       ST2
1995      3$: TST      @R3
1996      ;:GO, AGAIN ASK QUESTION
1997      BNE      4$
1998      ;:SEE IF ALL READY SELECTED
1999      INC      @R3
2000      ;:ERROR IF SELECTED ALL READY
2001      INC      DRIVS
2002      ;:SET UP FLAG FOR THE DRIVE
2003      MOV      @R0,R2
2004      ;:INCREMENT TOTAL NO OF DRIVES PRESENT
2005      BIC      #177400,R2
2006      ;:GET NEXT CHAR
2007      CMP      #'F,R2
2008      ;:CHARACTER ONLY
2009      BNE      8$
2010      ;:IS IT F?
2011      BIC      #BIT15,@R3
2012      ;:NO, GO ON
2013      BIT      #BIT0,R5
2014      ;:SET BIT 15 TO SHOW RK05F
2015      BEQ      9$
2016      ;:EVEN DRIVE?
2017      TST      -2(R3)
2018      ;:EVEN DRIVE SO BRANCH
2019      BNE      4$
2020      ;:CHECK EVEN DRIVE
2021      MOV      #BIT15!BIT0,-2(R3)
2022      ;:EVEN ALL READY SELECTED
2023      BR       10$
2024      ;:SELECT EVEN DRIVE
2025      TST      2(R3)
2026      ;:CONTINUE
2027      BNE      4$
2028      ;:CHECK ODD DRIVE
2029      MOV      #BIT15!BIT0,2(R3)
2030      ;:ERROR IF SELECTED BEFORE
2031      INC      DRIVS
2032      ;:SELECT ODD DRIVE
2033      TST      (R0)+
2034      ;:COUNT DRIVES SELECTED
2035      BR       11$
2036      ;:POINT TO NEXT CHAR
2037      CMP      #54,R2
2038      ;:CHECK FOR COMMA
2039      BEQ      5$
2040      ;:IS IT A 'COMMA'?
2041      TST      R2
2042      ;:YES, GO PROCESS NXT WORD
2043      BNE      4$
2044      ;:NO, IS IT A TERMINATOR?
2045      ;:IF NOT, SOMETHING WRONG
2046      ;:GO ASK QUESTION AGAIN
2047      BR       6$
2048      ;:EXIT, IF A TERMINATOR
2049      5$: TST      (R0)+
2050      ;:INCREMENT PTR TO NXT BYTE
2051      INC      R1
2052      ;:IN INPUT BUFFER
2053      BNE      1$
2054      ;:THERE SHOULD BE NO MORE THAN
2055      BR       4$
2056      ;:8 DRIVES, HENCE IF MORE
2057      ;:THAN 8 DIFFERENT NOS. TYPED IN, ERROR!
2058      ;:GO AGAIN ASK THE QUESTION
2059      6$: CLR      SIZYET
2060      ;:NO SIZI-G NEEDED
2061      BIT      #SW10,@SWR
2062      ;:TESTING ON SIMULATOR?
2063      BNE      7$
2064      ;:YES, BRANCH
2065      CLR      SIMUL
2066      ;:NO, CLR FLAG
2067      BR       ST4
2068      7$: MOV      #1,SIMUL
2069      ;:SET FLAG TO INDICATE SIMULATOR
2070      BR       ST4

```

```

2038 ;CHECK NUMBER OF DRIVES
2039 004262 012737 177777 001440 ST3: MOV #1,SIZ:ET ;CHECK FOR RK05F LATER
2040 004270 012737 004442 000004 MOV #5$,@#4 ;SET UP ADRES FOR TIME-OUT VECTOR
2041 004276 005777 175024 TST @RKDS ;REFERENCE RKDS
2042 004302 005777 175032 TST @RKDA ;REFERENCE RKDA
2043 004306 012737 004534 000004 MOV #BADTMO,@#4
2044 004314 104401 TYPE MSG1
2045 004316 001216 MSG1
2046 004320 012700 177770 MOV #-10,R0 ;INITIALIZE COUNT FOR THE 8 DRIVES
2047 004324 005037 001412 CLR DRVS ;INITIALIZE # OF DRIVES PRESENT TO 0
2048 004330 005001 CLR R1 ;INITIALIZE ADDRESS TO DRIVE 0
2049 004332 005004 CLR R4
2050 004334 012702 001414 MOV #DRIVO,R2
2051 004340 010177 174774 1$: MOV R1,@RKDA ;ADDRESS THE DRIVE
2052 004344 020177 174770 CMP R1,@RKDA ;CHECK, WAS IT ADDRESSED?
2053 004350 001405 BEQ 3$ ;YES
2054 004352 012703 004356 2$: MOV #2$,R3
2055 004356 004737 021026 JSR PC,TYERM ;WHILE CHECKING NUMBER OF DRIVE
2056 ;UNDER NON-MANUAL MODE :-
2057 ;RKDA HAD TO BE ADRESED BUT
2058 ;IT WAS FOUND THAT THE DRIVE NO
2059 ;THAT WAS WRITTEN COULD NOT BE READ BACK
2060 ;CORRECTLY.
2061
2062 004362 000413 BR 4$
2063 004364 032777 000200 174734 3$: BIT #200,@RKDS ;CHECK IF 'DRY' BIT IS SET, IF SET DRIVE IS
2064 ;PRESENT
2065 004372 001407 BEQ 4$
2066 004374 104401 TYPE
2067 004376 001213 $CRLF
2068 004400 005237 001412 INC DRVS ;IF PRESENT, INCREMENT # OF DRIVES
2069 004404 005212 INC (R2) ;SET UP FLAG INDICATING THIS DRIVE PRESENT
2070 004406 010446 MOV R4,-(SP)
2071 004410 104402 TYPOC
2072 004412 005722 4$: TST (R2)+ ;SHIFT POINTER TO NXT DRIVE INDICATOR
2073 004414 062701 020000 ADD #20000,R1 ;SET UP ADDRESS FOR THE NEXT DRIVE
2074 004420 005204 INC R4 ;HAVE U CHECKED FOR ALL 8 DRIVES
2075 004422 005200 INC R0
2076 004424 001345 BNE 1$
2077 004426 005737 001412 TST DRVS
2078 004432 001011 BNE ST4
2079 004434 104401 TYPE MSG2
2080 004436 001236 BR ST4
2081 004440 000406 ;GO CHECK THE DRIVE INDEPENDENT
2082 ;CONTROLLER LOGIC
2083 004442 011603 5$: MOV (SP),R3 ;GET PC WHERE TIMEOUT OCCURED
2084 004444 022626 CMP (SP)+,(SP)+ ;RESTORE STACK
2085 004446 062703 177776 ADD #-2,R3
2086 004452 004737 021026 JSR PC,TYERM ;GO TYPE ERROR MESSAGE
2087 ;WHILE CHECKING FOR THE NUMB&R OF
2088 ;DRIVES IN NON-MANUAL MODE:-
2089 ;RKDS AND RKDA HAD TO BE REFERENCE. TIMEOUT
2090 ;OCCURED ON REFERENCING.PC IN THE ERROR
2091 ;MESSAGE INDICATES WHERE THE TIMEOUT OCCURED.
2092
2093 ;

```

```

2094
2095
2096 004456 005037 001434 ST4: CLR T56FLG
2097 004462 005737 001412 TST DRVS
2098 004466 001004 BNE 1$
2099 004470 004727 021742 JSR PC,WATIME
2100 004474 000137 020652 JMP SEDP
2101 004500 012737 001414 1$: MOV #DRIVO,DRVPTR
2102 004506 005037 001352 CLR DRVDDN ;INITIALIZE THE NO. OF DRIVES
2103 ;THAT HAVE BEEN CHECKED
2104 004512 005037 001350 CLR DRIVAD ;INITIALIZE DRIVE ADDRESS TO
2105 ;THE FIRST DRIVE
2106 004516 012737 004534 000004 MOV #BADTMO,@#4 ;SET TIME OUT VECTOR FOR UNEXPECTED
2107 ;TIME OUTS
2108 004524 012777 004600 174650 MOV #BADINT,@RKVEC ;SET UP RK11 INTERRUPT VECTOR FOR
2109 ;UNEXPECTED INTERRUPTS FROM RK11
2110 004532 000465 BR TST1 ;GO TO TEST 1
2111
2112
2113
2114
2115 ;THIS ROUTINE HANDLES UNEXPECTED TIME OUTS
2116
2117 004534 011600 BADTMO: MOV (SP),R0 ;SAVE PC WHERE TIME OUT OCCURED
2118 004536 005740 TST -(R0)
2119 004540 022626 CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
2120 004542 104401 004550 TYPE ,65$ ;:TYPE ASCIZ STRING
2121 004546 000407 BR 64$ ;:GET OVER THE ASCIZ
2122 ;:65$: .ASCIZ <15><12>/TIMOUT,PC=/
2123 64$:
2124 004566 MOV R0,-(SP) ;SET UP FOR TYPING OUT PC
2125 004570 104402 TYPOC ;GO TYPE OUT OCTAL PC
2126 004572 000000 HALT
2127 004574 000137 002636 JMP @#START
2128
2129
2130
2131 ;THIS ROUTINE HANDLES UNEXPECTED INTERRUPTS FROM RK11
2132 ;SW 9 AND 10 FOR LOOPING ON ERROR
2133 ;AND LOOPING ON TEST IN WHICH TIMEOUT
2134 ;OCCURRED, ARE PROVIDED.
2135
2136 004600 011600 BADINT: MOV (SP),R0 ;SAVE PC WHERE INTERRUPT OCCURED
2137 004602 005740 TST -(R0)
2138 004604 032777 020000 174326 BIT #20000,@SWR ;INHIBIT ERROR TYPEOUT?
2139 004612 001014 BNE 1$ ;YES, DON'T TYPE OUT
2140 004614 104401 TYPE
2141 004616 001213 $CRLF
2142 004620 104401 TYPE EM43 ;TYPE 'UNEXPEXTED RK11 INTERRUPT'
2143 004622 026004 ;TYPE ' AT PC='
2144 004624 104401 004632 TYPE ,65$ ;:TYPE ASCIZ STRING
2145 004630 000403 BR 64$ ;:GET OVER THE ASCIZ
2146 ;:65$: .ASCIZ /,PC=/
2147 64$:
2148 004640 MOV R0,-(SP) ;SET UP FOR TYPING OUT PC
2149 004640

```

```

2150 004642 104402          TYPCC                ;GO TYPE OCTAL PC WHERE BAD
2151                          ;INTERUPT OCCURED
2152 004644 032777 001000 174266 1$: BIT #1000,@SWR        ;LOOP ON ERROR?
2153 004652 001403          BEQ 2$                ;NO. BRANCH
2154 004654 022526          CMP (SP)+,(SP)+      ;YES, REPOSITION STACK
2155 004656 000177 174224  JMP @$LPADR         ;GO TO THE STARTING ADDRESS OF
2156                          ;THE TEST THAT GAVE UNEXPECTED INTERRUPT
2157 004662 032777 040000 174250 2$: BIT #40000,@SWR      ;LOOP ON TEST?
2158 004670 001401          BEQ 3$                ;NO. BRANCH
2159 004672 000002          RTI                 ;YES, LOOP. GO BACK WHER U INTERRUPTED FROM.
2160 004674 000000          HALT                ;UNEXPECTED INTERRUPT OCCURED AS
2161                          ;INDICATED IN THE TYPE OUT.U CAN LUJP
2162                          ;ON ERROR, TEST,OR INHIBIT TYPEOUT BY
2163                          ;SETTING APPROPRIATE SWITCH'S.
2164 004676 000137 002636          JMP @#START         ;GO BACK TO THE START OF THE
2165                          ;PROGRAM. THUS PRESSING CONTINUE
2166                          ;AFTER THE ABOVE HALT WILL
2167                          ;RESTART THE PROGRAM
2168
2169
2170
2171                          ;RESTART AFTER POWER FA.L
2172                          ;THE PROGRAM WOULD RESTART HERE IF POWER CAME BACK AFTER A FALIURE.
2173
2174 004702 004737 021742  PFSTRT: JSR PC,WATIME ;KILL TIME
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192 004706 000004  TST1: SCOPE
2193
2194 004710 012700 001414          MOV #DRIVO,RO      ;INITIALIZE POINTER
2195 004714 005001          CLR R1             ;INITIALIZE DRIVE ADRES 0
2196 004716 005002          CLR R2             ;INITIALIZE DRIVE # 0
2197 004720 005737 001410  1$: TST DDPCH       ;LOADED FROM AN RK05 ?
2198 004724 001403          BEQ 2$             ;B IF NOT
2199 004726 120237 001410  CMPB R2,DDPCH     ;LOADED FROM THIS DRIVE ?
2200 004732 001435          BEQ 4$             ;BR IF YES
2201 004734 010177 174400  2$: MOV R1,@RKDA    ;ADRES THE DRIVE
2202 004740 105777 174362  TSTB @RKDS        ;DRIVE READY?
2203 004744 100005          BPL 3$             ;NO, THIS DRIVE NOT PRESENT
2204                          ;YES, THIS DRIVE SELECTED
2205 004746 005710          TST @R0            ;WAS THIS DRIVE SPECIFIED BY

```

```

2206                          ;THE USER?
2207 004750 001026          BNE 4$             ;YES, OK
2208                          ;NO, THIS DRIVE # WAS NOT SPECIFIED
2209                          ;BY THE USER, BUT STILL IS GIVING
2210                          ;'DRY' WHEN ADRESED. REPORT EROR.
2211 004752 010237 001162  MOV R2,$REGO      ;GET DRIVE #
2212 004756 104116  ERROR 116        ;THIS DRIVE # WAS NOT SPECIFIED BY
2213                          ;THE USER, BUT WHEN ADRESED GAVE
2214                          ;'DRY'. CHECK THAT THIS DRIVE # IF
2215                          ;PHYSICALLY PRESENT IS ON 'LOAD'. IF
2216                          ;THIS IS NOT THE CASE, THEN ONE DRIVE
2217                          ;MAY BE GETTING SELECTED BY TWO DIFFERENT
2218                          ;LOGICAL ADDRESSES.
2219 004760 005710  3$: TST @R0            ;CHECK THAT THIS DRIVE WAS NOT INDICATED
2220 004762 001421          BEQ 4$             ;IF IT WAS, & IT IS NOT FOUND TO BE
2221                          ;PRESENT (DRY CLEAR), REPORT ERROR.
2222 004764 004737 020774  JSR PC,GT4RG      ;GET RKCS, ER, DS. DA
2223 004770 104010  ERROR 10        ;DRIVE # (AS IN RKDA) WAS INDICATED BY
2224                          ;THE USER, BUT WAS NOT FOUND TO BE PRESENT.
2225                          ;CHECK THAT THE ROTARY DRIVE SELECTION
2226                          ;SWITCH ON THE MODULE IS SET TO THE RIGHT
2227                          ;DRIVE #.
2228
2229 004772 005010          CLR @R0            ;THIS DRIVE IS NOT FOUND TO BE PRESENT
2230                          ;HENCE DROP IT FROM THE SELECTION TABLE.
2231 004774 010003          MOV R0,R3         ;DRIVE #DR
2232 004776 162703 001414  SUB #DRIVO,R3     ;MINUS OFFSET FOR TABLE
2233 005002 042703 000003  BIC #3,R3         ;EVEN DRIVE OF PAIR
2234 005006 062703 001414  ADD #DRIVO,R3     ;POINT TO EVEN OF PAIR IF RK05 F
2235 005012 042723 100000  BIC #100000,(R3)+ ;NOT SPECIFIED AS F MODEL
2236 005016 042713 100000  BIC #100000,(R3)  ;SAME
2237 005022 005337 001412  DEC DRIVS         ;DECREMENT DRIVE COUNT
2238 005026 005202  4$: INC R2             ;INCRMNT DRIVE #
2239 005030 005720          TST (R0)+         ;INCRMNT POINTER
2240 005032 062701 020000  ADD #20000,R1     ;INCRMNT ADRES TO NXT DRIVE
2241 005036 001330          BNE 1$            ;LUP BAK IF NOT DONE
2242
2243
2244                          ;THIS PART OF THE PROGRAM IS GOING TO BE REPEATED FOR
2245                          ;EACH DRIVE PRESENT
2246                          ;
2247                          ;'DRIVAD' CONTAINS IN BITS 15,14,13 THE ADDRESS OF THE
2248                          ;DRIVE BEING CURRENTLY CHECKED.
2249                          ;
2250 005040          NUDRV:
2251
2252
2253
2254
2255
2256
2257
2258
2259 005040 000004  TST2: SCOPE
2260 005042 012737 000001 001206  MOV #1,$TIMES     ;DO 1 ITERATION
2261 005050 012737 000002 001102  MOV #2,$STNM     ;RESET POINTER TO THIS TEST

```



```
2374 ;THEN BACK TO RUN
2375 005402 032700 004000 1$: BIT #4000,R0 ;IS 'HDEN' BIT SET?
2376 005406 001004 BNE 25 ;YES, BRANCH
2377 005410 017737 173712 001162 MOV @RKDS,$REGO ;GET RKDS
2378 005416 104007 ERROR 7 ;ERROR, 'RKDS' BIT IS NOT SET
2379
2380 005420 032777 000040 173700 2$: BIT #40,@RKDS ;IS 'WPS' CLEAR?
2381 005426 001403 BEQ TST5 ;:YES, EXIT
2382 005430 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
2383 005434 104114 ERROR 114 ;'WPS'-WRITE PROTECT STATUS- BIT OF
;OF RKDS SHOULD BE CLEAR, IF THIS DRIVE
;IS WRITE ENABLED. CHECK & SEE IF THIS
;DRIVE IS WRITE ENABLED, IF IT IS NOT,
;WRITE ENABLE IT.
2384
2385
2386
2387
2388
2389
2390 ;*****
2391 ;*TEST 5 CHECK THAT 'DRIVE READY' IS SET IN RKDS
2392 ;*****
2393 TST5: SCOPE ;GO, DO CONTROL RESET
2394 005440 104413 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
2400 MOV DRIVAD,@RKDA ;ADDRS THE DRIVE
2401 TSTB @RKDS ;IS 'DRY' SET?
2402 BMI TST6 ;:YES, OK
2403 JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
2404 ERROR 10 ;'DRY' NOT SET
2405
2406 ;*****
2407 ;*TEST 6 CHECK THAT 'SOK' BIT CAN SET
2408 ;* THIS TEST CHECKS THAT WITHIN A CERTAIN TIME
2409 ;* 'SOK' BIT CAN SET, IF IT DOES NOT AN ERROR IS REPORTED
2410 ;*****
2411 TST6: SCOPE ;ADDRS THE DRIVE
2412 005464 000004 MOV DRIVAD,@RKDA ;INITIALIZE COUNT FOR TIMING WAIT LOOP
2413 005468 013777 001350 173644 CLR R1 ;IS SOK SET?
2414 005474 005001 CLR R1 ;:EXIT
2415 005476 032777 000400 173622 1$: BIT #4000,@RKDS ;NO, WAIT
2416 005504 001006 BNE TST7 ;WAITED LONG?
2417 005506 005201 INC R1 ;GET RKDS
2418 005510 001372 BNE 1$ ;WAITED LONG BUT 'SEC OK' BIT DID NOT
2419 005512 017737 173610 001162 MOV @RKDS,$REGO ;SET
2420 005520 104011 ERROR 11
2421
2422 ;*****
2423 ;*TEST 7 CHECK THAT 'SECTOR COUNTER' CAN COUNT FROM 0-13
2424
2425
2426
2427
2428
2429
```

```
2430 ;* THIS TEST CHECKS THAT THE SECTOR COUNTER CAN COUNT FROM
2431 ;* 0-13
2432 ;* 1) FIRST, FOR INITIALIZING PURPOSES THERE IS A TIMED LOOP
2433 ;* DURING WHICH SECTOR COUNTER SHOULD COUNT DOWN TO 0. IF THIS
2434 ;* IS NOT DONE AN ERROR IS REPORTED
2435 ;* 2) AFTER A COUNT OF 0 IS REAC.ED, THE PROGRAM WAITS
2436 ;* FOR A CERTAIN TIME, DURING WHICH THE SEC COUNTER
2437 ;* IS SAMPLED. IF THE COUNTER DOES NOT CHANGE WITHIN THIS
2438 ;* TIME PERIOD AN ERROR IS REPORTED.
2439 ;* 3) UPON FINDING THAT THE COUNTER HAS CHANGED, IT IS CHECKED
2440 ;* IF IT INCREMENTED CORRECTLY. IF IT DID NOT AN ERROR IS REPORTED
2441 ;* 4) IF IT INCREMENTED CORRECTLY, THE PROGRAM AGAIN WAITS IN A
2442 ;* LOOP TILL THE COUNTER CHANGES. (STEPS 2,3,4 ARE REPEATED
2443 ;* TILL THE COUNTER COUNTS UP TO 13)
2444 ;*****
2445 TST7: SCOPE ;GO, DO CONTROL RESET
2446 005524 104413 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
2450 MOV DRIVAD,@RKDA ;INITIALIZE
2451 MOV RKDS,R0 ;'COUNT' - TO TIME 'ERROR 35'
2452 CLR INDX1 ;INITIALIZE 'COUNT' - TO TIME
2453 CLR R5 ;'ERROR 36' (WAIT LOOP)
2454 MOV #-14,R4 ;INITIALIZE 'COUNT' - FOR THE 12 SECTORS.
2455 MOV #1,R3 ;R3 CONTAINS THE 'NEXT' COUNT OF SEC-CNTR
;R1 CONTAINS THE 'PREVIOUS' COUNT OF SEC-CNTR
;R2 CONTAINS THE 'PRESENT' COUNT OF SEC-CNTR
2456 005526 013777 001350 173604 MOV DRIVAD,@RKDA ;INITIALIZE 'COUNT' - TO TIME
2457 005534 013700 001326 MOV RKDS,R0 ;(WAIT LOOP) 'ERROR 34'
2458 005540 005037 001356 CLR INDX1 ;KEEP TIMING FOR 'ERROR 35'
2459 005544 005005 CLR R5 ;BRANCH & REPORT ERROR IF WAITED LONG?
2460 MOV #-14,R4 ;KEEP TIMING FOR 'ERROR 34'
2461 005546 012704 177764 MOV #1,R3 ;BRANCH & REPORT ERROR IF WAITED LONG?
2462 005552 012703 000001 MOV #1,R3
2463
2464
2465 005556 005037 001360 1$: CLR INDX2 ;INITIALIZE 'COUNT' - TO TIME
2466 ;(WAIT LOOP) 'ERROR 34'
2467 005562 005237 001356 INC INDX1 ;KEEP TIMING FOR 'ERROR 35'
2468 005566 001440 BEQ 6$ ;BRANCH & REPORT ERROR IF WAITED LONG?
2469 005570 005237 001360 2$: INC INDX2 ;KEEP TIMING FOR 'ERROR 34'
2470 005574 001441 BEQ 7$ ;BRANCH & REPORT ERROR IF WAITED LONG?
2471
2472 005576 011001 MOV @R0,R1 ;GET RKDS
2473 005600 032701 000400 BIT #400,R1 ;IS 'SOK' SET?
2474 005604 001771 BEQ 2$ ;NO, WAIT FOR IT TO SET
2475 005606 021001 CMP @R0,R1 ;MAKE SURE THAT 2 CONSECUTIVE
2476 005610 001362 BNE 1$ ;READINGS OF SEC-CNTR ARE SAME
2477 005612 042701 177760 BIC #177760,R1 ;YES, MASK OUT NON-SEC CNTR BITS
2478 005616 001357 BNE 1$ ;IS IT SECTOR 0, IF NOT LOOP BACK &
;WAIT FOR SECTOR 0
2479
2480 005620 005204 3$: INC R4 ;KEEP TRACK OF SECTORS CHECKED
2481 005622 001447 BEQ TST10 ;:EXIT, IF ALL SECTORS CHKD
2482 005624 005205 4$: INC R5 ;KEEP TIMING FOR 'ERROR 36'
2483 005626 001431 BEQ 9$ ;BR & REPORT ERROR IF WAITED LONG
2484 005630 011002 MOV @R0,R2 ;GET RKDS
2485 005632 032702 000400 BIT #400,R2 ;IS SOK SET?
```

```

2486 005636 001772      BEQ    4$          ;NO, WAIT FOR SDK
2487 005640 021002      CMP    @R0,R2     ;MAKE SURE THAT 2 CONSECUTIVE
2488 005642 001370      BNE   4$          ;READINGS OF SEC-CNTR ARE SAME
2489 005644 042702 177760 BIC   #177760,R2 ;MASK NON-SEC-CNTR BITS
2490 005650 020201      CMP    R2,R1     ;HAS SEC CNTR INCREMENTED?
2491 005652 001764      BEQ    4$          ;NO, WAIT FOR IT TO CHANGE
2492 005654 020203      CMP    R2,R3     ;YES, DID IT INCREMENT CORRECTLY?
2493 005656 001023      BNE   9$          ;NO - REPORT ERROR
2494
2495 005660 005203      5$: INC    R3          ;INCREMENT "NEXT COUNT"
2496 005662 005201      INC    R1          ;INCREMENT "PREVIOUS COUNT"
2497 005664 005005      CLR   R5          ;INITIALIZE AGAIN FOR TIMING 'ERROR 36'
2498 005666 000754      BR    3$          ;GO & CHECK THE NEXT SECTOR COUNT
2499
2500 005670 010137 001162 6$: MOV    R1,$REGO   ;GET 'SEC CNTR'
2501 005674 104012      ERROR 12          ;WAITED LONG, BUT SECTOR COUNTER
2502                                ;DID NOT COUNT TO 0
2503                                ;EXIT
2503 005676 000421      BR    TST10
2504
2505 005700 017737 173422 001162 7$: MOV    @RKDS,$REGO ;GET RKDS
2506 005706 104011      ERROR 11          ;WAITED LONG, BUT 'SOK' BIT DID
2507                                ;NOT SET
2508                                ;EXIT
2508 005710 000414      BR    TST10
2509
2510 005712 010237 001162 8$: MOV    R2,$REGO   ;GET SEC CNTR (PRESENT COUNT)
2511 005716 010337 001164      MOV    R3,$REG1  ;GET "NEXT COUNT"
2512 005722 104013      ERROR 13          ;WAITED LONG, BUT THE SECTOR
2513                                ;COUNTER DID NOT INCREMENT FROM
2514                                ;THE PRESENT COUNT TO THE NEXT COUNT
2514                                ;EXIT
2514
2515 005724 000406      BR    TST10
2516
2517 005726 010337 001162 9$: MOV    R3,$REGO   ;GET 'NEXT COUNT' (SEC CNTR SHOULD BE THIS)
2518 005732 010237 001164      MOV    R2,$REG1  ;GET PRESENT COUNT (WHAT SEC CNTR WAS)
2519 005736 104014      ERROR 14          ;SEC CNTR INCREMENTED WRONG, DID
2520                                ;NOT INCREMENT FROM PRESENT COUNT
2521                                ;TO NEXT COUNT
2522                                ;
2522 005740 000747      BR    5$
2523                                ;
2524                                ;*****
2525                                ;*TEST 10 CHECK THAT SC=SA CAN BE GENERATED
2526                                ;* THIS TEST CHECKS THAT SC=SA CAN BE GENERATED FOR
2527                                ;* EVERY SECTOR
2528                                ;*****
2529                                ;
2530 005742 000004      TST10: SCOPE
2531 005744 104413      CNT.RESET        ;GO, DO CONTROL RESET
2532                                ;THIS IS A CALL FOR THE 'CNTRL-
2533                                ;RESET' ROUTINE. A CONTROL RESET IS
2534                                ;ISSUED AND AFTER A CERTAIN TIME
2535                                ;IF THE 'CNTRL RDY' DOES NOT SET
2536                                ;AN ERROR IS REPORTED. NOTE THAT
2537                                ;THE PC IN ERROR MESSAGE IS THE
2538                                ;PC WHERE 'CNT.RESET' IS LOCATED.
2539                                ;THIS IS A VERY BASIC ERR & IF IT
2540                                ;OCCURS GO BACK TO TEST 10
2541 005746 013704 001350      MOV    DRIVAD,R4

```

```

2542 005752 013700 001326      MOV    RKDS,R0
2543 005756 012703 177754      MOV    #14,R3
2544 005762 010477 173352      1$: MOV    R4,@RKDA ;INITIALIZE COUNT FOR # OF SECTORS
2545 005766 005005      CLR   R5          ;ADDRESS THE DRIVE
2546 005770 005205      2$: INC    R5          ;INITIALIZE COUNT - FOR TIMING ERROR
2547 005772 001410      BEQ    3$          ;KEEP TIMING FOR ERROR
2548 005774 011001      MOV    @R0,R1     ;REPORT ERROR IF WAITED LONG
2549 005776 032701 000020      BIT    #20,R1     ;GET RKDS
2550 006002 001772      BEQ    2$          ;IS SC=SA SET?
2551 006004 005204      4$: INC    R4          ;NO, WAIT FOR IT
2552 006006 005203      INC    R3          ;ADDRS THE NEXT SECTOR
2553 006010 001364      BNE   1$          ;ARE ALL SECTORS CHECKED FOR SC=SA
2554 006012 000406      BR    TST11       ;NO, GO & CHECK NEXT
2555                                ;YES, EXIT
2556 006014 110437 001162      3$: MOVB   R4,$REGO ;GET SECTOR ADDRESS
2557 006020 010137 001164      MOV    R1,$REG1  ;GET RKDS
2558 006024 104015      ERROR 15          ;COULD NOT GET SC=SA FOR THIS
2559                                ;'SECTOR ADDRESS'
2560 006026 000766      BR    4$          ;GO CHK FOR THE REST
2561                                ;
2562                                ;*****
2563                                ;*TEST 11 CHECK THAT 'R/W/S RDY' IS SET & 'SIN' IS CLEAR
2564                                ;*****
2565 006030 000004      TST11: SCOPE
2566 006032 104413      CNT.RESET        ;GO, DO CONTROL RESET
2567 006034 013777 001350 173276      MOV    DRIVAD,@RKDA ;ADDRESS THE DRIVE
2568 006042 005001      CLR   R1
2569 006044 017700 173256 1$: MOV    @RKDS,R0 ;GET RKDS
2570 006050 032700 000100      BIT    #100,R0   ;IS R/W/S RDY SET?
2571 006054 001007      BNE   2$          ;YES, BRANCH
2572 006056 005201      3$: INC    R1          ;INCREASE LOOP TIME
2573 006060 001376      BNE   3$          ;FOR DRIVE RESET OF HEADS
2574 006062 005201      INC    R1          ;WAITED LONG ENOUGH?
2575 006064 001367      BNE   1$          ;IF NOT LUP BAK & WAIT
2576 006066 010037 001162      MOV    R0,$REGO ;GET RKDS
2577 006072 104016      ERROR 16          ;R/W/S RDY SHOULD BE SET
2578 006074 032700 001000      BIT    #1000,R0 ;IS SIN CLEAR?
2579 006100 001403      BEQ    TST12     ;YES, EXIT
2580 006102 004737 020774      JSR   PC,GT4RG  ;GET RKDS ER, DS,DA
2581 006106 104001      ERROR 1          ;'SIN' SHOULD HAVE BEEN CLEAR
2582                                ;IT WAS NOT CLEAR
2583                                ;NEXT TEST IS GOING TO CHECK
2584                                ;DRIVE RESET, SIN SHOULD BE
2585                                ;CLEARED THEN. IT WILL BE CHECKED
2586                                ;THERE.
2587                                ;
2588                                ;*****
2589                                ;*TEST 12 CHECK 'DRIVE RESET'
2590                                ;*THIS TEST CHECKS THE VERY BASIC DRIVE RESET LOGIC.
2591                                ;*SINCE THE HEADS ARE AT CYLINDER 0 (GOING INTO THIS
2592                                ;*TEST) DRIVE RESET RETRACTS THEM BACK BEYOND CYLINDER 0,
2593                                ;*AFTER WHICH THEY ARE PUSHED FORWARD TO CYLINDER 0 AGAIN.
2594                                ;*IN THE LATER PART OF THIS PROGRAM THERE IS A DRIVE RESET
2595                                ;*TEST WHICH DOES THE RESET FROM LAST CYLINDER.
2596                                ;*****
2597 006110 000004      TST12: SCOPE

```

```

2598 006112 104413          CNT.RESET          ;GO, DO CONTROL RESET
2599                          ;THIS IS A CALL FOR THE 'CNTRL-
2600                          ;RESET' ROUTINE. A CONTROL RESET IS
2601                          ;ISSUED AND AFTER A CERTAIN TIME
2602                          ;IF THE 'CNTRL RDY' DOES NOT SET
2603                          ;AN ERROR IS REPORTED. NOTE THAT
2604                          ;THE PC IN ERROR MESSAGE IS THE
2605                          ;PC WHERE 'CNT.RESET' IS LOCATED.
2606                          ;THIS IS A VERY BASIC ERR & IF IT
2607                          ;OCCURS GO BACK TO TEST 10
2608 006114 013700 001332      MOV    RKCS,R0
2609 006120 005004              CLR    R4
2610 006122 013777 001350 173210 MOV    DRIVAD,@RKDA
2611 006130 012710 000015      MOV    #15,@R0
2612 006134 104412              CHKCRDY
2613                          ;GO CHECK IF CONTROL RDY IS SET
2614 006136 104021              ERROR   21
2615                          ;IF SO, SKIP THE EROR MESSAGE.
2616                          ;CNTRL RDY DID NOT SET AFTER
2617                          ;SENDING CYL ADDR TO THE DRIV.
2618 006140 012705 177776      MOV    #-2,R5
2619 006144 032777 000100 173154 BIT    #100,@RKDS
2620 006152 001402              BEQ    .+6
2621 006154 000137 006176      JMP    3$
2622 006160 005204              INC    R4
2623 006162 001370              BNE   6$
2624 006164 005205              INC    R5
2625 006166 001366              BNE   6$
2626 006170 004737 020774      JSR    PC,GT4RG
2627 006174 104026              ERROR   26
2628                          ;GO, GET RKCS, ER, DS, DA
2629                          ;R/W/S RDY DID NOT SET AFTER
2630                          ;DRIVE RESET
2631 006176 032777 001000 173122 BIT    #1000,@RKDS
2632 006204 001403              BEQ    5$
2633 006206 004737 020774      JSR    PC,GT4RG
2634 006212 104001              ERROR   1
2635 006214 032710 140000      5$:   BIT    #140000,@R0
2636 006220 001403              BEQ    4$
2637 006222 004737 020774      JSR    PC,GT4RG
2638 006226 104022              ERROR   22
2639                          ;WAS 'ERR' BIT OR 'HE' BIT SET?
2640                          ;NO
2641                          ;GO, GET RKCS, ER, DS, DA
2642 006230 022710 000214      4$:   CMP    #214,@R0
2643 006236 012737 000214 001162 BEQ    TST13
2644 006244 011037 001164      MOV    #214,$REG0
2645 006250 104024              MOV    @R0,$REG1
2646                          ERROR   24
2647                          ;NO - RKCS SHOULD CONTAIN THE 'DRIV RES'
2648                          ;FUNCTION, ERROR IF DIFFERENT.
2649
2650 ;*****
2651 ;*TEST 13      CHECK 'SEEK' TO CYLINDER 0
2652 ;* THIS TEST CHECKS THE SEEK LOGIC DOING SEEK TO CYLINDER 0.
2653 ;* NOTE THAT SINCE THE HEADS ARE ALREADY ON CYLINDER 0, NO
2654 ;* HEAD MOVEMENT IS INVOLVED AND THE STRESS IS ON THE BASIC SEEK
2655 ;* LOGIC.
    
```

```

2654 ;*****
2655 TST13: SCOPE
2656 CNT.RESET          ;GO, DO CONTROL RESET
2657                          ;THIS IS A CALL FOR THE 'CNTRL-
2658                          ;RESET' ROUTINE. A CONTROL RESET IS
2659                          ;ISSUED AND AFTER A CERTAIN TIME
2660                          ;IF THE 'CNTRL RDY' DOES NOT SET
2661                          ;AN ERROR IS REPORTED. NOTE THAT
2662                          ;THE PC IN ERROR MESSAGE IS THE
2663                          ;PC WHERE 'CNT.RESET' IS LOCATED.
2664                          ;THIS IS A VERY BASIC ERR & IF IT
2665                          ;OCCURS GO BACK TO TEST 10
2666 006256 104421              TST.SIN
2667                          ;GO CHECK IF SIN SET. IF SET
2668                          ;A DO DRIVE RESET TO CLEAR 'T
2669 006260 013700 001332      MOV    RKCS,R0
2670 006264 013777 001350 173046 MOV    DRIVAD,@RKDA
2671                          ;ADDRESS THE DRIVE
2672 006272 012710 000011      MOV    #11,@R0
2673 006276 104412              CHKCRDY
2674                          ;SEEK' GO
2675 006300 104021              ERROR   21
2676                          ;GO CHECK IF CONTROL RDY IS SET
2677                          ;IF SO, SKIP THE EROR MESSAGE.
2678                          ;CNTRL RDY' DID NOT SET AFTER SENDING
2679                          ;CYL ADDR TO THE DRIVE. 'ADD ACK'
2680                          ;SHOULD HAVE COME BACK FROM THE
2681                          ;DRIVE, THEREUPON SETTING 'CNTRL RDY'
2682 006302 005005      2$:   CLR    R5
2683 006304 032777 000100 173014 BIT    #100,@RKDS
2684 006312 001005              BNE   3$
2685 006314 005205              INC    R5
2686 006316 001372              BNE  2$+2
2687 006320 004737 020774      JSR    PC,GT4RG
2688 006324 104026              ERROR   26
2689 006326 032777 001000 172772 3$:   BIT    #1000,@RKDS
2690 006334 001403              BEQ    6$
2691 006336 004737 020774      JSR    PC,GT4RG
2692 006342 104001              ERROR   1
2693                          ;GO, GET RKCS,ER,DS,DA
2694                          ;SIN SET ON DOING SEEK
2695                          ;TO CYL 0 NOTE THIS IS THE
2696                          ;FIRST TIME THE HEADS HAVE
2697                          ;BEEN MOVED
2698 006344 032710 140000      6$:   BIT    #140000,@R0
2699 006350 001403              BEQ    4$
2700                          ;WAS 'ERR' OR 'HE' BIT SET?
2701                          ;NO
2702 006352 004737 020774      JSR    PC,GT4RG
2703 006356 104022              ERROR   22
2704                          ;GO, GET RKCS, ER, DS, DA
2705                          ;'ERR' OR 'HE' BIT SET WHILE DOING 'SEEK'
2706 006360 005777 172744      4$:   TST    @RKER
2707 006364 001403              BEQ    5$
2708 006366 004737 021002      JSR    PC,GT3RG
2709 006372 104023              ERROR   23
2710                          ;GO, GET RKCS, ER, DS
2711                          ;RKER SHOWS AN ERROR BIT, CHECK
2712 006374 022710 000210      5$:   CMP    #210,@R0
2713 006400 001406              BEQ    TST14
2714 006402 012737 000210 001162 MOV    #210,$REG0
2715 006410 011037 001164      MOV    @R0,$REG1
2716 006414 104024              ERROR   24
2717                          ;DOES RKCS STILL CONTAIN 'SEEK' FUNCTION
2718                          ;YES, EXIT
2719                          ;GET EXPTD RKCS
2720                          ;GET RKCS RECVD
2721                          ;NO, RKCS SHOULD BE STILL CONTAINING
2722                          ;'SEEK' FUNCTION ERROR - IF IT CHANGED
    
```

```

2710
2711
2712
2713
2714
2715
2716
2717
2718
2719
2720
2721 006416 000004
2722 006420 104413
2723
2724
2725
2726
2727
2728
2729
2730
2731
2732 006422 104421
2733
2734 006424 004737 021504
2735 006430 104026
2736
2737 006432 005005
2738 006434 013777 001350 172676
2739 006442 052777 000100 172670
2740 006450 013701 001326
2741 006454 012701 000011 172650
2742 006462 032711 000100
2743 006466 001405
2744 006470 005205
2745 006472 100373
2746 006474 004737 021002
2747 006500 104025
2748
2749
2750 006502 004737 021436
2751 006506 104016
2752
2753
2754
2755
2756
2757
2758
2759
2760
2761
2762
2763
2764
2765

```

```

*****
;:*****
;:TEST 14 CHECK R/W/S RDY IS CLEAR WHEN HEADS ARE IN MOTION
;:THIS TEST CHECKS THAT R/W/S DOES GET CLEARED
;:WHEN THE HEADS ARE IN MOTION. SINCE 'MOVE L' ON
;:M7700 (RK05) GENERATES THIS SIGNAL, ABSENCE OF
;:R/W/S RDY-CLEAR COULD MEAN A FAULT ON M7702
;:WHERE 'MOVE L' IS GENERATED.
;:NOTE THIS IS THE FIRST TIME HEADS ARE MADE TO MOVE BY SEEKING
;:TO CYLINDER 2.
*****
TST14: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
TST.SIN ;GO CHECK IF SIN IS SET
;IF SET DO DRV-RESET TO CLR IT
JSR PC,DRESET ;MAKE SURE HEADS R ON CYL 0
ERROR 26 ;R/W/S RDY DIDN'T SET
;AFTER THE ABOVE DRV RESET
CLR R5
MOV DRIVAD,@RKDA
BIS #100,@RKDA ;SEEK CYLINDER 2
MOV RKDS,R1
MOV #11,@RKCS ;SEEK, GO
1$: BIT #100,@R1 ;DID R/W/S RDY CLR?
BEQ 2$ ;YES, BRANCH
INC R5
BPL 1$
JSR PC,GT3RG
ERROR 25 ;R/W/S RDY WAS NOT CLEAR WHEN HEADS
;WERE SEEKING TO CYLINDER 2
2$: JSR PC,TSTRWS ;GO, WAIT FOR R/W/S RDY TO SET
ERROR 16 ;R/W/S RDY DID NOT SET AFTER SEEK
;WAS TRIED TO CYLINDER 2 (ABOVE).
;NOTE THIS WAS THE FIRST TIME A SEEK
;WAS TRIED TO A CYLINDER OTHER THAN
;0.
*****
;:*****
;:TEST 15 CHECK 'WRITE' FORMAT FUNCTION-CYLINDER 0, SECTOR 0
;:THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
;:FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
;:1) CNTRL RDY WAS CLEARED AS GO WAS SET.
;:2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION

```

```

2766
2767
2768
2769
2770
2771
2772
2773
2774
2775 006510 000004
2776 006512 104413
2777
2778
2779
2780
2781
2782
2783
2784
2785
2786 006514 104421
2787
2788 006516 012703 033342
2789
2790
2791
2792
2793
2794
2795
2796
2797
2798
2799
2800
2801
2802 006522 012700 000001
2803
2804 006526 010023
2805 006530 010013
2806 006532 005423
2807 006534 005200
2808 006536 022700 000200
2809 006542 001371
2810 006544 005023
2811 006546 012713 125252
2812
2813 006552 012703 033342
2814 006556 013701 001332
2815 006562 013702 001336
2816 006566 010312
2817 006570 012777 177400 172536
2818 006576 013777 001350 172521
2819 006604 012711 002003
2820
2821 006610 105711
2822

```

```

*****
;:*****
;:3) IF 'HE' OR 'ERR' BIT SET?
;:4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
;:5) IF RKWC OVERFLOWED CORRECTLY TO 0?
;:6) IF RKBA INCREMENTED CORRECTLY BY 2?
;:7) IF ANY BIT IN RKER SET?
;:8) IF THE 'WRT FMT' FUNCTION BITS ARE STILL IN THE RKCS?
;:NOTE THAT ONE WORD '125252' WAS WRITTEN ON SECTOR
;:0 & IT WILL BE CHECKED IN THE NEXT TESTS.
*****
TST15: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
TST.SIN ;GO CHECK IF SIN IS SET
;IF SET, DO DRIVE RESET TO CLR IT
MOV #OUTBUF,R3 ;THIS CODE SETS UP A 256 WORD BUFFER
;WHICH WILL BE USED TO WRITE 1 SECTOR
;ON THE DISK
;1ST WORD 000001
;2ND WORD 177777 2'S COMPLEMENT
;3RD WORD 000002 OF ABOVE
;4TH WORD 177776
;...
;253RD WORD 000177
;254TH WORD 177601
;255TH WORD 000000
;256TH WORD 125252
MOV #1,R0 ;SET COUNT
9$: MOV R0,(R3)+ ;SET UP DATA WORDS
MOV R0,(R3)
NEG (R3)+
INC R0
CMP #200,R0 ;DONE?
BNE 9$
CLR (R3)+ ;SET 255TH WORD TO 0
MOV #125252,@R3 ;SET 256TH WORD
MOV #OUTBUF,R3 ;RESET POINTER TO OUTBUF
MOV RKCS,R1
MOV RKBA,R2
MOV R3,@R2 ;FROM HERE-SET UP CURRENT ADDRESS
MOV #-400,@RKWC ;SET UP WORD COUNT 400 WORDS
MOV DRIVAD,@RKDA ;SET UP DISK ADDR, SECTOR 0, CYLINDER 0
MOV #2003,@R1 ;WRITE FORMAT, GO
1$: TSTB @R1 ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?

```

```

2822 006612 100003          BPL      2$          ;YES, BRANCH
2823 006614 004737 021002 JSR      PC,GT3RG   ;GO, GET RKCS, ER, DS
2824 006620 104030          ERROR    30          ;'CNTRL RDY' DIDN'T CLEAR AS GO
2825                                     ;WAS SET TO 'WRITE FORMAT'
2826 006622 005000          2$: CLR      RO          ;
2827 006524 105711          TSTB   @R1          ;WAS 'CNTRL RDY' SET ON COMPLETION OF WRITE?
2828 006626 100411          BMI     3$          ;YES, BRANCH
2829 006630 005200          INC     RO          ;NO, HAVE U WAITED LONG ENOUGH?
2830 006632 001374          BNE    2$+2         ;IF NOT, LOOP BACK & WAIT
2831                                     ;IF YES, REPORT ERROR
2832 006634 004737 020774 JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS,DA
2833 006640 013737 001350 001202 MOV      DRIVAD,$REG10
2834 006646 104416          BRKDA4          ;GO TO 'BDA4' & BREAK CONTENTS OF
2835                                     ;$REG10 INTO DR #.CYL,SUR,SFC BITS
2836 006650 104031          ERROR    31          ;'CNTRL RDY' DIDN'T SET ON COMPLETION
2837                                     ;OF WRITE FORMAT
2838                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2839                                     ;INDICATED IN EROR MSGE.
2840 006652 004737 021234          3$: JSR      PC,CHKHE ;GO CHECK IF 'HE' OR 'ERR' BIT SET.
2841                                     ;IF YES, SAVE RKCS, ER, DS, DA.
2842                                     ;RETURN HERE IF ERROR.
2843 006656 104032          ERROR    32          ;'HE' OR 'ERR' BIT SET WHILE DOING
2844                                     ;A WRITE FORMAT
2845                                     ;WRT FMT WAS DONE STARTING AT <DSK-ADRES>
2846                                     ;INDICATED IN EROR MSGE.
2847 006660 004737 021262          4$: JSR      PC,CHKDA ;GO CHECK IF RKDA INCREMENTED CORRECTLY
2848                                     ;IF NOT, RETURN HERE.
2849 006664 104033          ERROR    33          ;RKDA SHOULD HAVE INCREMENTED BY
2850                                     ;1 SECTOR, IT DID NOT
2851 006666 004737 021316          5$: JSR      PC,CHKWC ;CHECK IF WORD COUNT OVERFLOWED, IF
2852                                     ;NOT RETURN HERE.
2853 006672 104034          ERROR    34          ;RKWC DID NOT OVERFLOW TO 0, AFTER
2854                                     ;XFER ON WRITE FORMAT
2855 006674 022712 034342          6$: CMP      #OUTBUF+1000,@R2 ;DID RKBA INCREMENT CORRECTLY?
2856 006700 001406          BEQ     7$          ;YES, BRANCH
2857 006702 012737 034342 001162 MOV      #OUTBUF+1000,$REG0 ;GET EXPTD RKBA
2858 006710 011237 001164 MOV      @R2,$REG1  ;GET ACTUAL RKBA
2859 006714 104035          ERROR    35          ;RKBA DIDN'T INCREMENT BY 1000 AFTER
2860                                     ;WRITE FORMAT OF 400 WORDS
2861 006716 004737 021342          7$: JSR      PC,CHKER ;CHECK IOF ANY BIT IN RKER SET,
2862                                     ;IF YES RETURN HERE.
2863 006722 104036          ERROR    36          ;RKER BIT SET ON DOING 1 WORD
2864                                     ;WRITE FORMAT
2865 006724 022711 002202          8$: CMP      #2202,@R1   ;DOES RKCS STILL HAVE 'WRT FMT' BITS?
2866 006730 001406          BEQ     TST16       ;YES, EXIT
2867 006732 012737 002202 001162 MOV      #2202,$REG0 ;GET EXP:TD RKCS
2868 006740 011137 001164 MOV      @R1,$REG1  ;GET ACTUAL RKCS
2869 006744 104024          ERROR    24          ;RKCS DIDN'T CONTAIN 'WRT FMT' BITS
2870                                     ;AFTER THE FUNCTION WAS COMPLETED
2871                                     ;
2872                                     ;*****
2873                                     ;*TEST 16 CHECK 'READ FORMAT' FUNCTION-CYLINDER 0, SECTOR 0
2874                                     ;*THIS TEST CHECKS THE LOGIC INVOLVED IN THE WRITE FMT
2875                                     ;*FUNCTION. ON ISSUING A WRT FMT, THE FOLLOWING IS CHECKED
2876                                     ;*1) CNTRL RDY WAS CLEARED AS GO WAS SET.
2877                                     ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION OF FUNCTION

```

```

2878                                     ;*3) IF 'HE' OR 'ERR' BIT SET?
2879                                     ;*4) IF RKDA INCREMENTED CORRECTLY FROM 0 TO 1?
2880                                     ;*5) IF RKWC OVERFLOWED CORRECTLY TO 0?
2881                                     ;*6) IF RKBA INCREMENTED CORRECTLY BY 2?
2882                                     ;*7) IF ANY BIT IN RKER SET?
2883                                     ;*8) IF THE CORRECT HEADER WAS RECEIVED?
2884                                     ;*9) FOR RK11C, AFTER RD FMT RKDB CONTAINS THE CHECKSUM
2885                                     ;*FOR THAT SECTOR. (125252 IN THIS CASE, BECAUSE THE
2886                                     ;*FIRST WORD IN SEC 0 WAS WRITTEN AS 125252 IN
2887                                     ;*THE PREVIOUS TEST)
2888                                     ;*10) FOR RK11D, AFTER RD FMT RKDB SHOULD CONTAIN
2889                                     ;*A ZERO
2890                                     ;*11) IF THE RD FMT FUNCTION BITS ARE STILL IN
2891                                     ;*THE RKCS?
2892                                     ;*****
2893 TST16: SCOPE
2894 CLR      RO
2895 CNT.RESET          ;GO, DO CONTROL RESET
2896                                     ;THIS IS A CALL FOR THE 'CNTRL-
2897 ;RESET' ROUTINE. A CONTROL RESET IS
2898 ;ISSUED AND AFTER A CERTAIN TIME
2899 ;IF THE 'CNTRL RDY' DOES NOT SET
2900 ;AN ERROR IS REPORTED. NOTE THAT
2901 ;THE PC IN ERROR MESSAGE IS THE
2902 ;PC WHERE 'CNT.RESET' IS LOCATED.
2903 ;THIS IS A VERY BASIC ERR & IF IT
2904 ;OCCURS GO BACK TO TEST 10
2905 006754 104421          TST.SIN          ;GO CHECK IF SIN IS SET
2906                                     ;IF SET, DO DRIVE RESET TO CLR IT
2907 006756 013701 001332          MOV      RKCS,R1
2908 006762 013702 001336          MOV      RKBA,R2
2909 006766 012703 033342          MOV      #OUTBUF,R3
2910 006772 010312          MOV      R3,@R2   ;SETUP ADRS WHERE HEADER WORD IS TO BE
2911                                     ;X-FERRED
2912 006774 012777 177777 172332 MOV      #-1,@RKWC  ;SET UP WORD COUNT
2913 007002 013777 001350 172330 MOV      DRIVAD,@RKDA ;SET UP DISK ADRS, SECTOR 0, CYLINDER 0
2914 007010 012711 002005          MOV      #2005,@R1 ;READ FORMAT, GO
2915
2916 007014 105711          1$: TSTB   @R1          ;WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
2917 007016 100003          BPL     2$          ;YES, BRANCH
2918 007020 004737 021002 JSR      PC,GT3RG   ;GO, GET RKCS, RKER
2919 007024 104030          ERROR    30          ;CNTRL RDY DIDN'T CLEAR AS GO WAS
2920                                     ;SET TO 'READ FORMAT'
2921 007026 005000          2$: CLR      RO          ;
2922 007030 105711          TSTB   @R1          ;WAS 'CNTRL RDY' SET ON COMPLETION OF
2923                                     ;TRANSFER
2924 007032 100411          BMI     3$          ;YES, BRANCH
2925 007034 005200          INC     RO          ;NO, HAVE U WAITED LONG ENOUGH?
2926 007036 001374          BNE    2$+2         ;IF NOT, LOOP BACK & WAIT
2927                                     ;IF YES, REPORT ERROR
2928 007040 004737 020774 JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS,DA
2929 007044 013737 001350 001202 MOV      DRIVAD,$REG10
2930 007052 104416          BRKDA4          ;GO TO 'BDA4' & BREAK CONTENTS OF
2931                                     ;$REG10 INTO DR #.CYL,SUR,SFC BITS
2932 007054 104045          ERROR    45          ;'CNTRL RDY' DIDN'T SET ON COMPLETION
2933                                     ;OF READ FORMAT

```

```

2934                                     :READ FMT WAS DONE STARTING AT <DSK-ADRES>
2935                                     :INDICATED IN EROR MESGE
2936 007056 004737 021234                35: JSR PC,CHKHE :CHECK IF 'ERR' OR 'HE' BIT SET, IF
2937                                     :YES RETURN HERE.
2938 007062 104046                        ERROR 46      : 'HE' OR 'ERR' BIT SET WHILE
2939                                     :DOING A 'READ FORMAT'
2940                                     :READ FMT WAS DONE STARTING AT <DSK-ADRES>
2941                                     :INDICATED IN EROR MESGE
2942 007064 004737 021262                45: JSR PC,CHKDA :CHECK IF RKDA INCREMENTED CORRECTLY
2943                                     :IF NOT, RETURN HERE.
2944 007070 104040                        ERROR 40      :RKDA SHOULD HAVE INCREMENTED
2945                                     :BY 1 SECTOR, IT DID NOT
2946
2947 007072 004737 021316                55: JSR PC,CHKWC :CHECK IF RKWC OVERFLOWED TO 0, IF
2948                                     :NOT RETURN HERE.
2949 007076 104041                        ERROR 41      :RKWC DID NOT OVERFLOW TO 0
2950                                     :AFTER XFER ON READ FORMAT
2951 007100 022712 033344                65: CMP #OUTBUF+2,@R2 :DID RKBA INCREMENT TO NXT WORD ADRES?
2952 007104 001406                        BEQ 75        :YES, BRANCH
2953 007106 012737 033344 001162        MOV #OUTBUF+2,$REG0 :GET EXPCTD RKBA
2954 007114 011237 001164                MOV @R2,$REG1  :GET ACTUAL RKBA
2955 007120 104042                        ERROR 42      :RKBA DIDN'T INCREMENT BY 2 AFTER
2956                                     : 'READ FORMAT' OF 1 WORD
2957 007122 004737 021342                75: JSR PC,CHKER :CHECK IF ANY BIT IN RKER SET, IF
2958                                     :YES RETURN HERE.
2959 007126 104036                        ERROR 36      :RKER BIT SET ON DOING
2960                                     :1 WORD READ FORMAT
2961 007130 005713                        85: TST @R3      :DOES OUTBUF CONTAIN THE HEADER
2962                                     :WORD-0
2963                                     :YES, BRANCH
2964 007132 001407                        BEQ 95        :GET SECTOR NO.
2965 007134 005037 001162                CLR $REG0     :EXPCTD HEADER
2966 007140 005037 001164                CLR $REG1     :GET HEADER RECVD
2967 007144 011337 001166                MOV @R3,$REG2 :CORRECT HEADER WORD-0-WAS
2968 007150 104043                        ERROR 43      :NOT RECEIVED ON READ FORMAT
2969 007152 022711 002204                95: CMP #2204,@R1  :DOES RKCS HAVE THE 'RDFMT' BITS?
2970 007155 001406                        BEQ TST17    :YES, BRANCH
2971 007160 012737 002204 001162        MOV #2204,$REG0 :GET EXPCTD RKCS
2972 007166 011137 001164                MOV @R1,$REG1 :GET ACTUAL RKCS
2973 007172 104024                        ERROR 24      :RKCS DIDN'T CONTAIN 'RD FMT'
2974                                     :BITS AFTER FUNCTION WAS
2975                                     :COMPLETED
2976
2977
2978
2979
2980 ;*****
2981 ;*TEST 17 CHECK 'READ' FUNCTION-CYLINDER 0,SECTOR 0
2982 ;*THIS IS THE FIRST TIME A PURE READ IS PREFORMED IN THIS
2983 ;*TEST SEQUENCE. THE FOLLOWING IS CHECKED
2984 ;*1) CNTRL RDY CLEARS AS GO IS SET
2985 ;*2) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
2986 ;*OF FUNCTION
2987 ;*3) IF 'HE' OR 'ERR' BIT SET?
2988 ;*4) IF RKDA INCREMENTED CORRECTLY?
2989 ;*5) IF RKWC OVERFLOWED TO 0?
2990 ;*6) IF RKBA INCREMENTED CORRECTLY?

```

```

2990                                     :*7) IF ANY RKER BIT SET?
2991                                     :*8) IF THE CORRECT PSUEDO-HEADER (FIRST WORD) WAS
2992                                     :*READ FROM SECTOR 0
2993                                     :*9) IF THE 'READ' FUNCTION BITS ARE STILL IN RKCS
2994
2995 007174 000004                        TST17: SCOPE
2996 007176 104413                        CNT.RESET
2997                                     :GO, DO CONTROL RESET
2998                                     :THIS IS A CALL FOR THE 'CNTRL-
2999                                     :RESET' ROUTINE. A CONTROL RESET IS
3000                                     :ISSUED AND AFTER A CERTAIN TIME
3001                                     :IF THE 'CNTRL RDY' DOES NOT SET
3002                                     :AN ERROR IS REPORTED. NOTE THAT
3003                                     :THE PC IN ERROR MESSAGE IS THE
3004                                     :PC WHERE 'CNT.RESET' IS LOCATED.
3005                                     :THIS IS A VERY BASIC ERR & IF IT
3006 007200 104421                        TST.SIN      :OCCURS GO BACK TO TEST 10
3007                                     :GO CHECK IF SIN IS SET
3008                                     :IF SET, DO DRIVE RESET TO CLR IT
3008 007202 013701 001332                MOV RKCS,R1
3009 007206 005000                        CLR R0
3010 007210 013702 001336                MOV RKBA,R2
3011 007214 012703 033342                MOV #OUTBUF,R3
3012 007220 010312                        MOV R3,@R2
3013                                     :SET UP ADRES WHERE DATA WORD IS
3014 007222 012777 177400 172104          MOV #-400,@RKWC :TO BE X-FERRED
3015 007230 013777 001350 172102          MOV DRIVAD,@RKDA :SET UP WORD COUNT
3016 007236 012711 000005                MOV #5,@R1     :SET UP DISK ADRES, SECTOR 0, CYLINDER 0
3017                                     :READ, GO
3018 007242 105711                        15: TSTB @R1     :WAS 'CNTRL RDY' CLEARED AS GO WAS SET?
3019 007244 100003                        BPL 25        :YES, BRANCH
3020 007246 004737 021002                JSR PC,GT3RG
3021 007252 104030                        ERROR 30      :GO, GET RKCS, ER
3022                                     :CNTRL RDY DID NOT CLEAR AS GO
3023                                     :WAS SET TO 'READ'
3023 007254 005000                        25: CLR R0
3024 007256 105711                        TSTB @R1     :WAS CNTRL RDY SET ON COMPLETION
3025                                     :OF TRANSFER?
3026 007260 100411                        BMI 35        :YES, BRANCH
3027 007262 005200                        INC R0
3028 007264 001374                        BNE 25+2     :NO, HAVE U WAITED LONG ENOUGH?
3029                                     :IF NOT, LOOP BACK & WAIT
3030 007266 004737 020774                JSR PC,GT4RG
3031 007272 013737 001350 001202          MOV DRIVAD,$REG10 :GO TO 'BDA4' & BREAK CONTENTS OF
3032 007300 104416                        MOV BRKDA4    :$REG10 INTO DR #,CYL,SUR,SEC BITS
3033                                     :CNTRL RDY DID NOT SET ON
3034 007302 104045                        ERROR 45      :COMPLETION OF READ
3035                                     :READ WAS DONE STARTING AT <DSK-ADRES>
3036                                     :INDICATED IN EROR MESGE
3037
3038
3039 007304 004737 021234                35: JSR PC,CHKHE :CHECK IF 'ERR' OR 'HE' BIT IS SET
3040                                     :IF YES, RETURN HERE.
3041 007310 104046                        ERROR 46      : 'HE' OR 'ERR' BIT SET WHILE
3042                                     :DOING A READ.
3043                                     :READ WAS DONE STARTING AT <DSK-ADRES>
3044                                     :INDICATED IN EROR MESGE
3045 007312 004737 021262                45: JSR PC,CHKDA :CHECK IF RKDA INCREMENTED CORRECTLY,

```

```

3046                                     ;IF NOT RETURN HERE.
3047 007316 104040                       ERROR 40                       ;RKDA DID NOT INCREMENT
3048                                     ;BY 1 (SECTOR)
3049 007320 004737 021316                 5$: JSR PC,CHKWC                ;CHECK IF RKWC OVERFLOWED TO 0,
3050                                     ;IF NOT RETURN HERE.
3051 007324 104041                       ERROR 41                       ;RKWC DID NOT OVERFLOW TO 0,
3052                                     ;AFTER X-FER ON READ
3053 007326 022712 034342                 6$: CMP #OUTBUF+1000,@R2        ;DID RKBA INCREMENT CORRECTLY?
3054 007332 001406                       BEQ 7$                          ;YES, BRANCH
3055 007334 012737 034342 001162         MOV #OUTBUF+1000,$REG0          ;GET EXPCTD RKBA
3056 007342 011237 001164                 MOV @R2,$REG1                  ;GET ACTUAL RKBA
3057 007346 104042                       ERROR 42                       ;RKBA DID NOT INCREMENT BY 2
3058                                     ;AFTER 'READ' OF 1 WORD
3059 007350 004737 021342                 7$: JSR PC,CHKER                ;CHECK IF ANY BIT IN RKER SET,
3060                                     ;IF YES RETURN HERE.
3061 007354 104036                       ERROR 36                       ;RKER BIT SET ON DOING 1
3062                                     ;WORD 'READ'
3063 007356 022713 000001                 8$: CMP #1,@R3                 ;DCES OUTBUF CONTAIN THE RIGHT
3064                                     ;DATA WORD
3065 007362 001411                       BEQ 9$                          ;YES BRANCH
3066 007364 012737 000001 001162         MOV #1,$REG0                  ;GET EXPCTD DATA WORD
3067 007372 011337 001164                 MOV (R3),$REG1                ;GET RECVD DATA WORD
3068 007376 013737 001350 001166         MOV DRIVAD,$REG2              ;GET DISK ADRS FROM WHICH READ WAS DONE
3069 007404 104044                       ERROR 44                       ;DID NOT READ THE CORRECT
3070                                     ;DATA WORD--FROM DISK ADRES,
3071                                     ;
3072                                     ;SEC 0, CYL 0, SUR 0
3073                                     ;
3074                                     ;AFTER 1 SECTOR READ RKDB CONTAINS
3075                                     ;FOR RK11C
3076                                     ;THE CHECKSUM FOR THAT SECTOR
3077                                     ;FOR RK11D
3078                                     ;THE LAST WORD TRANSFERRED TO MEMORY
3079                                     ;
3080                                     ;IT SO HAPPENS THAT WITH THE SECTOR
3081                                     ;THAT WAS READ, RKDB CONTAINS THE
3082                                     ;SAME INFORMATION FOR BOTH RK11C
3083                                     ;AND RK11D
3084 007406 022777 125252 171726 9$: CMP #125252,@RKDB            ;DOES RKDB CONTAIN THE EXPCTD WORD?
3085 007414 001407                       BEQ 10$                          ;YES, BRANCH
3086 007416 012737 125252 001162         MOV #125252,$REG0            ;GET EXPCTD RKDB
3087 007424 017737 171712 001164         MOV @RKDB,$REG1              ;GET RECVD RKDB
3088 007432 104037                       ERROR 37                       ;RKDB DOES NOT CONTAIN THE
3089                                     ;EXPCTD WORD AFTER A READ OF SEC 0
3090                                     ;CYL 0
3091 007434 022711 000204                 10$: CMP #204,@R1              ;DOES RKCS HAVE THE 'READ' BITS?
3092 007440 001406                       BEQ 11$                          ;YES, BRANCH
3093 007442 012737 000204 001162         MOV #204,$REG0               ;GET EXPCTD RKCS
3094 007450 011137 001164                 MOV @R1,$REG1                ;GET RECVD RKCS
3095 007454 104024                       ERROR 24                       ;RKCS DID NOT CONTAIN 'READ'
3096                                     ;FUNCTION BITS AFTER OPERATION
3097                                     ;WAS COMPLETED
3098 007456 104413                       11$: CNT.RESET                 ;GO DO CONTROL RESET
3099 007460 005777 171656                 TST @RKDB                     ;DID CONTROL RESET CLEAR RKDB?
3100 007464 001407                       BEQ TST20                       ;YES, EXIT
3101 007466 013737 001342 001164         MOV RKDB,$REG1               ;GET ADRES OF RKDB

```

```

3102 007474 017737 171642 001164         MOV @RKDB,$REG1              ;GET CONTENTS OF RKDB
3103 007502 104102                       ERROR 102                       ;CONTROL RESET DIDN'T CLR RKDB
3104
3105                                     ;*****
3106                                     ;*TEST 20 CHECK 'WRITE FORMAT' -CYLINDER 0, SECTOR 0-13
3107                                     ;*THIS TEST GOES ONE STEP FURTHER & PERFORMS A WRT
3108                                     ;*FMT ON CYLINDER 0 & CHECKS THE FOLLOWING
3109                                     ;*1) IF CNTRL RDY SET WITHIN A CERTAIN TIME ON COMPLETION
3110                                     ;*OF THE FUNCTION
3111                                     ;*2) IF 'HE' OR 'ERR' BIT SET?
3112                                     ;*3) IF THE RKDA INCREMENTS CORRECTLY?
3113                                     ;*4) IF THE RKDB IS CLEAR?
3114                                     ;*WRT FMT IS DONE ONE SECTOR AT A TIME
3115                                     ;*THE FIRST WORD OF EVERY SECTOR IS WRITTEN AS A
3116                                     ;*PSUEDO-HEADER CONSISTING OF DRIVE #, CYLINDER #, SURFACE
3117                                     ;*& SECTOR #. THIS WILL BE READ & CHECKED IN THE FOLLOWING TEST.
3118                                     ;*****
3119 007504 000004                       TST20: SCOPE
3120 007506 013703 001332                 MOV RKCS,R3
3121 007512 012702 177764                 MOV #-14,R2                   ;SET UP COUNT FOR 12 SECTORS
3122 007516 013704 001340                 MOV RKDA,R4
3123 007522 013701 001350                 MOV DRIVAD,R1                 ;GET DRIVE ADDRESS
3124 007526 010105                       MOV R1,R5                     ;STORE IT
3125 007530 005205                       INC R5
3126 007532 012737 007540 001110         MOV #1$,$LPERR               ;SET RETURN ADRES FOR LUPING
3127                                     ;ON ERROR (SW 9)
3128 007540 104413                       1$: CNT.RESET                 ;GO, DO CONTROL RESET
3129                                     ;THIS IS A CALL FOR THE 'CNTRL-
3130                                     ;RESET' ROUTINE. A CONTROL RESET IS
3131                                     ;ISSUED AND AFTER A CERTAIN TIME
3132                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3133                                     ;AN ERROR IS REPORTED. NOTE THAT
3134                                     ;THE PC IN ERROR MESSAGE IS THE
3135                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3136                                     ;THIS IS A VERY BASIC ERR & IF IT
3137                                     ;OCCURS GO BACK TO TEST 10
3138 007542 104421                       TST.SIN                         ;GO CHECK IF SIN IS SET
3139                                     ;IF SET, DO DRIVE RESET TO CLR IT
3140 007544 005000                       CLR R0
3141 007546 010137 033342                 MOV R1,OUTBUF                ;THIS WORD TO BE X-FERRED. FIRST
3142                                     ;WORD OF EACH SECTOR WILL BE THE
3143                                     ;ACTUAL DRIVE-ADRS CONSISTING OF
3144                                     ;DRIVE NO, CYL ADRES, SURFACE
3145                                     ;SECTOR NO.
3146 007552 012777 033342 171556         MOV #OUTBUF,@RKBA            ;ADRS FROM WHICH DATA WORD IS TO
3147                                     ;X-FERRED
3148 007560 012777 177777 171546         MOV #-1,@RKWC                ;SET UP WORD COUNT
3149 007566 010114                       MOV R1,@R4                    ;ADRS THE DRIVE, CYL 0, & CORRECT SECTOR
3150 007570 012713 002003                 MOV #2003,@R3                ;WRITE FORMAT, GO
3151
3152 007574 105777 171532                 2$: TSTB @RKCS                ;DID 'CNTRL RDY' SET?
3153 007600 100410                       BMI 3$                          ;YES, BRANCH
3154 007602 005200                       INC R0                        ;NO, HAVE U WAITED LONG?
3155 007604 001373                       BNE 2$                          ;IF NOT, LOOP BACK & WAIT
3156                                     ;IF YES, REPORT ERROR
3157 007606 004737 020774                 JSR PC,GT4RG                 ;GO, GET RKCS, ER, DS,DA

```



```

3270 ;RKBA SHOULD INCREMENT BY 24 BYTES
3271 ;AT THE END OF X-FER
3272 010032 022777 033372 171276 4$: CMP #OUTBUF+30,@RKBA ;DID RKBA INCREMENT CORRECTLY?
3273 010040 001407 BEQ 5$ ;YES, BRANCH
3274 010042 012737 033372 001162 MOV #OUTBUF+30,$REG0 ;GET EXPCTD RKBA
3275 010050 017737 171262 001164 MOV @RKBA,$REG1 ;GET ACTUAL RKBA
3276 010056 104042 ERROR 42 ;RKBA DID NOT INCREMENT CORRECTLY
3277 ;AFTER READ FORMAT OF 12 HEADERS
3278 010060 004737 021316 5$: JSR PC,CHKWC ;GO CHECK IF RKWC OVERFLOWED TO 0
3279 ;IF NOT RETURN HERE.
3280 010064 104041 ERROR 41 ;RKWC DID NOT OVERFLOW TO 0
3281 ;AFTER 'RD FMT' OF 12 HEADERS
3282 ;OF CYLINDER 0
3283 010066 005724 6$: TST (R4)+ ;WAS THE CORRECT HEADER RECEIVED?
3284 010070 001413 BEQ 7$ ;YES, BRANCH
3285 010072 010037 001162 MOV R0,$REG0 ;GET SECTOR FOR WHICH THE HEADER
3286 010076 062737 000014 001162 ADD #14,$REG0 ;COULD NOT BE READ CORRECT
3287 010104 005037 001164 CLR $REG1 ;EXPTD HEADER=0, FOR CYL 0
3288 010110 014437 001166 MOV -(R4),$REG2 ;GET WRONG HEADER RECVD
3289 010114 104043 ERROR 43 ;HEADER WAS NOT READ RIGHT FOR
3290 ;SECTOR (AS IN ER MSGE), & CYL 0
3291 010116 005724 7$: TST (R4)+ ;WAS THE CORRECT HEADER RECVD?
3292 010120 005200 INC R0 ;YES, HAVE U CHECKED FOR ALL 12 SECTORS?
3293 010122 001361 BNE 6$ ;IF NOT, LOOP BACK & CHK HDR FRM NXT SECTR
3294
3295 010124 004737 021342 JSR PC,CHKER ;CHECK IF ANY BIT IN RKER IS SET,
3296 ;IF YES, RETURN HERE.
3297 010130 104036 ERROR 36 ;RKER BIT SET ON DOING RD FMT
3298 ;OF CYL 0, SECTORS 0-13
3299 010132 022711 002204 8$: CMP #2204,@R1 ;DOES RKCS STILL CONTAIN FUNCTION BITS?
3300 010136 001406 BEQ TST22 ;YES, EXIT
3301 010140 012737 002204 001164 MOV #2204,$REG0 ;GET EXPCTD RKCS
3302 010146 011137 001164 MOV @R1,$REG1 ;GET ACTUAL RKCS
3303 010152 104024 ERROR 24 ;RKCS DID NOT CONTAIN 'RD F.T'
3304 ;FUNCTION BITS ON COMPETION OF
3305 ;THE FUNCTION
3306
3307
3308
3309
3310 ;*****
3311 ;*TEST 22 CHECK 'READ', CYLINDER 0, SECTORS 0 TO 13
3312 ;*THIS TEST PERFORMS A READ OF ALL THE SECTORS OF CYLINDER 0
3313 ;*8 CHECKS THE FOLLOWING
3314 ;*1) CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3315 ;*OF THE FUNCTION
3316 ;*2) IF 'HE' OR 'ERR' BIT SET?
3317 ;*3) IF THE CORRECT PSUEDO-HEADER (FIRST WORD OF EVERY
3318 ;*SECTOR, WRITTEN IN A PREVIOUS TEST) WAS RECEIVED.
3319 ;*4) IF RKCS CONTAINS THE CORRECT WORD.
3320 ;*4) IF RKDA INCREMENTED CORRECTLY.
3321 ;*5) IF REST OF THE (377) WORDS IN EACH SECTOR ARE '0', NOTE
3322 ;*PREVIOUSLY ONE WORD WAS WRITTEN PER SECTOR.
3323 ;*6) IF RKCS STILL CONTAINS THE 'READ' FUNCTION BITS
3324 ;*7) IF CONTROL RESET CLEARS RKDB.
3325 ;* IF TESTING IS BEING DONE ON A SIMULATOR ONLY LAST SECTOR(13)
;*IS READ BECAUSE THE SIMULATOR CAN STORE ONLY 1 SECTOR (256 WORDS).

```

```

3326 ;*HENCE ONLY THE DATA WRITTEN LAST CAN BE READ BACK.
3327 ;*****
3328 010154 000004 TST22: SCOPE
3329 010156 012737 010230 001110 MOV #1$,$LPERR ;SET RETURN ADRES FOR LUPING
3330 ;ON ERROR (SW 9)
3331 010164 013703 001332 MOV RKCS,R3
3332 010170 013701 001350 MOV DRIVAD,R1
3333 010174 010105 MOV R1,R5
3334 010176 012704 033342 MOV #OUTBUF,R4
3335 010202 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
3336 010206 001405 BEQ 9$ ;NO, BRANCH
3337 ;IF TESTING ON SIMULATOR READ
3338 ;SECTOR 13 ONLY
3339 010210 052701 000013 BIS #13,R1 ;SET BITS FOR SEC 13
3340 010214 052705 000020 BIS #20,R5 ;RKDA SHOULD INCRMNT TO THIS AFTER READ
3341 010220 000403 BR 1$
3342 010222 012702 177764 9$: MOV #-14,R2 ;SET COUNT FOR 12 SECTORS
3343 010226 005205 INC R5 ;RKDA SHOULD INCREMENT TO
;THIS AFTER 1 SECTOR READ
3344 ;GO, DO CONTROL RESET
3345 010230 104413 1$: CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
3346 ;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10
3347 ;GO CHECK IF SIN IS SET
3348 ;IF SET, DO DRIVE RESET TO CLR IT
3349 ;ADDRESS THE DRIVE
3350 ;ADRS TO WHICH X-FER DATA FROM DISK
3351 ;SETUP WORD COUNT
3352 ;READ,GO
3353
3354
3355 010232 104421 TST.SIN
3356
3357 010234 010177 171100 MOV R1,@RKDA
3358 010240 010477 171072 MOV R4,@RKBA
3359 010244 012777 177400 171062 MOV #-400,@RKWC
3360 010252 012713 000005 MOV #5,@R3
3361
3362 010256 005000 CLR R0
3363 010260 105713 2$: TSTB @R3 ;DID CNTRL RDY SET ON COMPETION?
3364 010262 100410 BMI 3$ ;YES, BRANCH
3365 010264 005200 INC R0 ;NO, WAIT FOR IT TO SET
3366 010266 001374 BNE 2$ ;IF WAITED LONG ENOUGH, REPORT
;ERROR, OTHERWISE LOOP BAK & WAIT
3367 ;GO, GET RKCS, ER, DS,DA
3368 010270 004737 020774 JSR PC,GT4RG ;GET SECTOR ADDRESS WHERE ERROR OCCURED
3369 010274 010137 001202 MOV R1,$REG10 ;GO TO 'BDA4' & BREAK CONTENTS OF
;SREG10 INTO DR #,CYL,SUR,SEC BITS
3370 010300 104416 BRKDA4 ;CNTRL RDY DID NOT SET ON COMPLETION
;OF READ OF CYLINDER 0, SECTOR
;AS SHOWN IN <DSK-ADRES>
3371 ;READ WAS DONE STARTING AT <DSK-ADRES>
3372 010302 104045 ERROR 45 ;INDICATED IN EROR MESGE
3373 ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
3374 ;IF YES RETURN HERE.
3375 ;HE OR ERR BIT SET
3376 ;ON 'READ' OF CYLINDER 0, SECTOR
3377 010304 004737 021226 3$: JSR PC,CHKHE1 ;AS SHOWN IN <DSK-ADRES>
3378
3379 010310 104046 ERROR 46
3380
3381

```

```
3382                                     ;READ WAS DONE STARTING AT <DSK-ADRES>
3383                                     ;INDICATED IN EROR MESGE
3384 010312 020114 4$: CMP R1,(R4) ;WAS THE DATA WORD RECVD, CORRECT?
3385                                     ;THE FIRST DATA WORD OF EACH SECTOR
3386                                     ;IS AN ADRS WORD COMPRISING OF DRIVE NO,
3387                                     ;CYLINDER ADRS, SUR, SECTOR ADRS
3388 010314 001407 BEQ 5$ ;GET EXPCTD DATA WORD FROM DISK
3389 010316 010137 001162 MOV R1,$REG0 ;GET THE DATA WORD RECVD
3390 010322 011437 001164 MOV (R4),$REG1 ;GET DISK ADRES
3391 010326 010137 001166 MOV R1,$REG2 ;DID NOT RECIEVE CORRECT DATA WCROD ON
3392 010332 104044 ERROR 44 ;READ, OF CYLINDER 0, SECTOR AS SHOWN IN 'DSK
3393                                     ;ADRES' OF EXPCTD DATA WORD
3394 010334 004737 021270 5$: JSR PC,CHKDA1 ;CHECK IF RKDA INCREMENTED CORRECTLY,
3395                                     ;IF NOT RETURN HERE.
3396 ERROR 40 ;RKDA DID NOT INCREMENT CORRECTLY
3397 010340 104040 ;AFTER READ OF 1 WORD, FROM CYL 0
3398                                     ;SEC IN ERROR IS 1 LESS THAN THAT
3399                                     ;SHOWN IN EXPCTD RKDA
3400
3401
3402                                     ;AS A RESULT OF 'WRT FMT' IN A PREVIOUS TEST
3403                                     ;FIRST WORD OF EVERY SECTOR IS NON-
3404                                     ;ZERO (PSUEDO-HDR), REST 377 WORDS
3405                                     ;ARE ALL 0'S.
3406                                     ;CHECK IF THE REST OF THE 377
3407                                     ;WORDS ARE ALL 0'S
3408 010342 012737 177775 001370 MOV #-3,EFLG1 ;ALLOW ONLY 3 ERRORS
3409 010350 012700 033344 MOV #OUTBUF+2,R0 ;INITIALIZE PTR TO 2ND WRD IN BUFR
3410 010354 012737 177401 001362 MOV #-377,COUNT ;CHECK 377 WORDS IN THE BUFFER
3411 010362 005710 11$: TST @R0 ;IS THIS WRD 0?
3412 010364 001005 BNE 12$ ;NO, ERROR
3413 010366 005720 TST (R0)+ ;INCRMNT PTR TO NXT WRD
3414 010370 005237 001362 INC COUNT ;CHKD ALL 377 WRDS?
3415 010374 001372 BNE 11$
3416 010376 000412 BR 7$ ;YES, BRANCH
3417 010400 005037 001162 12$: CLR $REG0 ;GET EXPCTD WORD
3418 010404 012037 001164 MOV (R0)+,$REG1 ;GET WORD RECVD
3419 010410 010137 001166 MOV R1,$REG2 ;GET DISK ADRES, ERROR IN THIS
3420                                     ;SECTOR
3421 010414 104044 ERROR 44 ;DATA ERROR, THE LAST 377 WORDS
3422                                     ;READ FROM EACH SECTOR SHOULD BE 0
3423                                     ;IN A PREVIOUS TEST, FIRST WORD OF
3424                                     ;EVERY SEC (CYL 0) WAS WRITTEN AS A
3425                                     ;PSUEDO-HDR, REST OF THE WORDS IN THE
3426                                     ;SECTR ARE AUTOMATICALLY WRITTEN AS
3427                                     ;0'S. THIS ERROR MAY MEAN THAT IT
3428                                     ;DIDN'T HAPPEN SO
3429 010416 005237 001370 INC EFLG1 ;ALLOW ONLY 3 DATA ERORS OF THIS KIND
3430 010422 001357 BNE 11$
3431
3432
3433 010424 005737 001344 7$: TST SIMUL ;TESTING ON SIMULATOR?
3434 010430 001011 BNE 10$ ;YES BRANCH
3435                                     ;IF NOT TESTING ON SIMULATOR GO AHEAD
3436                                     ; & READ ALL 12 SECTORS ON CYL 0
3437 010432 005201 INC R1 ;INCREMENT DRIV-ADRES TO NXT SECTOR
```

```
3438 010434 005205 INC R5 ;INCREMENT 'EXPCTD DRIV-ADRES'
3439 010436 122705 000014 CMPB #14,R5 ;R U GOING TO READ THE LAST SECTOR?
3440 010442 001002 BNE .+6 ;IF NOT, BRANCH
3441 010444 062705 000004 ADD #4,R5 ;IF YES, INCREMENT 'EXPCTD RKDA'
3442                                     ;CORRECTLY
3443 010450 005202 INC R2 ;HAVE U READ ALL 12 SECTORS?
3444 010452 001266 BNE 1$ ;IF NOT LOOP BACK & READ THE
3445                                     ;NXT SECTOR
3446 010454 022713 000204 10$: CMP #204,@R3 ;DOES RKCS, STILL HAVE THE 'READ' FUNCTION
3447 010460 001406 BEQ 8$ ;YES, BRANCH
3448 010462 012737 000204 001162 MOV #204,$REG0 ;GET EXPCTD RKCS
3449 010470 011337 001164 MOV @R3,$REG1 ;GET RKCS RECVD
3450 010474 104024 ERROR 24 ;RKCS SHOULD STILL CONTAIN THE 'READ'
3451                                     ;FUNCTION BITS
3452 010476 104413 8$: CNT.RESET ;GO ,DC CONTROL RESET
3453                                     ;THIS IS A CALL FOR THE 'CNTRL-
3454                                     ;RESET' ROUTINE. A CONTROL RESET IS
3455                                     ;ISSUED AND AFTER A CERTAIN TIME
3456                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3457                                     ;AN ERROR IS REPORTED. NOTE THAT
3458                                     ;THE PC IN ERROR MESSAGE IS THE
3459                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3460                                     ;THIS IS A VERY BASIC ERR & IF IT
3461                                     ;OCCURS GO BACK TO TEST 10
3462 010500 005777 170636 TST @RKDB ;DID CNTRL RESET CLEAR RKDB?
3463 010504 001407 BEQ TST23 ;YES, EXIT
3464 010506 013737 001342 001162 MOV RKDB,$REG0 ;GET ADRES OF RKDB
3465 010514 017737 170622 001164 MOV @RKDB,$REG1 ;GET CONTENTS OF RKDB
3466 010522 104102 ERROR 102 ;CONTROL RESET DID NOT
3467                                     ;CLEAR RKDB
3468
3469
3470
3471
3472 ;*****
3473 ;*TEST 23 CHECK 'WRITE FORMAT' OF THE DISK
3474 ;*THIS TEST WRITE FORMATS THE ENTIRE DISK. THE FIRST
3475 ;*WORD OF EVERY SECTOR IS WRITTEN TO BE A PSUEDO-HEADER
3476 ;*CONSISTING OF THE DRIVE #, CYLINDER #, SURFACE & SECTOR #.
3477 ;*1 SECTOR IS WRITTEN A: A TIME. THE WRITING IS DONE
3478 ;*IN THIS ORDER: CYL 0-SUR 0; CYL 0-SUR 1; CYL 1-SUR 0
3479 ;*CYL 1-SUR 1; CYL 2-SUR 0; CYL 2-SUR 1----- CYL 312-SUR 1.
3480 ;*IMPORTANCE OF THIS TEST SHOULD BE REALIZED. THIS IS
3481 ;*THE FIRST TIME EACH & EVERY SECTOR ON THE DISK IS
3482 ;*ACCESSED & WRITTEN ON. THIS IS THE FIRST TIME RKDA
3483 ;*IS BEING MADE TO INCREMENT OVER THE ENTIRE DISK (FROM
3484 ;*000000 TO 014520) IF A 'SIN' OCCURS AT ANY POINT
3485 ;*A DRIVE RESET IS DONE BEFORE DOING WRT FMT FOR THE NEXT
3486 ;*SECTOR. ANY OTHER ERROR IS CLEARED THROUGH A CONTROL RESET.
3487 ;*THE FOLLOWING CHECKING IS DONE AFTER WRITING EACH
3488 ;*CYLINDER.
3489 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3490 ;*OF THE FUNCTION.
3491 ;*2. IF 'SIN' OCCURRED?
3492 ;*3. IF 'HE' OR 'ERR' BIT SET?
3493 ;*4. IF RKDA INCREMENTED CORRECTLY, INCLUDING BOUNDARY
3494 ;*CONDITIONS (SECTOR COUNTER BITS OVERFLOWING INTO SURFACE,
3495 ;*SURFACE BIT OVERFLOWING INTO CYLINDER BITS) AT THE END
```

3494
3495
3496
3497 010524 000004
3498 010526 012737 000001 001206
3499 010534 012737 010564 001110
3500
3501 010542 005003
3502
3503 010544 012704 177465
3504 010550 012702 177764
3505 010554 013701 001350
3506 010560 010105
3507 010562 005205
3508 010564 104413
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518 010566 104421
3519
3520 010570 005037 001362
3521 010574 010137 033342
3522
3523
3524
3525 010600 012777 033342 170530
3526 010606 012777 177777 170520
3527 010614 010177 170520
3528
3529 010620 012777 002003 170504
3530
3531 010626 105777 170500
3532 010632 100411
3533 010634 005237 001362
3534 010640 001372
3535
3536 010642 004737 020774
3537 010646 010137 001202
3538 010652 104416
3539
3540 010654 104031
3541
3542
3543
3544
3545 010656 032777 001000 170442
3546 010664 001405
3547 010666 004737 021002
3548 010672 010137 001170
3549 010676 104001

```

; *OF THIS POINTERS ARE INCREMENTED ADJUSTED, ETC.
; * & 'WRT FMT' ON THE NEXT SECTOR IS DONE.
; *****
TST23: SCOPE
MOV #1,$TIMES ; DO 1 ITERATION
MOV #1,$LPERR ; SET RETURN ADRES FOR LUPING
; ON ERROR (SW 9)
; (R3)=0, SURFACE 0 BEING WRITTEN
; (R3)-1, SURFACE 1 BEING WRITTEN
; SET UP COUNT FOR 203 CYLINDERS
; SET UP COUNT FOR 12 SECTORS
; GET DRIVE ADRES
; STORE IT
CLR R3
MOV #-313,R4
MOV #-14,R2
MOV DRIVAD,R1
MOV R1,R5
INC R5
1$: CNT.RESET ; GO, DO CONTROL RESET
; THIS IS A CALL FOR THE 'CNTRL-
; RESET' ROUTINE. A CONTROL RESET IS
; ISSUED AND AFTER A CERTAIN TIME
; IF THE 'CNTRL RDY' DOES NOT SET
; AN ERROR IS REPORTED. NOTE THAT
; THE PC IN ERROR MESSAGE IS THE
; PC WHERE 'CNT.RESET' IS LOCATED.
; THIS IS A VERY BASIC ERR & IF IT
; OCCURS GO BACK TO TEST 10
; GO CHECK IF SIN IS SET
; IF SET, DO DRIVE RESET TO CLR IT

TST.SIN
7$: CLR COUNT
MOV R1,OUTBUF ; THIS WORD TO BE WRITTEN. THE FIRST
; WORD OF EACH SECTOR WILL BE THE ACTUAL
; DISK-ADRES, CONSISTING OF THE DRIVE NO.,
; CYL ADRES, SURFACE BIT SECTOR ADRES
; ADRES FROM WHICH WORD IS TO B X-FERRED
; SET UP WORD COUNT
; ADRES THE DRIVE, WITH CORRECT CYL
; & SECTOR ADRES
; WRITE FORMAT, GO
MOV #OUTBUF,@RKBA
MOV #-1,@RKWC
MOV R1,@RKDA
MOV #2003,@RKCS
2$: TSTB @RKCS ; DID CNTRL RDY SET
BMI 3$ ; YES, BRANCH
INC COUNT ; NO, HAVE U WAITED LONG ENOUGH?
BNE 2$ ; IF NOT, LOOP BACK & WAIT
; IF YES, REPORT ERROR
; GO, GET RKCS, ER, DS,DA
; GET DISK ADRES, WHERE ERROR OCCURED
; GO TO 'BDA4' & BREAK CONTENTS OF
; $REG10 INTO DR #,CYL,SUR,SEC BITS
; CNTRL RDY DID NOT SET ON COMPLETION
; OF 'WRITE FORMAT', ON SECTGR AS
; SHOWN IN <DSK-ADRES>
; WRT FMT WAS DONE STARTING AT <DSK-ADRES>
; INDICATED IN EROR MSGE.
; DID SIN BIT SET?
; NO, BRANCH
; GO, GET RKCS, ER, DS
; GET, DISK-ADRES WHERE ERROR OCCURED
; SIN SET WHILE DOING WRT FMT
BIT #1000,@RKDS
BEQ 4$
JSR PC,GT3RG
MOV R1,$REG3
ERROR 1

```

3550
3551
3552 010700 004737 021226
3553
3554 010704 104032
3555
3556
3557
3558
3559 010706 004737 021270
3560
3561 010712 104033
3562
3563
3564
3565 010714 005201
3566 010716 005205
3567 010720 022702 177776
3568
3569 010724 001002
3570 010726 062705 000004
3571 010732 005202
3572
3573 010734 001313
3574
3575
3576 010736 012702 177764
3577 010742 042701 000037
3578 010746 005703
3579 010750 001006
3580 010752 005203
3581 010754 062701 000020
3582 010760 010105
3583 010762 005205
3584 010764 000677
3585 010766 062701 000040
3586 010772 010105
3587 010774 005205
3588 010776 005003
3589 011000 005204
3590 011002 001270
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601
3602
3603
3604
3605

```

; TO DISK-ADRES (AS IN $REG3)
4$: JSR PC,CHKHE1 ; CHECK IF 'ERR' OR 'HE' BIT IS SET
; IF YES, RETURN HERE.
; HE OR ERR SET WHILE DOING WRITE
; FORMAT ON SECTOR AS INDICATED IN
; <DSK-ADRES>
; WRT FMT WAS DONE STARTING AT <DSK-ADRES>
; INDICATED IN EROR MSGE.
5$: JSR PC,CHKDA1 ; CHECK IF RKDA INCREMENTED CORRECTLY,
; IF NOT, RETURN HERE.
; RKDA DID NOT INCREMENT CORRECTLY
; AFTER 'WRITE FORMAT' WAS DONE
; TO THE SECTOR PREVIOUS TO THAT
; INDICATED IN 'EXPCTD' RKDA
; INCREMENT TO THE NXT SECTOR
; INCREMENT R5, TO WHAT RKDA WILL INCREMENT
; R U GOING TO FORMAT THE LAST SECTOR
; IN THE CYLINDER ?
; IF NOT, BRANCH
; INCREMENT R5 CORRECTLY TO 'EXPCTD RKDA'
; HAVE U FORMATTED ALL 12 SECTORS
; ON THIS CYLINDER
; IF NOT, LOOP BACK & FORMAT THE
; NEXT SECTOR
; YES
; RESET THE COUNT FOR 12 SECTORS
; CLEAR THE SEC ADRES BITS
; SURFACE 1?
; YES, BRANCH
; NO, SET FLAG
; INCREMENT TO THE NXT SURFACE
; THIS IS WHAT RKDA SHOULD
; INCREMENT TO.
; GO, DO NXT SURFACE
; INCREMENT TO NXT CYL
; POSITION FOR
; EXPCTD RKDA
; HAVE U FORMATTED ALL 203 CYLINDERS
; IF NOT, LOOP BACK & FORMAT THE
; NEXT CYLINDER
6$: INC R1
INC R5
CMP #-2,R2
BNE .+6
ADD #4,R5
INC R2
BNE 1$
MOV #-14,R2
BIC #37,R1
TST R3
BNE 8$
INC R3
ADD #20,R1
MOV R1,R5
INC R5
BR 1$
8$: ADD #40,R1
MOV R1,R5
INC R5
CLR R3
INC R4
BNE 1$
; *****
; *TEST 24 CHECK 'READ FORMAT' FOR THE ENTIRE DISK
; *THIS TEST READ FORMATS THE ENTIRE DISK, WHICH WAS WRT
; *FORMATTED IN THE PREVIOUS TEST. THE FOLLOWING CHECKING
; *IS DONE
; *1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
; *OF FUNCTION
; *2. IF 'SIN' OCCURRED?
; *3. IF 'HE' OR 'ERR' OCCURRED?
; *4. RKDA INCREMENTED CORRECTLY.
; *5. IF THE CORRECT HEADER WAS READ.

```

```

3606 ;*6. IF RKWC OVERFLOWED CORRECTLY.
3607 ;*12 SECTORS (1 CYLINDER) ARE READ AT A TIME. IF 'SIN'
3608 ;*OCCURS A DRIVE RESET IS DONE BEFORE READING THE NEXT
3609 ;*SECTOR. READING IS DONE IN THIS ORDER: CYL 0-SUR 0;
3610 ;*CYL 0-SUR 1; CYL 1-SUR 0; CYL 1-SUR 1; CYL 2-SUR 0;
3611 ;*CYL 2-SUR 1;-----CYL 312-SUR 1. IF TESTING ON SIMULATOR, ONLY
3612 ;*THE LAST CYLINDER (312), LAST SECTOR (13), SURFACE 1 IS READ.
3613 ;*****
3614 011004 000004 TST24: SCOPE
3615 011006 012737 000001 001206 MOV #1,$TIMES ;DO 1 ITERATION
3616 011014 012737 011100 001110 MOV #1,$SLPERR ;SET RETURN ADRES FOR LUPING
3617 ;ON ERROR (SW 9)
3618 011022 005037 001356 CLR INDX1 ;INDX1=0, SURFACE 0 BEING READ
3619 ;INDX1=1, SURFACE 1 BEING READ
3620 011026 013701 001350 MOV DRIVAD,R1 ;GET DRIVE ADRES
3621 011032 010102 R1,R2
3622 011034 005737 001344 TST SIMUL ;TESTING ON SIMULATOR?
3623 011040 001410 BEQ 12$ ;NO, BRANCH
3624 011042 052701 014533 BIS #14533,R1 ;SET BITS FOR CYL 312, SEC 13, SUR 1
3625 ;ON SIMULATOR, CHECK ONLY CYL 312,
3626 ;SECTOR 13, SURFACE 1
3627 011046 052702 014540 BIS #14540,R2 ;RKDA SHOULD INCRMNT TO THIS AFTR
3628 ;RD FMT OF 1 SECTOR
3629 011052 012737 177777 001370 MOV #-1,EFLG1 ;SET COUNT FOR READING HDR
3630 ;FROM 1 SECTOR ONLY
3631 011060 000407 BR 1$
3632 011062 012705 177465 12$: MOV #-313,R5 ;SET UP COUNT FOR 203 CYLINDERS
3633 011066 012737 177764 001370 MOV #-14,EFLG1 ;SET COUNT FOR 12 HDRS TO BE
3634 ;READ FROM EACH CYLINDER
3635 011074 062702 000020 ADD #20,R2 ;THIS IS WHAT RKDA SHOULD INCREMENT
3636 ;BY, AFTER 'RD FMT' OF EACH CYLINDER
3637 011100 104413 1$: CNT.RESET ;GO, DO CONTROL RESET
3638 ;THIS IS A CALL FOR THE 'CNTRL-
3639 ;RESET' ROUTINE. A CONTROL RESET IS
3640 ;ISSUED AND AFTER A CERTAIN TIME
3641 ;IF THE 'CNTRL RDY' DOES NOT SET
3642 ;AN ERROR IS REPORTED. NOTE THAT
3643 ;THE PC IN ERROR MESSAGE IS THE
3644 ;PC WHERE 'CNT.RESET' IS LOCATED.
3645 ;THIS IS A VERY BASIC ERR & IF IT
3646 ;OCCURS GO BACK TO TEST 10
3647
3648 011102 104421 TST.SIN ;CHECK IF SIN IS SET
3649 ;IF SET DO DRV-RESET TO CLR IT
3650
3651 011104 012703 033342 11$: MOV #OUTBUF,R3 ;STORE ADRES OF BUFFER
3652 011110 005037 001360 CLR INDX2
3653 011114 010377 170216 MOV R3,@RKBA ;ADRES TO WHICH DATA IS TO BE X-FERRED
3654 ;FROM THE DISK
3655 011120 013777 001370 170206 MOV EFLG1,@RKWC ;SET UP WORD COUNT FOR 12 HEADERS
3656 ;TO BE READ OFF EACH CYLINDER
3657 ;(ONLY 1 FOR SIMULATOR)
3658 011126 010177 170206 MOV R1,@RKDA ;ADRES THE DRIVE WITH CORRECT
3659 ;CYLINDER & SECTOR ADRES
3660 011132 012777 002005 170172 MOV #2005,@RKCS ;READ FORMAT, GO
3661

```

```

3662 011140 105777 170166 2$: TSTB @RKCS ;DID CNTRL RDY SET?
3663 011144 100411 BMI 3$ ;YES, BRANCH
3664 011146 005237 001360 INC INDX2 ;NO, HAVE U WAITED LONG ENOUGH?
3665 011152 001372 BNE 2$ ;IF NOT, LOOP BACK & WAIT FOR IT
3666 ;IF YES, REPORT ERROR
3667 011154 004737 020774 JSR PC,GT4RG ;GO, GET RKCS, ER, DS,DA
3668 011160 010137 001202 MOV R1,$REG10 ;GET DRIV-ADRES STARTING WHICH
3669 ;'READ FORMAT' WAS DONE
3670 011164 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3671 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3672 011166 104045 ERROR 45 ;CNTRL RDY DID NOT SET AFTER
3673 ;READ FORMAT. 'RKDA' IN EROR MSGE
3674 ;GIVES THE CONTENTS OF RKDA AT THE
3675 ;TIME OF ERROR.
3676 ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
3677 ;INDICATED IN EROR MSGE.
3678
3679 011170 032777 001000 170130 3$: BIT #1000,@RKDS ;DID 'SIN' SET?
3680 011176 001405 BEQ 4$ ;NO, BRANCH
3681 011200 004737 021002 JSR PC,GT3RG ;GO, GET RKCS, ER, DS
3682 011204 010137 001170 MOV R1,$REG3 ;GET DISK-ADRES WHERE 'SIN'
3683 ;OCCURED
3684 011210 104001 ERROR 1 ;SIN ERROR ON DOING RD FMT
3685 ;TO CYL INDICATED IN $REG3
3686
3687 011212 004737 021226 4$: JSR PC,CHKHE1 ;CHECK IF 'ERR' OR 'HE' BIT IS SET.
3688 ;IF YES, RETURN HERE.
3689 011216 104046 ERROR 46 ;HE OR ERR WHILE DOING A READ
3690 ;FORMAT. 'RKDA' IN EROR MSGE GIVES
3691 ;THE CONTENTS OF RKDA AT THE TIME OF ERROR
3692 ;READ FMT WAS DONE STARTING AT <DSK-ADRES>
3693 ;INDICATED IN EROR MSGE
3694 ;DID RKDA INCREMENT CORRECTLY BY 12 SEC
3694 011220 020277 170114 5$: CMP R2,@RKDA
3695 011224 001410 BEQ 6$
3696 011226 010237 001202 MOV R2,$REG10 ;GET EXPCTD RKDA
3697 011232 104415 BRKDA0 ;GO TO 'BDA0' & BREAK CONTENTS OF
3698 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3699 011234 017737 170100 001202 MOV @RKDA,$REG10 ;GET RECVD RKDA
3700 011242 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
3701 ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3702 011244 104040 ERROR 40 ;RKDA DID NOT INCREMENT BY 12 SECTORS
3703 ;AFTER RD FMT WAS DONE. ADRES
3704 ;OF CYLINDER IN ERROR CAN BE OBTAINED
3705 ;FROM 'EXPCTD' RKDA
3706 011246 013700 001370 6$: MOV EFLG1,R0 ;SET UP COUNT FOR 12 HEADERS TO B CHKD
3707 ;(ONLY 1 IF SIMULATOR)
3708 011252 010104 MOV R1,R4 ;GET DRIV-ADRES FROM WHERE RDFMT WAS DONE
3709 011254 042704 160037 BIC #160037,R4 ;GET THE CYLINDER ADRES ONLY. (HEADER)
3710 011260 020413 CMP R4,(R3) ;IS THE RECVD HEADER SAME AS EXPCTD?
3711 011262 001412 BEQ 8$
3712 011264 010437 001164 MOV R4,$REG1 ;GET EXPCTD HEADER WORD
3713 011270 011337 001166 MOV (R3),$REG2 ;GET HEADER WORD RECVD
3714 011274 010037 001162 MOV R0,$REG0
3715 011300 062737 000014 001162 ADD #14,$REG0 ;GET THE SECTOR (OCTAL NO) WHICH DID
3716 ;NOT GIVE THE CORRECT HEADER
3717 011306 104043 ERROR 43 ;DID NOT RECIEVE THE CORRECT HEADER

```

```

3718                                     ;WORD FROM 'SECTOR' AS INDICATED
3719                                     ;(NOTE SECTOR # IS OCTAL)
3720 011310 005723          BS:  TST  (R3)+      ;INCREMENT POINTER TO THE NXT WORD
3721                                     ;IN MEMORY WHERE THE RECVD HDR IS STORED
3722 011312 005200          INC  R0           ;HAVE U CHECKED ALL 12 HEADERS?
3723 011314 001361          BNE  7$         ;IF NOT, LOOP BACK & CHK THE NXT.
3724                                     ;YES, ALL HEADERS FOR THIS CYLINDER
3725                                     ;CHECKED.
3726 011316 004737 021316    JSR  PC,CHKWC   ;CHECK IF RKWC OVERFLOWED TO 0, IF
3727                                     ;NOT RETURN HERE.
3728 011322 104041          ERROR 41        ;RKWC DID NOT OVERFLOW AFTER DOING
3729                                     ;RDFMT OF 12 SECTORS ON THE CYLINDER
3730                                     ;NOTE THAT 'RKDA' IS THE INCREMENTED
3731                                     ;RKDA AFTER THE RDFMT
3732 011324 005737 001344    9$:  TST  SIMUL   ;TSTING ON SIMULATOR?
3733 011330 001031          BNE  TST25     ;:IF YES, EXIT
3734                                     ;NO
3735 011332 005737 001356    TST  INDX1   ;DOING SURFACE 1
3736 011336 001011          BNE  10$        ;YES, BRANCH
3737 011340 005237 001356    INC  INDX1   ;NO
3738 011344 062701 000020    ADD  #20,R1  ;INCREMENT DRIV ADRES TO THE NXT SURFACE
3739 011350 010102          MOV  R1,R2
3740 011352 062702 000020    ADD  #20,R2
3741                                     ;THIS IS WHAT RKDA SHOULD INCREMENT
3742 011356 000137 011100    JMP  1$         ;TO, AFTER READ FMT OF THE CYLINDER
3743 011362 005037 001356    10$: CLR  INDX1   ;GO RD FMT THE NXT SURFACE
3744 011366 042701 000037    BIC  #37,R1   ;CLR SEC, SURFACE BITS
3745 011372 062701 000040    ADD  #40,R1   ;INCREMENT TO NXT CYL
3746 011376 010102          MOV  R1,R2   ;THIS IS WHAT RKDA SHOULD BE
3747 011400 062702 000020    ADD  #20,R2   ;AFTER RD FMT OF CYLINDER
3748 011404 005205          INC  R5       ;HAVE U DONE ALL CYLINDERS?
3749 011406 001402          BEQ  TST25     ;EXIT
3750 011410 000137 011100    JMP  1$         ;IF NOT, LOOP BACK & READ FMT FROM
3751                                     ;THE NXT CYLINDER
3752
3753
3754
3755 ;*****
3756 ;*TEST 25 CHECK 'READ' OF THE ENTIRE DISK
3757 ;*READ OF THE ENTIRE DISK (ONE WORD PER SECTOR) IS DONE
3758 ;*IN THIS TEST. IN A PREVIOUS TEST THE FIRST WORD OF
3759 ;*EVERY SECTOR WAS WRITTEN LIKE A PSUEDO-HEADER (DRIVE #,
3760 ;*CYLINDER #, SURFACE & SECTOR #). THESE PSUEDO HEADERS
3761 ;*WILL BE READ & CHECKED IN THIS TEST, PROVING THAT ANY
3762 ;*SECTOR CAN BE ACCESSED AND READ.
3763 ;*THE FOLLOWING CHECKING IS DONE
3764 ;*1. CNTRL RDY SETS WITHIN A CERTAIN TIME ON COMPLETION
3765 ;*OF FUNCTION.
3766 ;*2. IF 'SIN' OCCURRED?
3767 ;*3. IF 'SIN' OR 'ERR' OCCURRED?
3768 ;*4. THE CORRECT FIRST WORD FROM EVERY SECTOR
3769 ;*WAS RECEIVED. THIS WORD REFLECTS THE ABSOLUTE
3770 ;*DISK ADDRESS (DRV #, CYL #, SUR, SEC#) OF THAT SECTOR.
3771 ;*5. IF RKDB CONTAINED THE CORRECT WORD.
3772 ;*IF 'SIN' OCCURS DRIVE RESET IS DONE BEFORE READING
3773 ;*THE NEXT SECTOR. READ IS DONE IN THIS ORDER SEC 0-11
3774 ;*CYL 0 SUR 0 -> SEC 0-11 CYL 0 SUR 1 -> SEC 0-11 CYL 1,....

```

```

3774                                     ;:IF TESTING ON SIMULATOR ONLY LAST CYLINDER (312), LAST
3775                                     ;:SECTOR (13), SURFACE 1 IS READ.
3776 ;*****
3777 011414 000004          TST25: SCOPE
3778 011416 012737 000001 001206    MOV  #1,$TIMES  ;:DO 1 ITERATION
3779 011424 012737 011470 001110    MOV  #1,$LPERR  ;SET RETURN ADRES FOR
3780                                     ;LOOPING ON ERROR (SW9)
3781 011432 012703 033342          MOV  #OUTBUF,R3
3782 011436 005004          CLR  R4       ;FLAG, CLEAR WHEN READING SURFACE 0
3783                                     ;SET WHEN READING SURFACE 1
3784 011440 013701 001350          MOV  DRIVAD,R1 ;GET DRIVE ADDRESS
3785 011444 005737 001344          TST  SIMUL   ;TSTING ON SIMULATOR?
3786 011450 001403          BEQ  10$        ;IF NOT BRANCH
3787 011452 052701 014533          BIS  #14533,R1 ;SET ADRES BITS FOR LAST CYL (312)
3788 011456 000404          BR   1$         ;LAST SECTOR (13), SURFACE 1
3789 011460 012700 177764          10$: MOV  #-14,R0 ;SET COUNT FOR 12 SECTORS
3790 011464 012705 177465          MOV  #-313,R5 ;SET UP COUNT FOR 203 CYLINDERS
3791
3792 011470 104413          1$:  CNT.RESET  ;GO, DO CONTROL RESET
3793                                     ;THIS IS A CALL FOR THE 'CNTRL-
3794                                     ;RESET' ROUTINE. A CONTROL RESET IS
3795                                     ;ISSUED AND AFTER A CERTAIN TIME
3796                                     ;IF THE 'CNTRL RDY' DOES NOT SET
3797                                     ;AN ERROR IS REPORTED. NOTE THAT
3798                                     ;THE PC IN ERROR MESSAGE IS THE
3799                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
3800                                     ;THIS IS A VERY BASIC ERR & IF IT
3801                                     ;OCCURS GO BACK TO TEST 10
3802 011472 104421          TST.SIN   ;GO CHECK SIN, IF SET DO
3803                                     ;DRIVE RESET TO CLR IT
3804 011474 005037 001356          8$:  CLR  INDX1   ;ADRES TO WHICH DATA IS TO B X-FERKED
3805 011500 010377 167632          MOV  R3,@RKBA ;FROM THE DISK
3806                                     ;SET UP WORD COUNT
3807 011504 012777 177777 167622    MOV  #-1,@RKWC ;ADRES THE DRIVE WITH CORRECT
3808 011512 010177 167622          MOV  R1,@RKDA ;CYLINDER & SECTOR ADRES
3809                                     ;READ, GO
3810 011516 012777 000005 167606    MOV  #5,@RKCS
3811
3812 011524 105777 167602          2$:  TSTB @RKCS  ;DID CNTRL RDY SET?
3813 011530 100411          BMI  3$         ;YES, BRANCH
3814 011532 005237 001356          INC  INDX1   ;NO, HAVE U WAITED LONG ENOUGH
3815 011536 001372          BNE  2$         ;IF NOT, LOOP BACK & WAIT FOR IT
3816                                     ;IF YES, REPORT ERROR
3817 011540 004737 020774          JSR  PC,GT4RG  ;GO, GET RKCS, ER, DS,DA
3818 011544 010137 001202          MOV  R1,$REG10 ;GET DISK-ADRES WHERE ERROR OCCURED
3819 011550 104416          BRKDA4     ;GO TO 'BDA4' & BREAK CONTENTS OF
3820                                     ;$REG10 INTO DR #,CYL,SUR,SEC BITS
3821 011552 104045          ERROR 45     ;CNTRL RDY DID NOT SET AFTER DOING
3822                                     ;A 1 WORD READ FROM ADRES AS
3823                                     ;INDICATED IN <DISK-ADRES>
3824                                     ;'RKDA' IN EROR MSGE GIVES THE
3825                                     ;CONTENTS OF RKDA AT THE TIME OF ERROR
3826
3827 011554 032777 001000 167544 3$: BIT  #1000,@RKDS ;DID 'SIN' SET?
3828 011562 001405          BEQ  4$         ;NO, BRANCH
3829 011564 004737 021002          JSR  PC,GT3RG  ;GO, GET RKCS, ER, DS

```

```

3830 011570 010137 001170      MOV      R1,$REG3      ;GET DISK-ADRES WHERE SIN OCCURED3
3831 011574 104001              ERROR      1          ;'SIN' ERROR ON DOING READ FROM
3832                                ;DISK-ADRES INDICATED IN $REG3
3833 011576 004737 021226      4$: JSR      PC,CHKHE1  ;CHECK IF 'ERR' OR 'HE' BIT IS SET.
3834                                ;IF YES, RETURN HERE.
3835 011602 104046              ERROR      46        ;'HE' OR 'ERR' ON DOING A READ OF
3836                                ;1 WORD FROM ADRES AS INDICATED
3837                                ;IN <DISK-ADRES>
3838                                ;'RKDA' IN EROR MSGE GIVES THE
3839                                ;CONTENTS OF RKDA AT THE TIME OF EROR
3840 011604 020113      5$: CMP      R1,(R3)    ;WAS THE CORRECT DATA WORD RECVD?
3841 011608 001407      BEQ      6$          ;
3842 011610 010137 001162      MOV      R1,$REG0      ;GET EXPCTD DATA WORD
3843 011614 011337 001164      MOV      (R3),$REG1    ;GET DATA WORD RECVD
3844 011620 010137 001166      MOV      R1,$REG2      ;GET DISK-ADRES
3845 011624 104044      ERROR      44        ;DID NOT RECIEVE THE CORRECT
3846                                ;DATA WORD FROM DISK ON DOING
3847                                ;1 WORD READ FROM 'DISK-ADRES'
3848                                ;AS INDICATED BY 'EXPCTD' DATA WORD
3849                                ;NOTE THAT IN A PREVIOUS TEST THE
3850                                ;FIRST WORD OF EACH SECTOR IS UNIQUELY
3851                                ;WRITTEN WITH A WORD GIVING THE
3852                                ;ABSOLUTE ADDRESS OF THAT SECTOR IN
3853                                ;TERMS OF, DRIV #, CYL ADRES, SUR, SEC ADRS.
3854 011626 020177 167510      6$: CMP      R1,@RKDB   ;DOES RKDB CONTAIN CORRECT WORD
3855 011632 001406      BEQ      7$          ;YES, BRANCH
3856 011634 010137 001162      MOV      R1,$REG0      ;NO, GET EXPCTD RKDB
3857 011640 017737 167476 001164  MOV      @RKDB,$REG1    ;GET RKDB RECVD
3858 011646 104037      ERROR      37        ;RKDB ERROR ON READ.
3859                                ;FOR RK11C, AFTER A READ RKDB
3860                                ;CONTAINS CHECKSUM FOR THE SECTOR
3861                                ;READ.
3862                                ;WHEREAS FOR RK11D, AFTER READ
3863                                ;RKDB CONTAINS THE LAST WORD
3864                                ;READ FROM THAT SECTOR &
3865                                ;X-FERRED TO MEMORY
3866 011650 005737 001344      7$: TST      SIMUL     ;TESTING ON SIMULATOR?
3867 011654 001022      BNE     TST26        ;IF YES, EXIT
3868 011656 005201      INC      R1          ;INCREMENT TO ADRES NEXT SECTOR
3869 011660 005200      INC      R0          ;HAVE U CHKD ALL 12 SECTORS?
3870 011662 001302      BNE     1$          ;IF NOT, LUP BAK & CHK THE NXT
3871                                ;IF YES...
3872 011664 012700 177764      MOV      #-14,R0     ;RESET THE COUNT FOR 12 SECTORS
3873 011670 042701 000037      BIC      #37,R1      ;CLEAR SECTOR, SURFACE BITS
3874 011674 005704      TST      R4          ;DOING SURFACE 1?
3875 011676 001004      BNE     9$          ;YES, BRANCH
3876 011700 005204      INC      R4          ;NO
3877 011702 062701 000020      ADD      #20,R1      ;INCREMENT THE ADRES TO NXT SURFACE
3878 011706 000670      BR       1$          ;GO READ SURFACE 1
3879 011710 005004      CLR      R4          ;
3880 011712 062701 000040      9$: ADD      #40,R1    ;INCREMENT TO NXT CYL
3881 011716 005205      INC      R5          ;HAVE U CHKD ALL 203 CYLINDERS
3882 011720 001263      BNE     1$          ;IF NOT, LOOP BACK & CHK THE NXT CYLINDER
3883                                ;YES
3884
3885

```

```

3886 ;*****
3887 ;*TEST 26 CHECK 'SEEK' FUNCTION, WITH DIFFERENT VELOCITY MODES
3888 ;* THIS TEST CHECKS SEEK IN DIFFERENT VELOCITY MODES (DIFF <3,
3889 ;* 3 < DIFF < 31, DIFF > 31). FOR THESE 3 BASIC VELOCITIES SEEK IS DONE BOTH
3890 ;* IN FWD AND REV DIRECTION TO CHECK THE ADDER & DIFFERENCE LOGIC. IF
3891 ;* WHILE DOING A SEEK 'SIN' OCCURS, A DRIVE RESET IS DONE TO INITIALIZE
3892 ;* THE POSITIONING LOGIC
3893 ;*****
3894 011722 000004      TST26: SCOPE
3895 011724 012737 000005 001206  MOV      #5,STIMES   ;DO 5 ITERATIONS
3896 011732 012703 001372      MOV      #SEEK0,R3  ;INITIALIZE POINTER TO THE FIRST
3897                                ;SEEK ADDRESS
3898 011736 005037 001356      CLR      INDX1      ;INDX1, WHEN 0 INDICATES SEEK IN FWD DIRECTION
3899                                ;WHEN 1 INDICATES SEEK IN REV DIRECTION
3900 011742 013700 001332      MOV      RKCS,R0    ;
3901 011746 013701 001326      MOV      RKDS,R1    ;
3902 011752 013702 001330      MOV      RKER,R2    ;
3903 011756 012737 011764 001110  MOV      #1$,SLPERR ;SET RETURN ADRES FOR LUPING ON
3904                                ;EROR (SW 9)
3905 011764 000240      1$: NOP
3906 011766 104413      2$: CNT.RESET
3907                                ;GO, DO CONTROL RESET
3908                                ;THIS IS A CALL FOR THE 'CNTRL-
3909                                ;RESET' ROUTINE. A CONTROL RESET IS
3910                                ;ISSUED AND AFTER A CERTAIN TIME
3911                                ;IF THE 'CNTRL RDY' DOES NOT SET
3912                                ;AN ERRO IS REPORTED. NOTE THAT
3913                                ;THE PC IN ERROR MESSAGE IS THE
3914                                ;PC WHERE 'CNT.RESET' IS LOCATED.
3915                                ;THIS IS A VERY BASIC ERR & IF IT
3916                                ;OCCURS GO BACK TO TEST 10
3917 011770 104421      TST.SIN
3918                                ;GO, CHECK IF SIN IS SET, IF SET
3919                                ;DO DRV-RESET TO CLEAR IT
3920
3921 011772 013704 001350      MOV      DRIVAD,R4   ;GET DRIV-ADRES
3922 011776 051304      BIS      (R3),R4    ;SET CYLINDER BITS
3923 012000 010477 167334      MOV      R4,@RKDA   ;ADRS THE DRIVE
3924 012004 012710 000011      MOV      #11,@R0    ;SET 'SEEK', 'GO'
3925
3926 012010 104412      CHKCRDY
3927                                ;GO CHECK IF CONTROL RDY IS SET
3928                                ;IF SO, SKIP THE EROR MESSAGE.
3929 012012 104021      ERROR      21      ;'CNTRL RDY' DID NOT SET AFTER
3930                                ;SENDING CYL ADD TO THE DRIV, 'ADD ACK'
3931                                ;FROM DRIVE SHLD HAVE COME BACK
3932                                ;THEREUPON SETTING 'CNTRL RDY'
3933
3934 012014 005005      4$: CLR      R5
3935 012016 032711 000100      5$: BIT      #100,@R1 ;DID R/W/S RDY SET?
3936 012022 001005      BNE     6$          ;YES, BRANCH
3937 012024 005205      INC      R5          ;NO, WAIT
3938 012026 001373      BNE     5$          ;WAITED LONG?
3939 012030 004737 020774      JSR      PC,GT4RG   ;GO, GET RKCS, ER, DS, DA
3940 012034 104026      ERROR      26      ;R/W/S RDY DID NOT SET ON
3941                                ;COMPLETION OF SEEK
3942                                ;DID SIN SET?
3943 012036 032711 001000      6$: BIT      #1000,@R1 ;NO, BRANCH
3944 012042 001403      BEQ      7$          ;GO, GET RKCS, ER, DS, DA
3945 012044 004737 020774      JSR      PC,GT4RG

```

```

3942 012050 104001
3943 012052 032710 140000
3944 012056 001403
3945 012060 004737 020774
3946 012064 104022
3947
3948
3949
3950 012066 022710 000210
3951 012072 001406
3952 012074 011037 001164
3953 012100 012737 000210 001162
3954 012106 104024
3955
3956
3957 012110 020477 167224
3958 012114 001406
3959 012116 010437 001162
3960 012122 017737 167212 001164
3961 012130 104027
3962
3963 012132 010477 167202
3964 012136 012777 033342 167172
3965 012144 012777 177777 167162
3966 012152 012710 002005
3967 012156 104414
3968 012160 021337 033342
3969 012164 001410
3970 012166 005037 001162
3971 012172 011337 001164
3972 012176 013737 033342 001166
3973 012204 104043
3974
3975
3976
3977 012206 005737 001356
3978 012212 001007
3979 012214 005723
3980 012216 022703 001400
3981 012222 001260
3982 012224 005237 001356
3983 012230 005743
3984 012232 005743
3985 012234 022703 001370
3986 012240 001251
3987
3988
3989
3990
3991
3992
3993
3994
3995
3996
3997

```

```

ERROR 1 ;SIN SET ON DOING SEEK
BIT #140000,@R0 ;DID 'HE' OR 'ERR' SET?
BEQ 85 ;YES
JSR PC,GT4RG ;GO, GET RKCS, ER, DS, DA
ERROR 22 ;'ERR OF 'HE' BIT SET WHEN
;SEEKING TO CYL AS INDICATED
;IN RKDA

8$: CMP #210,@R0 ;DOES RKCS STILL CONTAIN THE 'SEEK' FNCTION
BEQ 95 ;YES - EXIT
MOV @R0,$REG1 ;NO, GET RKCS RECVD
MOV #210,$REG0 ;GET EXPCTD RKCS
ERROR 24 ;RKCS SHOULD CONTAIN THE 'SEEK' BITS
;IF NOT, ERROR

9$: CMP R4,@RKDA ;DID RKDA CHANGE?
BEQ 10$ ;NO
MOV R4,$REG0 ;YES, GET EXPCTD?
MOV @RKDA,$REG1 ;GET RKDA
ERROR 27 ;RKDA CHANGED AFTER DOING SEEK

10$: MOV R4,@RKDA ;ADRES THE DRIVE, SEC 0
MOV #OUTBUF,@RKBA ;READ ONE HEADER INTO THIS
MOV #-1,@RKWC ;BUS ADRES
MOV #2005,@R0 ;GO, READ FORMAT
CNT.RDY ;WAIT FOR CNTRL RDY
CMP (R3),OUTBUF ;WAS THE CORRECT READE4R READ (FROM
BEQ 11$ ;CYLINDER TO WHICH SEEK WAS DONE BEFORE)
CLR $REG0 ;STORE SEC # FROME WHERE HDP WAS RD (0)
MOV (R3),$REG1 ;GET EXPCTD HEADER
MOV OUTBUF,$REG2 ;GET HDR RECVD
ERROR 43 ;WRONG HDR WAS RECVD FROM CYLINDER (ADRES
;IN ER MSGE). NOTE THAT A PURE SEEK WAS
;DONE TO THIS CYL BEFORE R_LADING HDR
;USING READ FORMAT
;SEEK IN REVRSE DIRECTION?
;YES, BRANCH
TST (R3)+ ;NO, INCREMENT PTR TO NXT SEEK ADRES
BNE #SEEK2+2,R3 ;DONE WITH ALL SKS IN FWD DIR?
INC 1$ ;NO, GO & DO NXT ONE
TST INDX1 ;SET FLAG INDICATING SK IN REVRSE
TST -(R3)
12$: TST -(R3) ;POSITION PTR TO NXT SK IN REV
CMP #SEEK0-2,R3 ;DONE WITH ALL?
BNE 1$ ;IF NOT, DO NXT ONE

```

```

*****
*TEST 27 CHECK DRIVE RESET FROM LAST CYLINDER
;THE HEADS ARE POSITIONED ON THE LAST CYLINDER (DOING
;AN IMPLIED SEEK-READ). THEN A DRIVE RESET IS ISSUED.
;IT'S CHECKED IF THE HEADS WERE BROUGHT BACK TO 0 BY
;DOING A 1 WORD READ & CHECKING THAT THE CORRECT WORD
;WAS RECEIVED. IF TESTING ON SIMULATOR THIS TEST IS SKIPPED.
*****

```

```

3998 012242 000004
3999 012244 012737 000005 001206
4000 012252 005737 001344
4001 012256 001124
4002 012260 013701 001332
4003 012264 104413
4004
4005
4006
4007
4008
4009
4010
4011
4012
4013 012266 005000
4014 012270 012703 033342
4015 012274 013704 001350
4016 012300 010405
4017 012302 052705 014500
4018 012306 010577 167026
4019 012312 012777 177777 167014
4020 012320 010377 167012
4021
4022 012324 012711 000005
4023
4024 012330 005000
4025 012332 104414
4026
4027
4028
4029
4030
4031
4032 012334 020513
4033 012336 001407
4034 012340 010537 001162
4035 012344 011337 001164
4036 012350 010537 001166
4037 012354 104044
4038
4039
4040
4041
4042 012356 012711 000015
4043 012362 104414
4044
4045
4046
4047
4048
4049
4050 012364 005000
4051 012366 032777 000100 166732
4052 012374 001011
4053 012376 012702 177763

```

```

TST27: SCOPE
MOV #5,$TIMES ;DO 5 ITERATIONS
TST SIMUL ;R U ON A SIMULATOR?
BNE TST30 ;YES, EXIT
MOV RKCS,R1
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR & IF IT
;OCCURS GO BACK TO TEST 10

CLR R0
MOV #OUTBUF,R3 ;ADRES WHERE DATA WILL BE READ INTO
MOV DRIVAD,R4
MOV R4,R5
BIS #14500,R5 ;SET CYL ADRES=312 (OCTAL)
MOV R5,@RKDA ;ADRES THE DRIVE, LAST CYLINDER
MOV #-1,@RKWC ;READ 1 WORD
MOV R3,@RKBA ;INTO THIS MEMORY ADRES

MOV #5,@R1 ;READ, GO

1$: CLR R0
CNT.RDY ;THIS IS A CALL FOR CN.RDY ROUTINE
;WHICH WAITS FOR CNTRL RDY TO SET.
;A RETURN IS MADE AFTER CNTRL RDY
;SETS. IF WITHIN A CERTAIN TIME
;CNTRL RDY DOESN'T SET AN ERROR
;MESSAGE IS GIVEN. WAITING TIME
;883 MS FOR 11/20, 175 MS FOR 11/45

2$: CMP R5,@R3 ;WAS THE CORRECT WORD READ?
BEQ 3$ ;YES, SEEK TO 312 WAS DONE CORRECTLY5.0
MOV R5,$REG0 ;GET EXPCTD WORD
MOV @R3,$REG1 ;GET WORD RECVD
MOV R5,$REG2 ;GET DSK-ADRES FROM WHERE WORD WAS READ
ERROR 44 ;DID NOT READ BACK CORRECT WORD FROM
;LAST CYL, SEC 0. IF TEST 45 & 46
;WERE SUCCESSFULLY DONE THIS
;ERROR MEANS THAT IMPLIED SEEK
;TO CYL 312 COULD NOT B DONE
;DRIVE RESET, GO

3$: MOV #15,@R1
CNT.RDY ;THIS IS A CALL FOR CN.RDY ROUTINE
;WHICH WAITS FOR CNTRL RDY TO SET.
;A RETURN IS MADE AFTER CNTRL RDY
;SETS. IF WITHIN A CERTAIN TIME
;CNTRL RDY DOESN'T SET AN ERROR
;MESSAGE IS GIVEN. WAITING TIME
;883 MS FOR 11/20, 175 MS FOR 11/45

4$: CLR R0
BIT #100,@RKDS ;DID R/W/S RDY SET?
BNE 5$ ;YES, BRANCH
MOV #-15,R2 ;IF U R ON A SLOWER MACHINE

```

```

4054 012402 005202      INC      R2      ;& DO NOT NEED SUCH A LARGE MACHINE
4055 012404 001376      BNE     .-2     ;TIME LOOP, CHANGE THESE 3
4056                      ;INSTRUCTIONS TO 'NOP' THE
4057                      ;LOOP TIME WILL BE REDUCED
4058                      ;TO 1100 MS
4059                      ;
4060                      ;THE TOTAL TIME FOR THE ABOVE
4061                      ;LOOPS (W/O PUTTING 'NOP'S) IS
4062                      ;5304 MS FOR 11/20 AND
4063                      ;1061 MS FOR 11/45 WITH MOS
4064                      ;OR BIPOLAR MEMORY
4065 012406 005200      INC      R0      ;WAITED LONG?
4066 012410 001366      BNE     4$      ;IF NOT, LUP BAK & WAIT
4067                      ;IF YES, ERROR
4068 012412 004737 020774 JSR     PC,GT4RG ;GET RKCS,ER,DS,DA
4069 012416 104026      ERROR   26      ;R/W/S RDY DID NOT SET AFTER
4070                      ;DOING DRIVE RESET
4071 012420 032711 140000 5$: BIT     #140000,@R1 ;DID HE OR ERR BIT SET?
4072 012424 001403      BEQ     6$      ;IF NOT, BRANCH
4073                      ;
4074 012426 004737 020774 JSR     PC,GT4RG ;GET RKCS,ER,DS,DA FOR ERROR MESSAGE
4075 012432 104022      ERROR   22      ;HE OR ERR BIT SET ON DOING DRIVE
4076                      ;RESET FROM LAST CYLINDER
4077 012434 005205      6$: INC     R5      ;POSITION R5 TO EXPCTD RKDA
4078 012436 020577 166676 CMP     R5,@RKDA ;DID THE CYL ADRES BITS IN RKDA GET CHANGED?
4079 012442 001406      BEQ     7$      ;NO, BRANCH
4080 012444 010537 001162 MOV     R5,$REG0 ;GET EXPCTD RKDA
4081 012450 017737 166664 001164 MOV     @RKDA,$REG1 ;GET RKDA RECVD
4082 012456 104054      ERROR   54      ;CYLINDER ADRES BITS IN RKDA
4083                      ;GOT CHANGED AFTER
4084                      ;DRIVE RESET, FROM LAST CYLINDER
4085 012460 012777 177777 166646 7$: MOV     #-1,@RKWC ;READ 1 WORD
4086 012466 010377 166644 MOV     R3,@RKBA ;INTO THIS ADRES
4087 012472 010477 166642 MOV     R4,@RKDA ;FROM THIS DSK ADRES-CYL 0, SEC 0
4088                      ;
4089 012476 012711 000005 MOV     #5,@R1   ;READ, GO
4090                      ;
4091 012502 005000      8$: CLR     R0      ;THIS IS A CALL FOR CN.RDY ROUTINE
4092 012504 104414      CNT.RDY ;WHICH WAITS FOR CNTRL RDY TO SET.
4093                      ;A RETURN IS MADE AFTER CNTRL RDY
4094                      ;SETS. IF WITHIN A CERTAIN TIME
4095                      ;CNTRL RDY DOESN'T SET AN ERROR
4096                      ;MESSAGE IS GIVEN. WAITING TIME
4097                      ;893 MS FOR 11/20, 175 MS FOR 11/45
4098                      ;
4099 012506 020413      9$: CMP     R4,@R3 ;WAS THE CORRECT WORD READ?
4100 012510 001407      BEQ     TST30    ;YES, EXIT
4101 012512 010437 001162 MOV     R4,$REG0 ;GET EXPCTD WORD
4102 012516 011337 001164 MOV     @R3,$REG1 ;GET WORD RECVD
4103 012522 010437 001166 MOV     R4,$REG2 ;GET DISK ADRES WHERE ERROR OCCURED
4104 012526 104044      ERROR   44      ;DID NOT READ CORRECT WORD FROM
4105                      ;CYL 0, SEC 0. IF TEST 45 & 46
4106                      ;WERE SUCCESSFULLY DONE THIS
4107                      ;ERROR COULD MEAN THAT DRIVE-RESET
4108                      ;DID NOT BRING HEADS BACK TO 0.
4109

```

```

4110
4111 ;*****
4112 ;*TEST 30 'WRITE' - 256 WORD BLOCK ON SECTOR 0, CYLINDER 0
4113 ;THE TEST BELOW SHOULD BE CONSIDERED AS A SET UP PHASE FOR
4114 ;THE FOLLOWING TEST. IT WRITES A BLOCK OF 256 WORDS IN
4115 ;SECTOR 0, CYLINDER 0 WITH A SPECIFIC PATTERN AND THIS WRITTEN
4116 ;BLOCK WILL BE MADE USE OF IN THE NEXT TEST TO CHECK
4117 ;OUT 'WRITE-CHECK' AND 'READ CHECK' FUNCTIONS.
4118 ;*****
4119 012530 000004      TST30: SCOPE
4120 012532 104413      CNT.RESET ;GO, DO CONTROL RESET
4121                      ;THIS IS A CALL FOR THE 'CNTRL-
4122                      ;RESET' ROUTINE. A CONTROL RESET IS
4123                      ;ISSUED AND AFTER A CERTAIN TIME
4124                      ;IF THE 'CNTRL RDY' DOES NOT SET
4125                      ;AN ERROR IS REPORTED. NOTE THAT
4126                      ;THE PC IN ERROR MESSAGE IS THE
4127                      ;PC WHERE 'CNT.RESET' IS LOCATED.
4128                      ;THIS IS A VERY BASIC ERR& IF IT
4129                      ;OCCURS GO BACK TO TEST 10
4130 012534 104421      TST.SIN ;CHECK IF SIN IS SET, IF SET
4131                      ;DO DRIVE RESET TO CLEAR IT
4132 012536 013704 001332 MOV     RKCS,R4 ;
4133                      ;THE FOLLOWING CODE IS FOR SETTING
4134                      ;UP THE I/O BUFFER IN MEMORY (STARTING AT
4135                      ;OUTBUF), WITH A PARTICULAR 256 WORD PATTERN.
4136                      ;STARTING FROM THE FIRST WORD IN THE BUFFER
4137                      ;THE LO BYTE WILL BE A COUNT PATTERN
4138                      ;FROM 0 TO 255 (DECIMAL), WHEREAS THE
4139                      ;HI-BYTE WILL BE THE COMPLEMENT OF LO BYTE.
4140                      ;A DECREASING COUNT PATTERN FROM 255 TO 0.
4141                      ;I.E.THE BUFFER WILL LOOK LIKE:
4142                      ;OUTBUF      (1 111 111 1 00 000 000)
4143                      ;OUTBUF+2    (1 111 111 0 00 000 001)
4144                      ;
4145                      ;LAST WORD      (0 000 000 0 11 111 111)
4146
4147 012542 012700 033342 MOV     #OUTBUF,R0 ;
4148 012546 012701 177401 MOV     #177401,R1 ;PATTERN GENERATING NUMBER
4149 012552 012702 177400 MOV     #-400,R2   ;SET UP COUNT FOR 256 WORDS
4150 012556 012703 177400 MOV     #177400,R3 ;SET UP THE FIRST PATTERN TO B WRITTEN
4151
4152 012562 010320      MOV     R3,(R0)+ ;SET UP FIRST WORD IN I/O BUFFER
4153 012564 005202      INC     R2        ;INCREMENT COUNT
4154 012566 060103      ADD     R1,R3     ;SET UP NEXT WORD PATTERN
4155 012570 010320      MOV     R3,(R0)+ ;WRITE IT IN NXT I/O BUFFER WORD
4156 012572 005202      INC     R2        ;HAVE U WRITTEN ALL 256 WORDS
4157 012574 001374      BNE     1$       ;IF NOT GO & WRITE NEXT PATTERN
4158
4159 012576 012777 177400 166530 MOV     #-400,@RKWC ;WRITE 256 WORDS
4160 012604 012777 033342 166524 MOV     #OUTBUF,@RKBA ;STARTING FROM THIS BUS ADRES
4161 012612 013777 001350 166520 MOV     DRIVAD,@RKDA ;TO THIS DISK ADRES, CYL 0, SEC 0
4162
4163 012620 012714 000003 MOV     #3,@R4    ;WRITE, GO
4164
4165 012624 105714      2$: TSTB   @R4    ;WAS CNTRL RDY CLEARED AS GO WAS SET?

```

```

4166 012626 100003          BPL 3$-2          ;YES, BRANCH
4167 012630 004737 021002   JSR PC,GT3RG     ;GET RKCS, ER, DS
4168 012634 104030          ERROR 30         ;CNTRL RDY DID NOT CLEAR AS GO WAS SET
4169                               ;TO 'WRITE'
4170
4171 012636 005002          CLR R2           ;
4172 012640 105777 166466   3$: TSTB @RKCS    ;DID CNTRL RDY SET?
4173 012644 100411          BMI 4$          ;YES, BRANCH
4174 012646 005202          INC R2          ;WAITED LONG ENOUGH?
4175 012650 001373          BNE 3$          ;IF NOT, LUP BAK & WAIT
4176                               ;IF YES, ERROR
4177 012652 004737 020774   JSR PC,GT4RG     ;GO, GET RKCD, ER, DS, DA
4178 012656 013737 001350 001202 MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
4179 012664 104416          BRKDA4          ;BREAK CONTENTS OF $REG10 INTO
4180                               ;DRV #, CYL, SUR, SEC #
4181 012666 104031          ERROR 31         ;CNTRL RDY DID NOT SET ON COMPLETION
4182                               ;OF WRITE OF 256 WORDS ON CYL 0, SEC 0
4183                               ;'RKDA' IN EROR MSGE GIVES THE
4184                               ;CONTENTS OF RKDA AT THE TIME OF EROR
4185                               ;WRITE WAS DONE STARTING AT <DSK-ADRES>
4186                               ;INDICATED IN EROR MSGE
4187 012670 004737 021234   4$: JSR PC,CHKHL  ;CHECK IF 'ERR' OR 'HE' BIT IS SET,
4188                               ;IF YES, RETURN HERE
4189 012674 104032          ERROR 32         ;HE OR ERR BIT SET ON DOING WRITE OF
4190                               ;256 WORDS ON CYL 0, SEC 0
4191                               ;WRITE WAS DONE STARTING AT <DSK-ADRES>
4192                               ;INDICATED IN EROR MSGE
4193                               ;'RKDA' IN EROR MSGE GIVES THE
4194                               ;CONTENTS OF RKDA AT THE TIME OF EROR
4195 012676 020077 166434   5$: CMP R0,@RKBA  ;DID RKBA INCREMENT CORRECTLY?
4196 012702 001406          BEQ 6$          ;YES, BRANCH
4197 012704 010037 001162   MOV R0,$REG0    ;GET EXPCD RKBA
4198 012710 017737 166422 001164 MOV @RKBA,$REG1 ;GET RKBA RECVD
4199 012716 104035          ERROR 35         ;RKBA DID NOT INCREMENT CORRECTLY
4200                               ;(BY 1000 OCTAL BYTES) AFTER WRITE
4201                               ;OF 400 (OCTAL) WORDS ON SEC 0, CYL 0
4202 012720 004737 021316   6$: JSR PC,CHKWC  ;CHECK IF RKWC OVERFLOWED TO 0,
4203                               ;IF NOT RETURN HERE.
4204 012724 104034          ERROR 34         ;RKWC DID NOT OVERFLOW, AFTER A
4205                               ;WRITE OF 256 WORDS ON CYL 0, SEC 0
4206 012726 004737 021262   7$: JSR PC,CHKDA  ;CHECK IF RKDA INCREMENTED CORRECTLY,
4207                               ;IF NOT RETURN HERE
4208 012732 104033          ERROR 33         ;RKDA DID NOT INCREMENT BY 1 AFTER
4209                               ;A WRITE OF 256 WORDS IN CYL 0, SEC 0
4210 012734 004737 021342   8$: JSR PC,CHKER  ;CHECK IF ANY BIT RKER IS SET
4211                               ;IF YES :ETURN HERE.
4212 012740 104036          ERROR 36         ;RKER BIT SET ON DOING WRITE ON
4213                               ;CYLINDER 0, SECTOR 0
4214 012742 022714 000202   9$: CMP #202,@R4  ;DOES RKCS STILL CONTAIN THE WRITE BITS?
4215 012746 001406          BEQ TST31       ;:YES, EXIT
4216 012750 012737 000202 001162 MOV #202,$REG0  ;GET EXPECTED RKCS
4217 012756 011437 001164   MOV @R4,$REG1  ;GET RKCS RECVD
4218 012762 104024          ERROR 24         ;RKCS DID NOT CONTAIN THE 'WRITE'
4219                               ;BITS AFTER THE FUNCTION WAS DONE.
4220
4221

```

```

4222 ;*****
4223 ;*TEST 31 CHECK THAT WRITE WAS DONE CORRECTLY
4224 ;*THIS TEST CHECKS IF THE 'WRITE' OF 256 WORDS DONE IN PREVIOUS
4225 ;*TEST IS GOOD. THE SEQUENCE OF OPERATIONS IS AS FOLLOWING:
4226 ;*1) DO A READ OF 256 WORDS FROM SECTOR 0, CYLINDER 0
4227 ;* INTO A BUFFER STARTING AT 'OUTBUF'.
4228 ;*2) COMPARE & CHECK THE DATA THAT IS READ (STARTING AT 'OUTBUF')
4229 ;* WITH THE DATA THAT WAS GENERATED PREVIOUSLY
4230 ;*3) REPORT AN ERROR IF THE DATA READ BACK FROM DISK DOES
4231 ;* NOT COMPARE WITH DATA THAT WAS SUPPOSE TO HAVE BEEN WRITTEN
4232 ;*****
4233 012764 000004          TST31: SCOPE
4234 012766 104413          CNT.RESET      ;GO, DO CONTROL RESET
4235                               ;THIS IS A CALL FOR THE 'CNTRL-
4236                               ;RESET' ROUTINE. A CONTROL RESET IS
4237                               ;ISSUED AND AFTER A CERTAIN TIME
4238                               ;IF THE 'CNTRL RDY' DOES NOT SET
4239                               ;AN ERROR IS REPORTED. NOTE THAT
4240                               ;THE PC IN ERROR MESSAGE IS THE
4241                               ;PC WHERE 'CNT.RESET' IS LOCATED.
4242                               ;THIS IS A VERY BASIC ERR& IF IT
4243                               ;OCCURS GO BACK TO TEST 10
4244 012770 104421          TST.SIN        ;CHECK IF SIN IS SET, IF SET
4245                               ;DO DRIVE RESET TO CLEAR IT
4246 012772 012700 177400   MOV #-400,R0    ;SET COUNT FOR 400 WORDS
4247 012776 012701 033342   MOV #OUTBUF,R1 ;TO BE C:EARED IN THE BUFFER
4248 013002 005021          8$: CLR (R1)+      ;CLR THE 400 WORD BUFFER
4249 013004 005200          INC R0          ;STARTING AT 'OUTBUF'
4250 013006 001375          BNE 8$
4251 013010 005000          CLR R0
4252 013012 012777 177400 166314 MOV #-400,@RKWC ;READ 256 WORDS
4253 013020 012777 033342 166310 MOV #OUTBUF,@RKBA ;INTO THIS ADRES
4254 013026 013777 001350 166304 MOV DRIVAD,@RKDA ;STARTING FROM THIS DISK ADRES
4255
4256 013034 012777 000005 166270 MOV #5,@RKCS    ;READ, GO
4257
4258 013042 105777 166264   1$: TSTB @RKCS    ;DID CNTRL RDY SET?
4259 013046 100411          BMI 2$          ;YES, BRANCH
4260 013050 005200          INC R0          ;WAITED LONG ENOUGH?
4261 013052 001373          BNE 1$          ;IF NOT, LUP BAK & WAIT
4262                               ;ERROR, IF YES
4263 013054 004737 020774   JSR PC,GT4RG     ;GO, GET RKCD, ER, DS, DA
4264 013060 013737 001350 001202 MOV DRIVAD,$REG10 ;GET THE STARTING ADRES
4265 013066 104416          BRKDA4          ;GO TO 'BDA4' & BREAK CONTENTS OF
4266                               ;$REG10 INTO DRV #, CYL, SUR, SEC BITS
4267 013070 104045          ERROR 45         ;CNTRL RDY DID NOT SET AFTER READ
4268                               ;OF 400 WORDS FROM CYL 0, SEC 0
4269                               ;'RKDA' IN EROR MSGE GIVES THE
4270                               ;CONTENTS OF RKDA AT THE TIME OF EROR
4271                               ;READ WAS DONE STARTING AT <DSK-ADRES>
4272                               ;INDICATED IN EROR MSGE
4273 013072 032777 001000 166220 2$: BIT #1000,@RKDS ;IS SIN SET?
4274 013100 001033          BNE TST32       ;:IF YES, EXIT
4275 013102 012701 177400   5$: MOV #-400,R1
4276 013106 012702 177777   MOV #177777,R2
4277 013112 012703 033342   MOV #OUTBUF,R3

```

```

4278 013116 012705 177773      MOV    #-5,R5
4279 013122 062702 177401      ADD    #177401,R2
4280 013126 020213      CMP    R2,(R3) ;WAS THE READ WORD SAME AS THE WORD
                                ;THAT WAS SUPPOSE TO BE WRITTEN
4281                                ;YES, BRANCH
4282 013130 001414      BEQ    7$
                                ;NO, ERR-R
4283                                ;GET THE # OF WORD
4284 013132 010137 001162      MOV    R1,$REG0
4285 013136 062737 000401      ADD    #401,$REG0
4286 013144 010237 001164      MOV    R2,$REG1
                                ;THAT IS IN ERROR (EXAMPLE=1,2--376,377,400)
                                ;GET EXPTD WORD (THAT WAS SUPPOSED TO
                                ;BE WRITTEN)
4287                                ;GET WORD RECVD (THAT WAS READ BAK)
4288 013150 011337 001166      MOV    (R3),$REG2
4289 013154 104055      ERROR  5$
                                ;DID NOT READ BACK WORD THAT WAS POSITIONED
                                ;TO HAVE BEEN WRITTEN PREVIOUSLY.  HENCE THE TEST WHICH
4290                                ;OF WORD IN ERROR IS AS INDICATED BY
4291                                ;WORD # ($REG0), SEC 0, CYL 0
4292
4293                                INC    R5
4294 013156 005205      BEQ    TST32
4295 013160 001403      TST    (R3)+
                                ;:EXIT
                                ;INCREMENT POINTER TO NXT WORD (THAT
                                ;WAS READ BACK)
4296                                ;HAVE U CHKD ALL 256 WORDS?
4297 013164 005201      INC    R1
4298 013166 001355      BNE    6$
                                ;IF NOT, LUP BAK & CHK THE NXT WORD
                                ;IF YES, EXIT
4299
4300                                ;*****
4301                                ;*TEST 32 CHECK 'READ CHECK' FUNCTION - CYLINDER 0, SECTOR 0
4302                                ;*THIS TEST CHECKS OUT THE BASIC 'READ CHECK' LOGIC, USING THE DATA BLOCK
4303                                ;*CYLINDER, SECTOR 0) WRITTEN IN A PREVIOUS TEST.  HENCE THE TEST WHICH
4304                                ;*WRITES THE DATA BLOCK SHOULD BE DONE PRIOR TO THIS TEST.
4305                                ;*****
4306                                ;*****
4307 013170 000004      TST32: SCOPE
4308 013172 104413      CNT.RESET
                                ;GO, DO CONTROL RESET
4309                                ;THIS IS A CALL FOR THE 'CNTRL-
4310                                ;RESET' ROUTINE.  A CONTROL RESET IS
4311                                ;ISSUED AND AFTER A CERTAIN TIME
4312                                ;IF THE 'CNTRL RDY' DOES NOT SET
4313                                ;AN ERROR IS REPORTED.  NOTE THAT
4314                                ;THE PC IN ERROR MESSAGE IS THE
4315                                ;PC WHERE 'CNT.RESET' IS LOCATED.
4316                                ;THIS IS A VERY BASIC ERR& IF IT
4317                                ;OCCURS GO BACK TO TEST 10
4318 013174 104421      TST.SIN
                                ;CHECK IF SIN IS SET, IF SET
4319                                ;DO DRIVE RESET TO CLEAR IT
4320                                MOV    RKCS,R1
4321                                MOV    RKWC,R2
4322                                MOV    RKDA,R3
4323                                MOV    RKBA,R4
4324 013216 012737 052525      MOV    #52525,OUTBUF
4325 013224 012712 177400      MOV    #-400,@R2
4326 013230 013713 001350      MOV    DRIVAD,@R3
4327 013234 012714 033342      MOV    @OUTBUF,@R4
4328 013240 012711 000013      MOV    #13,@R1
                                ;READ CHECK, GO
4329
4330 013244 105711      1$: TSTB  @R1
4331 013246 100003      BPL    2$
4332 013250 004737 021002      JSR    PC,GT3RG
4333 013254 104030      ERROR  30
                                ;DID CNTRL RDY GET CLEARED AS GO WAS SET?
                                ;YES, BRANCH
                                ;GET RKCS, ER, DS
                                ;CNTRL RDY DID NOT CLEAR AS GO

```

```

4334 013256 104412      2$: CHKCRDY
                                ;GO CHECK IF CONTROL RDY IS SET
4335                                ;IF SO, SKIP THE EROR MESSAGE.
4336                                ;WAS SET TO 'READ CHECK'
4337 013260 104056      ERROR  56
                                ;CNTRL RDY DID NOT SET ON DOING
                                ;'READ CHECK' FROM CYL 0, SEC 0
4338                                ;'READ CHECK' FROM CYL 0, SEC 0
4339 013262 032711 140000      3$: BIT  #140000,@R1
4340 013266 001403      BEQ    4$
4341 013270 004737 021002      JSR    PC,GT3RG
4342 013274 104057      ERROR  57
                                ;DID 'ERR' OR 'HE' BIT SET?
4343                                ;NO, BRANCH
4344 013276 032777 000002 166024 4$: BIT  #2,@RKER
4345 013304 001404      BEQ    5$
4346 013306 017737 166016 001162      MOV    @RKER,$REG0
4347 013314 104060      ERROR  60
                                ;SOFT ERROR - CSE - ON DOING 'READ
                                ;CHECK' ON CYLINDER 0, SECTOR 0
4348                                ;U SHOULD HAVE GOT ERROR 102 ALSO
4349                                ;DID WORD COUNT OVERFLOW TO 0?
4350 013316 005712      5$: TST  @R2
4351 013320 001405      BEQ    6$
4352 013322 011237 001162      MOV    @R2,$REG0
4353 013326 011137 001164      MOV    @R1,$REG1
4354 013332 104061      ERROR  61
                                ;GET RKWC
                                ;GET RKCS
                                ;WORD COUNT DID NOT OVERFLOW
4355                                ;ON DOING 'READ CHK' ON CYL 0, SEC 0
4356 013334 013702 001350      6$: MOV    DRIVAD,R2
4357 013340 005202      INC    R2
4358 013342 020213      CMP    R2,@R3
4359 013344 001405      BEQ    7$
4360 013346 010237 001162      MOV    R2,$REG0
4361 013352 011337 001164      MOV    @R3,$REG1
4362 013356 104062      ERROR  62
                                ;GET EXPTD RKDA
                                ;GET RKDA RECVD
                                ;RKDA DID NOT INCREMENT CORRECTLY
                                ;(BY 1) ON DOING 'READ CHK' ON
                                ;CYL 0, SEC 0
4363                                ;DID RKBA GET CHANGED?
4364                                ;NO, BRANCH (RKBA WON'T CHANGE, NO NPR'S)
4365 013360 022714 033342      7$: CMP    #OUTBUF,@R4
4366 013364 001406      BEQ    8$
4367 013366 012737 033342 001162      MOV    #OUTBUF,$REG0
4368 013374 011437 001164      MOV    @R4,$REG1
4369 013400 104063      ERROR  63
                                ;GET EXPTD RKBA
                                ;GET RKBA RECVD
                                ;RKBA CHANGED AFTER DOING 'READ CHK'
                                ;ON CYLINDER 0, SECTOR 0.  SHOULD
                                ;NOT CHANGE, FOR, NO NPR'S.
4370                                ;'OUTBUF' SHOULD STILL CONTAIN THE
4371                                ;SAME WORD AS IT DID BEFORE 'RD CHK'
4372 013402 022737 052525 033342 8$: CMP    #52525,OUTBUF
4373                                ;NOTE THAT AT THE BEGINING OF THIS TEST
4374                                ;52525 WAS WRITTEN INTO 'OUTBUF'
4375                                ;:YES, EXIT
4376                                ;:REPORT ERROR IF 'OUTBUF' CHANGED
4377                                ;:GET ADRES OF OUTBUF
4378 013412 012737 033342 001162      MOV    #OUTBUF,$REG0
4379 013420 012737 052525 001164      MOV    #52525,$REG1
4380 013426 013737 033342 001166      MOV    @OUTBUF,$REG2
4381 013434 104064      ERROR  64
                                ;GET WORD FOUND IN 'OUTBUF'
                                ;AS MENTIONED ABOVE, IF 'WRITE' OF
                                ;256 WORD DATA BLOCK WAS DONE
                                ;CORRECTLY BEFORE, THEN THIS ERROR
                                ;COULD MEAN THAT AN NPR WAS DONE
                                ;ON 'READ CHECK'.
4382
4383                                ;*****
4384                                ;*TEST 33 CHECK THE 'WRITE CHECK' FUNCTION - ON CYLINDER 0, SECTOR 0
4385                                ;*THIS TEST CHECKS OUT THE BASIC 'WRITE CHECK' LOGIC, USING THE 256
4386
4387
4388
4389

```

```

4390 ;*WORD DATA BLOCK (SECTOR 0, CYLINDER 0) WRITTEN IN A PREVIOUS
4391 ;*TEST. THE BUFFER IN MEMORY, USED FOR COMPARISON OF DATA, IS THE
4392 ;*ONE STARTING AT 'OUTBUF'. HENCE THE TEST WHICH WRITES THE
4393 ;*256 WORD BLOCK ON THE DISK (AS WELL AS CREATING THE 256
4394 ;*256 WORD MEMORY BUFFER) SHOULD BE DONE BEFORE THIS TEST.
4395 ;*****
4396 013436 000004 TST33: SCOPE
4397 013440 104413 CNT.RESET ;GO, DO CONTROL RESET
4398 ;THIS IS A CALL FOR THE 'CNTRL-
4399 ;RESET' ROUTINE. A CONTROL RESET IS
4400 ;ISSUED AND AFTER A CERTAIN TIME
4401 ;IF THE 'CNTRL RDY' DOES NOT SET
4402 ;AN ERROR IS REPORTED. NOTE THAT
4403 ;THE PC IN ERROR MESSAGE IS THE
4404 ;PC WHERE 'CNT.RESET' IS LOCATED.
4405 ;THIS IS A VERY BASIC ERR& IF IT
4406 ;OCCURS GO BACK TO TEST 10
4407 013442 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4408 ;DO DRIVE RESET TO CLEAR IT
4409 013444 013701 001332 MOV RKCS,R1
4410 013450 012700 177400 MOV #-400,R0
4411 013454 012702 033342 MOV #OUTBUF,R2
4412 013460 012703 177777 MOV #177777,R3
4413 013464 062703 177401 15: ADD #177401,R3
4414 013470 010322 MOV R3,(R2)+
4415 013472 005200 INC R0
4416 013474 001373 BNE 1$
4417 013476 012777 177400 165630 MOV #-400,@RKWC ;WRITE CHECK 256 WORDS
4418 013504 012777 033342 165624 MOV #OUTBUF,@RKBA ;STARTING AT THIS BUS ADRES
4419 013512 013777 001350 165620 MOV DRIVAD,@RKDA ;WITH THIS DISK DATA BLOCK (CYL 0, SEC 0)
4420 013520 012711 000007 MOV #7,@R1 ;WRITE CHECK, GO
4421 CLR R0 ;GIVE SOME TIME
4422 013524 005000 25: TSTB @R1 ;DID CNTRL RDY CLEAR AS GO WAS SET?
4423 013526 105711 BPL 3$ ;YES BRANCH
4424 013530 100003 JSR PC,GT3RG ;GET RKCS, ER, DS
4425 013532 004737 021002 ERROR 30 ;CNTRL RDY DID NOT CLEAR AS GO WAS
4426 013536 104030 ;SET TO DO WRITE CHECK
4427 ;GO CHECK IF CONTROL RDY IS SET
4428 013540 104412 35: CHKCRDY ;IF SO, SKIP THE EROR MESSAGE.
4429 ERROR 65 ;CNTRL RDY DID NOT SET AFTER
4430 013542 104065 ;COMPLETING WRITE CHECK ON
4431 ;CYLINDER 0, SECTOR 0
4432 ;DID HE OR ERR BIT SET
4433 013544 032711 140000 45: BIT #140000,@R1 ;NO, BRANCH
4434 013550 001403 BEQ 5$ ;GO GET RKCS ER DS FOR ERROR MESSAGE
4435 013552 004737 021002 JSR PC,GT3RG ;HE OR ERR BIT SET ON DOING WRITE
4436 013556 104066 ERROR 66 ;CHK ON CYLINDER 0, SEC 0
4437 ;DID WCE SET IN RKER?
4438 013560 032777 000001 165542 55: BIT #1,@RKER ;NO, BRANCH
4439 013566 001403 BEQ 6$ ;YES GET RKCS, ER, DS
4440 013570 004737 021002 JSR PC,GT3RG ;WCE ON WRITE CHECK OF CYL 0, SEC 0
4441 013574 104067 ERROR 67 ;NOTE THAT IF A PREVIOUS TEST
4442 ;& THEN COMPARED WITH MEMORY BUFFER
4443 ;TO SEE IF IT WAS WRITTEN CORRECT WAS
4444 ;DONE RIGHT BEFORE, THIS ERROR SHOULD NOT
4445

```

```

4446 ;HAPPEN UNLESS THERE IS A FAULT IN THE
4447 ;COMPARING LOGIC OF 'WRT CHK'
4448 013576 005777 165532 65: TST @RKWC ;DID RKWC OVERFLOW?
4449 013602 001406 BEQ 7$ ;YES, BRANCH
4450 013604 017737 165524 001162 MOV @RKWC,$REG0 ;NO, GET RKWC
4451 013612 011137 001164 MOV @R1,$REG1 ;GET RKCS
4452 013616 104061 ERROR 61 ;RKWC DID NOT OVERFLOW AFTER
4453 ;WRITE CHECK ON CYL 0, SEC 0
4454 013620 013704 001350 75: MOV DRIVAD, R4 ;RKDA SHOULD INCREMENT
4455 013624 005204 INC R4 ;TO THIS AFTER WRT CHK
4456 013626 020477 165506 CMP R4,@RKDA ;DID RKDA INCREMENT CORRECTLY?
4457 013632 001406 BEQ 8$ ;YES, BRANCH
4458 013634 010437 001162 MOV R4,$REG0 ;NO, GET EXPCTD RKDA
4459 013640 017737 165474 001164 MOV @RKDA,$REG1 ;GET RKDA RECVD
4460 013646 104070 ERROR 70 ;RKDA DID NOT INCREMENT CORRECTLY
4461 ;(BY 1 SECTOR) AFTER WAT CHK ON SEC 0, CYL 0
4462 013650 022777 034342 165460 85: CMP #OUTBUF+1000,@RKBA ;DID RKBA INCREMENT CORRECTLY?
4463 013656 001407 BEQ 9$ ;YES, EXIT
4464 013660 012737 034342 001162 MOV #OUTBUF+1000,$REG0 ;GET EXPCTD RKBA
4465 013666 017737 165444 001164 MOV @RKBA,$REG1 ;GET RKBA RECVD
4466 013674 104071 ERROR 71 ;RKBA DID NOT INCREMENT CORRECTLY
4467 ;(BY 1000 BYTES) AFTER A WRT CHK
4468 ;OF 256 WORDS ON CYL 0, SEC 0
4469 013676 022711 000206 95: CMP #206,@R1 ;DOES RKCS STILL CONTAIN THE WRT CHK BITS?
4470 013702 001406 BEQ TST34 ;YES, BRANCH
4471 013704 012737 000206 001162 MOV #206,$REG0 ;NO, GET EXPCTD RKCS
4472 013712 011137 001164 MOV @R1,$REG1 ;GET RKCS RECVD
4473 013716 104024 ERROR 24 ;RKCS BITS CHANGED AFTER WRT CHK
4474 ;WAS DONE
4475 ;*****
4476 ;*TEST 34 CHECK THAT IBA INHIBITS INCREMENTING OF RKBA
4477 ;*THIS TEST CHECKS THAT THE BUS ADDRESS DOES NOT INCREMENT WHEN
4478 ;*THE IBA BIT IS SET. SEQUENCE OF OPERATIONS:
4479 ;*1) CLEAR OUT 256 WORD BUFFER IN MEMORY (OUTBUF)
4480 ;*2) READ FROM SECTOR 0, CYLINDER 0 THE 256 WORD BLOCK THAT WAS
4481 ;*WRITTEN IN A PREVIOUS TEST (NOTE: THAT TEST SHOULD HAVE BEEN
4482 ;*DONE BEFORE THIS). IBA BIT IS SET DURING READ BACK.
4483 ;*3) CHECK THAT RKBA DID NOT INCREMENT
4484 ;*4) CHECK THAT THE ENTIRE BLOCK WAS READ INTO THE SAME MEMORY
4485 ;*WORD (OUTBUF) & THE REST OF THE WORDS IN THAT BUFFER ARE 0
4486 ;*AS PREVIOUSLY CLEARED OUT.
4487 ;*****
4488 013720 000004 TST34: SCOPE
4489 013722 104413 CNT.RESET ;GO, DO CONTROL RESET
4490 ;THIS IS A CALL FOR THE 'CNTRL-
4491 ;RESET' ROUTINE. A CONTROL RESET IS
4492 ;ISSUED AND AFTER A CERTAIN TIME
4493 ;IF THE 'CNTRL RDY' DOES NOT SET
4494 ;AN ERROR IS REPORTED. NOTE THAT
4495 ;THE PC IN ERROR MESSAGE IS THE
4496 ;PC WHERE 'CNT.RESET' IS LOCATED.
4497 ;THIS IS A VERY BASIC ERR& IF IT
4498 ;OCCURS GO BACK TO TEST 10
4499 013724 104421 TST.SIN ;CHECK IF SIN IS SET, IF SET
4500 ;DO DRIVE RESET TO CLEAR IT
4501 013726 013701 001332 MOV RKCS,R1

```

```

4502 013732 012700 177400      MOV    #-400,R0      ;SET UP COUNT FOR 256 WORDS
4503 013736 012702 033342      MOV    #OUTBUF,R2
4504 013742 010203      MOV    R2,R3
4505
4506 013744 005023      1$:   CLR    (R3)+      ;CLEAR OUT THE 256
4507 013746 005200      INC    R0           ;WORD MEMORY BUFFER STARTING
4508 013750 001375      BNE   1$          ;AT 'OUTBUF'
4509 013752 012777 177400 165354  MOV    #-400,@RKWC  ;READ BACK 256 WORDS
4510 013760 010277 165352      MOV    R2,@RKBA    ;INTO THIS BUS ADRES (IBA WILL B SET)
4511 013764 013777 001350 165346  MOV    DRIVAD,@RKDA ;FROM THIS DSK ADRES (SEC 0, CYL 0)
4512                                     ;NOTE: SEC 0 HAS BEEN WRITTEN IN A
4513                                     ;PREVIOUS TEST WITH A UNIQUE PATTERN
4514 013772 012711 004005      MOV    #4005,@R1   ;READ, GO, IBA SET
4515
4516 013776 005037 001362      CLR    COUNT
4517 014002 105711      2$:   TSTB   @R1         ;DID CNTRL RDY SET?
4518 014004 100412      BMI   @R1         ;YES, BRANCH
4519 014006 005237 001362      INC    COUNT      ;WAITED LONG ENOUGH?
4520 014012 001373      BNE   2$          ;IF NOT, LUP BAK & WAIT
4521 014014 004737 020774      JSR   PC,GT4RG    ;GO, GET RKCS, ER, DS, DA
4522 014020 013737 001350 001202  MOV    DRIVAD,$REG10 ;GET THE STARTING ADRES
4523 014026 104416      BRKDA4           ;BREAK CONTENTS OF $REG10
4524                                     ;INTO DR #, CYL, SUR, SEC
4525 014030 104045      ERROR  45        ;CNTRL RDY DID NOT SET AFTER DOING
4526                                     ;READ
4527 014032 004737 021234      3$:   JSR   PC,CHKHE   ;CHECK IF 'ERR' OR 'HE' BIT IS SET.
4528                                     ;IF YES, RETURN HERE.
4529 014036 104046      ERROR  46        ;ERR BIT SET ON DOING READ FROM SEC 0.
4530                                     ;CYL 0 (INDICATED IN <DSK-ADRES>)
4531                                     ;'RKDA' IN EROR MSGE GIVES THE
4532                                     ;CONTENTS OF RKDA AT THE TIME OF EROR
4533
4534 014040 020277 165272      4$:   CMP    R2,@RKBA  ;DID RKBA INCREMENT?
4535 014044 001406      BEQ   5$          ;OK IF NOT, BRANCH
4536 014046 010237 001162      MOV    R2,$REG0   ;GET EXPCTD RKBA
4537 014052 017737 165260 001164  MOV    @RKBA,$REG1 ;GET RKBA RECVD
4538 014060 104072      ERROR  72        ;RKBA INCREMENTED WHEN IBA BIT WAS
4539                                     ;SET, SHOULD NOT HAVE
4540 014062 032777 001000 165236  5$:   BIT    #1000,@RKDS ;IS SIN SET?
4541 014070 001042      BNE   TST35      ;;IF YES, EXIT
4542 014072 012700 177400      MOV    #-400,R0
4543 014076 022712 000377      CMP    #377,@R2   ;CHECK THAT THE FIRST WORD IN
4544                                     ;'OUTBUF' IS 377 (LAST WORD OF SEC 0,
4545                                     ;CYL 0). NOTE THAT READ WAS DONE
4546 014102 001411      BEQ   6$          ;INTO THIS SAME WRD WITH IBA SET
4547 014104 012737 000377 001162  MOV    #377,$REG0 ;GET EX:CTD WORD (LAST WORD OF THE BUFFER
4548 014112 011237 001164      MOV    (R2),$REG1 ;GET WORD RECVD (LAST WRD FROM SEC 0)
4549 014116 013737 001350 001166  MOV    DRIVAD,$REG2 ;DISK ADRES WHERE ERROR OCCURED
4550                                     ;(SEC 0, CYL 0 LAST WORD)
4551                                     ;DATA ERROR
4552 014124 104044      ERROR  44        ;THE FIRST WORD IN MEM BUFFER (OUTBUF)
4553                                     ;SHOULD BE NON-ZERO & SHOULD CONTAIN
4554                                     ;THE LAST WORD READ BACK FROM SEC 0
4555                                     ;CYL 0, THIS DID NOT HAPPEN IF THE ERROR OCCURS
4556 014126 005722      6$:   TST    (R2)+    ;INCREMENT POINTER TO THE NXT WORD
4557 014130 012705 177773      MOV    #-5,R5     ;ALLOW ONLY 5 MESSAGES FOR ERR 116

```

```

4558 014134 005200      7$:   INC    R0           ;CHKD ALL 256 WORDS IN THE BUFFER?
4559 014136 001417      BEQ   TST35      ;;YES, EXIT
4560 014140 005722      TST   (R2)+      ;IS THIS WORD 0?
4561 014142 001774      BEQ   7$          ;YES, LUP BAK & CHK THE NXT WORD?
4562 014144 005037 001164      CLR    $REG1     ;ERROR, GET EXPCTD WORD - 0
4563 014150 014237 001166      MOV    -(R2),$REG2 ;GET WORD THAT WAS FOUND IN THE BUFFER
4564 014154 010004      MOV    R0,R4
4565 014156 062704 000401      ADD   #401,R4
4566 014162 010437 001162      MOV    R4,$REG0  ;THIS 'WORD #' IN MEMORY BUFFER
4567                                     ;SHOULD HAVE BEEN ZERO
4568 014166 104073      ERROR  73        ;THE 256 WORD BUFER (STARTING AT
4569                                     ;'OUTBUF) WAS CLEARED BEFORE READING
4570                                     ;BAK SEC 0 INTO IT. SINCE THE IBA
4571                                     ;BIT WAS SET DURING THE READ, ONLY
4572                                     ;THE FIRST WORD OF (OUTBUF) SHOULD
4573                                     ;HAVE CHANGED, THE REST OF THE WORDS
4574                                     ;SHOULD BE STILL 0. IF THIS ERROR
4575                                     ;OCCURS, 'WORD #' (OF THE BUFFER) AS
4576                                     ;INDICATED IN THE EROR MESSAGE) GOT
4577                                     ;CHANGED WHEN READ WAS DONE FROM
4578                                     ;THE DISK, INDICATING THAT WITH IBA
4579                                     ;SET X-FER WAS NOT DONE INTO THE
4580                                     ;SAME MEMORY LOCATION. 'WORD #'
4581                                     ;IS OCTAL & SPECIFIES THE POSITION
4582                                     ;IN THE BUFFER (FIRST WORD IS 'WORD #' 1)
4583 014170 005205      INC    R5
4584 014172 001401      BEQ   TST35      ;;EXIT
4585 014174 000757      BR    7$
4586
4587
4588
4589 ;*****
4590 ;*TEST 35 CHECK THAT RK11 INTERRUPTS WHEN IDE IS SET
4591 ;*THIS TEST CHECKS IF RK11 INTERRUPTS TO ITS DESIGNATED VECTOR
4592 ;*ADDRESS WHEN IDE BIT IS SET, WITH CONTROL READY SET & GO CLEAR.
4593 ;* IT IS NORMALLY 220, UNLESS IT HAS BEEN CHANGED. IF IT HAS BEEN
4594 ;*CHANGED RK11 WILL INTERRUPT TO 'RKVEC'. NOTE 'RKVEC' HAS
4595 ;*TO BE SET UP BY THE USER.
4596 ;*****
4595 014176 000004      TST35: SCOPE
4596 014200 104413      CNT.RESET      ;GO, DO CONTROL RESET
4597                                     ;THIS IS A CALL FOR THE 'CNTRL-
4598                                     ;RESET' ROUTINE. A CONTROL RESET IS
4599                                     ;ISSUED AND AFTER A CERTAIN TIME
4600                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4601                                     ;AN ERROR IS REPORTED. NOTE THAT
4602                                     ;THE PC IN ERROR MESSAGE IS THE
4603                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4604                                     ;THIS IS A VERY BASIC ERR# IF IT
4605                                     ;OCCURS GO BACK TO TEST 10
4606 014202 104421      TST.SIN      ;CHECK IF SIN IS SET, IF SET
4607                                     ;DO DRIVE RESET TO CLEAR IT
4608 014204 012746 000340      MOV    #340,-(SP)
4609 014210 012746 014216      MOV    #645,-(SP)
4610 014214 000002      RTI
4611 014216
4612 014216 013701 001332      64$:  MOV    RKCS,R1
4613 014222 013700 001402      MOV    RKVEC,R0   ;GET POINTER TO RK VECTOR ADRES

```

```

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2 MACY11 30A(1052) 21-FEB-78 08:58 PAGE 86
CZRKKF.P11 21-FEB-78 08:51 T35 CHECK THAT RK11 INTERRUPTS WHEN IDE IS SET SEQ 0085
4614 014226 012720 014262 MOV #1$, (R0)+ ;SET UP INTERRUPT VECTOR FOR RK11
4615 014232 012710 000340 MOV #340, (R0) ;SET PSW ON INTERRUPT
4616 014236 105711 TSTB @R1 ;WAIT FOR CNTRL RDY TO SET
4617 014240 100376 BPL -2 ;
4618 014242 012711 000100 MOV #100, @R1 ;SET IDE BIT IN RKCS
4619 014246 104420 000005 WAT.INT ,5 ;WAIT FOR INTERRUPT, ATLEAST
4620 ; ;37 US FOR 11/20, 7 US FOR 11/45
4621 014252 011137 001162 MOV @R1, $REG0 ;GET RKCS
4622 014256 104074 ERROR 74 ;RK11 DID NOT INTERRUPT WHEN IDE
4623 ; ;WAS SET, WITH CNTRLE RDY SET & GO
4624 ; ;CLEAR
4625 014260 000400 BR 1$ ;
4626 014262 022626 1$: CMP (SP)+, (SP)+ ;RK11 INTERRUPTED CORRECTLY TO
4627 ; ;THIS. RESTORE STACK POINTER
4628 ; ;(FROM RK11 INTERRUPT)
4629 014264 022626 CMP (SP)+, (SP)+ ;RESTORE STACK POINTER
4630 ; ;(FROM WAT.INT)
4631 014266 012777 014302 165106 MOV #2$, @RKVEC ;IF THERE IS FAULTY POLLING OR INTERRUPT
4632 ; ;LOGIC SECOND INTERRUPT MIGHT OCCUR
4633 014274 104420 000005 WAT.INT ,5 ;WAIT FOR INTERRUPT, IF ANY
4634 ; ;DUE TO FAULTY LOGIC
4635 ;
4636 014300 000403 BR 3$ ;
4637 ;
4638 014302 022626 2$: CMP (SP)+, (SP)+ ;RESTORE STACK PTR (FROM RK11 INTRUPT)
4639 014304 022626 CMP (SP)+, (SP)+ ;RESTORE STACK PTR (FROM WAT.INT)
4640 014306 104020 ERROR 20 ;AN UNEXPECTED RK11 INTERRUPT
4641 ; ;OCCURED. THERE SHOULD HAVE BEEN
4642 ; ;ONLY 1 INTERRUPT (TO 1$ ABOVE)
4643 014310 012777 004600 165064 3$: MOV #BADINT, @RKVEC ;RESTORE VECTOR ADRES FOR
4644 ; ;UNEXPECTED RK11 INTERRUPT,
4645 014316 012746 000340 MOV #340, -(SP)
4646 014322 012746 014330 MOV #65$, -(SP)
4647 014326 000002 RTI
4648 014330 65$:
4649
4650
4651 ;*****
4652 ;*TEST 36 CHECK THAT WITH IDE SET RK11 INTERRUPTS AFTER INITIATION & COMPLETION OF
4653 ;*THIS TEST CHECKS THAT AN INTERRUPT FROM RK11 OCCURS AFTER
4654 ;*A SEEK IS INITIATED WITH 'IDE' BIT SET, AND THEN A SECOND
4655 ;*INTERRUPT OCCURS AFTER THE SEEK IS DONE. IT ALSO CHECKS THAT
4656 ;*AFTER THE FIRST INTERRUPT 'SCP' BIT IS NOT SET, WHEREAS AFTER
4657 ;*THE SECOND INTERRUPT 'SCP' IS SET.
4658 ;*THIS TEST ALSO CHECKS A PART OF THE POLLING LOGIC.
4659 ;*****
4660 014330 000004 TST36: SCOPE ;DO 5 ITERATIONS
4661 014332 012737 000005 001206 MOV #5, $TIMES ;GO, DO CONTROL RESET
4662 014340 104413 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
4663 ; ;RESET' ROUTINE. A CONTROL RESET IS
4664 ; ;ISSUED AND AFTER A CERTAIN TIME
4665 ; ;IF THE 'CNTRL RDY' DOES NOT SET
4666 ; ;AN ERROR IS REPORTED. NOTE THAT
4667 ; ;THE PC IN ERROR MESSAGE IS THE
4668 ; ;PC WHERE 'CNT.RESET' IS LOCATED.
4669

```

```

MD-11-CZRKKF, RK11 BASIC LOGIC TEST 2 MACY11 30A(1052) 21-FEB-78 08:58 PAGE 87
CZRKKF.P11 21-FEB-78 08:51 T36 CHECK THAT WITH IDE SET RK11 INTERRUPTS AFTER INITIATION & COMPLETION OF S SEQ 0086
4670 ;THIS IS A VERY BASIC ERR& IF IT
4671 ;OCCURS GO BACK TO TEST 10
4672 014342 013700 001332 MOV RKCS, R0
4673 014346 013777 001350 164764 MOV DRIVAD, @RKDA ;ADRES THE DRIVE
4674 014354 004737 021504 JSR PC, DRESET ;GO, DO DRIVE RESET
4675 014360 104026 ERROR 26 ;R/W/S RDY DIDN'T SET AFTER DOING
4676 ; ;ABOVE DRIVE RESET
4677 014362 013701 001402 2$: MOV RKVEC, R1
4678 014366 012721 014432 MOV #3$, (R1)+ ;SET UP VECTOR ADRES FOR RK11 INTERRUPT
4679 014372 012711 000340 MOV #340, (R1) ;SET UP PSW ON INTERRUPT
4680 014376 052777 000040 164734 BIS #40, @RKDA ;ADRES CYLINDER #1
4681 014404 012710 000111 MOV #111, @R0 ;SEEK, GO WITH IDE SET
4682 014410 104420 000300 WAT.INT ,300 ;WAIT FOR THE DRIVE TO
4683 ; ;INTERRUPT AFTER ADRES WAS RECVD
4684 ; ;WAITING TIME= 1.4 MS FOR 11/20
4685 ; ;280 US FOR 11/45
4686 ; ;ERROR, IF INTERRUPT DID NOT OCCUR
4687 ; ;BY NOW
4688 014414 012777 004600 164760 MOV #BADINT, @RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4689 014422 011037 001162 MOV @R0, $REG0 ;GET RKCS
4690 014426 104075 ERROR 75 ;INTERRUPT DID NOT OCCUR AFTER
4691 ; ;SEEK WAS INITIATED WITH IDE SET
4692 014430 000402 BR 3$+4 ;
4693 014432 022626 3$: CMP (SP)+, (SP)+ ;OK, IF RK11 INTERRUPTED TO THIS
4694 ; ;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4695 014434 022626 CMP (SP)+, (SP)+ ;RESTORE STACK POINTER (FROM
4696 ; ;WAT.INT)
4697 014436 012777 014502 164736 MOV #5$, @RKVEC ;SET UP NEW VECTOR ADRES FOR RK11
4698 014444 032710 020000 BIT #20000, @R0 ;IS SCP CLEAR
4699 014450 001403 BEQ 4$ ;YES, BRANCH
4700 014452 011037 001162 MOV @R0, $REG0 ;GET RKCS
4701 014456 104076 ERROR 76 ;SCP SET BEFORE SEEK TO LAST
4702 ; ;CYLINDER WAS DONE
4703 014460 104420 056700 4$: WAT.INT ,56700 ;WAIT FOR DRIVE TO INTERRUPT
4704 ; ;AFTER SEEK WAS COMPLETED
4705 ; ;WAITING TIME=180 MS FOR 11/20
4706 ; ;36 MS FOR 11/45
4707 014464 012777 004600 164710 MOV #BADINT, @RKVEC ;IT'S AN ERROR IF BY THIS TIME
4708 ; ;INTERRUPT HAS NOT OCCURRED
4709 014472 004737 021002 JSR PC, GT3RG ;GO GET RKCS, ER, DS
4710 014476 104077 ERROR 77 ;RK11 DID NOT INTERRUPT AFTER SEEK (TO
4711 ; ;LAST CYLINDER) WAS DONE WITH IDE SET
4712 014500 000401 BR 5$+2 ;
4713 014502 02 626 5$: CMP (SP)+, (SP)+ ;OK, IF RK11 INTERRUPTED TO THIS AFTER
4714 ; ;SEEK WAS COMPLETED. RESTORE
4715 ; ;STACK POINTER (FROM RK11 INTERRUPT)
4716 014504 022626 CMP (SP)+, (SP)+ ;RESTORE STACK POINTER (FROM
4717 ; ;WAT.INT)
4718 014506 012777 004600 164666 MOV #BADINT, @RKVEC ;RESTORE RK11 INTERRUPT VECTOR ADRES
4719 ; ;FOR UNEXPECTED INTERRUPTS
4720 014514 032710 020000 BIT #20000, @R0 ;DID SCP BIT SET?
4721 014520 001003 BNE 6$ ;YES, BRANCH
4722 014522 011037 001162 MOV @R0, $REG0 ;GET RKCS
4723 014526 104053 ERROR 53 ;SCP DID NOT SET AFTER RK11 INTERRUPTED
4724 ; ;INDICATING SEEK WAS DONE
4725 014530 017701 164572 6$: MOV @RKDS, R1 ;GET RKDS

```

```

4726 014534 042701 017777 BIC #17777,R1 ;MASK NON-ID BITS IN RKDS
4727 014540 020137 001350 CMP R1,DRIVAD ;CORRECT ID BITS IN RKDS?
4728 014544 001414 BEQ 7$ ;YES, BRANCH
4729
4730 014546 013746 001350 MOV DRIVAD,-(SP) ;PUSH DRV ADRES ON THE STACK
4731 014552 004737 021200 JSR PC,SFTRT ;GO, SHIFT RIGHT DRV #
4732 014556 012637 001162 MOV (SP)+,$REGO ;GET EXPCTD DRV #
4733 014562 010146 MOV R1,-(SP) ;PUSH ID BITS ON THE STACK
4734 014564 004737 021200 JSR PC,SFTRT ;GO SHIFT THEM RIGHT
4735 014570 012637 001164 MOV (SP)+,$REG1 ;POP THE RECVD ID BITS
4736 014574 104047 ERROR 47 ;WRONG ID BITS WERE RECVD IN
;RKDS AFTER SEEK WAS DONE (INTRUPT
;MODE). 'EXPT' INDICATES THE DRIVE
;# THAT SHOULD HAVE BEEN IN THE
;ID BITS. 'RECVD' INDICATES THE
;DRIVE # THAT WAS RECVD IN THE ID BITS
4743 014576 7$: MOV #340,-(SP)
4744 014576 012746 000340 MOV #64$,-(SP)
4745 014602 012746 014610 RTI
4746 014606 000002 64$: CNT.RESET ;GO DO CONTROL RESET
4747 014610 MOV DRIVAD,@RKDA ;ADRES THE DRIVE
4748 014610 104413 BIT #16000,@RKDS ;DID CNTRL RESET CLEAR DRIVE ID BITS?
4749 014612 013777 001350 164520 BEQ 8$ ;YES, BR:NCH
4750 014620 032777 160000 164500 MOV @RKDS,$REGO ;GET RKDS
4751 014626 001404 BEQ 8$ ;CONTROL RESET DIDN'T CLEAR THE
4752 014630 017737 164472 001162 ERROR 50 ;DRIVE ID BITS (13-15) IN RKDS
4753 014636 104050
4754
4755
4756 014640 022710 000200 8$: CMP #200,@R0 ;WAS SCP BIT CLEARED BY CNTRL RESET?
4757 014644 001403 BEQ TST37 ;:YES, EXIT
4758 014646 011037 001162 MOV @R0,$REGO ;GET RKCS
4759 014652 104100 ERROR 100 ;CNTRL RESET DID NOT CLEAR SCP BIT
4761
4762 ;*****
4763 ;*TEST 37 CHECK THAT WITH IDE SET RK11 INTERRUPTS WHEN READ IS DONE
4764 ;*THIS TEST CHECKS THAT WHEN A DATA TRANSFER FUNCTION IS DONE
4765 ;*WITH IDE BIT SET, RK11 INTERRUPTS WHEN THE FUNCTION IS COMPLETED
4766 ;*FUNCTION USED IN THIS TEST IS READ.
4767 ;*****
4768 014654 000004 TST37: SCOPE
4769 014656 104413 CNT.RESET ;GO, DO CONTROL RESET
4770 ;THIS IS A CALL FOR THE 'CNTRL-
4771 ;RESET' ROUTINE. A CONTROL RESET IS
4772 ;ISSUED AND AFTER A CERTAIN TIME
4773 ;IF THE 'CNTRL RDY' DOES NOT SET
4774 ;AN ERROR IS REPORTED. NOTE THAT
4775 ;THE PC IN ERROR MESSAGE IS THE
4776 ;PC WHERE 'CNT.RESET' IS LOCATED.
4777 ;THIS IS A VERY BASIC ERR# IF IT
4778 ;OCCURS GO BACK TO TEST 10
4779 014660 104421 TST.SIN ;CHECK IF SIN IS SET. IF SET
4780 ;DO DRIVE RESET TO CLEAR IT
4781

```

```

4782 014662 013700 001332 MOV RKCS,R0
4783 014666 013702 001340 MOV RKDA,R2
4784 014672 013704 001336 MOV RKBA,R4
4785 014676 013701 001350 MOV DRIVAD,R1
4786 014702 052701 000013 BIS #13,R1 ;SET BITS FOR SEC 13
4787 014706 012777 177600 164420 MOV #-200,@RKWC ;READ 200 (OCTAL WORDS)
4788 014714 010112 MOV R1,@R2 ;FROM THIS DISK ADRES (CYL 0, SEC 13)
4789 014716 012714 033342 MOV #OUTBUF,@R4 ;INTO THIS BUS ADRES
4790 014722 013705 001402 MOV RKVEC,R5
4791 014726 012725 014764 MOV #1$(R5)+ ;SET UP VECTOR ADRES FOR RK11 TO INTRUPT
4792 014732 012715 000340 MOV #340,(R5) ;SET PSW ON INTERRUPT
4793 014736 012710 000105 MOV #105,@R0 ;READ, GO, IDE SET
4794 014742 104420 127710 WAT.INT ,127710 ;WAIT FOR RK11 TO INTERRUPT ON
;COMPLETION OF READ
;WAITING TIME= 337 MS FOR 11/20
;67 MS FOR 11/45
4795
4796
4797
4798 014746 012777 004600 164426 MOV #BADINT,@RKVEC ;RESTORE UNEXPCTED INTERRUPT VECTOR ADRES
4799 014754 011037 001162 MOV @R0,$REGO ;GET RKCS
4800 014760 104101 ERROR 101 ;RK11 DID NOT INTERRUPT AFTER READ
;WAS DONE, IDE BIT SET.
4801
4802 014762 000404 BR 1$+10
4803 014764 022626 1$: CMP (SP)+,(SP)+ ;OK, IF RK11 INTERRUPTED TO THIS
;RESTORE STACK POINTER (FROM RK11 INTERRUPT)
4804
4805 014766 022626 CMP (SP)+,(SP)+ ;RESTORE STACK POINTER (FROM WAT.INT)
4806 014770 012777 004600 164404 MOV #BADINT,@RKVEC ;RESTORE UNEXPCTED RK11 INTERRUPT
;VECTOR ADRES
4807
4808 014776 004737 021342 JSR PC,CHKR ;CHECK IF ANY BIT IN RKER IS SET.
;IF YES, RETURN HERE.
4809
4810 015002 104036 ERROR 36 ;RKER SET ON DOING READ FROM SEC 0.
;CYL 13 IN INTERRUPT MDDE
4811
4812 015004 062701 000005 4$: ADD #5,R1 ;RKDA SHOULD HAVE INCREMENTED TO THIS
4813 015010 020112 CMP R1,@R2 ;DID RKDA INCREMENT CORRECTLY?
4814 015012 001405 BEQ 2$ ;YES BRANCH
4815 015014 010137 001162 MOV R1,$REGO ;GET EXPCTD RTDA
4816 015020 011237 001164 MOV @R2,$REG1 ;GET RKDA RECVD
4817 015024 104040 ERROR 40 ;RKDA INCREMENTED WRONG ON DOING
;A READ ON CYL 0, SEC 13
4818
4819 015026 004737 021316 2$: JSR PC,CHKWC ;CHECK THAT RKWC OVERFLOWED TO 0.
;IF NOT RETURN HERE.
4820
4821 015032 104041 ERROR 41 ;RKWC DIDN'T OUFLEO AFTER
;A READ OF 200 WORDS
4822
4823
4824
4825 015034 012746 000340 3$: MOV #340,-(SP)
4826 015040 012746 015046 MOV #64$,-(SP)
4827 015044 000002 RTI
4828 015046 64$: CMP #OUTBUF+400,@R4 ;DID RKBA INCREMENT CORRECTLY?
4829 015046 022714 033742 BEQ TST40 ;:YES, EXIT
4830 015052 001406 MOV #OUTBUF+400,$REGO ;GET EXPTC RKBA
4831 015054 012737 033742 001162 MOV @R4,$REG1 ;GET RKBA RECVD
4832 015062 011437 001164 ERROR 42 ;RKBA DID NOT INCREMENT CORRECTLY
;AFTER A READ OF 200 WORDS
4833 015066 104042
4834
4835
4836
4837 ;*****
;*TEST 40 CHECK THAT RK11 INTERRUPTS AT BR5 ONLY

```

```

4838 ;*THIS TEST CHECKS THAT RK11 CAN INTERRUPT AT BR5 ONLY. IF IT
4839 ;*INTERRUPTS AT A LEVEL HIGHER THAN BR5 AN ERROR IS INDICATED.
4840 ;*IF IT DOES NOT INTERRUPT AT BR5 OR LOWER THEN ALSO AN
4841 ;*ERROR IS INDICATED. IF FOR SOME REASON THE INTERRUPT
4842 ;*LEVEL IS CHANGED FROM BR5, THEN CONTENTS OF RKPRI WILL
4843 ;*HAVE TO BE CHANGED ACCORDINGLY AND STILL TEXT WILL
4844 ;*CHECK FOR THIS BR LEVEL.
4845 ;*****
4846 015070 000004 TST40: SCOPE
4847 015072 104413 CNT.RESET ;GO, DO CONTROL RESET
4848 ;THIS IS A CALL FOR THE 'CNTRL-
4849 ;RESET' ROUTINE. A CONTROL RESET IS
4850 ;ISSUED AND AFTER A CERTAIN TIME
4851 ;IF THE 'CNTRL RDY' DOES NOT SET
4852 ;AN ERROR IS REPORTED. NOTE THAT
4853 ;THE PC IN ERROR MESSAGE IS THE
4854 ;PC WHERE 'CNT.RESET' IS LOCATED.
4855 ;THIS IS A VERY BASIC ERR& IF IT
4856 ;OCCURS GO BACK TO TEST 10
4857 015074 104421 TST.SIN ;CHECK IF SIN IS SET, IF
4858 ;DO DRIVE RESET TO CLR IT
4859 015076 012737 015132 001110 MOV #1,$SLPDRR ;SET, DO DRIVE RESET TO CLR IT
4860 ;SET RETURN ADRES FOR LUPING
4861 ;ON ERROR (SW 9)
4861 015104 013700 001332 MOV RKCS,R0
4862 015110 013777 001350 164222 MOV DRIVAD,@RKDA
4863 015116 012701 000007 MOV #7,R1 ;PRIORITY LEVEL 7
4864 015122 012702 000340 MOV #340,R2 ;BR LEVEL 7 FOR PSW
4865 015126 013703 001400 MOV RKPRI,R3 ;NOTE, IF RK11 INTERRUPT LEVEL IS
;CHANGED FROM 5 TO ANY OTHER LEVEL
;THEN CHANGE CONTENTS OF 'RKPRI'
; ACCORDINGLY
4866
4867
4868
4869 015132 013704 001402 1$: MOV RKVEC,R4
4870 015136 012724 015244 MOV #3$(,R4)+ ;SET UP ADRES FOR RK11 TO INTERRUPT
4871 015142 012714 000340 MOV #340,(R4) ;SET UP PSW ON INTERRUPT
4872 015146 012465 MOV R2,-(SP) ;SET PROCESSOR PRIORITY LEVEL AS
4873 015150 012746 015156 MOV #4$,-(SP)
4874 015154 000002 RTI
4875 015156
4876 015156 012710 000100 4$: MOV #100,@R0 ;INDICATED BY R2
4877 015162 012705 177760 MOV #-20,R5 ;SET THE IDE BIT
4878 015166 005205 INC R5 ;WAIT FOR THE RK11 INTERRUPT
4879 015170 001376 BNE #-2 ;WAITING TIME=78 US FOR 11/20
4880 015172 020203 CMP R2,R3 ;13 US FOR 11/45
4881 015174 003005 BGT 2$ ;WAS THE CPU PRIORITY LEVEL LESS THAN
;THE RK11 LEVEL? IF YES, RK11
;SHOULD HAVE INTERRUPTED. ERROR,
;IF IT C.D NOT
4882
4883
4884 015176 010137 001162 MOV R1,$REG0 ;GET CPU BR LEVEL
4885 015202 011037 001164 MOV @R0,$REG1 ;GET RKCS
4886 015206 104103 ERROR 103 ;THOUGH CPU LEVEL WAS LESS THAN
;THE RK11 LEVEL (5). RK11 DID NOT
;INTERRUPT
4887
4888
4889 015210 005010 2$: CLR @R0 ;CLEAR RKCS
4890 015212 062702 177740 ADD #-40,R2 ;DECREASE THE PRIORITY LEVEL (FOR
;CPU) BY 1
4891
4892 015216 005301 DEC R1 ;CPU WILL B AT THIS LEVEL
4893 015220 001344 BNE 1$ ;LUP BAK & CHK FOR THIS BR LEVEL.

```

```

4894
4895 015222 012777 004600 164152 MOV #BADINT,@RKVEC ;DONE WITH CHKING FOR ALL LEVELS.
4896 ;RESTORE UNEXPECTED RK11 INTERRUPT
4897 015230 012746 000340 MOV #340,-(SP) ;VECTOR
4898 015234 012746 015242 MOV #64$,-(SP)
4899 015240 000002 RTI
4900 015242
4901 015242 000414 64$: BR TST41 ;EXIT, TO NXT TST
4902
4903 015244 022626 3$: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
4904 015246 012777 004600 164126 MOV #BADINT,@RKVEC ;RESTORE UNEXPECTED RK11 INTERRUPT
4905 ;VECTOR
4906 015254 020203 CMP R2,R3 ;IF THIS INTERRUPT OCCURED WHEN
4907 015256 003754 BLE 2$ ;CPU LEVEL WAS LESS THAN THE
;RK11 PRIORITY LEVEL (5) THEN IT IS
;OK. IF NOT SO, ERROR
4908
4909
4910 015260 010137 001162 MOV R1,$REG0 ;GET CPU BR LEVEL
4911 015264 011037 001164 MOV @R0,$REG1 ;GET RKCS
4912 015270 104104 ERROR 104 ;RK11 INTERRUPTED WHEN THE CPU
;LEVEL (AS POINTED BY R1) WAS
;HIGHER OR SAME AS THE RK11
;LEVEL (5)
4913
4914
4915
4916 015272 000746 BR 2$ ;GO BACK & CHK THE NXT LEVEL
4917
4918 ;*****
4919 ;*TEST 41 SIMULATE & CHECK 'OVR' ERROR
4920 ;*THIS TEST SIMULATES OVERRUN ERROR AND CHECKS IF THE OVR
4921 ;*BIT IN RKER GETS SET. THEN IT IS CLEARED USING CNTRL RESET
4922 ;*& CHECKED THAT IT WAS CLEARED. OVR CONDITION IS SIMULATED
4923 ;*BY TRYING TO READ 401(OCTAL) WORDS FROM LAST CYLINDER(312),
4924 ;*LAST SECTOR (13), SURFACE 1.
4925 ;*****
4926 015274 000004 TST41: SCOPE
4927 015276 104413 CNT.RESET ;GO, DO CONTROL RESET
4928 ;THIS IS A CALL FOR THE 'CNTRL-
4929 ;RESET' ROUTINE. A CONTROL RESET IS
4930 ;ISSUED AND AFTER A CERTAIN TIME
4931 ;IF THE 'CNTRL RDY' DOES NOT SET
4932 ;AN ERROR IS REPORTED. NOTE THAT
4933 ;THE PC IN ERROR MESSAGE IS THE
4934 ;PC WHERE 'CNT.RESET' IS LOCATED.
4935 ;THIS IS A VERY BASIC ERR& IF IT
4936 ;OCCURS GO BACK TO TEST 10
4937 015300 104421 TST.SIN ;CHECK IF SIN IS SET, IF
4938 ;DO DRIVE RESET TO CLR IT
4939 015302 013701 001350 MOV DRIVAD,R1 ;GET ADRES OF DRIVE
4940 015306 052701 014533 BIS #14533,R1 ;SET BITS FOR LAST CYLINDER (312),
;SUR 1, LAST SECTOR (13)
4941 ;READ 401 WORDS
4942 015312 012777 177377 164014 MOV #-401,@RKWC ;INTO THIS MEMORY BUFFER
4943 015320 012777 033342 164010 MOV #OUTBUF,@RKBA ;FROM THIS DSK ADRES, LAST CYL.
4944 015326 010177 164006 MOV R1,@RKDA ;LAST SEC, SURFACE 1
4945 ;READ, GO
4946 015332 012777 000005 163772 MOV #5,@RKCS
4947
4948 015340 005002 CLR R2
4949 015342 105777 163764 1$: TSTB @RKCS ;DID CNTRL RDY SET?

```

```

4950 015346 100410      BMI      25      ;YES, BRANCH
4951 015350 005202      INC      R2      ;NO, WAIT FOR IT
4952 015352 001373      BNE     15      ;IF WAITED LONG, REPORT ERROR MESSAGE BECAUSE
4953                                     ;OVR SHOULD HAVE SET HE CAUSING
4954                                     ;CNTRL RDY TO SET BY NOW
4955 015354 017737 163754 001166      MOV     @RKWC,$REG2 ;GO, GET RKCS, ER
4956 015362 004737 021010      JSR    PC,GT2RG   ;CNTRL RDY DID NOT SET AFTER DOING
4957 015366 104002      ERROR  2         ;AN OVR READ. HE SHOULD HAVE OCCURED
4958                                     ;SETTING CNTRL RDY (HE BECAUSE OF
4959                                     ;OVR CONDITIONS)
4960                                     ;DID OVR BIT SET IN RKER?
4961 015370 032777 040000 163732 25:   BIT     #40000,@RKER ;
4962 015376 001006      BNE     35      ;
4963 015400 004737 021010      JSR    PC,GT2RG   ;GET RKCS, ER
4964 015404 012737 040000 001166      MOV     #40000,$REG2 ;THIS BIT (OVR) DID NOT SET.
4965 015412 104105      ERROR  105      ;OVR ERROR BIT DID NOT SET IN RKER
4966                                     ;ON SIMULATING OVR CONDITIONS
4967 015414 022777 140204 163710 35:   CMP     #140204,@RKCS ;DID HE & ERR SET WHEN OVR SET IN RKER?
4968 015422 001403      BEQ     45      ;YES, BRANCH
4969 015424 004737 021010      JSR    PC,GT2RG   ;GET RKCS, ER
4970 015430 104106      ERROR  106      ;HE OR ERR BIT DID NOT SET IN RKCS WHEN
4971                                     ;AN OVR ERROR WAS SIMULATED
4972                                     ;CLEAR OVR, ERR, HE BITS
4973 015432 104413      45:   CNT.RESET      ;GO, DO CONTROL RESET
4974                                     ;THIS IS A CALL FOR THE 'CNTRL-
4975                                     ;RESET' ROUTINE. A CONTROL RESET IS
4976                                     ;ISSUED AND AFTER A CERTAIN TIME
4977                                     ;IF THE 'CNTRL RDY' DOES NOT SET
4978                                     ;AN ERROR IS REPORTED. NOTE THAT
4979                                     ;THE PC IN ERROR MESSAGE IS THE
4980                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
4981                                     ;THIS IS A VERY BASIC ERR& IF IT
4982                                     ;OCCURS GO BACK TO TEST 10
4983 015434 004737 021356      JSR    PC,CHKECLR ;CHECK IF 'OVR' BIT WAS CLEARED BY
4984                                     ;CON.RESET, IF NOT RETURN HERE.
4985 015440 104102      ERROR  102      ;CNTRL RESET DID NOT CLEAR OVR
4986                                     ;BIT IN RKER
4987 015442 004737 021402      55:   JSR    PC,CHKCCLR ;CHECK IF 'ERR' & 'HE' BIT GOT CLEARED BY
4988                                     ;CON.RESET, IF NOT RETURN HERE.
4989 015446 104102      ERROR  102      ;CNTRL RESET DID NOT CLEAR
4990                                     ;HE OR ERR BIT IN RKCS.
4991 015450 004737 021504      65:   JSR    PC,DRESEt ;GO DO DRIVE RESET
4992 015454 104026      ERROR  26      ;R/W/S RDY DIDN'T SET
4993                                     ;AFTER THE ABOVE DRIVE RESET
4994
4995 *****
4996 *TEST 42 SIMULATE & CHECK PGE ERROR
4997 ;*THIS TEST SIMULATES 'PROGRAMMING ERROR' & CHECKS IF IT IS
4998 ;*DETECTED BY PGE BIT IN RKER. THEN A CNTRL RESET IS DONE &
4999 ;*IT IS CHECKED IF PGE BIT WAS CLEARED. IT IS ALSO CHECKED IF
5000 ;*THE SETTING & CLEARING OF PGE BIT SETS & CLEARS HE, ERR
5001 ;*BITS IN RKCS.
5002 *****
5003 SCOPE
5004 CNT.RESET ;GO, DO CONTROL RESET
5005 ;THIS IS A CALL FOR THE 'CNTRL-

```

```

5006 ;RESET' ROUTINE. A CONTROL RESET IS
5007 ;ISSUED AND AFTER A CERTAIN TIME
5008 ;IF THE 'CNTRL RDY' DOES NOT SET
5009 ;AN ERROR IS REPORTED. NOTE THAT
5010 ;THE PC IN ERROR MESSAGE IS THE
5011 ;PC WHERE 'CNT.RESET' IS LOCATED.
5012 ;THIS IS A VERY BASIC ERR& IF IT
5013 ;OCCURS GO BACK TO TEST 10
5014 ;GO CHECK IF SIN IS SET, IF
5015 ;SET DO DRIVE RESET TO CLR IT
5016 015462 104421      TST.SIN
5017 015464 013701 001330      MOV     RKER,R1
5018 015470 013777 001350 163641      MOV     DRIVAD,@RKDA ;ADRES THE DRIVE, CYLINDER 0
5019 015476 012777 002011 163626      MOV     #2011,@RKCS ;SEEK, GO WITH FMT SET
5020                                     ;THIS IS A PGE SIMULATION
5021 015504 104414      CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
5022                                     ;ROUTINE WHICH WAITS FOR CNT
5023                                     ;RDY TO SET. IF CNTRL RDY DOES
5024                                     ;NOT SET WITHIN 883 MS/ 11-20
5025                                     ;(176 MS FOR 11-45 WITH BIPOLAR)
5026                                     ;AN ERRDR IS REPORTED
5027 015506 032711 004000      BIT     #4000,@r1 ;DID PGE BIT IN RKER SET?
5028 015512 301006      BNE     15      ;YES, BRANCH
5029 015514 012737 004000 001166      MOV     #4000,$REG2 ;THIS BIT IN RKER (PGE) DID NOT SET
5030 015522 004737 021010      JSR    PC,GT2RG   ;GO GET RKCS, ER FOR MESSAGE
5031 015526 104105      ERROR  105      ;PGE BIT DID NOT SET IN RKER
5032                                     ;ON SIMULATION OF PGE CONDITION
5033                                     ;$REG2 CONTAINS THE RKER BIT (PGE)
5034                                     ;THAT SHOULD HAVE SET.
5035 015530 022777 142210 163574 15:   CMP     #142210,@RKCS ;DID HE & ERR BITS SET?
5036 015536 001403      BEQ     25      ;YES, BRANCH
5037 015540 004737 021010      JSR    PC,GT2RG   ;GO, GET RKCS, ER
5038 015544 104106      ERROR  106      ;HE OR ERR BIT DID NOT SET WHEN
5039                                     ;PGE SET IN RKER.
5040                                     ;CLEAR PGE, HE, ERR BITS
5041 015546 104413      25:   CNT.RESET      ;GO, DO CONTROL RESET
5042                                     ;THIS IS A CALL FOR THE 'CNTRL-
5043                                     ;RESET' ROUTINE. A CONTROL RESET IS
5044                                     ;ISSUED AND AFTER A CERTAIN TIME
5045                                     ;IF THE 'CNTRL RDY' DOES NOT SET
5046                                     ;AN ERROR IS REPORTED. NOTE THAT
5047                                     ;THE PC IN ERROR MESSAGE IS THE
5048                                     ;PC WHERE 'CNT.RESET' IS LOCATED.
5049                                     ;THIS IS A VERY BASIC ERR& IF IT
5050                                     ;OCCURS GO BACK TO TEST 10
5051 015550 004737 021356      JSR    PC,CHKECLR ;CHECK IF 'PGE' BIT GOT CLEARED BY
5052                                     ;CONTROL RESET, IF NOT RETURN HERE.
5053 015554 104102      ERROR  102      ;CNTRL RESET DID NOT CLEAR
5054                                     ;PGE BIT IN RKER
5055 015556 004737 021402      35:   JSR    PC,CHKCCLR ;CHECK IF 'ERR' BITGOT CLEARED BY
5056                                     ;CON.RESET, IF NOT RETURN HERE.
5057 015562 104102      ERROR  102      ;RKCS BITS HE OR ERR DID NOT
5058                                     ;GET CLEARED BY CNTRL RESET
5059
5060 *****
5061 *TEST 43 SIMULATE & CHECK NXM ERROR

```

```

; *THIS TEST SIMULATES A NON-EXISTENT MEMORY ERROR (NXM) AND
; *CHECKS IF IT IS DETECTED BY NXM BIT OR RKER. LOCATION 760000
; *IS REFERENCED & IT HAPPENS TO BE A NON EXISTENT LOCATION
; *(FOR DIAGNOSTIC PURPOSES LIKE THIS). IT IS ALSO CHECKED
; *(IF HE & ERR BITS ALSO SET AND ALL 3 BITS CAN BE CLEARED
; * BY CONTROL RESET.
;*****
TST43: SCOPE                               ;GO, DO CONTROL RESET
CNT.RESET                                ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;GO CHECK IF SIN IS SET
;IF SET DO DRIVE RESET TO CLR IT

                                TST.SIN
0580 015570 104421
0581
0582 015572 005002                CLR    R2
0583 015574 013700                MOV    RKCS,R0
0584 015600 012777 177777 163526  MOV    #-1,@RKWC ;WRITE CHECK 1 WORD
0585 015606 012777 160000 163522  MOV    #160000,@RKBA ;AT THIS BUS ADRES
0586 015614 013777 001350 163516  MOV    DRIVAD,@RKDA ;WITH THIS DISK ADRES (CYL 0, SEC 0)
0587 015622 012710 000067        MOV    #67,@R0 ;WRT CHK. GO, MEX BITS SET
0588 015626 105777 163500        1$:   TSTB  @RKCS ;DID CNTRL RDY SET AS A RESULT OF HE?
0589 015632 100410                BMI    2$ ;YES, BRANCH
0590 015634 005202                INC    R2 ;WAITED LONG ENOUGH?
0591 015636 001373                BNE    1$ ;IF NOT LUP BAK & WAIT
0592 015640 004737 021010        JSR    PC,GT2RG ;GET RKCS, ER
0593 015644 017737 163464 001166  MOV    @RKWC,$REG2 ;GET RKWC
0594 015652 104113                ERROR  113 ;CNTRL RDY DID NOT SET ON DOING
;A WRT CHK WITH A NXM LOCATION.
;THIS HE SHOULD HAVE SET THE
;CNTRL RDY BIT IN RKCS
;DID NXM BIT IN RKER SET?
0597
0598 015654 032777 002000 163446 2$:   BIT    #2000,@RKER
0599 015662 001006                BNE    3$ ;YES, BRANCH
0600 015664 004737 021010        JSR    PC,GT2RG ;GO GET RKCS, RKER
0601 015670 012737 002000 001166  MOV    #2000,$REG2 ;THIS BIT (NXM) DID NOT SET IN RKER
0602 015676 104105                ERROR  105 ;NXM BIT DID NOT SET IN RKER ON
;SIMULATING NXM CONDITION.
;DID HE & ERR BIT SET?
0603
0604 015700 022710 140266        3$:   CMP    #140266,@R0
0605 015704 001403                BEQ    4$ ;YES, BRANCH
0606 015706 004737 021010        JSR    PC,GT2RG ;GO, GET RKCS, RKER
0607 015712 104106                ERROR  106 ;HE OR ERR BIT DID NOT SET WHEN
;NXM ERROR WAS SIMULATED
;CLEAR NXM, HE, ERR BITS
;GO, DO CONTROL RESET
0610 015714 104413        4$:   CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.

```

```

;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF 'NXM' BIT GOT C;LEARED BY
;CON.RESET, IF NOT RETURN HERE.
;CNTRL RESET DID NOT CLEAR
;NXM BIT IN RKER
5120 015716 004737 021356        JSR    PC,CHKECLR
5121
5122 015722 104102                ERROR  102
5123
5124 015724 004737 021402        5$:   JSR    PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS GOT CLEARED
5125
5126 015730 104102                ERROR  102 ;BY CON.RESET, IF NOT RETURN HERE.
5127
5128 015732 004737 021436        6$:   JSR    PC,TSTRWS ;CNTRL RESET DID NOT CLEAR
5129
5130 015736 104016                ERROR  16 ;HE OR ERR BIT IN RKCS.
;GO CHECK IF R/W/S RDY IS SET &
;WAIT FOR IT. SKIP ERROR IF IT IS SET
;R/W/S RDY IS NOT SET
;*****
; *TEST 44 SIMULATE & CHECK NXD ERROR
; *THIS TEST SIMULATES NON-EXISTENT DISK ERROR & CHECKS IF
; *IT IS DETECTED BY NXD BIT OF RKER. IF ALL EIGHT ARE PRESENT
; *THEN THIS TEST IS ABORTED FOR SIMULATION CANNOT BE DONE.
;*****
TST44: SCOPE                               ;GO, DO CONTROL RESET
CNT.RESET                                ;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF SET
;DO DRV RESET TO CLR IT

                                TST.SIN
5148 015744 104421
5149
5150
5151 015746 013700                MOV    RKCS,R0
5152 015752 012702 160000        MOV    #160000,R2 ;ADRES DRIVE 7 TO FIND
;IF IT IS PRESENT
5153
5154 015756 010277 163356        1$:   MOV    R2,@RKDA ;ADRES DRIVE # POINTED TO BY R2
5155 015762 104417 000001        DELAY ,1 ;TIME DELAY, 7.5 US ON 11/20,
;1.5 US ON 11/45
5156
5157 015766 105777 163334        TSTB  @RKDS ;IS IT PRESENT?
5158 015772 100004                BPL    2$ ;NO, BRANCH
5159 015774 062702 160000        ADD    #-20000,R2 ;ADRES THE NXT DRIVE IN THE
;REVERSE ORDER. I.E. 7.6...
5160
5161 016000 001366                BNE    1$ ;LUP BAK & TRY TO FIND A DRIVE
5162
5163 016002 000435                BR     TST45 ;THAT'S NOT PRESENT
;EXIT TO THE NXT TST
5164
5165 016004 012710 000015        2$:   MOV    #15,@R0 ;DRIVE RESET, ON A NX DRIVE
5166 016010 104417 000106        DELAY ,106 ;TIME DELAY, 525 US ON 11/20
;105 US ON 11/45
5167
5168 016014 105777 163310        TSTB  @RKER ;DID NXD BIT IN RKER SET?
5169 016020 001006                BNE    3$ ;YES, BRANCH
5170 016022 004737 021010        JSR    PC,GT2RG ;GET RKCS, RKER
5171 016026 012737 000200 001166  MOV    #200,$REG2 ;THIS BIT (NXD) IN RKER DID NOT SET
5172 016034 104105                ERROR  105 ;NXD BIT DID NOT SET ON TRYING
;TO PERFORM A FUNCTION ON A

```

```

5174 ;NON-EXISTENT DRIVE
5175 ;CHECK THAT THE JUMPER CARD CONTAINING
5176 ;JUMPERS FOR DRIVES PRESENT IS PROPERLY
5177 ;CONNECTED
5178 ;NOTE THAT ON RK11C IF A DRIVE
5179 ;IS OFFLINE BUT PHYSICALLY PRESENT
5180 ;((IE. DRY IS CLR FOR THAT DRIVE)
5181 ;& A FUNCTION IS INITIATED ON THAT
5182 ;DRIVE NXD WON'T SET, BUT U WILL
5183 ;GET ONLY A DRE,HE & ERR.
5184 016036 022710 140214 3S: CMP #140214,@R0 ;DID HE & ERR SET WHEN NXD SET?
5185 016042 001403 BEQ 4S ;YES BRANCH
5186 016044 004737 021010 JSR PC,GT2RG ;HE OR ERR BIT DID NOT SET
5187 016050 104106 ERROR 106 ;WHEN NXD WAS SIMULATED
5188 ;CLEAR NXD, HE, ERR BITS
5189 016052 104413 4S: CNT.RESET ;GO, DO CONTROL RESET
5190 ;THIS IS A CALL FOR THE 'CNTRL-
5191 ;RESET' ROUTINE. A CONTROL RESET IS
5192 ;ISSUED AND AFTER A CERTAIN TIME
5193 ;IF THE 'CNTRL RDY' DOES NOT SET
5194 ;AN ERROR IS REPORTED. NOTE THAT
5195 ;THE PC IN ERROR MESSAGE IS THE
5196 ;PC WHERE 'CNT.RESET' IS LOCATED.
5197 ;THIS IS A VERY BASIC ERR& IF IT
5198 ;OCCURS GO BACK TO TEST 10
5199 016054 004737 021358 JSR PC,CHKECLR ;CHECK IF 'NXD' BIT WAS CLEARED BY
5200 ;CON.RESET. IF NOT, RETURN HERE.
5201 016060 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5202 ;NXD BIT IN RKER
5203 016062 004737 021402 5S: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
5204 ;BY CON.RESET. IF NOT RETURN HERE.
5205 016066 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5206 ;HE OR ERR BIT IN RKCS
5207 016070 004737 021436 JSR PC,TSTRWS ;GO CHECK & WAIT FOR R/W/S RDY
5208 ;TO SET. IF SET SKIP ERROR
5209 016074 104016 ERROR 16 ;R/W/S SHOULD BE SET. IT'S
5210 ;NOT
5211 ;*****
5212 ;*TEST 45 SIMULATE & CHECK NXC ERROR
5213 ;*THIS TEST SIMULATES THE NON-EXISTENT CYLINDER ERROR & CHECKS
5214 ;*IF IT IS DETECTED BY THE NXC BIT OF RKER, HE & ERR BITS
5215 ;*DF RKCS. IT IS CHECKED IF THEY CAN BE CLEARED BY CONTROL
5216 ;*RESET
5217 ;*****
5218 TST45: SCOPE
5219 016076 000004 MOV RKCS,R0
5220 016100 013700 001332 2S: MOV #-5,COUNT ;ALLOW 'ERRDR 133' ONLY 5 TIMES
5221 016104 012737 177773 MOV DRIVAD,R2 ;GET ADRES OF DRIVE
5222 016112 013702 001350 BIS #14540,R2 ;SET BITS FOR CYL 313
5223 016116 052702 014540 MOV #3S,$LPERR ;SET RETURN ADRES FOR
5224 016122 012737 016130 001110 ;LUPING ON EROR (5W9)
5225 ;GO, DO CONTROL RESET
5226 016130 104413 3S: CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
5227 ;RESET' ROUTINE. A CONTROL RESET IS
5228 ;ISSUED AND AFTER A CERTAIN TIME
5229

```

```

5230 ;IF THE 'CNTRL RDY' DOES NOT SET
5231 ;AN ERROR IS REPORTED. NOTE THAT
5232 ;THE PC IN ERROR MESSAGE IS THE
5233 ;PC WHERE 'CNT.RESET' IS LOCATED.
5234 ;THIS IS A VERY BASIC ERR& IF IT
5235 ;OCCURS GO BACK TO TEST 10
5236 016132 004737 021436 JSR PC,TSTRWS ;GO CHECK & WAIT FOR R/W/S RDY
5237 ;TO SET. IF SET SKIP ERROR BELOW
5238 016136 104016 ERROR 16 ;R/W/S RDY IS NOT SET
5239 016140 104421 TST.SIN ;CHECK IF SIN IS SET. IF SET
5240 ;DO DRIVE RESET TO CLR IT
5241 016142 010277 163172 MOV R2,@RKDA ;ADRES DRIVE, NXC CYLINDER
5242 016146 012710 000011 MOV #11,@R0 ;SEEK, GO TO NXC CYL
5243 016152 104412 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5244 ;IF SO, SKIP THE EROR MESSAGE.
5245 016154 104021 ERROR 21 ;SEEK WAS TRIED TO A NON EXISTENT
5246 ;CYLINDER, NXC SHOULD HAVE OCCURED
5247 ;SETTING CNTRL RDY. BUT CNTRL RDY
5248 ;DID NOT SET.
5249 016156 032777 000100 163144 9S: BIT #100,@RKER ;DID NXC SET?
5250 016164 001020 BNE 4S ;YES, BRANCH
5251 016166 004737 021010 JSR PC,GT2RG ;GO GET RKCS, ER
5252 016172 017737 163142 001166 MOV @RKDA,$REG2 ;GET RKDA
5253 016200 104110 ERROR 110 ;NXC DID NOT SET WHEN SEEK
5254 ;WAS TRIED TO CYLINDER AS INDICATED
5255 ;IN RKDA
5256 016202 004737 021436 JSR PC,TSTRWS ;CHECK & WAIT FOR R/W/S RDY.
5257 ;IF SET SKIP ERROR
5258 016206 104016 ERROR 16 ;R/W/S SHOULD BE SET
5259 016210 104413 CNT.RESET ;GO DO CONTROL RESET
5260 016212 004737 021504 JSR PC,DRESET ;GO DO DRIVE RESET
5261 016216 104026 ERROR 26 ;NXC DID NOT SET AND DRIVE MAY
5262 ;HAVE TRIED TO DO A SEEK, AFTER
5263 ;WHICH R/W/S RDY DID NOT SET
5264 016220 005237 001362 INC COUNT ;ALLOW ONLY 5 MESSAGES FOR
5265 016224 001405 BEQ 5S ;ERROR 133
5266 016226 062702 000040 4S: ADD #40,R2 ;ADRES THE NXT CYL(IN NON-EXISTENT ZONE)
5267 016232 032702 017740 BIT #17740,R2 ;CHKD FOR ALL NXC'S?
5268 016236 001334 BNE 3S ;IF NOT, LUP BAK & CHK THE NXT NXC
5269
5270 016240 032710 140000 5S: BIT #140000,@R0 ;DID HE & ERR BIT SET WHEN NXC BIT SET?
5271 016244 001003 BNE 6S ;YES, BRANCH
5272 016246 004737 021010 JSR PC,GT2RG ;GET RKCS, ER
5273 016252 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET IN RKCS
5274 ;WHEN NXC ERROR WAS SIMULATED
5275 ;CLEAR HE, ERR, NXC BITS
5276 016254 104413 6S: CNT.RESET ;GO, DO CONTROL RESET
5277 ;THIS IS A CALL FOR THE 'CNTRL-
5278 ;RESET' ROUTINE. A CONTROL RESET IS
5279 ;ISSUED AND AFTER A CERTAIN TIME
5280 ;IF THE 'CNTRL RDY' DOES NOT SET
5281 ;AN ERROR IS REPORTED. NOTE THAT
5282 ;THE PC IN ERROR MESSAGE IS THE
5283 ;PC WHERE 'CNT.RESET' IS LOCATED.
5284 ;THIS IS A VERY BASIC ERR& IF IT
5285 ;OCCURS GO BACK TO TEST 10

```

```

5286 016256 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXC' BIT WAS CLEARED BY
5287 ;CON.RESET. IF NOT, RETURN HERE.
5288 016262 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5289 ;NXC BIT IN RKER.
5290 016264 032710 140000 7$: BIT #140000,@R0 ;DID HE & ERR BITS GET CLEARED?
5291 016270 001405 BEQ TST46 ;:YES, EXIT
5292 016272 010037 001162 MOV R0,$REG0 ;GET ADRES OF RKCS
5293 016276 011037 001164 MOV @R0,$REG1 ;GET RKCS CONTENTS
5294 016302 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5295 ;HE OR ERR BIT IN RKCS
5296
;*****
;*TEST 46 SIMULATE & CHECK NXS ERROR
5298 ;*THIS TEST SIMULATES NON-EXISTENT SECTOR ERROR & CHECKS THAT
5299 ;*IT IS DETECTED BY NXS BIT OF RKER. IT IS CHECKED THAT
5300 ;*WHEN NXS SETS HE & ERR OF RKER ALSO SETS, AND ALL THREE
5301 ;*CAN BE CLEARED BY CONTROL RESET.
5302
;*****
5303 TST46: SCOPE
5304 016304 000004 CNT.RESET ;GO, DO CONTROL RESET
5305 016506 104413 ;THIS IS A CALL FOR THE 'CNTRL-
5306 ;RESET' ROUTINE. A CONTROL RESET IS
5307 ;ISSUED AND AFTER A CERTAIN TIME
5308 ;IF THE 'CNTRL RDY' DOES NOT SET
5309 ;AN ERROR IS REPORTED. NOTE THAT
5310 ;THE PC IN ERROR MESSAGE IS THE
5311 ;PC WHERE 'CNT.RESET' IS LOCATED.
5312 ;THIS IS A VERY BASIC ERR& IF IT
5313 ;OCCURS GO BACK TO TEST 10
5314
5315 016310 013700 001332 MOV RKCS,R0 ;GET ADRES OF DRIVE
5316 016314 013777 001350 163016 MOV DRIVAD,@RKDA ;SET BITS FOR SECTOR 12 (DECIMAL)
5317 016322 052777 000014 163010 BIS #14,@RKDA ;READ 1 WORD
5318 016330 012777 177777 162776 MOV #-1,@RKWC ;INTO THIS BUS ADRES
5319 016336 012777 033342 162772 MOV #OUTBUF,@RKBA ;READ, GO (FROM NX SECTOR)
5320 016344 012710 000005 MOV #5,@R0 ;THIS IS A CALL FOR 'CN.RDY'
5321 016350 104414 CNT.RDY ;ROUTINE WHICH WAITS FOR CNT
5322 ;RDY TO SET. IF CNTRL RDY DOES
5323 ;NOT SET WITHIN 883 MS/ 11-20
5324 ;(176 MS FOR 11-45 WITH BIPOLAR)
5325 ;AN ERROR IS REPORTED
5326 ;NXS ERROR SHOULD OCCUR NOW
5327
5328 016352 017702 162752 MOV @RKER,R2 ;DID NXS BIT SET IN RKER?
5329 016356 032702 000040 BIT #40,R2 ;YES, BRANCH
5330 016362 001006 BNE 1$
5331 016364 004737 021010 JSR PC,GT2RG ;GO GET RKCS, RKER
5332 016370 012737 000040 001166 MOV #40,$REG2 ;THIS BIT (NXS) IN RKER DID NOT SET
5333 016376 104105 ERROR 105 ;NXS BIT DID NOT SET ON SIMULATING
5334 ;NXS ERROR
5335 016400 042702 000040 1$: BIC #40,R2 ;MASK NXS BIT
5336 016404 001407 BEQ 2$ ;CHECK IF ANY OTHER
5337 ;RKER BIT SET
5338 016406 012737 000040 001167 MOV #40,$REG0 ;GET EXPCTD RKER
5339 016414 017737 162710 001164 MOV @RKER,$REG1 ;GET RKER RECVD
5340 016422 104107 ERROR 107 ;ONLY 'NXS' SHOULD BE SET
5341 ;IN RKER, ANOTHER RKER BIT

```

```

5342 ;WAS SET. (NOTE 'NXS' WAS
5343 ;SIMULATED)
5344 016424 022710 140204 2$: CMP #140204,@R0 ;DID HE & ERR BITS SET?
5345 016430 001403 BEQ 3$ ;YES, BRANCH
5346 016432 004737 021010 JSR PC,GT2RG ;GO GET RKCS, RKER
5347 016436 104106 ERROR 106 ;HE OR ERR BIT DID NOT SET WHEN
5348 ;NXS ERROR OCCURED
5349 ;CLEAR NXS, HE, ERR BITS
5350 016440 104413 3$: CNT.RESET ;GO, DO CONTROL RESET
5351 ;THIS IS A CALL FOR THE 'CNTRL-
5352 ;RESET' ROUTINE. A CONTROL RESET IS
5353 ;ISSUED AND AFTER A CERTAIN TIME
5354 ;IF THE 'CNTRL RDY' DOES NOT SET
5355 ;AN ERROR IS REPORTED. NOTE THAT
5356 ;THE PC IN ERROR MESSAGE IS THE
5357 ;PC WHERE 'CNT.RESET' IS LOCATED.
5358 ;THIS IS A VERY BASIC ERR& IF IT
5359 ;OCCURS GO BACK TO TEST 10
5360 016442 004737 021356 JSR PC,CHKECLR ;CHECK IF 'NXS' BIT WAS CLEARED BY
5361 ;CON.RESET. IF NOT, RETURN HERE.
5362 016446 104102 ERROR 102 ;CNTRL RESET DID NOT CLEAR
5363 ;NXS BIT IN RKER
5364 016450 004737 021402 4$: JSR PC,CHKCCLR ;CHECK IF 'HE' & 'ERR' BITS WERE CLEARED
5365 ;BY CON.RESET. IF NOT, RETURN HERE.
5366 016454 104102 ERROR 102 ;RKCS BITS ERR OR HE WERE NOT
5367 ;CLEARED BY CNTRL RESET
5368
;*****
;*TEST 47 SIMULATE & CHECK WCE
5370 ;*THIS TEST SIMULATES A WRITE CHECK ERROR AND CHECKS THAT IT
5371 ;*IS DETECTED BY WCE BIT OF RKER. FOR COMPARISON IT USES
5372 ;*THE 256 WORDS DATA BLOCK WRITTEN ON SECTOR 0, CYLINDER 0
5373 ;*IN A PREVIOUS TEST. THIS BLOCK IS COMPARED WITH THE 256 WORDS
5374 ;*MEMORY BUFFER STARTING AT 'OUTBUF'. WCE IS SIMULATED BY
5375 ;*DROPPING A BIT FROM ONE OF THE WORDS IN THE MEMORY BUFFER.
5376
;*****
5377 TST47: SCOPE
5378 016456 000004 MOV RKCS,R0 ;GO, DO CONTROL RESET
5379 016460 013700 001332 CNT.RESET ;THIS IS A CALL FOR THE 'CNTRL-
5380 016464 104413 ;RESET' ROUTINE. A CONTROL RESET IS
5381 ;ISSUED AND AFTER A CERTAIN TIME
5382 ;IF THE 'CNTRL RDY' DOES NOT SET
5383 ;AN ERROR IS REPORTED. NOTE THAT
5384 ;THE PC IN ERROR MESSAGE IS THE
5385 ;PC WHERE 'CNT.RESET' IS LOCATED.
5386 ;THIS IS A VERY BASIC ERR& IF IT
5387 ;OCCURS GO BACK TO TEST 10
5388 ;CHECK IF SIN IS SET, IF
5389 ;SET DO DRV-RESET TO CLR IT
5390 016466 104421 TST.SIN ;THIS CODE SETS UP A MEMORY
5391 ;BUFFER OF 256 WORDS STARTING
5392 016470 012701 033342 MOV #OUTBUF,R1 ;AT OUTBUF
5393 016474 012702 177400 MOV #-400,R2 ;FIRST WORD 177400
5394 016500 012703 177777 MOV #177777,R3 ;SECOND 177001
5395
5396
5397 016504 062703 177401 1$: ADD #177401,R3

```

```

5398 016510 010321      MOV    R3,(R1)+      ;LAST WORD 000377
5399 016512 005202      INC    R2             ;HAVE U GENERATED ALL 256 WORDS?
5400 016514 001373      BNE   1$             ;IF NOT, LUP BAK & GENERATE NXT
5401
5402 016516 012737 170007 033360  MOV    #170007,OUTBUF+16 ;WCE WILL B SIMULATED BY DROPPING A
5403                                     ;BIT IN THE EIGHTH WORD WHICH IS
5404                                     ;SUPPOSED TO B 174007
5405 016524 012777 177400 162602  MOV    #-400,@RKWC    ;WRT CHK 400 WORDS
5406 016532 012777 033342 162576  MOV    #OUTBUF,@RKBA  ;STARTING AT THIS BUS ADRES
5407 016540 013777 001350 162572  MOV    DRIVAD,@RKDA   ;WITH THIS DISK ADRES, SEC 0, CYL 0
5408 016546 012710 000007      MOV    #7,@RO        ;WRT CHK, GO
5409
5410 016552 104412      CHKCRDY              ;GO CHECK IF CONTROL RDY IS SET
5411                                     ;IF SO, SKIP THE EROR MESSAGE.
5412 016554 104065      ERROR 65            ;CNTRL RDY DID NOT SET
5413                                     ;AFTER WRT CHK
5414 016556 032777 000001 162544 3$: BIT    #1,@RKER      ;DID WCE BIT SET?
5415 016564 001006      BNE   4$             ;GO, GET RKCS, RKER
5416 016566 004737 021010      JSR   PC,GT2RG       ;THIS BIT (WCE) DID NOT SET
5417 016572 012737 000001 001166  MOV    #1,$REG2      ;WCE DID NOT SET ON SIMULATING
5418 016600 104105      ERROR 105           ;WCE CONDITIONS
5419                                     ;IS RKCS CORRECT?
5420 016602 022710 100206      4$:  CMP    #100206,@RO ;YES, BRANCH
5421 016606 001403      BEQ   5$             ;GO, GET RKCS, RKER
5422 016610 004737 021010      JSR   PC,GT2RG       ;HE OR ER BIT DID NOT SET WHEN
5423 016614 104106      ERROR 106           ;WCE WAS SIMULATED
5424                                     ;CNTRL RESET.
5425 016616 104413      5$:  CNT.RESET
5426 016620 004737 021356      JSR   PC,CHKECLR     ;WAS 'WCE' BIT CLEARED?
5427                                     ;IF NOT, RETURN HERE.
5428 016624 104102      ERROR 102           ;CNTRL RESET DID NOT CLEAR
5429                                     ;WCE BIT IN RKER
5430 016626 004737 021402      6$:  JSR   PC,CHKCCLR   ;CHECK IF 'ERR' BIT WAS CLEARED. IF
5431                                     ;NOT RETURN HERE.
5432 016632 104102      ERROR 102           ;CNTRL RESET DID NOT CLEAR
5433                                     ;RKCS

```

```

;*****
;*TEST 50 CHECK THAT SSE STOPS ALL CONTROL ACTION ON SOFT ERROR
;THIS TEST CHECKS THAT WHEN 'STOP ON SOFT ERROR' BIT IS SET IN
;RKCS AND A SOFT ERROR IS ENCOUNTERED ALL CONTROL ACTION WILL
;STOP AT THE END OF THE CURRENT SECTOR IF IDE BIT IS CLEAR.
;SOFT ERROR IS SIMULATED BY A WCE AS IN THE PREVIOUS
;TEST. THE PREVIOUS TEST & THE TEST WHICH WRITES DATA
;BLOCK ON CYLINDER 0, SECTOR 0, SHOULD BE DONE PRIOR
;TO THIS TEST. A TWO SECTOR 'WRT CHK' WILL BE DONE, IF
;CONTROL ACTION SHOULD STOP AFTER THE FIRST SECTOR DURING
;WHICH A SOFT ERROR IS SIMULATED.
;*****

```

```

5444 TST50: SCOPE
5445 CNT.RESET ;GO, DO CONTROL RESET
5446 ;THIS IS A CALL FOR THE 'CNTRL-
5447 ;RESET' ROUTINE. A CONTROL RESET IS
5448 ;ISSUED AND AFTER A CERTAIN TIME
5449 ;IF THE 'CNTRL RDY' DOES NOT SET
5450 ;AN ERROR IS REPORTED. NOTE THAT
5451
5452
5453

```

```

5454 ;THE PC IN ERROR MESSAGE IS THE
5455 ;PC WHERE 'CNT.RESET' IS LOCATED.
5456 ;THIS IS A VERY BASIC ERR# IF IT
5457 ;OCCURS GO BACK TO TEST 10
5458 ;CHECK IF SIN IS SET, CLR
5459 ;SET DO DRIVE RESET TO CLR IT
5460 016640 104421      TST.SIN
5461 016642 013700 001332      MOV    RKCS,R0
5462 016646 012737 170007 033360  MOV    #170007,OUTBUF+16 ;WCE IS SIMULATED BY DROPPING A BIT
5463                                     ;IN THE EIGHTH WORD (WHICH IS ACTUALLY
5464                                     ;174007). NOTE THAT 256 WORD MEMORY
5465                                     ;BUFFER IS CREATED IN THE PREVIOUS TEST.
5466 016654 013701 001350      MOV    DRIVAD,R1
5467 016660 012777 177000 162446  MOV    #-1000,@RKWC  ;WRT CHK 1000 (OCTAL) WORDS, 2 SECTORS
5468 016666 012777 033342 162442  MOV    #OUTBUF,@RKBA ;FROM THIS BUS ADRES
5469 016674 010177 162440      MOV    R1,@RKDA     ;WITH THIS DISK ADRES, SEC 0, CYL 0
5470 016700 012710 000407      MOV    #407,@RO     ;WRT CHK, GO, SSE
5471 016704 104412      CHKCRDY              ;GO CHECK IF CONTROL RDY IS SET
5472 016706 104065      ERROR 65            ;IF SO, SKIP THE EROR MESSAGE.
5473                                     ;CNTRL RDY DID NOT SET AFTER WRT
5474                                     ;CHK. A SOFT ERROR (WCE) IN
5475                                     ;SECTOR 0 SHOULD HAVE STOPPED
5476 016710 022777 000001 162412 2$: CMP    #1,@RKER      ;ALL CONTROL ACTION.
5477                                     ;CHECK ONLY 'WCE' BIT SHOULD
5478 016716 001407      BEQ   3$             ;BE SET?
5479 016720 012737 000001 001162  BEQ   3$             ;YES, BRANCH
5480 016726 017737 162376 001164  MOV    @RKER,$REG1  ;GET EXPCTD RKER
5481 016734 104107      ERROR 107           ;GET RKER RECVD
5482                                     ;ONLY BIT 'WCE' OF RKER
5483                                     ;SHOULD BE SET (WCE WAS
5484                                     ;SIMULATED ABOVE). ERROR
5485 016736 005201      3$:  INC    R1             ;IF IT'S NOT
5486 016740 020177 162374      CMP    R1,@RKDA     ;CHECK THAT RKDA INCREMENTED BY
5487                                     ;1 SECTOR ONLY IMPLYING THAT
5488                                     ;CNTRL ACTION DID STOP AFTE..
5489                                     ;SOFT ERROR IN SECTOR 0
5490 016744 001406      BEQ   TST51         ;YES, EXIT
5491 016746 010137 001162      MOV    R1,$REG0     ;GET EXPCTD RKDA
5492 016752 017737 162362 001164  MOV    @RKDA,$REG1  ;GET RKDA RECVD
5493 016760 104070      ERROR 70            ;RKDA SHOULD HAVE INCRMNTD
5494                                     ;BY 1 SECTOR ONLY, IT DIDN'T.
5495                                     ;WCE WAS SIMULATED IN THE
5496                                     ;FIRST SECTOR & A WRT CHK
5497                                     ;OF 2 SECTORS WAS ISSUED.
5498                                     ;CONTROLLER SHOULD STOP AFTER
5499                                     ;DETECTING WCE IN THE FIRST
5500                                     ;SECTOR. HENCE RKDA SHOULD
5501                                     ;INCREMENT BY 1 SECTOR ONLY

```

```

;*****
;*TEST 51 CHECK THAT RK11 INTERRUPTS ON SOFT ERROR WHEN SSE & IDE ARE SET
;THIS TEST CHECKS WHEN SSE BIT IS SET WITH IDE SET AND A SOFT
;ERROR OCCURS, THEN ALL CONTROL ACTION WILL STOP AND A BUS
;REQUEST (INTERRUPT) WILL OCCUR AT THE END OF THE CURRENT
;SECTOR. SOFT ERROR IS SIMULATED BY WCE AS IN PREVIOUS
;TEST. PREREQUISITES FOR THIS TEST ARE THE SAME AS THOSE
;*****

```

```

; *FOR THE PREVIOUS TEST.
;*****
TST51: SCOPE
CNT.RESET ;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;CHECK IF SIN IS SET, IF
;SET DO DRIVE RESET TO CLR IT
;WCE IS SIMULATED BY DROPPING A BIT
;IN THE EIGHTH WORD (WHICH IS 174007)
;NOTE THAT THE 256 WORD MEMORY
;BUFFER (STARTING AT OUTBUF) IS
;CREATED IN A PREVIOUS TEST.

5510
5511
5512 016762 000004
5513 016764 104413
5514
5515
5516
5517
5518
5519
5520
5521
5522
5523 016766 104421
5524
5525 016770 012737 170007 033360
5526
5527
5528
5529
5530 016776 013701 001350
5531 017002 012777 177000 162324
5532 017010 012777 033342 162320
5533 017016 010177 162316
5534 017022 013700 001402
5535 017026 012720 017060
5536 017032 012710 000340
5537 017036 012777 000507 162266
5538 017044 104420 177777
5539
5540
5541 017050 004737 021010
5542 017054 104111
5543
5544 017056 000417
5545
5546 017060 022626
5547 017062 022626
5548 017064 012777 004600 162310
5549
5550 017072 005201
5551 017074 020177 162240
5552
5553
5554 017100 001406
5555 017102 010137 001162
5556 017106 017737 162226 001164
5557 017114 104003
5558
5559
5560
5561 017116
5562 017116 012746 000340
5563 017122 012746 017130
5564 017126 000002
5565 017130

TST.SIN
MOV #170007,OUTBUF+16
DRIVAD,R1
MOV #-1000,@RKWC
MOV #OUTBUF,@RKBA
MOV R1,@RKDA
MOV RKVEC,R0
MOV #1$, (R0)+
MOV #340,@R0
MOV #507,@RKCS
WAT.INT,177777

JRSR PC,GT2RG
ERROR 111
BR 2$

1$: CMP (SP)+,(SP)+
CMP (SP)+,(SP)+
MOV #BADINT,@RKVEC
INC R1
CMP R1,@RKDA
BEQ 2$
MOV R1,$REG0
MOV @RKDA,$REG1
ERROR 3

2$: MOV #340,-(SP)
MOV #64$,-(SP)
RTI

64$:

```

```

5566 017130 005077 162176
5567
5568
5569
5570
5571
5572
5573
5574
5575
5576
5577
5578 017134 000004
5579 017136 013700 001332
5580 017142 012701 177774
5581 017146 005002
5582 017150 012737 017156 001110
5583
5584 017156 104417 000142
5585 017162 004737 021436
5586 017166 104016
5587 017170 104413
5588
5589
5590
5591
5592
5593
5594
5595
5596
5597 017172 010210
5598 017174 012777 177777 162132
5599 017202 013777 001350 162130
5600 017210 012777 177776 162120
5601
5602 017216 052710 000007
5603
5604
5605
5606 017222 104412
5607
5608 017224 104065
5609 017226 010205
5610 017230 062705 000020
5611 017234 042705 000100
5612 017240 011004
5613 017242 042704 177717
5614 017246 020504
5615 017250 001405
5616 017252 010537 001162
5617 017256 010437 001164
5618 017262 104112
5619
5620
5621

CLR @RKCS ;CLEAR THE IDE BIT

;*****
; *TEST 52 CHECK THE MEX BITS IN RKCS
; *THIS TEST CHECKS OUT THE EXTENDED MEMORY BITS OF THE RKCS.
; *THE RKBA IS SET TO 177776 AND A ONE WORD WRITE CHECK IS TRIED.
; *THIS COULD GIVE RISE TO NXM ERROR, BUT EVEN THEN THE RKBA
; *SHOULD OVERFLOW INTO THE MEX BITS. SIMILARLY IT IS CHECKED
; *THAT THE OVERFLOWING BIT CAN MAKE THE MEX BITS COUNT
; *01,10,11,00.
;*****
TST52: SCOPE
MOV RKCS,R0
MOV #-4,R1
CLR R2
MOV #1$,$LPERR
;SET UP THE COUNT
;INITIALIZE MEX BITS TO B SET IN RKCS
;SET RETURN ADRES FOR
;LUPING ON EROR (SW9)
;TIME DELAY
1$: DELAY ,142
JRSR PC,TSTRWS
ERROR 16
CNT.RESET
;WAIT FOR R/W/S RDY
;R/W/S RDY IS NOT SET
;GO, DO CONTROL RESET
;THIS IS A CALL FOR THE 'CNTRL-
;RESET' ROUTINE. A CONTROL RESET IS
;ISSUED AND AFTER A CERTAIN TIME
;IF THE 'CNTRL RDY' DOES NOT SET
;AN ERROR IS REPORTED. NOTE THAT
;THE PC IN ERROR MESSAGE IS THE
;PC WHERE 'CNT.RESET' IS LOCATED.
;THIS IS A VERY BASIC ERR& IF IT
;OCCURS GO BACK TO TEST 10
;SET MEX BITS (AS IN R2) IN RKCS
;WRT CHK 1 WORD
;THIS DISK ADRES, SEC 0, CYL 0
;THIS BUS ADRES. NOTE THIS BA
;IN CONJUNCTION WITH MEX BITS OF RKCS
;WRT CHK, GO
;THERE MAY BE A NXM OR WCE BUT
;WHATEVER THE CASE RKBA SHOULD
;OVERFLOW MAKING THE MEX BITS COUNT
;GO CHECK IF CONTROL RDY IS SET
;IF SO, SKIP THE ERROR MESSAGE.
;CNTRL RDY DID NOT SET AFTER WRT CHK
3$: ERROR 65
MOV R2,R5
ADD #20,R5
BIC #100,R5
MOV @R0,R4
BIC #177717,R4
CMP R5,R4
BEQ 4$
MOV R5,$REG0
MOV R4,$REG1
ERROR 112
;MEX BITS SHOULD INCREMENT BY 1 TO THIS
;MASK OUT IDE BIT POSITION, IF SET
;GET RKCS
;MASK OUT ALL BITS EXCEPT MEX
;DID MEX BITS INCREMENT CORRECTLY?
;YES. BRANCH
;GET EXPTD MEX BITS
;GET MEX BITS RECVD
;MEX BITS DID NOT INCREMENT AS
;'EXPTD' WHEN RKBA OVERFLOWED.
;NOTE THAT BIT POSITION 4 & 5
;REFLECT MEX BITS 0 & 1 IN THE

```

```

5622
5623 017264 017703 162040 4S: MOV @RKER,R3 ;ERROR MESSAGE.
5624 017270 010305 MOV R3,R5 ;GET RKER
5625 017272 042703 003001 BIC #3001,R3 ;MASK WCE,DLT,NXM BIT, IF SET
5626 017276 001410 BIC 5S ;BRANCH IF REST OF RKER CLR
5627 017300 042705 177776 BIC #177776,R5 ;MASK NON-WCE BITS
5628 017304 010537 001162 MOV R5,$REG0 ;THIS IS THE EXPCTD RKER
5629 017310 017737 162014 001164 MOV @RKER,$REG1 ;GET RKER RECVD
5630 017316 104107 ERROR 107 ;ERROR IN RKER. IT SHOULD
5631 ;BE AS EXPECTED IN
5632 ;ERROR MESSAGE
5633 017320 062702 000020 5S: ADD #20,R2 ;INCREMENT TO NXT MEX BIT
5634 017324 005201 INC R1 ;HAVE U CHKD THE MEX BITS 4 TIMES?
5635 017326 001313 BNE 1S ;IF NOT, LUP BACK
5636
5637 ;*****
5638 ;*TEST 53 TRANSFER FROM DISK TO TTY
5639 ;* THIS TEST CHECKS THE HIGH ORDER BITS OF THE ADDRESS
5640 ;* LINES. FIRST A ONE WORD (100) IS WRITTEN ON SECTOR,
5641 ;* 2. CYL 0. THEN IT IS READ BACK, BUT THE NPR IS DONE
5642 ;* NOT TO THE MEMORY, BUT THE TELETYPE BUFFER (TKS 177560)
5643 ;* AND IT CHECKED THAT THE WORD WAS RECIEVED CDRRECTLY.
5644 ;* IF IT IS NOT, AN ERROR IS REPORTED. THIS TEST IS
5645 ;* SKIPPED ON AN 11/05.
5646 ;*****
5647 017330 000004 TST53: SCOPE
5648 017332 012737 000001 001206 MOV #1,$TIMES ;DO 1 ITERATION
5649 ;THIS CODE FINDS OUT IF THE CPU
5650 ;IS AN 11/05 OR ELSE.
5651 ;ON AN 11/05, R0 (177700) CAN BE
5652 ;ADDRESSED AS A MEMORY LOCATION, BUT
5653 ;ON ANY OTHER CPU IF 177700 IS REFERENCED
5654 ;A TIME OUT WILL OCCUR.
5655 017340 012737 017362 000004 MOV #5S,@#4 ;SET UP TIME OUT VECTOR
5656 017345 005737 177700 TST @#177700 ;REFERENCE R0
5657 017352 012737 004534 000004 MOV #BADTMD,@#4 ;R0 WAS REFERENCED W/O TIMEOUT
5658 ;HENCE 11/05
5659 017360 000520 BR TST54 ;SKIP THIS TEST
5660 017362 022626 5S: CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
5661 017364 012737 004534 000004 MOV #BADTMD,@#4 ;RESTORE TIMEOUT VECTOR
5662 017372 012746 000340 MOV #340,-(SP)
5663 017376 012746 017404 MOV #64S,-(SP)
5664 017402 000002 RTI
5665 017404
5666 017404 013700 001332 64S: MOV RKCS,R0
5667 017410 104413 CNT.RESET ;GO, DO CONTROL RESET
5668 ;THIS IS A CALL FOR THE 'CNTRL-
5669 ;RESET' ROUTINE. A CONTROL RESET IS
5670 ;ISSUED AND AFTER A CERTAIN TIME
5671 ;IF THE 'CNTRL RDY' DOES NOT SET
5672 ;AN ERROR IS REPORTED. NOTE THAT
5673 ;THE PC IN ERROR MESSAGE IS THE
5674 ;PC WHERE 'CNT.RESET' IS LOCATED.
5675 ;THIS IS A VERY BASIC ERR& IF IT
5676 ;OCCURS GO BACK TO TEST 10
5677 017412 012701 033342 MOV #OUTBUF,R1

```

```

5678 017416 013704 001336 MOV RKBA,R4
5679 017422 012711 000100 MOV #100,@R1 ;WRITE THIS WORD
5680 017426 012777 177777 161700 MOV #-1,@RKWC ;WRITE 1 WORD
5681 017434 013702 001350 MOV DRIVAD,R2
5682 017440 052702 000002 BIC #2,R2 ;ON CYL 0, SEC 2
5683 017444 010277 161670 MOV R2,@RKDA
5684 017450 010114 MOV R1,@R4 ;FROM THIS MEMORY LOC
5685 017452 012710 000003 MOV #3,@R0 ;WRITE, GO
5686 017456 005003 CLR R3
5687 017460 105710 1S: TSTB @R0
5688 017462 100410 BMI 2S
5689 017464 005203 INC R3
5690 017466 001374 BNE 1S
5691 017470 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS
5692 017474 010237 001202 MOV R2,$REG10 ;GET THE STARTING ADRES
5693 017500 104416 BRKDA4 ;BREAK IT INTO DRV #, CYL, SUR, SEC #
5694 017502 104031 ERROR 31 ;CNTRL RDY DID NOT SET AFTER
5695 ;WRITE OF 1 WORD ON CYL 0, SEC 2
5696 017504 012777 177777 161622 2S: MOV #-1,@RKWC ;READ 1 WORD
5697 017512 010277 161622 MOV R2,@RKDA ;FROM SEC 2, CYL 0
5698 017516 013714 001144 MOV STKS,@R4 ;INTO TTY STAU REGISTER
5699 017522 005077 161416 CLR @STKS ;CLEAR TTY KEY BRD STATUS REG
5700
5701 017526 012710 000065 MOV #6S,@R0 ;READ, MEX BITS SET
5702 017532 005003 CLR R3
5703 017534 105710 3S: TSTB @R0
5704 017536 100410 BMI 4S
5705 017540 005203 INC R3
5706 017542 001374 BNE 3S
5707 017544 004737 020774 JSR PC,GT4RG ;GET THE STARTING ADRES
5708 017550 010237 001202 MOV R2,$REG10 ;BREAK IT INTO DR#, CYL, SUR, SEC#
5709 017554 104416 BRKDA4 ;CNTRL RDY DIDN'T SET AFTER
5710 017556 104045 ERROR 45 ;READ OF 1 WORD FROM CYL 0, SEC 2.
5711 ;IN EROR MSGE, <DSK-ADRES> GIVES
5712 ;ADRES WHERE READ BEGAN. 'RKDA'
5713 ;GIVES CONTENTS OF RKDA AT TIME OF EROR
5714 ;WAS THE CORRECT WORD READ INTO
5715 017560 032737 000100 001144 4S: BIT #100,STKS ;THE TTY STATUS REGISTER?
5716 ;YES, EXIT
5717 017566 001015 BNE TST54 ;GET THE WORD RECVD FROM DISK
5718 017570 017705 161350 MOV @STKS,R5
5719 017574 010537 001164 MOV R5,$REG1
5720 017600 052705 000100 BIC #100,RE ;THIS WORD WAS EXPCTD
5721 017604 010537 001162 MOV R5,$REG0 ;STORE EXPCTD WORD
5722 017610 011437 001166 MOV @R4,$REG2 ;GET RKBA
5723 017614 011037 001170 MOV @R0,$REG3 ;GET RKC
5724 017620 104115 ERROR 115 ;DATA ERROR, A ONE WORD (100)
5725 ;NPR WAS TRIED FROM DISK TO
5726 ;TTY KEYBOARD STATUS REGISTER
5727 ;(17756) . BIT 6 SHOULD HAVE BEEN
5728 ;SET AS RESULT OF THIS
5729 ;BUT IT WAS NOT
5730
5731 ;*****
5732 ;*TEST 54 CHECK THAT RKBA CAN COUNT CORRECTLY
5733

```

```

5734 ;*THIS TEST CHECKS THAT RKBA CAN COUNT CORRECTLY. IT IS SET
5735 ;*TO THE DESIRED INITIAL VALUE. THEN A ONE WORD WRITE CHECK
5736 ;*IS TRIED, WITH MEX (MEMORY EXTENSION) BITS SET. IF THERE IS
5737 ;*NO MEMORY PRESENT (FOR CERTAIN BUS ADDRESSES). THERE
5738 ;*WILL BE AN NXM ERROR STOPPING CONTROLLER ACTION. BUT RKBA
5739 ;*SHOULD HAVE INCREMENTED BY 1 FROM ITS INITIAL VALUE. IF IT
5740 ;*HAS NOT, AN ERROR IS REPORTED.
5741 ;*****
5742 TST54: SCOPE
5743 MOV #5,STIMES ;DO 5 ITERATIONS
5744 TST SIN ;CHECK IF SIN SET. IF SET DRV RESET
5745 CLR R1 ;INITIALIZE (VALUE OF RKBA)
5746 MOV #2,R2 ;INITIALIZE (INCMNTD VALUE OF RKBA)
5747
5748 MOV #1$, $LPERR ;SET RETURN ADRES FOR LUPING
5749 ;ON ERROR
5750
5751 MOV RKBA,R5
5752 JSR PC,TSTRWS ;WAIT FOR R/W/S RDY
5753 ERROR 16 ;R/W/S RDY IS NOT SET
5754 CNT.RESET ;DO CONTROL RESET
5755 MOV #-1,@RKWC ;WRITE CHK 1 WORD
5756 MOV R1,@R5 ;THIS BUS ADRES
5757 MOV DRIVAD,@RKDA ;SET DISK ADRES
5758 MOV #67,@RKCS ;WRITE CHECK, GO, MEX BITS SET
5759 CHKCRDY ;GO CHECK IF CONTROL RDY IS SET
5760 ;IF SO, SKIP THE EROR MESSAGE.
5761 ERROR 65 ;CNTRL RDY DID NOT SET AFTER
5762 ;WRT CHK WAS TRIED TO NXM LOC
5763 ;U MIGHT WANT TO USE TESTS
5764 ;CHECKING MEX BITS & NXM.
5765 INC INDX1 ;ALLOW ONLY 5 ERRORS OF ABOVE KIND
5766 BEQ 5$
5767
5768 CMP R2,@R5 ;DID RKBA INCREMENT BY 1 FROM
5769 ;ITS INITIAL VALUE?
5770 BEQ 4$ ;YES, BRANCH
5771 MOV R1,$REGO ;GET EXPCTD RKBA
5772 MOV @R5,$REG1 ;GET RKBA RECVD
5773 ERROR 17 ;RKBA DID NOT INCREMENT BY
5774 ;1 FROM ITS INITIAL VALUE.
5775 ;ONE WORD WRT CHK WAS TRIED
5776 ;TO A NXM LOCATION. THERE
5777 ;WILL BE AN NXM ERROR.
5778 ;BUT STILL RKBA SHOULD
5779 ;INCREMENT BY 1 FROM ITS
5780 ;INITIAL VALUE.
5781 INC INDX2 ;ALLOW ONLY 5 ERRORS OF
5782 BEQ 5$ ;THE ABOVE KIND
5783 ADD R2,R1 ;SET NXT VALUE OF RKBA
5784 MOV R1,R2
5785 ADD #2,R2 ;SET EXPCTD VALUE OF RKBA
5786 BNE 1$ ;ALL DONE?
5787
5788 MOV #1,$LPERR ;DUMMY EXIT POINT
5789

```

```

5790 ;*****
5791 ;*TEST 55 CHECK FOR RK-05F
5792 ;*THIS TEST CHECKS RK-05F TYPE DRIVES
5793 ;*TO INSURE THAT IF SEEKS ARE ISSUED ON ONE
5794 ;*DRIVE, THE OTHER DRIVE BECOMES BUSY
5795 ;*****
5796 TST55: SCOPE
5797 MOV #1,STIMES ;DO 1 ITERATION
5798 TST FFLAG ;SEE IF RK-05F
5799 BEQ 1$ ;NOT F
5800 JSR R5,FCHECK ;SEE IF OTHER GOES BUSY
5801 ERROR 120
5802
5803
5804 020004 1$:
5805 ;*****
5806 ;*TEST 56 END OF PROGRAM
5807 ;*THIS IS NOT A TEST, BUT A LINKAGE PROVIDED TO PERFORM
5808 ;*THE ABOVE SUB-TESTS FOR ALL DRIVES THAT ARE PRESENT.
5809 ;*NOTE THAT THE NEXT TEST- HARDWARE POLLING LOGIC-
5810 ;*IS DONE USING ALL THE DRIVES THAT ARE INDICATED PRESENT.
5811 ;*DO NOT LOOP ON THIS 'TEST'.
5812 ;*****
5813 TST56: SCOPE
5814 MOV #1,STIMES ;DO 1 ITERATION
5815 INC DRVDON ;INCREMENT THE COUNT FOR THE NUMBER
5816 ;OF DRIVES THAT ARE CHECKED
5817 JSR PC,DRESET ;RESET THE DRIVE
5818 ERROR 26 ;R/W/S DIDN'T SET AFTER DRIVE RESET
5819 BTEOP: CMP DRIVS,DRVDON ;HAVE U TESTED ALL THE DRIVES
5820 ;THAT ARE PRESENT?
5821 BEQ 1$ ;IF YES, EXIT
5822 ADD #20000,DRIVAD ;ADRES THE NXT POSSIBLE DRIVE
5823 JMP NUDRV ;GO BACK AND TEST THE NEXT
5824 ;DRIVE PRESENT
5825
5826 020050 005037 001112 1$: CLR SERTTL
5827
5828 ;*****
5829 ;*TEST 57 CHECK HARDWARE POLLING LOGIC
5830 ;*THIS TEST CHECKS THE HARDWARE POLL LOGIC, USING ALL THE DRIVES
5831 ;*PRESENT ON THE RK11. ATLEAST TWO DRIVES SHOULD BE PRESENT
5832 ;*TO DO A MEANINGFUL HARDWARE POLL. SEQUENCE OF OPERATIONS IS
5833 ;*AS FOLLOWING:
5834 ;*1) NUMBER OF DRIVES ON THE RK11 IS ASCERTAINED.
5835 ;*2) HAVING LOCKED OUT ALL INTERRUPTS (CPU PR 7). SEEK IS INITIATED
5836 ;*FOR ONE DRIVE AT A TIME, ONLY WHEN 'CNTRL RDY' IS SET.
5837 ;*3) CPU PRIORITY IS DROPPED TO 4 SO THAT RK11 CAN INTERRUPT, THE INCOMING
5838 ;*INTERRUPT IS PROCESSED TO CHECK IF IT WAS DUE TO 'SEEK DONE' BY
5839 ;*ONE OF THE DRIVES.
5840 ;*4) IF BY THE END OF THE SET TIME A DRIVE HAS NOT INTERRUPTED
5841 ;*AN ERROR MESSAGE IS GIVEN INDICATING WHICH DRIVE DID NOT
5842 ;*INTERRUPT AFTER SEEK WAS DONE.
5843 ;*****
5844 TST57: SCOPE
5845 020054 000004

```

```

5846 020056 012737 000005 001206 MOV #5,STIMES ;:DO 5 ITERATIONS
5847 020064 005237 001440 INC SIZYET ;:FOUNR RK05F YET?
5848 020070 001002 BNE 25$ ;YES
5849 020072 004737 025304 JSR PC,SIZEF ;:FIND WHICH ARE RK-05F
5850 020076 005037 001436 25$: CLR PHYDRV ;:NUMBER OF ACTUAL DRIVES
5851 020102 012700 001414 MOV #DRIVO,R0 ;:TABLE
5852 020106 005710 23$: TST (R0) ;:DRIVE HERE+?
5853 020110 001405 BEQ 22$ ;NO
5854 020112 005237 001436 INC PHYDRV ;:COUNT DRIVE
5855 020116 005710 TST (R0) ;:RK05F?
5856 020120 100001 BPL 22$ ;NO
5857 020122 005720 TST (R0)+ ;:DONT COUNT F TWICE
5858 020124 005720 22$: TST (R0)+ ;:NEXT DRIVE
5859 020126 020027 001433 CMP R0,#DRIV7+1 ;:ALL YET
5860 020132 002765 BLT 23$ ;NO
5861 020134 005037 001406 CLR ODDEVN ;:EVEN DRIVES FIRST IF F
5862 020140 005737 001412 TST DRIVS ;:ANY DRIVES PRESENT?
5863 020144 001002 BNE 20$ ;YES
5864 020146 000137 020652 JMP $EOP ;:NO
5865 020152 005237 001434 20$: INC T56FLG ;:FLAG TO INDICATE:
5866 020156 013700 001332 MOV RKCS,R0 ;:(INDX1)=0 POLLING DONE AFTER ALL
5867 020162 005037 001356 CLR INDX1 ;:DRIVES SEEK TO CYL 0
5868 ;:DRIVES SEEK TO CYL 0
5869 ;:(INDX1)=1 POLLING DONE AFTER ALL
5870 ;:DRIVES SEEK TO CYL 4
5871 15$: CLR INDX2 ;:FLAG INDICATING TYPE OF INTERRUPT
5872 020166 005037 001360 ;:SET TO NON-ZERO TO INDICATE
5873 ;:THAT THE INTERRUPT IS DUE TO
5874 ;:SEEK DONE
5875 ;:GO, DO CONTROL RESET
5876 020172 104413 CNT.RESET ;:THIS IS A CALL FOR THE 'CNTRL-
5877 ;:RESET' ROUTINE. A CONTROL RESET IS
5878 ;:ISSUED AND AFTER A CERTAIN TIME
5879 ;:IF THE 'CNTRL RDY' DOES NOT SET
5880 ;:AN ERROR IS REPORTED. NOTE THAT
5881 ;:THE PC IN ERROR MESSAGE IS THE
5882 ;:PC WHERE 'CNT.RESET' IS LOCATED.
5883 ;:THIS IS A VERY BASIC ERR& IF IT
5884 ;:OCCURS GO BACK TO TEST 10
5885 ;:PERFORMING SEEKS TO CYL 4
5886 020174 005737 001356 TST INDX1 ;:YES, BRANCH
5887 020200 001002 BNE .+6 ;NO
5888 020202 005002 CLR R2
5889 020204 000402 BR .+6
5890 020206 012702 000200 MOV #200,R2 ;:SET ADRES FOR FOURTH CYLINDER
5891 020212 012701 001414 MOV #DRIVO,R1 ;:INITIALIZE POINTER
5892 020216 012703 177770 MOV #-10,R3 ;:SET COUNT FOR 8 DRIVES
5893 020222 012705 033342 MOV #OUTBUF,R5 ;:INITIALIZE POINTER TO INDICATOR AREA
5894 020226 005025 CLR (R5)+ ;:CLEAR OUT THE 8-WORD INDICATOR
5895 020230 005203 INC R3 ;:AREA WHICH IS USED FOR DOING
5896 020232 001375 BNE .-4 ;:SOFTWARE POLLING LATER ON
5897 020234 012703 177770 MOV #-10,R3 ;:SET COUNT FOR 8 POSSIBLE DRIVES
5898 020240 012705 033342 MOV #OUTBUF,R5 ;:INITIALIZE POINTER TO INDICATOR AREA
5899 020244 1$: MOV #340,-(SP)
5900 020244 012746 000340 MOV #64$,-(SP)
5901 020250 012746 020256
    
```

```

5902 020254 000002 RTI
5903 020256 64$: BIT #BIT0,(R1) ;:IS THIS DRIVE PRESENT?
5904 020256 032711 000001 BEQ 4$ ;:IF NOT, BRANCH
5905 020262 001433 TST (R1) ;:RK06F?
5906 020264 005711 BPL 17$ ;:NO, CONTINUE
5907 020266 100012 BIT #BIT13,R2 ;:DRIVE EVEN?
5908 020270 032702 020000 BEQ 16$ ;:YES
5909 020274 001404 TST ODDEVN ;:DO WE WANT ODD?
5910 020276 005737 001406 TST BEQ 4$ ;:NO, SO DO NOT TEST
5911 020302 001423 BR 17$ ;:ADD THIS DRIVE TO LIST
5912 020304 000403 16$: TST ODDEVN ;:DO WE WANT EVEN?
5913 020306 005737 001406 BNE 4$ ;:NO, SO SKIP
5914 020312 001017 17$: MOV R2,(R5) ;:SET UP THIS WORD IN THE
5915 020314 010215 ;:INDICATOR AREA SHOWING THAT THIS
5916 ;:DRIVE (AS IN BITS 13-15 OF R2)
5917 ;:IS PRESENT
5918 ;:MASK OUT UNWANTED BITS (CYL.SUR,SEC BITS)
5919 020316 042725 017777 BIC #17777,(R5)+
5920 020322 005004 CLR R4
5921 020324 105710 2$: TSTB @R0 ;:IS CNTRL RDY SET?
5922 020326 100405 BMI 3$ ;:YES, BRANCH
5923 020330 005204 INC R4 ;:NO, WAIT FOR IT
5924 020332 001374 BNE 2$ ;:IF WAITED LONG REPORT ERROR
5925 020334 004737 020774 JSR PC,GT4RG ;:GO, GET RKCS,ER,DS,DA
5926 020340 104021 ERROR 21 ;:CNTRL RDY DID NOT SET AFTER ACCEPTING
5927 ;:ADRES FROM PREVIOUS SEEK
5928 020342 010277 160772 3$: MOV R2,@RKDA ;:ADRES THIS DRIVE, CYL 0 OR CYL 4
5929 ;:(WHICHEVER THE CASE MAY BE)
5930 020346 012710 000111 MOV #111,@R0 ;:SEEK.GO,IDE SET
5931 020352 005721 4$: TST (R1)+ ;:NEXT DRIVE DATA
5932 020354 062702 020000 ADD #20000,R2 ;:INCREMENT DRIVE ADRES (BITS 15,14,13)
5933 020360 005203 INC R3 ;:TO NEXT ONE
5934 020362 001330 BNE 1$ ;:BRANCH BACK IF ALL DRIVES ARE
5935 ;:NOT CHECKED TO SEE IF THE NEXT
5936 ;:DRIVE IS PRESENT (& IF SO ISSUE A
5937 ;:SEEK TO IT)
5938 ;:BY NOW SEEKS HAVE BEEN ISSUED
5939 ;:TO ALL DRIVES PRESENT & POLLING
5940 ;:HAS BEGUN
5941 020364 005004 CLR R4
5942 020366 013702 001402 5$: MOV RKVEC,R2
5943 020372 012722 020424 MOV #6$, (R2)+ ;:SET ADRES FOR RK11 TO INTERRUPT
5944 020376 012712 000340 MOV #340,(R2) ;:SET PSW ON INTERRUPT
5945 020402 013746 001400 MOV RKPRI,-(SP) ;:DROP CPU PRIORITY TO 4 SO THAT
5946 020406 012746 020414 MOV #18$,-(SP) ;:RK11 CAN INTERRUPT
5947 020412 000002 RTI
5948 020414 000240 18$: NOP ;:THIS IS A TIME LOOP DURING
5949 020416 005204 INC R4 ;:WHICH ALL DRIVES PRESENT SHOULD
5950 020420 001375 BNE 18$ ;:INTERRUPT
5951 020422 000452 BR 11$ ;:BRANCH AND CHECK IF ALL AVAILABLE
5952 ;:DRIVES INTERRUPTED CORRECTLY
5953 020424 022626 6$: CMP (SP)+,(SP)+ ;:RESTORE STACK POINTER
5954 020426 005737 001360 TST INDX2 ;:WAS THIS FIRST INTERRUPT
5955 ;:DUE TO 'ADRES ACK' AFTER INITIATION
5956 ;:OF SEEK?
5957 020432 001021 BNE 9$ ;:IF YES, CHECK THE FOLLOWING
    
```

```

5958
5959 020434 032710 020000          BIT      #20000,@R0      ;CHECK THAT SCP IS NOT SET
5960 020440 001403                    BEQ      7$              ;BRANCH IF SCP CLEAR
5961 020442 011037 001162          MOV      @R0,$REGO      ;GET RKCS
5962 020446 104076                    ERROR    7$              ;AFTER THE FIRST INTERRUPT WHICH
;IS DUE TO INITIATION OF SEEK, SCP
;SHOULD NOT HAVE SET. IT DID
5963
5964
5965 020450 017701 160652          7$: MOV   @RKDS,R1      ;RKDS BITS 15-13 SHOULD BE CLR
5966 020454 032701 160000          BIT      #160000,R1
5967 020460 001403                    BEQ      8$              ;GET RKDS
5968 020462 010137 001162          MOV      R1,$REGO
5969 020466 104050                    ERROR    50              ;SEEK, WITH IDE SET WAS ISSUED TO
;ALL AVAILABLE DRIVES. THE FIRST
;INTERUPT IS DUE TO SEEK INITIATED
;BY FRST DRV. DRV ID BITS 13-15
;SHOULD BE CLR AFTR THIS FRST INRUPT.
;THEY WERE NOT IF THIS ERROR OCCURS.
5970
5971
5972
5973
5974
5975 020470 005237 001360          8$: INC   INDX2          ;SET UP FLAG INDICATING
;THAT THE FIRST INTERRUPT DUE
;TO INITIATION OF SEEK WAS
;PROCESSED
5976
5977
5978
5979 020474 000734                    BR       5$              ;GO BACK TO THE WAIT LOOP & WAIT
;FOR NEXT INTERRUPT FROM RK11
5980
5981 020476 013703 001436          9$: MOV   PHYDRV,R3      ;SET COUNT OF # OF DRIVES PRESENT
5982 020502 012705 033342          MOV      #OUTBUF,R5      ;INITIALIZE POINTER
5983 020506 017701 160614          MOV      @RKDS,R1      ;GET RKDS
5984 020512 042701 017777          BIC      #17777,R1      ;MASK BITS 0-12
5985
5986
5987
5988
5989
5990
5991 020516 020125                    CMP      R1,(R5)+        ;BRANCH IF INTERRUPTING DRIVE WAS FOUND
5992 020520 001411                    BEQ      10$             ;HAVE U CHKD ALL DRVS PRESENT?
5993 020522 005303                    DEC      R3              ;IF NOT LUP BAK & CHK
5994 020524 001374                    BNE      -6              ;REPORT ERROR IF THE INTERRUPTING
;DRIVE # (AS IN RKDS 13-15) WAS NOT
;ANY ONE OF THOSE THAT ARE PRESENT
5995
5996
5997
5998 020526 010146                    MOV      R1,-(R6)        ;GET WORD TO B SHFTD RT
5999 020530 004737 021200          JSR      PC,SHFTRT      ;GO SHIFT IT
6000 020534 012637 001162          MOV      (R6)+,$REGO    ;THIS DRIVE # WAS RCVD IN RKDS AS
;THE INTERRUPTING DRIVE, BUT THIS
;DRIVE IS NOT PHYSICALLY PRESENT
;RKDS INDICATES AN INTERRUPTING
;DRIVE # (DURING H'WARE POLL) BUT
;THAT DRIVE IS ACTUALLY NOT PRESENT
6001
6002
6003 020540 104051                    ERROR    51              ;SET UP FLAG INDICATING THAT
;THE INTERRUPT FOR THIS DRIVE
;(AFTER IT HAD COMPLETED ITS SEEK)
;WAS PROCESSED
6004
6005
6006 020542 000401                    BR       10$+2          ;GO BAK & WAIT FOR FURTHER INTRUPTS
6007 020544 005245                    10$: INC  -(R5)         ;GET # OF DRIVES
;INITIALIZE POINTER
6008
6009
6010
6011 020546 000707                    BR       5$              ;GO BAK & WAIT FOR FURTHER INTRUPTS
6012 020550 013703 001436          11$: MOV  PHYDRV,R3      ;GET # OF DRIVES
6013 020554 012705 033342          MOV      #OUTBUF,R5      ;INITIALIZE POINTER

```

```

6014
6015 020560 105715                    14$: TSTB  (R5)          ;DID THIS DRIVE INTERRUPT?
6016 020562 001006                    BNE     13$             ;YES, BRANCH
6017 020564 011546                    MOV     (R5),-(R6)      ;GET THIS DRIVE #
6018 020566 004737 021200          JSR     PC,SHFTRT      ;SHIFT IT TO THE RIGHT
6019 020572 012637 001162          MOV     (R6)+,$REGO    ;THIS DRIVE # DID NOT INTERRUPT
;DURING H'WARE POLL
6020
6021 020576 104052                    ERROR    52              ;DRIVE # (AS IN $REGO) DID NOT
;INTERUPT DURING HARDWARE POLL
6022
6023 020600 062705 000002          13$: ADD   #2,R5         ;INCREMENT POINTER TO THE NEXT FLAG
6024 020604 005303                    DEC     R3              ;CHKD FOR ALL DRIVES?
6025 020606 001364                    BNE     14$             ;IF NOT LUP BACK
6026
6027 020610 005737 001356          TST     INDX1          ;DONE POLLING FOR SEEKS TO CYL 312?
6028 020614 001004                    BNE     TSTEND          ;IF YES, EXIT
6029 020616 005237 001356          INC     INDX1          ;IF NOT, INCREMENT FLAG
6030 020622 000137 020166          JMP     15$            ;GO DD IT
6031
6032
6033
6034
6035
6036
6037
6038
6039
6040
6041
6042
6043
6044
6045
6046
6047
6048
6049
6050
6051
6052
6053
6054
6055 020626 005237 001406          TSTEND: INC  ODDEVN      ;NOW ODD IF RK05F
6056 020632 022737 000002 001406  CMP     #2,ODDEVN      ;SEE IF DONE
6057 020640 001402                    BEQ     21$             ;ALL DONE
6058 020642 000137 020140          JMP     T5$            ;TEST AGAIN
6059 020646 005037 001434          21$: CLR   T56FLG
6060
6061
6062
6063
6064
6065
6066
6067
6068
6069

```

.SBTTL END OF PASS ROUTINE

```

;*****
;INCREMENT THE PASS NUMBER ($PASS)
;INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
;TYPE "END PASS #XXXXX" (WHERE XXXXX IS A DECIMAL NUMBER)
;IF THERES A MONITOR GO TO IT
;IF THERE ISN'T JUMP TO ST4

```

6070
6071 020552
6072 020652 000004
6073 020654 005037 001102
6074 020660 005037 001206
6075 020664 005237 001100
6076 020670 042737 100000 001100
6077 020576 005327
6078 020700 000001
6079 020702 003022
6080 020704 012737
6081 020705 000001
6082 020710 020700
6083 020712 104401 020757
6084 020716 013746 001100
6085 020722 104405
6086 020724 104401 020754
6087 020730 013700 000042
6088 020734 001405
6089 020736 000005
6090 020740 004710
6091 020742 000240
6092 020744 000240
6093 020746 000240
6094 020750
6095 020750 000137
6096 020752 004456
6097 020754 377 377 000
6098 020757 015 042412 042116
6099 020764 050040 051501 020123
6100 020772 000043
6101
6102
6103
6104
6105
6106
6107
6108
6109
6110
6111
6112
6113
6114
6115
6116
6117
6118
6119
6120
6121
6122
6123
6124
6125

SEOP:
SCOPE
CLR STSTNM ;;ZERO THE TEST NUMBER
CLR STIMES ;;ZERO THE NUMBER OF ITERATIONS
INC \$PASS ;;INCREMENT THE PASS NUMBER
BIC #100000,\$PASS ;;DON'T ALLOW A NEG. NUMBER
DEC (PC)+ ;;LOOP?
SEOPCT: .WORD 1
BGT \$DDAGN ;;YES
MOV (PC)+,@(PC)+ ;;RESTORE COUNTER
SENDCT: .WORD 1
SEOPCT
TYPE .SENDMG ;;TYPE "END PASS #"
MOV \$PASS,-(SP) ;;SAVE \$PASS FOR TYPEOUT
TYPDS ;;GO TYPE--DECIMAL ASCII WITH SIGN
TYPE .SENULL ;;TYPE A NULL CHARACTER
\$GET42: MOV @#42,R0 ;;GET MONITOR ADDRESS
BEQ \$DDAGN ;;BRANCH IF NO MONITOR
RESET ;;CLEAR THE WORLD
SENDAD: JSR PC,(R0) ;;GO TO MONITOR
NOP ;;SAVE ROOM
NOP ;;FOR
NOP ;;ACT11
\$DDAGN:
JMP @(PC)+ ;;RETURN
\$RTNAD: .WORD ST4
\$ENULL: .BYTE -1,-1,0 ;;NULL CHARACTER STRING
\$ENDMG: .ASCIZ <15><12>/END PASS #/

.SBTTL GT2RG: ROUTINE FOR GETTING RKCS,RKER
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER
;TO \$REG0, \$REG1 RESPECTIVELY BEFORE TYPING OUT AN ERROR MESSAGE.
;CALL: JSR PC,GT2RG
.SBTTL GT3RG: ROUTINE FOR GETTING RKCS, RKER, RKDS
;GT3RG
;SUBROUTINE FOR TRANSFERRING THE CONTENTS OF RKCS, RKER, RKDS
;TO \$REG0, \$REG1, \$REG2 RESPECTIVELY BEFORE TYPING OUT AN
;ERROR MESSAGE.
;CALL: JSR PC,GT3RG
.SBTTL GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA
;GT4RG
;SUBROUTINE FOR TRANSFERRING CONTENTS OF RKCS, RKER, RKDS

6126
6127
6128
6129
6130 020774 017737 160340 001170
6131 021002 017737 160320 001166
6132 021010 017737 160314 001164
6133 021016 017737 160310 001162
6134 021024 000207
6135
6136
6137
6138
6139
6140
6141
6142
6143
6144
6145
6146
6147
6148 021026
6149 021026 104401 021034
6150 021032 000406
6151
6152 021050
6153 021050 010346
6154 021052 104402
6155 021054 000207
6156
6157
6158
6159
6160
6161
6162
6163
6164
6165
6166
6167
6168
6169
6170
6171
6172
6173
6174
6175
6176
6177
6178
6179
6180 021056 010046
6181 021060 012700 001172

GT4RG: ROUTINE FOR GETTING RKCS, RKER, RKDS, RKDA
;RKDA TO \$REG0, \$REG1, \$REG2, \$REG3 RESPECTIVELY BEFORE
;TYPING OUT AN ERROR MESSAGE.
;CALL: JSR PC,GT4RG
GT4RG: MOV @RKDA,\$REG3 ;GET RKDA
GT3RG: MOV @RKDS,\$REG2 ;GET RKDS
GT2RG: MOV @RKER,\$REG1 ;GET RKER
MOV @RKCS,\$REG0
RTS PC
.SBTTL TYERM: SPECIAL ERROR MESSAGE ROUTINE
;TYERM
;THIS ROUTINE TYPES OUT 'EROR AT PC=X'
;X IS THE PC WHERE THE EXPLANATION AS TO WHAT HAPPENED IS GIVEN. THIS ROUTINE
;IS USED ONLY FOR NON-MANUAL MODE OF THE PROGRAM.
;CALL: JSR TYERM
TYERM:
TYPE .65\$;;TYPE ASCIZ STRING
BR 64\$;;GET OVER THE ASCIZ
;;65\$: .ASCIZ <15><12>/ERROR,PC=
64\$:
MOV R3,-(SP)
TYPDC
RTS PC
.SBTTL BDA0, BDA4: BREAK DISK ADDRESS INTO SEC, SUR, CYL, DRIVE
;BDA0, BDA4
;THIS ROUTINE BREAKS A DISK ADDRESS (BITS 0-15) INTO DRIVE #,
;CYLINDER #, SURFACE, SECTOR #. THE ROUTINE IS CALLED BY USING EITHER
;BRKDAO OR BRKDA4, BOTH BEING 'TRAP' INSTRUCTIONS WITH THEIR LOWER BYTES
;ENCODED TO PROVIDE INDEXING TO 'BDA0' OR 'BDA4'. BEFORE CALLING
;THE ROUTINE THE DISK ADDRESS WHICH IS TO BE BROKEN AS ABOVE
;IS DEPOSITED IN \$REG10.
;'BRKDAO' PUTS THE BRKDA4 PUTS THE
;DRIVE # INTO \$REG0 DRIVE # INTO \$REG4
;CYLINDER # INTO \$REG1 CYLINDER # INTO \$REG5
;SURFACE # INTO \$REG2 SURFACE # INTO \$REG6
;SECTOR # INTO \$REG3 SECTOR # INTO \$REG7
;CALL: BRKDAO BRKDA4
BDA0: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
MOV #\$REG3+2,R0 ;SET UP POINTER

```

6182 021064 000403 BR BDAR
6183
6184 021066 010046 BDA4: MOV R0,-(SP) ;PUSH R0 ONTO THE STACK
6185 021070 012700 001202 MOV #SREG7+2,R0 ;SET UP POINTER
6186
6187 021074 032777 020000 160036 BDAR: BIT #20000,@SWR ;INHIBIT TYPEOUT?
6188 021102 001034 BNE 2$ ;YES, BRANCH TO EXIT POINT
6189
6190 021104 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
6191 021106 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
6192 021110 013701 001202 MOV $RREG10,R1 ;GET THE ADDRESS WHICH
6193 ;HAS TO BE BROKEN
6194 021114 042701 177760 BIC #177760,R1 ;EXTRACT SECTOR BITS 0-3
6195 021120 010140 MOV R1,-(R0) ;MOVE SECTOR BITS TO $REG3 OR $REG7
6196 021122 013701 001202 MOV $RREG10,R1 ;GET THE DSK-ADRES TO BE BROKEN
6197 021126 006201 ASR R1 ;SHIFT RIGHT 4 TIMES
6198 021130 006201 ASR R1
6199 021132 006201 ASR R1
6200 021134 006201 ASR R1
6201 021136 010102 MOV R1,R2 ;STORE THIS
6202 021140 042702 177776 BIC #177776,R2 ;EXTRACT THE SURFACE BIT
6203 021144 010240 MOV R2,-(R0) ;MOVE SURFACE BIT TO $REG3 OR $REG6
6204 021146 006201 ASR R1
6205 021150 010102 MOV R1,R2 ;STORE IT
6206 021152 042702 177400 BIC #177400,R2 ;EXTRACT THE CYLINDER BITS
6207 021156 010240 MOV R2,-(R0) ;MOVE CYLINDER BITS TO $REG1 OR $REG5
6208 021160 000301 SWAB R1 ;SWAB HI-LO BYTES
6209 021162 042701 177770 BIC #177770,R1 ;EXTRACT THE DRIVE #
6210 021166 010140 MOV R1,-(R0) ;MOVE DRIVE # TO $REG0 OR $REG4
6211
6212 021170 012602 MOV (SP)+,R2 ;RESTORE R2
6213 021172 012601 MOV (SP)+,R1 ;RESTORE R1
6214 021174 012600 2$: MOV (SP)+,R0 ;RESTORE R0 FROM THE STACK
6215 021176 000002 RTI ;RETURN FROM INTERRUPT, EXIT THIS
6216 ;ROUTINE
6217
6218
6219
6220 .SBTTL SHFTRT: SHIFT RIGHT ROUTINE
6221
6222 ;SHFTRT
6223 ;THIS ROUTINE SHIFTS A WORD TO THE RIGHT 13 TIMES. THE WORD TO BE SHIFTED
6224 ;IS PUT ON THE STACK BEFORE ENTERING THIS ROUTINE AND IT IS POPPED UP
6225 ;FROM THE STACK AFTER THE SHIFT HAS BEEN DONE.
6226 ;CALL: JSR PC,SHFTRT
6227
6228 021200 012737 177763 021224 SHFTRT: MOV #-15,2$ ;SET UP A COUNT OF 13
6229 021206 000241 CLC ;CLEAR THE C BIT
6230 021210 006056 000002 1$: ROR 2(R6) ;ROTATE RIGHT THE WORD TO B SHFTD
6231 021214 005237 021224 INC 2$ ;SHIFTED 13 TIMES?
6232 021220 001373 BNE 1$ ;IF NOT LUP BAK & SHIFT
6233 021222 000207 RTS PC ;EXIT FROM THIS SUBROUTINE
6234 021224 000000 2$: 0
6235
6236
6237

```

```

6238
6239
6240
6241 .SBTTL CHKHE: CHECK FOR 'ERR'OR
6242 .SBTTL CHKHE1: CHECK FOR 'ERR'OR
6243
6244 ;;CHKHE
6245 ;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6246 ;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6247 ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6248 ;AT THE TIME OF ENTRY 'DRIVAD' CONTAINS THE DISK ADDRESS WHICH IS TO
6249 ;BE BROKEN DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION
6250 ;IS SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6251 ;RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6252
6253 ;CHKHE1
6254 ;THIS ROUTINE CHECKS IF 'HE' OR 'ERR' BITS IN RKCS ARE SET. IF ANY OF THE
6255 ;TWO BITS ARE SET, THE CONTENTS OF RKCS, ER, DS, AND DA ARE SAVED AND A
6256 ;RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
6257 ;AT THE TIME OF ENTRY 'R1' CONTAINS THE DISK ADDRESS WHICH IS TO BE BROKEN
6258 ;DOWN INTO DRIVE #, CYLINDER, SURFACE AND SECTOR #. THIS INFORMATION IS
6259 ;SAVED TO BE USED LATER FOR ERROR REPORTING. IF THE BITS ARE NOT SET,
6260 ;RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6261 021226 010137 001202 CHKHE1: MOV R1,$RREG10 ;SAVE THE DISK ADRES
6262 021232 000403 BR CHE1
6263
6264 021234 013737 001350 001202 CHKHE: MOV DRIVAD,$RREG10 ;SAVE THE DISK ADRES
6265 021242 032777 140000 160062 CHE1: BIT #140000,@RKCS ;IS 'HE' OR 'ERR' BIT SET?
6266 021250 001467 BEQ CRETRN ;NO
6267 021252 004737 020774 JSR PC,GT4RG ;GET RKCS, ER, DS, DA
6268 021256 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS 0
6269 ;$RREG10 INTO DR #, CYL, SUR, SEC BITS
6270 021260 000207 RTS PC ;RETURN TO THE ERROR MESSAGE
6271
6272
6273
6274 .SBTTL CHKDA: CHECK IF RKDA INCREMENTED CORRECTLY
6275
6276 ;CHKDA
6277 ;THIS ROUTINE CHECKS IF RKDA INCREMENTED CORRECTLY. IF RKDA INCREMENTED
6278 ;CORRECTLY RETURN IS MADE TO SKIP THE ERROR MESSAGE.
6279 ;IF RKDA DID NOT INCREMENT CORRECTLY, THE EXPECTED AND RECIEVED VALUES
6280 ;OF RKDA ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE
6281 ;'JSR' CALL.
6282 021262 013705 001350 CHKDA: MOV DRIVAD,R5 ;RKDA SHOULD INCREMENT TO THIS
6283 021266 005205 INC R5 ;AFTER DATA TRANSFER IS DONE
6284 021270 020577 160044 CHKDA1: CMP R5,@RKDA ;DID RKDA INCREMENT CORRECTLY?
6285 021274 001455 BEQ CRETRN ;IF YES, BRANCH
6286 ;IF NOT, REPORT ERROR
6287 021276 010537 001202 MOV R5,$RREG10 ;GET EXPCD RKDA
6288 021302 104415 BRKDA0 ;GO TO 'BDA0' & BREAK CONTENTS OF
6289 ;$RREG10 INTO DR #,CYL,SUR,SEC BITS
6290 021304 017737 160030 001202 MOV @RKDA,$RREG10 ;GET ACTUAL RKDA
6291 021312 104416 BRKDA4 ;GO TO 'BDA4' & BREAK CONTENTS OF
6292 ;$RREG10 INTO DR #,CYL,SUR,SEC BITS
6293 021314 000207 RTS PC ;RETURN TO THE ERROR MESSAGE

```

6294
6295
6296
6297
6298
6299
6300
6301
6302 021316 005777 160012
6303 021322 001442
6304
6305 021324 017737 160004 001162
6306 021332 017737 160002 001164
6307 021340 000207
6308
6309
6310
6311
6312
6313
6314
6315
6316 021342 005777 157762
6317 021346 001430
6318
6319 021350 004737 021002
6320
6321 021354 000207
6322
6323
6324
6325
6326
6327
6328
6329 021356 005777 157746
6330 021362 001422
6331 021364 013737 001330 001162
6332 021372 017737 157732 001164
6333 021400 000207
6334
6335
6336
6337
6338
6339
6340 021402 022777 000200 157722
6341 021410 001407
6342 021412 013737 001332 001162
6343 021420 017737 157706 001164
6344 021426 000207
6345
6346 021430 062716 000002
6347 021434 000207
6348
6349

```
.SBTTL CHKWC: CHECK IF RKWC OVERFLOWED

;CHKWC
;THIS ROUTINE CHECKS IF RKWC OVERFLOWED :0 0. IF IT DID A RETURN IS MADE
;TO SKIP THE ERROR MESSAGE. IF NOT, THE CONTENTS OF RKWC AND RKDA ARE SAVED
;AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR' CALL.
CHKWC: TST @RKWC ;DID WORD COUNT OVERFLOW TO 0?
      BEQ CRETRN ;IF YES, BRANCH
      ;IF NOT, ERROR
      MOV @RKWC,$REG0 ;GET RKWC
      MOV @RKDA,$REG1 ;GET RKDA
      RTS PC ;RETURN TO THE ERROR MESSAGE

.SBTTL CHKER: CHECK RKER CONTENTS

;CHKER
;THIS ROUTINE CHECKS IF ANY BIT IN RKER SET. IF NOT RETURN IS MADE TO SKIP
;THE ERROR MESSAGE. IF ANY BIT IS SET THE CONTENTS OF RKCS, RKER. RKDS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE.
CHKER: TST @RKER ;DID ANY BIT IN RKER SET?
      BEQ CRETRN ;NO, BRANCH
      JSR PC,GT3RG ;GO, GET RKCS, ER, DS
      RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKECLR
;THIS ROUTINE CHECKS THAT RKER IS CLEAR. IF NOT, THE CONTENTS OF RKER
;ARE SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE FOLLOWING THE 'JSR'
;CALL. IF RKER IS CLEAR THE ERROR MESSAGE IS SKIPPED ON RET'RN.
CHKECLR: TST @RKER ;ANY BIT IN RKER SET?
      BEQ CRETRN ;NO
      MOV RKER,$REG0 ;GET ADRES OF RKER
      MOV @RKER,$REG1 ;GET CONTENTS OF RKER
      RTS PC ;RETURN TO THE ERROR MESSAGE

;CHKCCLR
;THIS ROUTINE CHECKS THAT RKCS IS CLEAR. IF NOT, THE CONTENTS OF RKCS ARE
;SAVED AND A RETURN IS MADE TO THE ERROR MESSAGE. IF RKCS IS CLEAR THE
;ERROR MESSAGE IS SKIPPED ON RETURN.
CHKCCLR: CMP #200,@RKCS ;IS RKCS CLEAR?
      BEQ CRETRN ;YES
      MOV RKCS,$REG0 ;SAVE ADRES OF RKCS
      MOV @RKCS,$REG1 ;SAVE THE CONTENT OF RKCS
      RTS PC ;RETURN TO THE ERROR MESSAGE

CRETRN: ADD #2,(SP) ;SKIP ERROR MESSAGE ON
      RTS PC ;RETURN
```

6350
6351
6352
6353
6354
6355
6356
6357
6358
6359
6360 021436 013777 001350 157674
6361 021444 005037 001366
6362 021450 032777 000100 157650
6363 021456 001007
6364 021460 005237 001366
6365 021464 001371
6366 021466 017737 157634 001162
6367 021474 000207
6368
6369 021476 062716 000002
6370
6371 021502 000207
6372
6373
6374
6375
6376
6377
6378
6379
6380
6381
6382
6383
6384
6385
6386
6387
6388
6389
6390 021504 005037 001364
6391 021510 013777 001350 157622
6392 021516 012777 000015 157606
6393 021524 104414
6394
6395
6396
6397
6398
6399 021526 032777 000100 157572
6400 021534 001013
6401 021536 012746 177770
6402 021542 005216
6403 021544 001376
6404 021546 005726
6405 021550 005237 001364

```
.SBTTL TSTRWS: WAIT FOR R/W/S RDY ROUTINE

;TSTRWS
;THIS ROUTINE WAITS FOR R/W/S RDY TO SET. WHEN IT SETS, THE RETURN PC
;IS INCREMENTED SO THAT ON RETURN (TO THE MAIN PROGRAM) THE ERROR
;MESSAGE FOLLOWING THE 'JSR' CALL IS SKIPPED. IF R/W/S RDY DOES NOT SET
;THEN A RETURN IS MADE TO THE ERROR MESSAGE (FOLLOWING THE 'JSR' CALL).
;WAITING TIME IS APPROX. 1040 MS FOR 11/20, APPROX. 208 MS FOR 11/45
;CALL: JSR TSTRWS
TSTRWS: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
      CLR TIMER ;INITIALIZE COUNT
      BIT #100,@RKDS ;DID R/W/S RDY SET?
      BNE 2$ ;YES, BRANCH
      INC TIMER ;WAIT FOR R/W/S RDY
      BNE 1$ ;ERROR IF IT'S NOT SET BY NOW
      MOV @RKDS,$REG0 ;GET RKDS
      RTS PC ;EXIT (TO ERROR FODLOWING 'JSR TSTRWS')

2$: ADD #2,(SP) ;ADJUST RETURN ADRES TO SKIP OVER
      ;ERROR (FOLLOWING 'JSR TSTRWS')
      RTS PC ;EXIT

.SBTTL DRESET: DRIVE RESET ROUTINE

;DRESET
;THIS ROUTINE DOES A DRIVE RESET ON THE DRIVE WHOOSE ADDRESS IS IN
;RKDA. MULTIPLE RETURN ADDRESSES FOR THIS ROUTINE ARE PROVIDED.
;IF THERE IS NO ERROR (R/W/S RDY SETS WITHIN CERTAIN TIME), THEN BEFORE
;EXITNG FROM THIS ROUTINE THE RETURN ADDRESS IS INCREMENTED BY 2, TO SKIP
;THE ERROR MESSAGE ON RETURN. IF THERE IS AN ERROR, THE 3 REGISTERS (CS,ER,DS)
;ARE STORED AND THEN A NORMAL EXIT IS MADE FROM THIS ROUTINE TO THE
;ERROR MESSAGE FOLLOWING THE CALL FOR THIS ROUTINE.
;CALL: JSR PC,DRESET
DRESET: CLR COUNT1 ;INITIALIZE THE COUNT
      MOV DRIVAD,@RKDA ;ADRES THE DRIVE
      MOV #15,@RKCS ;DRIVE RESET, GO
      CNT.RDY ;THIS IS A CALL FOR 'CN.RDY'
      ;ROUTINE WHICH WAITS FOR CNT
      ;RDY TO 'ET. IF CNTRL RDY DOES
      ;NOT SET WITHIN 883 MS/ 11-20
      ;(176 MS FOR 11-45 WITH BIPOLAR)
      ;AN ERROR IS REPORTED
      BIT #100,@RKDS ;DID R/W/S RDY SET?
      BNE 2$
      MOV #-10,-(SP) ;PUSH COUNT ON SP
      INC (SP) ;COUNT IT DOWN
      BNE -2
      TST (SP)+ ;POP UP SP
      INC COUNT1 ;IF NOT WAIT
```

```

6406 021554 001364          BNE 1$                ;WAITED LONG?
6407 021556 004737 020774    JSR PC,GT4RC
6408 021562 000402          BR 2$+4
6409 021564 062716 000002    2$: ADD #2,@R6
6410 021570 000207          RTS PC
6411
6412
6413
6414          .SBTTL TSTSIN: CHECK 'SIN' ROUTINE
6415
6416          ;TSTSIN
6417          ;THIS ROUTINE CHECKS IF 'SIN' IS SET, IF IT IS SET A
6418          ;DRIVE RESET IS DONE TO CLEAR 'SIN' AND INITIALIZE POSITIONER.
6419          ;CALL: TSTSIN
6420          ;IF ON DOING DRIVE RESET R/W/S ROY DOES NOT SET A MESSAGE
6421          ;ERROR PC=XXXXXX IS GIVEN.
6422          ;XXXXXX=PC IN THE MAIN PROGRAM WHERE 'TST.SIN' CALL IS LOCATED.
6423
6424
6425 021572 013777 001350 157540 TSTSIN: MOV DRIVAD,@RKDA ;ADRES THE DRIVE
6426 021600 032777 001000 157520          BIT #1000,@RKDS ;IS SIN SET?
6427 021606 001403          BEQ 1$
6428 021610 004737 021504          JSR PC,DRESET ;GO DO DRIVE RESET, SIN SET
6429 021614 000401          BR 2$            ;REPORT ERROR
6430 021616 000002          1$: RTI
6431 021620 032777 020000 157312 2$: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
6432 021626 001373          BNE 1$          ;IF YES, SKIP TYPEOUT
6433 021630 104401 021636          TYPE ,65$      ;;TYPE ASCIZ STRING
6434 021634 000406          BR 64$         ;;GET OVER THE ASCIZ
6435          ;;65$: .ASCIZ /ERROR PC= /
6436 021652
6437 021652 011646          MOV (SP),-(SP)
6438 021654 062716 177776          ADD #-2,(SP) ;GET THE PC WHERE 'TST.SIN' IS LOCATED
6439 021660 104402          TYPOC
6440 021662 000755          BR 1$          ;GO TYPE OUT PC
6441
6442
6443          .SBTTL DELAY: TIME DELAY ROUTINE
6444
6445          ;DELAY
6446          ;THIS ROUTINE PROVIDES A VARIABLE TIME DELAY. THE CALL FOR THIS
6447          ;ROUTINE IS AN ENCODED 'TRAP' INSTRUCTION.
6448          ;CALL: DELAY ,N N IS ANY OCTAL NO. FROM 1 TO 177777
6449          ;THE DELAY PROVIDED IS 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
6450          ;1.5N US FOR 11/45
6451          ;IF THE USER WANTS TO CHANGE THE DELAY TIME (EXMP: SHORTER DELAY TO
6452          ;GET A TIGHTER SCOPE LOOP) THE VARIABLE 'N' FOLLOWING 'DELAY' SHOULD
6453          ;BE CHANGED TO SUIT THE INDIVIDUAL NEED.
6454
6455
6456 021664 017637 000000 001366 DELA.Y: MOV @(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
6457 021672 062716 000002          ADD #2,(SP) ;DELAY IS TO BE PROVIDED
6458          ;ADJUST STACK POINTER TO SKIP OVER 'N'
6459 021676 005337 001366 1$: DEC TIMER ;COUNT DOWN TO 0
6460 021702 001375          BNE 1$
6461

```

```

6462 021704 000002          RTI                ;RETURN TO MAIN PROGRAM
6463
6464
6465
6466
6467
6468          .SBTTL WAT.INT: WAIT FOR INTERRUPT ROUTINE
6469
6470          ;WAT.INT
6471          ;THIS ROUTINE PROVIDES A VARIABLE TIME WAIT LOOP DURING WHICH AN INTERRUPT
6472          ;FROM RK11 CAN OCCUR. THE CALL IS AN ENCODED 'TRAP' INSTRUCTION.
6473          ;CALL: WAT.INT ,N N IS ANY OCTAL NO. FROM 1 TO 177777
6474
6475          ;WAIT LOOP TIME= APPROX. 7.5N US (CONVERT N TO DECIMAL) FOR 11/20
6476          ;APPROX. 1.5N US FOR 11/45
6477          ;UPON ENTERING THE ROUTINE THE CPU PRIORITY IS DROPPED SO THAT
6478          ;RK11 CAN INTERRUPT. NOTE THAT WHEN RK11 INTERRUPTS THIS ROUTINE
6479          ;IS EXITED WITHOUT POPPING THE STACK, THIS POPPING IS DONE AFTER GETTING
6480          ;TO RK11 INTERRUPT HANDLER.
6481          ;IF FOR ANY REASON THE WAIT LOOP TIME HAS TO BE CHANGED IT CAN BE DONE
6482          ;BY SIMPLY CHANGING THE VARIABLE 'N' FOLLOWING THE 'WAT.INT'.
6483
6484 021706 017637 000000 001366 WATINT: MOV @(SP),TIMER ;GET 'AMOUNT' (N) FOR WHICH
6485 021714 062716 000002          ADD #2,(SP) ;WAITING IS TO BE DONE
6486          ;ADJUST STACK POINTER FOR CORRECT RETURN
6487 021720 013746 001400          MOV RKPRI,-(SP) ;DROP CPU PRIORITY SO THAT RK11 CAN
6488 021724 012746 021732          MOV #1$,-(SP) ; INTERRUPT
6489 021730 000002          RTI
6490 021732 005337 001366 1$: DEC TIMER ;WAIT FOR RK11 TO INTERRUPT
6491 021736 001375          BNE 1$
6492
6493
6494 021740 000002          RTI                ;IF INTERRUPT HAS NOT OCCURED BY NOW
6495          ;RETURN AND REPORT ERROR
6496          ;EXIT
6497
6498          ;WATIME
6499
6500 021742 005000          WATIME: CLR R0
6501 021744 005001          CLR R1
6502 021746 005200          1$: INC R0
6503 021750 001376          BNE 1$
6504 021752 105201          INCB R1
6505 021754 001374          BNE 1$
6506 021756 000207          RTS PC
6507
6508
6509          .SBTTL CHKCRDY: CHECK CONTROL READY
6510
6511          ;;CH.CRDY
6512          ;THIS ROUTINE WAITS FOR THE CONTROL READY TO SET. IF THE CONTROL READY BIT
6513          ;DOES NOT SET WITHIN A CERTAIN TIME, THEN THE CONTENTS OF RKCS, RKER, RKDS
6514          ;AND RKDA ARE SAVED AND AN EXIT MADE TO THE ERROR MESSAGE FOLLOWING THE
6515          ;'JSR' CALL FOR THIS ROUTINE.
6516          ;IF CONTROL READY SETS THEN THE RETURN ADDRESS IS ADJUSTED TO SKIP THE
6517          ;ERROR MESSAGE ON RETURN.

```

6518
6519
6520
6521
6522 021760 005037 001366
6523 021764 105777 157342
6524 021770 100406
6525 021772 005237 001366
6526 021776 001372
6527 022000 004737 020774
6528 022004 000002
6529
6530 022006 062716 000002
6531 022012 000002
6532
6533
6534
6535
6536
6537
6538
6539
6540
6541
6542
6543
6544
6545
6546
6547
6548
6549
6550
6551
6552
6553
6554
6555
6556
6557
6558
6559 022014 012777 000001 157310
6560 022022 012737 177500 001170
6561 022030 000402
6562 022032 005037 001170
6563 022036 105777 157270
6564 022042 100435
6565 022044 005237 001170
6566 022050 001372
6567 022052 032777 020000 157060
6568 022060 001026
6569 022062 104401
6570 022064 001245
6571 022066 104401 022074
6572 022072 000403
6573

```
;CALL: CHKCRDY
; ERROR ;RETURN HERE IF ERROR
; --- ;RETURN HERE IF NO ERROR

CH.CRDY: CLR TIMER
1$: TSTB @RKCS ;CNTRL RDY SET?
BMI 2$ ;YES
INC TIMER
BNE 1$ ;NO, WAIT
JSR PC,GT4RG ;SAVE RKCS, ER, DS, DA
RTI

2$: ADD #2,(SP) ;ADJUST RETURN ADDRESS TO
RTI ;SKIP ERROR MESSAGE ON RETURN
```

.SBTTL CON.RESET: CONTROL REST ROUTINE

```
;CON.RESET
;THIS ROUTINE ISSUES A CONTROL RESET AND WAITS FOR
;THE 'CNTRL RDY' FLAG TO SET. WHEN THE FLAG SETS
;AN EXIT IS MADE OUT OF THE ROUTINE. IF 'CNTRL-RDY'
;DOES NOT SET WITHIN A CERTAIN TIME AN ERROR MESSAGE
; CNT RDY DIDN'T SET
; PC=XXXXXX RKCS=YYYYYY
;IS GIVEN. NOTE THAT XXXXXX IS THE PC WHERE 'CNT.RESET' OR 'CNT.RDY'
;IS CALLED.
```

;CALL: CNT.RESET

.SBTTL CNT.RDY: WAIT FOR CONTROL READY ROUTINE

```
;CN.RDY
;THIS ROUTINE WAITS FOR THE CONTROL READY BIT TO SET AND WHEN IT
;SETS EXITS OUT. IF WITHIN A CERTAIN TIME CNTRL RDY DOES
;NOT SET AN ERROR IS REPORTED. WAITING TIME IS 883 MS FOR 11/20
;175 MS FOR 11/45 WITH BIPOLAR MEMORY.
```

```
;CALL: CNT.RDY
CN.RST: MOV #1,@RKCS ;ISSUE A CONTROL RESET
MOV #-300,$REG3 ;SET UP COUNT
BR CN.RDY+4 ;SKIP OVER CN.RDY

CN.RDY: CLR $REG3
1$: TSTB @RKCS ;DID CNT.L-RDY SET?
BMI 3$ ;YES, EXIT
INC $REG3 ;WAITED LONG?
BNE 1$ ;IF NOT, GO BAK & WAIT
2$: BIT #SW13,@SWR ;INHIBIT TYPEOUT?
BNE 3$ ;IF YES, SKIP TYPEOUT
TYPE
MSG#
TYPE ,65$ ;TYPE ASCIZ STRING
BR 64$ ;GET OVER THE ASCIZ
;65$: .ASCIZ <15><12>/PC=/  
6573
```

6574 022102
6575 022102 011646
6576 022104 162716 000002
6577 022110 104402
6578
6579 022112 104401 022120
6580 022116 000404
6581
6582 022130
6583 022130 017746 157176
6584 022134 104402
6585
6586 022136 000002
6587
6588
6589
6590
6591
6592
6593
6594
6595
6596
6597
6598
6599
6600
6601
6602
6603
6604
6605
6606
6607
6608
6609 022140
6610 022140 104407
6611 022142 032777 040000 156770
6612 022150 001111
6613
6614 022152 000416
6615
6616 022154 013746 000004
6617 022150 012737 022200 000004
6618 022156 005737 177060
6619 022172 012637 000004
6620 022176 000463
6621 022200 022626 000004
6622 022202 012637
6623 022206 000423
6624 022210
6625 022210 032777 000400 156727
6626 022216 001404
6627 022220 127737 156714 001102
6628 022226 001462
6629 022230 105737 001103

```
64$: MOV (SP),-(SP)
SUB #2,(SP)
TYPOC ;GO TYPE PC IN THE MAIN PROGRAM,
; WHERE ERROR OCCURRED
TYPE ,67$ ;TYPE ASCIZ STRING
BR 66$ ;GET OVER THE ASCIZ
;67$: .ASCIZ / RKCS=/  
66$: MOV @RKCS,-(SP) ;GET RKCS
TYPOC ;GO TYPE IT

3$: RTI ;RETURN FROM THIS
;ROUTINE TO THE MAIN
;PROGRAM
```

```
;THIS PART OF THE PROGRAM CONTAINS THE COMMON ROUTINES CALLED
;FROM THE SYSMAC.SML PACKAGE
;
```

.SBTTL SCOPE HANDLER ROUTINE

```
*****
;THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
;AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
;AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
;THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
;SW14=1 LOOP ON TEST
;SW11=1 INHIBIT ITERATIONS
;SW09=1 LOOP ON ERROR
;SW08=1 LOOP ON TEST IN SWR<7:0>
;CALL SCOPE ;:SCOPE=IOT
;*
```

```
$SCOPE:
6609 022140 CksWR ;:TEST FOR CHANGE IN SOFT-SWR
6610 022140 104407 BIT #BIT14,@SWR ;:LOOP ON PRESENT TEST?
6611 022142 032777 040000 156770 $OVER ;:YES IF SW14=1
6612 022150 001111 BNE ;:TESTER#####
;#####START OF CODE FOR THE XOR TESTER#####
;IF RUNNING ON THE "XOR" TESTER CHANGE
;THIS INSTRUCTION TO A "NOP" (NOP=240)
;SAVE THE CONTENTS OF THE ERROR VECTOR
;SET FOR TIMEOUT
;TIME OUT ON XOR?
;RESTORE THE ERROR VECTOR
;GO TO THE NEXT TEST
;CLEAR THE STACK AFTER A TIME OUT
;RESTORE THE ERROR VECTOR
;LOOP ON THE PRESENT TEST
6623 022206 000423 BR 7$
6624 022210 ;:#####END OF CODE FOR THE XOR TESTER#####
6625 022210 032777 000400 156727 BIT #BIT08,@SWR ;:LOOP ON SPEC. TEST?
6626 022216 001404 BEQ ;:BR IF NO
6627 022220 127737 156714 001102 @SWR,$TSTNM ;:ON THE RIGHT TEST? SWR<7:0>
6628 022226 001462 $OVER ;:BR IF YES
6629 022230 105737 001103 2$: TSTB SERFLG ;:HAS AN ERROR OCCURRED?
```

6630 022234 001421 BEQ 3\$;:BR IF NO
6631 022236 123737 CMPB \$ERMAX,\$ERFLG ;:MAX. ERRORS FOR THIS TEST OCCURRED?
6632 022244 101015 BHI 3\$;:BR IF NO
6633 022246 032777 001000 156664 BIT #BIT09,@SWR ;:LOOP ON ERROR?
6634 022254 011404 MOV \$LPERR,\$LPADR ;:SET LOOP ADDRESS TO LAST SCOPE
6635 022256 013737 BR \$OVER
6636 022264 000443 CLR BR ;:ZERO THE ERROR FLAG
6637 022266 105037 001103 4\$: CLR BR \$ERFLG ;:CLEAR THE NUMBER OF ITERATIONS TO MAKE
6638 022272 005037 001206 CLR \$TIMES ;:ESCAPE TO THE NEXT TEST
6639 022276 000415 BR 1\$;:INHIBIT ITERATIONS?
6640 022300 032777 004000 156632 3\$: BIT #BIT11,@SWR ;:INHIBIT ITERATIONS?
6641 022306 001011 BNE 1\$;:BR IF YES
6642 022310 005737 001100 TST \$PASS ;:IF FIRST PASS OF PROGRAM
6643 022314 001406 BEQ 1\$;: INHIBIT ITERATIONS
6644 022316 005237 001104 INC \$ICNT ;:INCREMENT ITERATION COUNT
6645 022322 023737 001206 001104 CMP \$TIMES,\$ICNT ;:CHECK THE NUMBER OF ITERATIONS MADE
6646 022330 002021 BGE \$OVER ;:BR IF MORE ITERATION REQUIRED
6647 022332 012737 000001 001104 1\$: MOV #1,\$ICNT ;:REINITIALIZE THE ITERATION COUNTER
6648 022340 013737 022410 001206 MOV \$MXCNT,\$TIMES ;:SET NUMBER OF ITERATIONS TO DO
6649 022346 105237 001102 \$\$VLAD: INCB \$STNM ;:COUNT TEST NUMBERS
6650 022352 011637 001106 MOV (SP),\$LPADR ;:SAVE SCOPE LOOP ADDRESS
6651 022356 011637 001110 MOV (SP),\$LPERR ;:SAVE ERROR LOOP ADDRESS
6652 022362 005037 001210 CLR \$ESCAPE ;:CLEAR THE ESCAPE FROM ERROR ADDRESS
6653 022366 112737 000001 001115 \$OVER: MOV #1,\$ERMAX ;:ONLY ALLOW ONE(1) ERROR ON NEXT TEST
6654 022374 013777 001102 156540 \$OVER: MOV \$STNM,@DISPLAY ;:DISPLAY TEST NUMBER
6655 022402 013716 001106 MOV \$LPADR,(SP) ;:FUDGE RETURN ADDRESS
6656 022406 000002 RTI ;:FIXES PS
6657 022410 000050 \$MXCNT: 50 ;:MAX. NUMBER OF ITERATIONS

6658
6659
6660 ;:*****
6661
6662 .SBTTL ERROR HANDLER ROUTINE
6663
6664 ;*SW15=1 HALT ON ERROR
6665 ;*SW13=1 INHIBIT ERROR TYPEOUTS
6666 ;*SW10=1 TESTING ON SIMULATOR
6667 ;*SW09=1 LOOP ON ERROR
6668 ;*SW12=1 CYCLE ON ERROR TO PREVIOUS 'SCOPE'
6669 ;*SW06=1 DROP DRIVE AFTER MAXIMUM (ALLOWABLE) ERRORS ON THE DRIVE
6670 ;*GO TO \$ERRTYP ON ERROR
6671
6672 022412 104407 \$ERROR: CKSWR ;:CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6673 022414 105237 001103 7\$: INCB \$ERFLG ;:SET THE ERROR FLAG
6674 022420 001775 BEQ 7\$;:DON'T LET THE FLAG GO TO ZERO
6675 022422 013777 001102 156512 1\$: MOV \$STNM,@DISPLAY ;:DISPLAY TEST NUMBER AND ERROR FLAG
6676 022430 005237 001112 INC \$ERTTL ;:COUNT THE NUMBER OF ERRORS
6677
6678 022434 032777 000100 156476 BIT #BIT6,@SWR ;:DESELECT DRIVE SW SET?
6679 022442 001404 BEQ 6\$;:NO
6680 022444 023727 001112 000005 CMP \$ERTTL,#5 ;:MORE THAN 5 ERRORS ON THIS DRIVE?
6681 022452 101053 BHI 8\$;:YES, DESELECT THE DRIVE
6682
6683 022454 011637 001116 6\$: MOV (SP),\$ERRPC ;:GET ADDRESS OF ERROR INSTRUCTION
6684 022460 162737 000002 001116 SUB #2,\$ERRPC
6685 022466 117737 156424 001114 MOV \$ERRPC,\$ITEMB ;:STRIP AND SAVE THE ERROR ITEM CODE

6686 022474 032777 020000 156436 BIT #SW13,@SWR ;:SKIP TYPEOUT IF SET
6687 022502 001004 BNE 2\$;:SKIP TYPEOUTS
6688 022504 004737 022734 JSR PC,@\$ERRTYP ;:GO TO USER ERROR ROUTINE
6689 022510 104401 001213 TYPE ,SCRLF
6690 022514 023737 000042 000046 2\$: CMP #42,@#46 ;:ARE WE IN ACT11 AUTO MODE?
6691 022522 001403 BEQ +10 ;:YES, HALT ON ERROR
6692 022524 005777 156410 TST @SWR ;:HALT ON ERROR?
6693 022530 100002 BPL 3\$;:SKIP IF CONTINUE
6694 022532 000000 HALT ;:HALT ON ERROR!
6695 022534 104407 CKSWR ;:CHECK FOR SOFTWARE SWITCH REGISTER REQUEST
6696 022536 032777 010000 156374 3\$: BIT #SW12,@SWR ;:SW 12 SET?
6697 022544 001402 BEQ +6 ;:NO, BRANCH
6698 022546 013716 001106 MOV \$LPADR,(SP) ;:ADJUST RETURN ADRES FOR SW12
6699 022552 032777 001000 156360 BIT #SW09,@SWR ;:LOOP ON ERROR SWITCH SET?
6700 022560 001402 BEQ 4\$;:BR IF NO
6701 022562 013716 001110 MOV \$LPERR,(SP) ;:FUDGE RETURN FOR LOOPING
6702 022566 005737 001210 4\$: TST \$ESCAPE ;:CHECK FOR AN ESCAPE ADDRESS
6703 022572 001402 BEQ 5\$;:BR IF NONE
6704 022574 013716 001210 5\$: MOV \$ESCAPE,(SP) ;:FUDGE RETURN ADDRESS FOR ESCAPE
6705 022600 000002 RTI ;:RETURN
6706
6707 022602 005737 001434 8\$: TST T56FLG ;:IF EROR WAS IN LAST TEST (POLL)
6708 ;:DROP ALL THE DRIVES
6709
6710 022610 104401 001303 BEQ 10\$
6711 022614 005037 001412 TYPE ,MSG5
6712 022620 022626 CLR DRVS ;:DRIVE ADDR TO STACK
6713 022622 000137 020652 CMP (SP)+,(SP)+ ;:RIGHT JUSTIFY
6714 022626 013746 001354 JMP \$EOP ;:MAKE EVEN
6715 022632 162716 000002 10\$: MOV DRVPTR,-(SP) ;:POINTS TO TABLE FOR EVEN DRIVE
6716 022636 013746 001350 SUB #2,(SP) ;:TEST REMAINING DRIVE AS RK05E
6717 022642 004737 021200 MOV DRIVAD,-(SP) ;:POINT TO ODD
6718 022646 042716 000001 JSR PC,\$HFRTR ;:TEST AS RK-05E
6719 022652 062716 001414 BIC #1,(R6) ;:INDICATE THIS DRIVE DROPPED
6720 022656 042776 100000 ADD #DRIVO,(SP) ;:PUSH DRIVE # ON STACK
6721 022664 062716 000002 BIC #BIT15,@(R6) ;:SHIFT IT BEFORE TYPING
6722 022670 042736 100000 ADD #2,(R6) ;:TYPE OUT DRIVE #
6723 022674 012736 010009 BIC #BIT15,@(SP)+ ;:DECREMENT # OF DRIVES PRESENT
6724 022700 104401 001272 MOV #BIT12,@(SP)+ ;:RESTORE STACK
6725 022704 013746 001350 TYPE ,MSG4 ;:GO BACK TO THE END OF PROGRAM
6726 022710 004737 021200 MOV DRIVAD,-(R6) ;:LINKAGE.
6727 022714 104402 JSR PC,\$HFRTR
6728 022716 104401 001315 TYPE ,MSG6
6729 022722 005337 001412 DEC DRVS ;:RESTORE STACK
6730 022726 022626 9\$: CMP (SP)+,(SP)+ ;:GO BACK TO THE END OF PROGRAM
6731 022730 000137 020026 JMP BTEOP ;:LINKAGE.
6732
6733
6734 .SBTTL ERROR MESSAGE TYPEOUT ROUTINE
6735
6736 ;:*****
6737 ;:THIS ROUTINE USES THE "ITEM CONTROL BYTE" (\$ITEMB) TO DETERMINE WHICH
6738 ;:ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" (\$ERRTB),
6739 ;:AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
6740
6741 022734 \$ERRTYP:

```

6742 022734 104401 001213      TYPE      ,SCRLF      ;; "CARRIAGE RETURN" & "LINE FEED"
6743 022740 010046      MOV        RO,-(SP)   ;; SAVE RO
6744 022742 005000      CLR        RO        ;; PICKUP THE ITEM INDEX
6745 022744 153700      BISB      @#SITEMB,RO
6746 022750 001004      BNE       1$        ;; IF ITEM NUMBER IS ZERO, JUST
6747                          ;; TYPE THE PC OF THE ERROR
6748 022752 013746 001116      MOV        SERRPC,-(SP) ;; SAVE SERRPC FOR TYPEOUT
6749                          ;; ERROR ADDRESS
6750 022756 104402      TYP0C     BR         6$        ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
6751 022760 000426      BR         6$        ;; GET OUT
6752 022762 005300      1$: DEC    RO        ;; ADJUST THE INDEX SO THAT IT WILL
6753 022764 006300      ASL       RO        ;; WORK FOR THE ERROR TABLE
6754 022766 006300      ASL       RO
6755 022770 006300      ASL       RO
6756 022772 062700 001442      ADD       #SERRTB,RO  ;; FORM TABLE POINTER
6757 022776 012037 023006      MOV       (RO)+,2$    ;; PICKUP "ERROR MESSAGE" POINTER
6758 023002 001404      BEQ       3$        ;; SKIP TYPEOUT IF NO POINTER
6759 023004 104401      TYPE     .WORD      0        ;; TYPE THE "ERROR MESSAGE"
6760 023006 000000      .WORD    0          ;; "ERROR MESSAGE" POINTER GOES HERE
6761 023010 104401 001213      ,SCRLF    (RO)+,4$    ;; "CARRIAGE RETURN" & "LINE FEED"
6762 023014 012037 023024      MOV       (RO)+,4$    ;; PICKUP "DATA HEADER" POINTER
6763 023020 001404      BEQ       5$        ;; SKIP TYPEOUT IF 0
6764 023022 104401      TYPE     .WORD      0        ;; TYPE THE "DATA HEADER"
6765 023024 000000      .WORD    0          ;; "DATA HEADER" POINTER GOES HERE
6766 023026 104401 001213      ,SCRLF    (RO),RO    ;; "CARRIAGE RETURN" & "LINE FEED"
6767 023032 011000      MOV       (RO),RO    ;; PICKUP "DATA TABLE" POINTER
6768 023034 001004      BNE       7$        ;; GO TYPE THE DATA
6769 023036 012600      MOV       (SP)+,RO   ;; RESTORE RO
6770 023040 104401 001213      TYPE     ,SCRLF     ;; "CARRIAGE RETURN" & "LINE FEED"
6771 023044 000207      RTS      PC         ;; RETURN
6772 023046      7$: MOV      @(RO)+,-(SP) ;; SAVE @(RO)+ FOR TYPEOUT
6773 023046      TYP0C     BR         6$        ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
6774 023050 104402      TST      (RO)       ;; IS THERE ANOTHER NUMBER?
6775 023052 005710      BEQ      6$        ;; BR IF NO
6776 023054 001770      TYPE     .B$        ;; TYPE TWO(2) SPACES
6777 023056 104401 023064      BR       7$        ;; LOOP
6778 023062 000771      8$: .ASCIZ / /      ;; TWO(2) SPACES
6779 023064 020040 000      .EVEN
6780
6781      .SBTTL TYPE ROUTINE
6782
6783      ;*****
6784      ;ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
6785      ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
6786      ;NOTE1: SNULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
6787      ;NOTE2: SFILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
6788      ;NOTE3: SFILLC CONTAINS THE CHARACTER TO FILL AFTER.
6789      ;*
6790      ;*CALL:
6791      ;*1) USING A TRAP INSTRUCTION
6792      ;* TYPE ,MESADR      ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
6793      ;*
6794      ;*OR
6795      ;* TYPE
6796      ;* MESADR
6797      ;*

```

```

6798
6799 023070 105737 001157      $TYPE: TSTB  $TPFLG    ;; IS THERE A TERMINAL?
6800 023074 100002      BPL      1$        ;; BR IF YES
6801 023076 000000      HALT     1$        ;; HALT HERE IF NO TERMINAL
6802 023100 000407      BR       3$        ;; LEAVE
6803 023102 010046      1$: MOV     RO,-(SP)   ;; SAVE R0
6804 023104 017600 000002      MOV     @2(SP),RO   ;; GET ADDRESS OF ASCIZ STRING
6805 023110 112046      MOV     (RO)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
6806 023112 001005      BNE     4$        ;; BR IF IT ISN'T THE TERMINATOR
6807 023114 005726      TST     (SP)+      ;; IF TERMINATOR POP IT OFF THE STACK
6808 023116 012600      60$: MOV   (SP)+,RO  ;; RESTORE RO
6809 023120 062716 000002      ADD     #2,(SP)    ;; ADJUST RETURN PC
6810 023124 000002      RTI     1$        ;; RETURN
6811 023126 122716 000011      4$: CMPB  #HT,(SP)   ;; BRANCH IF <HT>
6812 023132 001430      BEQ     8$        ;; BRANCH IF NOT <CRLF>
6813 023134 122716 000200      CMPB   #CRLF,(SP)  ;; BRANCH IF NOT <CRLF>
6814 023140 001006      BNE     5$        ;; POP <CR><LF> EQUIV
6815 023142 005726      TST     (SP)+      ;; TYPE A CR AND LF
6816 023144 104401      TYPE   ,SCRLF     ;; TYPE A CR AND LF
6817 023146 001213      CLR    $CHARCNT    ;; CLEAR CHARACTER COUNT
6818 023150 105037 023304      BR     2$        ;; GET NEXT CHARACTER
6819 023154 000755      JSR    PC,$TYPE    ;; GO TYPE THIS CHARACTER
6820 023156 004737 023240      5$: CMPB  $FILLC,(SP)+ ;; IS IT TIME FOR FILLER CHARS.?
6821 023162 123726 001156      BNE     2$        ;; IF NO GO GET NEXT CHAR.
6822 023166 001350      MOV    $NULL,-(SP) ;; GET # OF FILLER CHARS. NEEDED
6823 023170 013746 001154      AND    $NULL,-(SP) ;; AND THE NULL CHAR.
6824
6825 023174 105366 000001      7$: DEC   1(SP)     ;; DOES A NULL NEED TO BE TYPED?
6826 023200 002770      BLT    6$        ;; BR IF NO--GO POP THE NULL OFF OF STACK
6827 023202 004737 023240      JSR    PC,$TYPE    ;; GO TYPE A NULL
6828 023206 105337 023304      DEC   $CHARCNT    ;; DO NOT COUNT AS A COUNT
6829 023212 000770      BR     7$        ;; LOOP
6830
6831      ;HORIZONTAL TAB PROCESSOR
6832
6833 023214 112716 000040      8$: MOV   #',(SP)   ;; REPLACE TAB WITH SPACE
6834 023220 004737 023240      9$: JSR   PC,$TYPE  ;; TYPE A SPACE
6835 023224 132737 000007 023304      BITB  #7,$CHARCNT ;; BRANCH IF NOT AT
6836 023232 001372      BNE    9$        ;; TAB STOP
6837 023234 005726      TST   (SP)+      ;; POP SPACE OFF STACK
6838 023236 000724      BR    2$        ;; GET NEXT CHARACTER
6839 023240 105777 155704      $TYPE: TSTB  @STPB   ;; WAIT UNTIL PRINTER IS READY
6840 023244 100375      BPL   $TYPE      ;; LOAD CHAR TO BE TYPED INTO DATA REG.
6841 023246 116677 000002 155676      MOV   2(SP),@STPB  ;; IS CHARACTER A CARRIAGE RETURN?
6842 023254 122766 000015 000002      CMPB  #CR,2(SP)   ;; IS CHARACTER A CARRIAGE RETURN?
6843 023262 001003      BNE    1$        ;; BRANCH IF NO
6844 023264 105037 023304      CLR   $CHARCNT   ;; YES--CLEAR CHARACTER COUNT
6845 023270 000406      BR    $TYPE      ;; EXIT
6846 023272 122766 000012 000002 1$: CMPB  #LF,2(SP)  ;; IS CHARACTER A LINE FEED?
6847 023300 001402      BEQ   $TYPE      ;; BRANCH IF YES
6848 023302 105227      INCB  (PC)+      ;; COUNT THE CHARACTER
6849 023304 000000      $CHARCNT: .WORD  0 ;; CHARACTER COUNT STORAGE
6850 023306 000207      $TYPE: RTS      PC
6851
6852
6853      .SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

```

6854
6855
6856
6857
6858
6859
6860
6861
6862
6863
6864
6865 023310
6866 023310 010046
6867 023312 010146
6868 023314 010246
6869 023316 010346
6870 023320 010546
6871 023322 012746 020200
6872 023326 016605 000020
6873 023332 100004
6874 023334 005405
6875 023336 112766 000055 000001
6876 023344 005000
6877 023346 012703 023524
6878 023352 112723 000040
6879 023356 005002
6880 023360 016001 023514
6881 023364 160105
6882 023365 002402
6883 023370 005202
6884 023372 000774
6885 023374 060105
6886 023376 005702
6887 023400 001002
6888 023402 105716
6889 023404 100407
6890 023406 106316
6891 023410 103003
6892 023412 116653 000001 177777
6893 023420 052702 000060
6894 023424 052702 000040
6895 023430 110223
6896 023432 005720
6897 023434 020027 000010
6898 023440 002746
6899 023442 003002
6900 023444 010502
6901 023446 000754
6902 023450 105726
6903 023452 100003
6904 023454 116653 177777 177776
6905 023462 105013
6906 023464 012605
6907 023466 012603
6908 023470 012602
6909 023472 012601

```

```

;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
;REPLACED WITH SPACES.
;CALL:
;* MOV NUM,-(SP) ;:PUT THE BINARY NUMBER ON THE STACK
;* TYPDS ;:GO TO THE ROUTINE

$TYPDS:
MOV R0,-(SP) ;:PUSH R0 ON STACK
MOV R1,-(SP) ;:PUSH R1 ON STACK
MOV R2,-(SP) ;:PUSH R2 ON STACK
MOV R3,-(SP) ;:PUSH R3 ON STACK
MOV R5,-(SP) ;:PUSH R5 ON STACK
MOV #20200,-(SP) ;:SET BLANK SWITCH AND SIGN
MOV 20(SP),R5 ;:GET THE INPUT NUMBER
BPL 1$ ;:BR IF INPUT IS POS.
NEG R5 ;:MAKE THE BINARY NUMBER POS.
MOV #'-,1(SP) ;:MAKE THE ASCII NUMBER NEG.
1$: CLR R0 ;:ZERO THE CONSTANTS INDEX
MOV # $DBLK,R3 ;:SETUP THE OUTPUT POINTER
MOV #',(R3)+ ;:SET THE FIRST CHARACTER TO A BLANK
2$: CLR R2 ;:CLEAR THE BCD NUMBER
MOV $DTBL(R0),R1 ;:GET THE CONSTANT
3$: SUB R1,R5 ;:FORM THIS BCD DIGIT
BLT 4$ ;:BR IF DONE
INC R2 ;:INCREASE THE BCD DIGIT BY 1
BR 3$
4$: ADD R1,R5 ;:ADD BACK THE CONSTANT
TST R2 ;:CHECK IF BCD DIGIT=0
BNE 5$ ;:FALL THROUGH IF 0
TSTB (SP) ;:STILL DOING LEADING 0'S?
BMI 7$ ;:BR IF YES
5$: ASLB (SP) ;:MSD?
BCC 6$ ;:BR IF NO
MOV 1(SP),-1(R3) ;:YES--SET THE SIGN
6$: BIS #0,R2 ;:MAKE THE BCD DIGIT ASCII
7$: BIS #' ,R2 ;:MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOV R2,(R3)+ ;:PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST (R0)+ ;:JUST INCREMENTING
CMP R0,#10 ;:CHECK THE TABLE INDEX
BLT 2$ ;:GO DO THE NEXT DIGIT
BGT 8$ ;:GO TO .XIT
MOV R5,R2 ;:GET THE LSD
BR 6$ ;:GO CHANGE TO ASCII
8$: TSTB (SP)+ ;:WAS THE LSD THE FIRST NON-ZERO?
BPL 9$ ;:BR IF NO
MOV -1(SP),-2(R3) ;:YES--SET THE SIGN FOR TYPING
9$: CLRB (R3) ;:SET THE TERMINATOR
MOV (SP)+,R5 ;:POP STACK INTO R5
MOV (SP)+,R3 ;:POP STACK INTO R3
MOV (SP)+,R2 ;:POP STACK INTO R2
MOV (SP)+,R1 ;:POP STACK INTO R1

```

```

6910 023474 012600
6911 023476 104401
6912 023502 016666 023524 000002 000004
6913 023510 012616
6914 023512 000002
6915 023514 023420
6916 023516 001750
6917 023520 000144
6918 023522 000012
6919 023524 000004
6920
6921
6922
6923
6924
6925
6926
6927
6928
6929
6930
6931
6932
6933
6934
6935
6936
6937
6938
6939
6940
6941
6942
6943
6944
6945
6946 023534 017646 000000
6947 023540 116637 000001 023757
6948 023546 112637 023761
6949 023552 062716 000002
6950 023556 000406
6951 023560 112737 000001 023757
6952 023566 112737 000006 023761
6953 023574 112737 000005 023756
6954 023602 010346
6955 023604 010446
6956 023606 010546
6957 023610 113704 023761
6958 023614 005404
6959 023616 062704 000006
6960 023622 110437 023760
6961 023626 113704 023757
6962 023632 016605 000012
6963 023636 005003
6964 023640 006105
6965 023642 000404

```

```

MOV (SP)+,R0 ;:POP STACK INTO R0
TYPE , $DBLK ;:NOW TYPE THE NUMBER
MOV 2(SP),4(SP) ;:ADJUST THE STACK
MOV (SP)+,(SP)
$DTBL: 10000.
1000.
100.
10.
$DBLK: .BLKW 4

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE
;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
;OCTAL (ASCII) NUMBER AND TYPE IT.
;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
;CALL:
;* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
;* TYPOS ;:CALL FOR TYPEOUT
;* .BYTE N ;:N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
;* .BYTE M ;:M=1 OR 0
;* ;:1=TYPE LEADING ZEROS
; ;:0=SUPPRESS LEADING ZEROS
;*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
;*$TYPOS OR $TYPOC
;CALL:
;* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
;* TYPON ;:CALL FOR TYPEOUT
;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
;CALL:
;* MOV NUM,-(SP) ;:NUMBER TO BE TYPED
;* TYPOC ;:CALL FOR TYPEOUT

$TYPOS: MOV @ (SP),-(SP) ;:PICKUP THE MODE
MOV 1(SP),$OFILL ;:LOAD ZERO FILL SWITCH
MOV (SP)+,$SOMODE+1 ;:NUMBER OF DIGITS TO TYPE
ADD #2,(SP) ;:ADJUST RETURN ADDRESS
BR $TYPON
$TYPOC: MOV #1,$OFILL ;:SET THE ZERO FILL SWITCH
MOV #6,$SOMODE+1 ;:SET FOR SIX(6) DIGITS
MOV #5,$SOCNT ;:SET THE ITERATION COUNT
MOV R3,-(SP) ;:SAVE R3
MOV R4,-(SP) ;:SAVE R4
MOV R5,-(SP) ;:SAVE R5
MOV $SOMODE+1,R4 ;:GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6,R4 ;:SUBTRACT IT FOR MAX. ALLOWED
MOV R4,$SOMODE ;:SAVE IT FOR USE
MOV $OFILL,R4 ;:GET THE ZERO FILL SWITCH
MOV 12(SP),R5 ;:PICKUP THE INPUT NUMBER
CLR R3 ;:CLEAR THE OUTPUT WORD
ROL R5 ;:ROTATE MSB INTO "C"
BR 3$ ;:GO DO MSB

```

```

6966 023644 006105      2$:  ROL  R5          ;;FORM THIS DIGIT
6967 023646 006105      ROL  R5
6968 023650 006105      ROL  R5
6969 023652 010503      MOV  R5,R3
6970 023654 006103      3$:  ROL  R3          ;;GET LSB OF THIS DIGIT
6971 023656 105337      DECB SOMODE        ;;TYPE THIS DIGIT?
6972 023662 100016      BPL  7$           ;;BR IF NO
6973 023664 042703      BIC  #177770,R3   ;;GET RID OF JUNK
6974 023670 001002      BNE  4$           ;;TEST FOR 0
6975 023672 005704      TST  R4           ;;SUPPRESS THIS 0?
6976 023674 001403      BEQ  5$           ;;BR IF YES
6977 023576 005204      INC  R4           ;;DON'T SUPPRESS ANYMORE 0'S
6978 023700 052703      BIS  #'0,R3       ;;MAKE THIS DIGIT ASCII
6979 023704 052703      BIS  #'1,R3       ;;MAKE ASCII IF NOT ALREADY
6980 023710 110337      MOVB R3,B5        ;;SAVE FOR TYPING
6981 023714 104401      TYPE ,8$         ;;GO TYPE THIS DIGIT
6982 023720 105337      7$:  DECB $OCNT     ;;COUNT BY 1
6983 023724 003447      BGT  2$           ;;ER IF MORE TO DO
6984 023726 002402      BLT  6$           ;;BR IF DONE
6985 023730 005204      INC  R4           ;;INSURE LAST DIGIT ISN'T A BLANK
6986 023732 000744      BR   2$           ;;GO DO THE LAST DIGIT
6987 023734 012605      6$:  MOV  (SP)+,R5   ;;RESTORE R5
6988 023736 012604      MOV  (SP)+,R4     ;;RESTORE R4
6989 023740 012603      MOV  (SP)+,R3     ;;RESTORE R3
6990 023742 016666      MOV  2(SP),4(SP)  ;;SET THE STACK FOR RETURNING
6991 023750 012616      MOV  (SP)+,(SP)   ;;RETURN
6992 023752 000002      RTI              ;;RETURN
6993 023754 000     8$:  .BYTE  0          ;;STORAGE FOR ASCII DIGIT
6994 023755 000     .BYTE  0          ;;TERMINATOR FOR TYPE ROUTINE
6995 023756 000     $OCNT: .BYTE  0          ;;OCTAL DIGIT COUNTER
6996 023757 000     $OFILL: .BYTE  0         ;;ZERO FILL SWITCH
6997 023760 000000     $OMODE: .WORD  0         ;;NUMBER OF DIGITS TO TYPE

.SBTTL  TTY INPUT ROUTINE
;*****
;ENABL  LSB
;*****
;*****
;SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
;ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
;SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
;WHEN OPERATING IN TTY FLAG MODE.
7009 023762 022737 000176 001140  SCKSWR: CMP  #SWREG,SWR   ;;IS THE SOFT-SWR SELECTED?
7010 023770 001074      BNE  15$          ;;BRANCH IF NO
7011 023772 105777 155146      TSTB @STKS       ;;CHAR THERE?
7012 023776 100071      BPL  15$          ;;IF NO, DON'T WAIT AROUND
7013 024000 117746 155142      MOVB @STKB,-(SP) ;;SAVE THE CHAR
7014 024004 042716 177800      BIC  #'C177,(SP) ;;STRIP-OFF THE ASCII
7015 024010 022725 000007      CMP  #7,(SP)+    ;;IS IT A CONTROL G?
7016 024014 001062      BNE  15$          ;;NO, RETURN TO USER
7017 024016 123727 001134 000001  CMPB SAUTOB,#1   ;;ARE WE RUNNING IN AUTO-MODE?
7018 024024 001456      BEQ  15$          ;;BRANCH IF YES
7019
7020 024026 104401 024647      TYPE  ,SCNTLG    ;;ECHO THE CONTROL-G (^G)
7021 024032 104401 024654      SGTSWR: TYPE  ,SMSWR   ;;TYPE CURRENT CONTENTS

```

```

7022 024036 013746 000176      MOV  SWREG,-(SP)  ;;SAVE SWREG FOR TYPEOUT
7023 024042 104402      TYPOC            ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
7024 024044 104401 024665      TYPE  ,SMNEW     ;;PROMPT FOR NEW SWR
7025 024050 005046      19$: CLR  -(SP)    ;;CLEAR COUNTER
7026 024052 005046      CLR  -(SP)       ;;THE NEW SWR
7027 024054 105777 155064      7$:  TSTB @STKS    ;;CHAR THERE?
7028 024060 100375      BPL  7$          ;;IF NOT TRY AGAIN
7029
7030 024062 117746 155060      MOVB @STKB,-(SP) ;;PICK UP CHAR
7031 024066 042716 177600      BIC  #'C177,(SP) ;;MAKE IT 7-BIT ASCII
7032
7033
7034
7035 024072 021627 000025      9$:  CMP  (SP),#25   ;;IS IT A CONTROL-U?
7036 024076 001005      BNE  10$         ;;BRANCH IF NOT
7037 024100 104401 024642      TYPE  ,SCNTLU    ;;YES, ECHO CONTROL-U (^U)
7038 024104 062706 000006      20$: ADD  #6,SP     ;;IGNORE PREVIOUS INPUT
7039 024110 000757      BR   19$        ;;LET'S TRY IT AGAIN
7040
7041
7042 024112 021627 000015      10$: CMP  (SP),#15   ;;IS IT A <CR>?
7043 024116 001022      BNE  16$         ;;BRANCH IF NO
7044 024120 005766 000004      TST  4(SP)       ;;YES, IS IT THE FIRST CHAR?
7045 024124 001403      BEQ  11$         ;;BRANCH IF YES
7046 024126 016677 000002 155004  MOV  2(SP),@SWR   ;;SAVE NEW SWR
7047 024134 062706 000006      11$: ADD  #6,SP     ;;CLEAR UP STACK
7048 024140 104401 001213      TYPE  ,SCRFLF    ;;ECHO <CR> AND <LF>
7049 024144 123727 001135 000001  14$: CMPB $INTAG,#1 ;;RE-ENABLE TTY KBD INTERRUPTS?
7050 024152 001003      BNE  15$         ;;BRANCH IF NOT
7051 024154 012777 000100 154762  MOV  #100,@STKS  ;;RE-ENABLE TTY KBD INTERRUPTS
7052 024162 000002      RTI              ;;RETURN
7053 024164 004737 023240      15$: JSR  PC,$TYPEC  ;;ECHO CHAR
7054 024170 021627 000060      CMP  (SP),#60   ;;CHAR < 0?
7055 024174 002420      BLT  19$         ;;BRANCH IF YES
7056 024176 021627 000067      CMP  (SP),#57   ;;CHAR > ??
7057 024202 003015      BGT  19$         ;;BRANCH IF YES
7058 024204 042726 000060      BIC  #60,(SP)+  ;;STRIP-OFF ASCII
7059 024210 005766 000002      TST  2(SP)       ;;IS THIS THE FIRST CHAR
7060 024214 001403      BEQ  17$         ;;BRANCH IF YES
7061 024216 006316      ASL  (SP)        ;;NO, SHIFT PRESENT
7062 024220 006316      ASL  (SP)        ;; CHAR OVER TO MAKE
7063 024222 006316      ASL  (SP)        ;; ROOM FOR NEW ONE.
7064 024224 005266 000062 17$:  INC  2(SP)       ;;KEEP COUNT OF CHAR
7065 024230 056616 177716      BIS  -2(SP),(SP) ;;SET IN NEW CHAR
7066 024234 000707      BR   7$          ;;GET THE NEXT ONE
7067 024236 104401 001212      18$: TYPE  ,SQUES  ;;TYPE ?<CR><LF>
7068 024242 000720      BR   20$        ;;SIMULATE CONTROL-U
7069
7070
7071
7072
7073
7074
7075
7076
7077
;*****
;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
;CALL
;RDCHR RETURN HERE ;;INPUT A SINGLE CHARACTER FROM THE TTY
; CHARACTER IS ON THE STACK
; WITH PARITY BIT STRIPPED OFF

```

```
7078 ;
7079 ;
7080 024244 011646 $RDCHR: MOV (SP),-(SP) ;;PUSH DOWN THE PC
7081 024246 016566 000004 000002 MOV 4(SP),2(SP) ;;SAVE THE PS
7082 024254 105777 154664 1$: TSTB @STKS ;;WAIT FOR
7083 024260 100375 BPL 1$ ;;A CHARACTER
7084 024262 117766 154660 000004 MOVVB @STKB,4(SP) ;;READ THE TTY
7085 024270 042766 177600 000004 BIC #^C<177>,4(SP) ;;GET RID OF JUNK IF ANY
7086 024276 026627 000004 000023 CMP 4(SP),#23 ;;IS IT A CONTROL-5?
7087 024304 001013 BNE 3$ ;;BRANCH IF NO
7088 024306 105777 154632 2$: TSTB @STKS ;;WAIT FOR A CHARACTER
7089 024312 100375 BPL 2$ ;;LOOP UNTIL ITS THERE
7090 024314 117746 154626 MOVVB @STKB,-(SP) ;;GET CHARACTER
7091 024320 042716 177600 BIC #^C177,(SP) ;;MAKE IT 7-BIT ASCII
7092 024324 022627 000021 CMP (SP)+,#21 ;;IS IT A CONTROL-Q?
7093 024330 001366 BNE 2$ ;;IF NOT DISCARD IT
7094 024332 000750 BR 1$ ;;YES, RESUME
7095 024334 026627 000004 000140 3$: CMP 4(SP),#140 ;;IS IT UPPER CASE?
7096 024342 002407 BLT 4$ ;;BRANCH IF YES
7097 024344 026627 000004 000175 CMP 4(SP),#175 ;;IS IT A SPECIAL CHAR?
7098 024352 003003 BGT 4$ ;;BRANCH IF YES
7099 024354 042766 000040 000004 BIC #40,4(SP) ;;MAKE IT UPPER CASE
7100 024362 000002 4$: RTI ;;GO BACK TO USER
7101 ;*****
7102 ;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7103 ;*CALL:
7104 ;* RDLIN ;;INPUT A STRING FROM THE TTY
7105 ;* RETURN HERE ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7106 ;* ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
7107
7108 024364 010346 $RDLIN: MOV R3,-(SP) ;;SAVE R3
7109 024366 005046 CLR -(SP) ;;CLEAR THE RUBOUT KEY
7110 024370 012703 024620 1$: MOV #TTYIN,R3 ;;GET ADDRESS
7111 024374 022703 024642 2$: CMP #TTYIN+22,R3 ;;BUFFER FULL?
7112 024400 101456 BLOS 4$ ;;BR IF YES
7113 024402 104410 RDCHR ;;GO READ ONE CHARACTER FROM THE TTY
7114 024404 112613 (SP)+,(R3) ;;GET CHARACTER
7115 024406 122713 000177 10$: CMPB #177,(R3) ;;IS IT A RUBOUT
7116 024412 001022 BNE 5$ ;;BR IF NO
7117 024414 005716 TST (SP) ;;IS THIS THE FIRST RUBOUT?
7118 024416 001007 BNE 6$ ;;BR IF NO
7119 024420 112737 000134 024616 MOVVB #' \,9$ ;;TYPE A BACK SLASH
7120 024426 104401 024616 TYPE .9$
7121 024432 012716 177777 MOV #-1,(SP) ;;SET THE RUBOUT KEY
7122 024436 005303 6$: DEC R3 ;;BACKUP BY ONE
7123 024440 020327 024620 CMP R3,#TTYIN ;;STACK EMPTY?
7124 024444 103434 BLO 4$ ;;BR IF YES
7125 024446 111337 024616 MOVVB (R3),9$ ;;SETUP TO TYPEOUT THE DELETED CHAR.
7126 024452 104401 024616 TYPE .9$ ;;GO TYPE
7127 024456 000746 BR 2$ ;;GO READ ANOTHER CHAR.
7128 024460 005716 5$: TST (SP) ;;RUBOUT KEY SET?
7129 024462 001406 BEQ 7$ ;;BR IF NO
7130 024464 112737 000134 024616 MOVVB #' \,9$ ;;TYPE A BACK SLASH
7131 024472 104401 024616 TYPE .9$
7132 024476 005016 CLR (SP) ;;CLEAR THE RUBOUT KEY
7133 024500 122713 000025 7$: CMPB #25,(R3) ;;IS CHARACTER A CTRL U?
```

```
7134 024504 001003 BNE 8$ ;;BR IF NO
7135 024506 104401 024642 TYPE ,SCNTLU ;;TYPE A CONTROL "U"
7136 024512 000726 BR 1$ ;;GO START OVER
7137 024514 122713 000022 9$: CMPB #22,(R3) ;;IS CHARACTER A "R"?
7138 024520 001011 BNE 3$ ;;BRANCH IF NO
7139 024522 105013 CLRVB (R3) ;;CLEAR THE CHARACTER
7140 024524 104401 001213 TYPE ,$CRLF ;;TYPE A "CR" & "LF"
7141 024530 104401 024620 TYPE ,TTYIN ;;TYPE THE INPUT STRING
7142 024534 000717 BR 2$ ;;GO PICKUP ANOTHER CHARACTER
7143 024536 104401 001212 4$: TYPE ,SQUES ;;TYPE A " "
7144 024542 000712 BR 1$ ;;CLEAR THE BUFFER AND LOOP
7145 024544 111337 024616 3$: MOVVB (R3),9$ ;;ECHO THE CHARACTER
7146 024550 104401 024616 TYPE .9$
7147 024554 122723 000015 CMPB #15,(R3)+ ;;CHECK FOR RETURN
7148 024560 001305 BNE 2$ ;;LOOP IF NOT RETURN
7149 024562 105063 177777 CLRVB -(R3) ;;CLEAR RETURN (THE 15)
7150 024566 104401 001214 TYPE ,SLF ;;TYPE A LINE FEED
7151 024572 005726 TST (SP)+ ;;CLEAN RUBOUT KEY FROM THE STACK
7152 024574 012603 MOV (SP)+,R3 ;;RESTORE R3
7153 024576 011646 MOV (SP),-(SP) ;;ADJUST THE STACK AND PUT ADDRESS OF THE
7154 024600 016566 000004 000002 MOV 4(SP),2(SP) ;; FIRST ASCII CHARACTER ON IT
7155 024606 012766 024620 000004 MOV #TTYIN,4(SP)
7156 024614 000002 RTI ;;RETURN
7157 024616 000 .BYTE 0 ;;STORAGE FOR ASCII CHAR. TO TYPE
7158 024617 000 .BYTE 0 ;;TERMINATOR
7159 024620 000022 $TTYIN: .BLKB 22 ;;RESERVE 22 BYTES FOR TTY INPUT
7160 024642 052536 005015 000 $CNTLU: .ASCIZ /"U"<15><12> ;;CONTROL "U"
7161 024647 136 006507 000012 $CNTLG: .ASCIZ /"G"<15><12> ;;CONTROL "G"
7162 024654 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
7163 024662 020075 000
7164 024665 040 047040 053505 $MNEW: .ASCIZ / NEW = /
7165 024672 036440 000040 ;CONTROL U, RUBOUT CAPABILITY
7166
7167 .SBTTL TRAP DECODER
7168
7169 ;*****
7170 ;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
7171 ;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
7172 ;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
7173 ;GO TO THAT ROUTINE.
7174
7175 024676 010046 $TRAP: MOV R0,-(SP) ;;SAVE R0
7176 024700 016600 000002 MOV 2(SP),R0 ;;GET TRAP ADDRESS
7177 024704 005740 TST -(R0) ;;BACKUP BY 2
7178 024706 111000 MOVVB (R0),R0 ;;GET RIGHT BYTE OF TRAP
7179 024710 006300 ASL R0 ;;POSITION FOR INDEXING
7180 024712 016000 024732 MOV STRPAD(R0),R0 ;;INDEX TO TABLE
7181 024716 000200 RTS R0 ;;GO TO ROUTINE
7182
7183 ;THIS IS USE TO HANDLE THE "GETPRI" MACRO
7184
7185
7186 024720 011646 $STRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN
7187 024722 016566 000004 000002 MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN
7188 024730 000002 RTI ;;RESTORE THE PSW
7189
```

```

7190
7191
7192
7193
7194
7195
7196
7197 024732 024720
7198 024734 023070
7199 024736 023560
7200 024740 023534
7201 024742 023574
7202 024744 023310
7203
7204 024746 024032
7205
7206 024750 023762
7207 024752 024244
7208 024754 024364
7209
7210 024756 021760
7211
7212 024760 022014
7213
7214 024762 022032
7215
7216 024764 021056
7217
7218 024766 021066
7219
7220 024770 021664
7221
7222 024772 021706
7223
7224 024774 021572
7225
7226
7227
7228
7229
7230
7231 024776 012737 025142 000024
7232 025004 012737 000340 000026
7233 025012 010046
7234 025014 010146
7235 025016 010246
7236 025020 010346
7237 025022 010446
7238 025024 010546
7239 025026 017746 154106
7240 025032 010637 025146
7241 025036 012737 025050 000024
7242 025044 000000
7243 025046 000776
7244
7245

```

.SBTTL POWER DOWN AND UP ROUTINES

```

*****
:POWER DOWN ROUTINE
SPWRDN: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST UP
MOV #340,@#PWRVEC+2 ;;PRIO:7
MOV R0,-(SP) ;;PUSH R0 ON STACK
MOV R1,-(SP) ;;PUSH R1 ON STACK
MOV R2,-(SP) ;;PUSH R2 ON STACK
MOV R3,-(SP) ;;PUSH R3 ON STACK
MOV R4,-(SP) ;;PUSH R4 ON STACK
MOV R5,-(SP) ;;PUSH R5 ON STACK
MOV @SWR,-(SP) ;;PUSH @SWR ON STACK
MOV SP,SSAVR6 ;;SAVE SP
MOV #SPWRUP,@#PWRVEC ;;SET UP VECTOR
HALT
BR -2 ;;HANG UP
*****

```

```

7245
7246 025050 012737 025142 000024
7248 025056 013706 025146
7249 025062 003037 025146
7250 025068 005237 025146
7251 025072 001375
7252 025074 012677 154040
7253 025100 012605
7254 025102 012604
7255 025104 012603
7256 025106 012602
7257 025110 012601
7258 025112 012600
7259 025114 012737 024776 000024
7260 025122 012737 000340 000026
7261 025130 104401
7262 025132 025150
7263 025134 012716
7264 025136 004702
7265 025140 000002
7266 025142 000000
7267 025144 000776
7268 025146 000000
7269 025150 005015 047520 042527
7270 025156 000122
7271
7272
7273 025160 004737 021504
7274 025164 104026
7275 025166 104413
7276 025170 013737 001350 025302
7277 025176 032737 020000 001350
7278 025204 001404
7279 025206 042737 020000 001350
7280 025214 000403
7281 025216 052737 020000 001350 1$:
7282 025224 013777 001350 154106 2$:
7283 025232 012777 000011 154072
7284 025240 104414
7285 025242 013777 025302 154070
7286 025250 104414
7287 025252 032777 000100 154046
7288 025260 001001
7289 025262 005725
7290 025264 013737 025302 001350 3$:
7291 025272 004737 021504
7292 025276 104026
7293 025300 000205
7294 025302 000000
7295 025304 005037 001350
7296 025310 012700 001414
7297 025314 005710
7298 025316 001413
7299 025320 005760 000002
7300 025324 001410
7301 025326 004537 025160

```

:POWER UP ROUTINE

```

SPWRUP: MOV #SILLUP,@#PWRVEC ;;SET FOR FAST DOWN
MOV $SAVR6,SP ;;GET SP
CLR $SAVR6 ;;WAIT LDDP FOR THE TTY
1$: INC $SAVR6 ;;WAIT FOR THE INC
BNE 1$ ;;OF WORD
MOV (SP)+,@SWR ;;POP STACK INTO @SWR
MOV (SP)+,R5 ;;POP STACK INTO R5
MOV (SP)+,R4 ;;POP STACK INTO R4
MOV (SP)+,R3 ;;POP STACK INTO R3
MOV (SP)+,R2 ;;POP STACK INTO R2
MOV (SP)+,R1 ;;POP STACK INTO R1
MOV (SP)+,R0 ;;POP STACK INTO R0
MOV #SPWRDN,@#PWRVEC ;;SET UP THE POWER DOWN VECTOR
MOV #340,@#PWRVEC+2 ;;PRIO:7
TYPE ;;REPORT THE POWER FAILURE
SPWRMG: .WORD SPOWER ;;POWER FAIL MESSAGE POINTER
MOV (PC)+,(SP) ;;RESTART AT PFSTRT
SPWRAD: .WORD PFSTRT ;;RESTART ADDRESS
RTI
$ILLUP: HALT ;;THE POWER UP SEQUENCE WAS STARTED
BR -2 ;; BEFORE THE POWER DOWN WAS COMPLETE
$SAVR6: 0
$POWER: .ASCIZ <15><12>*POWER* ;;PUT THE SP HERE
.EVEN
FCHECK: JSR PC,DRESET ;;RESETB DRIVE
ERROR 26
CNT,RESET
MOV DRIVAD,DRHOLD ;;SAVE DRIVE ADDR
BIT #20000,DRIVAD ;;SEE IF ODD
BEQ 1$
BIC #20000,DRIVAD ;;MAKE EVEN
BR 2$
BIS #20000,DRIVAD ;;MAKE ODD
2$: MOV DRIVAD,@RKDA ;;DRIVE ADDR
MOV #11,@RKCS ;;DRIVE SEEK
CNT,RDY
MOV DRHOLD,@RKDA ;;OTHER DRIVE
CNT,RDY
BIT #100,@RKDS ;;HEAEDS IN MOTION?
BNE 3$
TST (R5)+ ;;NO SO RK-05J
MOV DRHOLD,DRIVAD ;;RESTORE ADDR
3$: JSR PC,DRESET ;;WAIT FOR RESET
ERROR 26
RTS R5
DRHOLD: 0
SIZEF: CLR DRIVAD ;;START AT DRO
MOV #DRIVO,R0 ;;TABLE OF AVAIL DRIVES
4$: TST (R0) ;;THIS DRIVE HERE?
BEQ 2$ ;;NO
TST 2(R0) ;;COMPLEMENT #R0CY
BEQ 2$ ;;NO
JSR R5,FCHECK ;;SEE IF F MOD'LL

```

7302	025332	000405				BR	2\$;J MODEL
7303	025334	052710	100000			BIS	#100000,(R0)		;SET SIGN FOR F
7304	025340	052760	100000	000002		BIS	#100000,2(R0)		;BOTH DRIVES
7305	025346	005720			2\$:	TST	(R0)+		
7306	025350	005720				TST	(R0)+		;NEXT PAIR OF DRIVES
7307	025352	062737	040000	001350		ADD	#40000,DRIVAD		;NEXT ACTUL ADDR
7308	025360	022700	001433			CMP	#DRIV7+1,R0		;CHECKED ALL?
7309	025364	003353				BGT	4\$;NOT YET
7310	025366	000207				RTS	PC		
7311									
7312									;ERROR MESSAGES
7313									
7314									.SBTTL ERROR MESSAGES
7315									
7316	025370	045522	041527	042440	EM11:	.ASCIZ	/RKWC EROR/		
7317	025376	047522	000122						
7318									
7319									
7320	025402	044523	020116	051511	EM12:	.ASCIZ	/SIN IS SET/		
7321	025410	051440	052105	000					
7322									
7323	025415	122	041113	020101	EM13:	.ASCIZ	/RKBA EROR/		
7324	025422	051105	051117	000					
7325									
7326	025427	122	042113	020101	EM16:	.ASCIZ	/RKDA WRONG AFTER 'SSE'/		
7327	025434	051127	047117	020107					
7328	025442	043101	042524	020122					
7329	025450	051447	042523	000047					
7330									
7331	025456	045522	051504	042440	EM21:	.ASCIZ	/RKDS EROR/		
7332	025464	047522	000122						
7333									
7334	025470	050104	020114	042523	EM30:	.ASCIZ	/DPL SET/		
7335	025476	000124							
7336									
7337	025500	051104	020125	042523	EM31:	.ASCIZ	/DRU SET/		
7338	025506	000124							
7339									
7340	025510	045522	032460	041040	EM32:	.ASCIZ	/RK05 BIT NOT SET/		
7341	025516	052111	047040	052117					
7342	025524	051440	052105	000					
7343									
7344	025531	104	054522	041040	EM33:	.ASCIZ	/DRY BIT NOT SET/		
7345	025536	052111	047040	052117					
7346	025544	051440	052105	000					
7347									
7348	025551	123	045517	042040	EM34:	.ASCIZ	/SOK DIDN'T SET/		
7349	025556	042111	023516	020124					
7350	025564	042523	000124						
7351									
7352	025570	042523	026503	047103	EM35:	.ASCIZ	/SEC-CNTR DIDN'T COUNT TO 0/		
7353	025576	051124	042040	042111					
7354	025604	023516	020124	047503					
7355	025612	047125	020124	047524					
7356	025620	030040	000						
7357									

7358	025623	123	041505	041455	EM36:	.ASCIZ	/SEC-CNTR DIDN'T INCRMNT/		
7359	025630	052116	020122	044504					
7360	025636	047104	052047	044440					
7361	025644	041516	046522	052116					
7362	025652	000							
7363									
7364	025653	123	041505	041455	EM37:	.ASCIZ	/SEC-COUNTR INCRMENTED WRONG/		
7365	025660	052517	052116	020122					
7366	025666	047111	051103	042515					
7367	025674	052116	042105	053440					
7368	025702	047522	043516	000					
7369									
7370	025707	104	042111	023516	EM40:	.ASCIZ	/DIDN'T GET SC=SA FOR THIS SECTR/		
7371	025714	020124	042507	020124					
7372	025722	041523	051475	020101					
7373	025730	047506	020122	044124					
7374	025736	051511	051440	041505					
7375	025744	051124	000						
7376									
7377	025747	105	047522	026522	EM41:	.ASCIZ	"ERROR-R/W/S RDY SHOULD BE SET"		
7378	025754	027522	027527	020123					
7379	025762	042122	020131	044123					
7380	025770	052517	042114	041040					
7381	025776	020105	042523	000124					
7382									
7383	026004	047125	054105	042520	EM43:	.ASCIZ	/UNEXPECTED RK11 INTERRUPT/		
7384	026012	052103	042105	051040					
7385	026020	030513	020061	047111					
7386	026026	042524	051122	050125					
7387	026034	000124							
7388									
7389	026036	047103	051124	020114	EM44:	.ASCIZ	/CNTRL RDY DIDN'T SET AFTER SEEK OR DR RESET/		
7390	026044	042122	020131	044504					
7391	026052	047104	052047	051440					
7392	026060	052105	040440	052106					
7393	026066	051105	051440	042505					
7394	026074	020113	051117	042040					
7395	026102	020122	042522	042523					
7396	026110	000124							
7397									
7398	026112	051105	020122	051117	EM45:	.ASCIZ	/ERR OR HE BIT SET ON SEEK OR DR RESET/		
7399	026120	044040	020105	044502					
7400	026126	020124	042523	020124					
7401	026134	047117	051440	042505					
7402	026142	020113	051117	042040					
7403	026150	020122	042522	042523					
7404	026156	000124							
7405									
7406	026160	045522	051105	041040	EM46:	.ASCIZ	/RKER BIT, ON SEEK OR DR RESET/		
7407	026166	052111	020054	047117					
7408	026174	051440	042505	020113					
7409	026202	051117	042040	020122					
7410	026210	042522	042523	000124					
7411									
7412	026216	045522	051503	041440	EM47:	.ASCIZ	/RKCS CHNGD AFTR FUNCTION WAS DONE/		
7413	026224	047110	042107	040440					

7494	027026	045522	040504	044440	EM63:	.ASCIZ /RKDA INCRMNTD WRONG ON RD OR RD FMT/
7495	027034	041516	046522	052116		
7496	027042	020104	051127	047117		
7497	027050	020107	047117	051040		
7498	027056	020104	051117	051040		
7499	027064	020104	046506	000124		
7500						
7501	027072	045522	041527	042040	EM64:	.ASCIZ /RKWC DIDN'T OVRFLO ON RD OR RD FMT/
7502	027100	042111	023516	020124		
7503	027106	053117	043122	047514		
7504	027114	047440	020116	042122		
7505	027122	047440	020122	042122		
7506	027130	043040	052115	000		
7507						
7508	027135	122	041113	020101	EM65:	.ASCIZ /RKBA INCRMNTD WRONG ON RD OR RD FMT/
7509	027142	047111	051103	047115		
7510	027150	042124	053440	047522		
7511	027156	043516	047440	020116		
7512	027164	042122	047440	020122		
7513	027172	042122	043040	052115		
7514	027200	000				
7515						
7516	027201	111	041516	051117	EM66:	.ASCIZ /INCORRECT HEADER FROM 'SECTOR'/
7517	027206	042522	052103	044040		
7518	027214	040505	042504	020122		
7519	027222	051106	046517	023440		
7520	027230	042523	052103	051117		
7521	027236	000047				
7522						
7523	027240	040504	040524	042440	EM67:	.ASCIZ /DATA ERROR/
7524	027246	051122	051117	000		
7525						
7526	027253	103	052116	046122	EM70:	.ASCIZ "CNTRL RDY DIDN'T SET ON RD/FMT STARTING FROM <DSK-ADRES>"
7527	027260	051040	054504	042040		
7528	027266	042111	023516	020124		
7529	027274	042523	020124	047117		
7530	027302	051040	027504	046506		
7531	027310	020124	052123	051101		
7532	027316	044524	043516	043040		
7533	027324	047522	020115	042074		
7534	027332	045523	040455	051104		
7535	027340	051505	000076			
7536						
7537	027344	042510	047440	020122	EM71:	.ASCIZ "HE OR ERR ON RD/FMT STARTING FROM <DSK-ADRES>"
7538	027352	051105	020122	047117		
7539	027360	051040	027504	046506		
7540	027366	020124	052123	051101		
7541	027374	044524	043516	043040		
7542	027402	047522	020115	042074		
7543	027410	045523	040455	051104		
7544	027416	051505	000076			
7545						
7546	027422	051127	047117	020107	EM72:	.ASCIZ /WRONG DRIVE ID IN RKDS AFTER SEEK/
7547	027430	051104	053111	020105		
7548	027436	042111	044440	020116		
7549	027444	045522	051504	040440		

7550	027452	052106	051105	051440		
7551	027460	042505	000113			
7552						
7553	027464	051110	053504	042522	EM73:	.ASCIZ /HRDWRE POLL-DRV ID BITS(13-15) SHLDBE CLR/
7554	027472	050040	046117	026514		
7555	027500	051104	020126	042111		
7556	027506	041040	052111	024123		
7557	027514	031461	030455	024465		
7558	027522	051440	046110	041104		
7559	027530	020105	046103	000122		
7560						
7561	027536	051110	053504	042522	EM74:	.ASCIZ /HRDWRE POLL-INTRUPTING DRV # NOT PRSNT/
7562	027544	050040	046117	026514		
7563	027552	047111	051124	050125		
7564	027560	044524	043516	042040		
7565	027566	044522	020126	020043		
7566	027574	047516	020124	051120		
7567	027602	047123	000124			
7568						
7569	027606	051104	053111	021440	EM75:	.ASCIZ /DRV # DIDN'T INTRUPT AFTER HRDWRE POLL/
7570	027614	042040	042111	023516		
7571	027622	020124	047111	051124		
7572	027630	050125	020124	043101		
7573	027636	042524	020122	051110		
7574	027644	053504	042522	050040		
7575	027652	046117	000114			
7576						
7577	027656	041523	020120	044504	EM76:	.ASCIZ /SCP DIDN'T SET AFTER SEEK WAS DONE/
7578	027664	047104	052047	051440		
7579	027672	052105	040440	052106		
7580	027700	051105	051440	042505		
7581	027708	020113	040527	020123		
7582	027714	047504	042516	000		
7583						
7584	027721	122	042113	020101	EM77:	.ASCIZ /RKDA CHANGD AFTER DRV RESET/
7585	027726	044103	047101	042107		
7586	027734	040440	052106	051105		
7587	027742	042040	044522	020126		
7588	027750	042522	042523	000124		
7589						
7590	027756	040504	040524	042440	EM100:	.ASCIZ /DATA EROR AT WORD#/
7591	027764	047522	020122	052101		
7592	027772	053440	051117	021504		
7593	030000	000				
7594						
7595	030001	103	052116	046122	EM101:	.ASCIZ /CNTRL RDY DIDN'T SET AFTER RD CHK/
7596	030006	051040	054504	042040		
7597	030014	042111	023516	020124		
7598	030022	042523	020124	043101		
7599	030030	042524	020122	042122		
7600	030036	041440	045510	000		
7601						
7602	030043	105	051122	047440	EM102:	.ASCIZ /ERR OR HE ON RD CHK/
7603	030050	020122	042510	047440		
7604	030056	020116	042122	041440		
7605	030064	045510	000			

7718	031100	020122	051447	050103		
7719	031106	000047				
7720						
7721	031110	045522	030461	042040	EM124:	.ASCIZ /RK11 DIDN'T INTRUPT AFTER RD DONE/
7722	031116	042111	023516	020124		
7723	031124	047111	051124	050125		
7724	031132	020124	043101	042524		
7725	031140	020122	042122	042040		
7726	031146	047117	000105			
7727						
7728	031152	047103	051124	020114	EM125:	.ASCIZ /CNTRL RESET DIDN'T CLR REGISTR/
7729	031160	042522	042523	020124		
7730	031166	044504	047104	052047		
7731	031174	041440	051114	051040		
7732	031202	043505	051511	051124		
7733	031210	000				
7734						
7735	031211	122	030513	020061	EM126:	.ASCIZ /RK11 DIDN'T INTRUPT AT CPU LEVEL/
7736	031216	044504	047104	052047		
7737	031224	044440	052116	052522		
7738	031232	052120	040440	020124		
7739	031240	050103	020125	042514		
7740	031246	042526	000114			
7741						
7742	031252	045522	030461	044440	EM127:	.ASCIZ /RK11 INTRUPTED AT WRONG CPU LEVEL/
7743	031260	052116	052522	052120		
7744	031266	042105	040440	020124		
7745	031274	051127	047117	020107		
7746	031302	050103	020125	042514		
7747	031310	042526	000114			
7748						
7749	031314	042447	051122	041040	EM130:	.ASCIZ /'ERR BIT' DIDN'T SET IN RKER/
7750	031322	052111	020047	044504		
7751	031330	047104	052047	051440		
7752	031336	052105	044440	020116		
7753	031344	045522	051105	000		
7754						
7755	031351	110	020105	051117	EM131:	.ASCIZ /HE OR ERR DIDN'T SET/
7756	031356	042440	051122	042040		
7757	031364	042111	023516	020124		
7758	031372	042523	000124			
7759						
7760	031376	045522	051105	042440	EM132:	.ASCIZ /RKER EROR/
7761	031404	047522	000122			
7762						
7763	031410	054116	020103	044502	EM133:	.ASCIZ /NXC BIT DIDN'T SET/
7764	031416	020124	044504	047104		
7765	031424	052047	051440	052105		
7766	031432	000				
7767						
7768	031433	122	030513	020061	EM134:	.ASCIZ /RK11 DIDN'T INTRUPT ON SOFT EROR/
7769	031440	044504	047104	052047		
7770	031446	044440	052116	052522		
7771	031454	052120	047440	020116		
7772	031462	047523	052106	042440		
7773	031470	047522	000122			

7774						
7775	031474	042515	020130	044502	EM135:	.ASCIZ /MEX BITS INCRMNTD WRONG-RKCS/
7776	031502	051524	044440	041516		
7777	031510	046522	052116	020104		
7778	031516	051127	047117	026507		
7779	031524	045522	051503	000		
7780						
7781	031531	127	051520	047040	EM137:	.ASCIZ /WPS NOT CLEAR/
7782	031536	052117	041440	042514		
7783	031544	051101	000			
7784						
7785	031547	104	052101	020101	EM140:	.ASCIZ /DATA EROR ON TRANSFER FROM DISK TO TTY/
7786	031554	051105	051117	047440		
7787	031562	020116	051124	047101		
7788	031570	043123	051105	043040		
7789	031576	047522	020115	044504		
7790	031604	045523	052040	020117		
7791	031612	052124	000131			
7792						
7793	031616	042047	044522	020126	EM141:	.ASCIZ /'DRIV #' PRESENT, BUT NOT INDICATED/
7794	031624	023443	050040	042522		
7795	031632	042523	052116	020054		
7796	031640	052502	020124	047516		
7797	031646	020124	047111	044504		
7798	031654	040503	042524	000104		
7799	031662	047040	020117	052502	EM142:	.ASCIZ / NO BUSY ON OTHER HALF OF RK-05F/
7800	031670	054523	047440	020116		
7801	031676	052117	042510	020122		
7802	031704	040510	043114	047440		
7803	031712	020106	045522	030055		
7804	031720	043065	000			
7805						
7806						
7807						
7808						
7809						
7810		031724				.EVEN
7811						
7812						.SBTTL ERROR DATA POINTERS
7813						
7814	031724	001116	001162	000000	DT1:	.WORD \$ERRPC,\$REG0,0
7815						
7816	031732	001116	001162	001164	DT2:	.WORD \$ERRPC,\$REG0,\$REG1,0
7817	031740	000000				
7818						
7819	031742	001116	001162	001164	DT20:	.WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,0
7820	031750	001166	001170	000000		
7821						
7822	031756	001116	000000		DT21:	.WORD \$ERRPC,0
7823						
7824	031762	001116	001162	001164	DT26:	.WORD \$ERRPC,\$REG0,\$REG1,\$REG2,0
7825	031770	001166	000000			
7826						
7827	031774	001116	001162	001164	DT54:	.WORD \$ERRPC,\$REG0,\$REG1,\$REG2,\$REG3,\$REG4,\$REG5,\$REG6,\$REG7,0
7828	032002	001166	001170	001172		
7829	032010	001174	001176	001200		

```

7830 032016 000000
7831
7832
7833
7834
7835
7836
7837 032020 020040 041520 020040 DH2: .ASCIZ / PC REGADD RECVD/
7838 032026 051040 043505 042101
7839 032034 020104 020040 051040
7840 032042 041505 042126 000
7841
7842 032047 040 050040 020103 DH4: .ASCIZ / PC EXPCT RECVD/
7843 032054 020040 042440 050130
7844 032062 052103 020040 051040
7845 032070 041505 042126 000
7846
7847 032075 040 050040 020103 DH5: .ASCIZ / PC RECVD/
7848 032102 020040 051040 041505
7849 032110 042126 000
7850
7851 032113 040 050040 020103 DH14: .ASCIZ / PC RKCS RKER RKWC/
7852 032120 020040 051040 041513
7853 032126 020123 020040 051040
7854 032134 042513 020122 020040
7855 032142 051040 053513 000103
7856
7857 032150 020040 041520 000 DH21: .ASCIZ / PC/
7858
7859 032155 040 050040 020103 DH30: .ASCIZ / PC RKCS RKER RKDS/
7860 032162 020040 020040 045522
7861 032170 051503 020040 020040
7862 032176 045522 051105 020040
7863 032204 020040 045522 051504
7864 032212 000
7865
7866 032213 040 050040 020103 DH34: .ASCIZ / PC RKDS/
7867 032220 020040 020040 045522
7868 032226 051504 000
7869
7870 032231 040 050040 020103 DH35: .ASCIZ / PC SEC-CNTR/
7871 032236 020040 045523 026503
7872 032244 047103 051124 000
7873
7874 032251 040 050040 020103 DH36: .ASCIZ / PC PRSNT NXT-CNT/
7875 032256 020040 020040 051120
7876 032264 047123 020124 047040
7877 032272 052130 041455 052116
7878 032300 000
7879
7880 032301 040 050040 020103 DH40: .ASCIZ / PC SECTOR RKDS/
7881 032306 020040 051440 041505
7882 032314 047524 020122 020040
7883 032322 045522 051504 000
7884
7885 032327 040 050040 020103 DH44: .ASCIZ / PC RKCS RKER RKDS RKDA/
    
```

```

7886 032334 020040 051040 041513
7887 032342 020123 020040 051040
7888 032350 042513 020122 020040
7889 032356 051040 042113 020123
7890 032364 020040 051040 042113
7891 032372 000101
7892
7893 032374 020040 041520 020040 DH54: .ASCIZ / PC RKCS RKER RKDS RKDA DRV#...CYL.<DSK-ADRS>.SUR..SEC/
7894 032402 020040 045522 051503
7895 032410 020040 020040 045522
7896 032416 051105 020040 020040
7897 032424 045522 051504 020040
7898 032432 020040 045522 040504
7899 032440 020040 042040 053124
7900 032446 027043 027056 041456
7901 032454 046131 036056 051504
7902 032462 026513 042101 051522
7903 032470 027076 052523 027122
7904 032476 051456 041505 000
7905
7906 032503 040 041520 020040 DH56: .ASCIZ / PC EXPC: DR# CYL SUR SEC REC: DR# CYL SUR SEC/
7907 032510 054105 041520 020072
7908 032516 051104 020043 020040
7909 032524 054503 020114 020040
7910 032532 020040 052523 020122
7911 032540 020040 051440 041505
7912 032546 020040 042522 053103
7913 032554 020072 051104 020043
7914 032562 020040 054503 020114
7915 032570 020040 020040 052523
7916 032576 020122 020040 020040
7917 032604 042523 000103
7918
7919 032610 020040 041520 020040 DH64: .ASCIZ / PC RKWC RKDA/
7920 032616 020040 045522 041527
7921 032624 020040 051040 042113
7922 032632 000101
7923
7924 032634 020040 041520 020040 DH66: .ASCIZ / PC SECTR EXPCT RECVD/
7925 032642 020040 042523 052103
7926 032650 020122 020040 054105
7927 032656 041520 020124 020040
7928 032664 042522 053103 000104
7929
7930 032672 020040 041520 020040 DH67: .ASCIZ / PC EXPCT RECVD DSK-ADRS/
7931 032700 020040 054105 041520
7932 032706 020124 020040 042522
7933 032714 053103 020104 042040
7934 032722 045523 040455 051104
7935 032730 000123
7936
7937 032732 020040 041520 020040 DH74: .ASCIZ / PC DRIV #/
7938 032740 020040 020040 051104
7939 032746 053111 021440 000
7940
7941 032753 040 050040 020103 DH100: .ASCIZ / PC WORD # EXPCT RECVD/
    
```


BADINT	004600	2108	2136#	4643	4688	4707	4718	4798	4806	4895	4904	5548		
BADTMO	004534	2043	2106	2117#	5657	5661								
BDAR	021074	6182	6187#											
BDA0	021056	6180#	7215											
BDA4	021066	6184#	7218											
BIT0	= 000001	993#	993	2006	2010	2270	5904							
BIT00	= 000001	983#	993											
BIT01	= 000002	982#	992											
BIT02	= 000004	981#	991											
BIT03	= 000010	980#	990											
BIT04	= 000020	979#	989											
BIT05	= 000040	978#	988											
BIT06	= 000100	977#	987											
BIT07	= 000200	976#	986											
BIT08	= 000400	975#	985	6625										
BIT09	= 001000	974#	984	6633										
BIT1	= 000002	992#												
BIT10	= 002000	973#												
BIT11	= 004000	972#	6640											
BIT12	= 010000	971#	6723											
BIT13	= 020000	970#	5908											
BIT14	= 040000	969#	6611											
BIT15	= 100000	968#	2001	2006	2010	6720	6722							
BIT2	= 000004	991#												
BIT3	= 000010	990#												
BIT4	= 000020	989#												
BIT5	= 000040	988#												
BIT6	= 000100	987#	6678											
BIT7	= 000200	986#												
BIT8	= 000400	985#												
BIT9	= 001000	984#												
BPTVEC	= 000014	1000#												
BRKDA0	= 104415	3697	6288	7216#										
BRKDA4	= 104416	2834	2930	3032	3160	3249	3370	3538	3670	3700	3819	4179	4265	4523
		5693	5709	6268	6291	7218#								
BTEDP	C20026	5820#	6731											
CH21	021242	6262	6265#											
CHKKCL	C21402	4987	5055	5124	5203	5364	5430	6340#						
CHKCRD	= 104412	2612	2672	3925	4334	4428	5243	5410	5470	5606	5759	7210#		
CHKDA	021262	2847	2942	3045	4206	6282#								
CHKDA1	021270	3175	3205	3395	3559	6284#								
CHKKECL	021356	4983	5051	5120	5199	5286	5360	5426	6329#					
CHKER	021342	2881	2957	3059	3295	4210	4808	6316#						
CHKHE	021234	2840	2936	3039	3256	4187	4527	6264#						
CHKHE1	021226	3166	3377	3552	3687	3933	6261#							
CHKWC	021316	2851	2947	3049	3278	3726	4202	4819	6302#					
CH.CRD	021760	6522#	7210											
CKSWR	= 104407	6610	6672	6695	7206#									
CNT.RD	= 104414	3967	4025	4043	4092	5021	5321	6393	7214#	7284	7286			
CNT.RE	= 104413	2310	2357	2394	2446	2531	2566	2598	2722	2776		2895	2996	3098
		3128	3221	3345	3452	3508	3637	3792	3906	4003	4120	4234	4308	4397
		4489	4596	4662	4748	4769	4847	4927	4973	5004	5041	5070	5110	5139
		5189	5226	5259	5276	5305	5350	5380	5425	5448	5513	5587	5667	5754
		5876	7212#	7275										
CN.RDY	022032	6561	6562#	7214										
CN.RST	022014	6559#	7212											

COUNT	001362	1195#	3410*	3414*	3520*	3533*	4516*	4519*	5221*	5264*				
CCOUNT1	001364	1136#	6390*	6405*										
CR	= 000015	908#	6842	6852										
CRETRN	021430	6266	6285	6303	6317	6330	6341	6346#						
CRLF	= 000200	909#	1884	6813	6852									
DDISP	= 177570	915#	1057	1855										
DDPCH	001410	1156#	1885	1905	1912*	1914	1916*	1920	1929	1941	2197	2199	2275	2284
DELAY	= 104417	2342	5155	5166	5584	7220#								
DELA.Y	021664	6456#	7220											
DH100	032753	1565	1663	7941#										
DH103	033010	1586	7947#											
DH104	033024	1593	7950#											
DH107	033050	1614	7955#											
DH117	033106	1551	1670	1677	1684	1698	1705	7961#						
DH126	033122	1719	1726	7964#										
DH130	033150	1733	7969#											
DH131	033207	1741	1762	7976#										
DH133	033235	1755	7981#											
DH14	032113	1248	1776	7851#										
DH140	033273	1760	7988#											
DH2	032020	1712	7837#											
DH21	032150	1346	7857#											
DH30	032155	1269	1276	1367	1381	1402	1452	1579	1628	1635	1691	7859#		
DH34	032213	1262	1283	1297	1332	1530	7866#							
DH35	032231	1304	7870#											
DH36	032251	1311	7874#											
DH4	032047	1255	1318	1339	1374	1395	1445	1459	1482	1523	1558	1600	1607	1642
		1649	1656	1748	1769	1805	7842#							
DH40	032301	1325	7880#											
DH44	032327	1241	1290	1353	1360	1388	1572	1621	1783	7885#				
DH5	032075	1438	7847#											
DH54	032374	1410	1420	1504	1514	7893#								
DH56	032503	1429	1466	7906#										
DH64	032610	1475	7919#											
DH66	032634	1489	7924#											
DH67	032672	1486	7930#											
DH74	032732	1537	1544	1798	7937#									
DISPLA	001142	1057#	1855*	1863*	6654*	6675*								
DISPRE	000174	1015#	1863											
DRESET	021504	2734	4674	4991	5260	5818	6390#	6428	7273	7291				
DRHOLD	025302	7276*	7285	7290	7294#									
DRIVAD	001350	1127#	2104*	2272*	2277	2289	2321	2367	2404	2416	2456	2541	2567	2610
		2669	2738	2818	2833	2913	2929	3015	3031	3068	3123	3236	3248	3262
		3332	3505	3620	3784	3920	4015	4161	4178	4254	4264	4326	4356	4419
		4454	4511	4522	4549	4673	4727	4730	4749	4785	4862	4939	5017	5086
		5222	5316	5407	5465	5530	5599	5681	5757	5823*	6264	6282	6360	6391
		6425	6716	6725	7276	7277	7279*	7281*	7282	7290*	7295*	7307*		

DRV7	001432	1177#	5859	7308															
DRVDDN	001352	1128#	2102*	5816*	5820														
DRVPR	001354	1131#	2101*	2268	2286*	6714													
DSWR =	177570	914#	1056	1854															
DT1	031724	1263	1284	1298	1305	1333	1439	1538	1545	1552	1587	1671	1678	1685					
		1699	1706	1799	7814#														
DT2	031732	1256	1312	1319	1326	1340	1375	1396	1446	1460	1476	1483	1524	1531					
		1559	1594	1601	1608	1643	1650	1657	1713	1720	1727	1742	1749	1763					
		1770	1806	7816#															
DT20	031742	1242	1291	1354	1361	1389	1573	1622	1784	1791	7815#								
DT21	031756	1347	7822#																
DT26	031762	1249	1270	1277	1368	1382	1403	1453	1490	1497	1566	1LJ0	1615	1629					
		1636	1664	1692	1734	1756	1777	7824#											
DT54	031774	1412	1422	1431	1468	1506	1516	7827#											
EM100	001370	1138#	3408*	3429*	3629*	3633*	3655	3706											
EMTVEC=	000030	1003#	1839*	1840*															
EM101	030001	1571	7595#																
EM102	030043	1578	7602#																
EM103	030067	1585	7607#																
EM104	030105	1592	7611#																
EM105	030156	1599	7619#																
EM106	030214	1606	7625#																
EM107	030245	1613	7631#																
EM11	025370	1804	7316#																
EM110	030306	1620	1775	7638#															
EM111	030351	1627	7645#																
EM112	030376	1634	7650#																
EM113	030417	1641	7654#																
EM114	030456	1648	7661#																
EM115	030515	1655	7668#																
EM116	030551	1662	7674#																
EM117	030624	1669	7683#																
EM12	025402	1240	7320#																
EM120	030671	1676	7691#																
EM121	030744	1683	7700#																
EM122	031002	1690	7706#																
EM123	031051	1697	7714#																
EM124	031110	1704	7721#																
EM125	031152	1711	7728#																
EM126	031211	1718	7735#																
EM127	031252	1725	7742#																
EM13	025415	1338	7323#																
EM130	031314	1732	7749#																
EM131	031351	1740	7755#																
EM132	031376	1747	7760#																
EM133	031410	1754	7763#																
EM134	031433	1761	7768#																
EM135	031474	1768	7775#																
EM137	031531	1782	7781#																
EM140	031547	1789	7785#																
EM141	031616	1797	7793#																
EM142	031662	1809	7799#																
EM16	025427	1254	7326#																
EM21	025456	1261	7331#																
EM30	025470	1268	7334#																

EM31	025500	1275	7337#																
EM32	025510	1282	7340#																
EM33	025531	1289	7344#																
EM34	025551	1296	7348#																
EM35	025570	1303	7352#																
EM36	025623	1310	7358#																
EM37	025653	1317	7364#																
EM40	025707	1324	7370#																
EM41	025747	1331	7377#																
EM43	026004	1345	2143	7383#															
EM44	026036	1352	7389#																
EM45	026112	1359	7398#																
EM46	026160	1366	7406#																
EM47	026216	1373	7412#																
EM50	026260	1380	7419#																
EM51	026307	1387	7424#																
EM52	026362	1394	7433#																
EM53	026407	1401	7438#																
EM54	026452	1408	7445#																
EM55	026544	1418	7456#																
EM56	026623	1428	7465#																
EM57	026662	1437	7472#																
EM60	026720	1444	7478#																
EM61	026757	1451	7485#																
EM62	027014	1458	7491#																
EM63	027026	1465	7494#																
EM64	027072	1474	7501#																
EM65	027135	1481	7508#																
EM66	027201	1488	7516#																
EM67	027240	1495	7523#																
EM70	027253	1247	1502	7526#															
EM71	027344	1512	7537#																
EM72	027422	1522	7546#																
EM73	027464	1529	7553#																
EM74	027536	1536	7561#																
EM75	027606	1543	7569#																
EM76	027656	1550	7577#																
EM77	027721	1557	7584#																
ERRVEC=	000004	996#	1852	1853*	1864*	1892	1893*	1901*	6616	6617*	6619*	6622*							
FHECK	025160	5801	7273#	7301															
FFLAG	001404	1152#	2291*	2303*	5799														
FTITLE	001346	1126#																	
GNS =	***** U	1014	1883	1926	1938	1947	1951	1966	1990	2122	2147	2301	6151	6435					
		6573	6581	7198	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212					
		7214	7216	7218	7220	7222	7224												
		1878	7204#																
GTSWR =	104406	4956	4963	4969	5030	5037	5092	5100	5106	5170	5186	5251	5272	5331					
GT2RG	021010	5346	5416	5422	5541	6132#													
GT3RG	021002	2335	2371	2701	2746	2823	2918	3020	3547	3681	3829	4167	4332	4341					
		4425	4435	4440	4709	6131#	6319												
GT4RG	020774	2222	2382	2407	2580	2626	2632												

	7001	7004	7072	7101	7169	7229	7245										
S.WRSU	1#	1008#	1850#														
TRMTRP	7190#																
TYPBIN	1#	1008#															
TYPDEC	1#	1008#	6084														
TYPNAM	1#	852#	1008#	1868													
TYPNUM	1#	1008#															
TYPOCS	1#	1008#															
TYPOCT	1#	1008#	6748	6772	7022												
TYPTXT	1#	1008#	1923	1936	1945	1949	1964	1987	2120	2145	2299	6148	6433	6571	6579		
SSCMRE	1029#	1068	1069	1070	1071	1072	1073	1074	1075	1076	1077						
SSCMTM	1029#																
SSESCA	1#	1008#															
SSNEWT	1#	1008#	2178	2253	2306	2353	2390	2410	2428	2525	2562	2588	2648	2711	2780		
	2872	2979	3105	3200	3309	3470	3595	3754	3886	3990	4111	4222	4301	4387	4475		
	4587	4651	4762	4836	4918	4995	5060	5132	5212	5297	5369	5435	5503	5569	5637		
	5732	5791	5806	5829													
SSSET	7190#	7199	7200	7201	7202	7204	7206	7207	7208	7210	7212	7214	7216	7218	7220		
	7222	7224															
SSSKIP	1#	1008#	2341	2381	2406	2419	2481	2503	2508	2515	2554	2579	2642	2705	2866		
	2970	3100	3300	3463	3733	3749	3867	4001	4100	4215	4274	4294	4376	4470	4541		
	4559	4584	4758	4830	4901	5163	5291	5489	5659	5717							
.EQUAT	1#	852#	898														
.HEADE	1#	852#	861														
.KT11	1#																
.SETUP	1#	852#	1814														
.SWRHI	1#	852#	873														
.SWRLD	852#																
.SACT1	1#	852#	1019														
.SAPT8	1#																
.SAPTH	1#																
.SAPTY	1#																
.SASTA	1#																
.SCATC	1#	852#	1008														
.SCMTA	1#	852#	1029														
.SDB2D	1#																
.SDB2O	1#																
.SDIV	1#																
.SEOP	1#	852#	6062														
.SERRD	1#																
.SERRT	1#	852#	6734														
.SMULT	1#																
.SPOWE	1#	852#	7227														
.SRAND	1#																
.SRDDE	1#	852#															
.SRDOC	1#																
.SREAD	1#	852#	6999														
.SR2AZ	1#																
.SSAVE	1#																
.SSB2D	1#																
.SSB2O	1#																
.SSCOP	1#	852#	6595														
.SSIZE	1#																
.SSUPR	1#																
.STRAP	1#	852#	7167														
.STYPB	1#																

.STYPD	1#	852#	6853
.STYPE	1#	852#	6782
.STYPD	1#	852#	6921
.S40CA	1#		
.1170	1#		

. ABS. 034342 000

ERRORS DETECTED: 0

CZRKKF, CZRKKF, LST/CRF/SOL=CZRKKF.SML, CZRKKF.P11
 RUN-TIME: 22 31 1 SECONDS
 RUN-TIME RATIO: 392/55=7.0
 CORE USED: 34K (67 PAGES)