

TCAG DEC/X11 SYSTEM EXERCISER MODULE  
XTCAGO.P11 12-OCT-78 12:21

MACV11 30A(1052) 12-OCT-78 17:05 PAGE 2

SEQ 0C01

.REM --

IDENTIFICATION  
-----

PRODUCT CODE: AC-E685G-MC  
PRODUCT NAME: CXCAGO DEC/X11 TC11 MODULE  
DATE: SEPTEMBER 1978  
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSIDERED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE OR EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973, 1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT

TCA EXERCISES A TC11 DECTAPE CONTROL AND UP TO EIGHT (8) DECTAPE DRIVES. BASIC TEST SEQUENCE CONSISTS OF WRITING 1024 WORDS (4 BLOCKS) IN FORWARD DIRECTION, AND THEN CHECKING THE DATA. THE BASIC PASS IS COMPLETED USING A DIFFERENT DRIVE EACH TIME, UNTIL A SEARCH SEQUENCE. EACH SEARCH AND DATA TRANSFER OR DATA CHECK IS RETRIEVED UP TO A LIMIT AND THEN THE END OF TAPE IS REACHED, THEN THE READS DROPPED OR THAT BLOCK IS SKIPPED. WHEN THE END OF TAPE IS REACHED, THEN THE READS AND WRITES GO IN REVERSE UNTIL THE BEGINNING OF THE TAPE IS REACHED, ETC.

2. REQUIREMENTS

HARDWARE: TC11 DECTAPE CONTROL, AND ONE TUS6 DUAL DECTAPE TRANSPORT.

- 1. DECIMAL WORDS: 895
- 2. OCTAL WORDS: 1577
- 3. OCTAL BYTES: 3376

3. PASS DEFINITION

ONE PASS OF TCA MODULE CONSISTS OF 40 ITERATIONS OF BASIC TEST SEQUENCE, WHICH RESULTS IN:

160 BLOCKS WRITTEN, 40 BLOCKS READ.

4. EXECUTION TIME

TCA RUNNING ALONE, WITH ONE DECTAPE DRIVE, ON PDP-11/05 TAKES APPROXIMATELY 1 MINUTE.

5. CONFIGURATION REQUIREMENTS

DEFAULT PARAMETERS:

DEVADR: 177340, VECTOR: 214, BRI: 6, DEVCNT: 1, SRI: 0

REQUIRED PARAMETERS:

NONE

6. DEVICE/OPTION SETUP  
-----

- EACH DECTAPE DRIVE MUST BE:
- A. LOADED WITH A FORMATTED DECTAPE.
  - B. SET TO REMOTE.
  - C. WRITE ENABLED.

7. MODULE OPERATION  
-----

TEST SEQUENCE:

- A. SELECT A DRIVE. (ERROR AND MODULE DROPPED IF NONE AVAILABLE).
- B. WRITE 4 BLOCKS FWD (1024 WORDS).
- C. READ THE FIRST BLOCK WRITTEN (256 WORDS).
- D. CHECK DATA (256 WORDS).
- E. REPEAT A THROUGH D 40 TIMES FOR ONE PASS.

NOTES: TCA DOES NOT USE DRIVE 0 IF LOAD MEDIUM IS DECTAPE.

8. OPERATION OPTIONS  
-----

MODULE LOCATION "DVID1" MAY BE CHANGED TO TEST OTHER THAN A FULL  
COMPLEMENT OF DRIVES. "DVID1" BITS 0 THROUGH 7 ONLY APPLY. ONE BIT  
INDICATES A DRIVE. BIT0= DRIVE 0, ETC.

LOCATION "RLMT" CONTAINS A 2 TO INDICATE 3 RETRYS. THIS MAY BE CHANGED FROM  
0=NO RETRYS UP TO 377=256 RETRYS.

SRI IS A 0 CAUSING THE MODULE TO SKIP AN OPENING BLOCK AFTER THE RETRY LIMIT  
IS EXCEEDED. IF A 1 IS PUT IN BIT 0 THE DRIVE WILL BE DROPPED WHEN  
THE LIMIT IS EXCEEDED.

9. NON STANDARD PRINTOUTS  
-----

NONE. ALL PRINTOUTS HAVE STANDARD MEANINGS AS REPRESENTED IN  
DEC/X11 DOCUMENTATION.

THERE IS AN ERROR MSG FOR EVERY ERROR AND THERE ARE EXPLANATORY MESSAGES THAT COME  
WITH SOME BUT NOT ALL. THESE EXTRA MESSAGES ALSO INCLUDE THE FOLLOWING ENDING  
D<>R<VVV>  
WHERE X IS THE DRIVE NUMBER AND VVV IS THE FAILING BLOCK NUMBER.

```

TCAG DEC/X11 EXERCISER MODULE.
IDMODX <TCAG > 177340,214,6,0,0,40,10,RBUF,256,,1024.
MODULE 150000,TCAG,177340,214,6,0,0,40,10,RBUF,256,,1024.
TITLE TCAG DEC/X11 SYSTEM EXERCISER MODULE
DDXCOM VERSION 6 23-MAY-78
*****LIST BIN*****
000000* 041524 043501 040 BEGIN: ASCII /TCAG / ;MODULE NAME
000000* 000000 MODNAM: .BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
000005* 000000 XFLAG: .BYTE OPEN ;LIST DEVICE ADDR.
000006* 177340 ADDR: 177340+0 ;LIST DEVICE VECTOR.
000010* 000214 VECTOR: 214+0 ;1ST BR LEVEL.
000012* 300 BR1: .BYTE PRTV6+0 ;2ND BR LEVEL.
000013* 000000 BR2: .BYTE PRTV6+0 ;3RD BR LEVEL.
000014* 000000 DVID1: 0+1 ;DEVICE INDICATOR 1.
000016* 000000 SR1: OPEN ;SWITCH REGISTER 1.
000020* 000000 SR2: OPEN ;SWITCH REGISTER 2.
000022* 000000 SR3: OPEN ;SWITCH REGISTER 3.
000024* 000000 SR4: OPEN ;SWITCH REGISTER 4.
*****
000026* 150000 STAT: 150000 ;STATUS WORD.
000030* 000326 INIT: START ;MODULE START ADDR.
000032* 000252 SPOINT: MODSP ;MODULE STACK POINTER.
000034* 000000 PASCNT: 0 ;PASS COUNTER.
000036* 000050 ICONF: 40. ;# OF ITERATIONS PER PASS=40.
000040* 000000 ICOUNT: 0 ;# OF COUNT ITERATIONS
000042* 000000 SOFCNT: 0 ;LCC TO SAVE TCTAL SOFT ERRORS
000044* 000000 HRDCNT: 0 ;LCC TO COUNT ITERATIONS
000046* 000000 SDPAS: 0 ;LCC TO SAVE TCTAL HARD ERRORS
000050* 000000 HRDPAS: 0 ;LCC TO SAVE SOFT ERRORS PER PASS
000052* 000000 SYSCHT: 0 ;LCC TO SAVE HARD ERRORS PER PASS
000054* 000000 RANNUM: 0 ;# OF SYS ERRORS ACCUMULATED
000056* 000000 CONFIG: 0 ;#CLS RANDOM # WHEN RAND MACRC IS CALLED
000060* 000000 RES1: 0 ;RESERVED FOR MONITOR USE
000062* 000000 RES2: 0 ;RESERVED FOR MONITOR USE
000064* 000000 SVR0: OPEN ;LCC TO SAVE R0.
000066* 000000 SVR1: OPEN ;LCC TO SAVE R1.
000068* 000000 SVR2: OPEN ;LCC TO SAVE R2.
000070* 000000 SVR3: OPEN ;LCC TO SAVE R3.
000072* 000000 SVR4: OPEN ;LCC TO SAVE R4.
000074* 000000 SVR5: OPEN ;LCC TO SAVE R5.
000076* 000000 SVR6: OPEN ;LCC TO SAVE R6.
00100* 000000 CSRA: OPEN ;ADDR OF CURRENT CSR.
00102* 000000 SBADR: OPEN ;ADDR OF GOOD DATA CR.
00104* 000000 ACSR: OPEN ;CONTENTS OF CSR.
00106* 000000 WASADR: OPEN ;ADDR OF BAD DATA CR.
00110* 000000 ERRTYP: OPEN ;TYPE OF ERROR.
00112* 000000 ASS: OPEN ;EXPECTED DATA.
00114* 000000 AWAS: OPEN ;ACTUAL DATA.
00116* 000000 RSTRT: RESTRT ;RESTART ADDRESS AFTER END OF PASS
00118* 000000 WDTC: OPEN ;#CRDS TO MEMORY PER ITERATION
00120* 000000 WDFR: OPEN ;#CRDS FROM MEMORY PER ITERATION
00122* 000010 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
IDNUM: 10 ;MODULE IDENTIFICATION NUMBER=1C
    
```

```

000124* 002376* RBUFVA: RBUF ;READ BUFFER VIRTUAL ADDRESS
000126* 000000 RBUFA: OPEN ;READ BUFFER PHYSICAL ADDRESS
000130* 000000 RBUFEA: OPEN ;READ BUFFER EA BITS
000132* 000400 RBUFSZ: 256. ;SIZE OF THE READ BUFFER
000134* 000000 WBUFA: OPEN ;WRITE BUFFER PHYSICAL ADDRESS
000136* 000000 WBUFEA: OPEN ;WRITE BUFFER EA BITS
000140* 002000 WBUFRQ: 1024. ;WRITE BUFFER SIZE REQUESTED
000142* 000000 WBUFSZ: OPEN ;WRITE BUFFER SIZE AVAILABLE
000144* 000000 CDERRC: OPEN ;DATA/DATCK ERROR COUNT
000146* 000000 CDWRC: OPEN ;DATA/DATCK WRC COUNT
000150* 000000 FREE: OPEN ;RESERVED FOR FUTURE USE.
-REPT SPSIZ ;MODULE STACK STARTS HERE.
-MLIST 0
-WORD 0
-LIST
-ENDR
000252* MODSP:
*****
    
```

```

222      C10000      ILO=BIT12      ;ILLEGAL OPERATION
223      C04000      SELE=BIT11     ;SELECTION ERROR
224      C00100      IE=BIT6       ;INTERRUPT TRABLE
225      C02000      RM=BIT10      ;BLOCK MISSED
226      C01000      DIRM=BIT9     ;DATA MISSED
227      C04000      REV=BIT11     ;FOR REVERSE DIRECTION
228      000257      INTSM: - BYTE  OPEN ;INTERRUPT SWITCH OFF SEARCH CN=DATA
229      000254      DIRIND: - BYTE  OPEN ;# OF TIMES REVERSED DIRECTION WHILE SEARCHING
230      000254      FLAG: - BYTE  OPEN  ;DIRECTION INDICATOR TO SHOW WHICH DIR. FOR DATA XFER C=
231      000257      DRTRVC: - BYTE  OPEN ;SET TO SHOW TAPE OVERFLOWED INTO END REGION
232      000257      SRTRYC: - BYTE  OPEN ;**DATA RETRY COUNTER
233      000257      SRTRYC: - BYTE  OPEN ;**SEARCH RETRY COUNTER
234      000260      000002      ;**RETRY LIMIT
235      000264      000000      ;TEMP LOCATION FOR NEXT COMMAND DURING SEARCH
236      000266      000000      ;TEMP LOCATION FOR TCBA VALUE
237      000270      000000      ;ADDR OF CONTROL AND STATUS REG
238      000274      000000      ;" " COMMAND REGISTER
239      000276      000000      ;" " WORD COUNT REG
240      000300      000000      ;" " BUS ADDRESS REG
241      000304      000000      ;" " DATA REGISTER
242      000306      000000      ;LCC TO SAVE CONTENTS OF TCWC
243      000310      000000      ;" " TCBA
244      000314      000000      ;A BIT /DEVICE LIST OF DRIVES TO BE EXERSIZED
245      000316      000000      ;HOLD EXTENDED ADDRESS BITS
246      000320      000000      ;WRITE BUFFER COUNT (2'S COMP)
247      000324      000000      ;READ DTC
248      000324      000000      ;R1 SAVE LOC.

```

```

254      ;MODULE CODE STARTS HERE.
255
256      000326      012767      C00400      177560      START:  MOV     #256,WDTO      ;256 WORDS TC MEV PER ITERATION
257      000334      012767      C07900      177584      MOV     #1024,WBFR      ;1024 WORDS FROM MEV PER ITERATION
258      000334      012767      C00001      177590      MOV     #17,INTR       ;INTERRUPTS PER ITERATION
259      000335      016705      177432      MOV     ADDR,R5        ;GET DEVICE ADDR.
260      000335      010567      177712      MOV     R5,TCST       ;SAVE IT
261      000336      010567      177512      TST    (R5)+         ;GET COMMAND REGISTER ADDRESS
262      000336      010567      177702      MOV     R5,CSRA       ;LOAD ADDRESS OF COMMAND REG.
263      000336      010567      177702      MOV     R5,TCCTP      ;PUT THIS ADDRESS IN MY POINTER FOR TC COMMANDS
264      000337      005725      177676      TST    (R5)+         ;MAKE ADDRESS OF WORD COUNT REG
265      000337      005725      177676      MOV     R5,TCWC       ;PUT IT THERE
266      000400      005725      177672      MOV     R5,TCBA       ;MAKE ADDRESS OF BUS ADDRESS REG
267      000400      005725      177672      TST    (R5)+         ;PUT IT THERE
268      000400      005725      177666      MOV     R5,TCDT       ;MAKE ADDRESS OF DATA REG
269      000400      005725      177370      TST    (R5)+         ;PUT IT THERE
270      000410      016700      177370      MOV     WCN1,RO       ;LCCD TC11 VECTOR.
271      000420      012720      C01120      MOV     VECTOR,RO     ;LCCD TC11 VECTOR.
272      000420      016720      177362      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
273      000420      016720      177362      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
274      000430      016767      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
275      000436      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
276      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
277      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
278      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
279      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
280      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
281      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
282      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
283      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
284      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
285      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
286      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
287      000440      005067      177652      MOV     WCN1,RO     ;LCCD TC11 VECTOR.
288      000504      104415      C00000      000124      RESTRT: GETPAS,BEGIN,RBUFVA ;GET PHYSICAL ADDRESS FROM 16-BIT RBUFVA
289      000504      104415      C00000      000124      MOV     RBUFVSZ,WCN1 ;SAVE READ BUFFER SIZE
290      000520      005467      177572      NEG    WCN1          ;GET THE 2'S COMPLEMENT
291      000520      005467      177572      TST    BLOCK        ;GET THE 2'S COMPLEMENT
292      000524      005767      177540      BNE   SEGB         ;IS THIS A RESTART OR START?
293      000530      001004      000010      177514      MOV     WCN1,DIRIND ;BRANCH IF RESTART
294      000532      017767      177514      MOV     WCN1,DIRIND ;START IN REVERSE PUT
295      000540      000453      000010      177514      BR     BR           ;THIS JMP PUTS IT INTO FORWARD AND INSURES ALL CCDE IS
296      000542      000453      000010      177514      BR     BR           ;RIGHT FOR THIS DIRECTION
297
298      000542      104414      000000      177540      SEGB:  GMBUFS, BEGIN ;GET WRITE BUFFER INFORMATION
299      000546      016767      177370      MOV     WCN1,WCN1    ;SAVE WRITE BUFFER SIZE
300      000546      005467      177370      NEG    WCN1          ;GET THE 2'S COMPLEMENT
301      000560      062767      000004      177502      STEP:  ADD     #4,BLOCK   ;STEP 4 BLOCKS (1024 WORDS)
302      000560      062767      001101      177474      CMP    #577,PLCK    ;LEGAL BLOCK NUMBER ?
303      000566      027677      000000      177466      CMP    BLOCK,#0     ;BRANCH IF BLOCK # IS TOO BIG
304      000576      026727      177466      000000      CMP    BLOCK,#0     ;BY CHANGING THIS #C WHICH IS THE DEFAULT
305      ;LOWER BLOCK #, AND THE #577 TWO INSTRUCTIONS UP, #C IS THE DEFAULT UPPER
306      ;BLOCK LIMIT, YOU CAN FORCE THE DECAPES TO STAY BETWEEN ANY TWO BLOCK NUMBERS YOU DESIR
307      BMI   GOBK      ;BRANCH IF BLOCK # IS TOO SMALL
308
309      000604      100431      001302      X1:    JSR    PC,SEQDRV ;SELECT SEQUENTIAL DRIVE.

```

310 000612\* 105067 177441  
 311 000616\* 105067 177434  
 312 000622\* 004767 000130  
 313 000626\* 000407  
 315

WRITE: CLRBB SRTVRC ;\*\*CLEAR SEARCH RETRY COUNT  
 CLRBB DRTVRC ;\*\*CLEAR DATA RETRY COUNT  
 JSR PC,WDATAF ;WRITE BLOCK FORWARD.  
 BR SECC ;ERROR RETURN.

316 000630\* 004767 000154  
 317 000634\* 000404  
 318 000638\* 104412 000000 000126\*  
 319 000644\* 000646\*  
 320 000646\* 104413 000000\*  
 321  
 322  
 323 000652\* 132767 000001 177375  
 324 000660\* 001730  
 325 000662\* 142767 000001 177365  
 326  
 327  
 328  
 329  
 330  
 331  
 332 000670\* 105767 177360  
 333 000674\* 010104  
 334 000676\* 112767 000010 177350  
 335 000704\* 012767 177774 177650  
 336 000712\* 005067 001034  
 337 000716\* 012767 000240 001022  
 338 000724\* 007706  
 339 000726\* 105067 177322  
 340 000732\* 012767 000004 177622  
 341 000740\* 012767 001101 001004  
 342 000746\* 012767 005400 000772  
 343 000754\* 000672  
 344  
 345  
 346  
 347  
 348  
 349  
 350 000756\* 112767 000115 177300  
 351 000764\* 016767 177144 177274  
 352 000772\* 016777 177316 177276  
 353 001000\* 016767 177132 177304  
 354 001006\* 000414  
 355  
 356  
 357  
 358 001010\* 112767 000105 177246  
 359 001016\* 016767 177104 177242  
 360 001024\* 016777 177266 177244  
 360 001032\* 016767 177072 177252

READ: JSR PC,WDATAF ; YES, READ ELCK FORWARD  
 ER SECC ; ERROR RETURN.  
 CDATAF,BEGIN,RBUFFA ; REQUEST FOR MONITOR TO CHECK DATA  
 +2 ; IF ERROR, CONTINUE  
 SECC: ENDITS,BEGIN ; SIGNAL END OF ITERATION.  
 ; MONITOR SHALL TEST END OF PASS  
 BITR #BIT0,FLAG ; NO, END OF TAPE ?  
 REQ SECC ; NO, CONTINUE  
 BICB #BIT0,FLAG ; YES, CLEAR FLAG AND DRCP INTO CCRK  
 ; SUB TO REVERSE DIRECTION OF TAPE MOTION. THIS IS DONE BY CHANGING THE VALUE OF  
 ; MANY COUNTING AND LIMIT CONSTANTS AND 1 INSTRUCTION WHICH IS EITHER A NCP  
 ; OR A NEGATE.  
 GOBK: TSTB DIRIND ; WHICH WAY WE GOING NOW?  
 SNE BACK ; SET IF BACKWARD  
 MOV #BIT3,DIRIND ; MUST GO INTO REVERSE  
 MOV #-4,STEP+2 ; DEC BY 4 CURRENT BLOCK #  
 CLR R0CM+8 ; CHANGE MAX ELCK# TO 0  
 MOV #240,PAYBE ; CHANGE SENSE OF SUBTRACTION  
 BR SECC  
 BACK: CLR DIRIND ; MUST GO FORWARD  
 MOV #4,STEP+2 ; INC BLOCK # BY 4  
 MOV #577,R0CM+8 ; CHANGE MAX ELCK # TO 577  
 MOV #540,PAYBE ; PUTS A NEGATE INST. IN PLACE OF NCP  
 BR SECC  
 ; WRITE DATA SUB ENTRY.  
 WDATAF: MOV #115,CMND ; PRESET COMMAND.  
 MOV RBUFFA,BATNP ; LOAD TEMPORARY STORAGE.  
 MOV WCNT1,CCWMC ; LOAD WORD COUNT.  
 MOV RBUFFA,EPBITS ; SAVE EXTENDED MEMORY BITS  
 BR COMMON  
 ; READ DATA SUB ENTRY.  
 RDATAF: MOV #105,CMND ; PRESET COMMAND.  
 MOV RBUFFA,BATNP ; LOAD TEMPORARY STORAGE  
 MOV WCNT2,CCWMC ; LOAD WORD COUNT.  
 MOV RBUFFA,EPBITS ; SAVE EXTENDED MEMORY BITS

```

361 001040 016777 177222 177232 COMMCN: MOV    BATMP,@TCBA
362 001046 042767 000060 177210 BIC    #60,CMND
363 001054 056767 177232 177202 BIC    #BITS,CMND ;SET UP EXT. MEM. BITS
364 001062 112767 000005 177163 MOV    #5,REVCNT ;SET MAX REVERSE COUNT.
365 001074 112767 000103 177160 CLR    INTSW ;SET INT SWITCH TO SEARCH.
366 001074 112767 000103 177160 MOV    #13,UNIT ;SET UP SEARCH COMMAND.
367 001102 156767 177146 177153 BISR   DIRIND,UNIT+1 ;SET UP SEARCH SAME DIR AS XFR.
368 001110 016777 177146 177153 MOV    UNIT,@TCMM ;ISSUE IT
369 001116 104400 000000 177156 EXITS, BEGIN ;EXIT TO MCNTR. MODULE WAIT FOR INTERRUPT.
370
371
372 001122 105767 177124 ;TC11 INTERRUPTS HERE
373 001126 001146 DTINT: TSTB   INTSW ;DATA XFR INTERRUPT?
374 BNE     XPRINT ;BR IF YES.
375
376 001130 005777 177140 TST    @TCMM ;NC. IN SEARCH MODE. ERROR?
377 001134 100556 DTR    DTR ;IF YES
378 001144 001516 177140 177124 CMP    @TCDT,BLCK ;BLOCK FOUND?
379 BGT    LARGER ;IF YES.
380 BGT    LARGER ;BR IF BLOCK FOUND IS LARGER.
381
382 001150 062777 000003 177124 LOWER: ADD    #3,@TCDT ;LCWER. BY 3 OR MORE?
383 001156 027767 177120 177104 CMP    @TCDT,BLCK ;FIND OUT.
384 BGT    CONT ;IF NOT.
385 001166 032777 004000 177100 BIT    #REV,@TCMM;YES. ;REV BIT SET?
386 001174 001017 BNE    DTREV ;BR IF YES TO TURN AROUND.
387
388 001176 016777 177060 177070 CONT:  MOV    UNIT,@TCMM ;ISSUE COMMAND.
389 001204 000002 RTI ;EXIT INTERRUPT.
390
391 001206 162777 000003 177066 LARGER: SUB   #3,@TCDT ;LARGER. BY 3 OR MORE?
392 001214 026777 177050 177060 CMP    @TCDT,@TCDT ;IF NOT.
393 001222 003365 BGT    CONT ;IF NOT.
394 001232 001361 BIT    #REV,@TCMM ;CHECKING FND?
395 BNE    CONT ;IF NOT.
396
397 001234 062767 004000 177020 DTREV: ADD   #REV,UNIT ;COMPLIMENT DIRECTION.
398 001242 042767 010099 177012 BIC    #BIT1,UNIT ;CLEAR POSSIBLE CARRY INTO BIT 12
399 001254 001350 DEC    REVCNT ;EXHAUSTED REV ALLOWANCE?
400 001256 004767 BNE    CONT ;YES. STOP DECTAPE.
401 JSR    PC,STOP
402
403 001262 000004 000000 001270 ;IRQS,BEGIN,IS
404
405 001270 004767 000546 002164 1$: JSR    PC,NCH ;GC INSERT DRIVE AND BLOCK #
406 001302 012767 000004 176596 MSGNS,BEGIN,MP1 ;ASCII MESSAGE CALL WITH COMMON HEADER
407 ***** ;BLOCK NOT FOUND
408 ***** ;IF NOT
409 ***** ;BLOCK NOT FOUND
410 ***** ;BLOCK NOT FOUND
411 ***** ;EXCEEDED RETRY LIMIT ?
412 ***** ;BRANCH IF NC
  
```

```

412
413 001326 104403 000000 002172 DROP: MSGNS,BEGIN,MP2 ;ASCII MESSAGE CALL WITH COMMON HEADER
414 001334 005767 176456 TST    SRI ;IF DROP OR NOT TO DROP?
415 BNE    AO ;BRANCH IF YES
416 001340 001001 RTS    PC ;NE
417 001344 000207 MOV    UNIT+1,R1 ;YES
418 001344 116701 176713 BIC    #17770,R1 ;LEAVE ONLY DEVICE # BITS
419 001350 042701 177770 MOV    UNTAB(1),R1 ;GET PROPER BIT IN #0
420 001354 116101 002366 MOV    BIC    R1,USELCT ;CLEAR BIT IN USELCT TO DROP DRIVE
421 001360 040167 176724 MSGNS,BEGIN,MP3 ;ASCII MESSAGE CALL WITH COMMON HEADER
422 001364 104403 000000 002200 CAN    KEEP GOING
423 001372 000207 RTS    PC ;BUMP RETRY COUNT UP
424 001374 105267 INCB   SRTRYC ;BUMP RETRY COUNT UP
425 001400 000617 BR     COMMON ;GC BACK AND TRY AGAIN
426
427
428
429 001402 032777 004000 176664 SAME: BIT    #REV,@TCMM ;SAME. CHECK DIRECTION.
430 001410 001011 BNE    SRCHG ;BR IF IN REV.
431 001412 105767 176636 TSTB   DIRIND ;FD. WANT FND XFR?
432 001416 001267 BNE    CONT ;BR IF NOT.
433
434 001420 116767 176640 176634 XFR:  MOV    CMND,UNIT ;PRESET COMMAND.
435 001426 105167 176620 BR     INTSW ;SET INT SWITCH TO DATA XFR.
436 001432 000664 COMB   CONT ;SET UP SEARCH COMMAND.
437 001434 105767 176614 SRCHG: TSTB   DIRIND ;IN REV. REV XFR WANTED?
438 BNE    XFR ;BR IF YES.
439 001440 001367 BR     CONT ;BR IF NOT.
440 001442 000655 ;NC. CONTINUE SAME DIR.
  
```

```

441
442
443 001444 005777 176624 ;DATA XFR INTERRUPT SERVICED HERE.
444 001450 100410 ;XFRINT: TST @TCM ;ERROR?
445 001452 004767 000254 JSR DTR ;IF YES
446 JSR PC,STOP1 ;STOP DECTAPE.
447
448 001456 000004 000000 001464 * ;-----
449 ;PIRQS,BEGIN,XFRA ; QUEUE UP TC CONTINUE AT XFRA AND RTI
450 XFRA: ADD #2,(6) ;SET UP CK EXIT.
451 RTS #2 ;EXIT.
452
453 001472 005777 176574 DTR: TST @TCST ;END ZONE?
454 001476 100003 ;IF NCT, TROUBLE!
455 001500 105767 176546 TSTB INTSH ;IF SEARCH MCODE?
456 001504 001653 ;IF YES TC REVERSE.
457 001506 004767 000170 JSR PC,STOP ;NCT. STOP DECTAPE.
458
459 001512 000004 000000 001520 * ;-----
460 ;PIRQS,BEGIN,2$ ; QUEUE UP TC CONTINUE AT 2$ AND RTI
461 2$: JSR RS,ROCM ; WAS THERE RCCM ON TAPE FOR TRANSFER ?
462 RTS PC ; NO THEREFOR NCT REALLY AN ERROR
463 JSR PC,NOW ;TYPE DRIVE AND BLOCK #
464 BIT #M,ASTAT ;BLOCK MISSED?
465 BEQ #S ;
466 MSGNS,BEGIN,#P4 ;ASCII MESSAGE CALL WITH COMMON HEADER
467 BR #S ;
468 MOV #S,ERRTYF ;BLOCK MISSED CODE
469 MSGNS,BEGIN,#P4 ;ASCII MESSAGE CALL WITH COMMON HEADER
470 BR #S ;
471 BIT #DATM,ASTAT ;DATA LATE?
472 MOV #S,ERRTYF ;DATA LATE CCDE
473 BR #S ;CC REPORT
474 CLR #ERRTYF ;UNKNOWN ERROR
475 MOV #S,ERRDNUM ;SAVE ASTAT
476 ;*****
477 HRDRS,BEGIN,NULL ;DECTAPE ERROR
478 BIT #S,ERRDNUM ;
479 BEQ #SELE,DNUM ;SELECTION ERROR?
480 MSGNS,BEGIN,#P7 ;ASCII MESSAGE CALL WITH COMMON HEADER
481 MOV #S,ERRTYF ;SELECTION CODE
482 ;*****
483 HRDRS,BEGIN,NULL ;FATAL ERROR
484 ;*****
485 001652 000167 174666 JMP AO ;GIVE UP AND DROP THAT DRIVE
486 001656 126767 176376 JSR BTLMT,DRTRYC ;EXCEEDED RETRY LIMIT?
487 001664 001002 177434 BR #S ;BRANCH IF NC
488 001666 000167 177336 JMP DROP ;YES
489 001676 000167 177136 INCB DRTRYC ;BUMP RETRY COUNT
490 JMP COMMON ;
491
492 001702 017767 176366 176172 STOP: MOV @TCM,ACSR ;TCM CONTENTS TO ACSR.
493 001710 017767 176356 176166 MOV @TCST,ASTAT ;TCST CONTENTS TO ASTAT.
494 001724 017767 176350 176160 MOV @TCNC,TCNCS ;SAVE TCNC
495 001732 042777 176354 176154 MOV @TCB,TCBAS ;SAVE TCBA
496 001740 000207 176334 STOP1: BIC #116,@TCM ;STOP DECTAPE.
497 RTS PC ;EXIT.

```

```

497
498
499
500 001742 016700 176322 ROOM: MOV BLOCK,RO ; SAVE CURRENT BLOCK #
501 ;*****
502 MAYBE: NEG RO ;THIS INST IS CHANGED BY SUBROUTINE GCRK TC EITHER BE
503 ;A NEGATE RO OR A NEG, DEPENDINC ON
504 ;*****
505 001746 005400 ;*****
506 ;CAREFULL* ;THE DIRECTION THE TAPE IS MOVING
507
508 001750 012701 001101 MOV #577,#R1 ; LOAD MAX. NUMBER OF BLOCKS
509 001754 005002 CLR #2 ; ZERO REG. 2
510 001760 022701 000400 CMP #256,#R1 ; GET # OF BLOCKS LEFT ON TAPE
511 001764 003420 000400 BLE #45 ; MORE THAN 256 BLOCK LEFT ?
512 1$: ADD #256,#R2 ; YES
513 001766 062702 000400 DEC #1 ; GET TOTAL # OF WORDS LEFT
514 001772 005301 000400 DEC #1 ; ALL BLOCKS ADDED IN ?
515 001776 005702 000400 TST #2 ; NO, KEEP ADDING
516 002000 100404 176134 BMT #2 ; IS NUMBER OF WORDS LEFT ON TAPE NEG. ?
517 002006 100411 176134 TST #BUFSZ ; IS TRANSFER SIZE NEG. ?
518 002010 000403 176124 BR #3 ; YES
519 002012 005767 176124 TST #BUFSZ ; NO, GO CONTINUE
520 002016 100003 176116 CMP #5 ; IS TRANSFER SIZE PCS. ?
521 002020 020267 176116 BPL #5 ; YES
522 002024 002402 176116 BLT #5 ; WAS THERE ENOUGH ROOM ?
523 002026 005725 176116 TST (R5)+ ; NO, RETURN OK
524 002030 000205 000001 176215 RTS #RTO,FLAG ; YES, MUST BE A REAL ERROR
525 002032 152767 000001 176215 BIRSB ; RETURN AS REAL ERROR
526 002040 000205 176215 RTS #R5 ; SET OVERFLW FLAG
527 ; RETURN OK
528 ;-----
529
530
531 ; SUBR TO TYPE PRESENT DRIVE# AND BLOCK#
532 NOW: ;*****
533 ;*****
534
535 002042 104421 000000 000324 * BTODS,BEGIN,RISV,DNUM ;CONVERT RISV TO ASCII AND
536 002050 002360 000000 000324 * ;STORE AT DNUM
537 ;*****
538
539 002052 116767 000306 000247 * ;*****
540 ;MOV# DNUM+4,MSG6+3 ;PUT IN MSG
541 ;*****
542 ;*****
543 002060 104421 000000 000270 * BTODS,BEGIN,BLCK,DNUM ;CONVERT BLOCK TC ASCII AND
544 002066 002360 000000 000270 * ;STORE AT DNUM
545 ;*****
546 ;*****
547 002070 116767 000266 000234 * ;*****
548 ;MOV# DNUM+2,MSG6+6 ;PUT IN FIRST DIGIT OF MSG
549 002076 116767 000261 000227 * ;AD
550 002104 116767 000254 000222 * ;D
551 002112 000207 000254 000222 * ;DNUM+4,MSG6+8. ;ARD
552 RTS PC ;RETURN

```



```

550 002114 012702 000010
551 002114 012702 176200
552 002114 012702 176200
553 002126 042701 177770
554 002132 010167 176166
555 002139 036167 002366 176144
556 002146 005302
557 002150 001365
558 002150 104410 000000
559 002152 110167 176101
560 002162 000207
561
562
563 002164 002222
564 002166 002222
565 002170 177777
566 002177 002244
567 002177 002244
568 002177 002244
569 002200 002263
570 002200 002263
571 002207 002244
572 002208 177777
573 002208 102304
574 002210 002324
575 002211 177777
576 002211 002336
577 002216 177777
578 002220 177777
579 002222 020040 C46102 041517
580 002226 020113 C47516 020124
581 002230 047506 047125 050104
582 002244 020040 051040 052105
583 002255 054522 C46040 046511
584 002259 052111
585 002270 053111 020040 051104
586 002276 050117 042520 000104
587 002304 020040 041040 047514
588 002312 045503 051440 051511
589 002320 042523 000104
590 002324 042040 C20124 041040
591 002332 020040 C00040
592 002334 041505 044524 046105
593 002352 042440 C51122 047117
594 002360 000003
595 002366 001 002 004
596 002371 010 020 040
597 002374 100 200
598 002376 000400
599 003376
600 C00001

```

```

ROUTINE TO SEQUENTIALLY SELECT A DRIVE FOR TESTING.
SEQDRV: MOV #8,R2 ;DRIVE AVAILABLE?
;WILL CHECK 6 TIMES.
MOV R1,R1
1S: BNC #177770,R1 ;CLEAR JUNK BITS.
MOV R1,R1
BITB UNTAB(1),USELCT ;DRIVE AVAILABLE?
BNE ZS ;IF YES
BNE ZS ;CHECKED 6 TIMES?
BNE 1S ;IF NOT
ENDS,BEGIN ;INC DRIVE AVAILABLE
MOV R1,UNIT+1 ;SELECTED DRIVE # TC UNIT+1.
RTS PC ;EXIT.

MP1: MSG1 MSG1
MSG2 177777
MP2: MSG2 MSG2
MSG3 177777
MP3: MSG3 MSG3
MSG4 177777
MP4: MSG4 MSG4
MSG5 177777
MP7: MSG7 MSG7
MSG6 177777
MSG1: .ASCIZ ' BLOCK NOT FOUND'
MSG2: .ASCIZ ' RETRY LIMIT'
MSG3: .ASCIZ ' DRIVE DRCPPED'
MSG4: .ASCIZ ' BLOCK MISSED'
MSG6: .ASCIZ ' DT B '
MSG7: .ASCIZ ' SELECTION ERR'

DNUM: .EVEN 3
UNTAB: .BLKW 3 ;RESERVE 6 BYTES FOR BTOD
;BYTE BIT0,BIT1,BIT2,BIT3,BIT4,BIT5,BIT6,BIT7

RBUF: .BLKW 256.
.END

```

```

ACSR 000102R 192# 491*
ADDR 000006R 260# 260
ADDR22= 001000 221#
ASB 000106R 196#
ASTAT 000104R 194# 463 468 473 492*
AWAS 01 001344R 417# 419#
AO 001374R 411# 425#
BACK 000726R 333# 339#
BATMP 000268R 155# 155#
BEGIN 000000R 155# 155#
BIT0 = 000001 221# 221#
BIT1 = 002000 221# 221#
BIT10 = 002000 221# 221#
BIT11 = 004000 221# 221#
BIT12 = 010000 221# 221#
BIT13 = 020000 221# 221#
BIT14 = 040000 221# 221#
BIT15 = 100000 221# 221#
BIT2 = 000004 221# 221# 598
BIT3 = 000010 221# 221# 794
BIT4 = 000020 221# 221# 598
BIT5 = 000040 221# 221# 598
BIT6 = 000100 221# 221# 598
BIT7 = 000200 221# 221# 224
BIT8 = 000400 221# 221# 598
BIT9 = 001000 221# 221# 226
BLK1 000320R 253#
BLK2 000320R 253#
BLOCK 000270R 239# 276* 292 301* 302 304 377 382 391 500 543
BM = 002000 225# 463
BREAKS= 104407 221# 221#
BR1 00012R 160# 273
BR2 000013R 161#
BTODS = 104421 221# 221# 536 543
CDATAS= 104412 221# 221# 318
CDERCT 000144R 212#
CDWDCT 000146R 212#
CMND 000264R 237# 349* 357* 362* 363* 435
COMMON 001040R 353# 426
CONFIG 00056R 169#
CONS 001176R 189# 387# 392 394 399 433 437 440
CSRA 000100R 190# 263#
DATCKS= 104411 221# 221#
DATEX = 104400 221# 221#
DATA = 001000 226# 226#
DIRIND 000254R 250# 294* 332 334* 339* 367 432 438
DNUM 002360R 473# 477 536 539 543 546 547 548 597#
DROP 00026R 41# 487
DRTRVC 00026R 41# 311* 485 488*
DTER 001472R 376# 444 452#
DTINT 001122R 272# 372#
DTREV 001234R 385# 455 396#
DVIC1 000014R 162# 274
EABITS 000312R 248# 352* 360* 363

```



SVR6	000076R	189#															
SYSCNT	000052R	178#															
TCBA	000300R	243#	268*	361*	494												
TCBAS	000306R	246#	494*														
TCCM	000274R	241#	264*	368*	375*	384	387*	393	430	443	491	495*					
TCDT	000392R	244#	270*	377	381*	382	390*	391									
TCS1	000292R	240#	261*	452	492												
TCCM	000276R	242#	266*	351*	359*	493											
TCWCS	000304R	245#	493*														
TIPDF=	000072	221#															
UNIT	000262R	236#	366*	367*	368	387	396*	397*	419	435*	561*						
UNITAB	002366R	421	556	598#													
USELCT	000310R	247#	274*	286*	422*	556											
VECTOR	000010R	159#	271														
WASADR	000104R	193#															
WBUPFA	000136R	208#	352														
WBUPFA	000134R	207#	350														
WBUPRC	000140R	209#															
WBUPSZ	000142R	210#	299	517	520	522											
WCNT1	000314R	249#	299*	300*	351												
WCNT2	000316R	250#	290*	291*	359												
WDATAF	000756R	312#	349#														
WDPR	000116R	206#	258#														
WDTD	000114R	199#	257*														
WRITE	000622R	314#															
XFLAG	000005R	155#															
XFR	001420R	435#	439														
XFRA	001464R	447#	449#														
XPRINT	001444R	373#	443#														
X1	000606R	309#															
.	= 003376R	319	596#	597#	601#	602#											

. ABS. 000000 000  
 003376 001

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATFD: 0

XTCAGO,XTCAGO/SOL/CRF:SYM=DDXCOM,XTCAGO  
 RUN-TIME: 11.3 SECONDS  
 RUN-TIME RATIO: 15/3=4.1  
 CORE USED: 7K (15 PAGES)