

## MASTER INDEX

The following pages contain the XVM/RSX master index. This master index is a result of merging the indexes of all the document PARTs.

The format of the index entries is:

Topic, part no.-page no.

Example:

QJOB, V-2-29

Interpretation:

Page 2-29 of PART V discusses QJOB.

## INDEX

- Abbreviations for commands, VII-1-9
- ABORT, IV-2-2, VI-2-5, VI-3-11, VI-65, VI-9-6, VI-12-8, VI-13-8, VI-18-1, VIII-6-4
- ABORT command, VIII-6-4
- Aborting I/O for task, VI-2-5, VI-3-11, VI-6-5, VI-9-6, VI-12-8, VI-13-8
- Aborting task execution, IV-2-2
- ACD, TDV Function task, VII-24-1, VII-5-4, VIII-6-3
- ACI, TDV Function task, VII-24-1, VIII-5-2, VIII-6-3
- Active Task List (ATL), II-1-4, III-1-9, IV-2-2, IX-2-3
- Activating task, II-1-4
- Activating task execution, IV-2-57
- AD conversion, starting, VI-14-12 stopping, VI-14-13
- AD handler, requests, VI-14-1 task, VI-14-1
- ADCON, VI-14-4
- Adding a new device, IV-2-9
- Adding a task, IV-2-35
- Adding tasks, XII-5-1
- ADDIS, VI-14-5
- ADRMAP, VI-14-15
- ADRSET, VI-14-9
- ADSMAP, VI-14-14
- ADSSSET, VI-14-6
- ADSTOP, VI-14-13
- ADSTRT, VI-14-12
- ADV, IV-2-9
- Advanced task, construction, XI-1-1 development, II-4-2
- AF handler, requests, VI-15-1 task, VI-15-1
- ACF I/O functions, VI-15-2
- AFT, VI-1-2
- AI, VI-15-3
- Alias-execute option, V-2-18
- Allocate, VI-6-6
- Allocation of I/O buffers, XI-6-1, XI-6-2
- Allocation of space, X-2-3
- Altmode, IV-1-2, IV-2-38, IV-2-59, VII-1-8, VII-6-3, VII-6-9, XI-2-1, XI-3-2
- Altmode character, X-2-6
- Analog channels, reading sequence of, VI-15-3
- Analog output--A633 modules, VI-16-4
- Analog-to-digital converter I/O, VI-14-1 functions, VI-14-2
- ANY subroutine, X-2-15, X-3-6
- AO, VI-16-4
- API level, II-1-4
- API level light, II-1-4
- API lines, V-2-5
- Arguments, X-2-2
- Arrays, X-2-1, X-2-15 size of, X-2-2
- ASCII string, X-2-5
- ASCII to BCD conversion, VI-8-18
- ASCII to EBCDIC conversion, VI-8-19
- ASP, IV-2-12
- Assembler options, VII-3-2
- Assembling a MACRO program, VII-3-1
- Assembly parameters, III-B-1, III-C-1, X-D-1
- Assigning a partition, IV-2-12
- At Sign (@), IV-1-3, VII-1-9
- ATTACH, VI-2-6, VI-7-3, VI-18-2
- Attach Flag Table (AFT), VI-1-2, IX-4-1
- ATTACH macro, VI-B-4
- Attaching I/O device, VI-2-6
- Automatic flying capacitor scanner I/O, VI-15-1 functions, VI-15-2
- Automatic priority interrupt (API), V-2-4
- AUTORM, IV-2-32, IV-2-59, V-2-17, IX-2-8.1
- Auxiliary disk functions, VII-2-3
- Backarrow (+), VII-1-9, VII-7-3
- Backing up a system, IV-2-59
- Backslash (\), IV-1-3, VII-1-9
- Backspacing, files, VI-8-4 records, VI-8-5
- Bank-mode option, VII-6-7
- Basic Task Builder (BTK), VII-6-1, VII-6-18
- BATCH, VIII-1-1, VIII-6-2 load command, VIII-4-3 operator interaction, VIII-4-1 special commands, VIII-2-2, VIII-3-1 states, VIII-4-1, VIII-4-2 use, VIII-2-1
- Batch account file, display, VII-24-1, VIII-5-4, VIII-6-3 initialization, VII-24-1, VIII-5-2, VIII-6-3 organization, VIII-5-1
- Batch control for operator, IV-2-41
- Batch file editing, VII-5-1
- Batch job, queuing, V-2-29
- Batch job file, VIII-6-7 running, XII-3-4, XII-3-7 submission, VIII-2-1

INDEX (CONT.)

- Batch mode, VII-3-1
  - FORTTRAN, VII-2-1
  - MACRO Assembler, VII-3-1
  - processing, VII-13-1, VII-14-1, VII-15-1
- Batch processing, II-1-3, II-3-3, II-4-2, VIII-1-1
  - example, VIII-1-2
  - introduction, VIII-1-1
  - invoking, VIII-2-1
  - sequence sample, VIII-1-1
  - sources, III-B-15
  - terminating, VIII-2-3
- Batch Processor (BATCH), VIII-1-1, VIII-6-2
- Batch system, XII-3-6
  - errors, VIII-B-1
  - installation checklist, VIII-A-1
  - management, VIII-5-1
  - operations, VIII-6-1
  - organization, VIII-6-1
- Baud specification, IV-2-29
- Beam position, X-3-2
- Binary file,
  - TSK extension, IV-2-35
- Bit maps, VI-6-2
- BLANK subroutine, X-2-13
- BLINK, X-2-8
- Block-mode editing, VII-4-1
- Blocks,
  - system COMMON, III-1-2, III-1-13
- Bootstrap,
  - Warm-Start, IV-2-60
- Bootstrapping,
  - DOS, IV-2-26
  - RSX system, XII-4-1
- Boundaries of core, X-2-2
- Braces ({}), VII-1-10
- Breakpoints in a task, VII-22-1
- BSPFIL, VI-8-4
- BSPREC, VI-8-5
- BTK (Basic Task Builder), III-3-3
- Buffer allocation and deallocation, XI-6-2
- Buffer and partition size, VII-4-3
- Buffer preallocation, XI-6-1
- Buffers, IX-2-16, XI-4-2, XI-6-1
  - within a partition, XI-6-4
- BUILD, XII-3-1
  - preparing to run, XII-3-1
  - questions, XII-3-1
  - running, XII-3-1
  - termination, XII-3-4
- Building process, XII-1-1
- Building task for execution, VII-6-1
- Building,
  - XVM/DOS system, XII-2-1
  - XVM/RSX VLB, XII-3-4
- CAL,
  - dispatch routine, V-1-2
  - function code, V-1-2
  - instructions, V-1-1
  - service routines, V-1-2
- CAL parameter block (CPB), V-1-1, VI-2-3, VI-2-6, VI-2-25
- CALL DEFINE statement, VI-3-14
- CANCEL, IV-2-13, V-2-2
- CANCEL ALL command, VIII-4-7
- CANCEL command, VIII-4-7
- Cancelling mark-time requests, V-2-69
- Cancelling requests for a task, IV-2-13
- Cancelling task requests, V-2-2
- Card punch handler,
  - requests, VI-19-1
  - task, VI-19-1
- Card punch input/output, VI-19-1
  - functions, VI-19-1
- Card reader I/O, VI-10-1
  - functions, VI-10-1
- Carriage return IV-1-2, IV-2-38, VII-1-8, XI-2-1, XII-4-1
- CC handler,
  - requests, VI-17-1
  - task, VI-17-1
- CCLOSE routine, X-5-3
- CD handler,
  - requests, VI-10-1
  - task, VI-10-1
- CHAIN and EXECUTE programs, VII-6-4
- Changing device assignment, IV-2-51
- Character set, .SIXBT, V-C-1
- Characters, nonprinting, X-2-6
- Characters, upper/lower case, VII-1-10
- Checkout package, XII-3-3
  - running, XII-4-3
  - sources, III-B-30
- CINIT routine, X-5-3
- CIRCLE subroutine, X-2-16
  - example, X-2-19
- Clearing interrupt line, VI-2-12, VI-3-11, VI-7-4
- Clock, XII-4-1
- Clock handler, IX-2-3
- Clock Queue (CKQ), II-1-5, III-1-9, IV-1-13, IX-2-6
- CLOSE, VI-2-7, VI-3-12, VI-7-3, VI-12-7, VI-13-6, VI-18-2, VI-19-2
- CLOSE macro, VI-B-5
- Closing a file, VI-2-7, VI-3-12, VI-7-3, VI-12-7, VI-13-6, VI-19-2
- CNAME, X-2-2, X-2-4, X-2-5, X-3-4
- Code modification routines, X-4-1
- COMGET, VI-17-3
- Comma, IV-1-2
- Comma character, VII-7-2

INDEX (CONT.)

- Command,
  - abbreviations, VII-1-9
  - conventions, IV-1-3
  - input line, XI-2-1
  - syntax errors, SLIP, VII-5-16
- Command string terminators, VII-1-8
- Commands,
  - BATCH, special, VIII-2-2, VIII-3-1
  - MULTIACCESS Monitor, VII-1-2.1
  - OPR, VIII-4-1, VIII-4-3
- Comment, IV-1-3
- COMMON, IV-2-14
- COMMON blocks, II-1-5, VII-6-8, VII-6-10, VII-6-11
  - system, III-1-2, III-1-13, IV-2-46
- Common communicator I/O
  - functions, VI-17-1
- Comparing a record, VI-8-20
- Compiling a FORTRAN program, VII-2-1
- Compiler options, FORTRAN IV, VII-2-2
- COMPUT, VI-17-5
- Concepts, II-1-3
- Configuration procedures, XII-4-1
- CONNECT, V-2-4
- Connecting AD to task, VI-14-4
- Connecting buffer, VI-16-10
- Connecting to interrupt line, V-2-4
- Conserving space, IV-2-32
- Console dialogue, X-9-1
- Console listing, example, X-9-2
- CONSTRUCT, IV-2-15
- CONSTRUCT TDV Function task, VII-19-1
  - error messages, VII-19-2
- Construction of advanced tasks, XI-1-1
- Contact interrupt digital
  - input--W733 module, VI-16-9
- Contact sense/interrupt digital
  - input--W731, W733 modules, VI-16-7
- Control-character facilities, VII-1-2.1
- Control lines, VIII-2-2, VIII-6-7
- Control records, SLIP, VII-5-4
- Conventions,
  - directive, V-1-3
  - I/O handler construction, XI-4-1
  - MCR task construction, XI-2-1
  - TDV task construction, XI-3-1
- Conventions for TDV command, VII-1-8
- Conversion to XVM/RSX, VII-6-18
- COPY subroutine, X-2-6, X-3-2
- Core,
  - allocation, III-1-6
  - examining, IV-2-37
  - management, III-1-1
  - partitioned, II-1-5
  - reconfiguration, IV-2-45
  - sharing, V-2-53
  - size, III-A-1, XII-4-1
- Core boundaries, X-2-2
- Core locations,
  - examining, V-2-55
  - modifying, V-2-57
- Core partition, IV-1-1
  - availability, IV-2-2, VI-1-3
  - freeing, IV-2-37, V-2-67
- Core space,
  - exec-mode, III-1-14
  - permanent, III-1-11
  - semipermanent, III-1-13
  - type of, III-1-11
  - user-mode, III-1-11, III-1-16
- CPB word, V-4-1
- CREATE, VI-3-13
- Creating random-access file, VI-3-13
- CR03B handler,
  - operation, VI-10-8
- CR15 error messages, VI-10-3
- Cross disk system, XII-1-1, XII-3-2
  - building, XII-B-1
- CTDI, VI-16-9, VI-16-10
- CTRL/C, IV-1-1, VI-1-2, IV-2-14, IV-2-42, IV-2-70, VI-9-3, XI-2-1, XII-3-4
- CTRL/D, VII-3-6
- CTRL/P, VI-9-4
- CTRL/Q, VII-6-3
- CTRL/R, XII-3-4, XII-3-7
- CTRL/T, VI-9-4, VII-1-7, XI-3-2, VIII-6-2
- CTRL/U, VI-1-3, VII-1-9
- CTRL/X, VI-9-4
- CTRL/Y, IV-2-62.1, VI-9-4
- Current task pointer, IX-3-2
- DASH (dashed lines), X-2-8
- Data modes, VI-1-8
  - by device, VI-1-9
  - legal, VI-9-2
- Data records,
  - random-access file, VI-3-4
  - sequential-access file, VI-3-2
- DATE, IV-2-16, V-2-8, VII-11-1
  - entering, IV-2-31
- DCLOSE routine, X-5-3
- DEALLOCATE, VI-6-9
- Deallocation of buffers, XI-6-2
- Debugging,
  - on-line, IV-2-37
- Debugging with ODT, VII-22-2

INDEX (CONT.)

DEC026 character set, VI-10-7  
 DEC029 character set, VI-10-6  
 DECTape Directory List,  
   TDV Function task, VII-11-1  
   error messages, VII-11-2,  
   VII-11-3  
 DECTape handler, III-1-4  
 DECTape I/O, VI-7-1  
   functions, VI-7-2  
 Default node assignments,  
   III-1-11  
 Default priority of task,  
   VII-6-8  
 Default values, XII-3-7, XII-4-1  
 Deferred-execute option,  
   V-2-18.1  
 Defining terminal character-  
   istics, IV-2-29  
 DELETE, VI-2-9, VI-3-11  
 Delete character or line,  
   VII-1-9  
 DELETE FILE error messages,  
   VII-8-2  
 DELETE FILE, TDV Function task,  
   VII-8-1  
 DELETE macro, VI-B-5  
 DELETE routine, X-4-2  
 Deleting a task, IV-2-54  
 Deleting file name from  
   directory, VI-3-11  
 Deleting files, VI-2-9  
 Deletion, IV-1-3  
 Delimiter, IV-1-2  
 Delimiters, VII-7-3  
 DEQ, IV-2-17  
   list symbols, IV-2-17  
   listing abbreviations,  
   IV-2-18  
 Deque, II-1-4  
 Deque list, IX-1-1  
 DETACH, VI-2-11, VI-7-3,  
   VI-18-2  
 DETACH directive, XI-4-2  
 DETACH macro, VI-B-4  
 Device,  
   adding a, IV-2-9  
 Device assignment,  
   changing, IV-2-51  
 Devices, IV-2-10, IV-2-24  
   VI-1-5  
   I/O, VII-1-6  
 Devices and assignments, IV-2-23  
 Devices and assignments list,  
   IV-2-51  
 DFDI, VI-16-9, VI-16-12  
 DI, VI-16-7  
 Dialogue, TKB, VII-6-17  
 Differences between XVM/R SX  
   and RSX PLUS III, II-1-2  
 Digital output latching--M685,  
   M803, M805 modules, VI-16-6  
 Digital output, single shot--  
   M687 and M807 modules,  
   VI-16-5  
 DINIT routine, X-5-2  
 Directive errors, V-1-2  
 DIRECTORY LIST, TDV Function  
   task, VII-10-1  
   error messages VII-10-2,  
   VII-10-3  
 DISABLE, IV-2-25, V-2-10  
 Disabling a task, IV-2-25, V-2-10  
 Disabling file-oriented I/O,  
   IV-2-27  
 DISCONNECT, V-2-12, VI-2-12,  
   VI-3-11, VI-7-4  
 Disconnecting AD from task,  
   VI-14-5  
 Disconnecting buffer, VI-16-12  
 Disconnecting from an interrupt  
   line, V-2-12  
 Disk addresses, VI-4-1  
   RK, VI-4-1  
   RP, VI-5-1  
 Disk blocks, IV-2-54  
 Disk block number, VI-6-1  
 Disk,  
   configuration, II-2-4  
   directory, VII-10-1  
   support, II-2-3  
 Disk-to-disk editing, VII-4-3  
 Disk driver I/O, VI-6-1  
   functions, VI-6-4  
 Disk driver,  
   requests, VI-6-3  
   tasks, VI-6-1  
 Disk errors, VI-6-3  
 Disk file I/O, VI-3-1  
 Disk I/O buffers, III-1-7  
   size, III-1-7  
 Disk parameters, IX-3-4  
 Disk platters,  
   RK, VI-4-1  
   RP, VI-5-1  
 Disk registers,  
   examining, IV-2-37  
 Disk, task storage on, VII-19-1  
 Disk-UFD table, IV-2-27, IV-2-36  
 DISMOUNT, TDV Function task, VII-17-1  
   error messages, VII-17-1  
 Dismount tape, VII-7-4  
 Dismounting a disk, IV-2-27  
 Dismounting a disk, (logically),  
   VII-17-1  
 Dismounting tape, VI-8-12, VI-8-13  
 DISPAT partition, III-1-5  
 Dispatcher, MCR, IV-1-1  
 Display file, X-2-2, X-2-3  
 Display parameter settings, X-2-10  
 Documentation, II-4-1  
 DOL, VI-16-6  
 \$ command, VIII-3-7  
 -\$ command, VII-5-5  
 Done bit, IV-2-32  
 DOS, IV-2-26, VI-16-5  
 DOS batch job file,  
   generating, XII-3-1  
 Dots, XI-3-1, XI-4-1  
 DQRQ, VI-2-5  
 Driver call, VI-6-4  
 DSKAL macro, VI-B-1  
 DSKDAL macro, VI-B-2

INDEX (CONT.)

DSKGET, VI-B-2  
 DSKPUT macro, VI-B-2  
 DSM, IV-2-27  
 DSM, TDV Function task, VII-17-1  
 DT handler,  
     requests, VI-7-1  
     task, VI-7-1  
 DTC, IV-2-29  
 Dump mode, VII-3-6  
 DYLINK routine, X-6-2  
 Dynamic reconfiguration, II-1-5  
 DYSET-DYLINK, example, X-6-4  
 DYSET routine, X-6-1  
  
 Editing batch files, VII-5-1  
 Editing disk-to-disk, VII-4-3  
 Editor, VII-4-1  
     error messages, VII-4-3,  
         VII-4-4  
 \$EJECT command, VIII-3-6  
 Embedded subroutines, X-6-3  
 ENABLE, IV-2-25, IV-2-30,  
     V-2-14  
 Enabling file-oriented I/O,  
     IV-2-36  
 \$END command, VIII-3-8  
 END-OF-FILE, VII-5-14  
     SLIP, VII-5-5  
 End-of-file pointer, X-2-2  
 ENTER, VI-2-13, VI-3-10, VI-7-3,  
     VI-18-2  
 ENTER macro, VI-B-4  
 Entering register restore  
     routine, V-3-3  
 Entering register save routine,  
     V-3-2  
 Entering time and date, IV-2-31  
 Environment, II-1-1  
 EOT, VI-8-8  
 ERROR CLOSE, VI-3-16  
 Error codes for \*FILE routine,  
     VII-5-15  
 \$ERROR command, VIII-3-10  
 Error flags, MACRO Assembler,  
     VII-3-7  
 Error messages, IV-3-1, X-A-1,  
     XII-4-3  
     CONSTRUCT, VII-19-2  
     CR15, VI-10-2  
     DECTAPE DIRECTORY LIST,  
         VII-11-3  
     DELETE FILE, VII-8-1  
     DIRECTORY LIST, VII-10-3  
     DISMOUNT, VII-17-2  
     EDITOR, VII-4-3, VII-4-4  
     FORTRAN, VII-2-5  
     INSTALL, VII-13-3  
     MACRO Assembler, VII-3-9  
     MOUNT, VII-16-2  
     NEW DIRECTORY, VII-12-2  
     ODT, VII-22-10  
     OPR, VII-4-10, VIII-4-9  
     OTS, VII-2-15, VII-2-17  
     QUEUE, VII-21-4  
  
 Error messages (cont.)  
     REMOVE, VII-15-2  
     RENAME FILE, VII-9-2  
     REQUEST, VII-14-2  
     SLIP, VII-5-14  
     TDV, VII-7-5  
     TKB, VII-6-19  
     UC15, VI-10-5  
 Error recovery, VI-8-17  
     handler, VI-8-17  
     user, VI-8-17  
 Errors,  
     batch system, VIII-B-1  
     \$SLIP control record, VII-5-15  
     SLIP sequencing, VII-5-16  
     TKB recoverable, VII-6-20  
 Errors, directive, V-1-2  
 Establishing random links, VI-14-9  
 Establishing sequential links,  
     VI-14-6  
 ETIME, IV-2-31  
 Event variable, V-1-2  
     setting, V-2-24  
     waiting for, V-2-71  
 Event variables, V-4-1, VI-1-7,  
     VI-A-1  
     returned, V-4-3, VI-A-2  
     special meanings, VI-A-5  
 Examining core, IV-2-37  
 Examining core locations, V-2-55  
 Examining disk registers, IV-2-37  
 Example of batch processing,  
     VIII-1-2  
 Examples, VI-18-4  
     CIRCLE subroutine, X-2-19  
     console listing, X-9-2  
     DYSET-DYLINK, X-6-4  
     FORTRAN, X-9-6  
     four-square display, X-2-18  
     MACRO programming, X-7-6  
     PRAMTR settings, X-2-25  
     ROTATE subroutine, X-2-26  
     sine wave, X-2-20 through X-2-23  
     writing tablet, X-8-3  
 Exceeding time limit, VIII-4-8  
 EXEC mode, III-1-2, IV-2-2, XI-3-1  
     core space, III-1-14  
 EXECUTE, IV-2-32, V-2-16  
 Execute List (EXELH), III-1-9,  
     IX-2-8  
 Execution of Resident MCR,  
     IV-1-1  
 Executive-mode option, VII-6-7  
 Executive, II-1-3, II-3-2  
     placement, III-1-2  
     replacing XII-A-1  
     sources, III-B-28  
 EXELH, IV-2-32  
 EXIT, IV-2-2, V-2-19, VI-2-12,  
     VI-3-11, VI-7-4  
 EXIT command, VIII-4-7  
 Exit Processor, MULTIACCESS,  
     V-1-3  
 External links, VII-6-14  
 EXU.13, VII-6-13

INDEX (CONT.)

- F option, VII-7-3
- FAC (Fetch-A-Character), IV-1-2
- Fetch-A-Character (FAC)
  - subroutine, XI-2-1
- File,
  - creation date, VII-10-2
  - size, VII-10-2
  - transfer, VII-7-3, VII-7-4
- \*FILE errors, VII-5-14
- File name and extension,
  - VII-10-2
- File name format, X-2-2
- File name list, VII-6-13
- \*FILE records, VII-5-4
- \*FILE specification, SLIP,
  - VII-5-3
- Files, XI-1-2
- FIN, TDV Function task, VII-7-2
- FININS, IV-2-32, IX-2-8.1
- Fix, IV-2-34, V-2-22
- Fixing a task, V-2-22
  - in core, IV-2-34
- Flicker, X-2-9
- Floating point, XII-3-2, XII-3-6
- Floating-point exit register,
  - V-2-52
- Floating-point processor (FPP),
  - VII-2-1, VII-2-4
- FORCE command, VIII-4-7
- Form feeds, VII-7-3
- FORMAT, VI-8-6
- Format of information returned
  - by READ, VI-18-2
- FORTRAN,
  - error messages, VII-2-5
  - examples, VI-18-4, X-9-6
  - interface, VI-16-3
  - line numbers, VII-5-10
  - other versions, VII-2-3
  - program compilation, VII-2-1
- FORTRAN IV Compiler, II-3-3
  - options, VII-2-2
- FOU, TDV Functions task, VII-7-2
- Four-square display example,
  - X-2-18
- FPP system OTS error messages,
  - VII-2-17
- Free blocks, VII-11-1
- Free core, XI-6-2
- Freeing attached I/O device,
  - VI-2-11, VI-7-3
- Freeing a core partition, IV-2-73,
  - V-2-67
- Freeing storage, VI-6-9
- Front-End Interrupt Driver task
  - (VPVEC), XI-5-1
- FSPEOT, VI-8-8
- FSPFIL, VI-8-9
- Function of system directives,
  - V-1-1
- Function tasks, TDV, VII-1-2
- Functions,
  - task development, III-1-5
- GARBAGE COLLECTION, XI-6-3
- Generating DOS batch job file,
  - XII-3-1
- GET, VI-6-12, VI-7-5
- GET functions, X-7-3
- GETBLT routine, X-8-1
- GETPSH routine, X-5-5
- Getting on the air, X-9-1
- GO command, VIII-4-6
- GRAPH subroutine, X-2-11, X-3-5
- Graphics system, II-4-2
- Guidelines for advanced task
  - construction, XI-1-2
- Handler,
  - exit, VI-1-7
  - initialization, VI-1-6
  - recovery, VI-8-17
- Handler internal closing of file,
  - VI-3-16
- Hardware, II-1-3, X-1-2
  - expanded, II-2-2
  - minimum, II-2-1
  - interrupts, XI-4-2
  - registers, XI-1-2
- Hardware existence flags, IX-3-5.1
- Header word, XI-6-2
- HINF, VI-2-15, VI-3-10, VI-6-4,
  - VI-7-2, VI-8-3, VI-9-5,
  - VI-10-2, VI-11-2, VI-12-2,
  - VI-13-2, VI-14-2, VI-15-2,
  - VI-16-2, VI-17-2, VI-18-2,
  - VI-19-1, VIII-6-3
- HINF macro, VI-B-5
- Historical system information,
  - VII-23-2
- HLD, IV-2-43
- HOLD command, VIII-4-6
- Hollerith card code,
  - type 26 punch, VI-10-7
  - type 29 punch, VI-10-6
- Hollerith data statements,
  - X-2-5
- IFAC subroutine, XI-2-1
- IFAC (Initialize Fetch-A-Character), XI-1-2
- Image ALPHA, VI-11-1
- Image ASCII, VI-1-8
  - mode 3, VI-8-23, VI-8-27,
  - VI-9-8, VI-9-10, VI-12-6,
  - VI-13-5, VI-13-7
- Image binary, VI-1-8
  - mode 1, VI-8-22, VI-8-26,
  - VI-12-3, VI-13-4, VI-13-7
- IMAGE mode, VII-7-3
- Index register (XR), VII-6-7
- Initialize FORTRAN I/O tables,
  - VII-2-4

INDEX (CONT.)

- Initializing the account file, VIII-5-2, VIII-6-3
- Initializing floating-point exit register, V-2-52
- Initiating time slicing, IV-2-63
- Input lines, IV-1-2
- Input/output, VII-2-3
  - CONSTRUCT, VII-19-1
  - DECTAPE DIRECTORY LIST, TDV Function task, VII-11-2
  - DELETE FILE, VII-8-1
  - DIRECTORY LIST, TDV Function task, VII-10-2
  - DSM, VII-17-1
  - EDITOR, VII-4-2
  - FORTRAN IV, VII-2-4
  - INSTALL, TDV Function task, VII-13-2
  - MACRO Assembler, VII-3-5, VII-3-6
  - MOUNT, VII-16-1
  - QUEUE, VII-21-3
  - REMOVE, VII-15-1
  - RENAME FILE, TDV Function task, VII-9-2
  - REQUEST, VII-14-1
  - SLIP, VII-5-14
  - STATUS, VII-23-1
  - Task Builder, VII-6-4
  - TDV function tasks, VII-7-3
- Input/output operations, II-4-2
- Input/output routines, X-5-1
- INSERT, VII-5-6, VII-5-7
- Insertion records, SLIP, VII-5-4
- INSTALL, IV-2-35
- INSTALL, TDV Function task, VII-13-1
  - error messages, VII-13-3
- Installation checklist, batch system, VIII-A-1
- Installation Guide, II-4-2
- Installing a task on a user disk, IV-2-15
- Integer event variable (IEV), X-8-1
- INTENSITY, X-2-7
- INTENTRY, V-3-1, V-3-2
- Internal interrupt routine, XI-5-1
- Internal links, VII-6-14
- Interrupt line,
  - connecting to, V-2-4
  - disconnecting, V-2-12
- Interrupts, XI-1-2
- Interval ranges, IV-2-57, IV-2-61, IV-2-68, V-2-24, V-2-42, V-2-60
- INTEXT, V-3-1, V-3-3
- Introduction, IV-1-1, V-1-1, VI-1-1, VII-1-1, XII-1-1
  - to software capabilities, II-3-1
  - to XVM/RSX, II-1-1
- Invoking,
  - batch processing, VIII-2-1
  - construct, VII-19-1
  - core sharing, V-2-53
  - DECTAPE DIRECTORY LIST, VII-11-1
  - Invoking (cont.)
    - DIRECTORY LIST, VII-10-1
    - DISMOUNT, VII-17-1
    - FIN, DEC, FOU, LIS and TYPE, VII-7-2
    - FORTRAN IV Compiler, VII-2-1
    - INSTALL, VII-13-1
    - MACRO Assembler, VII-3-2
    - MOUNT, VII-16-1
    - NEW DECTAPE DIRECTORY LIST, VII-12-1
    - ODT, VII-22-2
    - QUEUE, VII-21-1
    - REMOVE, VII-15-1
    - REQUEST, VII-14-1
    - SLIP, VII-5-2
    - STATUS, VII-23-1
    - Task Builder, VII-6-2
    - Text Editor, VII-4-1
- I/O,
  - disabling file-oriented, IV-2-26
  - enabling file-oriented, IV-2-36
- I/O buffers, XI-1-2, XI-4-2, XI-6-1, XI-6-4
- I/O data modes, VI-1-8
- I/O device handler,
  - sources, III-B-18
  - tasks, III-1-4, III-1-13
- I/O device handler task, II-1-3, II-3-4, III-1-4, III-1-13, VI-1-4
  - example, XI-4-4
- I/O devices, VII-1-6
- I/O devices and codes, VI-2-17
- I/O functions, VI-2-1, VI-2-2, VIII-6-3
- I/O handler construction, XI-4-1
- I/O handler task priority, IV-2-4
- I/O handler tasks, reentrant routines for, IX-3-8
- I/O handlers, XII-3-3
- I/O request, III-1-9
  - processing, VI-1-7
  - queuing, VI-1-6
- I/O Rundown, IV-2-2, XI-4-2
- I/O Rundown Queue (IORDQ), III-1-9, IX-2-9
- I/O Rundown task and Queue, VI-1-3
- I/O tables, lists, and tasks, VI-1-1
- IOPS ASCII, VI-1-8
  - mode 2, VI-8-22, VI-8-26, VI-9-7, VI-9-9, VI-11-1, VI-12-5, VI-13-4, VI-13-7, VII-7-3
- IOPS binary, VI-1-8
  - mode 0, VI-8-22, VI-8-26, VI-12-3, VI-13-3, VI-13-7
  - modes, VI-18-3
- IOPS binary data mode, VII-7-3
- IORDQ, VI-1-3
- IORD, VI-1-4, VI-9-6



INDEX (CONT.)

- \$job command, VIII-3-1
- JOB LIST command, VIII-4-5
- Job processing, prevention of, VIII-4-7
- Job requests, removal of, VIII-4-8
- Job selection, VIII-6-5
- Job Startup Processor (JOB...), VIII-6-2
- Job Termination Processor (END...), VIII-6-2
  
- KILL command, VIII-4-8
  
- LABEL, VI-8-11
- Large Node Description List (LNDL), IX-2-12
- Level,
  - API, II-1-4
  - mainstream, II-1-4
  - task, II-1-4
- Library files, VII-6-13
- Library routines, VII-6-13
- Light pen, X-5-3
- LIGHT PEN ENABLE, X-2-8
- Line formats supported, VI-11-1
- Line printer handler, III-1-4
- Line printer I/O, VI-11-1
  - functions, VI-11-2
- LINE subroutine, X-2-4, X-3-3
- Line-by-line mode editing, VII-4-1
- LINK definitions, VII-6-14
- Linkages, VII-3-1
- Links and structures description, VII-6-13
- LIS, TDV Function task, VII-7-2
- List options, Task Builder, VII-6-4
- List system dequeues, IV-2-66
- Listheads, IX-2-8
- Listing output, XI-2-1
- Listing system dequeues, IV-2-17
- LOG, IV-1-3
- \$LOG command, VIII-3-5
- Logical unit number, XI-4-1
- Logical Unit Table (LUT), VI-1-1, XI-4-1
- Lowercase characters, VII-1-10
- LP handler,
  - requests, VI-11-2
  - task, VI-11-1
- LP11, XII-3-6
- LPOOL (Pool of Empty Large Nodes), IX-1-2
- LTORPB routine, X-5-3
- LUN, VI-1-1, VI-2-3
  - deassigning, IV-2-51
  - mapping, V-2-34, VI-2-3
- LUN assignments,
  - Editor, VII-4-2
  - FORTRAN IV, VII-2-3
  - MACRO Assembler, VII-3-5
  - TDV function tasks, VII-1-4
- LUN-0, VI-2-5
- LUN-2, IV-1-1, IV-1-3, IV-2-52
- LUN-3, IV-1-3, IV-2-14, IV-2-16, IV-2-42, IV-2-52, IV-2-70, V-1-3
- LUN-5, IV-2-35
- LUN-6, VIII-A-2
- LUN-7, VIII-A-2
- LUN-8, VIII-A-1
- LUN-10, VIII-5-3, VIII-5-4
- LUN-16, IV-2-17, IV-2-66, VIII-5-4
- LUNs, IV-2-23
  - number of, XII-3-3, XII-3-7
- LUN-UFD table, IV-2-27, IV-2-36
- LUT, IV-2-36, VI-1-1
  
- MACRO Assembler, II-3-3
  - error flags, VII-3-7
  - error messages, VII-3-9
  - other versions of, VII-3-6
- Macro definitions file, V-A-1, VI-B-1, VII-3-6
- MACRO program assembly, VII-3-1
- MACRO programming X-7-5
  - example, X-7-6
- Magtape handler, III-1-4
- Magtape I/O, VI-8-1
  - functions, VI-8-2
- Magtape operation, VII-7-4
- Main display file routines, X-3-1
- Mainstream level, II-1-4
- Mapped LUNs, V-2-35.1, VI-1-2
- Mapping random input parameters, VI-14-15
- Mapping sequential input parameters, VI-14-14
- MARK, V-2-24
- Master File Directory (MFD), IV-2-36, IV-2-53
- MCR, III-1-3
  - Dispatcher, IV-1-1
- MCR function task, IV-1-1, IV-2-1
  - example, XI-2-2
- MCR interaction, XI-2-1
- MCR OPR command (...OPR), VIII-6-3
- MCR (Monitor Console Routine) communications, IX-3-3
- MCR partition size, XII-4-2
- MCR request inhibit (MCRR1) flag, IV-1-2, XI-2-1
- MCR system communication, IV-1-2
- MCR task construction, XI-2-1
- MCR terminal, VI-9-3
- MCR timeout interval, XII-3-7
- MDALLO macro, VI-B-2
- MDDEAL macro, VI-B-3
- MDGET macro, VI-B-3
- MDPUT macro, VI-B-3
- Memory management facilities, II-1-1
  - extended, II-2-3
- Memory,
  - protection II-1-7, VII-6-7
  - relocation, II-1-7

INDEX (CONT.)

- Memory-protect bound,
  - raising, V-2-36
- Memory size, xii-3-2
- MFD, IV-2-36, IV-2-53, VI-3-1
- MISCO, III-1-4, III-1-12, III-1-13
- Miscellaneous,
  - partitions, III-1-4
  - sources, III-B-24
- mnemonics, X-C-1
- MNT, IV-2-36
- MNT, TDV Function task, VII-16-1
  - error messages, VII-16-1
- Modifying core locations, V-2-57
- Modifying VT-15 code, X-4-1
- Monitor Console Routine (MCR),
  - II-1-3, II-3-2, II-4-1, III-1-3
  - function sources, III-B-1
- Monitoring task progress, ODT, VII-22-6
- MORE command, VIII-4-9
- MOUNT, VI-8-12
- Mount tape, VII-7-4
- Mounting a disk, IV-2-36
- Mounting a disk logically, VII-16-1
- Mounting tape, VI-8-12
  - unlabeled, VI-8-13
- \$MSG command, VIII-3-3
- MT handler,
  - request, VI-8-1
  - task, VI-8-1
- MTGET, VI-8-14
- MTPUT, VI-8-16
- MULTIACCESS, II-1-2, VI-1-2, VII-1-1, XII-3-6
  - control-character facilities, VII-1-2.1
  - Exit Processor, V-1-3
  - Exit Queue (TDV.EQ), IX-2-26
  - Monitor, II-1-3, III-1-5
  - Monitor commands, VII-1-2.1
    - shutting down, IV-2-62.1
- Multiple batch jobs, VIII-6-7
- Multiprogramming, real-time, II-1-5
  
- N option, VII-7-3
- Name of MCR function task, XI-2-1
- NAME REGISTER, X-2-8
- Name task option VII-6-8
- Naming conventions, XI-1-2
- NEW DECTAPE DIRECTORY, TDV Function task, VII-12-1
  - error messages, VII-12-2
- No parity check, VII-7-3
- NODCNT, IV-2-59
- Node,
  - allocation, III-1-8
  - analysis, III-1-8
  - block size, IV-2-46
  - contents, IV-2-17
  - removal, IV-2-13
  - sizes, III-1-8
- Node, IX-1-1, IX-1-2, XI-1-2
  - decreasing, III-1-4
  - default assignment of, III-1-11
  - deletion, III-1-11
  - estimating number of, III-1-8, III-1-9
- Nonprinting characters, X-2-6
- Nonstandard display files, X-6-3
  
- Object-Time System (OTS) library routines, VII-2-1
- Obtaining exclusive use of device, VI-7-3
- ODT, VII-22-1, XII-3-6
  - commands, VII-22-2
  - error messages, VII-22-10
  - example, VII-22-6
  - monitoring task progress, VII-22-6
  - restrictions, VII-22-1
- OFF command, VIII-4-5
- OFFSET, X-2-8
- ON command, VIII-4-5
- On-line debugging, IV-2-37
- On-line task development, II-3-2, II-4-2
- OPEN, IV-2-37
  - line terminators, IV-2-38
- Open disk file, III-1-9
- Operator,
  - console, VIII-4-1
  - interaction with BATCH, VIII-4-1
- Opening file for input, VI-2-23, VI-3-10, VI-7-3
- Opening file for output, VI-2-13, VI-3-10, VI-7-3
- Operation of CR03B handler, VI-10-8
- OPERATOR, IV-2-41
- OPR,
  - commands, VIII-4-1, VIII-4-3
  - error messages, VIII-4-9, VIII-4-10
- Optional characters, VII-1-9
- Optional items, VII-1-10
- Options,
  - assembler, VII-3-2
  - SLIP, VII-5-3
  - \$SLIP, VII-5-2
- Organization of batch account file, VIII-5-1
- OTS, V-2-65
  - ASCII, VI-11-1
  - error messages, VII-2-15
  - error messages in FPP systems, VII-2-17
  - output, VII-2-4
- Overlay structure description, VII-6-15
- Overlays, III-1-7
- Overview of XVM/RSX system, II-4-1

INDEX (CONT.)

- Page eject, VII-7-4
- Page-mode option, VII-6-7
- Paper tape punch I/O, VI-13-1
  - functions, VI-13-1
- Paper tape reader I/O, VI-12-1
  - functions, VI-12-1
- Parameter input, MACRO
  - assembler, VII-3-6
- Parameters,
  - assembly, III-B-1
  - task building, III-B-1
- PARINF, V-2-27
- PARITY parameter, VI-9-2
- Parity error message suppression, VII-7-3
- Partition, IV-1-1
  - address, V-2-27
  - blocks, IX-2-13
  - description, VII-6-9
  - DISPAT, III-1-5
  - management, III-1-1
  - miscellaneous, III-1-4
  - size, V-2-27, VII-4-3, VII-6-7, VII-6-8, VII-6-9, XI-6-2, XII-4-2
  - reconfiguration, III-1-7
- Partition Block Description List (PBDL), III-1-8, III-1-9, IV-2-12, VII-6-9, IX-2-13, XI-6-2
- Partitioned core, II-1-5
- Partitions, IV-2-41, IV-2-46, IV-2-47
  - reconfiguring, IV-2-49
  - size, IV-2-49
  - user, III-1-7
- PASS1, PASS2, PASS3, VII-3-1
- Password, XII-2-1
- \$PAUSE command, VIII-3-4
- PAUSE statements, VII-2-4
- PBDL, III-1-8
- PDVL, VI-1-2, VI-4-1, VI-5-1
- Permanent core space, III-1-11
- Permanent system lists, III-1-8
- Phosphor damage, X-2-9
- Physical Device List (PDVL), III-1-9, IV-2-9, IV-2-27, IV-2-36, VI-1-2, IX-2-17, XI-4-2
- Picture flickering, X-2-9
- PIP, III-B-1
- PLOT routine, X-3-1, X-3-2
- Plotter, VI-18-1
- PNAME, X-2-3
- POINT subroutine, X-2-14, X-3-5
- POLLER, IV-2-59
- POOL, IX-1-2, IX-3-6
- Pool of empty nodes, VII-6-7, XI-1-2
- PP handler,
  - request, VI-13-1
  - task, VI-13-1
- PR handler,
  - request VI-12-1
  - task VI-12-1
- PRAMTR settings example, X-2-25
- PRAMTR subroutine, X-2-7, X-3-4
- PREAL, VI-2-19, VI-3-11
- PREALlocate I/O directive, XI-6-2
- Preallocating I/O buffers, VI-2-19, XI-6-1
  - space, VI-3-11
- Preconfigured system,
  - saving, XII-3-7
- Premature termination of MCR
  - function task, IV-1-2, IV-2-14
- Preparing to run BUILD, XII-3-1
- Printing COMMON block
  - definition, IV-2-14
- Printing control lines, VIII-6-7
- Printing current list of device units and LUNs, IV-2-23
- Printing partition definitions, IV-2-42
- Printing task descriptions, IV-2-70
- Priority, IV-2-35
  - calculation, VIII-6-5
  - changing, IV-2-12
  - default, VII-6-8
  - tests, VIII-6-6
  - time slicing, IV-2-63
- Priority of task, II-1-4
- Privileged mode, III-1-2
- PROCEED command, VIII-4-6
- Processing a directive, V-1-2
- Program interrupt (PI), V-2-4
- Prompting character (>), IV-1-1, IV-2-37
- Prompting symbol (>), II-1-4
- Protected mode, III-1-2
- Protection, memory, II-1-7
- PUP (Peripheral Utility Program), VII-1-1
- PUT, VI-6-16, VI-7-6
- PUT functions, X-7-1
- QJOB, V-2-29, VIII-6-2
- QUEUE,
  - I/O, V-2-34, VI-2-3
  - I/O directive, XI-4-1
- QUEUE, TDV Function task, VII-21-1, VIII-6-1
  - error messages, VII-21-3
- Queuing batch job, V-2-29
- Queuing I/O device requests, V-2-34
- Queuing requests for a device, VI-2-3
- \$QUIT command, VIII-3-9
- Radix default, IV-2-38
- RAISEB, V-2-36

INDEX (CONT.)

RAISEBound directive, XI-6-2  
 Raising memory-protect bound,  
     V-2-36  
 Random-access file, VI-3-1, VI-3-3  
 Random-access information, VII-10-2  
 Random links  
     establishing, VI-14-9  
 RASP SCOM words, IX-3-6  
 RBCD, VI-16-7  
 RBIN, VI-16-7  
 RCF, III-1-7, IV-2-45  
 RCP, III-1-7, IV-2-49  
 RDCOMP, VI-8-20  
 RDDI, VI-16-9, VI-16-11  
 READ, VI-2-20, VI-3-17, VI-7-3,  
     VI-8-22, VI-9-7, VI-10-3,  
     VI-12-3, VI-18-2, VIII-6-4  
 Read BCD, VI-16-7  
 Read binary, VI-16-7  
 READ macro, B-1  
 Read point, VI-16-8  
 Reading,  
     buffer, VI-16-11  
     from DEctape, VI-7-5  
     from disk, VI-6-12  
     from I/O device, VI-2-20  
     from tape into user's buffer,  
         VI-8-14  
     input into buffer, VI-3-17,  
         VI-7-3, VI-8-22, VI-9-7,  
         VI-10-3, VI-12-3  
     record, VI-8-20  
     sequence of analog channels,  
         VI-15-3  
     tape label, VI-8-11  
 REASSIGN, IV-2-11, IV-2-51  
 REASSIGN, MCR Function task, XI-4-2  
 Real-time multiprogramming, II-1-5  
 Reconfiguration,  
     dynamic, II-1-5  
     partition, III-1-7  
 Reconfiguring core layout, IV-2-45  
 Reconfiguring partitions, IV-2-49  
 Record,  
     comparing, VI-8-20  
     reading, VI-8-20  
 Recoverable TKB errors, VII-6-20  
 Reenabling task, IV-2-30, V-2-14  
 REENTRANT ROUTINES FOR I/O  
     HANDLER TASKS, IX-3-8  
 Reentrant system calls, IX-3-1  
 Reentrant system subrouines,  
     XI-6-3  
 Register address, IV-2-37  
 Register, V-B-1, XI-1-2  
 RELEASE command, VIII-4-6  
 Relocatable mode, III-1-2  
 Relocation, memory, II-1-7  
 Relocation routines, X-6-1  
 Remote stimulus, VI-9-4  
 Removal of nodes, IV-2-13  
 REMOVE, IV-2-25, IV-2-54  
 REMOVE, TDV Function task,  
     VII-15-1  
     error messages, VII-15-2  
 Remove-on-exit bit, IV-2-32  
 RENAME, VI-2-21  
 RENAME FILE, TDV Function task,  
     VII-9-1  
     error messages, VII-9-2  
 RENAME macro, VI-B-5  
 Renaming file, VI-2-21  
 REPLACE, VII-5-8  
 REPLACE WITH FILE, VII-5-9  
 Replacing RSX Executive, XII-A-1  
 REPLOT routine, X-4-2  
 REQUEST, IV-2-55, VI-2-37  
     faster response, IV-2-34  
     rejection, IV-2-25  
 REQUEST MAPPED, V-2-35.1  
 REQUEST system directive, IV-1-1  
 REQUEST, TDV Function task,  
     VII-14-1  
     error messages, VII-14-2  
 Requesting a task with mapped  
     LUNS, V-2-35.1  
 Requesting driver task  
     information, VI-6-4  
 Requesting handler task  
     information, VI-3-10,  
     VI-7-2, VI-9-5, VI-10-2,  
     VI-11-2, VI-12-2, VI-13-2,  
     VI-14-2, VI-15-2, VI-16-2,  
     VI-17-2, VI-19-1  
 Requesting I/O handler  
     information, VI-2-15, VI-8-3  
 Requesting task execution,  
     IV-2-55  
     from user disk, IV-2-32, V-2-16  
 Reserving storage, VI-6-6  
 Reschedule interval ranges,  
     V-2-24, V-2-42, V-2-60  
 Resident code definition,  
     VII-6-13  
 Resident MCR task, IV-1-1, IV-2-59  
     execution of, IV-1-1  
 RESIDENT MONITOR CONSOLE ROUTINE  
     (MCR), II-1-3, II-3-2  
 Resident task development (TDV),  
     II-1-3  
 Resident TDV Dispatcher,  
     VII-1-7  
 Restore operations, V-B-1  
 Restrictions, X-2-1  
 RESUME, IV-2-56, V-2-40  
 Resuming task execution, IV-2-56  
 Retrieving time and date, V-2-8  
 Returned event variables, V-4-3,  
     VI-A-2  
 Returning name of issuing task,  
     V-2-65  
 Returning partition address and  
     size, V-2-27  
 REWIND, VI-8-24  
 Rewinding tape, VI-8-24  
 RF disk handler, III-1-4  
 RF disk I/O, VI-3-1  
     functions, VI-3-9  
 RF handler,  
     requests, VI-3-8  
     structure, VI-3-7  
     Task, VI-3-1  
 RK disk handler, III-1-4  
 RK disk I/O, VI-4-1

INDEX (CONT.)

RK handler task, VI-4-1  
 ROTATE, X-2-8  
 ROTATE subroutine, X-2-16  
     example, X-2-26  
 RP disk handler, III-1-4  
 RP disk I/O, VI-5-1  
 RP handler task, VI-5-1  
 RSETPT routine, X-4-3  
 RSX devices, XI-4-3  
 RSX system lists, IX-2-2  
 RSX Task Builder (TKB), XII-3-2  
 RSXIMG, IV-2-59  
 Rubout, IV-1-3, VII-1-9  
 RUN, IV-2-57, V-2-42  
     faster response, IV-2-34  
     rejection, IV-2-25  
 Runing batch job file, XII-3-4,  
     XII-3-7  
 Running BUILD, XII-3-1

Sample batch processing sequence,  
     VIII-1-1  
 SAVE, IV-2-59  
 Save operations,  
     registers, V-B-1  
 SAVE-REMOVE-INSTALL system file,  
     IV-2-54, IV-2-60  
 SAVE-RESTORE option, X-2-7  
 Saving preconfigured system,  
     XII-3-7  
 SCALE (picture size), X-2-7  
 SCHEDULE, IV-2-61, V-2-7  
     faster response, IV-2-34  
     rejection, IV-2-25  
 SCHEDULE command, VIII-4-4, VIII-6-3  
 Scheduling,  
     task, II-1-3  
     task execution, IV-2-61, V-2-47  
 SCOM (System Communications  
     Area), IX-2-1, IX-3-1  
 Scope images, storage of, X-6-1  
 SEARCH AND INSERT, VII-5-10,  
     VII-5-11  
 SEARCH AND REPLACE, VII-5-12  
 SEARCH AND REPLACE WITH FILE,  
     VII-5-13  
 SEEK, VI-2-23, VI-3-10, VI-7-3  
 SEEK macro, VI-B-4  
 Semipermanent core space,  
     III-1-13  
 Separators, IV-1-3  
 Sequential-access file, VI-3-1,  
     VI-3-2  
 Sequential files transfer,  
     VII-7-1  
 Sequential links,  
     establishing, VI-14-6  
 Set system clock and calendar,  
     IV-2-31  
 SETJEA, V-2-52  
 SETPT routine, X-3-1, X-3-2  
 Setting and event variable,  
     V-2-24

Setting pointers, IV-1-2  
 SHARE, V-2-53  
 Shared address space (SAS),  
     VII-6-10, VII-6-11  
     external (ESAS), VII-6-11  
     internal (ISAS), VII-6-11  
 Shared COMMON block description,  
     VII-6-10, VII-6-11  
 SHUT, IV-2-62.1  
 Shutting down MULTIACCESS, IV-2-62.1  
 Sign default, IV-2-38  
 Significant event, II-1-4  
 Significant event declaration,  
     VI-14-3  
 Sine wave program example,  
     X-2-20, X-2-21, X-2-22  
 Sine wave program written for  
     single display file,  
     X-2-23  
 .SIXBT character set, V-C-1  
 Size,  
     core, III-A-1  
     disk I/O buffer III-1-8  
     node, III-1-8  
     user task, III-1-7  
 SIZE command, VII-4-3  
 SLICE, IV-2-63  
 SLIP, II-3-3, VII-5-1  
     command syntax errors,  
         VII-5-16  
     control records, VII-5-4  
     editing demonstration,  
         VII-5-16  
     error messages, VII-5-14  
     options, VII-5-3  
     sequencing errors, VII-5-16  
 \$SLIP,  
     control record errors, VII-5-15  
     options, VII-5-2  
 Small Node Description List  
     (SNDL), III-1-9, IX-2-20  
 Software, II-1-3  
     capabilities, II-3-1  
     modules, II-1-3  
 Source files, X-9-1  
 Source programs, VII-3-1  
 Space, IV-1-2, VII-1-10  
 Space, allocation, X-2-3  
 Space character, VII-7-2  
 Special BATCH commands,  
     VIII-2-2, VIII-3-1  
 Spacing forward,  
     files, VI-8-9  
     records, VI-8-10  
 Spacing forward to EOT, VI-8-8  
 Specifying environment, XII-4-3  
 Specifying tape format, VI-8-6  
 SPY, V-2-55  
 SPYREL, V-2-55  
 SPYSET, V-2-57  
 Square brackets, ([ ]), VII-1-10,  
     X-2-5  
 Starting AD conversion, VI-14-12  
 Starting block number, VII-10-2  
 STATUS, TDV Function task, VII-23-1

INDEX (CONT.)

- STOP command, VIII-4-8
- STOP Statements, VII-2-4
- Stopping AD conversion, VI-14-12
- Storage of display file, X-2-2
- Storage of scope images, X-6-1
- Storage overhead, X-2-3
- STROBE, IV-2-66
- Strobe system dequeues, IV-2-66
- Structures description VII-6-13
- Subpicture routines, X-2-1
- Subroutines calling conventions, X-2-2
- Subroutines, XI-6-3
- Summary of routines, X-B-1
- SUSPEND, V-2-59
- SUSPENDING TASK EXECUTION, V-2-59
- SYMBOL TABLE, VII-3-1
- SYNC (synchronization), X-2-9
- SYNC, IV-2-68, V-2-60
  - faster response, IV-2-34
  - rejection, IV-2-25
- Synchronizing task execution, IV-2-68, V-2-60
- System backup, IV-2-59
- System blocks, VII-11-1
- System build procedures, XII-6-1
- System COMMON blocks, III-1-2, IV-2-46
- System COMMON blocks
  - description, VII-6-10
- System COMMON Blocks
  - Description List (SCDL), IX-2-19
- System Communications Area (SCOM), IV-1-2, IX-2-1
- System configuration, XII-4-1
- System deque listheads, IX-3-6
- System dequeues,
  - list, IV-2-66
  - listing, IV-2-17
  - strobe, IV-2-66
- System directive abbreviations, V-4-2
- System directives, V-2-1
  - table of V-1-4
- System error log, IX-3-3
- System library, VII-6-13
- System lists,
  - permanent, III-1-8
  - transient, III-1-8
- System lists and organization, II-4-2
- System macros, V-3-1
- System management, II-4-1, VIII-5-1
- System organization, III-1-1
- System parameters, IX-3-2
- System pointers, IX-3-1
- System program,
  - core size, III-A-1
- System resources, XI-1-2, XI-4-2
- System status, VII-23-1
- System subroutines, XI-6-3
- System Task List (STL), II-1-4, III-1-9, IV-2-2, IV-2-12, IV-2-60, IX-2-21
- System tasks, III-1-14
- System transients, III-1-14
- System reconfiguration,
  - on-line, II-1-1
- TABLE INITIALIZATION, VII-2-4
- Tape,
  - dismounting, VI-8-12, VI-8-13
  - mounting, VI-8-12
- Tape label,
  - read, VI-8-11
  - write, VI-8-11
- Task,
  - aborting I/O for, VI-2-5, VI-6-5
  - activating execution, V-2-42
  - activation, II-1-4
  - adding, IV-2-35
  - breakpoints, VII-22-1
  - cancelling request for, IV-2-13
  - deleting, IV-2-54
  - disabling, IV-2-25, V-2-10
  - exit, VI-1-3
  - fixing, IV-2-34, V-2-22
  - installing, IV-2-15
  - reenabling, IV-2-30, V-2-14
  - requesting execution, V-2-37
  - requesting execution from user disk, V-2-16
  - resuming execution, V-2-40
  - returning name of, V-2-65
  - scheduling execution, V-2-47
  - size, V-2-36
  - suspending execution, V-2-59
  - synchronizing execution, V-2-60
  - terminating execution, V-2-19
- Task Builder, II-3-3, VII-6-1
  - input/output, VII-6-4
  - options, VII-6-5
- Task building,
  - CONSTRUCT, VII-19-1
  - DECTAPE DIRECTORY LIST, VII-11-2
  - DELETE FILE, VII-8-1
  - DIRECTORY LIST, VII-10-2
  - DISMOUNT, VII-17-1
  - FILE INPUT, VII-7-3
  - INSTALL, VII-13-1
  - MOUNT, VII-16-1
  - NEW DECTAPE DIRECTORY, VII-12-1
  - parameters, III-B-1
  - QUEUE, VII-21-3
  - REMOVE, VII-15-1
  - RENAME FILE, VII-9-2
  - REQUEST, VII-14-1
  - STATUS, VII-23-1
- Task development functions (TDV),
  - II-3-3, III-1-5, VII-1-1
  - partitions, III-1-5
  - sources, III-B-9
- Task development, on-line, II-3-2
- Task execution, II-1-3.1, II-1-5
  - activating, IV-2-57
  - requesting, IV-2-32, IV-2-55
  - resuming, IV-2-56
  - scheduling, IV-2-61
  - suspending, IV-2-56
  - synchronizing, IV-2-68

INDEX (CONT.)

Task exit, IX-3-7, XI-1-2  
 Task interruption, II-1-5  
 Task level, II-1-4  
 Task list, IV-2-70  
     active, II-1-4  
     system, II-1-4  
 Task name, VII-6-8  
 Task priority, XI-4-2  
 Task scheduling, II-1-3  
     example, II-1-5, II-1-6  
 Task size, user, III-1-7  
 Task Termination Notice  
     Request List (TNRL),  
     III-1-9, V-1-3, IX-2-24  
 Task size, XI-6-2  
 Task status, IX-2-4  
 Task storage on disk, VI-19-1  
 Tasks, II-1-3  
     adding, XII-5-1  
     system, III-1-14  
 TDV command conventions,  
     VII-1-9  
 TDV command line,  
     transferring, V-2-73  
 TDV error messages, VII-7-5  
 TDV function task example,  
     XI-3-3  
 TDV function tasks, VII-1-2, VII-1-9  
 TDV/system communication,  
     VII-1-8  
 TDV task construction, XI-3-1  
 TDV terminal, VI-9-4  
 Terminal characteristics,  
     VI-9-1  
 Terminal handler parameters,  
     IX-3-4  
 Terminal handler task, IV-1-2  
 Terminal I/O, VI-9-1  
     functions, VI-9-4  
 Terminals, XII-3-7  
     supported, IV-2-29  
 Terminating batch processing, VIII-2-3  
 Terminating task execution,  
     V-2-19  
     (terminator), VII-1-10  
 Terminators, command string,  
     VII-1-9  
 Text Editor, II-3-3  
     other versions of, VII-4-3  
 Text-editing source code,  
     VII-4-1  
 Text string rotation, X-2-8  
 TEXT subroutine, X-2-5, X-3-4  
 Time,  
     entering, IV-2-31  
     retrieving, IV-2-16  
 Time interval ranges, IV-2-57,  
     IV-2-61, IV-2-68  
 Time limit options, VIII-4-8  
 Time slicing, II-1-2  
     initiating, IV-2-63  
     priority range, IV-2-63  
 TIMFLG, V-2-20  
 Time values, IX-3-3  
 TKB, XII-3-2, XII-3-6  
 TKB errors, VII-6-19  
     recoverable, VII-6-20  
     unrecoverable, VII-6-21  
 TTRACT command, VIII-4-8  
 TNTERN, V-1-3  
 Tracking, X-5-2  
 TRACK routine, X-5-5  
 Transferred files, VII-7-3  
 Transferring data from COMMON  
     block to task, VI-17-3  
 Transferring data from task to  
     COMMON block, VI-17-5  
 Transferring TDV command line,  
     V-2-73  
 Transient,  
     queues, III-1-8  
     system tasks, III-1-14  
 Trigger event variable, XI-4-2  
 Truncation, X-2-5, X-2-11, X-3-2  
 Truncation mark, VII-10-2  
 TSK files, XII-3-3  
 TSKNAM, V-2-65  
 TTY handler,  
     requests, VI-9-4  
     task, VI-9-1  
 TYPE, TDV Function task, VII-7-1  
 Type-in, VI-9-3  
 UC15,  
     errors, VI-10-5  
     operation, VI-10-4, VI-11-3  
 UDC I/O functions, VI-16-2  
 UF handler,  
     requests, VI-16-1  
     task, VI-16-1  
 UFD, VI-3-1, VI-3-4, VII-16-1  
 Unassigned LUNs, IV-2-23  
 UNBLNK subroutine, X-2-14  
 UNFIX, IV-2-73, V-2-67  
 Unichannel,  
     configuration, II-2-5  
     support, I-2-5  
 Unichannel hardware, XII-3-4  
 Unichannel operation, VI-18-4  
 Unichannel space, III-1-6  
 UNIVERSAL DIGITAL CONTROLLER I/O,  
     VI-16-1  
     functions, VI-16-2  
 Unloading tape, VI-12-7  
 UNMARK, V-2-69  
 Unpacking and event variable,  
     VI-6-20  
 Unrecoverable TKB errors,  
     VII-6-21  
 UPKEV, VI-6-20  
 Upper-case characters, VII-1-10  
 Use and allocation of I/O  
     buffers, XI-6-1  
 Use of BATCH, VIII-1-1  
 User,  
     files, VII-11-1  
     partitions, III-1-7  
     task size, III-1-7

INDEX (CONT.)

User disk,  
 dismount, IV-2-27  
 execution from, IV-2-32  
 User file directory (UFD),  
 VI-3-4  
 User mode, III-1-2, III-1-7,  
 XI-3-1  
 core space, III-1-11  
 option, VII-6-7  
 User recovery, VI-8-17  
 Utility functions, II-3-3

Virtual LUNs, V-2-18, V-2-34, VI-1-2  
 Virtual partition size,  
 VII-6-10, XI-6-2  
 VT15 handler, X-D-1  
 VTUNIT routine, X-5-2

WAIT, V-2-70  
 WAIT command, VIII-4-6  
 WAITFOR, V-2-71  
 Waiting for event variable,  
 V-2-71  
 Waiting for next significant  
 event, V-2-70

WREOF, VI-8-25  
 WRITE, VI-2-25, VI-3-18, VI-7-3  
 VI-8-26, VI-9-9, VI-11-3,  
 VI-13-3, VI-18-3, VI-19-2, VIII-6-4  
 WRITE macro, VI-B-1  
 Writing end-of-file mark, VI-8-25  
 Writing output from buffer,  
 VI-3-8, VI-7-3, VI-8-26,  
 VI-9-9, VI-11-3, VI-13-3,  
 VI-19-2  
 Writing tablet example, X-8-3  
 Writing tablet handler, X-8-1  
 Writing tape label, VI-8-11  
 Writing to DECTape, VI-7-6  
 Writing to disk, VI-6-16  
 Writing to I/O device, VI-2-25  
 Writing to tape from user's  
 buffer, VI-8-16

XFRCMD system directive,  
 V-2-73, VII-1-9  
 XVM hardware, XII-3-6  
 XY handler,  
 requests, VI-18-1  
 task, VI-18-1  
 XY plotter I/O, VI-18-1  
 functions, VI-18-1



READER'S COMMENTS

NOTE: This form is for document comments only. Problems with software should be reported on a Software Problem Report (SPR) form.

Did you find errors in this manual? If so, specify by page.

---

---

---

---

---

Did you find this manual understandable, usable, and well-organized? Please make suggestions for improvement.

---

---

---

---

---

Is there sufficient documentation on associated system programs required for use of the software described in this manual? If not, what material is missing and where should it be placed?

---

---

---

---

---

Please indicate the type of user/reader that you most nearly represent.

- Assembly language programmer
- Higher-level language programmer
- Occasional programmer (experienced)
- User with little programming experience
- Student programmer
- Non-programmer interested in computer concepts and capabilities

Name \_\_\_\_\_ Date \_\_\_\_\_

Organization \_\_\_\_\_

Street \_\_\_\_\_

City \_\_\_\_\_ State \_\_\_\_\_ Zip Code \_\_\_\_\_

or  
Country

If you require a written reply, please check here.

Please cut along this line.

-----  
- Fold Here -  
-----

-----  
Do Not Tear - Fold Here and Staple  
-----

FIRST CLASS  
PERMIT NO. 33  
MAYNARD, MASS.

BUSINESS REPLY MAIL  
NO POSTAGE STAMP NECESSARY IF MAILED IN THE UNITED STATES

Postage will be paid by:

**digital**

Software Communications  
P. O. Box F  
Maynard, Massachusetts 01754

