

Sampling Basics(1B)

-
-

Copyright (c) 2009, 2010, 2011 Young W. Lim.

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.2 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts. A copy of the license is included in the section entitled "GNU Free Documentation License".


Please send corrections (or suggestions) to youngwlim@hotmail.com.

This document was produced by using OpenOffice and Octave.


Measuring Rotation Rate

Angular Speed (Frequency)

$$\omega = \frac{2\pi}{T} = 2\pi f$$



$+\omega_0$ rad / 1 sec



$-\omega_0$ rad / 1 sec

$+\omega_0$ (rad/sec)

$-\omega_0$ (rad/sec)

RPM


rpm = revolutions / minute

$$\begin{aligned} 1 \text{ rpm} &= 2\pi \text{ rad} / 1 \text{ min} \\ &= 2\pi \text{ rad} / 60 \text{ sec} \\ &= \frac{\pi}{30} \text{ rad/sec} \end{aligned}$$

← • **Negative Angles**

Angular Frequency and Sinusoid


Time Domain




$$\omega_0 = \frac{2\pi}{T_0}$$

$$\begin{aligned} x(t) &= A \cos(\omega_0 t) \\ &= \frac{A}{2} e^{j\omega_0 t} + \frac{A}{2} e^{-j\omega_0 t} \end{aligned}$$

Frequency Domain




For 1 second



$+\omega_0$ (rad/sec)


For 1 second




$-\omega_0$ (rad/sec)

Angular Speed Examples


$+\omega_0$ (rad/sec)




$+2\omega_0$ (rad/sec)




$+3\omega_0$ (rad/sec)



$+4\omega_0$ (rad/sec)




$+5\omega_0$ (rad/sec)




Negative Angles


$-\omega_0$ (rad/sec)




$-2\omega_0$ (rad/sec)




$-3\omega_0$ (rad/sec)




$-4\omega_0$ (rad/sec)



$-5\omega_0$ (rad/sec)



Co-terminal Angles



Angular Speed and Frequency



$$\omega = \frac{2\pi}{T} = 2\pi f$$

T (sec)	0.01 sec	0.1 sec	1 sec	10 sec	100 sec
f (Hz)	100 Hz	10 Hz	1 Hz	0.1 Hz	0.01 Hz
ω (rad/sec)	200π (rad/sec)	20π (rad/sec)	2π (rad/sec)	0.2π (rad/sec)	0.02π (rad/sec)
	= 628	= 62.8	= 6.28	= 0.628	= 0.0628


Sampling

continuous-time signals

$$x(t) = A \cos(\omega_0 t)$$



discrete-time sequence



Sampling Time

$$T_s (= \tau)$$

Sequence Time Length

$$T = N \cdot T_s$$

Sampling Frequency

$$f_s = \frac{1}{T_s} \text{ (samples / sec)}$$



Signal's Frequency

$$f_0 = \frac{1}{T_0} \text{ (cycles / sec)}$$

Sampling Frequency

continuous-time signals

$$x(t) = A \cos(\omega_0 t)$$



For 1 second

$$\frac{1}{T_s} \text{ (samples / sec)}$$

For 1 sample

$$1 \text{ (samples) / } T_s \text{ (sec)}$$

For 1 second

$$\frac{1}{T_0} \text{ (cycles / sec)}$$

For 1 cycle

$$1 \text{ (cycles) / } T_s \text{ (sec)}$$

Sampling Time

$$T_s (= \tau)$$

Sequence Time Length

$$T = N \cdot T_s$$


Sampling Frequency

$$f_s = \frac{1}{T_s} \text{ (samples / sec)}$$

Signal's Frequency


$$f_0 = \frac{1}{T_0} \text{ (cycles / sec)}$$

Angular Frequencies in Sampling



$$\omega_0 = 2\pi f_0$$

$$f_0 = \frac{1}{T_0}$$




$$\omega_s = 2\pi f_s$$

$$f_s = \frac{1}{T_s}$$

continuous-time signals


For 1 second

$$\omega_0 = 2\pi f_0 \text{ (rad/sec)}$$



For 1 revolution


$$2\pi \text{ (rad)} / T_0 \text{ (sec)}$$



sampling sequence


For 1 second

$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$





For 1 revolution

$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$



Dimensionless Sequence

$x[n] \rightarrow \dots, x[0], x[1], x[2], x[3], x[4], x[5], x[6], x[7], x[8], \dots$



The same sequence

*Infinite number of
continuous time signals*

Sampling



*The same discrete-time
sequence*

Sampling of Sinusoid Functions

$$x(t) = A \cos(\omega t + \phi)$$

$$\downarrow t \rightarrow n T_s$$

$$x[n] = x(n T_s)$$

$$= A \cos(\omega \cdot n T_s + \phi)$$

$$= A \cos(\omega \cdot T_s n + \phi)$$


$$= A \cos(\hat{\omega} \cdot n + \phi)$$

$$\hat{\omega} = \omega \cdot T_s = \frac{\omega}{1/T_s}$$


$$\hat{\omega} = \frac{\omega}{f_s} = 2\pi \frac{f}{f_s}$$

↑ ↑
Normalized to f_s

Normalized Radian Frequency




Normalized Radian Frequency (1)



Normalized Radian Frequency
can be viewed as
“the angular displacement of a signal
during the period of its sample time T_s ”


- **Negative Angles**
→ folding
- **Co-terminal Angles**
→ periodic

Normalized Radian Frequency (2)



$$\omega_0 = 2\pi f_0$$

$$f_0 = \frac{1}{T_0}$$




$$\omega_s = 2\pi f_s$$

$$f_s = \frac{1}{T_s}$$

For 1 revolution


$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$



sampling sequence

For T_s second

$$\hat{\omega} = \omega_0 \cdot T_s \text{ (rad/sample)}$$




continuous-time signals

$$\hat{\omega} = \omega T_s$$

$$\hat{\omega} = \frac{\omega}{f_s}$$


Signal's relative angle position after each of T_s second

Normalized Radian Frequency (3)



$$\omega_0 = 2\pi f_0$$

$$f_0 = \frac{1}{T_0}$$



$$\omega_s = 2\pi f_s$$

$$f_s = \frac{1}{T_s}$$

Normalized Frequency

$$\frac{f_0}{f_s} \frac{(\text{cycle / sec})}{(\text{sample / sec})} \quad \rightarrow \quad \frac{f_0}{f_s} \text{ (cycle / sample)}$$

Normalized Radian Frequency

$$2\pi \frac{(\text{rad})}{(\text{cycle})} \cdot \frac{f_0}{f_s} \frac{(\text{cycle})}{(\text{sample})} \quad \rightarrow \quad \frac{\omega_0}{f_s} \text{ (rad / sample)}$$


$$f \in \left[-\frac{f_s}{2}, \quad +\frac{f_s}{2} \right]$$

$$\frac{f}{f_s} \in \left[-\frac{1}{2}, \quad +\frac{1}{2} \right]$$

$$\hat{\omega} \in \left[-\pi, \quad +\pi \right]$$

Normalized Radian Frequency (4)

$$x(t) = A \cos(\omega_0 t)$$





$$\omega_0 = 2\pi f_0$$


$$f_0 = \frac{1}{T_0}$$

$$\omega_s = 2\pi f_s$$

$$f_s = \frac{1}{T_s}$$




$$\hat{\omega} = +\pi \text{ (rad/sample)}$$



$$\hat{\omega} = -\pi \text{ (rad/sample)}$$

Sampling



$$\begin{array}{cc} + & - \\ \omega_p - \omega_n = 2\pi \end{array}$$

$$\begin{array}{cc} + & - \\ \omega_p = 2\pi + \omega_n \end{array}$$

$$\begin{array}{cc} - & + \\ \omega_n = \omega_p - 2\pi \end{array}$$

Sampling

$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$

$$A \cos(\omega_1 t + \phi)$$

$$A \cos(\omega_2 t + \phi)$$




$$\omega_1 = \frac{\omega_s}{2}$$

$$\omega_2 = \frac{\omega_s}{4}$$

$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$

$$\hat{\omega} = \pi \text{ (rad)}$$

$$\hat{\omega} = \frac{\pi}{2} \text{ (rad)}$$



- Negative Angles**

$$\hat{\omega} = -\pi \text{ (rad)}$$

$$\hat{\omega} = -\frac{3\pi}{2} \text{ (rad)}$$

$$\omega_1 = -\frac{\omega_s}{2}$$

$$\omega_2 = -\frac{3\omega_s}{2}$$

Sampling

$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$


$$A \cos(\omega_1 t + \phi)$$

$$A \cos(\omega_2 t + \phi)$$


$$\omega_1 = \frac{\omega_s}{2}$$

$$\omega_2 = \frac{\omega_s}{4}$$


$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$



$$\hat{\omega} = \pi \text{ (rad)}$$



$$\hat{\omega} = \frac{\pi}{2} \text{ (rad)}$$



- Co-terminal Angles**



$$\hat{\omega} = \pi + 2\pi \text{ (rad)}$$

$$\omega_1 = \frac{\omega_s}{2} + \omega_s$$

$$\hat{\omega} = \frac{\pi}{2} + 2\pi \text{ (rad)}$$

$$\omega_2 = \frac{\omega_s}{4} + \omega_s$$

Sampling



$T_s (= \tau)$

$T = NT_s$

Sampling Time

$$T_s$$

Sequence Time Length

$$T = NT_s$$


Sampling Frequency

$$f_s = \frac{1}{T_s}$$

(samples per second)

Sampling

$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$



$$\omega_1 = 2\pi f_1$$

$$\omega_1 = \frac{\omega_s}{2} \text{ (rad/sec)}$$


$$f_1 = \frac{f_s}{2} \text{ (rad/sec)}$$

$$\omega_2 = 2\pi f_2$$


$$\omega_2 = -\frac{\omega_s}{2} \text{ (rad/sec)}$$

$$f_2 = -\frac{f_s}{2} \text{ (rad/sec)}$$


$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$



$$\pi \text{ (rad)} / T_s \text{ (sec)}$$




$$-\pi \text{ (rad)} / T_s \text{ (sec)}$$




Sampling


$$\omega_1 = 2\pi f_1 \text{ (rad/sec)}$$




$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$



$$2\pi \text{ (rad)} / T_s \text{ (sec)}$$



$$\frac{\pi}{2} \text{ (rad)} / T_s \text{ (sec)}$$



For the period of T_s
Angular displacement $\frac{\pi}{2}$ (rad)

$$\begin{aligned} \hat{\omega} &= \omega \cdot T_s \text{ (rad)} \\ &= 2\pi f_1 \cdot T_s \text{ (rad)} \\ &= 2\pi \frac{f_s}{4} \cdot T_s \text{ (rad)} \\ &= \frac{\pi}{2} \text{ (rad)} \end{aligned}$$

Angular Frequencies in Sampling

continuous-time signals


Signal Frequency

$$f_0 = \frac{1}{T_0}$$


Signal Angular Frequency

$$\omega_0 = 2\pi f_0 \text{ (rad/sec)}$$

For 1 second
 $2\pi f_0 \text{ (rad/sec)}$



For 1 revolution
 $2\pi \text{ (rad)}$
 $T_0 \text{ (sec)}$



sampling sequence


Sampling Frequency

$$f_s = \frac{1}{T_s}$$


Sampling Angular Frequency

$$\omega_s = 2\pi f_s \text{ (rad/sec)}$$

For 1 second
 $2\pi f_s \text{ (rad/sec)}$



For 1 revolution
 $2\pi \text{ (rad)}$
 $T_s \text{ (sec)}$



References

- [1] <http://en.wikipedia.org/>
- [2] J.H. McClellan, et al., Signal Processing First, Pearson Prentice Hall, 2003
- [3] A “graphical interpretation” of the DFT and FFT, by Steve Mann